



SIE/C815412 SC
DESCRIPTION
INFORMATION

I/O COMMUNICATION SYSTEM FOR *Memocon-SC*TM

MEMOLINK


MASTER MODULE TYPE JAMSC-B1084

SLAVE MODULE TYPE JAMSC-B1085


I/O SLAVE MODULE TYPE DISCT-J2040

USER'S MANUAL

This manual describes MEMOLINK specifications, programming, and external wiring needed to design MEMOLINK (I/O communication) system among Programmable Controller Memocon-SCs (PCs).



Master Module
Type JAMSC-B1084



Slave Module
Type JAMSC-B1085



I/O Slave Module
Type DISCT-J2040

CONTENTS

1. INTRODUCTION	1
2. SPECIFICATIONS	3
2.1 PERFORMANCE SPECIFICATIONS	3
2.2 NUMBER OF LINKS	4
3. HARDWARE CONFIGURATION AND OPERATION	5
3.1 LIST OF COMPONENTS	5
3.2 SYSTEM CONFIGURATION	6
3.3 MASTER MODULE (JAMSC-B1084)	7
3.4 SLAVE MODULE (JAMSC-B1085)	11
3.5 I/O SLAVE MODULE (DISCT-J2040)	14
4. DATA LINK	15
4.1 NUMBER OF LINK POINTS	15
4.2 CONNECTION OF B1084 AND B1085	16
4.3 CONNECTION OF B1084 AND J2040	24
4.4 PROCESSING TIME	29
5. OPERATION OF PROGRAMMING PANEL	38
5.1 P190 PROGRAMMING PANEL	38
5.2 P150 PROGRAMMING PANEL	84
6. OPERATIONAL PROCEDURES	149
6.1 OPERATION START	149
6.2 OPERATION STOP	150
6.3 TROUBLESHOOTING	152
7. OPERATIONAL PRECAUTIONS	158
7.1 BACKUP FUNCTION IN POWER FAILURE	158
7.2 POWER SUPPLY CAPACITY	158
7.3 EXTERNAL POWER SUPPLY FOR OPTICAL CONNECTORS	161
7.4 MASTER MODULE MOUNTING POSITION	161
8. OPTICAL FIBER CABLES	162
8.1 INTERMODULE CONNECTIONS	162
8.2 SPECIFICATIONS OF OPTICAL FIBER CABLES	163
8.3 OPERATIONAL PRECAUTIONS FOR OPTICAL FIBER CABLE	164
8.4 OPTICAL FIBER CABLE INSTALLATION	165
9. DIMENSIONS in mm	168
APPENDIX J2040 REGISTER SERVICE	171

INDEX

Subject	Section	Page	
A			
Actual Allocation Examples	4.2.5	21	
Actual Allocation Examples	4.3.4	27	
B	BACKUP FUNCTION IN POWER FAILURE	7.1..... 158	
	Battery Replacement	6.3.5	156
C	CONNECTION OF B 1084 AND B1085	4.2	16
	CONNECTION OF B 1084 AND J2040	4.3	24
	Controller Operation	5.1.6	70
	Controller Operation	5.2.6	116
D	Data Exchange with PCs	2.2.1	4
	Data Flow	4.4.2	30
	DATA LINK	4	15
	DIMENSIONS in mm	9	168
	Dump/Load/Verify of Allocation Data	5.1.7	73
E	EXTERNAL POWER SUPPLY FOR OPTICAL CONNECTORS	7.3	161
F	File Management Operation	5.2.9	129
H	Hard Copy	5.1.9	79
	HARDWARE CONFIGURATION AND OPERATION	3	5
I	INTERMODULE CONNECTIONS	8.1	162
	Interrupt Input	3.3.3	8
	INTRODUCTION	1.....	1
	I/O Slave Module Check	6.3.3	154
	I/O SLAVE MODULE (DISCT-J2040)	3.5	14
	I/O Slave Unit	4.3.1	24
J	J2040 REGISTER SERVICE	APPENDIX ..	171
L	Link Data	2.2.2	4
	Link Data	4.1.2	15
	Link Data Allocation	4.2.2	17
	Link Data Allocation	4.3.3	26
	Link Data Allocation	5.1.3	42
	Link Data Allocation	5.2.3	89
	Link Data Disable Operation	5.1.5	66
	Link Data Disable Operation	5.2.5	112
	Link Data Monitor	5.1.4	53
	Link Data Monitor	5.2.4	100
	LIST OF COMPONENTS	3.1.....	5
M	Master Module Checking	6.3.1	152
	MASTER MODULE (JAMSC-B1084)	3.3	7
	MASTER MODULE MOUNTING POSITION	7.4.....	161
	Master PC I/O Allocation	4.2.3	19
	MEMOBUS Address Switch	3.3.6	10
	MEMOLINK Address Switch	3.4.4	13
	MEMOLINK Operation Flow	5.1.1	38
	MEMOLINK Operation Flow	5.2.1	84

INDEX (Cont'd)

Subject	Section	Page
MEMOLINK Operation Stop	6.2.1	150
Memory Protect Switch	3.3.7	10
Module Status Display	3.3.2	8
Modules Status Display	3.4.1	11
Module Status Display	3.5.1	14
N		
Number of Input and Output Points	4.1.1	15
NUMBER OF LINK POINTS	4.1	15
NUMBER OF LINKS	2.2	4
Numerical Display	3.3.1	7
O		
OPERATIONAL PRECAUTIONS	7	158
OPERATIONAL PRECAUTIONS FOR OPTICAL FIBER CABLE	8.3	164
OPERATIONAL PROCEDURES	6	149
OPERATION OF PROGRAMMING PANEL	5	38
OPERATION START	6.1	149
OPERATION STOP	6.2	150
Optical Connector Power	3.4.6	13
Optical Connectors	3.4.5	13
OPTICAL FIBER CABLE INSTALLATION	8.4	165
OPTICAL FIBER CABLES	8	162
P		
PC Stop	6.2.2	150
PERFORMANCE SPECIFICATIONS	2.1	3
Power OFF	6.2.3	150
POWER SUPPLY CAPACITY	7.2	158
Preparation	5.1.2	40
Preparation	5.2.2	86
Printing	5.2.10	146
P190 PROGRAMMING PANEL	5.1	38
P150 PROGRAMMING PANEL	5.2	84
PROCESSING TIME	4.4	29
R		
Reference No.	4.2.1	16
Reference No.	4.3.2	25
S		
Save/Load/Verify of Allocation Data	5.2.7	119
Setting Port Parameters	5.1.8	77
Setting Port Parameters	5.2.8	127
Slave Module Check	6.3.2	153
SLAVE MODULE (JAMSC-B1085)	3.4	11
Slave PC I/O Allocation	4.2.4	20
SPECIFICATIONS	2	3
SPECIFICATIONS OF OPTICAL FIBER CABLES	8.2	163
Status Output	3.3.5	9
Status Output	3.4.3	12
Status Reading	6.3.4	155
SYSTEM CONFIGURATION	3.2	6
T		
Terminal Connector	3.3.4	9
Terminal Connector	3.4.2	12
Transmission Delay Time	4.4.1	29
TROUBLESHOOTING	6.3	152

1. INTRODUCTION

The MEMOLINK system provides I/O data communications among Programmable Controller Memocon-SCs (PCs). As a result, it reduces wiring and simplifies building of a distributed control system.

The system requires a master module (JAMSC-B1084), slave modules (JAMSC-B1085) and an I/O slave module (DISCT-J2040). Mutual connection among PCs* is possible by using B1084 and B1085 via optical fiber cables.

The PC mounted with the master module is called the master PC and the PC mounted with the slave module is called the slave PC. The master PC and master module together are called the master station, and the slave PC and slave module together are called the slave station.

Both the master and slave modules are I/O modules, and several MEMOLINK networks can be built to the extent that the I/O space permits.

Remote I/O is possible by using B1084 and J2040. J2040 is a slave of the MEMOLINK and can be used in any station of the 31 slave stations. The 2000 Series I/O† is used as an I/O module.

* Memocon-SC R84 not included.

† Only discrete, register and analog modules available.

1. INTRODUCTION (Cont'd)




Fig. 1.1 Conventional Mutual Connection among Memocon-SCs (PCs)

WIRING REDUCED




Fig. 1.2 MEMOLINK System




Fig. 1.3 Remote I/O

2. SPECIFICATIONS

2.1 PERFORMANCE SPECIFICATIONS

Table 2.1 Performance Specifications

Item	Specifications
Data Rate	1 Mbps
Communication Mode	Half duplex, bit serial
Synchronization	Bit synchronization
Transmission Control	Multi-point polling method
Cable Length	1 km max between stations
No. of Stations	32 max (1 master station, 31 slave stations)
Code	CMI
Frame Format	Complying with HDLC
Error Detection	CCITT-CRC (generator polynomial $X^6 + X^{12} + X^3 + 1$) Time-out
Fail-safe Function	Self-detaching on self-diagnostic error
Optical Fiber Connector	DC9007 (HITACHI, Ltd.), bi-directional
Optical Fiber	CA9003 Type SI compound glass, two-core Core diameter: 200 μm Clad diameter: 250 μm (See Table 8.1)
Transmission Loss of Optical Fiber Cable	24 dB/km max ($\lambda = 0.85 \mu\text{m}$) (See Table 8.1.)
Transmitted Level	-17 dB m to -11 dB m (peak value)
Received Level	-32 dB m to 11 dB m (peak value)
Operating Temperature	0 to 55°C
Storage Temperature	-20 to +75 °C
Humidity	5 to 95% RH (no-condensing)
Vibration	Complying with JIS C0911
Shock Resistance	Complying with JIS C0912 (10 G applied 3 times in each direction of X, Y, Z)
Ambient Condition	No inflammable or corrosive gases or no excessive dust

2.2 NUMBER OF LINKS

2.2.1 Data Exchange with PCs

MEMOLINK modules are PC I/O modules. PCs exchange discrete and register data in accordance with I/O allocation of the PCs. I/O allocations to the module equipment positions are allocations of link data to the PC side. By allocating I/O points for links, the number of I/O points is reduced correspondingly.

Table 2.2 No. of Data to be Exchanged with PC

Master Module	Discrete Input (DI) Discrete Output (DO) Register Input (RI) Register Output (RO)	256 points max (allocated in increments of 8 points) 256 points max (allocated in increments of 8 points) 16 sets max (allocated in increments of 1 reg) 16 sets max (allocated in increments of 1 reg)
Sieve Module	Discrete Input (DI) Discrete Output (DO) Register Input (RI) Register Output (RO)	128 points max (allocated in increments of 8 points) 128 points max (allocated in increments of 8 points) 8 sets max (allocated in increments of 1 reg) 8 sets max (allocated in increments of 1 reg)

Note: When viewed from the PC, input and output data terminate/originate at the PC. One set of registers has 16 bits.

2.2.2 Link Data

The maximum number of I/O data occurs when I/O data allocated to the different modules (mentioned earlier) are distributed to all stations as link data.

- (1) Discrete data
 $256 + 128 \times 31 = 4224$ points
- (2) Register data
 $16 + 8 \times 31 = 264$ registers

Note: Allocation of maximum I/O points and maximum link data as mentioned above is possible.

3. HARDWARE CONFIGURATION AND OPERATION

Tables 3.1, 3.2 and 3.3 list the components comprising the MEMOLINK system. Select the necessary components in accordance with your PC system.

3.1 LIST OF COMPONENTS

Where building a standard MEMOLINK system with B1084 and B1085, refer to Table 3.1. For a remote I/O system using J2040, refer to Table 3.2.

Table 3.1 List of PC System Components

Type	Application
JAMSC-B1084	MEMOLINK master module
JAMSC-B1085	MEMOLINK slave module
JAMSI-B1036	I/O mounting base for U84S CPU
JARMSI-B1037	I/O mounting base for U84S CPU (ASCII applicable)
JRMSI-B1033	Local I/O mounting base for U84S
JRMSI-B1027	Expansion mounting base
JRMSI-B1028	Expansion mounting base (for auxiliary power)
JRMSI-B1034	Remote I/O mounting base
JRMSI-B1026	I/O mounting base for R84H CPU
JRMSP-P8101	Main power supply module for U84
JRMSP-P8052	Auxiliary power supply module
JRMSP-P8051	Main power supply module for R84H (power supply module for remote I/O)
JRMSP-P8054	Auxiliary power supply module
JRMSP-P8601	Main power supply module for U84S

Table 3.2 List of Remote I/O Components

Type	Application
DISCT-J2040	MEMOLINK I/O slave module
JRMSI-MB20	I/O mounting base
JRMSP-PS21	Power supply module
JAMSC-B2×××	2000 Series I/O module (discrete, register, analog)

Table 3.3 List of Peripheral Units

Type	Application
DISCT-P190	Programming panel
DISCT-P150	Programming panel
T190-S002	MEMOLINK programmer tape for P190
T190-000	Blank tape for P190
F150-002	MEMOLINK programmer floppy for P150
F150-000	Blank disc for P150
JZMSZ-W1015	Communication cable for programming panel (for P190)
JZMSZ-W1015-T1	Communication cable for programming panel (for P150)

3.2 SYSTEM CONFIGURATION

Fig. 3.1 shows an example of the MEMOLINK system configuration.




Fig. 3.1 An Example of System Configuration

- ① B1084 is mounted on the mounting base of 1000 Series I/O.
- ② B1085 is mounted on the mounting base of 1000 Series I/O.
- ③ J2040 is mounted on the mounting base (MB20) of 2000 Series I/O.
- ④ The Programming Panel P150 or P190 offers monitoring, disable and I/O allocation of the data in any station. The panel is connected to the B1084 MEMOBUS communication port using specified cable.

3.3 MASTER MODULE (JAMSC-B1084)

This module is used as a master module of the MEMOLINK. The PC with a master module is called a master PC. A combination of a master PC and master module is called a master station.




Fig. 3.2 Master Module
Type JAMSC-B1084

3.3.1 Numerical Display

Two-digit numerical display is offered.

Fig. 3.3 Two-digit Numerical Display




Table 3.4 lists the meaning of numerical displays. The module status indication LED blinks simultaneously with the code indication.

Table 3.4 Numerical Display

Display	Meaning
00 (00)	Normal
01 to 31 (E1)	Indicates the slave station address in communication error. The smallest number is shown if multiple communication errors.
E1 (E1)	System ROM error
E2 to E4 (E2)	System RAM error
E5 (E5)	MEMOBUS port parameter error
E6 (E6)	MEMOLINK allocation data and/or disable data error
E7 (E7)	WDT (Watchdog timer) error
E8 (E8)	MEMOLINK communication ROM error
E9 (E9)	MEMOLINK communication RAM error

Note: MEMOBUS port parameter error display is shown alternately with the previous display every 0.5 second.

(E5 → E1)

3.3.2 Module Status Display

The LED blinks to indicate the module operation status.

Fig. 3-4 Module Status Display

READY	—	○	○	—	I/F ACTIVE
RXD	—	○	○	—	MASTER OK
TXD	—	○	○	—	SLAVE OK
COMM ERR	—	○	○	—	BATT ALARM

Table 3.5 Module Status Display

Status	Indication	Color
READY	Normal in self diagnosis	Green
RXD	Master module receives MEMOLINK data.	Green
TXD	Master module transmits MEMOLINK data.	Green
COMM ERR	Error in MEMOLINK communication. Turned off when MEMOLINK communication is stopped by programming panel.	Red
I/F ACTIVE	Data exchanged with PC	Green
MASTER OK	Almost the same with I/F ACTIVE	Green
SLAVE OK	Normal communication with allocated slaves.	Green
BATT ALARM	Battery voltage reduced	Red

3.3.3 Interrupt Input

The status of input signals at eight points which are input directly from the external devices are shown.

If the interrupt inputs changes, the master module preferentially transmits this information to all the slaves at the same time. Therefore, these interrupt inputs will be useful if there is a common interlock signal that requires urgent action.




Fig. 3.5 Interrupt Input Status Display

Fig. 3.6 Input Circuit

Table 3.6 Electrical Specifications of Interrupt Input

Item	Specifications
No. of Circuits	8
Rated Voltage	24 VDC (19 to 29 V)
Input Current	Approx. 10 mA (at 24 V)
Operating Voltage	ON level: 11 V or more (across common and input terminals) OFF level: 8 V or less (across common and input terminals)
Response Time	OFF → ON: 10 ms max ON → OFF: 10 ms max
Input Indication	LED (red) ON at Input ON
Isolation	Optical coupler
Dielectric Strength	1500 VAC for a minute
Supply Current at 24 V (Bias Current)	All input points OFF: 1 mA max All input points ON: 100 mA max

3.3.4 Terminal Connector

Fig. 3.7 shows terminal connections of the master module. Refer to Pars. 3.3.3 and 3.3.5 for input and output, respectively.




Fig. 3.7 Terminal Connector Connection

3.3.5 Status Output

"MASTER OK" and "SLAVE OK" are interlocked to the module status display LEDs of the same names (Refer to Par. 3.2.2).

Table 3.7 ON Condition

Output	ON Condition	Terminal
MASTER OK	Data exchanged with PC	A6
SLAVE OK	Normal communication with allocated slaves	B6

Table 3.8 Electrical Specifications of Status Output

Item	Specifications
No. of Circuits	2
Rated Voltage	24 VDC (19 to 29 V)
Max Output Current	300 mA/point, 600 mA/two points (continued)
Leakage Current at OFF	1 mA max
ON Voltage	1 V max (at 300 mA)
Response Time	OFF → ON: 1 ms max ON → OFF: 1 ms max
Transient Voltage	35 V (peak value)
Peak Surge Current	1 A (10 ms)
Output Form	Transistor output (open collector)
Isolation	Optical coupler
Dielectric Strength	1500 VAC for a minute
Fuse	None
Output Indication	LED (green) ON at output ON

3.3.5 Status Output (Cont'd)




Fig. 3.8 Output Circuit

3.3.6 MEMOBUS Address Switch

The switch sets address for each MEMOBUS port.




Fig. 3.9 MEMOBUS Address Switch

Addresses 1 to F can be set. To change an address partway through an operation, set the switch at the desired address and depress the reset switch.

3.3.7 Memory Protect Switch

Setting the memory protect switch to ON prohibits a change in allocation or status of a coil, etc.




Fig. 3.10 Memory Protect Switch

3.4 SLAVE MODULE (JAMSC-B1085)

This is a MEMOLINK slave module. The PC with a slave module is called slave PC, and a set of a slave PC and slave module(s) is called a slave station.




Fig. 3.11 Slave Module Type JAMSC-B1085

3.4.1 Modules Status Display

The LED blinks to indicate the module operation status.

READY		I/F ACTIVE
RXD		SLAVE OK
TXD		EXT PWR OK
COMM ERR		

Fig. 3.12 Module Status Display

Table 3.9 Module Status Indication

Status	Indication	Color
READY	Normal in self diagnosis.	Green
RXD	Slave module receives MEMOLINK data.	Green
TXD	Slave module transmits MEMOLINK data.	Green
COMM ERR	Error in MEMOLINK communication (transmit error). Turned off when MEMOLINK communication stops.	Red
I/F ACTIVE	Data exchanged with PC.	Green
SLAVE OK	Normal MEMOLINK communication. Data exchanged with PC.	Green
EXT PWR OK	External power provided.	Green

3.4.2 Terminal Connector

Fig. 3.13 shows terminal connections of the slave module. Refer to Par. 3.4.3 for output (A1). The 24 VDC external power between A4 and A5 (refer to Par. 3.4.6) is used for the MEMOLINK optical connector.




Fig. 3.13 Terminal Connector Connections

3.4.3 Status Output

This is output for "SLAVE OK" and interlocks with the module status indication LED of the same name (Refer to Par. 3.4.1).

Table 3.10 ON Condition

Output	ON Condition	Terminal
SLAVE OK	Normal in MEMOLINK communication. Data communicated with PC.	A1

Table 3.11 Electrical Specifications of Status Output

Item	Specifications
No. of Circuits	1
Rated Voltage	24 VDC (19 to 30 V)
Max Output Current	300 mA/point (continued)
Leakage Current at OFF	1 mA max
ON Voltage	1 V min (at 300 mA)
Response Time	OFF → ON: 1 ms max ON → OFF: 1 ms max
Transient Voltage	35 V (peak value)
Peak Surge Current	1 A (10 ms)
Output Form	Transistor output (open collector)
Isolation	Optical coupler
Dielectric Strength	1500 VAC for a minute
Fuse	None
Output Indication	LED (green) ON at output ON




Fig. 3.14 Output Circuit

3.4.4 MEMOLINK Address Switch

This switch sets slave module addresses (station Nos.) 01 to 09, 10, 11 to 19, 20, 21 to 29, 30 and 31. Connection from the master to slave stations is performed in a multi-drop mode.




Fig. 3.15 MEMOLINK Address Switch




Fig. 3.16 Master and Slave Station Connection

Slave station addresses do not have to be set sequentially beginning with the station which is closest to the master station. It is important not to set the same addresses. However, from the standpoint of maintenance, sequential numbering "01, 02, ... and 31" beginning with the slave station closest to the master station is preferable.

3.4.5 Optical Connectors

One slave module has two optical connectors. Optical fiber cables are connected to them to build a MEMOLINK transmission circuit.




Fig. 3.17 Optical Connectors

Connect the UPWARD optical connector to the upstream side (master station side). Connect the DOWNWARD optical connector to the downstream side (next slave side). The DOWNWARD connector of the final slave station should not be connected with an optical fiber cable. Mount a protective cap on it.

Each station is connected in a multi-drop mode. A broken optical fiber cable or an optical connector power failure along the line completely stops communications with the downstream slave stations.

As mentioned in Par. 3.4.2, power for the optical connectors is supplied from the outside.

3.4.6 Optical Connector Power

Table 3.12 Power Specifications of Optical Connector

Item	Specifications
Input Voltage	21.6 to 26.4 VDC
Input Current	50 mA
Protective Fuse	1 A

3.5 I/O SLAVE MODULE (DISCT-J2040)

This is a MEMOLINK I/O slave module (J2040) used to build a remote I/O system. Actually, the module is combined with the master module B1084. A slave station with J2040 is one of the 31 slave stations.




Fig. 3.18 I/O Slave Module Type DISCT-J2040

3.5.1 Module Status Display

READY○○	I/O ACTIVE
RXD○○	SLAVE OK
TXD○○	T-COP ERR
COMM ERR○○	I/O BUS ERR

Fig. 3.19 Module Status Display

Table 3.13 Module Status Indication

Status	Indication	Color
READY	Normal in self diagnosis.	Green
RXD	Slave module receives MEMOLINK data.	Green
TXD	Slave module transmits MEMOLINK data.	Green
COMM ERR	Error in MEMOLINK communication (transmit error). Turned off when MEMOLINK communication stops.	Red
I/O ACTIVE	I/O service is performed.	Green
SLAVE OK	Normal in MEMOLINK communication.	Green
T-COP ERR	Mismatch in allocation and module size.	Red
I/O BUS ERR	Error in I/O bus.	Red

Note: For MEMOLINK address switch and optical connector, refer to Pars. 3.4.4 and 3.4.5.

4. DATA LINK

MEMOLINK system does not require a special program and a change of the PC itself. The only necessary information is "FROM - TO" wiring information.

"Use output data of PC of A as input data of PC of B."

The wiring information is registered in the master module as "Link data allocation." Both master (B1084) and slave (B1085) modules are 1000 Series I/O modules, and normal I/O allocation is performed with PCs of each station. For I/O slave module (J2040), I/O allocation is not required.

4.1 NUMBER OF LINK POINTS

4.1.1 Number of Input and Output Points

The master module (B1084) and slave module (B1085) are I/O modules of the PC. The PC exchanges discrete and register data in accordance with the individual I/O allocations of each PC. Allocation of I/O slots for MEMOLINK modules is of link data in the PC side. The number of I/O points is reduced by allocation of I/O for the link.

I/O is not allocated with the I/O slave module (J2040). The number of I/O points to be used corresponds to them of the slave module.

Table 4.1 No. of I/O Points

Master Module	Discrete Input (DI)	256 points max (allocated in increments of 8 points)
	Discrete Output (DO)	256 points max (allocated in increments of 8 points)
	Register Input (RI)	16 regs max (allocated in increments of 1 reg)
	Register Output(RO)	16 regs max (allocated in increments of 1 reg)
Slave Module	Discrete Input (DI)	128 points max (allocated in increments of 8 points)
	Discrete Output (DO)	128 points max (allocated in increments of 8 points)
	Register Input (RI)	8 regs max (allocated in increments of 1 reg)
	Register Output(RO)	8 regs max (allocated in increments of 1 reg)
I/O Slave Module	Discrete Input (DI)	128 points max (allocated in increments of 8 points)
	Discrete Output (DO)	128 points max (allocated in increments of 8 points)
	Register Input (RI)	8 regs max (allocated in increments of 1 reg)
	Register Output(RO)	8 regs max (allocated in increments of 1 reg)

An identification for input and output is defined from the PC side. One register contains 16 bits.

4.1.2 Link Data

The maximum number of link data is obtained under the following conditions:

- Master and slave modules — where distributing, to all stations, I/O data allocated to each module as link data.
- I/O slave module — where distributing, to all stations, I/O data equalling to the size of the I/O module installed in the rack as link data.

The each maximum number for discrete and register modules is as follows:

- Discrete data — 4224 points ($256 + 128 \times 31$)
- Register data — 264 regs ($16 + 8 \times 31$)

4.1.2 Link Data (Cont'd)

The number of link data points depends on link data allocation.

The maximum link data that can be allocated to each slave stations as follows:

- Discrete data: 128 points
- Register data: 8 regs

4.2 CONNECTION OF B1084 AND B1085

4.2.1 Reference No.

Link data allocation is wiring information between input and output. It is performed by giving information: "Connect the output of PC of A to the input of PC of B."

Link data are assigned with reference Nos. for identification to clear wiring information.

Table 4.2 Reference Numbers

Data		Module → PC		PC → Module	
Master/ Slave	Station No.	Discrete	Register	Discrete	Register
Master	00	60001 to 60256	80001 to 80016	50001 to 50256	90001 to 90016
Slave	01 to 31	60001 to 60128	80001 to 80008	50001 to 50128	90001 to 90008

Note:

1. A module is B1084 or B1085.
2. Reference Nos. "70001 to 70008" of interrupt signals are called up in the master module.
Interrupt signals can be allocated to any station as input relays.

Table 4.3 Relations to References

PC	Output Coil	Output Register	Input Relay	Input Register
PC	0 xxxx to 0 xxxx + 8 × n ₁ - 1	4 xxxx to 4 xxxx + n ₂ - 1	1 xxxx to 1 xxxx + 8 × n ₃ - 1	3 xxxx to 3 xxxx + n ₄ - 1
Data Flow	↓	↓	↑	↑
Module	50001 to 50000 + 8 × n ₁ - 1	90001 to 90000 + n ₂	60001 to 60000 + 8 × n ₃ or 70001 to 70008	80001 to 80000 + n ₄
Data Flow	↓	↓	?	?
Module	60 xxx to 60 xxx + 8 × n ₁ - 1 or 70001 to 70008	8000 x to 8000 x + n ₂ - 1	50 xxx to 50 xxx + 8 × n ₃ - 1	9000 x to 9000 x + n ₄ - 1
Data Flow	↓	↓	↑	^
PC	1 xxxx to 1 xxxx + 8 × n ₁ - 1	3 xxxx to 3 xxxx + 8 × n ₂ - 1	0 xxxx to 0 xxxx + 8 × n ₃ - 1	4 xxxx to 4 xxxx + n ₄ - 1
	Input Relay	Input Register	Output Coil	Output Register

Note: n₁, n_{1'}, n₂, n_{2'}, n₃, n_{3'}, n₄, n_{4'} are determined by allocation.

4.2.2 Link Data Allocation

Link data are allocated by designating data (5xxxx and 7xxxx) from the station using data (6xxxx and 8xxxx) to be transferred to its PC as a standard. Allocation is performed for each station. Data from the station are called "FROM" data.

(1) Discrete Data Allocation

Allocation is made in units of 8 points. FROM data are designated using station Nos. and reference data. Interrupt signal is allocated finally for the station.

Table 4.4 Master Station Allocation

Master PC Input Reference	Master Module Reference	FROM Data	
		Station No.	Reference
1 0 0 9 7 to 1 0 1 0 4	6 0 0 0 1 to 6 0 0 0 3	0 1	5 0 0 1 7 to 5 0 0 2 4
1 0 1 0 5 to 1 0 1 1 2	6 0 0 0 9 to 6 0 0 1 6	0 3	5 0 0 0 1 to 5 0 0 0 8
1 0 1 1 3 to 1 0 1 2 0	6 0 0 1 7 to 6 0 0 2 4	0 5	5 0 0 0 1 to 5 0 0 0 8
1 0 1 2 1 to 1 0 1 2 8	6 0 0 2 5 to 6 0 0 3 2	0 2	5 0 1 2 1 to 5 0 1 2 8
.	.	.	.
.	.	.	.
1 0 3 1 3 to 1 0 3 2 0	6 0 2 1 7 to 6 0 2 2 4	3 1	5 0 0 2 5 to 5 0 0 3 2
1 0 3 2 1 to 1 0 3 2 8	6 0 2 2 5 to 6 0 2 3 2	0 0	7 0 0 0 1 to 7 0 0 0 8
—	6 0 2 3 3 to 6 0 2 4 0	—	No allocation
—	6 0 2 4 1 to 6 0 2 4 8	—	No allocation
—	6 0 2 4 9 to 6 0 2 5 6	—	No allocation

Table 4.5 Slave Station Allocation

Slave PC Input Reference	Slave Module Reference	FROM Data	
		Station No.	Reference
1 0 0 1 7 to 1 0 0 2 4	6 0 0 0 1 to 6 0 0 0 8	0 0	5 0 0 0 1 to 5 0 0 0 8
1 0 0 2 5 to 1 0 0 3 2	6 0 0 0 9 to 6 0 0 1 6	0 1	5 0 0 1 7 to 5 0 0 2 4
1 0 0 3 3 to 1 0 0 4 0	6 0 0 1 7 to 6 0 0 2 4	0 4	5 0 1 1 3 to 5 0 1 2 0
1 0 0 4 1 to 1 0 0 4 8	6 0 0 2 5 to 6 0 0 3 2	0 3	5 0 0 0 1 to 5 0 0 0 8
.	.	.	.
.	.	.	.
1 0 1 0 5 to 1 0 1 1 2	6 0 0 8 9 to 6 0 0 9 6	3 0	5 0 1 2 1 to 5 0 1 2 8
1 0 1 1 3 to 1 0 1 2 0	6 0 0 9 7 to 6 0 1 0 4	0 0	7 0 0 0 1 to 7 0 0 0 8
—	6 0 1 0 5 to 6 0 1 1 2	—	No allocation
—	6 0 1 1 3 to 6 0 1 2 0	—	No allocation
—	6 0 1 2 1 to 6 0 1 2 8	—	No allocation

Note:

1. Interrupt signal (70001 to 70008) does not have to be allocated.
2. More allocation is not allowed behind interrupt signal (70001 to 70008).

4.2.2 Link Data Allocation (Cont'd)

(2) Register Allocation

Registers are allocated in units of one register. "FROM" data is designated using the station.

No. and reference data.

Table 4.6 Master Station Allocation

Master PC Input Reference	Master Module Reference	FROM Data	
		Station No.	Reference
3 0 0 0 3	8 0 0 0 1	0 1	9 0 0 0 2
3 0 0 0 4	8 0 0 0 2	0 3	9 0 0 0 2
3 0 0 0 5	8 0 0 0 3	0 0	9 0 0 0 1
3 0 0 0 6	8 0 0 0 4	0 4	9 0 0 0 7
.	.	.	.
.	.	.	.
.	.	.	.
3 0 0 1 6	8 0 0 1 4	2 9	9 0 0 0 3
—	8 0 0 1 5	—	No allocation
—	8 0 0 1 6	—	No allocation

Table 4.7 Slave Station Allocation

Slave PC Input Reference	Slave Module Reference	FROM Data	
		Station No.	Reference
3 0 0 0 9	8 0 0 0 1	0 0	9 0 0 1 1
3 0 0 1 0	8 0 0 0 2	0 1	9 0 0 0 7
3 0 0 1 1	8 0 0 0 3	0 2	9 0 0 0 6
3 0 0 1 2	8 0 0 0 4	0 7	9 0 0 0 3
3 0 0 1 3	8 0 0 0 5	0 5	9 0 0 0 2
—	8 0 0 0 6	—	No allocation
—	8 0 0 0 7	—	No allocation
—	8 0 0 0 8	—	No allocation

4.2.3 Master PC I/O Allocation

I/O allocation has to be made to the PC side for slots mounted with a master module. The size of I/O allocation must coincide with that of link data allocation (see Par. 4.2.2).

Allocation should be made to both left and right slots of the master module. The slot on the left side viewed from the front of the module is called the left slot and that on the right side, right slot. The slot with a newest No. is the left slot and one with an oldest No. is the right slot. Registers must be always allocated in binary.

Table 4.8 No. of Allocation Points

	Left Slot	Right Slot
Input Relay	128 points max (unit of 8 points)	128 points max (unit of 8 points)
Output Coil	128 points max (unit of 8 points)	128 points max (unit of 8 points)
Input Register	8 regs max (unit of 1 reg)	8 regs max (unit of 1 reg)
Output Register	8 regs max (unit of 1 reg)	8 regs max (unit of 1 reg)

By justifying to the left slot, the allocation must be performed to match the data amount to be allocated as link data.

Example:

Allocation will be as shown in Table 4.9.

Input relay: 232 points

Output coil: 128 points

Input register: 14 regs

Output register: 7 regs

Table 4.9 Allocation Example

	PC		Module
Input Relay	Left Slot	1 0 0 9 7 to 1 0 2 2 4 (1 2 8 points)	6 0 0 0 1 to 6 0 1 2 8
	Right Slot	1 0 2 2 5 to 1 0 3 2 8 (1 0 4 points)	6 0 1 2 9 to 6 0 2 3 2
Output Coil	Left Slot	0 0 0 0 9 to 0 0 1 3 6 (1 2 8 points)	5 0 0 0 1 to 5 0 1 2 8
	Right Slot	(0)	—
Input Register	Left Slot	3 0 0 0 3 to 3 0 0 1 0 (8 regs)	8 0 0 0 1 to 8 0 0 0 8
	Right Slot	3 0 0 1 1 to 3 0 0 1 6 (6 regs)	8 0 0 0 9 to 8 0 0 1 4
Output Register	Left Slot	4 0 0 0 1 to 0 0 0 0 7 (7 regs)	9 0 0 0 1 to 9 0 0 0 7
	Right Slot	(0)	—

I/O references on the PC side are actually used in the PC ladder. The No. to be set differs depending on the module mounting position and system. References on the module side cannot be used in the ladder, because of references only for connection.

4.2.4 Slave PC I/O Allocation

I/O allocation has to be made to the PC side for slots mounted with slave modules. The size of I/O allocation must coincide with that of link data allocation (see Par. 4.2.2).

The slave module size is two spans of 1000 series I/O modules. Input and output are allocated only to the left slot. Allocation to the right slot becomes invalid.

Table 4.10 No. of Allocation Points

	Left Slot	Right Slot
Input Relay, Output Coil	128 points max (unit of 8 points)	No allocation
Input Register, Output Register	8 reg ^s max (unit of 1 reg)	

Registers must be always allocated in binary.

Example:

Allocation will be as shown in Table 4.11

Input relay: 128 points

Output coil: 64 points

Input register: 8 reg^s

Output register: 5 reg^s

Table 4.11 Allocation Example

PC		Module
Input Relay	Left Slot	1 0 0 3 3 to 1 0 1 6 0 (1 2 8 points)
Output Coil	Left Slot	0 0 0 1 7 to 0 0 0 8 0 (1 2 8 points)
Input Register	Left Slot	3 0 0 0 1 to 3 0 0 0 8 (8 reg ^s)
Output Register	Left Slot	4 0 0 0 5 to 4 0 0 0 9 (5 reg ^s)

Note: The right slot is not allocated.

I/O references on the PC side are actually used in the PC ladder. The No. to be set differs depending on the module mounting position and system. References on the module side cannot be used in the a ladder, because of references only for connection.

4.2.5 Actual Allocation Examples

Using simple models, transmission of data of each station to destination stations is shown. Only the connection part is described. There are one master and two slave stations. To simplify the explanation, discrete data only is considered. Tables 4.12 to 4.14 show station allocation. Fig. 4.1 shows ladders.

Table 4.12 Master Station Allocation

Master PC	Master Module			
	Reference	Station No.	FROM Reference	
Input Relay	1 0 0 1 7 to 1 0 0 2 4	6 0 0 0 1 to 6 0 0 0 8	0 1	5 0 0 0 1 to 5 0 0 0 8
	1 0 0 2 5 to 1 0 0 3 2	6 0 0 0 9 to 6 0 0 1 6	0 2	5 0 0 0 1 to 5 0 0 0 8
	1 0 0 3 3 to 1 0 0 4 0	6 0 0 1 7 to 6 0 0 2 4	0 0	7 0 0 0 1 to 7 0 0 0 8
Output Coil	0 0 0 0 9 to 0 0 0 1 6	5 0 0 0 1 to 5 0 0 0 8		
	0 0 0 1 7 to 0 0 0 2 4	5 0 0 0 9 to 5 0 0 1 6		

Table 4.13 Slave Station No. 1 Allocation




Slave PC	Slave Module			
	Reference	Station No.	FROM Reference	
Input Relay	1 0 0 0 1 to 1 0 0 0 8	6 0 0 0 1 to 6 0 0 0 3	0 0	5 0 0 0 1 to 5 0 0 0 8
	1 0 0 0 9 to 1 0 0 1 6	6 0 0 0 9 to 6 0 0 1 6	0 2	5 0 0 0 1 to 5 0 0 0 8
	1 0 0 1 7 to 1 0 0 2 4	6 0 0 1 7 to 6 0 0 2 4	0 0	7 0 0 0 1 to 7 0 0 0 8
Output Coil	0 0 1 2 9 to 0 0 1 3 6	5 0 0 0 1 to 5 0 0 0 8		

4.2.5 Actual Allocation Examples (Cont'd)

Table 4.14 Slave Station No. 2 Allocation

Slave PC	Reference	Slave Module	
		FROM Station No.	Reference
Input Relay	1 0 0 4 1 to 1 0 0 4 8	6 0 0 0 1 to 6 0 0 0 8	0 1 5 0 0 0 1 to 5 0 0 0 8
	1 0 0 4 9 to 1 0 0 5 6	6 0 0 0 9 to 6 0 0 1 6	0 0 5 0 0 0 9 to 5 0 0 1 6
	1 0 0 5 7 to 1 0 0 6 4	6 0 0 1 7 to 6 0 0 2 4	0 0 7 0 0 0 1 to 7 0 0 0 8
Output Coil	0 0 0 5 7 to 0 0 0 6 4	5 0 0 0 1 to 5 0 0 0 8	—

Interrupt signal (70001 to 70008) does not have to be allocated. Assume that the master and slave PCs have the following ladders:



Note: AA, BB, and CC do not have a direct relationship with link data.

Fig. 4.1 Ladder of Each Station

Signals will be connected as follows.




Fig. 4.2

The operation in the example of ladders shown in Fig. 4.1 will be as follows:

- ① Output coil 00129 is turned on as BB of slave station No. 1 goes on.
- ② Output coil 00129 of slave station No. 1 goes to input relay 10017 of the master station and input relay 10041 of slave station No. 2. As a result, output coil 00010 of the master station and output coil 00060 of slave station No. 2 are turned on.
- ③ 00010 of the master station goes to 10002 of slave station No. 1 and 00060 of slave station No. 2 goes to 10012 of slave station No. 1.
- ④ Output coil 00129 of the master station is turned off. Therefore, if the state of 00129 of slave station No. 1 changes from ON to OFF, it means that this signal has transferred to the master station and slave station No. 2.

NOTE

One scan pulse of each PC is hardly transferred.

4.3 CONNECTION OF B1084 AND J2040

4.3.1 I/O Slave Unit

(1) Unit Configuration

The I/O slave unit consists of only one rack. Therefore, this rack can mount a maximum of eight 2000 Series I/O modules.

The I/O slave unit can access discrete, register, and analog modules. The I/O module can be installed in any of the eight slots.

However, for ease of wiring and maintenance, the layout is recommended to be arranged by grouping whenever possible, such as grouping inputs and outputs, voltage levels, and applications, and by filling the slots consequently from slot 1.

Fig. 4.3 shows an example of I/O module layout.

POWER SUPPLY	I/O SLAVE	SLOT 1 REGISTER INPUT	SLOT 2 REGISTER INPUT	SLOT 3 24 VDC INPUT	SLOT 4 24 VDC INPUT	SLOT 5 ANALOG INPUT	SLOT 6 REG STEP OUTPUT	SLOT 7 24 VDC OUTPUT	SLOT 8 ANALOG OUTPUT

Fig. 4.3 Example of I/O Module Layout

(2) I/O Processing

Fig. 4.4 shows the sequence for input and output processing of the I/O slave module. Individual processing is performed by the module mounted with the slot with a low slot No. Care should be taken when laying out the I/O modules.




Fig. 4.4 I/O Processing Sequence

4.3.2 Reference No

Link data allocation gives information for connecting I/O's, one after another. It is performed by giving information: "Connect the output of PC of A to the input of PC of B." Where both of A and B are I/O slave units, replace the PC in above information with the I/O module and consider the link data allocation.

Link data are assigned with reference Nos. for identification to clear wiring information.

Table 4.15 Reference Numbers

Data		J2040→Input Module		Output Module→J2040	
Type	Station No.	Discrete	Register	Discrete	Register
I/O Slave	01 to 31	60001 to 60128	80001 to 80008	50001 to 50128	90001 to 90008

Table 4.16 Relations to Reference

	Output Coil	Output Register	Input Relay	Input Register
PC	0 xxxx to 0 xxxx - 8 × n ₁ - 1	4 xxxx to 4 xxxx + n ₂ - 1	1 xxxx to 1 xxxx + 8 × n ₃ - 1	3 xxxx to 3 xxxx + n ₄ - 1
Data Flow	↓	↑	↑	↑
B 1085 B 1084	50001 to 50000 - 8 × n ₁	90001 to 90000 + n ₂	60001 to 60000 + 8 × n ₃	80001 to 80000 - n ₄
Data Flow	↓	↓	↑	↑
J 2040	60xxx to 60xxx + 8 × n' ₁ - 1	8000x to 8000x + n' ₂ - 1	50xxx to 50xxx + 8 × n' ₃ - 1	9000x to 9000x + n' ₄ - 1
Data Flow	↓	↓	↑	↑
I/O Module	Discrete output	Register output	Discrete input	Register input

Note: n₁, n'₁, n₂, n'₂, n₃, n'₃, n₄, n'₄ are determined by allocation.

4.3.3 Link Data Allocation

Link data is allocated by designating data (5XXXX, 9XXXX) to be received from the other station using data (6XXXX, 8XXXX) to be given to the I/O module as a reference.

Allocation is made in units of one station. The size of attached module and link data allocation must coincide, or the allocation must be smaller.

(1) Discrete Data Allocation

Allocation is made in units of 8 points. "FROM" data are designated using station Nos. and reference data. Interrupt signal is allocated finally for the station.

Table 4.17 Slave Station (J2040) Allocation

I/O Slave Module Reference	FROM Data	
	Station No.	Reference
60001 to 60008	00	50017 to 50024
60009 to 60016	05	50001 to 50008
60017 to 60024	06	50001 to 50008
60025 to 60032	01	50113 to 50120
.	.	.
.	.	.
.	.	.
60089 to 60096	31	50009 to 50016
60097 to 60104	20	50121 to 50128
60105 to 60112	.	No allocation
60113 to 60120	—	No allocation
60121 to 60128	—	No allocation

Note:

1. Interrupt signal (70001 to 70008) does not have to be allocated.
2. More allocation is not allowed behind interrupt signal (70001 to 70008).

(2) Register Allocation

Registers are allocated in units of one register. "FROM" data is designated using the station No. and reference data.

Table 4.18 Slave Station (J2040) Allocation

I/O Slave Module Reference	FROM Data	
	Station No.	Reference
80001	00	90012
80002	08	90007
80004	15	90001
80005	07	90004
80006	—	No allocation
80007	—	No allocation
80008	—	No allocation

NOTE

Discrete module can be used as register by J2040. For detailed information, Refer to APPENDIX J2040 REGISTER SERVICE.

4.3.4 Actual Allocation Examples

Assume one master station and one slave station. The slave station is an I/O slave module.




Fig. 4.5 Connection Relationship between B1084 and J2040

- ① I/O allocation of the master module (B1084) is programmed in the master PC.
- ② Program the link data allocation of the master module and I/O slave (J2040) in the master module.

I/O modules must be installed in the I/O slave's mounting base as shown in Fig. 4.6.




Fig. 4.6 Example of I/O Module Layout

4.3.4 Actual Allocation Examples (Cont'd)

Tables 4.19 and 4.20 show allocation for each station:

Table 4.19 Master Station Allocation

Master PC	Master Module		
	Reference	FROM	
		Station No.	Reference
Input Relay	10009 to 10016 30004	60009 to 60016 80001	01 01 50017 to 50024 90001
Output Coil	00001 to 00008 00033 to 00040	50009 to 50016 50017 to 50024	—

Table 4.20 Slave Station No.1 Allocation

I/O Module	I/O Slave Module		
	Reference	FROM	
		Station No.	Reference
32-Discrete Outputs	60001 to 60008	00	50009 to 50016
	60009 to 60016	00	50017 to 50024
32-Discrete Inputs	50017 to 50024	—	
8-Register Inputs	90001	—	

Note: For I/O module, refer to Fig. 4.6.

This allocation enables transmission from the master output to the I/O slave input, and from the I/O slave output to the master input.

4.4 PROCESSING TIME

4.4.1 Transmission Delay Time

Table 4.21 presents the maximum transmission delay time between stations.

Table 4.21 Maximum Transmission Delay Time

Data Flow	Max Transmission Delay Time
Master PC → Slave PC	Master PC 1 scan + 2 × transmission processing time + slave PC 1 scan
Slave PC → Master PC	Slave PC 1 scan + 2 × transmission processing time + master PC 1 scan
Slave PC No. i → Slave PC No. j	Slave PC No. i 1 scan + 3 × transmission processing time + slave PC No. j 1 scan
Interrupt Input → Master PC	Master PC 1 scan
Interrupt Input → Slave PC	10 ms + slave PC 1 scan
Master PC → I/O Slave	Master PC 1 scan + 2 × transmission processing time + 10 ms
I/O Slave → Master PC	10 ms + 2 × transmission processing time + master PC 1 scan
I/O Slave → I/O PC	10 ms + 3 × transmission processing time + slave PC 1 scan
I/O Slave → I/O Slave	10 ms + 3 × transmission processing time + 10 ms

Transmission processing time is the time for one cycle to exchange (send and receive) data with all the stations. Communication processing of the MEMOLINK is not synchronized to scanning of the PCs of each station.

$$\text{Transmission Processing Time} = \sum_{i=1}^n \lceil \frac{\text{Max.}(I_i + 16, O_i) + 120}{128} \rceil \times \frac{\sum_{i=1}^n (I_i + O_i)}{256} \times 1.2 + 0.4 \\ \times (\text{No. of slaves}) - 6.8 \text{ ms}$$

where i : slave station No.

I_i: number of bits from all slave stations to master station

O_i: number of bits from master station to all slave stations

Max (A, B): Whichever is larger between A and B

Number of data bits = number of discrete points
+ number of registers × 16

⌈x⌉=maximum integer not exceeding x. Example ⌈1.9⌉=1

NOTE

PC 1 scan means from logic solving to actual I/O module accessing.

Therefore, conversion coefficients differ between PCs that perform logic solving and I/O service serially (as in the R84H type) and those that perform in parallel (as in the U84 type).

Table 4.22 Conversion Coefficients

	R84H	U84, Local I/O	U84, Remote I/O
PC 1 Scan	1	2	3

4.4.2 Data Flow

(1) Master PC and MEMOLINK Communication

Fig. 4.7 shows one scan of the Master PC and MEMOLINK communications. One scan of master PC and MEMOLINK communications are asynchronous.




Fig. 4.7 Data Flow

Fig. 4.7 shows data flow between the master station and slave modules. MEMOLINK communications are provided only to those slaves that are actually allocated. Therefore, the MEMOLINK communication cycle becomes shorter as the number of allocated slave stations becomes smaller.

(2) Master PC to Slave PC

Fig. 4.8 shows the data flow from the master PC to the slave PC when there is one slave station. The flow is the same even when there are several slave stations.




Fig. 4.8 Data Flow

4.4.2 Data Flow (Cont'd)

(3) Slave PC to Master PC

Fig. 4.9 shows the data flow from the slave PC to the master PC when there is one slave station. The flow is the same even when there are several slave stations.




Fig. 4.9 Data Flow

(4) Slave PC to Slave PC

Fig. 4.10 shows the data flow from one slave PC to other slave PCs. The data from the slave PCs is temporarily collected in the master station and is distributed to the slave stations in accordance with the allocation.




Fig. 4.10 Data Flow

4.4.2 Data Flow (Cont'd)

(5) Master PC to I/O Slave

Fig. 4.11 shows the data flow from the master PC to the I/O slave when there is one slave station.




Fig. 4.11 Data Flow

(6) I/O Slave to Master PC

Fig. 4.12 shows the data flow from the I/O slave to the master PC when there is one slave station.





Fig. 4.12 Data Flow

4.4.2 Data Flow (Cont'd)

(7) I/O Slave to Slave PC

Fig. 4.13 shows the data flow from one I/O slave to one slave PC. The data from the I/O slave is temporarily collected in the master station and is distributed to each station in accordance with the allocation.



Note:

1. Status changed at "X" position.
2. I/O processing cycle: 10 ms min.

Fig. 4.13 Data Flow

(8) I/O Slave to I/O Slave

Fig. 4.14 shows the data flow from one I/O slave to other I/O slaves. The data from the I/O slave is temporarily collected in the master station and distributed to each station in accordance with the allocation.




Fig. 4.14 Data Flow

5. OPERATION OF PROGRAMMING PANEL

Data of each MEMOLINK station are allocated, monitored, and put into disable operation through P190 programming panel or P150 programming panel.

5.1 P190 PROGRAMMING PANEL

5.1.1 MEMOLINK Operation Flow




Fig. 5.1.1

NOTE

1. For normal operation, set the switches as shown below, to prevent errors.

P190 key switch: ON

MEMOLINK master module memory protect switch: ON

2. In program mode, all operations are possible.

When MEMOLINK is operating, however, the asterisked operations cannot be accomplished.

3. In monitor mode, the operations in are not possible.

4. The keys are classified as follows:

: CRT label keys

: Function keys, such as numeric, fixed function, cursor control, and ASCII keys.

5. Eight labels displayed on the screen indicate the functions of the eight keys (CRT label keys: F1 to F8) located at a top of the keyboard.

5.1.2. Preparation

Performing ATTACH operation makes data communication between the P190 and the MEMOLINK master module possible.





Fig. 5.1.2



Fig. 5.1.3

Program mode: All program operations possible.
Monitor mode: Memory contents cannot be changed.
This protects memory contents from being erased inadvertently.

Table 5.1.1

Operation Module	P190 Key
Program	OFF
Monitor	ON




Fig. 5.1.4

NOTE

1. When INIT and INIT LOCK are depressed simultaneously, the state becomes the same as when power is initially supplied to the P190. This can be used to load another tape in the P190 while operating.
2. When a MEMOLINK program tape is removed, place it in the tape container, and store in the specified place.
3. When LOGOUT is depressed (see Fig. 5.1.4) or when the P190 key switch is set first to on and then off, the original state is restored (same as prior to installation).

PRECAUTIONS

1. Plug the P190 power cord into a properly grounded 100 VAC receptacle.
2. Connect the P190 and MEMOLINK master before connecting to power.
3. Turn off power to the P190 before disconnecting the P190 and MEMOLINK master.

5.1.3 Link Data Allocation

MEMOLINK allocation is carried out by loading connection information "Use 'A' PC output data as 'B' PC input data" into the master module.




Fig. 5.1.5





Fig. 5-1-6

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
 2. When "PREVIOUS MENU" key is depressed, the state returns to the state as shown in Fig. 5.1.5.
 3. See Section 4 for detailed allocation.

(1) Typical Allocation of Discrete Input in Master Station

Discrete data are allocated in increment of 8 points. Allocation is loaded by setting the station number to STATION and the last three digits (001 to 249) of the first reference numbers to AR and depressing "SET DISCRETE" key. It is not necessary to allocate interrupt signals (70001 to 70008).




Fig. 5.1.8


UNIT : 1				STATION : 00 AR : 00000		
MASTER DIN	MASTER RIN	SLAVE INPUT	OUTPUT			PREVIOUS MENU

Fig. 5.1.7

# MASTER DISCRETE INPUT #							
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	1	INHIBIT	60129-60136	1	INHIBIT	60137-60144	1
60009-60016	1	INHIBIT	60145-60152	1	INHIBIT	60153-60160	1
60017-60024	1	INHIBIT	60161-60168	1	INHIBIT	60169-60176	1
60025-60032	1	INHIBIT	60177-60184	1	INHIBIT	60185-60192	1
60033-60040	1	INHIBIT	60193-60200	1	INHIBIT	60201-60208	1
60041-60048	1	INHIBIT	60209-60216	1	INHIBIT	60217-60224	1
60049-60056	1	INHIBIT	60225-60232	1	INHIBIT	60233-60240	1
60057-60064	1	INHIBIT	60241-60248	1	INHIBIT	60249-60256	1
60065-60072	1	INHIBIT					
60073-60080	1	INHIBIT					
60081-60088	1	INHIBIT					
60089-60096	1	INHIBIT					
60097-60104	1	INHIBIT					
60105-60112	1	INHIBIT					
60113-60120	1	INHIBIT					
60121-60128	1	INHIBIT					

UNIT : 1				STATION : 00 AR : 00000			
SET STATION #	SET DISCRETE	SET DIRECT INPUT		CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU

Fig. 5.1.8



The cursor moves downward to the next legal position.
Fig. 5.1.10


UNIT : 1				STATION : 01 AR : 00017			
SET STATION #	SET DISCRETE	SET DIRECT INPUT		CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU

Fig. 5.1.9

# MASTER DISCRETE INPUT #							
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	01	50017	60129-60136	1	INHIBIT	60137-60144	1
60009-60016	1	INHIBIT	60145-60152	1	INHIBIT	60153-60160	1
60017-60024	1	INHIBIT	60161-60168	1	INHIBIT	60169-60176	1
60025-60032	1	INHIBIT	60177-60184	1	INHIBIT	60185-60192	1
60033-60040	1	INHIBIT	60193-60200	1	INHIBIT	60201-60208	1
60041-60048	1	INHIBIT	60209-60216	1	INHIBIT	60217-60224	1
60049-60056	1	INHIBIT	60225-60232	1	INHIBIT	60233-60240	1
60057-60064	1	INHIBIT	60241-60248	1	INHIBIT	60249-60256	1
60065-60072	1	INHIBIT					
60073-60080	1	INHIBIT					
60081-60088	1	INHIBIT					
60089-60096	1	INHIBIT					
60097-60104	1	INHIBIT					
60105-60112	1	INHIBIT					
60113-60120	1	INHIBIT					
60121-60128	1	INHIBIT					

Fig. 5.1.10

(1) Typical Allocation of Discrete Input in Master Station (Cont'd)



UNIT : 1		STATION : 03 AR : 0000				
SET STATION #	SET DISCRETE	SET DIRECT INPUT	CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU

Fig. 5.1.11




Fig. 5.1.12

* MASTER DISCRETE INPUT *							
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	01	50017	60129-60136	INHIBIT			
60009-60016	03	50001	60137-60144	INHIBIT			
60017-60024	05	50001	60145-60152	INHIBIT			
60025-60032	02	50121	60153-60160	INHIBIT			
60033-60040	04	50025	60161-60168	INHIBIT			
60041-60048	06	50049	60169-60176	INHIBIT			
60049-60056	10	50001	60177-60184	INHIBIT			
60057-60064	10	50009	60185-60192	INHIBIT			
60065-60072	07	50017	60193-60200	INHIBIT			
60073-60080	09	50001	60201-60208	INHIBIT			
60081-60088	10	50001	60209-60216	INHIBIT			
60089-60096	10	50001	60217-60224	INHIBIT			
60097-60104	10	50001	60225-60232	INHIBIT			
60105-60112	10	50001	60233-60240	INHIBIT			
60113-60120	10	50001	60241-60248	INHIBIT			
60121-60128	10	50001	60249-60256	INHIBIT			

Fig. 5.1.12





Fig. 5.1.13

* MASTER DISCRETE INPUT *							
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	01	50017	60129-60136	INHIBIT			
60009-60016	03	50001	60137-60144	INHIBIT			
60017-60024	05	50001	60145-60152	INHIBIT			
60025-60032	02	50121	60153-60160	INHIBIT			
60033-60040	04	50025	60161-60168	INHIBIT			
60041-60048	06	50049	60169-60176	INHIBIT			
60049-60056	10	50001	60177-60184	INHIBIT			
60057-60064	10	50009	60185-60192	INHIBIT			
60065-60072	07	50017	60193-60200	INHIBIT			
60073-60080	09	50001	60201-60208	INHIBIT			
60081-60088	10	50001	60209-60216	INHIBIT			
60089-60096	10	50001	60217-60224	INHIBIT			
60097-60104	10	50001	60225-60232	INHIBIT			
60105-60112	10	50001	60233-60240	INHIBIT			
60113-60120	10	50001	60241-60248	INHIBIT			
60121-60128	10	50001	60249-60256	INHIBIT			

Fig. 5.1.13

2

UNIT : 1		STATION : 07 AR : 00017				
SET STATION #	SET DISCRETE	SET DIRECT INPUT	CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU



* MASTER DISCRETE INPLT *							
REF	ST#	REF		REF	ST#	REF	
60001-60008	01	50017		60129-60136	1	INHIBIT	
60009-60016	03	50001		60137-60144	1	INHIBIT	
60017-60024	05	50001		60145-60152	1	INHIBIT	
60025-60032	02	50121		60153-60160	1	INHIBIT	
60033-60040	04	50025		60161-60168	1	INHIBIT	
60041-60048	06	50049		60169-60176	1	INHIBIT	
60049-60056	10	50001		60177-60184	1	INHIBIT	
60057-60064	10	50000		60185-60192	1	INHIBIT	
60065-60072	07	50017		60193-60200	1	INHIBIT	
60073-60080	00	70001		60201-60208	1	INHIBIT	
60081-60088		INHIBIT		60209-60216	1	INHIBIT	
60089-60096		INHIBIT		60217-60234	1	INHIBIT	
60097-60104		INHIBIT		60225-60232	1	INHIBIT	
60105-60112		INHIBIT		60233-60240	1	INHIBIT	
60113-60120		INHIBIT		60241-60248	1	INHIBIT	
60121-60128		INHIBIT		60249-60256	1	INHIBIT	
UNIT : 1				STATION : 07 AR : 00017			
SET STATION #	SET DISCRETE	SET DIRECT INPUT		CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU

Fig. 5.1.14

NOTE

1. In monitor mode, only label "PREVIOUS" MENU appears.
 2. When "INCREASE" REF + 8 is depressed, the AR content increases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
 3. When "DECREASE" REF - 8 is depressed, the AR content decreases to become $8N - 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
 4. When "CLEAR" PARAMETER is depressed, the allocation at the cursor is cleared.
 5. Once an interrupt signal is allocated, succeeding discrete data cannot be allocated.

(2) Typical Allocation of Register Input in Master Station

Registers are input one by one. Allocation is loaded by setting the station number to STATION and the last two digits (01 to 16) of the reference numbers to AR and depressing "SET" REGISTER.




Fig. 5.1.16

UNIT : 1	STATION : 00 AR : 00000					
MASTER DIN	MASTER R14	SLAVE INPUT	OUTPUT			PREVIOUS MENU

Fig. 5.1.15




Fig. 5.1, 17

UNIT : 1 STATION : DD AR : 00001

SET STATION #		SET REGISTER	CLEAR PARAMETER	INCREASE REF +1	DECREASE REF -1	PREVIOUS MENU
------------------	--	-----------------	--------------------	--------------------	--------------------	------------------

Fig. 5.1, 17




Fig. 5.1.18

* MASTER REGISTER INPUT *			
REF	ST#	REF	REF
80001	00 80001		80009
80002	INHIBIT		80010
80003	INHIBIT		80011
80004	INHIBIT		80012
80005	INHIBIT		80013
80006	INHIBIT		80014
80007	INHIBIT		80015
80008	INHIBIT		80016

Fig. 5.1.18




Fig. 5.1.19

UNIT : 1	STATION : 03 AR : 00002				
SET STATION #	SET REGISTER PARAMETER	CLEAR PARAMETER	INCREASE REF +1	DECREASE REF -1	PREVIOUS MENU

Fig. 5.1.19







Fig. 5.1.20

NOTE

1. In monitor mode, only "PREVIOUS" appears.
MENU
 2. When "INCREASE"
REF + 1 is depressed, the AR content increases by 1.
 3. When "DECREASE"
REF - 1 is depressed, the AR content decreases by 1.
 4. When "CLEAR
PARAMETER" is depressed, the allocation at the cursor is cleared.

(3) Typical Allocation of Discrete Input in Slave Station

Discrete data are allocated in increment of 8 points. Allocation is loaded by setting the station number to STATION and the last three digits (001 to 249) of the first reference numbers to AR and depressing "SET DISCRETE". It is not necessary to allocate interrupt signals (70001 to 70008).



The cursor automatically moves downward to the next legal position.
Fig. 5.1.23

1

UNIT : E				STATION : 00 AR : 00001	
MASTER DIN	MASTER RIN	SLAVE INPUT	OUTPUT		PREVIOUS MENU

Fig. 5.1.21


DISCRETE * SLAVE 01 INPUT *						REGISTER	
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	14H1BIT		80001	14H1BIT			
60009-60016	1NH1BIT		80002	1NH1BIT			
60017-60024	1NH1BIT		80003	1NH1BIT			
60025-60032	1NH1BIT		80004	1NH1BIT			
60033-60040	1NH1BIT		80005	1NH1BIT			
60041-60048	1NH1BIT		80006	1NH1BIT			
60049-60056	1NH1BIT		80007	1NH1BIT			
60057-60064	14H1BIT		80008	14H1BIT			
60065-60072	1NH1BIT						
60073-60080	1NH1BIT						
60081-60088	1NH1BIT						
60089-60096	1NH1BIT						
60097-60104	1NH1BIT						
60105-60112	NH1BIT						
60113-60120	NH1BIT						
60121-60128	NH1BIT						

UNIT : I				STATION : 00 AR : 00001			
SET STATION #	SET DISCRETE	SET DIRECT INPLT	CLEAR PARAMETER	INCREASE REF +8	DECREASE REF -8	PREVIOUS MENU	

Fig. 5.1.22

DISCRETE * SLAVE 01 INPUT *						REGISTER	
REF	ST#	REF	REF	ST#	REF	ST#	REF
60001-60008	00 50001		80001	1NH1BIT			
60009-60016	1NH1BIT		80002	1NH1BIT			
60017-60024	1NH1BIT		80003	1NH1BIT			
60025-60032	1NH1BIT		80004	1NH1BIT			
60033-60040	14H1BIT		80005	14H1BIT			
60041-60048	1NH1BIT		80006	1NH1BIT			
60049-60056	1NH1BIT		80007	1NH1BIT			
60057-60064	1NH1BIT		80008	1NH1BIT			
60065-60072	NH1BIT						
60073-60080	NH1BIT						
60081-60088	NH1BIT						
60089-60096	NH1BIT						
60097-60104	NH1BIT						
60105-60112	NH1BIT						
60113-60120	NH1BIT						
60121-60128	NH1BIT						

Fig. 5.1.23



DISCRETE			# SLAVE 01 INPUT #			REGISTER		
REF	ST#	REF				REF	ST#	REF
60001-60008	00	50001				80001	1NH1BIT	
60009-60016	01	50017				80002	1MH1BIT	
60017-60024	04	50113				80003	1MH1BIT	
60025-60032	03	50001				80004	1NH1BIT	
60033-60040	15	50001				80005	1NH1BIT	
60041-60048	15	50000				80006	1NH1BIT	
60049-60056	14	1BIT				80007	1NH1BIT	
60057-60064	14	1BIT				80008	1NH1BIT	
60065-60072	14	1BIT						
60073-60080	14	1BIT						
60081-60088	1M	1BIT						
60089-60096	1N	1BIT						
60097-60104	1N	1BIT						
60105-60112	1N	1BIT						
60113-60120	1N	1BIT						
60121-60128	1N	1BIT						

Fig. 5.1.24

DISCRETE			* SLAVE 01 INPUT *			REGISTER		
REF	ST#	REF	REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001			80001		INHIBIT
60009-60016	01	50017	80002			80002		INHIBIT
60017-60024	04	50113	80003			80003		INHIBIT
60025-60032	03	50001	80004			80004		INHIBIT
60033-60040	15	50001	80005			80005		INHIBIT
60041-60048	15	50009	80006			80006		INHIBIT
60049-60056	00	70001	80007			80007		INHIBIT
60057-60064	INHIBIT		80008			80008		INHIBIT
60065-60072	INHIBIT							
60073-60080	INHIBIT							
60081-60088	INHIBIT							
60089-60096	INHIBIT							
60097-60104	INHIBIT							
60105-60112	INHIBIT							
60113-60120	INHIBIT							
60121-60128	INHIBIT							

Fig. 5-1-25

NOTE

1. In monitor mode, only "PREVIOUS" MENU appears..
 2. When "INCREASE" REF + 8 is depressed, the AR content increases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
 3. When "DECREASE" REF - 8 is depressed, the AR content decreases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
 4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.
 5. Once an interrupt signal is allocated, succeeding discrete data cannot be allocated.

(4) Typical Allocation of Register Input in Slave Station

Registers are input one by one. Allocation is loaded by setting the station number to STATION and the last two digits (01 to 16) of the reference number to AR and depressing "SET REGISTER".




Fig. 5.1.26




Fig. 5.1.26




Fig. 5.1.27




Fig. 5.1.27




Fig. 5.1.28



Fig. 5.1.28




Fig. 5.1.29




Fig. 5.1.29

1





Fig. 5.1.29



UNIT : 1		STATION : 01 AR : 00007					
SET STATION #			SET REGISTER	CLEAR PARAMETER	INCREASE REF +1	DECREASE REF -1	PREVIOUS MENU

Fig. 5.1.30

DISCRETE \$ SLAVE 01 INPUT #			REGISTER		
REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	00	90011
60009-60016	01	50017	80002	01	90007
60017-60024	04	50113	80003		INHIBIT
60025-60032	03	50001	80004		INHIBIT
60033-60040	15	50001	80005		INHIBIT
60041-60048	15	50009	80006		INHIBIT
60049-60056	00	70001	80007		INHIBIT
60057-60064		INHIBIT	80008		INHIBIT
60065-60072		INHIBIT			
60073-60080		INHIBIT			
60081-60088		INHIBIT			
60089-60096		INHIBIT			
60097-60104		INHIBIT			
60105-60112		INHIBIT			
60113-60120		INHIBIT			
60121-60128		INHIBIT			

Fig. 5.1.31

DISCRETE \$ SLAVE 01 INPUT #			REGISTER		
REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	00	90011
60009-60016	01	50017	80002	01	90007
60017-60024	04	50113	80003	02	90006
60025-60032	03	50001	80004	07	90003
60033-60040	15	50001	80005	05	90002
60041-60048	15	50009	80006		INHIBIT
60049-60056	00	70001	80007		INHIBIT
60057-60064		INHIBIT	80008		INHIBIT
60065-60072		INHIBIT			
60073-60080		INHIBIT			
60081-60088		INHIBIT			
60089-60096		INHIBIT			
60097-60104		INHIBIT			
60105-60112		INHIBIT			
60113-60120		INHIBIT			
60121-60128		INHIBIT			

UNIT : 1		STATION : 02 AR : 00002					
SET STATION #			SET REGISTER	CLEAR PARAMETER	INCREASE REF +1	DECREASE REF -1	PREVIOUS MENU


Fig. 5.1.32

NOTE

1. In monitor mode, only "PREVIOUS" MENU appears.
2. When "INCREASE" REF +1 is depressed, the AR content increases by 1.
3. When "DECREASE" REF -1 is depressed, the AR content decreases by 1.
4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.

(5) Output Allocation Display

Every station number output allocation is indicated.



UNIT : 1		STATION : 00 AR : 00000		
MASTER DIN	MASTER RIN	SLAVE INPUT	OUTPUT	PREVIOUS MENU

Fig. 5.1.33

# OUTPUT #					
STATION	DISCRETE	REGISTER	STATION	DISCRETE	REGISTER
00	008	11	16	000	00
01	024	07	17	000	00
02	008	06	18	000	00
03	008	02	19	000	00
04	120	08	20	000	00
05	008	05	21	000	00
06	056	08	22	000	00
07	024	08	23	000	00
08	000	00	24	000	00
09	000	00	25	000	00
10	016	00	26	000	00
11	000	00	27	000	00
12	000	00	28	000	00
13	000	00	29	000	00
14	000	00	30	000	00
15	016	00	31	000	00

UNIT : 1		STATION : 00 AR : 00000		
				PREVIOUS MENU

Fig. 5.1.34

NOTE

The output allocation display indicates the PC output capacity of each station, corresponding to the number of inputs of discrete data and registers allocated to each station.

5.1.4 Link Data Monitor

(1) Discrete Data Status Indication in Master Station

Discrete data appear in increment of 16 points, as shown below (1 indicates ON; 0 indicates OFF). The underlined numerals are in disabled state. An interrupt signal appears in 8 points

Example: $60001 - 60016 = 1000110001000010$

↑ ↑
60001 60016




Fig. 5.1.35

UNIT : 1	STATION : 00 AR : 00000					
CONTROLLER OPERATIONS	PORT 1	PORT 2	TRAFFIC COP	LOADER OPERATIONS		LOGOUT

** MASTER (STATION 00) DISCRETE MONITOR **

70001-70008 = 00000000	50001-50016 = 0000000000000000
60001-60016 = 0101101001000000	50017-50032 = 0000000000000000
60017-60032 = 0000100000000000	50033-50048 = 0C00000000000000
60033-60048 = 0000010011100000	50049-50064 = 0000000000000000
60049-60064 = 0000000000000000	50085-50080 = 0000000000000000
60065-60080 = 0001000100000000	50081-50096 = 0000000000000000
60081-60096 = 0000000000000000	50097-50112 = 0000000000000000
60097-60112 = 0000000000000000	50113-50128 = 0000000000000000
60113-60128 = 0000000000000000	50129-50144 = 0000000000000000
60129-60144 = 0000000000000000	50145-50160 = 0000000000000000
60145-60160 = 0000000000000000	50161-50176 = 0000000000000000
60161-60176 = 0000000000000000	50177-50192 = 0000000000000000
60177-60192 = 0000000000000000	50193-50208 = 0000000000000000
60193-60208 = 0000000000000000	50209-50224 = 0000000000000000
60209-60224 = 0000000000000000	50225-50240 = 0000000000000000
60225-60240 = 0000000000000000	50241-50256 = 0000000000000000

UNIT : 1 STATION : 00 AR : 00000

SELECT STATION	ENABLE	DISABLE	FORCE ON	FORCE OFF	NEXT MENU	
-------------------	--------	---------	-------------	--------------	--------------	--

Fig. 5.1.36

NOTE

1. This step can be skipped, if ATTACHII operation has already been completed.
 2. In monitor mode, "ENABLE," "DISABLE," "FORCE_{ON}," "FORCE_{OFF}," and small cursor do not appear.
 3. When "SHIFT" and "RESET" _{EXIT} are depressed simultaneously, the display returns to that shown in Fig. 5.1.35.

(2) Indication of Register Contents in Master Station

Initially, the register contents appear in decimal, but can appear in decimal, hexadecimal, binary, or ASCII.




Fig. 5.1.37




Fig. 5.1.39



** MASTER (STATION 00) REGISTER MONITOR **							
	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE	PREVIOUS MENU
80001 = 0000 DECIMAL	90001 = 0000 DECIMAL						
80002 = 0005 DECIMAL	80002 = 0000 DECIMAL						
80003 = 0025 DECIMAL	90003 = 0000 DECIMAL						
80004 = 0000 DECIMAL	90004 = 0000 DECIMAL						
80005 = 0000 DECIMAL	90005 = 0000 DECIMAL						
80006 = 0256 DECIMAL	80006 = 0000 DECIMAL						
80007 = 0000 DECIMAL	90007 = 0000 DECIMAL						
80008 = 1230 DECIMAL	90008 = 0000 DECIMAL						
80009 = 0010 DECIMAL	90009 = 0000 DECIMAL						
80010 = 0000 DECIMAL	90010 = 0000 DECIMAL						
80011 = 0022 DECIMAL	90011 = 0000 DECIMAL						
80012 = 0022 DECIMAL	90012 = 0000 DECIMAL						
80013 = 0000 DECIMAL	90013 = 0000 DECIMAL						
80014 = 0000 DECIMAL	90014 = 0000 DECIMAL						
80015 = 0000 DECIMAL	90015 = 0000 DECIMAL						
80016 = 0000 DECIMAL	90016 = 0000 DECIMAL						

Fig. 5.1.37

MASTER (STATION 00) REGISTER MONITOR

80001 = 0000 HEXADECIMAL	90001 = 0000 DECIMAL
80002 = 0005 DECIMAL	90002 = 0000 DECIMAL
80003 = 0025 DECIMAL	90003 = 0000 DECIMAL
80004 = 0000 DECIMAL	90004 = 0000 DECIMAL
80005 = 0000 DECIMAL	90005 = 0000 DECIMAL
80006 = 0256 DECIMAL	90006 = 0000 DECIMAL
80007 = 0000 DECIMAL	90007 = 0000 DECIMAL
80008 = 1230 DECIMAL	90008 = 0000 DECIMAL
80009 = 0010 DECIMAL	90009 = 0000 DECIMAL
80010 = 0000 DECIMAL	90010 = 0000 DECIMAL
80011 = 0022 DECIMAL	90011 = 0000 DECIMAL
80012 = 0022 DECIMAL	90012 = 0000 DECIMAL
80013 = 0000 DECIMAL	90013 = 0000 DECIMAL
80014 = 0000 DECIMAL	90014 = 0000 DECIMAL
80015 = 0000 DECIMAL	90015 = 0000 DECIMAL
80016 = 0000 DECIMAL	90016 = 0000 DECIMAL

Fig. 5.1.38

```

## MASTER (STATION 00) REGISTER MONITOR ##

80001 = 0000000000000000          90001 = 0000 DECIMAL
80002 = 0005 DECIMAL             90002 = 0000 DECIMAL
80003 = 0025 DECIMAL             90003 = 0000 DECIMAL
80004 = 0000 DECIMAL              90004 = 0000 DECIMAL
80005 = 0000 DECIMAL              90005 = 0000 DECIMAL
80006 = 0256 DECIMAL              90006 = 0000 DECIMAL
80007 = 0000 DECIMAL              90007 = 0000 DECIMAL
80008 = 1230 DECIMAL              90008 = 0000 DECIMAL
80009 = 0010 DECIMAL              90009 = 0000 DECIMAL
80010 = 0000 DECIMAL              90010 = 0000 DECIMAL
80011 = 0022 DECIMAL              90011 = 0000 DECIMAL
80012 = 0022 DECIMAL              90012 = 0000 DECIMAL
80013 = 0000 DECIMAL              90013 = 0000 DECIMAL
80014 = 0000 DECIMAL              90014 = 0000 DECIMAL
80015 = 0000 DECIMAL              90015 = 0000 DECIMAL
80016 = 0000 DECIMAL              90016 = 0000 DECIMAL

```

UNIT : 1




Fig. 5.1.40




Fig. 5.1.40




Fig. 5.1.37

NOTE


1. This step can be skipped, if ATTACH operation has already been completed.
 2. In monitor mode, "ENABLE" and "DISABLE" do not appear. Also, "NEXT" (see Fig. 5.1.39) and small cursor do not appear.
 3. When "PREVIOUS" MENU is depressed, the display returns to that shown in Fig. 5.1.36.

(3) Discrete Status Indication in Slave Station

As in the master module, discrete data appear in increment of 16 points, (1 indicates ON; 0 indicates OFF.) The underlined numerals are in disabled state.

Example: $60001 - 60016 = 1000\underline{1}1000\underline{1}000010$

↑ ↑
60001 60016



UNIT : 1	STATION : 00 AR : 00000			
SELECT STATION	ENABLE	DISABLE	FORCE ON	FORCE OFF
NEXT MENU				

Fig. 5.1.41

## STATION 01 MONITOR ##							
60001-60016 = 0000000000000000	80001 = 0000 DECIMAL						
60017-60032 = 0001011000101000	80002 = 0000 DECIMAL						
60033-60048 = 0000000010000000	80003 = 0017 DECIMAL						
60049-60064 = 0000100100000000	80004 = 0000 DECIMAL						
60065-60080 = 0000000000000000	80005 = 3241 DECIMAL						
60081-60096 = 0000000000000000	80006 = 0032 DECIMAL						
60097-60112 = 0000000000000000	80007 = 0000 DECIMAL						
60113-60128 = 0000000010100000	80008 = 0000 DECIMAL						
50001-50016 = 0000000000000000	90001 = 0000 DECIMAL						
50017-50032 = C0000000000000000	90002 = 0000 DECIMAL						
50033-50048 = 0000000000000000	90003 = 0000 DECIMAL						
50049-50064 = 0000000000000000	90004 = 0000 DECIMAL						
50065-50080 = 0000C00000000000	90005 = 0000 DECIMAL						
50081-50096 = 0000000000000000	90006 = 0000 DECIMAL						
50097-50112 = 0000000000000000	90007 = 0000 DECIMAL						
50113-50128 = 0000000000000000	90008 = 0000 DECIMAL						
STATION : 00 AR : 00000							
UNIT : 1	ENABLE	DISABLE	FORCE ON	FORCE OFF			


Fig. 5.1.42

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. In monitor mode, "ENABLE," "DISABLE," "FORCE ON," "FORCE OFF," and small cursor do not appear.
3. When "SHIFT" and "RESET" are depressed simultaneously, the display returns to that shown in Fig. 5.1.35.

(4) Indication of Register Contents in Slave Station

Initially, the register contents appear in decimal, but can appear in decimal, hexadecimal, binary, or ASCII.



** STATION 01 MONITOR **		
60001-60016 =	0000000000000000	80001 = 0000 DECIMAL
60017-60032 =	0001011000101000	80002 = 0000 DECIMAL
60033-60048 =	0000000010000000	80003 = 0017 DECIMAL
60049-60064 =	0000100100000000	80004 = 0000 DECIMAL
60065-60080 =	0000000000000000	80005 = 3241 DECIMAL
60081-60096 =	0000000000000000	80006 = 0032 DECIMAL
60097-60112 =	0000000000000000	80007 = 0000 DECIMAL
60113-60128 =	0000000001010000	80008 = 0000 DECIMAL
50001-50016 =	0000000000000000	90001 = 0000 DECIMAL
50017-50032 =	0000000000000000	90002 = 0000 DECIMAL
50033-50048 =	0000000000000000	90003 = 0000 DECIMAL
50049-50064 =	0000000000000000	90004 = 0000 DECIMAL
50065-50080 =	0000000000000000	90005 = 0000 DECIMAL
50081-50096 =	0000000000000000	90006 = 0000 DECIMAL
50097-50112 =	0000000000000000	90007 = 0000 DECIMAL
50113-50128 =	0000000000000000	90008 = 0000 DECIMAL

UNIT : 1

STATION : 00 AR : 00000

SELECT STATION			ENABLE	DISABLE	FORCE ON	FORCE OFF

Fig. 5.1.43

UNIT : I	STATION : 00	AR : 00000				
SELECT STATION	DISPLAY DECIMAL	DISPLAY HEX.	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE

Fig. 5.1.44

```

** STATION 01 MONITOR **

60001-60016 = 0000000000000000          80001 = 0000 HEXADECIMAL
60017-60032 = 0001011000101000          80002 = 0000 DECIMAL
60033-60048 = 0000000010000000          80003 = 0017 DECIMAL
60049-60064 = 0000100100000000          80004 = 0000 DECIMAL
60065-60080 = 0000000000000000          80005 = 3241 DECIMAL
60081-60096 = 0000000000000000          80006 = 0032 DECIMAL
60097-60112 = 0000000000000000          80007 = 0000 DECIMAL
60113-60128 = 0000000010100000          80008 = 0000 DECIMAL
50001-50016 = 0000000000000000          90001 = 0000 DECIMAL
50017-50032 = 0000000000000000          90002 = 0000 DECIMAL
50033-50048 = 0000000000000000          90003 = 0000 DECIMAL
50049-50064 = 0000000000000000          90004 = 0000 DECIMAL
50065-50080 = 0000000000000000          90005 = 0000 DECIMAL
50081-50096 = 0000000000000000          90006 = 0000 DECIMAL
50097-50112 = 0000000000000000          90007 = 0000 DECIMAL
50113-50128 = 0000000000000000          90008 = 0000 DECIMAL

```

UNIT 1

STATION : 00 AB : 00000

SELECT STATION	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE
-------------------	--------------------	----------------	-------------------	------------------	--------	---------

Fig. 5.1.45

(4) Indication of Register Contents in Slave Station (Cont'd)




Fig. 5.1.46




Fig. 5-1-47

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
 2. In monitor mode, "ENABLE," "DISABLE" do not appear.
Also, "NEXT" (Fig. 5.1.46) and small cursor do not appear.
 3. When "SHIFT" and "RESET" are depressed simultaneously, the display returns to that shown in Fig. 5.1.35.
 4. If a register content that is more than 9999 is set to decimal indication, it appears as follows:
Example: 90001 = > 9999 OVERFLOW
 5. If the register content that cannot be indicated in ASCII is so set, it appears as follows:
Example: 90001= 55 ASCII

(5) Indication of Any Discrete State

When "CHG" is depressed while the minotor display appears, the expansion reference area appears as shown in Fig. 5.1.48, so that up to 36 desired discrete data can be indicated in columns of 18 lines each.




Fig. 5.1.49




Fig. S.1.S0

UNIT : 1	STATION : 00	AR : 00000					
SET STATION #							

Fig. 5.1.4B


UNIT : 1	STATION : 00 AR : 80001
SET STATION : 1	DISPLAY IPOINT

Fig. 5.1.49

00 60001 = OFF	02 50009 = OFF
00 60002 = ON	02 50010 = OFF
00 60003 = OFF	02 50011 = OFF
00 60004 = ON	02 50012 = OFF
00 60005 = ON	05 50033 = OFF
00 60006 = OFF	05 50034 = OFF
00 60007 = ON	05 50035 = OFF
00 60008 = OFF	05 50036 = OFF
01 60001 = OFF	05 50037 = OFF
01 60002 = OFF	05 50038 = OFF
01 60003 = OFF	05 50039 = OFF
01 60004 = OFF	06 50001 = OFF
01 60005 = OFF	06 50002 = OFF
01 60006 = OFF	08 50003 = OFF
01 60007 = OFF	08 50004 = OFF
01 60008 = OFF	08 50005 = OFF
01 60009 = OFF	09 50001 = OFF
01 60010 = OFF	09 50002 = OFF

Fig. 5.1.50

(5) Indication of Any Discrete State (Cont'd)



00 60001 = OFF	02 50010 = OFF
00 60002 = ON	02 50011 = OFF
00 60003 = OFF	02 50012 = OFF
00 60004 = ON	03 50033 = OFF
00 60005 = ON	03 50034 = OFF
00 60006 = OFF	03 50035 = OFF
00 60007 = ON	03 50036 = OFF
00 60008 = OFF	03 50037 = OFF
01 60001 = OFF	03 50038 = OFF
01 60002 = OFF	03 50039 = OFF
01 60003 = OFF	05 50001 = OFF
01 60004 = OFF	06 50002 = OFF
01 60005 = OFF	06 50002 = OFF
01 60006 = OFF	06 50003 = OFF
01 60007 = OFF	06 50004 = OFF
01 60008 = OFF	06 50005 = OFF
01 60009 = OFF	08 50001 = OFF
01 60010 = OFF	09 50002 = OFF

UNIT : 1	STATION : 00 AR : 60000
SET STATION #	DISPLAY 1POINT

Fig. 5.1.51

00 60001 = OFF	02 50010 = OFF
00 60002 = ON	02 50011 = OFF
00 60003 = OFF	02 50012 = OFF
00 60004 = ON	05 50033 = OFF
00 60005 = ON	06 50034 = OFF
00 60006 = OFF	06 50035 = OFF
00 60007 = ON	05 50036 = OFF
00 60008 = OFF	06 50037 = OFF
01 60001 = OFF	05 50038 = OFF
01 60002 = OFF	05 50039 = OFF
01 60003 = OFF	06 50001 = OFF
01 60004 = OFF	06 50001 = OFF
01 60005 = OFF	06 50002 = OFF
01 60006 = OFF	06 50002 = OFF
01 60007 = OFF	06 50003 = OFF
01 60008 = OFF	06 50004 = OFF
01 60009 = OFF	06 50005 = OFF
01 60010 = OFF	08 50001 = OFF

UNIT : 2		STATION : 00 AR : 6000E	
SET STATION #	DISPLAY 1POINT	DISPLAY 16POINTS	ENABLE DISABLE FORCE ON FORCE OFF

Fig. 5.1.52

00 60001 = OFF	02 50010 = OFF
00 60002 = ON	02 50011 = OFF
00 60003 = OFF	02 50012 = OFF
00 60004 = ON	05 50033 = OFF
00 60005 = ON	05 50034 = OFF
00 60006 = OFF	05 50035 = OFF
00 60007 = ON	05 50036 = OFF
00 60008 = OFF	05 50037 = OFF
C1 60001 = OFF	05 50038 = OFF
C1 80002 = OFF	05 50039 = OFF
01 60003 = OFF	06 50001 = OFF
01 60004 = OFF	06 50001 = OFF
01 60005 = OFF	06 50002 = OFF
01 60006 = OFF	06 50002 = OFF
01 60007 = OFF	06 50003 = OFF
01 60008 = OFF	06 50004 = OFF
01 60009 = OFF	06 50005 = OFF
01 60010 = OFF	09 50001-50018 = 0000000000000000

UNIT : 1 STAT ON : 00 AR : E0001
SET DISPLAY DISPLAY | ENABLE DISABLE FORCE FORCE
STATION # 1POINT 16POINTS | ON OFF

Fig. 5.1.53




Fig. 5.1.54




Fig. 5.1.55




Fig. 5.1.56


(5) Indication of Any Discrete State (Cont'd)

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. When "CHG" is depressed, an alternate operation occurs. (This does not clear the contents on the screen.)
3. In monitor mode, "ENABLE," "DISABLE," "FORCE" ON, and "FORCE" OFF do not appear.

(6) Indication of Desired Register State

When "CHG" is depressed while the monitor display appears, the expansion reference area appears as shown in Fig. 5.1.57, so that up to 36 desired registers can be indicated in 2 columns of 18 lines each.



> 00 909D1 = 0000 DEC. HAL

UNIT : 1	STATION : 00 AR : 00000
SET STATION ■	DISPLAY DECIMAL DISPLAY HEX DISPLAY BINARY DISPLAY ASC. I ENABLE DISABLE

Fig. 5.1.57

20 20001 - 0000 MEXICO

Fig. 5.1.58

00 0000 = 000000000000000

SET STATION #	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE	NEXT MENU
---------------	-----------------	-------------	----------------	---------------	--------	---------	-----------

Fig. 5.1.59


00 90001 ± 35 ASCII

Fig. 5.1.60

$\Rightarrow 00\ 90001 = 0000$ DECIMAL

Fig. 5.1.61

(6) Indication of Desired Register State (Cont'd)



UNIT : 1		STATION : 00 AR : 00000				
SET STATION #	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE
00 90001	= 0000 DECIMAL			00 80001 = 0000 DECIMAL		
00 90002	= 0000 DECIMAL			00 80002 = 0005 DECIMAL		
00 90003	= 0000 DECIMAL			00 80003 = 0025 DECIMAL		
00 90004	= 0000 DECIMAL			00 80004 = 0000 DECIMAL		
00 90005	= 0000 DECIMAL			00 80005 = 0000 DECIMAL		
00 90006	= 0000 DECIMAL			00 80006 = 0256 DECIMAL		
00 90007	= 0000 DECIMAL			00 80007 = 0000 DECIMAL		
00 90008	= 0000 DECIMAL			00 80008 = 1230 DECIMAL		
00 90009	= 0000 DECIMAL			01 80001 = 0000 DECIMAL		
00 90010	= 0000 DECIMAL			02 80001 = 0000 DECIMAL		
01 80001	= 0000 DECIMAL			03 80001 = 0000 DECIMAL		
02 80001	= 0000 DECIMAL			04 80001 = 0000 DECIMAL		
03 80001	= 0000 DECIMAL			05 80001 = 0000 DECIMAL		
04 80001	= 0000 DECIMAL			06 80001 = 0000 DECIMAL		
05 80001	= 0000 DECIMAL			07 80001 = 0000 DECIMAL		
06 80001	= 0000 DECIMAL			08 80001 = 0000 DECIMAL		
07 80001	= 0000 DECIMAL			09 80001 = 0000 DECIMAL		
08 80001	= 0000 DECIMAL			10 80001 = 0000 DECIMAL		

Fig. 5.1.62

UNIT : 1		STATION : 00 AR : 00000				
SET STATION #	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE
00 90001	= 0000 DECIMAL			00 800C2 = 0005 DECIMAL		
00 90002	= 0000 DECIMAL			00 80003 = 0025 DECIMAL		
00 90003	= 0000 DECIMAL			00 80004 = 0000 DECIMAL		
00 90004	= 0000 DECIMAL			00 80005 = 0000 DECIMAL		
00 90005	= 0000 DECIMAL			00 80006 = 0256 DECIMAL		
00 90006	= 0000 DECIMAL			00 80007 = 0000 DECIMAL		
00 90007	= 0000 DECIMAL			00 80008 = 1230 DECIMAL		
00 90008	= 0000 DECIMAL			01 80001 = 0000 DECIMAL		
00 90009	= 0000 DECIMAL			02 80001 = 0000 DECIMAL		
00 90010	= 0000 DECIMAL			03 80001 = 0000 DECIMAL		
01 90001	= 0000 DECIMAL			04 80001 = 0000 DECIMAL		
02 90001	= 0000 DECIMAL			05 80001 = 0000 DECIMAL		
03 90001	= 0000 DECIMAL			06 80001 = 0000 DECIMAL		
04 90001	= 0000 DECIMAL			07 80001 = 0000 DECIMAL		
05 90001	= 0000 DECIMAL			08 80001 = 0000 DECIMAL		
06 90001	= 0000 DECIMAL			09 80002 = 0000 DECIMAL		
07 90001	= 0000 DECIMAL			10 80001 = 0000 DECIMAL		
08 90001	= 0000 DECIMAL					

Fig. 5.1.62

UNIT : 1		STATION : 00 AR : 00000				
SET STATION #	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE
00 B0001	= 0000 DECIMAL			00 80002 = 0005 DECIMAL		
00 B0002	= 0000 DECIMAL			00 80003 = 0025 DECIMAL		
00 B0003	= 0000 DECIMAL			00 80004 = 0000 DECIMAL		
00 B0004	= 0000 DECIMAL			00 80005 = 0000 DECIMAL		
00 B0005	= 0000 DECIMAL			00 80006 = 0256 DECIMAL		
00 B0006	= 0000 DECIMAL			00 80007 = 0000 DECIMAL		
00 B0007	= 0000 DECIMAL			00 80008 = 1230 DECIMAL		
00 B0008	= 0000 DECIMAL			01 80001 = 0000 DECIMAL		
00 B0009	= 0000 DECIMAL			02 80001 = 0000 DECIMAL		
00 B0010	= 0000 DECIMAL			03 80001 = 0000 DECIMAL		
01 B0001	= 0000 DECIMAL			04 80001 = 0000 DECIMAL		
02 B0001	= 0000 DECIMAL			05 80001 = 0000 DECIMAL		
03 B0001	= 0000 DECIMAL			06 80001 = 0000 DECIMAL		
04 B0001	= 0000 DECIMAL			07 80001 = 0000 DECIMAL		
05 B0001	= 0000 DECIMAL			08 80001 = 0000 DECIMAL		
06 B0001	= 0000 DECIMAL			09 80002 = 0000 DECIMAL		
07 B0001	= 0000 DECIMAL			10 80001 = 0000 DECIMAL		
08 B0001	= 0000 DECIMAL					

Fig. 5.1.63

UNIT : 1		STATION : 00 AR : 00000				
SET STATION #	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY	DISPLAY ASCII	ENABLE	DISABLE
00 B0001	= 0000 DECIMAL			00 80002 = 0005 DECIMAL		
00 B0002	= 0000 DECIMAL			00 80003 = 0025 DECIMAL		
00 B0003	= 0000 DECIMAL			00 80004 = 0000 DECIMAL		
00 B0004	= 0000 DECIMAL			00 80005 = 0000 DECIMAL		
00 B0005	= 0000 DECIMAL			00 80006 = 0256 DECIMAL		
00 B0006	= 0000 DECIMAL			00 80007 = 0000 DECIMAL		
00 B0007	= 0000 DECIMAL			00 80008 = 1230 DECIMAL		
00 B0008	= 0000 DECIMAL			01 80001 = 0000 DECIMAL		
00 B0009	= 0000 DECIMAL			02 80001 = 0000 DECIMAL		
00 B0010	= 0000 DECIMAL			03 80001 = 0000 DECIMAL		
01 B0001	= 0000 DECIMAL			04 80001 = 0000 DECIMAL		
02 B0001	= 0000 DECIMAL			05 80001 = 0000 DECIMAL		
03 B0001	= 0000 DECIMAL			06 80001 = 0000 DECIMAL		
04 B0001	= 0000 DECIMAL			07 80001 = 0000 DECIMAL		
05 B0001	= 0000 DECIMAL			08 80001 = 0000 DECIMAL		
06 B0001	= 0000 DECIMAL			09 80002 = 0000 DECIMAL		
07 B0001	= 0000 DECIMAL			10 80001 = 0000 DECIMAL		
08 B0001	= 0000 DECIMAL					

Fig. 5.1.64


NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. When "CHG SCREEN" is depressed, an alternate operation occurs. (This does not clear the contents on the screen.)
3. In monitor mode, "ENABLE," "DISABLE," "NEXT," "MENU," and small cursor do not appear.
4. If a register content that is more than 9999 is set to decimal indication, it appears as follows:
Example: 90001 = > 9999 OVERFLOW
5. If the register content that cannot be indicated in ASCII is so set, it appears as follows:
Example: 90001 = 万万 ASCII

5.1.5 Link Data Disable Operation


(1) Disabling Coils and Input Relays

While the monitor display or expansion reference area appears, a disable operation (forced ON and OFF operations) can be carried out by specifying disable to the desired coil or input relay.



## MASTER (STATION 00) DISCRETE MONITOR ##	
70001-70008 = 00000000	50001-50016 = 0000000000000000
60001-60016 = 0101101001000000	50017-50032 = 0000000000000000
60017-60032 = 00C0100000000000	50033-50048 = 0000000000000000
60033-60048 = 0000C10011103000	50049-50064 = 0000000000000000
60049-60064 = 0000000000000000	50065-50080 = 0000000000000000
60065-60080 = 0001000100000000	50081-50096 = 0000000000000000
60081-60096 = 0000000000000000	50097-50112 = 0000000000000000
60097-60112 = 0000000000000000	50113-50128 = 0000000000000000
60113-60128 = 0000000000000000	50129-50144 = 0000000000000000
60129-60144 = 0000000000000000	50145-50160 = 0000000000000000
60145-60160 = 0000000000000000	50161-50176 = 0000000000000000
60161-60176 = 0000000000000000	50177-50192 = 0000000000000000
60177-60182 = 0000000000000000	50193-50208 = 0000000000000000
60193-60208 = 0000000000000000	50209-50224 = 0000000000000000
60209-60224 = 0000000000000000	50225-50240 = 0000000000000000
60225-60240 = 0000000000000000	50241-50256 = 0000000000000000
60241-60256 = 0000000000000000	

Fig. 5.1.65

 60081 · 60096 = 0000000000000000 50097 · 50112 = 0000000000000000
Fig. 5.1.66

 60081 · 60096 = 0010000000000000 50097 · 50112 = 0000000000000000
Fig. 5.1.67

Fig. 5.1.66

Fig. 5.1-67

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
 2. When the discrete data is indicated as a one-point increment, a disable operation indicates the following: 00 60001 - OFF DISABLED
 3. In the monitor mode, no disable operation can be applied.
 4. Disabled coil or input coil must be returned to enable state, when it is not necessary.

(2) Storing Data in Register

While the monitor display or expansion reference area appears, the desired numerics can be stored in a register. This is possible only when the register is disabled.



Data types that can be stored

Decimal: 0000 to 9999

Hexadecimal: 0000 to FFFF

Binary: Any 16-bit pattern

ASCII: Any 2 ASCII characters



UNIT : 1		STATION : 00 AR : 00000	
SELECT STATION	DISPLAY DECIMAL	DISPLAY HEX	DISPLAY BINARY
			DISPLAY ASCII
			ENABLE
			DISABLE
			PREVIOUS MENU

** MASTER (STATION 00) REGISTER MONITOR **

REG	DATA	REG	DATA
80001	= 0000 DECIMAL	90001	= 0000 DECIMAL
80002	= C005 DECIMAL	90002	= 0000 DECIMAL
80003	= C025 DECIMAL	90003	= 0000 DECIMAL
80004	= D000 DECIMAL	90004	= 0000 DECIMAL
80005	= 0000 DECIMAL	90005	= 0000 DECIMAL
80006	= C256 DECIMAL	90006	= 0000 DECIMAL
80007	= 0000 DECIMAL	90007	= 0000 DECIMAL
80008	= 1230 DECIMAL	90008	= 0000 DECIMAL
80009	= 0010 DECIMAL	90009	= 0000 DECIMAL
80010	= 0000 DECIMAL	90010	= 0000 DECIMAL
80011	= 0022 DECIMAL	90011	= 0000 DECIMAL
80012	= 0022 DECIMAL	90012	= 0000 DECIMAL
80013	= 0000 DECIMAL	90013	= 0000 DECIMAL
80014	= 0000 DECIMAL	90014	= 0000 DECIMAL
80015	= 0000 DECIMAL	90015	= 0000 DECIMAL
80016	= 0000 DECIMAL	90016	= 0000 DECIMAL

Fig. 5.1.68

80001 = 0000 DECIMAL DISABLED 90001 = 0000 DECIMAL

Fig. 5.1.69

80001 = 0084 DECIMAL DISABLED 90001 = 0000 DECIMAL

Fig. 5.1.70

80001 = 0054 HEXADECIMAL DISABLED 90001 = 0000 DECIMAL

Fig. 5.1.71

80001 = F00A HEXADECIMAL DISABLED 90001 = 0000 DECIMAL

Fig. 5.1.72



80001 = 1111000000001010 DISABLED 90001 = 0000 DECIMAL

Fig. 5.1.73

UNIT : 1		STATION : 00 AR : 00000				
		SET BIT	CLEAR BIT	SET ALL	CLEAR ALL	PREVIOUS MENU

Fig. 5.1.74

(2) Storing Data in Register (Cont'd)



NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If a register content that is more than 9999 is set to decimal indication, it appears as follows:
Example: $900001 - > 9999$ OVERFLOW
3. If the register content that cannot be indicated in ASCII is so set, it appears as follows:
Example: $90001 = \overline{33}$ ASCII
4. In the monitor mode, no numerics can be stored.

(3) Searching for Disabled Items

Disabled coils, input relays and registers can be searched for. This is used when disabled states have not been released.





Fig. 5.1.85

NOTE

This step can be skipped, if ATTACH operation has already been completed.

5.1.6 Controller Operation

(1) Start

This operation restarts MEMOLINK that is in the process of stopping.

POINT

Port parameter setting and disable operations can be carried out whether MEMOLINK is running or stopping. Clearing memory, allocation, and load operations can be done only when MEMOLINK is stopping.




Fig. 5.1.86

MEMOLINK SYSTEM

MASTER(STATION 00)	SLAVE(STATION 01-31)
COILLS : 256	128
DISCRETE INPLTS : 256	128
DIRECT INPUTS : 008	...
INPUT RECS : 016	008
OUTPUT REGS : 018	008

* MEMOBUS PORT PARAMETERS *

MODE	PARITY	STOP BITS	BAUD RATE	DEVICE ADDR	DELAY
PORT1 : RTU	EVEN	1	09600	1	001
PORT2 : RTU	EVEN	1	01200	1	000

STOPPED MEMOLINK

UNIT : 1		STATION : 00 AR : 00000			
CONTROLLER OPERATIONS	PORT 1	PORT 2	TRAFFIC COP	LOADER OPERATIONS	LOGOUT

Fig. 5.1.86



Fig. 5.1.87

STOPPED MEMOLINK

UNIT : 1		STATION : 00 AR : 00000			
STOP MEMOLINK	START MEMOLINK	CLEAR MEMORY			

Fig. 5.1.87




Fig. 5.1.88

MEMOLINK START REQUESTED

UNIT : 1		STATION : 00 AR : 00000			
				CONFIRM	CANCEL

Fig. 5.1.88

NOTE


1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens, and the display returns to that shown in Fig. 5.1.87.

(2) Stop

This operation stops MEMOLINK that is running.

POINT

All operations are possible when MEMOLINK is stopping. Note that clearing memory, allocation, and load operations can be done only when MEMOLINK is stopping.



MEMOLINK SYSTEM

MASTER(STATION 00)		SLAVE(STATION 01-31)	
COILS :	256	DISCRETE INPUTS :	128
DIRECT INPUTS :	256	INPUT REGS :	128
INPUT REGS :	008	OUTPUT REGS :	---
OUTPUT REGS :	016	INPUT REGS :	008
	016	OUTPUT REGS :	008


* MEMOBUS PORT PARAMETERS *

MODE	PARITY	STOP BITS	BAUD RATE	DEVICE ADDR	DELAY
PORT1 : RTU	EVEN	1	09600	1	001
PORT2 : RTU	EVEN	1	01200	1	000

RUNNING MEMOLINK

UNIT : 1		STATION : 00 AR : 00000			
CONTROLLER OPERATIONS	PORT 1	PORT 2	TRAFFIC COP	LOADER OPERATIONS	LOGOUT


Fig. 5.1.89



RUNNING MEMOLINK


UNIT : 1		STATION : 00 AR : 00000			
STOP MEMOLINK	START MEMOLINK	CLEAR MEMORY			

Fig. 5.1.90



"MEMOLINK STOP REQUESTED" is indicated.

Fig. 5.1.91



"STOPPED MEMOLINK" is indicated.

End

MEMOLINK STOP REQUESTED

UNIT : 1		STATION : 00 AR : 00000		
			CONFIRM	CANCEL

Fig. 5.1.91

NOTE


1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens, and the display returns to that shown in Fig. 5.1.90.

(3) Clearing Memory

This operation clears the contents of I/O allocation table, disable table, and status table.

POINT

MEMOLINK must be stopped.



MEMOLINK SYSTEM

MASTER(STATION 00)		SLAVE(STATION 01-31)	
COILS :	256	128	
DISCRETE INPUTS :	256	128	
DIRECT INPUTS :	008		
INPUT REGS :	016	008	
OUTPUT REGS :	016	008	

* MEMOBUS PORT PARAMETERS *

MODE	PARITY	STOP BITS	BAUD RATE	DEVICE ADDR	DELAY
PORT1 : RTL	EVEN	1	09600	1	001
PORT2 : RTU	EVEN	1	01200	1	000

STOPPED MEMOLINK

UNIT : 1	STAT ON : 00	AR : 00000			
CONTROLLER OPERATIONS	PORT 1	PORT 2	TRAFFIC CUP	LOADER OPERATIONS	LOGOUT

Fig. 5.1.92

STOPPED MEMOLINK

UNIT : 1	STATION : 00	AR : 00000			
STOP MEMOLINK	START MEMOLINK	CLEAR MEMORY			

Fig. 5.1.93

MEMORY CLEAR REQUESTED

UNIT : 1	STATION : 00	AR : 00000		
			CONFIRM	CANCEL

Fig. 5.1.94


NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens and the display returns to that shown in Fig. 5.1.93.

5.1.7 Dump/Load/Verify of Allocation Data

(1) Setting Titles and Date

When title and date are set before recording allocation data, they can be recorded together with the allocatin data. If not required, this operation need not be done.



UNIT : 1 STATION : 00 AR : 00000

CONTROLLER OPERATIONS	PORT 1	PORT 2	TRAFFIC CDP	LOADER OPERATIONS	LOGOUT
-----------------------	--------	--------	-------------	-------------------	--------

Fig. 5.1.95

LABEL :
DATE :

UNIT : 1 STATION : 00 AR : 00000

SET TITLE	SET DATE	EVALUATE TAPE	LOAD MEMOLINK	DUMP MEMOLINK	VERIFY WITH TAPE	PREVIOUS MENU
-----------	----------	---------------	---------------	---------------	------------------	---------------

Fig. 5.1.96

UNIT : 1 STATION : 00 AR : 00000

END TITLE						
-----------	--	--	--	--	--	--


Fig. 5.1.97

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. Set data and title, using numerics, alphabet, and symbols. If an error is found during setting, depress "RUBOUT" and make correction.
3. When data is set with 6 characters, the display automatically returns to that shown in Fig. 5.1.96.

(2) Dumping Allocation Data

The memory contents of MEMOLINK master module can be dumped on a blank tape by the following operation. After dumping, check the contents and store the tape. If the programs are destroyed, this tape can be used to restore them by loading.



UNIT : 1		STATION : 00 AR : 00000			
SET TITLE	SET DATE	EVALUATE TAPE	LOAD MEMOLINK	DUMP MEMOLINK	VERIFY WITH TAPE
PREVIOUS MENU					

Fig. 5.1.98

DUMP REQUESTED UNIT : 1		STATION : 00 AR : 00000			
COMMENCE					CANCEL


Fig. 5.1.99

LABEL : MEMOLINK DATE : 860825			
ACTION	COLNT	MEMORY TYPE	ADDRESS
DUMPING	370	T-COP	0000
UNIT : 1 STATION : 00 AR : 00000			
STOP			

Fig. 5.1.100

UNIT : 1 STATION : 00 AR : 00000			
PROCEED			ABORT

Fig. 5.1.101



(a) Recording Prohibited

(b) Recording Ready


Fig. 5.1.102 Tape Cartridge Switch

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If "STOP" is depressed in Fig. 5.1.100, Fig. 5.1.101 is displayed. If "PROCEED" is depressed, the dump is continued. If "ABORT" is depressed, the operation stops, and Fig. 5.1.98 is displayed again.

(3) Loading Allocation Data

Data dumped on tape can be written into the master module. Before this operation, MEMOLINK must be stopped. When loading is finished, check the contents and remove the tape.



UNIT : 1 STATION : 00 AR : 00000

SET TITLE	SET DATE	EVALUATE TAPE	LOAD MEMOLINK	DUMP MEMOLINK WITH TAPE	VERIFY	PREVIOUS MENU
-----------	----------	---------------	---------------	-------------------------	--------	---------------

Fig. 5.1.103

LOAD REQUESTED UNIT : 1 STATION : 00 AR : 00000

COMMENCE					CANCEL
----------	--	--	--	--	--------

Fig. 5.1.104

LABEL : MEMOLINK
DATE : 800325

ACTION	COUNT	MEMORY TYPE	ADDRESS
LOADING	170	T-COP	0000

UNIT : 1 STATION : 00 AR : 00000

	STOP				
--	------	--	--	--	--

Fig. 5.1.105

UNIT : 1 STATION : 00 AR : 00000

	PROCEED				ABORT
--	---------	--	--	--	-------


Fig. 5.1.106

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If "STOP" is depressed in Fig. 5.1.105, Fig. 5.1.106 is displayed. If "PROCEED" is depressed, the load is continued. If "ABORT" is depressed, the operation stops, and Fig. 5.1.103 is displayed again.

(4) Verifying Allocation Data

This operation is used for verification of tape data and data in MEMOLINK master module. After dumping and loading are completed, the operation must be accomplished.



UNIT : 1		STATION : 00 AR : 00000			
SET TITLE	SET DATE	EVALUATE TAPE	LOAD MEMOLINK	DUMP MEMOLINK	VERIFY MEMOLINK WITH TAPE
				PREVIOUS MENU	

Fig. 5.1.107

VERIFY REQUESTED UNIT : 1		STATION : 00 AR : 00000			
COMMENCE					CANCEL

Fig. 5.1.108

LABEL : MEMOLINK DATE : 860325		STATION : 00 AR : 00000			
ACTION	COUNT	MEMORY TYPE		ADDRESS	
VERIFYING	170	T-COP		0000	
LAST MISCOMPARE : NONE		ADDRESS		MEMORY	
				TAPE	
		UNIT : 1			
		STOP	↑PAUSE↓	CONTINUE	

Fig. 5.1.109










UNIT : 1		STATION : 00 AR : 00000			
PROCEED	↑PAUSE↓	CONTINUE			ABORT

Fig. 5.1.110

- NOTE**
- After dump or load operation and before starting MEMOLINK, perform a verification check.
 - If a miscomparison is found during a verification check, Fig.5.1.110 is displayed. If "PROCEED" is depressed, the verify operation is continued. If "ABORT" is depressed, the operation stops, and Fig.5.1.107 is displayed again.
 - When label "↑PAUSE↑" is toggled to "PAUSE" by depressing "CONTINUE" key, the verify operation is continued even if an error exists. For example, "0023 ERRORS: VERIFY COMPLETE" (meaning 23 errors) is displayed in the message area.

(2) Typical Setting of Port 2

Usually, port 2 is connected to a high-level computer. Set the port parameter to the proper value.



NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. Set the baud rate to 150, 300, 600, 1200, 2400, 4800, 9600, or 19200.
3. Set delay count in a range of 0 to 255.
4. When "PREVIOUS" ^{MENU} is depressed (Fig. 5.1.115), the set data is not written, and the display returns to that shown in Fig. 5.1.114.

5.1.9 Hard Copy

The P190 has RS-232C peripheral port (PORT 2, PERIPHERAL). When a serial printer (available on the market) is connected to this port, and "PRINT" is depressed, the display hard copy is printed. The CRT label, however, is not printed.

(1) Applicable Printers

Recommended Printer:

- | | | |
|---|---|--|
| • Type FP-80,
#8145 (RS-232C interface) |] | Made by Epson Co., Ltd. |
| • Type SP-850A-RE
(RS-232C interface incorporated) |] | Made by Nada Electronic Laboratory, Ltd. |

In addition to the above, printers with the following specifications may be used.

(a) Interface : EIA RS-232C

(b) Baud rate: 110, 200, 300, 600, 1200, 2400, 4800, or 9600 bauds.

(c) Data format:

- Data - 7 or 8 bits
- Stop bit - 1 or 2 bits
- Parity check - Even, odd, or none

(d) Character code: ASCII

Note: JIS C 6220 characters can be used as well.

In this case, NC contact print is → ¥ ← instead of → N ←.

(e) Printing width: 80 characters/line minimum

(2) Accessories

In addition to MEMOLINK master module, P190, their connecting cable (Type JZMSZ-W1015), and MEMOLINK programmer tape, the following accessories are required.

Table 5.1.2

Name	Type	O'ty	Manufacturer	Remarks
Cable between Printer and P190	JZMSZ W193-T01	1	Yaskawa	Cable length: 2.5m
Printer (recommended)	FP-80 (with #8145) SP-850A-RE	1	Epson Nada	Purchased from maker or agents.
Printing Paper	—	1 set	—	—

(3) Setting Communication Parameters (Recommended Example)

9600 bauds, 7-bit data, 2-stop bit, parity disable

POINT

- Before setting the printer, turn off the power.
- The P190 has been preset to the above condition prior to shipment.
- For setting the P190, see the next page.

(a) Typical FP-80 setting for the recommended communication parameters




Fig. 5.1.122 Example of FP-80 Setting

(b) Typical SP-850A-RE setting for the recommended communication parameters




Fig. 5.1.123 Example of SP-850A-RE Setting

NOTE

For details of switch setting, see the applicable printer manual.

(4) Setting P190 Communication Parameters

- Set P190 communication parameters using DIP switch.
- PORT 1 (CONTROLLER): Connect to PORT 1 or 2 of MEMOLINK master module.
- PORT 2 (PERIPHERAL): Connect to printer, etc.

POINT

- Before changing the DIP switch setting, turn off the P190 power.
- The P190 DIP switch has been preset to the state of mark prior to shipment as shown in Fig.5.1.124.
- MEMOLINK can be connected, without changing the setting condition as shown in Fig. 5.1.124.

**Table 5.1.3 Setting List of P190 DIP Switch
(Common to PORT 1, and PORT 2)**

BAUD RATE	S1	S2	S3	S4	
19,200	1	1	1	1	
9,600	1	1	1	0	← 9600 bauds
7,200	1	1	0	1	
4,800	1	1	0	0	
3,600	1	0	1	1	
2,400	1	0	1	0	
2,000	1	0	0	1	
1,800	1	0	0	0	
1,200	0	1	1	1	
600	0	1	1	0	
300	0	1	0	1	
150	0	1	0	0	
134.5	0	0	1	1	
110	0	0	1	0	
75	0	0	0	1	
50	0	0	0	0	
S5	1	PARITY ENABLE			
	0	PARITY DISABLE			
S6	1	EVEN PARITY			
	0	ODD PARITY			
S7	1	1 STOP BIT			
	0	2 STOP BIT			
S8	1	8 DATA BIT			
	0	7 DATA BIT			




Fig. 5.1.124 P190 DIP Switch Setting

(5) Cable Connecting P190 and Printer

The following two cables are available:

- Type JZMSZ-W193-T01 (2.5 M) applicable to FP-80, SP-850-RE
- Type JZMSZ-W181 (2.5 M) applicable to FP-80

Table 5.1.4 Connections of W193-T01

P190		Signal Direction	Printer	
Signal Name	Pin No.		Pin No.	Signal Name
P-GND	1	↔	1	P-GND
XMT	2	↙ ↘	2	XMT
RCV	3	↙ ↘	3	RCV
RTS	4	→		
CTS	5	←	5	CTS
DSR	6	←	6	DSR
DTR	20	↑ ↓	20	DTR
S-GND	7	↔	7	S-GND

Table 5.1.5 Connections of W181

P190		Signal Direction	Printer	
Signal Name	Pin No.		Pin No.	Signal Name
P-GND	1	↔	1	P-GND
XMT	2	↙ ↘	2	XMT
RCV	3	↙ ↘	3	RCV
CTS	5	↔	11	REV (BUSY)
DSR	6	←	6	DSR
DTR	20	↑ ↓	8	DCD
S-GND	7	↔	20	DTR
			7	S-GND

(6) Setting Printer Type

To use a printer which cannot accept a form-feed code, select "NO FORM FEED".





Fig. 5.1.125

NOTE

If ATTACH operation has already been completed, depress "LOGOUT" (Fig. 5.1.4), or turn the P190 key switch on and then off.

5.2 P150 PROGRAMMING PANEL

5.2.1 MEMOLINK Operation Flow




Fig. 5.2.1




Fig. 5.2.2

NOTE

1. For normal operation, set the switches as shown below, to prevent errors.
MEMOLINK master module memory protect switch : ON
2. In program mode, all operations are possible.
When MEMOLINK is operating, however, the asterisked operations cannot be accomplished.
3. In monitor mode, the operations in are not possible.
4. The keys are classified as follows:
 - : Label keys
 - : Function keys, such as numeric, fixed function, cursor control, and ASCII keys.
5. Eight labels displayed on the screen indicate the functions of the eight keys (label keys : F1 to F8) located at a top of the keyboard.

5.2.2 Preparation

Performing ATTACH operation makes data communication between the P150 and the MEMOLINK master module possible.






Fig. 5.2.3 Connection of P150 and MEMOLINK Master



1
After reading the system,
menu is displayed

Fig. 5.2.7

SYSTEM DISK VERSION : 3.0

MENU LIST

1. PROGRAM MODE
2. MONITOR MODE
3. FILE MANAGEMENT MODE

INPUT MENU NO.

AR : 00000

1	2	3	4	5	6	7 CONFIRM	8
---	---	---	---	---	---	-----------	---

Fig. 5.2.7

Depress EJECT button and
remove system disk.



• Determine operation mode.
• Set any menu No. in AR,
then depress "CONFIRM".

Fig. 5.2.8

PROGRAM MODE : All the program operations are
(On-line Program) possible.
Writing

MONITOR MODE : Memory contents cannot be altered.
(On-line Program) (Accidental or erroneous memory
(Monitor destruction is prevented.)

FILE MANAGEMENT MODE : This mode is selected to
(File Management) check the disk, display file names,
delete files and set transmission
conditions, ect. All the functions in
this mode can be executed with a
P150 alone.

Table 5.2.1 Setting of Memory Protect Switch of MEMOLINK

Menu No.	Operation Mode	Memory Protect Switch
1	Program mode	OFF
2	Monitor mode	ON (or OFF)
3	File management mode	ON (or OFF)

ATTACH

INPUT COMMUNICATION UNIT NO.

AR : 00000

1	2	3	4PRINTER TYPE	5	6	7	8 ATTACH
---	---	---	---------------	---	---	---	----------

Fig. 5.2.8

5.2.2 Preparation (Cont'd)




Fig. 5.2.9

NOTE

1. Before inserting a system disk, check that it is a MEMOLINK programmer.
2. To restart the system, start from the power supply ON/OFF operation.
3. Store the removed system disk in the specified area.
4. After ATTACH operation, depressing "SUPER" and "INITIAL", or "SHIFT" and "SUPER" may lead to the menu (initial) display.

PRECAUTIONS

1. Plug in the P150 power code into a properly grounded 100 VAC receptacle.
2. Connect the P150 and MEMOLINK master before connecting to power.
3. Turn off power to the P150 before disconnecting the P150 and MEMOLINK master.

5.2.3 Link Data Allocation

MEMOLINK allocation is carried out by loading connection information "Use 'A' PC output data as 'B' PC input data" into the master module.

POINT

When altering an allocation, stop MEMOLINK.





Fig. 5.2.10




Fig. 5.2.11

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. When "PREVIOUS MENU" key is depressed, the state returns to the state as shown in Fig. 5.2.10.
3. See Section 4 for detailed allocation.

(1) Typical Allocation of Discrete Input in Master Station

Discrete data are allocated in increment of 8 points. Allocation is loaded by setting the station number to STATION and the last three digits (001 to 249) of the first reference numbers to AR and depressing "SET" key. It is not necessary to allcate interrupt signals (70001 to 70008).




Fig. 5.2.13






Fig. 5.2.12



The cursor moves
downward to the next
legal position.
Fig. 5.2.15




Fig. 5.2.13




Fig. 5.2.14




Fig. 5.2.15

1

Set "3" in AR and depress
"SET STATION #" key.

STATION : 03	AR : 00001	
1 SET STATION #	2 SET DISCRETE	3SET DIRECT INPUT
5 CLEAR PAKAMETEN	6 INCREASE REF +8	7DECREASE REF -8
8PREVIOUS MENU		

Fig. 5.2.16

Set "1" in AR and depress
"SET DISCRETE" key.

Fig. 5.2.17

UNIT:1			PROGRAM MODE		
* MASTER DISCRETE INPUT *					
REF	ST#	REF	REF	ST#	REF
60001-60008	01	50017	60129-60136	--	----
60009-60016	03	50001	60137-60144	--	----
60017-60024	--	-----	60145-60152	--	----
60025-60032	--	-----	60153-60160	--	----
60033-60040	--	-----	60161-60168	--	----
60041-60048	--	-----	60169-60176	--	----
60049-60056	--	-----	60177-60184	--	----
60057-60064	--	-----	60185-60192	--	----
60065-60072	--	-----	60193-60200	--	----
60073-60080	--	-----	60201-60208	--	----
60081-60088	--	-----	60209-60216	--	----
60089-60096	--	-----	60217-60224	--	----
60097-60104	--	-----	60225-60232	--	----
60105-60112	--	-----	60233-60240	--	----
60113-60120	--	-----	60241-60248	--	----
60121-60128	--	-----	60249-60256	--	----

Fig. 5.2.17

Allocate the remaining discrete inputs in the same way above.

Fig. 5.2.18


UNIT:1			PROGRAM MODE		
* MASTER DISCRETE INPUT *					
REF	ST#	REF	REF	ST#	REF
60001-60008	01	50017	60129-60136	--	----
60009-60016	03	50001	60137-60144	--	----
60017-60024	05	50001	60145-60152	--	----
60025-60032	02	50121	60153-60160	--	----
60033-60040	04	50025	60161-60168	--	----
60041-60048	06	50049	60169-60176	--	----
60049-60056	10	50001	60177-60184	--	----
60057-60064	10	50009	60185-60192	--	----
60065-60072	07	50017	60193-60200	--	----
60073-60080	--	-----	60201-60208	--	----
60081-60088	--	-----	60209-60216	--	----
60089-60096	--	-----	60217-60224	--	----
60097-60104	--	-----	60225-60232	--	----
60105-60112	--	-----	60233-60240	--	----
60113-60120	--	-----	60241-60248	--	----
60121-60128	--	-----	60249-60256	--	----

STATION : 07	AR : 00017	
1 SET STATION #	2 SET DISCRETE	3SET DIRECT INPUT
5 CLEAR PARAMETER	6 INCREASE REF +8	7DECREASE REF -8
8PREVIOUS MENU		

Fig. 5.2.18

2

(1) Typical Allocation of Discrete Input in Master Station (Cont'd)



UNIT:1			PROGRAM MODE		
* MASTER DISCRETE INPUT *					
REF	ST#	REF	REF	ST#	REF
60001-60009	01	50017	60129-60138	--	-----
60009-60018	03	50031	60137-60144	--	-----
60017-60024	05	50001	60145-60152	--	-----
60025-60032	02	50121	60153-60160	--	-----
60033-60040	04	50025	60161-60168	--	-----
60041-60048	06	50049	60169-60176	--	-----
60049-60056	10	50001	60177-60184	--	-----
60057-60064	10	50000	60185-60192	--	-----
60065-60072	07	50017	60193-60200	--	-----
60073-60080	00	70001	60201-60208	--	-----
60081-60088	--	-----	60209-60216	--	-----
60089-60096	--	-----	60217-60224	--	-----
60097-60104	--	-----	60225-60232	--	-----
60105-60112	--	-----	60233-60240	--	-----
60113-60120	--	-----	60241-60248	--	-----
60121-60128	--	-----	60249-60256	--	-----
STATION : 07 AR : 00017					
1 SET STATION	2 SET DISCRETE	3 SET DIRECT INPUT	5 CLEAR PARAMETER	6 INCREASE REF +8	7 DECREASE REF -8
8 PREVIOUS MENU					

Fig. 5.2.19




Fig. 5.2.20

NOTE

1. In monitor mode, only label "PREVIOUS" MENU appears.
2. When "INCREASE" REF +8 is depressed, the AR content increases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
3. When "DECREASE" REF -8 is depressed, the AR content decreases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.
5. Once an interrupt signal is allocated, succeeding discrete data cannot be allocated.
6. As a reference number set in AR, any one of the last 3 digits (AR : 00001) or all 5 digits (AR : 50001) can be used.
7. If output in the same station is used as its input, "ERROR : CAUTION : THE OUTPUT IN THE SAME STATION" is displayed and label display shown in Fig. 5.2.20 appears. If the allocation is OK, depress "CONFIRM", and not OK, depress "CANCEL".

(2) Typical Allocation of Register Input in Master Station

Registers are input one by one. Allocation is loaded by setting the station number to STATION and the last two digits (01 to 16) of the reference numbers to AR and depressing "SET REGISTER".




Fig. 5.2.22




Fig. 5.2.21




Fig. 5.2.22




Fig. 5.2.23





Fig. 5.2.24

UNIT:1			PROGRAM MODE		
# MASTER REGISTER INPUT #					
REF	ST#	REF	REF	ST#	REF
80001	--	-----	80009	--	-----
80002	--	-----	80010	--	-----
80003	--	-----	80011	--	-----
80004	--	-----	80012	--	-----
80005	--	-----	80013	--	-----
80006	--	-----	80014	--	-----
80007	--	-----	80015	--	-----
80008	--	-----	80016	--	-----

(2) Typical Allocation of Register Input in Master Station (Cont'd)





Fig. 5.2.25

UNIT:1				PROGRAM MODE	
# MASTER REGISTER INPUT #					
REF	ST#	REF	REF	ST#	REF
80001	01	90001	80009	--	-----
80002	03	90002	80010	--	-----
80003	03	90003	80011	--	-----
80004	04	90007	80012	--	-----
80005	04	90008	80013	--	-----
80006	05	90005	80014	--	-----
80007	06	90008	80015	--	-----
80008	07	90008	80016	--	-----

Fig. 5.2.26




Fig. 5.2.27

- NOTE**
1. In monitor mode, only "PREVIOUS MENU" appears.
 2. When "INCREASE REF +1" is depressed, the AR content increases by 1.
 3. When "DECREASE REF -1" is depressed, the AR content decreases by 1.
 4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.
 5. As a reference number set in AR, any one of the last 3 digits (AR : 00001) or all 5 digits (AR : 90001) can be used.
 6. If output in the same station is used as its input, "ERROR : CAUTION : THE OUTPUT IN THE SAME STATION" is displayed and label display shown in Fig. 5.2.27 appears. If the allocation is OK, depress "CONFIRM," and not OK, depress "CANCEL."

(3) Typical Allocation of Discrete Input in Slave Station

Discrete data are allocated in increment of 8 points. Allocation is loaded by setting the station number to STATION and the last three digits (001 to 249) of the first reference numbers to AR and depressing "SET DISCRETE". It is not necessary to allocate interrup signals (70001 to 70008).





Fig. 5.2.28

DISCRETE			# SLAVE 01 INPUT #		PROGRAM MODE		
REF	ST#	REF	REF	ST#	REF		
60001-60008	--	----	80001	--	----		
60009-60016	--	----	80002	--	----		
60017-60024	--	----	80003	--	----		
60025-60032	--	----	80004	--	----		
60033-60040	--	----	80005	--	----		
60041-60048	--	----	80006	--	----		
60049-60056	--	----	80007	--	----		
60057-60064	--	----	80008	--	----		
60065-60072	--	----					
60073-60080	--	----					
60081-60088	--	----					
60089-60096	--	----					
60097-60104	--	----					
60105-60112	--	----					
60113-60120	--	----					
60121-60128	--	----					

STATION : 00 AR : 00001


1 SET STATION #	2 SET DISCRETE	3 SET DIRECT INPUT	5 CLEAR PARAMETER	6 INCREASE REF +8	7 DECREASE REF -8	8 PREVIOUS MENU
-----------------	----------------	--------------------	-------------------	-------------------	-------------------	-----------------

Fig. 5.2.29

DISCRETE			# SLAVE 01 INPUT #		PROGRAM MODE		
REF	ST#	REF	REF	ST#	REF		
60001-60008	00	50001	80001	--	----		
60009-60016	--	----	80002	--	----		
60017-60024	--	----	80003	--	----		
60025-60032	--	----	80004	--	----		
60033-60040	--	----	80005	--	----		
60041-60048	--	----	80006	--	----		
60049-60056	--	----	80007	--	----		
60057-60064	--	----	80008	--	----		
60065-60072	--	----					
60073-60080	--	----					
60081-60088	--	----					
60089-60096	--	----					
60097-60104	--	----					
60105-60112	--	----					
60113-60120	--	----					
60121-60128	--	----					

Fig. 6.2.30

(3) Typical Allocation of Discrete Input in Slave Station (Cont'd)



DISCRETE			# SLAVE 01 INPUT #			REGISTER		
REF	ST#	REF	REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	--	-----			
60009-60016	02	50017	80002	--	-----			
60017-60024	04	50113	80003	--	-----			
60025-60032	03	50001	80004	--	-----			
60033-60040	15	50001	80005	--	-----			
60041-60048	15	50009	80006	--	-----			
60049-60056	--	-----	80007	--	-----			
60057-60064	--	-----	80008	--	-----			
60065-60072	--	-----						
60073-60080	--	-----						
60081-60088	--	-----						
60089-60096	--	-----						
60097-60104	--	-----						
60105-60112	--	-----						
60113-60120	--	-----						
60121-60128	--	-----						

Fig. 5.2.31

DISCRETE			# SLAVE 01 INPUT #			REGISTER		
REF	ST#	REF	REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	--	-----			
60009-60016	02	50017	80002	--	-----			
60017-60024	04	50113	80003	--	-----			
60025-60032	03	50001	80004	--	-----			
60033-60040	15	50001	80005	--	-----			
60041-60048	15	50009	80006	--	-----			
60049-60056	00	70001	80007	--	-----			
60057-60064	--	-----	80008	--	-----			
60065-60072	--	-----						
60073-60080	--	-----						
60081-60088	--	-----						
60089-60096	--	-----						
60097-60104	--	-----						
60105-60112	--	-----						
60113-60120	--	-----						
60121-60128	--	-----						

STATION : 15 AR : 00009

Fig. 5.2.32

<input type="button" value="1"/>	<input type="button" value="2"/>	<input type="button" value="3"/>	<input type="button" value="4"/>	<input type="button" value="5"/>	<input type="button" value="6"/>	<input type="button" value="7"/>	<input type="button" value="8"/>	<input type="button" value="9"/>
----------------------------------	----------------------------------	----------------------------------	----------------------------------	----------------------------------	----------------------------------	----------------------------------	----------------------------------	----------------------------------

Fig. 5.2.33

NOTE

1. In monitor mode, only "PREVIOUS" MENU appears.
2. When "INCREASE REF -8" is depressed, the AR content increases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
3. When "DECREASE REF -8" is depressed, the AR content decreases to become $8N + 1$ ($N = 0, 1, 2, \dots, 31$) nearest the value set in AR.
4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.
5. Once an interrupt signal is allocated, succeeding discrete data cannot be allocated.
6. As a reference number set in AR, any one of the last 3 digits (AR : 00001) or all 5 digits (AR : 50001) can be used.
7. If output in the same station is used as its input, "ERROR : CAUTION : THE OUTPUT IN THE SAME STATION" is displayed and label display shown in Fig. 5.2.33 appears. If the allocation is OK, depress "CONFIRM," and not OK depress "CANCEL".

(4) Typical Allocation of Register Input in Slave Station

Registers are input one by one. Allocation is loaded by setting the station number to STATION and the last two digits (01 to 16) of the reference number to AR and depressing "SET REGISTER".





Fig. 5.2.34

UNIT:1				PROGRAM MODE	
DISCRETE		# SLAVE 01 INPUT #		REGISTER	
REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	--	---
60009-60016	02	50017	80002	--	---
60017-60024	04	50113	80003	--	---
60025-60032	03	50001	80004	--	---
60033-60040	15	50001	80005	--	---
60041-60048	15	50009	80006	--	---
60049-60056	00	70001	80007	--	---
60057-60064	--	--	80008	--	---
60065-60072	--	--	--	--	---
60073-60080	--	--	--	--	---
60081-60088	--	--	--	--	---
60089-60096	--	--	--	--	---
60097-60104	--	--	--	--	---
60105-60112	--	--	--	--	---
60113-60120	--	--	--	--	---
60121-60128	--	--	--	--	---

STATION : 15 AR : 00008

1 SET STATION # 2 SET DISCRETE 3 SET DIRECT INPUT 4 SET REGISTER 5 CLEAR PARAMETER 6 INCREASE REF +1 7 DECREASE REF -1 8 PREVIOUS MENU

Fig. 5.2.35





Fig. 5.2.36



UNIT:1				PROGRAM MODE	
DISCRETE		# SLAVE 01 INPUT #		REGISTER	
REF	ST#	REF	REF	ST#	REF
60001-60008	00	50001	80001	00	90011
60009-60016	02	50017	80002	--	---
60017-60024	04	50113	80003	--	---
60025-60032	03	50001	80004	--	---
60033-60040	15	50001	80005	--	---
60041-60048	15	50009	80006	--	---
60049-60056	00	70001	80007	--	---
60057-60064	--	--	80008	--	---
60065-60072	--	--	--	--	---
60073-60080	--	--	--	--	---
60081-60088	--	--	--	--	---
60089-60096	--	--	--	--	---
60097-60104	--	--	--	--	---
60105-60112	--	--	--	--	---
60113-60120	--	--	--	--	---
60121-60128	--	--	--	--	---

STATION : 00 AR : 00011

1 SET STATION # 2 3 4 SET REGISTER 5 CLEAR PARAMETER 6 INCREASE REF +1 7 DECREASE REF -1 8 PREVIOUS MENU

Fig. 5.2.37

(4) Typical Allocation of Register Input in Slave Station (Cont'd)

STATION : 02				AR : 00007		
1 SET STATION #	2	3	4 SET REGISTER	5 CLEAR PARAMETER	6 INCREASE REF +1	7 DECREASE REF -1
			BPREVIOUS MENU			

Fig. 5.2.38




Fig. 5.2.39

UNIT:1			PROGRAM MODE		
DISCRETE		# SLAVE DI INPUT #		REGISTER	
REF	ST#	REF	REF	ST#	REF
80001-80008	00	50001	80001	00	90011
80009-80016	02	50017	80002	02	90007
60017-60024	04	50113	80003	--	-----
60025-60032	03	50001	80004	--	-----
60033-60040	15	50001	80005	--	-----
60041-60048	15	50009	80006	--	-----
60049-60056	00	70001	80007	--	-----
60057-60064	--	-----	80008	--	-----
60065-60072	--	-----			
60073-60080	--	-----			
60081-60088	--	-----			
60089-60096	--	-----			
60097-60104	--	-----			
60105-60112	--	-----			
60113-60120	--	-----			
60121-60128	--	-----			

Fig. 5.2.39




Fig. 5.2.40

UNIT:1			PROGRAM MODE		
DISCRETE		# SLAVE DI INPUT #		REGISTER	
REF	ST#	REF	REF	ST#	REF
80001-80008	00	50001	80001	00	90011
80009-80016	02	50017	80002	02	90007
60017-60024	04	50113	80003	03	90006
60025-60032	03	50001	80004	07	90003
60033-60040	15	50001	80005	05	90002
60041-60048	15	50009	80006	--	-----
60049-60056	00	70001	80007	--	-----
60057-60064	--	-----	80008	--	-----
60065-60072	--	-----			
60073-60080	--	-----			
60081-60088	--	-----			
60089-60096	--	-----			
60097-60104	--	-----			
60105-60112	--	-----			
60113-60120	--	-----			
60121-60128	--	-----			

STATION : 05 AR : 00002

1 SET STATION #	2	3	4 SET REGISTER	5 CLEAR PARAMETER	6 INCREASE REF +1	7 DECREASE REF -1	8 PREVIOUS MENU
-----------------	---	---	----------------	-------------------	-------------------	-------------------	-----------------

Fig. 5.2.40

1	2	3	4	5	6	7 CONFIRM	8 CANCEL
---	---	---	---	---	---	-----------	----------

Fig. 5.2.41

NOTE

1. In monitor mode, only "PREVIOUS" MENU appears.
2. When "INCREASE" REF +1 is depressed, the AR content increases by 1.
3. When "DECREASE" REF -1 is depressed, the AR content decreases by 1.
4. When "CLEAR PARAMETER" is depressed, the allocation at the cursor is cleared.
5. As a reference number set in AR, any one of the last 3 digits (AR : 00001) or all 5 digits (AR : 90001) can be used.
6. If output in the same station is used as its input, "ERROR : CAUTION : THE OUTPUT IN THE SAME STATION" is displayed and label display shown in Fig. 5.2.41 appears.
7. If the allocation is OK, depress "CONFIRM," and not OK, depress "CANCEL."

(5) Output Allocation Display

Every station number output allocation is indicated.





Fig. 5.2.42

UNIT:1			PROGRAM MODE		
# OUTPUT #					
STATION	DISCRETE	REGISTER	STATION	DISCRETE	REGISTER
00	008	11	18	000	00
01	024	07	17	000	00
02	008	06	18	000	00
03	008	02	19	000	00
04	120	08	20	000	00
05	008	05	21	000	00
06	056	08	22	000	00
07	024	01	23	000	00
08	000	00	24	000	00
09	000	00	25	000	00
10	016	00	26	000	00
11	000	00	27	000	00
12	000	00	28	000	00
13	000	00	29	000	00
14	000	00	30	000	00
15	016	00	31	000	00

STATION : 00 AR : 00000

1 2 3 4 5 6 7 8PREVIOUS MENU

Fig. 5.2.43

NOTE


The output allocation display indicates the PC output capacity of each station, corresponding to the number of inputs of discrete data and registers allocated to each station.

5.2.4 Link Data Monitor

(1) Discrete Data Status Indication in Master Station

Discrete data appear in increment of 16 points, as shown below (1 indicates ON ; 0 indicates OFF). The underlined numerals are in disabled state. An interrupt signal appears in 8 points.

Example : $60001 - 60016 = \underline{10001} \underline{10001} 000010$



NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
 2. In monitor mode, "ENABLE," "DISABLE," "FORCE," "ON" and "OFF" and small cursor do not appear.
 3. Even if "MONITOR" is depressed in Fig. 5.2.10, display shown in Fig. 5.2.44 comes up.

(2) Indication of Register Contents in Master Station

Initially, the register contents appear in decimal, but can appear in decimal, hexadecimal, binary, or ASCII.





Fig. 5.2.45




Fig. 5.2.46





Fig. 5.2.47

(2) Indication of Register Contents in Master Station (Cont'd)



NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. In monitor mode, "ENABLE" and "DISABLE" do not appear. Also, "NEXT" (see Fig. 5.2.47) and small cursor do not appear.
3. When "PREVIOUS" MENU is depressed, the display returns to that shown in Fig. 5.2.44.

(3) Discrete Status Indication in Slave Station

As in the master module, discrete data appear in increment of 16 points, (1 indicates ON ; 0 indicates OFF.) The underlined numerals are in disabled state.

Example : $60001\cdot60016 = 1000\underline{1}1000\underline{1}000010$

60001 60016





Fig. 5.2.49

UNIT:1		PROGRAM MODE	
# STATION 01 MONITOR #			
60001-60016 =	0000000000000000	80001 =	0000 DECIMAL
60017-60032 =	0001011000101000	80002 =	0000 DECIMAL
60033-60048 =	0000000010000000	80003 =	0017 DECIMAL
60049-60064 =	0000100100000000	80004 =	0000 DECIMAL
60065-60080 =	0000000000000000	80005 =	3241 DECIMAL
60081-60096 =	0000000000000000	80006 =	0032 DECIMAL
60097-60112 =	0000000000000000	80007 =	0000 DECIMAL
60113-60128 =	0000000010100000	80008 =	0000 DECIMAL
50001-50016 =	0000000000000000	90001 =	0000 DECIMAL
50017-50032 =	0000000000000000	90002 =	0000 DECIMAL
50033-50048 =	0000000000000000	90003 =	0000 DECIMAL
50049-50064 =	0000000000000000	90004 =	0000 DECIMAL
50065-50080 =	0000000000000000	90005 =	0000 DECIMAL
50081-50096 =	0000000000000000	90006 =	0000 DECIMAL
50097-50112 =	0000000000000000	90007 =	0000 DECIMAL
50113-50128 =	0000000000000000	90008 =	0000 DECIMAL

STATION : 01 AR : 00000

1 SELECT STATION	2	3	4	5 ENABLE	6 DISABLE	7 FORCE ON	8 FORCE OFF
------------------	---	---	---	----------	-----------	------------	-------------





Fig. 5.2.50


NOTE

1. This step can be skipped, if ATTACII operation has already been completed.
2. In monitor mode, "ENABLE," "DISABLE," "FORCE," "ON," "OFF," and small cursor do not appear.

(4) Indication of Register Contents in Slave Station

Initially, the register contents appear in decimal, but can appear in decimal, hexadecimal, binary, or ASCII.





Depress "DISPLAY" key to display in ASCII mode.

Fig. 5.2.55

Depress "DISPLAY" key to DECIMAL display in decimal.

END




Fig. 5.2.54




Fig. 5.2.55

NOTE

1. This step can be skipped, if ATTACHII operation has already been completed.
2. In monitor mode, "ENABLE" and "DISABLE" do not appear.
Also, "NEXT" (Fig. 5.2.54) and small cursor do not appear.
3. If a register content that is more than 9999 is set to decimal indication, it appears as follows:
Example : 90001 = > 9999 OVERFLOW
4. If the register content that cannot be indicated in ASCII is so set, it appears as follows:
Example : 90001 = ♂♂ ASCII

(5) Indication of Any Discrete State

When "CHG SCREEN" is depressed while the monitor display appears, the expansion reference area appears as shown in Fig. 5.2.56, so that up to 36 desired discrete data can be indicated in columns of 18 lines each.





Fig. 5.2.56




Fig. 5.2.57




Fig. 5.2.58





Fig. 5.2.59




Fig. 5.2.60




Fig. 5.2.61

(5) Indication of Any Discrete State (Cont'd)





Fig. 5.2.62





Fig. 5.2.63





Fig. 5.2.64

1. This step can be skipped, if ATTACH operation has already been completed.
2. When "CHG SCREEN" is depressed, an alternate operation occurs. (This does not clear the contents on the screen.)
3. In monitor mode, "ENABLE," "DISABLE," "FORCE," "ON," and "FORCE," "OFF" do not appear.

(6) Indication of Desired Register State

When "CHG SCREEN" is depressed while the monitor display appears, the expansion reference area appears as shown in Fig. 5.2.65, so that up to 36 desired registers can be indicated in 2 columns of 18 lines each.





Fig. 5.2.65



Fig. 5.2.66




Fig. 5.2.67





Fig. 5.2.68



Fig. 5.2.69

(6) Indication of Desired Register State (Cont'd)



UNIT:1			PROGRAM MODE	
00	90001	= 0000	DECIMAL	00 80001 = 0000 DECIMAL
00	90002	= 0000	DECIMAL	00 80002 = 0005 DECIMAL
00	90003	= 0000	DECIMAL	00 80003 = 0025 DECIMAL
00	90004	= 0000	DECIMAL	00 80004 = 0000 DECIMAL
00	90005	= 0000	DECIMAL	00 80005 = 0000 DECIMAL
00	90006	= 0000	DECIMAL	00 80006 = 0256 DECIMAL
00	90007	= 0000	DECIMAL	00 80007 = 0000 DECIMAL
00	90008	= 0000	DECIMAL	00 80008 = 1230 DECIMAL
00	90009	= 0000	DECIMAL	01 80001 = 0000 DECIMAL
00	90010	= 0000	DECIMAL	02 80001 = 0000 DECIMAL
01	90001	= 0000	DECIMAL	03 80001 = 0000 DECIMAL
02	90001	= 0000	DECIMAL	04 80001 = 0000 DECIMAL
03	90001	= 0000	DECIMAL	05 80001 = 0000 DECIMAL
04	90001	= 0000	DECIMAL	06 80001 = 0000 DECIMAL
05	90001	= 0000	DECIMAL	07 80001 = 0000 DECIMAL
06	90001	= 0000	DECIMAL	08 80001 = 0000 DECIMAL
07	90001	= 0000	DECIMAL	09 80001 = 0000 DECIMAL
08	90001	= 0000	DECIMAL	10 80001 = 0000 DECIMAL
STATION : 10			AR : 80001	
1	SET STATION #	2 DISPLAY DECIMAL	3 DISPLAY HEX	4 DISPLAY BINARY
		5 DISPLAY ASCII	6 ENABLE	7 DISABLE

Fig. 5.2.70

UNIT:1			PROGRAM MODE	
00	90001	= 0000	DECIMAL	00 80002 = 0005 DECIMAL
00	90002	= 0000	DECIMAL	00 80003 = 0025 DECIMAL
00	90003	= 0000	DECIMAL	00 80004 = 0000 DECIMAL
00	90004	= 0000	DECIMAL	00 80005 = 0000 DECIMAL
00	90005	= 0000	DECIMAL	00 80006 = 0256 DECIMAL
00	90006	= 0000	DECIMAL	00 80007 = 0000 DECIMAL
00	90007	= 0000	DECIMAL	00 80008 = 1230 DECIMAL
00	90008	= 0000	DECIMAL	01 80001 = 0000 DECIMAL
00	90009	= 0000	DECIMAL	02 80001 = 0000 DECIMAL
00	90010	= 0000	DECIMAL	03 80001 = 0000 DECIMAL
01	90001	= 0000	DECIMAL	04 80001 = 0000 DECIMAL
02	90001	= 0000	DECIMAL	05 80001 = 0000 DECIMAL
03	90001	= 0000	DECIMAL	06 80001 = 0000 DECIMAL
04	90001	= 0000	DECIMAL	07 80001 = 0000 DECIMAL
05	90001	= 0000	DECIMAL	08 80001 = 0000 DECIMAL
06	90001	= 0000	DECIMAL	09 80001 = 0000 DECIMAL
07	90001	= 0000	DECIMAL	10 80001 = 0000 DECIMAL
STATION : 10			AR : 80001	
1	SET STATION #	2 DISPLAY DECIMAL	3 DISPLAY HEX	4 DISPLAY BINARY
		5 DISPLAY ASCII	6 ENABLE	7 DISABLE

Fig. 5.2.71

UNIT:1			PROGRAM MODE	
00	90001	= 0000	DECIMAL	00 80002 = 0005 DECIMAL
00	90002	= 0000	DECIMAL	00 80003 = 0025 DECIMAL
00	90003	= 0000	DECIMAL	00 80004 = 0000 DECIMAL
00	90004	= 0000	DECIMAL	00 80005 = 0000 DECIMAL
00	90005	= 0000	DECIMAL	00 80006 = 0256 DECIMAL
00	90006	= 0000	DECIMAL	00 80007 = 0000 DECIMAL
00	90007	= 0000	DECIMAL	00 80008 = 1230 DECIMAL
00	90008	= 0000	DECIMAL	01 80001 = 0000 DECIMAL
00	90009	= 0000	DECIMAL	02 80001 = 0000 DECIMAL
00	90010	= 0000	DECIMAL	03 80001 = 0000 DECIMAL
01	90001	= 0000	DECIMAL	04 80001 = 0000 DECIMAL
02	90001	= 0000	DECIMAL	05 80001 = 0000 DECIMAL
03	90001	= 0000	DECIMAL	06 80001 = 0000 DECIMAL
04	90001	= 0000	DECIMAL	07 80001 = 0000 DECIMAL
05	90001	= 0000	DECIMAL	08 80001 = 0000 DECIMAL
06	90001	= 0000	DECIMAL	09 80001 = 0000 DECIMAL
07	90001	= 0000	DECIMAL	10 80001 = 0000 DECIMAL
STATION : 10			AR : 80001	
1	SET STATION #	2 DISPLAY DECIMAL	3 DISPLAY HEX	4 DISPLAY BINARY
		5 DISPLAY ASCII	6 ENABLE	7 DISABLE

Fig. 5.2.72

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. When "SCREEN" is depressed, an alternate operation occurs. (This does not clear the contents on the screen.)
3. In monitor mode, "ENABLE," "DISABLE," "NEXT," and small cursor do not appear.
4. If a register content that is more than 9999 is set to decimal indication, it appears as follows :
Example : 90001=>9999 OVERFLOW
5. If the register content that cannot be indicated in ASCII is so set, it appears as follows :
Example : 90001 = ?? ASCII

5.2.5 Link Data Disable Operation

(1) Disabling Coils and Input Relays

While the monitor display or expansion reference area appears, a disable operation (forced ON and OFF operations) can be carried out by specifying disable to the desired coil or input relay.





Fig. 5.2.73

[60081-60096 = 0000000000000000] 50097-50112 = 0000000000000000]

Fig. 5.2.74

[60081-60096 = 0000000000000000] 50097-50112 = 0000000000000000]

Fig. 5.2.75

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. When the discrete data is indicated as a one-point increment, a disable operation indicates the following:
00 60001 = OFF DISABLED
3. In the monitor mode, no disable operation can be applied.
4. Disabled coil or input coil must be returned to enable state, when it is not necessary.

(2) Storing Data in Register

While the monitor display or expansion reference area appears, the desired numerics can be stored in a register. This is possible only when the register is disabled.

Data types that can be stored

Decimal : 0000 to 9999

Hexadecimal : 0000 to FFFF

Binary : Any 16-bit pattern

ASCII : Any 2 ASCII characters




Fig. 5.2.76




Fig. 5.2.77




Fig. 5.2.78




Fig. 5.2.79




Fig. 5.2.80



Fig. 5.2.81



Fig. 5.2.82

UNIT:1		PROGRAM MODE	
## MASTER (STATION 00) REGISTER MONITOR ##			
80001 = 0000	DECIMAL	90001 = 0000	DECIMAL
80002 = 0005	DECIMAL	90002 = 0000	DECIMAL
80003 = 0025	DECIMAL	90003 = 0000	DECIMAL
80004 = 0000	DECIMAL	90004 = 0000	DECIMAL
80005 = 0000	DECIMAL	90005 = 0000	DECIMAL
80006 = 0258	DECIMAL	90006 = 0000	DECIMAL
80007 = 0000	DECIMAL	90007 = 0000	DECIMAL
80008 = 1230	DECIMAL	90008 = 0000	DECIMAL
80009 = 0010	DECIMAL	90009 = 0000	DECIMAL
80010 = 0000	DECIMAL	90010 = 0000	DECIMAL
80011 = 0022	DECIMAL	90011 = 0000	DECIMAL
80012 = 0022	DECIMAL	90012 = 0000	DECIMAL
80013 = 0000	DECIMAL	90013 = 0000	DECIMAL
80014 = 0000	DECIMAL	90014 = 0000	DECIMAL
80015 = 0000	DECIMAL	90015 = 0000	DECIMAL
80016 = 0000	DECIMAL	90016 = 0000	DECIMAL

STATION : 00 AR : 00000

[1] SELECT STATION [2] DISPLAY DECIMAL [3] DISPLAY HEX [4] DISPLAY BINARY [5] DISPLAY ASCII [6] ENABLE [7] DISABLE [8] PREVIOUS MENU

Fig. 5.2.76

Fig. 5.2.77

Fig. 5.2.78

Fig. 5.2.79

Fig. 5.2.80

Fig. 5.2.81

Fig. 5.2.82

UNIT:1		PROGRAM MODE	
80001 = 0000	DECIMAL	90001 = 0000	DECIMAL
80002 = 0005	DECIMAL	90002 = 0000	DECIMAL
80003 = 0025	DECIMAL	90003 = 0000	DECIMAL
80004 = 0000	DECIMAL	90004 = 0000	DECIMAL
80005 = 0000	DECIMAL	90005 = 0000	DECIMAL
80006 = 0258	DECIMAL	90006 = 0000	DECIMAL
80007 = 0000	DECIMAL	90007 = 0000	DECIMAL
80008 = 1230	DECIMAL	90008 = 0000	DECIMAL
80009 = 0010	DECIMAL	90009 = 0000	DECIMAL
80010 = 0000	DECIMAL	90010 = 0000	DECIMAL
80011 = 0022	DECIMAL	90011 = 0000	DECIMAL
80012 = 0022	DECIMAL	90012 = 0000	DECIMAL
80013 = 0000	DECIMAL	90013 = 0000	DECIMAL
80014 = 0000	DECIMAL	90014 = 0000	DECIMAL
80015 = 0000	DECIMAL	90015 = 0000	DECIMAL
80016 = 0000	DECIMAL	90016 = 0000	DECIMAL

STATION : 00 AR : 0F00A

[1] SELECT STATION [2] DISPLAY DECIMAL [3] DISPLAY HEX [4] DISPLAY BINARY [5] DISPLAY ASCII [6] CLEAR BIT [7] SET ALL [8] CLEAR ALL [9] PREVIOUS MENU

Fig. 5.2.82

(2) Storing Data Register (Cont'd)





Fig. 5.2.83	80001 = 1111111111111111 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.84	80001 = 0000111111111111 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.85	80001 = 0000000000000000 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.86	80001 = 0000000000000000 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.87	80001 = 0011000000000000 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.88	80001 = 0011000000000000 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.89	80001 = 0011000000110000 DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.90	80001 = 00 ASCII DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.91	80001 = 0E ASCII DISABLED	90001 = 0000 DECIMAL
Fig. 5.2.92	80001 = 0000 DECIMAL	90001 = 0000 DECIMAL

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If a register content that is more than 9999 is set to decimal indication, it appears as follows :
Example : 900001 -> 9999 OVERFLOW
3. If the register content that cannot be indicated in ASCII is so set, it appears as follows :
Example : 90001= 55 ASCII
4. In the monitor mode, no numerics can be stored.

(3) Searching for Disabled Items

Disabled coils, input relays and registers can be searched for. This is used when disabled states have not been released.



NOTE

This step can be skipped, if ATTACH operation has already been completed.




Fig. 5.2.93





5.2.6 Controller Operation

(1) Start

This operation restarts MEMOLINK that is in the process of stopping.

POINT

Port parameter setting and disable operations can be carried out whether MEMOLINK is running or stopping. Clearing memory, allocation, and load operations can be done only when MEMOLINK is stopping.



NOTE





1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens, and the display returns to that shown in Fig. 5.2.95.
3. If "SUPER" is depressed in Fig. 5.2.95, the display returns to that shown in Fig. 5.2.94.

(2) Stop

This operation stops MEMOLINK that is running.

POINT

All operations are possible when MEMOLINK is stopping. Note that clearing memory, allocation, and load operations can be done only when MEMOLINK is stopping.



NOTE




1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens, and the display returns to that shown in Fig. 5.2.98.
3. If "SUPER" VISORY is depressed in Fig. 5.2.98, the display returns to that shown in Fig. 5.2.97.

(3) Clearing Memory

This operation clears the contents of I/O allocation table, disable table, and status table.

POINT

MEMOLINK must be stopped.



NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. If "CANCEL" is depressed instead of "CONFIRM," nothing happens and the display returns to that shown in Fig. 5.2.101.
3. If "SUPER" is depressed in Fig. 5.2.101, the display returns to that shown in Fig. 5.2.100.

5.2.7 Save/Load/Verify of Allocation Data

This operation is for loading, (write-in), saving (read out) and verifying programs with the MEMORINK. Prepare data disk.





Fig. 5.2.103




Fig. 5.2.104

NOTE

1. If ATTACH operation has already been completed, this step can be skipped.
2. Label for "LOAD" key is not displayed in monitor mode.
3. Depressing "PREVIOUS MENU" returns to the display shown in Fig. 5.2.103.
4. For operation of disk files, refer to Par. 5.2.9 "File Management."

IMPORTANT

The data disk cannot be used unless initialized (made usable with P150). For initialization, refer to the disk initialization under Par. 5.2.9 (2) "Disk Formatting". Blank disks (Model: F150-000) are in the initialized state when delivered.

(1) Saving Allocation Data

The memory contents of MEMOLINK master module can be saved on a data disk by the following operation. After saving, check the contents and store the disk. If the programs are destroyed, this disk can be used to restore them by loading.

POINT

Make the data disk ready for writing.





Fig. 5.2.105

POINT

File name is within 8 characters by ANK.
Escape character is within 3 characters.
Refer to Par. 5.2.9 (4).

TESTLDR1 • U84
FILE NAME ESCAPE CHARACTER





Fig. 5.2.106



UNIT:1 PROGRAM MODE

FILE NAME : B:MEMOLINK.TXT			
TITLE : MEMOLINK TEST PROGRAM			
DATE : 07-20-1986			
ACTION	COUNT	MEMORY TYPE	ADDRESS
SAVE	00824	T-CUP	1106

1 2 STOP 3 4 5 6 7 8

Fig. 5.2.107

SAVE COMPLETE

1 2 END 3 4 5 6 7 8

Fig. 5.2.108

1 2 PROCEED 3 4 5 6 7 8 ABORT

Fig. 5.2.109

UNIT:1 PROGRAM MODE

INSERT DATA DISK IN DRIVE B: AND INPUT FILE NAME

FILE NAME : MEMOLINK.TXT

COMMAND.COM	MEMOLINK.TXT	FUJINOK	MD2416	MX1616
-------------	--------------	---------	--------	--------

Fig. 5.2.110


(1) Saving Allocation Data (Cont'd)

NOTE


1. If ATTACH operation has already been completed, this step can be skipped.
2. Depressing " DIRECTORY" key displays the file names. (Fig. 5.2.110).
3. Depressing " CANCEL" key restores the state as shown in Fig. 5.2.104.
4. To stop the save process during save execution, depress " STOP" key (Fig. 5.2.107).
The labels shown in Fig. 5.2.109 are displayed. Depressing " PROCEED" key causes the saving process to resume, and depressing " ABORT" key returns to the display as shown in Fig. 5.2.104.
5. Date can be input in the form "7-20-86" or "7/20/86" in addition to the example shown in Fig. 5.2.106.
6. Save operation can be executed also while MEMOLINK is running. However, execution of verify operation causes a mismatch.

IMPORTANT

Make the data disk ready for write-in beforehand.



(a) Write-in Disable



(b) Write-in Enable

(2) Loading Allocation Data

Data saved on disks can be written into MEMOLINK master module. After loading, check the contents and store the disk.

POINT

Stop the MEMOLINK before starting this operation.





Fig. 5.2.111










Fig. 5.2.112

(2) Loading Allocation Data (Cont'd)



NOTE

1. If ATTACH operation has already been completed, this step can be skipped.
2. Depressing "DIRECTORY" key displays the file names (Fig. 5.2.116).
3. Depressing "CANCEL" key restores the state as shown in Fig. 5.2.104.
4. To stop the loading during execution, depress "STOP" key (Fig. 5.2.113). The labels shown in Fig. 5.2.115 are displayed. Depressing "PROCEED" key causes the loading to resume, and depressing "ABORT" key returns to the display as shown in Fig. 5.2.104.

(3) Verifying Allocation Data

This operation is used for verification of floppy disk contents and MEMOLINK master module memory contents.





Fig. 5.2.117




Fig. 5.2.118




Fig. 5.2.119

(3) Verifying Allocation Data (Cont'd)




Fig. 5.2.120




Fig. 5.2.121




Fig. 5.2.122

NOTE

1. If ATTACH operation has already been completed, this step can be skipped.
2. Depressing "DIRECTORY" key displays the file names (Fig. 5.2.122).
3. Depressing "CANCEL" key restores the state as shown in Fig. 5.2.104.
4. If any miscomparison is found, labels shown in Fig. 5.2.121 are displayed. Depressing "PROCEED" key continues the VERIFY operation but "ABORT" key returns to the display shown in Fig. 5.2.104.
5. When label "PAUSE" is toggled to "CONTINUE" by depressing "PAUSE" key, the VERIFY operation is continued even if an error exists. For example, "0023 ERRORS: VERIFY COMPLETE" is displayed in the message area.

5.2.8 Setting Port Parameters

This operation sets transmission conditions for communications when a high-level computer or P150 is connected. The initial condition is preset before shipment so that P150 can be connected unconditionally and the port parameters need not be changed. Always check that the setting is correct.

(1) Typical Setting of Port 1

Usually, port 1 is connected to P150 (using cable type JZMSZ-W1015-T or -T2). Note that only delay count* can be set.




Fig. 5.2.123




Fig. 5.2.124




Fig. 5.2.125

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. Set delay count in a range of 0 to 255.
3. When "PREVIOUS MENU" is depressed (Fig. 5.2.124), the set data is not written, and the display returns to that shown in Fig. 5.2.123.

* Delay count is a function to give the specified delay time to the period from the MEMOLINK receiving the port parameter to the start of an answer and sending the data. This can usually be set to 0.

(2) Typical Setting of Port 2

Usually, port 2 is connected to a high-level computer. Set the port parameter to the proper value.




Fig. 5.2.126




Fig. 5.2.127




Fig. 5.2.128




Fig. 5.2.129



Fig. 5.2.130




Fig. 5.2.131




Fig. 5.2.132




Fig. 5.2.133

NOTE

1. This step can be skipped, if ATTACH operation has already been completed.
2. Set the baud rate to 150, 300, 600, 1200, 2400, 4800, 9600, or 19200.
3. Set delay count in a range of 0 to 255.
4. When "PREVIOUS MENU" is depressed (Fig. 5.2.127), the set data is not written, and the display returns to that shown in Fig. 5.2.126.

5.2.9 File Management Operation

The file management is used for operation of data disk files (user files), disk formatting and P150 communication parameter settings, as listed below:

FILE MANAGEMENT

- Directory: File names are displayed.
- Delete: Unnecessary files are deleted.
- Rename: File names are altered.
- Format: New disks are formulated (initialized).
- Chek Disk: Disk status is checked.
- Copy: From the disk inserted in drive B, specified files or all the files are copied onto the disk inserted in drive A.
- Set Port Parameter: The communication parameters for PORT 1 and PORT 2 of P150 are set.

These operations can be executed with P150 alone (off-line).

POINT

Before starting operation, insert the correct disks as instructed by the display in drives A and B.

5.2.9 File Management Operation (Cont'd)




Fig. 5.2.134




Fig. 5.2.134




Fig. 5.2.135




Fig. 5.2.135

NOTE

1. If ATTACH operation has already been completed, depress "SUPER" and then "INITIAL" key, or depress "SHIFT" and "SUPER" keys simultaneously to call up the operation menu display.
2. Depressing "INITIAL" key as shown in Fig. 5.2.135 also calls up the operation menu display.

(1) Port Parameter Setting

When the P150 serial port (RS-232C) is used, port parameters must be set in the port (1 or 2) to connect MEMOLINK by the following steps.

1. Select port (1 or 2) to connect MEMOLINK.
2. Set port parameters to the selected port.
3. Connect MEMOLINK to the port.
4. Use the other port for serial printer (for future use).

When the printer (PC-PR101F or PC-PR201F) is used, it is connected to parallel port (CENTRONICS) by only setting printer.

POINT

- If MEMOLINK is connected to PORT 1, and its port parameters to be set are the same as those set before shipping, port parameter setting is not required.
- Parallel port has already been set before shipping, to connect printer.




Fig. 5.2.136

* FILE MANAGEMENT *		
COMMENT		
1. <input type="button" value="1 DIRECTORY"/>	<input type="button" value="2 DELETE"/>	<input type="button" value="3 RENAME"/>
(1) DRIVE A: INSERT SYSTEM DISK OR P150 FORMATTED DISK		
(2) DRIVE B: INSERT DATA DISK		
2. <input type="button" value="4 FORMAT"/>	<input type="button" value="5 CHECK DISK"/>	3. <input type="button" value="6 COPY"/> <input type="button" value="7 SET PORT PARAMETER"/>
(1) DRIVE A: INSERT SYSTEM DISK		
(2) DRIVE B: INSERT DATA DISK		
DISK MUST NOT BE INSERTED IN THESE FUNCTIONS		
<input type="button" value="1 DIRECTORY"/> <input type="button" value="2 DELETE"/> <input type="button" value="3 RENAME"/> <input type="button" value="4 FORMAT"/> <input type="button" value="5 CHECK DISK"/> <input type="button" value="6 COPY"/> <input type="button" value="7 SET PORT PARAMETER"/> <input type="button" value="8 INITIAL DISPLAY"/>		

Fig. 5.2.136

Depress "SET PORT" key.


Fig. 5.2.137

* SET PORTPARAMETER *		
	PORT1	PORT2
OUTPUT DEVICE	SERIAL	PRINTER
BAUD RATE	9600	9600
PARITY CHECK	EVEN	DISABLE
STOP BIT	1 STOP BIT	2 STOP BIT
DATA LENGTH	8 BIT DATA	8 BIT DATA
<input type="button" value="1 SELECT"/> <input type="button" value="2"/> <input type="button" value="3"/> <input type="button" value="4"/> <input type="button" value="5"/> <input type="button" value="6"/> <input type="button" value="7"/> <input type="button" value="8 END"/>		

Fig. 5.2.137

1

(1) Port Parameter Setting (Cont'd)



* SET PORTPARAMETER *

	PORT 1	PORT 2
OUTPUT DEVICE	PRINTER	S C
BAUD RATE	9600	9600
PARITY CHECK	DISABLE	EVEN
STOP BIT	2 STOP BIT	1 STOP BIT
DATA LENGTH	8 BIT DATA	8 BIT DATA

1 SELECT 2 3 PRINT A
PRINT B 4 CENTRO SERIAL 5 6 7 8 END

Fig. 5.2.138

* SET PORTPARAMETER *

	PORT 1	PORT 2
OUTPUT DEVICE	PRINTER	S C
BAUD RATE	9600	9600
PARITY CHECK	DISABLE	EVEN
STOP BIT	2 STOP BIT	1 STOP BIT
DATA LENGTH	8 BIT DATA	8 BIT DATA

1 SET UP 2 3 SAVE
SET UP 4 5 CANCEL 6 7 8

Fig. 5.2.139

CANCEL PROTECTION OF SYSTEM DISK AND INSERT IN DRIVE A:

1 CONFIRM 2 3 CANCEL 4 5 6 7 8

Fig. 5.2.140

NOTE

1. If "CENTRO" | SERIAL label is displayed, this label key should not be depressed.
2. P150 has a communication parameter file in the system disk, the default values (initial values) are shown in Fig. 5.2.137. By copying all modifications of these initial values on the system disk, altering the communication parameters is not required at system starting. Depress "SAVE" key instead of "SET UP" key (Fig. 5.2.139). After the display shown in Fig 5.2.140 appears, insert the system disk, with writable state, in drive A, and depress "CONFIRM" key.

IMPORTANT

Be sure to bring the system disk to the write disable state after executing "SAVE" SET UP.

Table 5.2.2 Change of Setting Value at "SELECT" Key Depression

Item	Setting Value
OUTPUT DEVICE	→ SC → PRINTER
BAUD RATE	→ 75 → 110 → 150 → 300 → 600 ← 19200 ← 9600 ← 4800 ← 2400 ← 1200 ←
PARITY CHECK	→ DISABLE → ODD → EVEN
STOP BIT	→ 1 STOP BIT → 2 STOP BIT
DATA LENGTH	→ 7 BIT DATA → 8 BIT DATA

(2) Disk Formatting

The disks are formatted by this procedure. Through this operation, disks become usable with P150.

POINT

- Blank disks (model F150-000) are delivered in the formatted state. This operation is not required.
- When disks purchased on the market are used, format the disks with writable state before using.





Fig. 5.2.141




Fig. 5.2.142

POINT

For media type, four types (320 to 720k bytes) can be selected. Usually, select 720 k bytes type.





Fig. 5.2.143




*** FORMAT ***

Select media type
 320kb type ---> 1
 360kb type ---> 2
 640kb type ---> 3
 720kb type ---> 4
 4
 Insert new diskette for drive B:
 and strike any key when ready

All data in disk of drive B: are cleared,Are you sure <Y/N>?

Fig. 5.2.144




*** FORMAT ***

Select media type
 320kb type ---> 1
 360kb type ---> 2
 640kb type ---> 3
 720kb type ---> 4
 4
 Insert new diskette for drive B:
 and strike any key when ready

All data in disk of drive B: are cleared,Are you sure <Y/N>? y
 Formatting...

Fig. 5.2.145



*** FORMAT ***

Select media type
 320kb type ---> 1
 360kb type ---> 2
 640kb type ---> 3
 720kb type ---> 4
 4
 Insert new diskette for drive B:
 and strike any key when ready

All data in disk of drive B: are cleared,Are you sure <Y/N>? y
 Formatting... System transferred
 730112 bytes total disk space
 61440 bytes used by system
 668672 bytes available on disk
 Format another <Y/N>? n

1 [] 2 [] 3 [] 4 [] 5 [] 6 [] 7 [] 8 [] END

Fig. 5.2.146

NOTE

1. Depressing "N" key in the display of Fig. 5.2.144 displays "END." Depressing "END" key returns to the display shown in Fig. 5.2.141.
2. The disk formatted by P150 contains a file "COMMAND.COM." This disk can be used in place of the system disk in the file operation.

IMPORTANT

When disks are formatted, all the data on the disk are deleted. To empty formatted disks, use the file deletion function.

(3) Disk Checking

This function is for checking inconsistent or incorrect disk usage and records. The use of this function is recommended to check the directory and the disk residual capacity.





Fig. 5.2.147







Fig. 5.2.148

(4) Directory

Data disk directory information is displayed by this operation. The directory contains file names, sizes, and the date of creation and updating.



(4) Directory (Cont'd)

NOTE

1. In place of a system disk, a disk formatted by P150 (containing "COMMAND.COM" file) can be used.
2. The file name is made by using 8 characters max for file name and 3 characters max for escape character. The escape character may be omitted. If it is used, a period "," must be put before it. For file names and escape characters, the following characters are usable:

A-Z	0-9	\$	&	#
%	"	()	-
*	{	}	-	!

Although file names are written in both capital letters and small letters, P150 converts all characters into capital letters. However, the following file names cannot be used because they are used in the system.




AUX
CON
LST
PRN
NUL
IO.SYS
MSDOS.SYS
COMMAND.COM

(5) File Renaming

The file names on the data disks can be altered. However, if the same name is already present on the disk, the name cannot be used again.

POINT

Make the data disk writable in advance.



(5) File Renaming (Cont'd)





Fig. 5.2.153




Fig. 5.2.154

NOTE

1. Depressing "CANCEL" key in the display of Fig. 5.2.154 returns to the display shown in Fig. 5.2.152.
2. In place of the system disk, a disk formatted by P150 (containing "COMMAND. COM" file) can be used.

(6) File Copying





The specified files or all the files can be copied from the disk in drive B to the disk in drive A.

Drive A...Destination disk (accepting copy)

Drive B...Source disk (original files)

POINT

Make the destination disk writable in advance.



NOTE

It is recommended that all the disks (especially important ones) be copied for backup purposes, as a safety measure against accidental damage or deletion of files.

FILE COPY

The specified file contents, from the disk in drive B to the disk in drive A, are copied.




Fig. 5.2.157




Fig. 5.2.157




Fig. 5.2.158

NOTE

1. Make the destination disk writable in advance.
 2. Depressing "CANCEL" key (Fig. 5.2.158) returns to the display shown in Fig. 5.2.156.

DISK COPY

The entire contents of the disk in drive B are copied onto the disk in drive A.





Fig. 5.2.159





Fig. 5.2.160




Fig. 5.2.159




Fig. 5.2.160




Fig. 5.2.161




Fig. 5.2.161




Fig. 5.2.162



END

NOTE

1. Make the destination disk writable in advance.
2. Depressing "CANCEL" key (Fig. 5.2.159) returns to the display shown in Fig. 5.2.156.
3. To copy other disks in Fig. 5.2.162, first depress "Y" key, and then make the same operations as shown above.

(7) File Deleting

This function is used to delete unnecessary files in the data disk.

POINT

Make the data disk writable in advance.





Fig. 5.2.163




Fig. 5.2.164




Fig. 5.2.165

NOTE

1. Depressing "CANCEL" key (Fig. 5.2.165) returns to the display shown in Fig. 5.2.164
2. A disk formatted by P150 (containing "COMMAND.COM" file) can be used in place of the system disk.



IMPORTANT

Be sure to put important disks in write disable state.

6.2.10 Printing

(1) Allocation Data Printing

Only allocation data are printed out by depressing "T-COP" PRINT after connecting a printer to P150 parallel port (Centronics).



*** MASTER DISCRETE INPUT ***			UNIT NO : 1		
REFERENCE	STATION	REFERENCE	REFERENCE	STATION	REFERENCE
60001-60008	01	50001	60129-60136	--	-----
60009-60016	01	50009	60137-60144	--	-----
60017-60024	01	50017	60145-60152	--	-----
60025-60032	01	50025	60153-60160	--	-----
60033-60040	01	50033	60161-60168	--	-----
60041-60048	01	50041	60169-60176	--	-----
60049-60056	01	50049	60177-60184	--	-----
60057-60064	01	50057	60185-60192	--	-----
60065-60072	00	70001	60193-60200	--	-----
60073-60080	--	-----	60201-60208	--	-----
60081-60088	--	-----	60209-60216	--	-----
60089-60096	--	-----	60217-60224	--	-----
60097-60104	--	-----	60225-60232	--	-----
60105-60112	--	-----	60233-60240	--	-----
60119-60120	--	-----	60241-60248	--	-----
60121-60128	--	-----	60249-60256	--	-----

*** MASTER REGISTER INPUT ***			UNIT NO : 1		
REFERENCE	STATION	REFERENCE	REFERENCE	STATION	REFERENCE
80001	--	-----	80009	--	-----
80002	--	-----	80010	--	-----
80003	--	-----	80011	--	-----
80004	--	-----	80012	--	-----
80005	--	-----	80013	--	-----
80006	--	-----	80014	--	-----
80007	--	-----	80015	--	-----
80008	--	-----	80016	--	-----

Fig. 5.2.168 Printing Example

NOTE

For printer setting, refer to the next page.

(2) Hard Copy

Using a printer available on the market, connected to the parallel port of P150, then depressing "SHIFT" and "PRINT" keys simultaneously produces a hard copy of the display.

Use of Parallel Port

(a) Applicable printer

- PC-PR201 F (made by NEC Corp.)
- PC-PR101 F (made by NEC Corp.)

(b) Accessories

The following accessories are required in addition to MEMOLINK, P150, and their connecting cables (JZMSZ-W1015):

Name	Type	Q'ty	Remarks
Cable between P150 and Printer	PC-8894	1	Delivered with printer.
Printer	PC-PR201F PC-PR101F	1	Purchased from maker or agents
Printing Paper	10" x 11"	1 set	

Note: Cable and Printer above are made by NEC Corp.

(c) Setting communication parameter

Set DIP switches of PC-PR201F or PC-PR101F as follows:





Fig. 5.2.109

POINT

For detailed information of switches, refer to user's manual attached to printer.

(3) Printer Type Setting

Select "NO FORM" FEED, when using printer which cannot accept a form feed code.



ATTACH
INPUT COMMUNICATION UNIT NO.

AR : 00000

1 [] 2 [] 3 [] 4 [] 5 [] 6 [] 7 [] 8 [] B ATTACH

Fig. 5.2.170

AR : 00000

1 NO FORM 2 FEED 3 [] 4 [] 5 [] 6 [] 7 [] 8 [] B

Fig. 5.2.171

NOTE


If ATTACH operation has already been completed, perform either the following two operations:

- Depress "SHIFT" and "SUPER" VISORY keys.
- Depress "INITIAL" in status shown in Fig. 5.2.10.

6. OPERATIONAL PROCEDURES

6.1 OPERATION START

Start operation in accordance with the following flow:



* Operation needed only at initial system start.

Note: Power may be turned on randomly irrespective of station numbers.

6.2 OPERATION STOP

Stop operation after considering all operating factors of the system.

6.2.1 MEMOLINK Operation Stop

MEMOLINK operation (communications) can be stopped by stopping the master module through the programming panel. If the MEMOLINK is not operating, all data from the modules to the PCs of the stations turn OFF (input relay) or go to 0 (input register). The module is disconnected from the PCs.

By starting the master module, MEMOLINK operation (communications) is restarted. The module also restarts data exchange with the PCs.

6.2.2 PC Stop

By stopping the PCs, data exchanges between the PCs of that station and module will stop because I/O service stops. In this case, link data of that station turn OFF or go to 0, but operation (communications) will continue.

By starting PCs, the I/O service is restarted, and data exchanges with the module is also performed. Link data of that station become the normal state.

6.2.3 Power OFF

(1) Master PC power OFF

By turning off power to the master PC, the MEMOLINK stops operation (communications). At this time, all the slave stations become MEMOLINK communication errors and the "COMM ERR" indicator lights. The stations stop exchanging data with the PCs, and input data from the module to the PCs turn OFF (input relay) or go to 0 (input register).

By turning on power to the master PC again, operation (communications) with the MEMOLINK restarts, and the data exchanges between the PCs of the stations and module is also performed.

(2) Slave PC power OFF

By turning off power to the slave PCs, link data of this station turn OFF or go to 0. Only this station is disconnected from the MEMOLINK. MEMOLINK operation (communications) still continues. The master module displays the station No. of the separated slave station. If there are several trouble stations, the smallest station No. is displayed.

By turning on power again, the slave station is connected to the MEMOLINK automatically again.

(3) Optical connector power OFF

By turning off power to the optical fiber connector of one slave station, this station and the stations in the down-stream can no longer have communications with the MEMOLINK and are separated. The link data of the separated stations turn OFF or go to 0. MEMOLINK communications with the other stations continue normally. The master module displays the smallest No. of the separated stations this time. The stations to be disconnected relate only to physical positions.




Fig. 6.1 Optical Fiber Connector Power OFF

By turning on power again, all the disconnected stations are connected. Table 6.1 summarizes the foregoing.

Table 6.1 Operation Status

Condition	MEMOLINK Communication	Date Exchange between PC and Module
MEMOLINK Operation Stop (by programming panel)	Stop	No (OFF or 0)
PC Stop	Continued (Data in PC stop station: OFF or 0)	Yes (except for PC stop station)
Master PC Power OFF	Stop	No (OFF or 0)
Slave PC Power OFF	Continued (Data in power OFF station: OFF or 0)	Yes (except for power OFF station)
Optical Fiber Connector Power OFF	Communication interrupted after power OFF station. Operation continuation of upstream station (Data of disconnected station is OFF or 0.)	No disconnected station No upstream station

6.3 TROUBLESHOOTING

6.3.1 Master Module Checking

The MEMOLINK system status can be checked through the master-module numerical indicators and module status indicators.

Table 6.2 Troubles and Causes

No.	Light ON/OFF	Cause	Remarks
1	Error code display and module status shown by blinking	Self-diagnosis error. ①	Refer to Tables 3.3 and 6.3.
2	"COMM ERR" ON (SLAVE OK OFF)	MEMOLINK communication error. ②	-
3	"RXD", "TXD" OFF	MEMOLINK communication stop. ③	-
4	"I/F ACTIVE" OFF (MASTER OK OFF)	Stopped data exchange with PCs. ④	-
5	"BATT ALARM" OFF	Battery voltage lower than the specified value (2.5 V).	• Replace a battery. • Refer to Par. 6.3.4.

Note: Refer to Par. 6.2.

① Error display (E 11)

Error code E 6 (allocation data trouble, etc.) also occurs if memory data is not held well or is faulty.

A module failure can be suspected if the error E 11 is displayed during operation. Replace the module.

② MEMOLINK communication error

The failed slave station No. is indicated on the numerical indicator if this error occurs. (See Table 3.3.) Check for the following:

- ① Broken optical fiber
- ② Failure of optical connector power
- ③ Failure of slave PC power
- ④ Slave station No. setting
- ⑤ Slave module condition

③ MEMOLINK communications stop

Check for the following if E 11 is not displayed:

- ① Link data allocated
- ② MEMOLINK communications started (or communications restarted after stopping)
- ③ MEOLINK communications stopped

④ Stopped data exchange with PCs

Check for the following:

- ① MEMOLINK communications stopped
- ② PCs stopped
- ③ Correct I/O allocation of PCs
- ④ Matching of I/O allocation and link data allocation

Table 6.3 Master Module Error Indication

Error	COMM ERR	I/F ACTIVE	TXD	RXD	READY	Error Code
System ROM Error	○				○	E1
System RAM Error	○			○		E2
System RAM Error	○			○	○	E3
System RAM Error	○		○			E4
MEMOBUS Port Parameter						E5
Allocation Data Error	○		○	○		E6
WDT Error	○		○	○	○	E7
MEMOLINK Communication ROM Error	○	○				E8
MEMOLINK Communication RAM Error	○	○			○	E9

Note:

1. ○: LED is blinking
2. Check MEMOBUS port with Port 2. If MEMOBUS port parameter trouble is detected during power increase, the condition is determined to be an initial status and a default value will be.

6.3.2 Slave Module Check

A MEMOLINK communication goes to error if the slave module is in trouble. This error can be checked by the master module.

Table 6.4 Troubles and Causes

No.	Light ON/OFF	Cause	Remarks
1	Module status shown by blinking	Self diagnosis error	Refer to Table 6.5
2	"COMM ERR" ON	MEMOLINK communication error. ①	-
3	"RXD," "TXD" ON	MEMOLINK communication stop. ②	-
4	"I/F ACTIVE" OFF ("SLAVE OK" OFF)	Stopped data exchange with PCs. ③	-
5	"EXT PWR OK" OFF	No external power for optical connector.	• Check voltage. • Check fuse.

Note: Refer to Par. 6.2.

① MEMOLINK communication error

This is basically a time-out error. Check for the following:

- ① Broken optical fiber
- ② External power for optical connectors.
- ③ Master station condition (Refer to Par. 6.3.1.)

② MEMOLINK communication stop

Check for the following:

- ① Correct station No. setting
- ② MEMOLINK communications stopped
- ③ MEMOLINK communications started (or communications restarted after stopping)
- ④ Power to the master station turned on

②, ③, and ④ are problems on the master side (Refer to Par. 6.3.1).

③ Stop of data exchange with PCs

Check for the following:

- ① PCs stopped
- ② COMM ERR lit

6.3.2 Slave Module Check (Cont'd)

Table 6.5 Slave Module Error Indication

Error	COMM ERR	I/F ACTIVE	TXD	RXD	READY
System ROM Error	○				○
System RAM Error	○			○	
System RAM Error	○			○	○
System RAM Error	○		○		
Allocation Data Error	○		○	○	
WDT Error	○		○	○	○
MEMOLINK Communication ROM Error	○	○			
MEMOLINK Communication RAM Error	○	○			○

Note:

1. ○ : LED is blinking.
2. Allocation data is sent from the master during start. An allocation data error is activated if this data is incorrect or is destroyed.

6.3.3 I/O Slave Module Check

A MEMOLINK communication goes to error if the I/O slave module is in trouble. This error can be checked by the master module.

Table 6.6 Troubles and Causes

No.	Light ON/OFF	Cause	Remarks
1	Module status shown by blinking	Self-diagnosis error	Refer to Table 6.7.
2	"COMM ERR" ON	MEMOLINK communication error	
3	"RXD", "TXD" ON	MEMOLINK communication stop	
4	"I/F ACTIVE" OFF	Data transmit/receive with I/O stopped*	
5	"I/O BUS ERR" ON	2000 Series I/O bus error	

- * Check for the following:
 - I/O modules positively inserted.
 - COMM ERR lit.

Table 6.7 Slave Module Error Indication

Error	COMM ERR	TXD	RXD	READY
System ROM Error	○			○
System RAM Error	○		○	
System RAM Error	○		○	○
Allocation Data Error	○	○	○	
WDT Error	○	○	○	○

Note:

1. ○: LED is blinking.
2. Allocation data is sent from the master during start. An allocation data error is activated if this data is incorrect or is destroyed.

6.3.4 Status Reading

The status of the master module can be checked on the programming panel. The status is displayed hexadecimally in four digits.

Table 6.8 Status Codes

Code	Status
0 0 0 1	
0 0 0 2	
0 0 0 4	No data exchange with slave PC
0 0 0 8	WDT (Watchdog timer) error
0 0 1 0	MEMOLINK communication error
0 0 2 0	MEMOLINK communication ROM error
0 0 4 0	MEMOLINK communication RAM error
0 0 8 0	System ROM error
0 1 0 0	System RAM error
0 2 0 0	System RAM error
0 4 0 0	No data exchange with master PC
0 8 0 0	MEMOBUS port 1 communication error
1 0 0 0	MEMOBUS port 2 communication error
2 0 0 0	Allocation data error
4 0 0 0	MEMOBUS port parameter error
8 0 0 0	MEMOBUS stop flag

6.3.5 Battery Replacement

Backup power for master module memory is provided by a battery. It is recommended that this battery be replaced every two years. The battery service life varies with the environmental conditions (temperature and humidity) and working time (AC power failure time).

Table 6.9 Battery Specifications

Item	Specifications
Battery	Lithium battery
Type	BR-2/3A-1 (Wiring tab provided)
Manufacturer	Matsushita Battery Industry Co., Ltd.
Nominal Rated Voltage	3 V
Nominal Rated Capacity	1200 mAH
Ambient Temperature	0 to + 55°C
Storage Temperature	-20 to + 45 °C
Life	5-year warranty at 25 °C, 2 years for memory holding without conduction at 25°C.
Approx Weight	15 g

Note: When the battery in the table above is required, contact Yaskawa representative.

Replace the battery within one month if the "BATT ALARM" indicator lights on the master module.


Battery replacement:

1. Preheat a soldering iron.
2. Stop feeding power to the mounting base on which the master module is mounted.
3. Remove the master module from the mounting base.
4. Remove the master-module side panel. [See Fig. 6.2 (a).]
5. Disconnect the connector mounted at the tip of the lead wire from the printed circuit board.
6. Remove the battery from the battery holder using a screwdriver or other tool. [See Fig. 6.2 (b).]
7. Remove the lead wire from the soldering tab of the battery using the preheated soldering iron.
8. Solder the disconnected lead wire on the new battery soldering tab. Use care to observe polarity. (Positive : red lead; negative : black lead)
9. Place the new battery in the battery holder and insert the connector at the tip of the lead wire in connector of the printed circuit board. Be careful not to disconnect the connector pin.

10. Remount the master-module side panel.
11. Remount the master module on the mounting base and turn on power. Check that "BATT ALARM" lamp is off.


This completes the battery replacement.

Check that allocation data error (error code: E6) is not activated. If data are destroyed, reload data dumped on a tape or a floppy disk beforehand using the loader function of the programming panel.




586-76

(a) Side Plate Removed



586-77

(b) Removing Battery
from Battery Holder



586-78

(c) Removing Leads from Soldered Tab

Fig. 6.2 Battery Removal

7. OPERATIONAL PRECAUTIONS

7.1 BACKUP FUNCTION IN POWER FAILURE

The following three types of data are saved in the event of a power failure. A battery backs up the master module memory.

- (1) Allocation data
- (2) Disable table
- (3) MEMOBUS port parameters


The MEMOBUS port parameters are set to default values if parameter error is detected at a power-on check, and normal operation can be continued. Operation is stopped if trouble with other allocation data or disable table occurs. (Refer to Tables 3.3 and 6.3.)

The memory data are not destroyed by power failures during normal operation. However, data may be destroyed if a power failure occurs during a change of allocated data or disable status by the programming panel. Clear the memory and write allocated data correctly. Reload if data were dumped on a tape or a floppy disk beforehand.


7.2 POWER SUPPLY CAPACITY

The number of modules to be mounted depends on the power supply unit capacity, and the total current consumption.

(1) U84 LOCAL




(2) U84 REMOTE




Note: The other modules are not considered for calculation of current consumption.

7.2 POWER SUPPLY CAPACITY (Cont'd)

(3) U84S



(4) R84H



7.3 EXTERNAL POWER SUPPLY FOR OPTICAL CONNECTORS

External 24 -VDC power supply is needed to operate slave module optical connectors. See Table 3.11 for specifications.

If this power is turned on, communications with downstream stations can be activated normally even if power to PC of the station is turned off.

7.4 MASTER MODULE MOUNTING POSITION

The direction to open and close the cover of the external wiring connector terminals on the faceplate of the master module is opposite that of other modules. Therefore, mounting at the right end of the mounting base is recommended to avoid module wiring interference, etc.

8. OPTICAL FIBER CABLES

8.1 INTERMODULE CONNECTIONS

Optical fiber cables are installed to connect the master module (B1084) and slave module (B1085) and between slave modules. The master module has one connector for an optical fiber cable while a slave module has two such connectors as shown in Figs. 3.2 and 3.10. The optical fiber cable connectors for a slave module are called UP WARD and DOWN WARD as shown in Fig. 8.1.




Fig. 8.1 Slave Optical Connectors

UP WARD: The optical fiber cable from the master module or the slave module in the preceding stage is connected. (For connection upstream)

DOWN WARD: The optical fiber cable to the slave module in the subsequent stage is connected. (For connection downstream.) Connect the connectors as shown in Fig. 8.2.




Fig. 8.2 Optical Fiber Cable Connections

The connectors of the master and slave modules, as well as of optical fiber cables, are provided with protective caps to prevent contamination by foreign matter or damage. Do not remove these protective caps until immediately before the optical fiber cables are connected.






Fig. 8.3 Protective Cap

8.2 SPECIFICATIONS OF OPTICAL FIBER CABLES

Table 8.1 Specifications of Optical Fiber Cable

Item	Specifications	
Cable	2-core, Type Si, compound glass fiber (indoor use)	
Type	Type CA9003-[]M-AH	Type CA9003-[]M-BL
Length	5 to 500 m (in increments of 5 m)	5 to 1000 m (in increments of 5 m)
Transmission Loss	24 dB/km	12 dB/km
Connecting Loss	2 dB max	
Ambient Temperature	-20 to +75 °C	
Operating Temperature	-10 to +70 °C	
Allowable Tension	20 kg max (3 kg max for connected part)	
Allowable Bending Radius	45 mm min (90 mm min for installation)	85 mm min (170 mm min for installation)
Compression Strength	5 kg · cm max	10 kg · cm max
Core	200 μ m	
Cladding	250 μ m	
Core Sheathing	Nylon resin (Outer diameter: 0.9 mm)	
Reinforcement	FRP	
Cable Sheathing	PVC (orange)	
Finish Outer Diameter	4.5 mm	8.5 mm
Approx Weight	15 kg/km	65 kg/km
Sectional View		

Note:

- The optical fiber cables are provided with connectors at both ends. Sufficient allowance of cable length should be given in wiring. Select a type suited to the wiring distance and then specify the length in 5-m units corresponding to [] of the type when ordering from Yaskawa representative.
- For information on optical fiber cable with tension member, consult Yaskawa representative.

8.3 OPERATIONAL PRECAUTIONS FOR OPTICAL FIBER CABLE

Optical fiber cables contain thin glass fibers as their cores, and these optical fibers may break if they are bent, pulled or subjected to unreasonably strong force. If these optical fibers are broken, they cannot be spliced as in electric wires, and the following precautions should be taken:

- (1) Do not bend the cables sharply. Use the allowable bending radius shown in Table 8.1 as a reference.
- (2) Do not pull the cables excessively. Use the allowable tension shown in Table 8.1 as a reference.
- (3) Do not compress the cables or subject them to damaging situations.
- (4) Do not step on the cables or place articles on them.
- (5) Do not twist the cables.
- (6) Do not pull them by holding the optical connector.
- (7) Do not insert the optical connectors diagonally. When connecting them, insert the optical connectors straight and push them until they are positively locked.
- (8) When disconnecting the optical connectors, remove the optical connector pushing the metal locking pieces on both sides with the lock unlocked. (Do not pull the cable.)




Fig. 8.4 Optical Connector Removal

8.4 OPTICAL FIBER CABLE INSTALLATION

(1) Use optical fiber cables of the specifications given in Table 8.1. When ordering, specify lengths in 5-m units. Provide a sufficient surplus to the lengths for optical fiber cables.

Table 8.2 Applicable Optical Fiber Cable

Item	Optical Fiber Cable Type	
	CA9003-[]M-AH	CA9003-[]M-BL
Length	5 to 500 m	5 to 1000 m
Finished Outer Diameter	45 mm	85 mm
Allowable	45 mm min (90 mm when installed)	85 mm min (170 mm when installed)
Allowable Tension	Cable 20 kg max	20 kg max
	Connector 3 kg max	3 kg max

Note:

1. [] in the optical fiber cable type column is the length in 5-m units.
2. Both ends of a cable have connectors.
3. The cables are for indoor use.

(2) Check for obstacles along the route for installing the optical fiber cables. Select routes that assure safety of the optical fiber cables.

(3) Install the optical fiber cables so that they are physically separated from other electrical cables whenever possible. If they must be installed in the same pits or ducts, install the optical fiber cables last.

(4) Place protective pieces or padding at the corners of structures or at curves of the cable routes to protect the optical fiber cables.

(5) Do not bend excessively or apply strong tension or pressure to the optical fibers during installation. As the parts of the optical connectors are not strong, do not hold the optical connectors when installing the optical fiber cables.

(6) Before installing the optical fiber cables, place the optical connectors inside vinyl pipe or other similar material and secure them using vinyl tape.

8.4 OPTICAL FIBER CABLE INSTALLATION (Cont'd)

(7) Fig. 8.5 shows how to attach a pulling cord at the tip of an optical fiber cable.




Fig. 8.5 Pulling Cord at Tip of Optical Fiber Cable

(8) Anchor the cable drum (bobbin) at the installation start point when installing an optical fiber cable. Rotate the drum (bobbin) to pay out the cable and pull the cord. Install the cables at a pulling rate of less than 10 m/minute.

(9) Install the optical fiber cables straight without twisting them. The cables may kink and cause breakage of the optical fibers if the cables are twisted.




Fig. 8.6 Cable Kink

(10) After installing the optical fiber cables, connect the optical connectors of the optical fiber cables to those of the master and slave modules. Remove the optical connector protective caps. Insert the optical connectors straight and push till the connectors are positively locked. (Do not push excessively.) Clamp the optical fiber cable so that force is not applied to the optical connectors.

(11) After installing the optical fiber cables, check for broken fibers if this is possible, using one of the following methods:




Fig. 8.7 Check for Broken Cord Using He-Ne Laser Beam

① Emit a He-Ne laser beam (visible red beam) form one end of the optical fiber cable and visually check the beam at the other end.

② Optical fiber loss measurement

Broken optical fibers are located by measuring optical fiber losses using a standard lights source.




Fig. 8.8 Check for Broken Cord by Optical Fiber Loss Measurement


Assuming the loss (catalog value) per km of the installed optical fiber cable to be z (dB), the transmission loss = $P_1 - P_2 - L \times z/1000$ (dBm)

③ Transmission optical power measurement


Optical fiber breakage is located by measuring the optical transmission power from the master module using an optical power meter at the reception end of the slave module side after actually operating the MEMOLINK system.

9. DIMENSIONS in mm

(1) Master Module Type JAMSC -B1084




(2) Slave Module Type JAMSC-B1085




9. DIMENSIONS in mm (Cont'd)

(3) I/O Slave Module Type DISCT-J2040




(4) Optical Fiber Cable Type CA9003-[] M-AH



Note:

1. [] of type indicates length L.
2. L = 5 to 300 m in increments of 5 m.

(5) Optical Fiber Cable Type CA9003-[] M-BL



Note:

1. [] of type indicates length L.
2. L = 305 to 500 m in increments of 5 m.
3. When L = 5 m, asterisked length is 0.5 m.

APPENDIX J2040 REGISTER SERVICE

Normally, discrete data is sent to the discrete module, and register data to the register module. In the following cases, register data is sent to the discrete module:

- (1) Registers are allocated to the discrete module.
- (2) The register allocation is larger than the register module size, and the discrete module has an empty space for more than 2 bytes. In this case register data is sent beginning with the next byte of the discrete data.

Example 1: As shown below, the rack contains discrete modules only.

POWER SUPPLY	I/O SLAVE	32-POINT DISCRETE INPUTS	32-POINT DISCRETE INPUTS	32-POINT DISCRETE INPUTS	32-POINT DISCRETE INPUTS
--------------	-----------	--------------------------	--------------------------	--------------------------	--------------------------

LINK DATA ALLOCATION:
4-REGISTER INPUTS

I/O service of J2040 is as follows:

- Slot 1: 2 Registers (Registers 1, 2)*
- Slot 2: 2 Registers (Registers 3, 4)*
- Slot 3:

* The register Nos. in parentheses () correspond to the allocation Nos. For example, the input of the first register set in the allocation is sent to the first 16 points of slot 1.

Example 2: As shown below, the rack contains modules in slots 1 to 4.

POWER SUPPLY	I/O SLAVE	32-POINT DISCRETE INPUTS	32-POINT DISCRETE INPUTS	4-REGISTER INPUTS	32-POINT DISCRETE INPUTS
--------------	-----------	--------------------------	--------------------------	-------------------	--------------------------

LINK DATA ALLOCATION:
• 48-POINT DISCRETE INPUTS
• 6-REGISTER INPUTS

I/O service of J2040 is as follows:

- Slot 1: 32-Point discretes
- Slot 2: 16-Point discretes + 1-Register (Register 1)*
- Slot 3: 4-Registers (Registers 3 to 6)*
- Slot 4: 1-Registers (Registers 2)*

* The register Nos. in parentheses () correspond to the allocation Nos. For example, the input of the first register set in the allocation is sent to the last 16 points of slot 2.



A Better Tomorrow for Industry through Automation
YASKAWA Electric Mfg. Co., Ltd.

TOKYO OFFICE Otemachi Bldg., Chiyoda-ku, Tokyo, 100 Japan
Phone (03) 284-9111, -9146, -9148 Telex YASKAWA J33580 Fax (03) 284-9034

SEOUL OFFICE Seoul Center Bldg., 91-1 So Kong-Dong, Chung-Ku, Seoul, Korea
Phone (02) 776-7844 Fax (02) 753-2139

SINGAPORE OFFICE CPT Bldg., 79 Robinson Road No. 24-03, Singapore 0108
Phone 2217530 Telex (67) 24890 YASKAWA RS Fax (65) 224-5864

TAIPEI OFFICE Union Commercial Bldg., 137, Nanking East Road, Sec. 2, Taipei, Taiwan
Phone (2) 531-7732, 551-7065 Fax (2) 537-3837

YASKAWA ELECTRIC AMERICA, INC.: SUBSIDIARY

Los Angeles Office 7341 Lincoln Way, Garden Grove, California 92641, U. S. A.
Phone (714) 891-5911 Telex (230) 678396 YASKAWAUS TSTN Fax (714) 894-3258

New Jersey Office 30 Two Bridges Road, Fairfield, New Jersey 07006, U. S. A.
Phone (201) 575-5040 Fax (201) 575-5047

Chicago Office/YASNAC America 3160 MacArthur Blvd., Northbrook, Illinois 60062, U. S. A.
Phone (312) 291-2340 Telex (230) 270197 YSKW YSNAC NBRK Fax (312) 498-2430

YASKAWA ELECTRIC EUROPE GmbH: SUBSIDIARY
Monschauerstrasse 1, 4000 Düsseldorf 11, West Germany
Phone (0211) 50127 Telex (41) 8568673 YASD D Fax (0211) 507737

YASKAWA ELÉTRICO DO BRASIL COMERCIO LTDA.: SUBSIDIARY
Av. Brig. Faria Lima 1664-cj. 611, Pinheiros, São Paulo-SP, Brasil CEP-01452
Phone (011) 212-5464, 813-3694 Telex (011) 24168 FERN BR

Due to ongoing product modification/improvement, data subject to change without notice.