

## Machine Controller MP3000 Series

# MP3200


# USER'S MANUAL

Power Supply Unit model: JEPMC-PSA3012-E or JEPMC-PSD3012-E

CPU Unit model: JEPMC-CP3201-E or JEPMC-CP3202-E

Base Unit model: JEPMC-BUB3003-E, JEPMC-BUB3005-E, or JEPMC-BUB3008-E

Rack Expansion Interface Unit model: JEPMC-EXU3001-E or JEPMC-EXU3002-E



Introduction **1**

Appearances and Parts **2**

CPU Unit Functionality **3**

Specifications **4**

External Dimensions **5**

Copyright © 2011 YASKAWA ELECTRIC CORPORATION

---

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

## About this Manual

This manual describes the specifications and system configuration of MP3200 Machine Controllers and the functionality of the CPU Units.

Read this manual carefully to ensure the correct usage of the Machine Controller and apply the Machine Controller to control your manufacturing system.

Keep this manual in a safe place so that it can be referred to whenever necessary.

## Using this Manual

### ◆ Basic Terms

Unless otherwise specified, the following definitions are used:

Basic Terms	Meaning
MP2000	A Machine Controller in the MP2000 Series
MP3000	A Machine Controller in the MP3000 Series
MPE720	The Engineering Tool or a personal computer running the Engineering Tool
PLC	A Programmable Logic Controller
MP3200	A generic name for the Power Supply Unit, CPU Unit, Base Unit, and Rack Expansion Interface Unit
Motion Control Function Modules	The Function Modules in the Motion Modules and the Function Modules in the SVC32 or SVR32 built into the CPU Units.
Communications Function Modules	The Function Modules in the Communications Modules and the Function Modules in the 218IFD built into the CPU Units.

### ◆ MPE720 Engineering Tool Version Number

In this manual, the operation of MPE720 is described using screen captures of MPE720 version 7.

### ◆ Indication of Reverse Signals

In this manual, the names of reverse signals (ones that are valid when low) are written with a forward slash (/) before the signal name, as shown in the following example:

Notation Examples

- $\overline{S-ON}$  = /S-ON
- $\overline{P-CON}$  = /P-CON

### ◆ Terms Used to Describe “Torque”

Although the term “torque” is commonly used when describing rotary Servomotors and “force” is used when describing linear Servomotors, this manual uses “torque” when describing either one (excluding parameter names).

---

## ◆ Copyrights

- MECHATROLINK is a trademark of the MECHATROLINK Members Association.
- DeviceNet is a registered trademark of the ODVA (Open DeviceNet Venders Association).
- PROFIBUS is a trademark of the PROFIBUS User Organization.
- Ethernet is a registered trademark of the Xerox Corporation.
- Other product names and company names are the trademarks or registered trademarks of the respective company. “TM” and the ® mark do not appear with product or company names in this manual.

## ◆ Visual Aids

The following aids are used to indicate certain types of information for easier reference.



Important

Indicates precautions or restrictions that must be observed.

Indicates alarm displays and other precautions that will not result in machine damage.



Note

Indicates items for which caution is required or precautions to prevent operating mistakes.

Example

Indicates operating or setting examples.

Information

Indicates supplemental information to deepen understanding or useful information.



Terms

Indicates definitions of difficult terms or terms that have not been previously explained in this manual.

## Related Manuals

The following table lists the related manuals. Refer to these manuals as required.

Be aware of all product specifications and restrictions to product application before you attempt to use any product.

Category	Manual Name	Manual Number	Contents
Basic functionality	Machine Controller MP2000/MP3000 Series Machine Controller System Setup Manual	SIEP C880725 00	Describes the functions of the MP2000/MP3000-series Machine Controllers and the procedures that are required to use the Machine Controller, from installation and connections to settings, programming, trial operation, and debugging.
	Machine Controller MP3000 Series MP3200 Troubleshooting Manual	SIEP C880725 01	Describes troubleshooting an MP3000-series MP3200 Machine Controller.
	Machine Controller MP2200 User's Manual	SIEP C880700 14	Describes the functions, specifications, and application methods of the MP2200 Machine Controller.
	Machine Controller MP2000 Series MPU-01 Multi-CPU Module User's Manual	SIEP C880781 05	Describes the functions, specifications, operating methods, maintenance, inspections, and troubleshooting of the MP2000-series MPU-01 Multi-CPU Module.
Communications functionality	Machine Controller MP3000 Series Communications User's Manual	SIEP C880725 12	Describes the specifications, system configuration, and communications connection methods for the Ethernet communications that are used with an MP3000-series Machine Controller.
	Machine Controller MP2000 Series Communication Module User's Manual	SIEP C880700 04	Provides information on the Communications Modules that can be connected to an MP2000-series Machine Controller and describes the communications methods.
	Machine Controller MP2000 Series 262IF-01 FL-net Communication Module User's Manual	SIEP C880700 36	Describes the specifications and communications methods for the FL-net Communications Module that can be connected to an MP2000-series Machine Controller.
	Machine Controller MP2000 Series 263IF-01 EtherNet/IP Communication Module User's Manual	SIEP C880700 39	Describes the specifications and communications methods for the EtherNet/IP Communications Module that can be connected to an MP2000-series Machine Controller.
	Machine Controller MP2000 Series 265IF-01 CompoNet Module User's Manual	SIEP C880700 44	Describes the specifications and communications methods for the CompoNet Communications Module that can be connected to an MP2000-series Machine Controller.

Continued on next page.

Continued from previous page.

Category	Manual Name	Manual Number	Contents
Motion control functionality	Machine Controller MP3000 Series Motion Control User's Manual	SIEP C880725 11	Describes the specifications, system configuration, and operating methods for the SVC32/SVR32 Motion Function Modules that are used in an MP3000-series Machine Controller.
	Machine Controller MP2000 Series Pulse Output Motion Module PO-01 User's Manual	SIEP C880700 28	Describes the functions, specifications, and operating methods of the MP2000-series PO-01 Motion Module.
	Machine Controller MP2000 Series SVA-01 Motion Module User's Manual	SIEP C880700 32	Describes the functions, specifications, and operating methods of the MP2000-series SVA-01 Motion Module.
	Machine Controller MP2000 Series Built-in SVB/SVB-01 Motion Module User's Manual	SIEP C880700 33	Describes the functions, specifications, and operating methods of the MP2000-series Motion Module (built-in Function Modules: SVB, SVB-01, and SVR).
	Machine Controller MP2000 Series SVC-01 Motion Module User's Manual	SIEP C880700 41	Describes the functions, specifications, and operating methods of the MP2000-series SVC-01 Motion Module.
Programming	Machine Controller MP3000 Series Ladder Programming Manual	SIEP C880725 13	Describes the ladder programming specifications and instructions of MP3000-series Machine Controller.
	Machine Controller MP3000 Series Motion Programming Manual	SIEP C880725 14	Describes the motion programming and sequence programming specifications and instructions of MP3000-series Machine Controller.
Engineering Tools	Machine Controller MP2000/MP3000 Series MPLoader Ver. 4 User's Manual	SIEP C880761 01	Describes how to install and operate the MPLoader.
	Machine Controller MP2000/MP3000 Series MPLoad Maker Version 4 User's Manual	SIEP C880761 02	Describes how to install and operate the MPLoad Maker.
	Machine Controller MP2000/MP3000 Series Engineering Tool MPE720 Version 7 User's Manual	SIEP C880761 03	Describes how to operate MPE720 version 7.
I/O Modules	Machine Controller MP2000 Series Analog Input/Analog Output Module AI-01/AO-01 User's Manual	SIEP C880700 26	Describes the functions, specifications, and operating methods of the AI-01 and AO-01 I/O Modules for MP2000-series Machine Controllers.
	Machine Controller MP2000 Series Counter Module CNTR-01 User's Manual	SIEP C880700 27	Describes the functions, specifications, and operating methods of the CNTR-01 Counter Module for MP2000-series Machine Controllers.
	Machine Controller MP2000 Series I/O Module User's Manual	SIEP C880700 34	Describes the functions, specifications, and operating methods of the LIO-01, LIO-02, LIO-04, LIO-05, LIO-06, and DO-01 I/O Modules for MP2000-series Machine Controllers.

Continued on next page.

Continued from previous page.

Category	Manual Name	Manual Number	Contents
MECHA-TROLINK I/O	MECHATROLINK-III Compatible I/O Module User's Manual	SIEP C880781 04	Describes the functions, specifications, operating methods, and MECHATROLINK-III communications for the Remote I/O Modules for MP2000/MP3000-series Machine Controllers.
	Machine Controller MP900/MP2000 Series Distributed I/O Module User's Manual MECHATROLINK System	SIE-C887-5.1	Describes MECHATROLINK distributed I/O for MP900/MP2000-series Machine Controllers.

# Safety Precautions

The following signal words and marks are used to indicate safety precautions in this manual.


Information marked as shown below is important for safety. Always read this information and heed the precautions that are provided.




Indicates precautions that, if not heeded, could possibly result in loss of life or serious injury.




Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or property damage.

If not heeded, even precautions classified as cautions () can lead to serious results depending on circumstances.



Indicates prohibited actions. For example,  indicates prohibition of open flame.



Indicates mandatory actions. For example,  indicates that grounding is required.

The following precautions are for storage, transportation, installation, wiring, operation, maintenance, inspection, and disposal. These precautions are important and must be observed.

## ◆ General Precautions

### WARNING

- The installation must be suitable and it must be performed only by an experienced technician. There is a risk of electrical shock or injury.
- Before connecting the machine and starting operation, make sure that an emergency stop procedure has been provided and is working correctly. There is a risk of injury.
- Do not approach the machine after a momentary interruption to the power supply. When power is restored, the Machine Controller and the device connected to it may start operation suddenly. Provide safety measures in advance to ensure human safety when operation restarts. There is a risk of injury.
- Do not touch anything inside the Machine Controller. There is a risk of electrical shock.
- Do not remove the front cover, cables, connector, or options while power is being supplied. There is a risk of electrical shock, malfunction, or damage.
- Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch the cables. There is a risk of electrical shock, operational failure of the product, or burning.
- Do not attempt to modify the Machine Controller in any way. There is a risk of injury or device damage.



## ◆ Storage and Transportation

### CAUTION

- Do not store the Machine Controller in any of the following locations.
  - Locations that are subject to direct sunlight
  - Locations that are subject to ambient temperatures that exceed the storage conditions
  - Locations that are subject to ambient humidity that exceeds the storage conditions
  - Locations that are subject to rapid temperature changes and condensation
  - Locations that are subject to corrosive or inflammable gas
  - Locations that are subject to excessive dust, dirt, salt, or metallic powder
  - Locations that are subject to water, oil, or chemicals
  - Locations that are subject to vibration or shockThere is a risk of fire, electrical shock, or device damage.
- Hold onto the main body of the Machine Controller when transporting it.  
Holding the cables or connectors may damage them or result in injury.
- Do not overload the Machine Controller during transportation. (Follow all instructions.)  
There is a risk of injury or an accident.
- Never subject the Machine Controller to an atmosphere containing halogen (fluorine, chlorine, bromine, or iodine) during transportation.  
There is a risk of malfunction or damage.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, pallets, or plywood, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.  
Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.  
If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.


## ◆ Installation

### CAUTION


- Do not install the Machine Controller in any of the following locations.
  - Locations that are subject to direct sunlight
  - Locations that are subject to ambient temperatures that exceed the operating conditions
  - Locations that are subject to ambient humidity that exceeds the operating conditions
  - Locations that are subject to rapid temperature changes and condensation
  - Locations that are subject to corrosive or inflammable gas
  - Locations that are subject to excessive dust, dirt, salt, or metallic powder
  - Locations that are subject to water, oil, or chemicals
  - Locations that are subject to vibration or shockThere is a risk of fire, electrical shock, or device damage.
- Never install the Machine Controller in an atmosphere containing halogen (fluorine, chlorine, bromine, or iodine).  
There is a risk of malfunction or damage.
- Do not step on the Machine Controller or place heavy objects on the Machine Controller.  
There is a risk of injury or an accident.
- Do not block the air exhaust ports on the Machine Controller. Do not allow foreign objects to enter the Machine Controller.  
There is a risk of internal element deterioration, malfunction, or fire.
- Always mount the Machine Controller in the specified orientation.  
There is a risk of malfunction.
- Leave the specified amount of space between the Machine Controller, and the interior surface of the control panel and other devices.  
There is a risk of fire or malfunction.
- Do not subject the Machine Controller to strong shock.  
There is a risk of malfunction.
- Suitable Battery installation must be performed and it must be performed only by an experienced technician.  
There is a risk of electrical shock, injury, or device damage.
- Do not touch the electrodes of the Battery.  
Static electricity may damage the Battery.

## ◆ Wiring

### ⚠ CAUTION

- Check the wiring to be sure it has been performed correctly.  
There is a risk of motor run-away, injury, or accidents.
- Always use a power supply of the specified voltage.  
There is a risk of fire or accident.
- In places with poor power supply conditions, ensure that the input power is supplied within the specified voltage range.  
There is a risk of device damage.
- Install breakers and other safety measures to provide protection against shorts in external wiring.  
There is a risk of fire.
- Provide sufficient shielding when using the Machine Controller in the following locations.
  - Locations that are subject to noise, such as from static electricity
  - Locations that are subject to strong electromagnetic or magnetic fields
  - Locations that are subject to radiation
  - Locations that are near power linesThere is a risk of device damage.
- Configure the circuits to turn ON the power supply to the CPU Unit before the 24-V I/O power supply. Refer to the following manual for details on circuits.  
 *MP3000 Series CPU Unit Instructions* (Manual No.: TOBP C880725 16)  
If the power supply to the CPU Unit is turned ON after the external power supply, e.g., the 24-V I/O power supply, the outputs from the CPU Unit may momentarily turn ON when the power supply to the CPU Unit turns ON. This can result in unexpected operation that may cause injury or device damage.
- Provide emergency stop circuits, interlock circuits, limit circuits, and any other required safety measures in control circuits outside of the Machine Controller.  
There is a risk of injury or device damage.
- If you use MECHATROLINK I/O Modules, use the establishment of MECHATROLINK communications as an interlock output condition.  
There is a risk of device damage.
- Connect the Battery with the correct polarity.  
There is a risk of battery damage or explosion.
- Select the I/O signal wires for external wiring to connect the Machine Controller to external devices based on the following criteria:
  - Mechanical strength
  - Noise interference
  - Wiring distance
  - Signal voltage
- Separate the I/O signal cables for control circuits from the power cables both inside and outside the control panel to reduce the influence of noise from the power cables.  
If the I/O signal lines and power lines are not separated properly, malfunction may occur.

Example of Separated Cables



## ◆ Operation

### CAUTION

- Follow the procedures and instructions in the user's manuals for the relevant products to perform normal operation and trial operation.  
Operating mistakes while the Servomotor and machine are connected may damage the machine or even cause accidents resulting in injury or death.
- Implement interlock signals and other safety circuits external to the Machine Controller to ensure safety in the overall system even if the following conditions occur.
  - Machine Controller failure or errors caused by external factors
  - Shutdown of operation due to Machine Controller detection of an error in self-diagnosis and the subsequent turning OFF or holding of output signals
  - Holding of the ON or OFF status of outputs from the Machine Controller due to fusing or burning of output relays or damage to output transistors
  - Voltage drops from overloads or short-circuits in the 24-V output from the Machine Controller and the subsequent inability to output signals
  - Unexpected outputs due to errors in the power supply, I/O, or memory that cannot be detected by the Machine Controller through self-diagnosis.There is a risk of injury, device damage, or burning.

## ◆ Maintenance and Inspection

### CAUTION

- Do not attempt to disassemble or repair the Machine Controller.  
There is a risk of electrical shock, injury, or device damage.
- Do not change any wiring while power is being supplied.  
There is a risk of electrical shock, injury, or device damage.
- Suitable Battery replacement must be performed and it must be performed only by an experienced technician.  
There is a risk of electrical shock, injury, or device damage.
- Replace the Battery only while power is supplied to the MP3200.  
Replacing the Battery while the power supply to the MP3200 is turned OFF may result in loss of the data stored in memory in the MP3200.
- When you replace the Battery, do not touch the electrodes of the Battery.  
Static electricity may damage the Battery.
- Do not forget to perform the following tasks when you replace the CPU Unit:
  - Back up all programs and parameters from the CPU Unit that is being replaced.
  - Transfer all saved programs and parameters to the new CPU Unit.If you operate the CPU Unit without transferring this data, unexpected operation may occur. There is a risk of injury or device damage.

---

## ◆ Disposal

### CAUTION

- Dispose of the Machine Controller as general industrial waste.
- Observe all local laws and ordinances when you dispose of used Batteries.

## ◆ Other General Precautions

### Observe the following general precautions to ensure safe application.

- The products shown in the illustrations in this manual are sometimes shown without covers or protective guards. Always replace the cover or protective guard as specified first, and then operate the products in accordance with the manual.
- The illustrations that are presented in this manual are typical examples and may not match the product you received.
- If the manual must be ordered due to loss or damage, inform your nearest Yaskawa representative or one of the offices listed on the back of this manual.

---

# Warranty

## ◆ Details of Warranty

### ■ Warranty Period

The warranty period for a product that was purchased (hereinafter called “delivered product”) is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

### ■ Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the warranty period above. This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- Causes not attributable to the delivered product itself
- Modifications or repairs not performed by Yaskawa
- Abuse of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from Yaskawa
- Events for which Yaskawa is not responsible, such as natural or human-made disasters

## ◆ Limitations of Liability

- Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

---

## ◆ Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
  - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
  - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
  - Systems, machines, and equipment that may present a risk to life or property
  - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
  - Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

## ◆ Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

---

# Contents

About this Manual .....	iii
Using this Manual .....	iii
Related Manuals .....	v
Safety Precautions .....	viii
Warranty .....	xiv

## 1

### Introduction

---

<b>1.1</b>	<b>Definition of Terms .....</b>	<b>1-2</b>
	MP3200 .....	1-2
	Racks .....	1-3
	Main Rack and Expansion Racks .....	1-3
	Rack Numbers .....	1-6
	Unit Numbers .....	1-7
	Slot Numbers .....	1-7
<b>1.2</b>	<b>System Configuration Example .....</b>	<b>1-8</b>
<b>1.3</b>	<b>Devices and Components That Are Required to Build a System .....</b>	<b>1-9</b>
	MP3200 Unit List .....	1-11
	Optional Modules .....	1-12
<b>1.4</b>	<b>Precautions When Combining Products .....</b>	<b>1-14</b>
	Precautions When Combining MP3200 Units .....	1-14
	Precautions When Combining Optional Modules .....	1-14
<b>1.5</b>	<b>Precautions When Setting the Parameters .....</b>	<b>1-15</b>
	Precautions When Setting the Circuit Numbers .....	1-15
	Precautions When Setting Module Configuration Definitions .....	1-15

## 2

### Appearances and Parts

---

<b>2.1</b>	<b>Power Supply Units .....</b>	<b>2-2</b>
	Appearance and Part Names .....	2-2
	Indicators .....	2-2
	Connectors .....	2-3
<b>2.2</b>	<b>CPU Unit .....</b>	<b>2-5</b>
	Appearance and Part Names .....	2-5
	Display and Indicators .....	2-6
	Switches .....	2-9
	Connectors .....	2-11
	Fan .....	2-12
	Temperature Sensor .....	2-13
<b>2.3</b>	<b>Base Units .....</b>	<b>2-14</b>
	Appearance and Part Names .....	2-14
	Connector .....	2-14



<b>2.4</b>	<b>Rack Expansion Interface Unit . . . . .</b>	<b>2-15</b>
	Appearance and Part Names . . . . .	2-15
	Indicators . . . . .	2-16
	Connectors . . . . .	2-17

## 3 CPU Unit Functionality

<b>3.1</b>	<b>Basic Functionality . . . . .</b>	<b>3-2</b>
	Programs . . . . .	3-2
	Registers . . . . .	3-19
	Execution Scheduling . . . . .	3-31
	Scans . . . . .	3-32
<b>3.2</b>	<b>Function Modules . . . . .</b>	<b>3-38</b>
	Self Configuration . . . . .	3-38
	Communications Function Module (218IFD) . . . . .	3-48
	Motion Control Function Modules (SVC32 and SVR32) . . . . .	3-50
	The M-EXECUTOR . . . . .	3-56
	Data Logging . . . . .	3-70
	USB Memory . . . . .	3-85
	File Transfer . . . . .	3-89
	Security . . . . .	3-93
	Calendar . . . . .	3-93
<b>3.3</b>	<b>Multi-CPU Functions . . . . .</b>	<b>3-94</b>
	Differences between Sub CPU Synchronization and Slave CPU Synchronization . . . . .	3-94
	Sub CPU Synchronization . . . . .	3-95
	Slave CPU Synchronization . . . . .	3-108

## 4 Specifications

<b>4.1</b>	<b>MP3200 Installation and Usage Conditions . . . . .</b>	<b>4-2</b>
	Control Panel Cooling Method . . . . .	4-2
<b>4.2</b>	<b>Power Supply Unit Specifications . . . . .</b>	<b>4-4</b>
<b>4.3</b>	<b>CPU Unit Specifications . . . . .</b>	<b>4-5</b>
	Hardware Specifications . . . . .	4-5
	Performance Specifications . . . . .	4-6
	Communications Specifications . . . . .	4-9
	Motion Control Function Module Specifications . . . . .	4-10
	M-EXECUTOR Specifications . . . . .	4-11
	USB Memory Specifications . . . . .	4-12
	System Register Specifications . . . . .	4-13
<b>4.4</b>	<b>Base Unit Specifications . . . . .</b>	<b>4-80</b>
<b>4.5</b>	<b>Rack Expansion Interface Unit Specifications . . . . .</b>	<b>4-81</b>

---

# 5

## External Dimensions

---

5.1	Power Supply Units . . . . .	5-2
5.2	CPU Units . . . . .	5-3
5.3	Base Units . . . . .	5-4
5.4	Rack Expansion Interface Units . . . . .	5-6

Index

Revision History

# Introduction

# 1

This chapter introduces the MP3200.

<b>1.1</b>	<b>Definition of Terms</b> . . . . .	<b>1-2</b>
	MP3200 . . . . .	1-2
	Racks . . . . .	1-3
	Main Rack and Expansion Racks . . . . .	1-3
	Rack Numbers . . . . .	1-6
	Unit Numbers . . . . .	1-7
	Slot Numbers . . . . .	1-7
<b>1.2</b>	<b>System Configuration Example</b> . . . . .	<b>1-8</b>
<b>1.3</b>	<b>Devices and Components That Are Required to Build a System</b>	<b>1-9</b>
	MP3200 Unit List . . . . .	1-11
	Optional Modules . . . . .	1-12
<b>1.4</b>	<b>Precautions When Combining Products</b> . . . . .	<b>1-14</b>
	Precautions When Combining MP3200 Units . . . . .	1-14
	Precautions When Combining Optional Modules . . . . .	1-14
<b>1.5</b>	<b>Precautions When Setting the Parameters</b> . . . . .	<b>1-15</b>
	Precautions When Setting the Circuit Numbers . . . . .	1-15
	Precautions When Setting Module Configuration Definitions . . . . .	1-15

# 1.1 Definition of Terms

This section defines terms that have specific meanings in this manual.


## MP3200

”MP3200” is a collective term that refers to the four Units in the following table.

Unit Name	Primary Function
Power Supply Unit	Supplies the power that is needed for the operation of the Units that are connected to each other and to any Optional Modules that are connected in the Controller.
CPU Unit	Stores the module definitions and programs, and interprets the programs. The CPU Unit also controls the Optional Modules.
Base Unit	Used to mount Optional Modules.
Rack Expansion Interface Unit	Used to expand a Rack.

## MP3200 Connection Example


The MP3200 is typically connected as shown in the following examples.



## Racks

A Rack is a set of Units that are connected to each other.

Connection Example



## Main Rack and Expansion Racks

You can add Units and Optional Modules to a Rack to expand functionality. However, if a restriction such as the power supply capacity or number of Base Unit slots for one Rack is exceeded, you must add an Expansion Rack.

You can achieve the following things by adding Units or Optional Modules to a Rack.

- Increase the number of Optional Modules that you can use.
- Increase the number of axes that are controlled.
- Use more than one CPU Unit to increase the speed of system response.\*

\* You can not only add Expansion Racks, but you can also achieve more things by expanding the system.

- If you add an Expansion Rack, you can use Sub CPU synchronization under a Main CPU Unit.
- If you expand the system, you can use slave CPU synchronization with the CPU Units.

Refer to the following section for details on Sub CPU synchronization and slave CPU synchronization.

3.3 Multi-CPU Functions (page 3-94)

If you add Racks, the Racks are classified into the Main Rack and Expansion Racks.

Type	Description
Main Rack	The Main Rack contains the Main CPU Unit. There can be only one Main Rack in any one system configuration.
Expansion Racks	Expansion Racks are connected to the Main Rack. You can connect up to six Expansion Racks to the Main Rack. (You can connect up to three Expansion Racks by using a Rack Expansion Interface Unit and up to three Expansion Racks by using EXIOIF Modules.)

The method for adding Expansion Racks depends on the number of CPU Units that you use.

Number of CPU Units in Use	Method to Add Expansion Racks
One CPU Unit	Use MP2200 Base Units and EXIOIF Modules (MP2000-series Optional Modules) to add Expansion Racks.* <sup>1</sup>
Two CPU Units	Use one of the following methods. <ul style="list-style-type: none"> <li>• Method 1 Expand the Main Rack by connecting two CPU Units to it.*<sup>2</sup></li> <li>• Method 2 Use a Rack Expansion Interface Unit to add Expansion Racks.</li> </ul>
Three or more CPU Units	Use the following method 1 and method 2 together, or use only method 2. <ul style="list-style-type: none"> <li>• Method 1 Expand the Main Rack by connecting two CPU Units to it.*<sup>2</sup></li> <li>• Method 2 Use a Rack Expansion Interface Unit to add Expansion Racks.</li> </ul>

\*1. Refer to the following manual for details on the MP2200 Base Unit and EXIOIF Module.

*MP2200 Series User's Manual* (Manual No.: SIEP C880700 14)


## 1.1 Definition of Terms

---

### Main Rack and Expansion Racks


\*2. To mount the Unit with screws, use the JEPMC-OP3006-E or JEPMC-OP3007-E Rack Reinforcement Bracket.

Refer to the following section for an expansion example.

 *MP3200 Expansion Example (page 1-5)*

## MP3200 Expansion Example

An MP3200 expansion example is given in the following figure.



\*1. Refer to the following manual for details on the MP2200 Base Unit and EXIOIF Module.

*MP2200 Series User's Manual* (Manual No.: SIEP C880700 14)

\*2. If you use two CPU Units, you can connect to the Main Rack without adding an Expansion Rack. To mount the CPU Units with screws, use the JEPMC-OP3006-E or JEPMC-OP3007-E Rack Reinforcement Bracket.


## Rack Numbers

When you add Expansion Racks, the MPE720 automatically assigns a number to each Rack so that the Racks can be identified.


Rack No.	Description	
Rack 1	Main Rack	
Rack 2	Expansion Racks added by using EXIOIF Modules	
Rack 3		
Rack 4		
Rack 5	Expansion Racks added by using a Rack Expansion Interface Unit	The Expansion Rack that is connected to port 1 on the Rack Expansion Interface Unit on the Main Rack
Rack 6		The Expansion Rack that is connected to port 2 on the Rack Expansion Interface Unit on the Main Rack
Rack 7		The Expansion Rack that is connected to port 3 on the Rack Expansion Interface Unit on the Main Rack

**Information**

Depending on how the Expansion Racks are connected, the Rack numbers may not be sequential. Example: If two Expansion Rack were connected with EXIOIF Modules and one Expansion Rack was connected with a Rack Expansion Interface Unit, the Rack numbers would be as shown below. There would be no rack 4.



The following figure illustrates Rack numbers.





---

## Unit Numbers

---

The MPE720 automatically assigns Unit numbers to the Units on each Rack so that the Units can be identified.

Numbers 1 to 5 are assigned to the Units in order from the left.

---

## Slot Numbers

---

The MPE720 automatically assigns slot numbers to the slots on the Base Unit so that the slots can be identified.


Numbers 1 to 9\* are assigned to the slots in order from the left.

\* The highest slot number depends on the specifications of the Base Unit.

# 1.2 System Configuration Example

The following figure shows a typical system configuration. Refer to the following section for details on 1 to 11 in the following figure.

1.3 Devices and Components That Are Required to Build a System (page 1-9)





\*1. This manual primarily describes this area.  
 \*2. Refer to the following section for an MP3200 expansion example.

MP3200 Expansion Example (page 1-5)

## 1.3 Devices and Components That Are Required to Build a System

The following table lists the devices and components that are required to build the system that is shown in *1.2 System Configuration Example (page 1-8)*. The numbers 1 to 13 correspond to the numbers in the figure in *1.2 System Configuration Example (page 1-8)*.

No.	Name	Use	Model	Remarks
①	MP3200	Power Supply Unit		Supplies the power that is needed for the operation of the Units that are connected to each other and to any Optional Modules that are connected in the Controller.  Stores the module definitions and programs, and interprets the programs. The CPU Unit also controls the Optional Modules.  Used to mount Optional Modules.  Used to expand a Rack.  Refer to the following section for details.  <i>MP3200 Unit List (page 1-11)</i>
		CPU Unit		
		Base Unit		
		Rack Expansion Interface Unit		
②	Ethernet communications cables	Used to connect the CPU Unit to Ethernet communications devices or to connect the CPU Unit to a PC that has the MPE720 installed on it.		Use a commercially available cable that meets the following conditions: • Ethernet specification: 100Base-TX • Category 5 or higher • Twisted-pair cable with RJ-45 connectors  Use a cross cable that meets the above conditions to connect the Main CPU Unit to a Sub CPU Unit or to connect two Sub CPU Units.
③	Battery with Special Connector	Provides power for the calendar and backup memory while the power is turned OFF.	JEPMC-OP3005	The Battery is provided with the CPU Unit.
④	Power supply cable	Connects the Power Supply Unit to a 24-VDC power supply or an AC power supply.		Use a commercially available cable that meets the following conditions: • Wire size: AWG18 to AWG13 (0.8 to 2.6 mm <sup>2</sup> ) • Twisted-pair cable
⑤	RLYOUT connector cable	Connects the Power Supply Unit to a 24-VDC power supply, an AC power supply, or a status monitoring device.		Use a commercially available cable that meets the following conditions: • Wire size: AWG28 to AWG14 (0.08 to 2.0 mm <sup>2</sup> )
⑥	Front cover for unused slot	Used to cover unused slots on the Base Unit.	JEPMC-OP2300	–
⑦	Optional Modules	Motion Modules, I/O Modules, and Communications Modules are selected based on the application.		Refer to the following section for details.  <i>Optional Modules (page 1-12)</i>


Continued on next page.

Continued from previous page.

No.	Name	Use	Model	Remarks	
⑧	MECHATROLINK-III Cable	Connects the CPU Unit to MECHATROLINK-III Communications devices.	JEPMC-W6012-□□-E	Standard cable Length: 0.2 to 50 m	
			JEPMC-W6013-□□-E	Cable with ferrite cores Length: 10 to 50 m	
			JEPMC-W6014-□□-E	Cable with loose wires at one end Length: 0.5 to 50 m	
⑨	SERVOPACK with MECHATROLINK-III Communications	Used to control Servomotors.	SGDV-□□□□ 21□□□□□□	Σ-V-series AC SERVOPACK with MECHATROLINK-III Communications for Rotational Motor	
			SGDV-□□□□ 25□□□□□□	Σ-V-series AC SERVOPACK with MECHATROLINK-III Communications for Linear Motor	
⑩	I/O Modules with MECHATROLINK-III Communications	Used to input or output digital, analog, or pulse train signals.	JEPMC-MTD2310-E	24 VDC, 64 inputs, 64 outputs	
			JEPMC-MTA2900-E	8 analog input channels	
			JEPMC-MTA2910-E	4 analog output channels	
			JEPMC-MTP2900-E	2 pulse-train inputs	
			JEPMC-MTP2910-E	4 pulse-train outputs	
⑪	MPE720 Integrated Engineering Tool Version 7	Used to adjust, maintain, and program AC Servo Drives and Inverters that are connected to the network.	CPMC-MPE780	—	
⑫	Rack Expansion Interface Unit Cable	Used to use a Rack Expansion Interface Unit to connect the Main Rack to an Expansion Rack.	JEPMC-W3401-A5-E	Length: 0.5 m	<ul style="list-style-type: none"> <li>• Connector on both ends with ferrite cores</li> <li>• Wire size: AWG28</li> <li>• Twin coaxial cable</li> </ul>
			JEPMC-W3401-2A5-E	Length: 2.5 m	
			JEPMC-W3401-06-E	Length: 6.0 m	
⑬	EXIOIF Module Cable*	Used to use an EXIOIF Module to connect the Main Rack to an Expansion Rack or to connect two Expansion Racks.	JEPMC-W2094-A5-E	Length: 0.5 m	<ul style="list-style-type: none"> <li>• If you use more than one Cable, do not allow the total cable length to exceed 6 m.</li> <li>• Connector on both ends with ferrite cores</li> <li>• Wire size: AWG28</li> <li>• Equivalent to UL20276.</li> </ul>
			JEPMC-W2094-01-E	Length: 1.0 m	
			JEPMC-W2094-2A5-E	Length: 2.5 m	

Continued on next page.

Continued from previous page.

No.	Name	Use	Model	Remarks
–	Panel-mounting Bracket	Used to mount the MP3200 inside a control panel.	JEPMC-OP3001-E	This Attachment is provided with the Power Supply Unit.
–	Rack Reinforcement Bracket	Used to mount the Sub CPU Unit to the Main Rack with screws.	JEPMC-OP3006-E	Refer to the following manual for information on model selection and mounting methods.  <i>MP2200/MP3000 Series Machine Controller System Setup Manual (Manual No.: SIEP C880725 00)</i>
JEPMC-OP3007-E				


\* You cannot use an MP2000-series EXIOIF Module Cable (model: JEPMC-W2091-□□(□)).

## MP3200 Unit List

The following table lists the MP3200 Units.




Observe all precautions when combining MP3200 Units. Refer to the following section for details.

 *Precautions When Combining MP3200 Units (page 1-14)*

Unit	Abbreviation	Model	Description	Maximum Internal Current Consumption	
Power Supply Units	PSA-12	JEPMC-PSA3012-E	AC power supply	–	
	PSD-12	JEPMC-PSD3012-E	DC power supply	–	
CPU Unit	CPU-201	JEPMC-CP3201-E	–	2,000 mA	
	CPU-202	JEPMC-CP3202-E	–	4,000 mA	
	Motion Control Function Module	SVC32	–	MECHATROLINK -III	–
		SVR32	–	Virtual axes*	–
Communications Function Module	218IFD	–	Ethernet	–	
Base Units	MBU-B03	JEPMC-BUB3003-E	3 slots	10 mA	
	MBU-B05	JEPMC-BUB3005-E	5 slots	10 mA	
	MBU-B08	JEPMC-BUB3008-E	8 slots	10 mA	
Rack Expansion Interface Unit	EXU-001	JEPMC-EXU3001-E	For Main Rack	1,500 mA	
	EXU-002	JEPMC-EXU3002-E	For Expansion Rack	1,500 mA	

\* Refer to the following section for details.

 *3.2 Function Modules – Motion Control Function Modules (SVC32 and SVR32) (page 3-50)*


## Optional Modules

You can add the Optional Modules that are listed in the following table for as many open slots there are in the Base Unit.



Note

Observe all precautions when combining Optional Modules. Refer to the following section for details.

 *Precautions When Combining Optional Modules (page 1-14)*

Unit	Abbreviation	Model	Description	Maximum Internal Current Consumption
Motion Modules	SVC-01	JAPMC-MC2320-E	MECHATROLINK -III × 1	460 mA
	SVB-01	JAPMC-MC2310-E	MECHATROLINK -II × 1	470 mA
	SVA-01	JAPMC-MC2300	2-axis analog servo interface	540 mA
	PO-01	JAPMC-PL2310-E	4-axis control with pulse-train output	760 mA
	MPU-01	JAPMC-CP2700-E	Optional Module with CPU Unit and SVC-01 functionality MECHATROLINK -III × 1	580 mA
Communications Modules	217IF-01	JAPMC-CM2310-E	RS-232C/RS-422 communications	240 mA
	218IF-01	JAPMC-CM2300-E	RS-232C/Ethernet communications (10Base-T)	360 mA
	218IF-02	JAPMC-CM2302-E	RS-232C/Ethernet communications (100Base-TX/10Base-T)	480 mA
	260IF-01	JAPMC-CM2320-E	RS-232C/DeviceNet communications	150 mA
	261IF-01	JAPMC-CM2330-E	RS-232C/PROFIBUS communications	260 mA
	262IF-01	JAPMC-CM2303-E	FL-net communications	480 mA
	263IF-01	JAPMC-CM2304-E	EtherNet/IP communications	480 mA
	264IF-01	JAPMC-CM2305-E	EtherCAT (EtherCAT slave)	540 mA
	265IF-01	JAPMC-CM2390-E	CompoNet (I/O communications and message communications)	200 mA
	266IF-01	JAPMC-CM2306-E	PROFINET master	540 mA
	266IF-02	JAPMC-CM2307-E	PROFINET slave	540 mA
	215AIF-01	JAPMC-CM2360-E	RS-232C/MPLINK communications	410 mA
		JAPMC-CM2361	RS-232C/CP-215 communications	420 mA
	AFMP-01	–	Anywire-Master DB by Anywire Corporation	*
	AFMP-02-C	–	CC-Link by Anywire Corporation	*
	AFMP-02-CA	–	CC-Link and Anywire-Master DB by Anywire Corporation	*
	MPANL00-0	–	A-net/A-Link by ALGO System	*
	MPALL00-0	–	A-Link/A-Link by ALGO System	*
	MPAL000-0	–	A-Link by ALGO System	*
MPAN000-0	–	A-net by ALGO System	*	
MPCUNET-0	–	CUNet by ALGO System	*	

Continued on next page.

\* Refer to the manuals for individual Optional Modules for details.

Continued from previous page.


Unit	Abbreviation	Model	Description	Maximum Internal Current Consumption
I/O Modules	LIO-01	JAPMC-IO2300-E	16 inputs, 16 sinking outputs, 1 pulse-train input	300 mA
	LIO-02	JAPMC-IO2301-E	16 inputs, 16 sourcing outputs, 1 pulse-train input	300 mA
	LIO-04	JAPMC-IO2303-E	32 inputs, 32 sinking outputs	400 mA
	LIO-05	JAPMC-IO2304-E	32 inputs, 32 sourcing outputs	400 mA
	LIO-06	JAPMC-IO2305-E	8 digital inputs, 8 digital sinking outputs 1 analog input channel and 1 analog output channel 1 pulse-train counter channel	500 mA
	DO-01	JAPMC-DO2300-E	64 sinking outputs	500 mA
	AI-01	JAPMC-AN2300-E	8 analog input channels	340 mA
	AO-01	JAPMC-AN2310-E	4 analog output channels	740 mA
	CNTR-01	JAPMC-PL2300-E	2 counter channels, input circuits: 5 V or 12 V	610 mA
Expansion Rack Module	EXIOIF	JAPMC-EX2200-E	–	–

## 1.4 Precautions When Combining Products

The following precautions must be observed when combining the MP3200 Units and Optional Modules.

### Precautions When Combining MP3200 Units

There are restrictions in the order in which you can connect the Units. Build the Rack by connecting each Unit in the order that is shown below.



Note

The Units will not operate if they are connected in the wrong order (e.g., if the Base Unit is connected to the left side of the Power Supply Unit).

### Precautions When Combining Optional Modules

When combining Optional Modules, make sure the following conditions are met.

- The output current of the Power Supply Unit\* must be held to approximately 75% (approximately 9 A) or less of the rated current capacity.

\* This is the total of the maximum internal current consumption of the Base Units and Optional Modules that are connected to the Power Supply Unit.



Note

Always attach the front covers to unused slots on the Base Unit.



## 1.5

## Precautions When Setting the Parameters

Observe the following precautions when setting the MP3200.

### Precautions When Setting the Circuit Numbers

When assigning circuit numbers to the Motion Control and Communications Function Modules, the numbers must be within the following ranges.

Unit		Abbreviations of Built-in Modules	Circuit numbers
Function Modules in CPU Unit	Motion Control Function Module	SVC32, SVR32	1 to 16
	Communications Function Module	218IFD	1 to 8
Optional Modules	Motion Modules	SVA-01 (SVA), SVB-01 (SVB01), SVC-01 (SVC), MPU-01 (MPUIF), PO-01 (PO)	1 to 16
	Communications Modules	217IF-01 (217IF)	1 to 16
		218IF-01 (218IF), 218IF-02 (218IFB), 260IF-01 (260IF (DeviceNet)), 261IF-01 (261IFS (Profibus)), 262IF-01 (FL-net), 263IF-01 (EtherNet/IP), 264IF-01 (EtherCAT-S), 265IF-01 (Componet), 266IF-01, 266IF-02, 215AIF-01 (MPLINK), 215AIF-01 (CP-215)	1 to 8

### Precautions When Setting Module Configuration Definitions

Observe the following precautions when writing module configuration definitions.

- Write the module configuration definitions only when the high-speed scan has sufficient unused processing time.  
Otherwise, processing may exceed the time limit of the high-speed scan.
- Before writing module configuration definitions, make sure the machine is not in operation.
- Before you use the Machine Controller, save any written data to flash memory and turn the power supply to the Racks OFF and ON again.

# Appearances and Parts

# 2

This section describes the appearance and parts of the MP3200.

<b>2.1</b>	<b>Power Supply Units</b> . . . . .	<b>2-2</b>
	Appearance and Part Names . . . . .	2-2
	Indicators . . . . .	2-2
	Connectors . . . . .	2-3
<b>2.2</b>	<b>CPU Unit</b> . . . . .	<b>2-5</b>
	Appearance and Part Names . . . . .	2-5
	Display and Indicators . . . . .	2-6
	Switches . . . . .	2-9
	Connectors . . . . .	2-11
	Fan . . . . .	2-12
	Temperature Sensor . . . . .	2-13
<b>2.3</b>	<b>Base Units</b> . . . . .	<b>2-14</b>
	Appearance and Part Names . . . . .	2-14
	Connector . . . . .	2-14
<b>2.4</b>	<b>Rack Expansion Interface Unit</b> . . . . .	<b>2-15</b>
	Appearance and Part Names . . . . .	2-15
	Indicators . . . . .	2-16
	Connectors . . . . .	2-17


## 2.1 Power Supply Units

The Power Supply Unit supplies the connected Units and Optional Modules with the power needed to operate. There are two Power Supply Units available: an AC Power Supply Unit and a DC Power Supply Unit.

This section shows the appearance and part names of the Power Supply Unit and describes the indicators and connectors.


### Appearance and Part Names

The following figure shows the appearance of the Power Supply Unit and the part names.



### Indicators

These indicators show the load on the Power Supply Unit.



Output Current		8.9 A or less	9.0 to 11.4 A	11.5 to 13.9 A*	14.0 A or more*
Load		Normal: Within power supply capacity		Normal: Maximum power supply capacity	Error: Over power supply capacity
Indicator	POWER <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	●	●	●	○
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	○	●	●	○
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	○	○	●	○

Note: ●: Lit, ○: Not lit.


\* Reduce the number of Optional Modules that are connected.

## Connectors

The Power Supply Unit has three connectors: RLYOUT, power supply, and Unit connectors.

### RLYOUT Connector

This connector outputs the operating status of the CPU Unit.



Model: 734-302


#### ◆ Pin Assignments

No.	Signal Label	Description
1	OUT	<ul style="list-style-type: none"> <li>• Normal operation: Circuit closed.</li> <li>• Error: Circuit open.</li> </ul>
2	OUT	


### Power Connector

Connect the power supply to this connector.

AC Power Supply Unit



DC Power Supply Unit



Type	Model	Color
AC Power Supply Unit	721-203/026-304	Black
DC Power Supply Unit	721-203/026-000	White

#### ◆ Pin Assignments: AC Power Supply Unit

Pin No.	Signal Label	Description
3	AC	AC input
2	AC	AC input
1	FG	Connects to the frame ground. (Ground to 100 Ω max.)


#### ◆ Pin Assignments: DC Power Supply Unit

Pin No.	Signal Label	Description
3	24 VDC	Power input wire for 24 VDC
2	0 VDC	Power input wire for 0 VDC
1	FG	Connects to the frame ground. (Ground to 100 Ω max.)

## Unit Connector

This connector is used to connect the next Unit.

Refer to the following manual for details on connecting Units.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

2.2

CPU Unit

The CPU Unit stores the module definitions and programs, and interprets the programs. The CPU Unit also controls the Optional Modules.


This section shows the appearance and part names of the CPU Unit and describes the indicators, switches, connectors, Fan,\* and temperature sensor.\*

\* These are built into the CPU-202 only.

Appearance and Part Names


The following figure shows the appearance of the CPU Unit and the part names.

CPU-201



\* Open the cover to access the switch and USB connector.

CPU-202



\* Open the cover to connect or remove the Battery.










## Display and Indicators

The CPU Unit has the following display and four indicators.

- Display
- Status indicators
- USB status indicator
- MECHATROLINK-III status indicators
- Ethernet status indicators

### Display

The display shows the execution or error status of the CPU Unit.

Color	Display	Status	Description
Red	 Lit dot at lower right	Initializing	The CPU Unit started normally after the power was turned ON or after the system was reset.
	 Flashing dot at lower right	Normal operation	The CPU Unit is operating normally.
		USB mem- ory batch transfer	Save or load is starting.
			Save or load is in progress.
			Save or load was completed. After 2 seconds, the display will indicate the status of the CPU Unit.
			
	 (Displayed by CPU-202 only.)	Failsafe function stopped the CPU Unit.	Refer to the following manual for information on internal temperature errors and Fan operation failure.  <i>MP3000 Series MP3200 Troubleshooting Manual</i> (Manual No.: SIEP C880725 01)
Three digits after <b>E.</b> or <b>A.</b>	A system error occurred. An alarm occurred.	Refer to the following manual for details on errors.  <i>MP3000 Series Basic Units Troubleshooting Manual</i> (Manual No.: SIEP C880725 01)	

## Status Indicators

These indicators show the status of the CPU Unit.

RDY □  
 RUN □  
 ALM □  
 ERR □  
 BAT □  
 M-ALM □

Indicator Name	Color	Status When Lit*
RDY	Green	Operation is normal.
RUN	Green	A user program is being executed.
ALM	Red	An alarm occurred.
ERR	Red	An error occurred.
BAT	Red	The battery alarm occurred.
M_ALM	Red	An error occurred with one of the Servo axes: <ul style="list-style-type: none"> <li>• Warning</li> <li>• Alarm</li> <li>• Command Error Completed Status</li> </ul>

\* Refer to the following manual for details.

📖 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)


## USB Status Indicator

This indicator shows the status of the USB memory.

Indicator Name	Indicator Status	Status	Description
USB ACTIVE	□ Not lit	No USB memory device	No USB memory device has been inserted yet, or the USB memory device is ready to be removed.
	■ Lit	USB memory device inserted	A USB memory device is inserted.
	⚡ Flashing	Accessing USB memory	The USB memory is being accessed.

## MECHATROLINK-III Status Indicators

These indicators show the status of the MECHATROLINK-III communications.




Indicator Name	Color	Status When Lit
CN	Green	MECHATROLINK-III communications is established with the CPU Unit as a slave (i.e., the Connect command is ON).
LK1	Green	MECHATROLINK-III communications are active on PORT1.
LK2	Green	MECHATROLINK-III communications are active on PORT2.



## Ethernet Status Indicators

These indicators show the status of Ethernet communications.



Indicator Name	Color	Status When Not Lit, Lit, or Flashing
LINK/ACT	Yellow	Lit: Ethernet link established. Flashing: Ethernet communications activity.
100M	Green	Not lit: 10 M connection Lit: 100 M connection


## Switches

The CPU Unit has the following four switches.

- DIP switch: Mode switch 1
- DIP switch: Mode switch 2
- Rotary switches
- STOP/SAVE switch

### DIP Switch: Mode Switch 1


This DIP switch primarily sets the operating mode of the CPU Unit.



Pin Name	Status	Operating Mode	Default	Remarks
STOP	ON	Stops the user programs.	OFF	Turn ON the pin to stop execution of the user program.
	OFF	Executes the user programs.		
E-INIT	ON	Sets the IP address to 192.168.001.□□□.	OFF	The setting of □□□ is determined by the rotary switch setting. Refer to the following section for details on the setting. Rotary Switches (page 2-10)
	OFF	Sets the IP address that is set in the MPE720.		
INIT	ON	Resets memory.	OFF	Turn OFF the pin to execute the programs that are stored in the flash memory.
	OFF	Normal operation		
CNFG	ON	Configuration Mode	OFF	Turn ON the pin to perform self configuration. Turn OFF the pin to operate according to the definitions that are stored in the flash memory.
	OFF	Normal operation		
LOAD	ON	Load data.	OFF	Turn ON the pin and then turn ON the power to batch load data from the USB memory to the CPU Unit. Refer to the following section for details. 3.2 Function Modules – USB Memory (page 3-85)
	OFF	Does not load data.		
D-RST	ON	Reserved for system.	OFF	Keep this pin OFF at all times.
	OFF	Normal operation		

## DIP Switch: Mode Switch 2


This DIP switch primarily sets the operating mode of the CPU Unit.



Pin Name	Status	Operating Mode	Default	Remarks
E-PM0	ON	Reserved for system.	OFF	Keep this pin OFF at all times.
	OFF	Normal operation		
E-PM1	ON	Reserved for system.	OFF	Keep this pin OFF at all times.
	OFF	Normal operation		
TEST	ON	Reserved for system.	OFF	Keep this pin OFF at all times.
	OFF	Normal operation		
MNT	ON	Reserved for system.	OFF	Keep this pin OFF at all times.
	OFF	Normal operation		

## Rotary Switches

When the E-INIT pin on Mode Switch 1 is ON, the IP address will be set to 192.168.001.□□□. The value of □□□ is set on the rotary switches, S1 and S2. Set the hexadecimal value.



Set Value		IP Address
X16 <sup>1</sup>	X16 <sup>0</sup>	
0	0	Reserved for system.
0	1	192.168.001.001 (default setting)
0	2	192.168.001.002
⋮	⋮	⋮
F	E	192.168.001.254
F	F	Reserved for system.




Note

To enable the rotary switch setting, turn ON the E-INIT pin on the mode switch 1. If the E-INIT pin is OFF, the IP address will be set from the MPE720.

## STOP/SAVE Switch

This switch is used when removing the USB memory device, or when batch saving data to the USB memory.




- Lightly press this switch to prepare the USB memory device for removal. The USB memory device can be safely removed when the USB status indicator changes from flashing to not lit.
- Press and hold this switch for at least 2 seconds to save all of the data to the USB memory. The display will show the progress of saving.

## Connectors

The CPU Unit has four connectors: MECHATROLINK-III, Ethernet, USB, and Unit connectors.

### MECHATROLINK-III Connectors

These connectors are used to connect MECHATROLINK-III communications devices.




### Ethernet Connectors

These connectors are used to connect Ethernet communications devices.



## USB Connector

This connector is used to connect a USB memory device.



Note

Before removing the USB memory device, press the STOP/SAVE switch and wait until the USB status indicator goes out. If the USB memory device is removed while the USB status indicator is lit or flashing, the data may become corrupted.

## Unit Connector


This connector is used to connect the next Unit.

Refer to the following manual for details on connecting Units.

📖 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

## Fan

A Fan is built into the CPU-202 CPU Unit.



- Fan model: JEPMC-OP3101-E
- Screw specifications: M3 × 14 mm × 2 screws with spring washers

The Fan life is 50,000 hours minimum (at an average ambient operating temperature of 40°C). An alarm is displayed on the CPU-202 if the Fan stops.

There are three levels of alarms, as shown in the following table.

Display	ALM Indicator	Error Description
A.240	Lit	A Fan operation failure was detected.
E.083	Lit	The Fan remained stopped for more than a minute after A.240 was detected. (The CPU Unit will stop.)
h	Lit	The failsafe function was activated for E.083 (Fan Alarm) or E.082 (Temperature Warning). (The CPU Unit will stop.) (This alarm is displayed 5 seconds after E.083 is detected.)



Important

If the above alarms occur, turn OFF the power supply to the CPU-202 immediately and replace the Fan.

Refer to the following manual for the Fan replacement procedure.

*MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

## Temperature Sensor

A temperature sensor is built into the CPU-202 CPU Unit.

The temperature sensor constantly monitors for abnormal temperatures in the CPU-202 Unit. If a temperature error is detected, an alarm is displayed on the CPU-202.

There are four levels of alarms, as shown in the following table.

Display	ALM Indicator	Error Description
A.241	Lit	A rise in the internal temperature was detected.
E.081	Lit	The temperature continued to increase after A.241 was detected and is approaching the permissible temperature of the internal parts. (The CPU Unit will stop.)
E.082	Lit	The temperature continued to increase after E.081 was detected and has reached the permissible temperature of the internal parts. (The CPU Unit will stop.)
h	Lit	The failsafe function was activated for E.083 (Fan Alarm) or E.082 (Temperature Warning). (The CPU Unit will stop.) (This alarm is displayed if the temperature continues to increase after E.082 was detected.)



Important

If the above alarms occur, turn OFF the power supply to the CPU-202 immediately and check the ambient environment and installation conditions.

Refer to the following section for details on the ambient environment and installation requirements.

*4.1 MP3200 Installation and Usage Conditions (page 4-2)*

## 2.3 Base Units

The Base Unit is used to mount Optional Modules. There are three models of Base Units, a three-slot model, a five-slot model, and an eight-slot model.


This section shows the appearance and part names of the Base Unit and describes the connector.

---

### Appearance and Part Names

---

The following figure shows the appearance of the Base Unit and a part name.



---

### Connector

---

The Base Unit has a Unit connector.

#### Unit Connector

This connector is used to connect the next Unit.

Refer to the following manual for details on connecting Units.

📖 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

## 2.4

## Rack Expansion Interface Unit


A Rack Expansion Interface Unit is used to expand a Rack. There are two models of Rack Expansion Interface Units, a Main Rack Expansion Interface Unit and an Expansion Rack Expansion Interface Unit.

This section shows the appearance and part names of the Rack Expansion Interface Units and describes the indicators and connectors.


## Appearance and Part Names

The following figure shows the appearance of the Rack Expansion Interface Unit and the part names.

Main Rack Expansion Interface Unit



Expansion Rack Expansion Interface Unit





## Indicators

These indicators show the operating status of the Rack Expansion Interface Unit, the communications status of the cable, and the error status.

For Main Rack

- LKP1
- LKP2
- LKP3
- ERR

For Expansion Rack

- LKP1
- ERR

Indicator Name	Color	Status When Lit, Flashing, or Not Lit	
LKP1	Green	Lit	Communications are active with the Rack Expansion Interface Unit connected to port 1.
		Not lit	<ul style="list-style-type: none"> <li>• Consecutive communications errors occurred and communications cannot be recovered automatically.</li> <li>• The cable was disconnected or was not connected to the port.</li> <li>• The current Rack Expansion Interface Unit or another Rack Expansion Interface Unit connected to it has a hardware failure.</li> </ul>
LKP2	Green	Lit	Communications are active with the Rack Expansion Interface Unit connected to port 2.
		Not lit	Same as LKP1.
LKP3	Green	Lit	Communications are active with the Rack Expansion Interface Unit connected to port 3.
		Not lit	Same as LKP1.
ERR	Red	Lit	<ul style="list-style-type: none"> <li>• Consecutive communications errors occurred on one of the ports and communications cannot be recovered automatically.</li> <li>• The cable was disconnected or was not connected. These errors are not shown on the Main Rack Expansion Interface Unit before the connection is established.</li> <li>• The current Rack Expansion Interface Unit or another Rack Expansion Interface Unit connected to it has a hardware failure.</li> </ul>



Important

If communications errors occur consecutively during operation, communications between the Main Rack and Expansion Rack will stop.

---

## Connectors


---

The Rack Expansion Interface Unit has two connectors: Rack Expansion Interface Unit connector and Unit connector.

### Rack Expansion Interface Unit Connector

This connector is used to connect an Expansion Rack.


The Main Rack Expansion Interface Unit has three connectors (port 1, port 2, and port 3), and the Expansion Rack Expansion Interface Unit has one connector (port 1).



### Unit Connector

This connector is used to connect the next Unit.

Refer to the following manual for details on connecting Units.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

# CPU Unit Functionality

# 3

This chapter describes the functionality of the MP3200 CPU Units.

<b>3.1</b>	<b>Basic Functionality</b> . . . . .	<b>3-2</b>
	Programs . . . . .	3-2
	Registers . . . . .	3-19
	Execution Scheduling . . . . .	3-31
	Scans . . . . .	3-32
<b>3.2</b>	<b>Function Modules</b> . . . . .	<b>3-38</b>
	Self Configuration . . . . .	3-38
	Communications Function Module (218IFD) . . . . .	3-48
	Motion Control Function Modules (SVC32 and SVR32) . . . . .	3-50
	The M-EXECUTOR . . . . .	3-56
	Data Logging . . . . .	3-70
	USB Memory . . . . .	3-85
	File Transfer . . . . .	3-89
	Security . . . . .	3-93
	Calendar . . . . .	3-93
<b>3.3</b>	<b>Multi-CPU Functions</b> . . . . .	<b>3-94</b>
	Differences between Sub CPU Synchronization and Slave CPU Synchronization . . . . .	3-94
	Sub CPU Synchronization . . . . .	3-95
	Slave CPU Synchronization . . . . .	3-108

## 3.1 Basic Functionality

This section describes the basic functionality of the CPU Unit.

---

### Programs

---

A program is a list of instructions to be processed by the CPU Unit.

This section describes the types of programs and gives an overview of each type.

### Types of Programs

There are three types of user programs:

- Ladder programs
- Motion programs
- Sequence programs

This section describes these programs.

#### ◆ Ladder Programs

Ladder programs are managed as drawings (ladder diagrams) that are identified by their drawing numbers (DWG numbers). These drawings form the basis of the user program.

#### ■ Drawing Types and Hierarchical Configuration

This section describes the types of ladder drawings and their hierarchical configuration.

##### • Types

Ladder drawings are divided into four different types based on their purpose.

- DWG.A (Startup Drawings)  
This type of ladder drawing is used to set register data. These ladder drawings are executed before high-speed scan process drawings and low-speed scan process drawings.
- DWG.I (Interrupt Drawings)  
This type of ladder drawing is used to perform processing with priority given to signals input from an Optional Module. These ladder drawings are executed with higher priority than high-speed scan process drawings regardless of the scan cycle.
- DWG.H (High-speed Scan Process Drawings)  
This type of ladder drawing is used to perform motion control or high-speed I/O control.
- DWG.L (Low-speed Scan Process Drawings)  
This type of ladder drawing is used for communications with HMIs and external devices as well as for standard I/O control.

The following table lists the priority, execution conditions, and maximum number of drawings for each type of ladder drawing.

Drawing Type	Priority*	Execution Condition	Maximum Number of Drawings
DWGA (Startup Drawings)	1	Power ON (These drawings are executed once when the power supply is turned ON.)	64
DWGI (Interrupt Drawings)	2	External interrupt (These drawings are executed when a DI interrupt or counter match interrupt is received from an Option Module.)	64
DWGH (High-speed Scan Process Drawings)	3	Started at fixed intervals. (These drawings are executed once every high-speed scan.)	200
DWGL (Low-speed Scan Process Drawings)	4	Started at fixed intervals. (These drawings are executed once every low-speed scan.)	1000


\* Drawings with lower numbers have higher priority.


#### • Hierarchical Configuration

There are four types of ladder drawings: parent drawings, child drawings, grandchild drawings, and operation error drawings.


- Parent Drawings  
These drawings are automatically executed by the system program when the execution conditions are met.
- Child Drawings  
These drawings are executed when they are called from a parent drawing with a SEE instruction.
- Grandchild Drawings  
These drawings are executed when they are called from a child drawing with a SEE instruction.
- Operation Error Drawings  
These drawings are automatically executed by the system program when an operation error occurs.

A parent drawing cannot call a child drawing from a different type of drawing. Similarly, a child drawing cannot call a grandchild drawing from a different type of drawing. A parent drawing cannot call a grandchild drawing directly. The parent drawing first must call the child drawing, and then the child drawing must call the grandchild drawing. This is called the hierarchical configuration of drawings. The following figure shows the parent-child-grandchild structure in which a program is created.





Note: The following notation is used for operation error drawings.



The breakdown of the number of ladder drawings in each category is given in the following table.


Drawings	Number of Drawings			
	DWG.A	DWG.I	DWG.H	DWG.L
Parent Drawings	1	1	1	1
Operation Error Drawings	1	1	1	1
Child Drawings	Total of 62 max.	Total of 62 max.	Total of 998 max.	Total of 1,998 max.
Grandchild Drawings				

**Information** There are separate functions that can be called from the drawings as required. Functions are executed when they are called from a parent, child, or grandchild drawing with the FUNC instruction. You can create up to 2,000 functions.

## ■ Execution Processing of Drawings

The drawings are executed by calling them from the top to the bottom, following the hierarchy of the drawings. The following figure illustrates the execution processing of a high-speed scan drawing (DWG.H).

Execution is started by the system program when the execution condition is met.



- Note: 1. The parent drawing is automatically called and executed by the system. Child drawings and grandchild drawings are executed by calling them from a parent drawing or a child drawing using the SEE instruction.  
 2. You can call functions from any drawing. You can also call functions from other functions.  
 3. If an operation error occurs, the operation error drawing for the drawing type will be started automatically.  
 4. Always specify 00 as the drawing number for operation error drawings.

## ■ Functions

Functions are executed when they are called from a parent, child, or grandchild drawing with the FUNC instruction.

Functions can be freely called from any drawing. The same function can be called simultaneously from different types of drawings or different levels of drawings. You can also call functions from other functions that you have created.

The use of functions provides the following merits:

- Easy user program modularization
- Easy user program creation and maintenance

You can use standard functions that are provided by the system, and you can define user functions.

### • Standard System Functions

The following functions for communications and other purposes are provided as standard functions in the system. You cannot change the system functions.

Function	Name	Name Used in MPE720
COUNTER	Counter	Counter
FINFOUT	First-in First-out	First-in First-out
TRACE	Trace	Trace
DTRC-RD	Read Data Trace	Data-Trace Read Extend
MSG-SND	Send Message	Send Message
MSG-SNDE	Send Message	Send Message Extend
MSG-RCV	Receive Message	Receive Message
MSG-RCVE	Receive Message Extended	Receive Message Extend
MOTREG-W	Write Motion Register	Write the Motion Parameter to Motion Register
MOTREG-R	Read Motion Register	Read the Motion Parameter from Motion Register
IMPORT	Import	Import
EXPORT	Export	Export


### • User Functions

You can freely program the body of a user function and program the user function definitions.

A maximum of 2,000 user function drawings can be defined.

#### Information

Refer to the following manual for details on how to define functions.

 *MP3000 Series Ladder Programming Manual* (Manual No.: SIEP C880725 13)

## ◆ Motion Programs

A motion program is a program that is written in a text-based motion language.

There are two types of motion programs.


Type	Designation Method	Features	Number of Programs
Main programs	MPM□□□ (□□□=1 to 512)	<ul style="list-style-type: none"> <li>Main programs are called from a DWG.H drawing.</li> <li>Main programs are called from the M-EXECUTOR program execution definitions.</li> </ul>	You can create up to 512 motion programs, including the following programs: <ul style="list-style-type: none"> <li>Motion main programs</li> <li>Motion subprograms</li> <li>Sequence main programs</li> <li>Sequence subprograms</li> </ul>
Subprograms	MPS□□□ (□□□=1 to 512)	Subprograms are called from a main program.	



Important


- The same numbers are used to manage the motion programs and sequence programs. Use a unique number for each program.
  - Motion program numbers are given in the form MPM□□□ or MPS□□□.
  - Sequence program numbers are given in the form SPM□□□ or SPS□□□.
- The number of motion programs that can be executed simultaneously depends on the model of the Machine Controller. If the number of simultaneously executable programs is exceeded, an alarm will occur (No System Work Available Error).






### ■ Motion Program Execution

Motion programs are called with an MSEE instruction from a ladder program in an H drawing.




Note

You can also register the motion program in the M-EXECUTOR (Motion Executor) to call it. Refer to the following section for details.

 *The M-EXECUTOR (page 3-56)*

After you create the motion program, place a Call Motion Program (MSEE) instruction in the ladder program of an H drawing. Motion programs can be called from any H drawing, regardless of whether it is a parent, child, or grandchild drawing.

The following figure shows an execution example.



The ladder instruction in the H drawing is executed every high-speed scan cycle according to the hierarchical organization of parent-child-grandchild drawings.

The above programming only prepares for execution of the motion program. The motion program is not executed when the MSEE instruction is inserted. To start the motion program after inserting the MSEE instruction, use a control signal to turn ON the Request for Start of Program Operation.

The motion program is executed in the scan cycle, but unlike ladder programs, the entire program is not executed in a single scan. Motion programs are controlled specifically by the system's motion management.



Note

The following points must be taken into consideration when executing motion programs.

- Motion programs that are registered in the M-EXECUTOR cannot be executed with MSEE instructions.
- More than one instance of the same motion program (i.e., the same program number) cannot be executed with MSEE instructions.
- Subprograms (MPS□□□) cannot be executed with MSEE instructions in a ladder program. You can call subprograms only from motion programs and motion subprograms (MPM□□□ and MPS□□□).
- You cannot call the same subprogram more than once at the same time.
- Sequence programs (SPM□□□ or SPS□□□) cannot be called with MSEE instructions from a ladder program.

### ■ Specifying Motion Programs

There are two methods that you can use to specify motion programs.


- Calling the motion program by specifying it directly
- Calling the motion program by specifying it indirectly

These two methods are described below.

#### • Calling the Motion Program by Specifying It Directly

Direct designation is used to call a motion program by specifying its program number (MPM□□□) directly.

To call the motion program from a ladder program with the MSEE instruction, specify the program number in the Program Number operand of the MSEE instruction.




#### • Calling the Motion Program by Specifying It Indirectly

Indirect designation is used to call a motion program by specifying its number in a register.

In this method, the program (MPM□□□) whose number is the same as the value that is stored in the register is called.


To call the motion program from a ladder program with an MSEE instruction, use the Program Number operand of the MSEE instruction to specify the M or D register that indirectly designates the motion program.



■ Work Registers

Work registers are used to set and monitor motion programs.

The address of the first work register for the motion program that is called with an MSEE instruction is specified in the MSEE instruction in the ladder program. The following figure shows the structure of the work registers.



Work Register	Contents	Reference
1st register	Motion Program Status Flags	Page 3-10
2nd register	Motion Program Control Signals	Page 3-12
3rd register	Interpolation Override	Page 3-15
4th register	System Work Number	Page 3-15

• Status Flags

The Motion Program Status Flags give the execution condition of the motion program. The following table describes the meanings of the Status Flags.

Bit No.	Name	Description
Bit 0	Program Executing	This bit is set to 1 when a motion program is running. 0: Motion program is stopped. 1: Motion program is running.
Bit 1	Program Paused	This bit is set to 1 when execution of a motion program is paused by a Request for Pause of Program. After a Request for Pause of Program control signal is input, it is confirmed that the axis decelerated to a stop and then the status flag is turned ON. 0: Program is not stopped by a pause request. 1: Program is stopped by a pause request.
Bit 2	Program Stopped for Stop Request	This bit is set to 1 when execution of a motion program is stopped by a Request for Stop of Program. 0: Program is not stopped by a stop request. 1: Program is stopped by a stop request.
Bit 3	Reserved for system.	—
Bit 4	Program Single-block Execution Stopped	This bit is set to 1 when execution of a single block is stopped in Debug Operation Mode. 0: Single block execution is not stopped. 1: Single block execution is stopped.
Bit 5	Reserved for system.	—

Continued on next page.


Continued from previous page.


Bit No.	Name	Description
Bit 6	Reserved for system.	–
Bit 7	Reserved for system.	–
Bit 8	Program Alarm	This bit is set to 1 when a program alarm occurs. When this bit is set to 1, details on the error will be displayed in the Error Information Dialog Box and are given in the S registers. 0: There is no program alarm. 1: A program alarm occurred.
Bit 9	Program Stopped at Breakpoint	This bit is set to 1 when execution of a program stops at a breakpoint in Debug Operation Mode. 0: Not stopped at a breakpoint. 1: Stopped at a breakpoint.
Bit A	Reserved for system.	–
Bit B	Debug Operation Mode	This bit is set to 1 when a program is running in Debug Operation Mode. 0: Not in Debug Operation Mode (Normal Execution Mode). 1: In Debug Operation Mode.
Bit C	Program Type	This bit reports whether the program that is being executed is a motion program or a sequence program. 0: Motion program 1: Sequence program
Bit D	Start Request History	This bit is set to 1 when the Request for Start of Program Operation is ON. 0: Request for Start of Program Operation is OFF. 1: Request for Start of Program Operation is ON.
Bit E	No System Work Error or Execution Scan Error	This bit is set to 1 when a system work number that was needed to execute a motion program could not be obtained, or when an MSEE instruction is programmed in a drawing other than a DWG.H. 0: There is no system work error or execution scan error. 1: A no system work error or execution scan error occurred.
Bit F	Main Program Number Limit Exceeded Error	This bit is set to 1 when the specified motion program number is out of range. Motion program number range: 1 to 512 0: There is no motion program number error. 1: A motion program number error occurred.













Note: If a program alarm occurs, motion program error information is provided in the Error Information Dialog Box and given in the S registers.

- Control Signals

To control the execution of a motion program, you must input program control signals (Request for Start of Program Operation, or Request for Stop of Program, etc.). The following table describes the control signals for motion programs.

: This mark indicates that the signal must be kept ON until the system acknowledges it.

: This mark indicates that the signal needs to be turned ON only for one high-speed scan.

Bit No.	Name	Description
Bit 0  	Request for Start of Program Operation	This bit makes a request to start execution of a motion program. The motion program starts when this bit changes from 0 to 1. This bit is ignored when there is a motion program alarm. 0: Turn OFF the request to start the program. 1: Turn ON the request to start the program.
Bit 1 	Request for Pause of Program	This bit makes a request to pause execution of a motion program. Execution of the program that was paused will resume when the pause request is turned OFF. 0: Turn OFF the request to pause the program (i.e., cancel the pause). 1: Turn ON the request to pause the program.
Bit 2 	Request for Stop of Program	This bit makes a request to stop execution of a motion program. A motion program alarm occurs if this bit is set to 1 while the axis is in motion. 0: Turn OFF the request to stop the program. 1: Turn ON the request to stop the program.
Bit 3 	Program Single-block Mode Selection	This bit makes a request to select Program Single-block Execution Mode. This mode can be used in place of Debug Operation Mode. 0: Turn OFF the request to select single-block mode. 1: Turn ON the request to select single-block mode.
Bit 4  	Program Single-block Start Request	When this bit is changed from 0 to 1, program execution changes to single-block execution (step execution). This bit is valid only when bit 3 (Program Single-block Mode Selection) in the control signals is set to 1. 0: Turn OFF the request to start the program in single-block mode. 1: Turn ON the request to start the program in single-block mode.
Bit 5 	Program Reset and Alarm Reset Request	This bit resets motion programs and alarms. 0: Turn OFF the request to reset the program and alarms. 1: Turn ON the request to reset the program and alarms.
Bit 6  	Request for Start of Continuous Program Operation	This bit makes a request to resume execution of a program that was stopped by a Request for Stop of Program. 0: Turn OFF the request to resume the program. 1: Turn ON the request to resume the program.
Bit 7	Reserved for system.	–
Bit 8 	Skip 1 Information	If this bit changes to 1 while an axis is in motion due to a SKP instruction (when the skip input signal selection is set to SS1), the axis will decelerate to a stop, and the reference in the remaining travel distance will be canceled. 0: Turn OFF the skip 1 signal. 1: Turn ON the skip 1 signal.
Bit 9 	Skip 2 Information	If this bit changes to 1 while an axis is in motion due to a SKP instruction (when the skip input signal selection is set to SS2), the axis will decelerate to a stop, and the reference in the remaining travel distance will be canceled. 0: Turn OFF the skip 2 signal. 1: Turn ON the skip 2 signal.
Bit A, B	Reserved for system.	–
Bit C	Reserved for system.	–

Continued on next page.

Continued from previous page.

Bit No.	Name	Description
Bit D — —	System Work Number Setting *1	To specify a system work number, set this bit to 1. 0: Do not specify a system work number. 1: Specify a system work number.
Bit E — —	Interpolation Override Setting *2	To specify an interpolation override, set this bit to 1. 0: Do not specify an interpolation override. 1: Specify an interpolation override.
Bit F	Reserved for system.	—

## \*1. System Work Number Setting

- When the Motion Program Is Registered in M-EXECUTOR:

The system work number cannot be specified. The system will use the definition number as the system work number.

- When a Motion Program Is Called from a Ladder Program with an MSEE Instruction:

OFF: The system will use an automatically acquired system work number. The system work number will be different each time.

ON: The work number that is specified by the system will be used.

However, if the work number is assigned to the M-EXECUTOR, a No System Work Available Error (Status Flag Bit E) is reported.

## \*2. Interpolation Override Setting

OFF: The interpolation override is always 100%.


ON: The interpolation override in the parameter setting is used.

Note: 1. Use the specified signal types for the ladder program inputs.


2. At startup, the motion programs for which the Request for Start of Program Operation control signals are ON will be executed.

**Example** Timing chart examples for axis operations and status flags after a control signal is input are provided below.

**Request for Start of Program Operation**




**Request for Pause**



\* Status flags related to control signal input are updated after one scan.


**Request for Stop**



\* Status flags related to control signal input are updated after one scan.



## If a Motion Program Alarm Occurs



\* Status flags related to control signal input are updated after one scan.



Important

1. If the Request for Stop of Program control signal is turned ON while the axis is being controlled for a motion language instruction, an alarm will occur.
2. If the Request for Stop of Program control signal is turned ON while the axis is being controlled for an interpolation motion language instruction, the axes will stop immediately. To perform a deceleration stop, use the Request for Pause of Operation control signal.
3. The Request for Pause of Program control signal is not acknowledged while a Zero Point Return (ZRN) instruction is being executed. To stop the operation, use the Request for Stop of Program control signal.
4. If a motion program alarm occurs while an axis is in motion, the axis stops immediately.

Refer to the following manuals for details on programming examples for controlling motion programs.

📖 *MP3000 Series Motion Programming Manual* (Manual No.: SIEP C880725 14)

#### • Interpolation Override

An interpolation override allows you to change the output ratio of the axis movement speed reference for interpolation motion language instructions.

Set the override value to use when executing interpolation instructions (MVS, MCW, MCC, or SKP).

The interpolation override is valid only when bit E (Interpolation Override Setting) in the control signals is ON.

The setting range of the interpolation override is 0 to 32,767.

Unit: 1 = 0.01%

#### • System Work Numbers

When you call a motion program from a ladder program with the MSEE instruction, set the system work number to use to call the motion program. This system work number is valid only when bit D (System Work Number Setting) of the control signals is ON.

Setting range: 1 to 32



When using MSEE instructions in ladder programs along with the M-EXECUTOR, do not specify the system work numbers that are for the M-EXECUTOR in the MSEE instructions in the ladder programs. If you specify one, a No System Work Error will occur.

System work numbers for the M-EXECUTOR: 0 to the set value of the number of program definitions

**Information**

You cannot set the system work numbers when you use the M-EXECUTOR. The system will use system work numbers that are the same as the definition numbers.

### ■ Monitoring Motion Program Execution Information

The execution information for motion programs can be monitored using the S registers (SW03200 to SW05119 and SW08192 to SW09125).

The execution information is monitored differently, depending on whether the motion program is called from a ladder program with an MSEE instruction, or the motion program is registered in the M-EXECUTOR program execution definitions.

This section describes these two monitoring methods.

#### • When the Motion Program Is Called from the Ladder Program with an MSEE Instruction

When a motion program is called from the ladder program with an MSEE instruction, the monitoring method depends on the setting of bit D (System Work Number Setting) in the Motion Program Control Signals.

Bit D (System Work Number Setting) in the Control Signal Word for Motion Programs	Monitoring
ON	<p>The execution information is reported in the Work n Program Information registers (SW03264 to SW05119 and SW08192 to SW09125). For example, if the system work number is 1, you can monitor the execution information of the motion program with the Work 1 Program Information registers (SW03264 to SW03321).</p>
OFF	<p>The system automatically determines the system work number to use. You can check the work numbers that are in use in the Active Program Numbers registers (SW03200 to SW03231). For example, if MPM001 is the motion program to be monitored and SW03202 contains a 1, the system work number is 3. You can therefore monitor the execution information of the motion program with the Work 3 Program Information registers (SW03380 to SW03437).</p>

#### • When the Motion Program Is Registered in the M-EXECUTOR Program Execution Definitions:

When the motion program is registered in the M-EXECUTOR program execution definitions, the system work number used will be the same as the program execution registration number in the M-EXECUTOR.

For example, if the motion program is registered for execution as number 3, system work number 3 is used. You can therefore monitor the execution information of the motion program with the Work 3 Program Information registers (SW03380 to SW03437).

## ◆ Sequence Programs

A sequence program is written in a text-based motion language.

There are two types of sequence programs.

Type	Designation Method	Features	Number of Programs
Main programs	SPM□□□ (□□□=1 to 512)	Main programs are called from the M-EXECUTOR program execution definitions.	You can create up to 512 motion programs, including the following programs: <ul style="list-style-type: none"> <li>• Motion main programs</li> <li>• Motion subprograms</li> <li>• Sequence main programs</li> <li>• Sequence subprograms</li> </ul>
Subprograms	SPS□□□ (□□□=1 to 512)	Subprograms are called from a main program.	



Important

The same numbers are used to manage the sequence programs and motion programs.

Use a unique number for each program.


- Motion program numbers are given in the form MPM□□□□ or MPS□□□□.
- Sequence program numbers are given in the form SPM□□□□ or SPS□□□□.

## ■ Sequence Program Execution

A sequence program is executed by registering it in the M-EXECUTOR execution definitions.

The sequence programs are executed in ascending order.

The following figure shows an execution example.




If the execution type is set to an H-scan sequence program or L-scan sequence program, then the program will be executed as soon as the definition is saved. If the execution type is set to a startup sequence program, then the program will be executed the next time when the power supply is turned ON.

### ■ Specifying Sequence Programs

Sequence programs must be specified directly. Indirect designations cannot be used.

Specify the program number of the sequence program to execute (SPM□□□).



### ■ Work Registers

Work registers are used to monitor sequence programs.

The work registers have Status Flags inside the M-EXECUTOR control registers, in the same way as motion programs that are registered in the M-EXECUTOR.

#### • Sequence Program Status Flags

The Sequence Program Status Flags give the execution condition of the sequence program.

The following table describes the meanings of the Status Flags.

Bit No.	Name	Status
0	Program Executing	Program is being executed.
1	–	Reserved for system.
2	–	Reserved for system.
3	–	Reserved for system.
4	–	Reserved for system.
5	–	Reserved for system.
6	–	Reserved for system.
7	–	Reserved for system.
8	Program Alarm	There is a program alarm.
9	Program Stopped at Breakpoint	Execution is stopped at a breakpoint.
A	–	Reserved for system.
B	Debug Operation Mode	The program is in Debug Mode (EWS debugging).
C	Program Type	Program Type, 1: Sequence program
D	Start Request History	There is a request to start program execution.
E	–	Reserved for system.
F	–	Reserved for system.



Note

#### Sequence Program Alarms

When an error is detected, bit 8 (Program Alarm) turns ON in the Status Flags in the M-EXECUTOR control registers.

When the error is removed, this bit turns OFF.

The following errors can occur.

- The called program is not registered.
- The called program is not a sequence program.
- The called program is not a subprogram (a main program was called).
- Called Program Number Limit Exceeded Error
- Too Many Nesting Levels Error


## Registers

Registers are areas that store data within the Machine Controller. Variables are registers with labels (variable names).

There are two kinds of registers: global registers that are shared between all programs, and local registers that are used only by a specific program.

### Global Registers


Global registers are shared by ladder programs, user functions, motion programs, and sequence programs. Memory space for global registers is reserved by the system for each register type.




### Local Registers

Local registers can be used within each specific drawing. These registers cannot be shared by other drawings. Local registers are stored in the program memory for each drawing.


Ladder Program Conceptual Diagram



Motion Program Conceptual Diagram



## Structure of Register Addresses



**Information**

You can also use index registers or array registers as variables to address specific registers. Refer to the following sections for details.

*Index Registers (i, j) (page 3-27)*

*Array Registers ([ ]) (page 3-30)*

## Register Types

This section describes global and local registers.

### ◆ Global Registers

Global registers are shared by ladder programs, user functions, motion programs, and sequence programs. In other words, the operation results of a ladder program can be used by other user functions, motion programs, or sequence programs.

Type	Name	Designation Method	Usable Range	Description
S	System registers (S registers)	SBnnnnnh, SWnnnnn, SLnnnnn, SQnnnnn, SFnnnnn, SDnnnnn, SAnnnnn	SW00000 to SW65534	These registers are prepared by the system. They report the status of the Machine Controller and other information. The system clears the registers from SW00000 to SW00049 to 0 at startup. They have a battery backup.
M	Data registers (M registers)	MBnnnnnnnh, MWnnnnnnn, MLnnnnnnn, MQnnnnnnn, MFnnnnnnn, MDnnnnnnn, MAnnnnnnn	MW0000000 to MW1048575	These registers are used as interfaces between programs. They have a battery backup.

Continued on next page.

Continued from previous page.


Type	Name	Designation Method	Usable Range	Description
G	G registers	GBnnnnnnnh, GWnnnnnnn, GLnnnnnnn, GQnnnnnnn, GFnnnnnnn, GDnnnnnnn, GAnnnnnnn	GW0000000 to GW2097151	These registers are used as interfaces between programs. They do not have a battery backup.
I	Input registers (I registers)	IBhhhhhh, IWhhhhhh, ILhhhhhh, IQhhhhhh, IFhhhhhh, IDhhhhhh, IAhhhhhh	IW00000 to IW07FFF, IW10000 to IW17FFF	These registers are used for input data.
			IW08000 to IW0FFFF	These registers store the motion monitor parameters. These registers are used for Motion Modules.
			IW20000 to IW21FFF	These registers are used as interfaces between CPU Units when Expansion Racks are used (CPU interface registers).
O	Output registers (O registers)	OBhhhhhh, OWhhhhhh, OLhhhhhh, OQhhhhhh, OFhhhhhh, ODhhhhhh, OAhhhhhh	OW00000 to OW07FFF, OW10000 to OW17FFF	These registers are used for output data.
			OW08000 to OW0FFFF	These store the motion setting parameters. These registers are used for Motion Modules.
			OW20000 to OW21FFF	These registers are used as interfaces between CPU Units when Expansion Racks are used (CPU interface registers).
C	Constant registers (C registers)	CBnnnnnh, CWnnnnn, CLnnnnn, CQnnnnn, CFnnnnn, CDnnnnn, CAnnnnn	CW00000 to CW16383	These registers can be read in programs but they cannot be written. The values are set from the MPE720.

Note: n: decimal digit, h: hexadecimal digit

## ◆ Local Registers

Local registers are valid within only one specific program. The local registers in other programs cannot be accessed.

You specify the usable range from the MPE720.

Type	Name	Designation Method	Description	Features
#	# registers	#Bnnnnnh, #Wnnnnn, #Lnnnnn, #Qnnnnn, #Fnnnnn, #Dnnnnn, #Annnnn	These registers can be read in programs but they cannot be written. The values are set from the MPE720.	Program-specific
D	D registers	DBnnnnnh, DWnnnnn, DLnnnnn, DQnnnnn, DFnnnnn, DDnnnnn, DAnnnnn	These registers can be used for general purposes within a program. By default, 32 words are reserved for each program. The default value after startup depends on the setting of the <b>D Register Clear when Start</b> option. Refer to the following section for details.  <i>Setting the D Register Clear When Start Option (page 3-23)</i>	
X	Function input registers	XBnnnnnh, XWnnnnn, XLnnnnn, XQnnnnn, XFnnnnn, XDnnnnn	These registers are used for inputs to functions. <ul style="list-style-type: none"> <li>• Bit inputs: XB000000 to XB00000F</li> <li>• Integer inputs: XW00001 to XW00016</li> <li>• Double-length integers: XL00001 to XL00015</li> <li>• Quadruple-length integers: XQ00001 to XQ00013</li> <li>• Real numbers: XF00001 to XF00015</li> <li>• Double-precision real numbers: XD00001 to XD00013</li> </ul>	Function-specific
Y	Function output registers	YBnnnnnh, YWnnnnn, YLnnnnn, YQnnnnn, YFnnnnn, YDnnnnn	These registers are used for outputs from functions. <ul style="list-style-type: none"> <li>• Bit outputs: YB000000 to YB00000F</li> <li>• Integer outputs: YW00001 to YW00016</li> <li>• Double-length integers: YL00001 to YL00015</li> <li>• Quadruple-length integers: YQ00001 to YQ00013</li> <li>• Real numbers: YF00001 to YF00015</li> <li>• Double-precision real numbers: YD00001 to YD00013</li> </ul>	
Z	Function internal registers	ZBnnnnnh, ZWnnnnn, ZLnnnnn, ZQnnnnn, ZFnnnnn, ZDnnnnn	These are internal registers that are unique within each function. You can use them for internal processing in functions. <ul style="list-style-type: none"> <li>• Bits: ZB000000 to ZB00063F</li> <li>• Integers: ZW00000 to ZW00063</li> <li>• Double-length integers: ZL00000 to ZL00062</li> <li>• Quadruple-length integers: ZQ00000 to ZQ00060</li> <li>• Real numbers: ZF00000 to ZF00062</li> <li>• Double-precision real numbers: ZD00000 to ZD00060</li> </ul>	
A	Function external registers	ABnnnnnh, AWnnnnn, ALnnnnn, AQnnnnn, AFnnnnn, ADnnnnn	These are external registers that use the address input value as the base address. When the address input value of an M or D register is provided by the source of the function call, then the registers of the source of the function call can be accessed from inside the function by using that address as the base.	

Note: n: decimal digit, h: hexadecimal digit





User functions can be called from any programs, any number of times.


### ■ Precautions When Using Local Registers within a User Function

When you call a user function, consider what values could be in the local registers, and perform initialization as needed.

Name	Precautions
X registers (function input registers)	If input values are not set, the values will be uncertain. Do not use X registers that are outside of the range that is specified in the input definitions.
Y registers (function output registers)	If output values are not set, the values will be uncertain. Always set the values of the range of Y registers that is specified in the output definitions.
Z registers (function internal registers)	When the function is called, the previously set values will be lost and the values will be uncertain. These registers are not appropriate for instructions if the previous value must be retained. Use them only after initializing them within the function.
# registers	These are constant registers. Their values cannot be changed.
D registers	When the function is called, the previously set values are preserved. If a previous value is not necessary, initialize the value, or use a Z register instead. D registers retain the data until the power is turned OFF. The default value after startup depends on the setting of the <b>D Register Clear when Start</b> option. Refer to the following sections for details. <i>Setting the D Register Clear When Start Option (page 3-23)</i>

#### • Setting the D Register Clear When Start Option

1. Select **File – Environment Setting** from the MPE720 Version 7 Window.
2. Select **Setup – System Setting**.
3. Select **Enable** or **Disable** for the **D Register Clear when Start** option.  
Disable: The initial values will be uncertain.  
Enable: The initial values will be 0.



## Data Types

There are various data types that you can use depending on the purpose of the application: bit, integer, double-length integer, quadruple-length integer, real number, double-precision real number, and address.

Symbol	Data Type	Range of Values	Data Size	Description
B	Bit	1 (ON) or 0 (OFF)	–	Used in relay circuits and to determine ON/OFF status.
W	Integer	-32,768 to 32,767 (8000 to 7FFF hex)	1 word	Used for numeric operations. The values in parentheses on the left are for logical operations.
L	Double-length integer	-2,147,483,648 to 2,147,483,647 (80000000 to 7FFFFFFF hex)	2 words	Used for numeric operations. The values in parentheses on the left are for logical operations.
Q	Quadruple-length integer <sup>*1</sup>	-9,223,372,036,854,775,808 to 9,223,372,036,854,775,807 (8000000000000000 to 7FFFFFFFFFFFFFFF hex)	4 words	Used for numeric operations. The values in parentheses on the left are for logical operations.
F	Real number	$\pm (1.175E - 38 \text{ to } 3.402E + 38)$ or 0	2 words	Used for advanced numeric operations. <sup>*2</sup>
D	Double-precision real number <sup>*1</sup>	$\pm (2.225E - 308 \text{ to } 1.798E + 308)$ or 0	4 words	Used for advanced numeric operations. <sup>*2</sup>
A	Address	0 to 2,097,152	–	Used only as pointers for addressing.


\*1. These data types cannot be used for indirect designation of motion programs.

\*2. Conforms to IEEE754 standards.



Important

The MP3000-series Machine Controller does not have separate registers for each data type. As shown in the following figure, the same address will access the same register even if the data type is different. For example, MB00001003, a bit address, and the MW0000100, an integer address, have different data types, but they both access the same register, MW0000100.



Terms

**Pointer Designation**

When an address is passed to a function as a parameter, this is referred to as pointer designation. When pointer designation is used, the continuous data area starting from the address of the specified register address can be used in internal processing for functions with all data types.

## ◆ Precautions for Operations Using Different Data Types

If you perform an operation using different data types, be aware that the results will be different depending on the data type of the storage register, as described below.


- Storing Real Number Data in an Integer Register

MW0000100 = MF0000200; the real number is stored after it is converted to an integer.

(00001) (1.234)

Note: There may be rounding error due to storing a real number in an integer register.

Whether numbers are rounded or truncated when converting a real number to an integer can be set in the properties of the drawing.

 ■ *Setting for Real Number Casting (page 3-26)*

MW0000100 = MF0000200 + MF0000202

(0124) (123.48) (0.02) The result of the operation may be different depending on the value of the variable.

(0123) (123.49) (0.01)

- Storing Real Number Data in a Double-length Integer Register

ML0000100 = MF0000200; the real number is stored after it is converted to an integer.

(65432) (65432.1)

- Storing Double-length Integer Data in an Integer Register

MW0000100 = ML0000200; the lower 16 bits of the double-length integer are stored without change.

(-00001) (65535)

- Storing Integer Data in a Double-length Integer Register

ML0000100 = MW0000200; the integer is stored after it is converted to double-length integer data.

(0001234) (1234)


### ■ Setting for Real Number Casting

The casting method (truncating or rounding) can be set in the detailed definitions in the Drawing Properties Dialog Box. The method to use for real number casting is set for each drawing.

Use the following procedure to display the Program Property Dialog Box.

1. In the Ladder Pane, select the ladder program for which to view the properties.
2. Right-click the selected program and select **Property** from the pop-up menu.


The Program Property Dialog Box will be displayed.



**Information**

The data is little endian, as shown in the following example.


- MB00001006




- MW0000100 = 1234 hex



- ML0000100 = 12345678 hex




- MQ0000100 = 123456789ABCDEF0 hex



### Index Registers (i, j)

There are two special registers, i and j, that are used to modify relay and register addresses. The functions of i and j are identical. They are used to handle register addresses like variables.

There are subscript registers for each program type, as shown in the following figure.



\* Motion programs and sequence programs have separate i and j registers for each task.

Note: Functions reference the i and j registers that belong to the calling drawing.

For example, a function called by DWG.H will reference the i and j registers for DWG.H.

We will describe this with examples for each register data type.

### ◆ Attaching an Index to a Bit Register

Using an index is the same as adding the value of  $i$  or  $j$  to the register address.

For example, if  $i = 2$ ,  $MB00000000i$  is the same as  $MB00000002$ .

$i = 2;$   
 $DB000000 = MB00000000i;$       Equivalent       $DB000000 = MB00000002;$

### ◆ Attaching an Index to an Integer Register

Using an index is the same as adding the value of  $i$  or  $j$  to the register address.


For example, if  $j = 30$ ,  $MW0000001j$  is the same as  $MW0000031$ .

$j = 30;$   
 $DW000000 = MW0000001j;$       Equivalent       $DW000000 = MW0000031;$

### ◆ Attaching an Index to a Double-length Integer or a Real Number Register

Using an index is the same as adding the value of  $i$  or  $j$  to the register address.

For example, if  $j = 1$ ,  $ML0000000j$  is the same as  $ML0000001$ . Similarly, if  $j = 1$ ,  $MF0000000j$  is the same as  $MF0000001$ .



Note



Double-length integers and real numbers use a region that is 2 words in size. For example, when using  $ML0000000j$  with both  $j = 0$  and  $j = 1$ , the one-word area of  $MW0000001$  will overlap. Be careful of overlapping areas when indexing double-length integer or real number register addresses.

### ◆ Attaching an Index to a Quadruple-length Integer or a Double-precision Real Number Register



Using an index is the same as adding the value of  $i$  or  $j$  to the register address.

For example, if  $j = 2$ , MQ0000000j is the same as MQ0000002. Similarly, if  $j = 2$ , MD0000000j is the same as MD0000002.

Quadruple-length Integer



Double-precision Real Number



Note

Quadruple-length integers and double-precision real numbers use a region that is 4 words in size. For example, when using MQ0000000j with both  $j = 0$  and  $j = 2$ , the two-word area of MW0000002 and MW0000003 will overlap. Be careful of overlapping areas when indexing quadruple-length integer or double-precision real number register addresses.

## Array Registers ([ ])

Array registers are used to modify register addresses, and are denoted by square brackets [ ].

These are used to handle register addresses like variables.

Similarly to index registers, an offset is added to the register address.

### ◆ Attaching an Array Register to a Bit Register

Using an array register is the same as adding the value of the array register to the register address.

For example, if  $DW00000 = 2$ ,  $MB00000000[DW00000]$  is the same as  $MB00000002$ .

$DW00000 = 2;$	Equivalent	
$DB000020 = MB00000000[DW00000];$	$\longleftrightarrow$	$DB000020 = MB00000002;$

### ◆ Attaching an Array Register to a Register Other Than a Bit Register

Using an array register is the same as adding the word size of the data type of the array register times the value of the array register to the register address.

For example, if  $DW00000 = 30$ ,  $ML0000002[DW00000]$  is the same as  $ML0000062$ .

$DL00002 = ML00000 (30 \times 2 + 2) = ML0000062$

$DW00000 = 30;$	Equivalent	
$DL00002 = ML0000002[DW00000];$	$\longleftrightarrow$	$DL00002 = ML0000062;$




## Execution Scheduling

This section describes the execution order of drawings.

### Controlling the Execution of Drawings

Drawings are executed based on their priorities, as shown in the following figure.




\*1. DWG.A drawings are executed immediately after the power supply is turned ON.


\*2. When an interrupt signal is input, execution of the DWG.I drawing is given priority even if execution of a DWG.H or DWG.L drawing is currently in progress.

Note: The parent drawing of each drawing is automatically called and executed by the system.

### Scheduling the Execution of High-speed and Low-speed Scan Process Drawings

High-speed scan process drawings (DWG.H) and low-speed scan process drawings (DWG.L) cannot be executed at the same time. DWG.L drawings are executed during the idle time of DWG.H drawings. The period during which DWG.H drawings are executed is called the high-speed scan time. The period during which DWG.L drawings are executed is called the low-speed scan time.



 : Actual processing time during the scan

\* Background processing is used to execute internal system processing, such as communications processing.

Refer to the following section for the setting procedure for the high-speed and low-speed scans.

 [Setting the High-speed and Low-speed Scan Times \(page 3-34\)](#)

## Scans

A scan refers to the processing that starts at fixed intervals.

This section describes the scans.

### Types of Scans

The CPU Unit has two types of scans, the high-speed H scan and low-speed L scan.

A high-speed H scan has higher priority than a low-speed L scan. The fixed period for each scan, also known as the scan time, can be set by the user.

This section describes the settings for the scan times.

### High-speed (H) Scan

The following table shows the different high-speed scan time set values depending on whether the MP2000 Optional Module is used.



Note

There are restrictions on the set value of the high-speed scan time. Refer to the following section for details.

◆ *High-speed Scan Time Set Value Restrictions (page 3-32)*

When the MP2000 Optional Module Is Not Used	When the MP2000 Optional Module Is Used
0.125 to 32.0 ms (in 0.125-ms increments)	0.125 ms, 0.250 ms, or 0.5 to 32.0 ms (in 0.5-ms increments)

**Information** The default high-speed scan time is 4.0 ms.

### ◆ High-speed Scan Time Set Value Restrictions

This section describes the restrictions on the set value of the high-speed scan time.

#### ■ Restrictions Imposed by the MECHATROLINK-III Communications Cycle

The high-speed scan of the CPU Unit is synchronized with the MECHATROLINK-III communications cycle of the SVC32 Module built into the CPU Unit. This imposes the following restrictions in the set value of the high-speed scan time.

Communications Cycle	High-speed Scan Time Set Value Restrictions	Possible Set Values	
		When MP2000 Optional Module Is Not Used	When MP2000 Optional Module Is Used
125 $\mu$ s	Integral multiple of 125 $\mu$ s	0.125 to 32.0 ms (in increments of 0.125 ms)	0.125 ms, 0.250 ms, or 0.5 to 32.0 ms (in increments of 0.5 ms)
250 $\mu$ s	Integral multiple of 250 $\mu$ s or 1 times the integer portion	0.250 to 32.0 ms (in increments of 0.250 ms)	0.250 ms or 0.5 to 32.0 ms (in increments of 0.5 ms)
500 $\mu$ s	Integral multiple of 500 $\mu$ s or 1 times the integer portion	0.5 to 32.0 ms (in increments of 0.5 ms)	0.5 to 32.0 ms (in increments of 0.5 ms)
1 ms	Integral multiple of 1 ms or 1 times the integer portion	1.0 to 32.0 ms (in increments of 1 ms)	1.0 to 32.0 ms (in increments of 1 ms)
1.5 ms	Integral multiple of 1.5 ms or 1 times the integer portion	1.5 to 31.5 ms (in increments of 1.5 ms)	1.5 to 31.5 ms (in increments of 1.5 ms)

Continued on next page.

Continued from previous page.

Communications Cycle	High-speed Scan Time Set Value Restrictions	Possible Set Values	
		When MP2000 Optional Module Is Not Used	When MP2000 Optional Module Is Used
2 ms	Integral multiple of 2 ms or 1 times the integer portion	2.0 to 32.0 ms (in increments of 2 ms)	2.0 to 32.0 ms (in increments of 2 ms)
3 ms	Integral multiple of 3 ms or 1 times the integer portion	3.0 to 30.0 ms (in increments of 3 ms)	3.0 to 30.0 ms (in increments of 3 ms)

If these restrictions are not observed, the high-speed scan cycle will stop and an alarm will occur. The alarm is reported in the M-III Restrictions Error Bit (SB00041D) in the CPU Error Status System Register. Refer to the following section for details.

4.3 CPU Unit Specifications – ♦ System Status (page 4-19)

### ■ Restrictions Imposed by $\Sigma$ -V SERVOPACKs

The specifications of MECHATROLINK-III  $\Sigma$ -V-series SERVOPACKs impose the following restrictions on the set value of the high-speed scan time.

$\Sigma$ -V SERVOPACK Version	Restrictions
Lower than version 21	High-speed scan time set value $\leq (32 \times \text{Communications cycle})$ Example: If the MECHATROLINK-III communications cycle is 125 $\mu\text{s}$ , the set value of the high-speed scan time can be up to 4.0 ms (125 $\mu\text{s} \times 32$ ).
Version 21 or higher	High-speed scan time set value $\leq (254 \times \text{Communications cycle})$ Example: If the MECHATROLINK-III communications cycle is 125 $\mu\text{s}$ , the set value of the high-speed scan time can be up to 31.75 ms (125 $\mu\text{s} \times 254$ ).

If these restrictions are not observed, an A.94B Data Setting Warning 2 (Data Out of Range) warning will occur in the SERVOPACK.


### ♦ I/O Processing

If the high-speed scan time is set to at least 0.5 ms, the I/O service (I/O processing) of the MP2000 Optional Module will be performed every scan.

If the high-speed scan time is set to less than 0.5 ms (0.125 ms or 0.250 ms), the I/O service (I/O processing) of the MP2000 Optional Module will be performed at the filtered basic cycle of 0.5 ms.


The following figures show the timing results for these settings.

### ■ Example: High-speed Scan Time Set to 0.5 ms




\* The purpose of this system service register is to determine from a ladder program whether the I/O scan service is being executed for MP2000 Optional Modules

### ■ Example: High-speed Scan Time Set to 0.250 ms



\* The purpose of this system service register is to determine from a ladder program whether the I/O scan service is being executed for MP2000 Optional Modules

### ■ Example: High-speed Scan Time Set to 0.125 ms



\* The purpose of this system service register is to determine from a ladder program whether the I/O scan service is being executed for MP2000 Optional Modules

## Low-speed (L) Scan

The setting range for the low-speed scan time is 2.0 to 300.0 ms (in increments of 0.5 ms).

**Information** The default low-speed scan time is 200.0 ms.

### ◆ I/O Processing

During the low-speed scan, the I/O service (I/O processing) is performed every scan, regardless of the set value.

## Setting the High-speed and Low-speed Scan Times

Use MPE720 version 7 and perform the procedure given below to set the high-speed and low-speed scan times.


1. Stop the CPU Unit.

2. Select **File – Environment Setting** from the menu bar. Alternatively, click the **System Setting** Icon on the Start Tab Page.

The Environment Setting Dialog Box will be displayed.

3. Select **Setup – Scan Time Setting**.

The following dialog box will be displayed.



Setting Value: Enter the scan time settings.

Current Value: A value of 0.0 ms is displayed when the MPE720 is offline. Otherwise, the actual processing times for the scans are displayed.

Maximum Value: The maximum processing time for the scan is displayed. You can set the maximum value. The setting is retained until it is exceeded.

4. Enter the high-speed scan time in the **Setting Value** Box under **High-speed Scan**. Enter the low-speed scan time in the **Setting Value** Box under **Low-speed Scan**.

The following table shows the possible set values and default values for each scan time.

Item	Possible Set Values	Default
High-speed Scan Time	0.125 to 32 ms (in 0.125-ms increments)	4.0 ms
Low-speed Scan Time	2.0 to 300.0 ms (in 0.5-ms increments)	200.0 ms

Note: The possible set values and default values depend on the model. Refer to the user's manual for the Module you are using for details.

5. Click the **OK** Button.

The settings will be saved and the Environment Setting Dialog Box will close.



Important

Observe the following precautions when setting the high-speed scan time and low-speed scan time.

1. Set the scan set value so that it is 1.25 times greater than the maximum value.  
If the scan set value is too close to the maximum value, the refresh rate of the MPE720 window will noticeably drop and can cause communications timeout errors to occur. If the maximum value exceeds the scan set value, a watchdog error may occur and cause the Machine Controller system to shut down.
2. If you are using MECHATROLINK-II or MECHATROLINK-III, set values that are an integral multiple of the communications cycle. If you change the communications cycle, check the scan time set values.
3. Do not change the scan set value while the Servo is ON. Never change the scan set value while an axis is in motion (i.e., while the motor is rotating). Doing so may cause the motor to rotate out of control.
4. After changing or setting a scan time, always save the data to flash memory.


## Keep Latest Value Setting in High-speed/Low-speed Scans

You can use the Keep Latest Value setting to specify the number of scans to hold previous data when an input error occurs. If the input error still exists after the number of scans specified for the Keep Latest Value setting, the input values will be treated as 0. When the input error is removed, reading the input values is resumed automatically. There are separate Keep Latest Value settings for the high-speed scan and the low-speed scan.

### ◆ Operation

The following figure illustrates the operation for the Keep Latest Value setting.


Keep Latest Value setting: 3 scans for high-speed scan



### ◆ Setting Procedure

Perform the following procedure with MPE720 version 7 to set the Keep Latest Value setting.

1. Select **File – Environment Setting** from the menu bar. Alternatively, click the **System Setting** Icon on the Start Tab Page.  
The Environment Setting Dialog Box will be displayed.
2. Select **Setup – System Setting**.  
The following dialog box will be displayed.



3. Set values in the **High-speed Input** and **Low-speed Input** Boxes in the **Keep Latest Value** Group.

#### 4. Click the **OK** Button.

The settings will be saved and the Environment Setting Dialog Box will close.


##### Information

The Keep Latest Value setting specifies the number of scans to process before the I/O service clears the input registers.

If the high-speed scan time setting is set to 0.250 ms or 0.125 ms, the scan at which the input registers are cleared will differ for the MP2000-series Optional Module and the 218IFD and SVC32 Function Modules that are built into the CPU Unit.

In the following example, an input error occurs simultaneously on the MP2000-series Optional Module and the 218IFD and SVC32 Function Modules in the CPU Unit when the high-speed scan setting is set to 0.250 ms and the Keep Latest Value setting is set to 5 scans.

The input registers in the 218IFD and SVC32 Function Modules built into the CPU Unit are cleared on the sixth scan that immediately follows the specified number of scans, whereas on the MP2000-series Optional Module, the input registers are cleared on the seventh service scan that immediately follows the specified number of scans.




# 3.2 Function Modules

This section describes the Function Modules that are built into the CPU Unit.

## Self Configuration

Self configuration is a feature that automatically recognizes all the Optional Modules that are installed in the Machine Controller and all the slave devices that are connected via the MECHATROLINK connector (such as Servo Drives), and creates the module configuration definition files based on that information. Self configuration greatly reduces the steps that are required to set up the system. Use the DIP switch on the CPU Unit or use the MPE720 to execute self configuration.

The following figure illustrates self configuration.







## Operating Procedures

This section describes the procedures for executing self configuration.

- Refer to the following section when you perform self configuration for the first time after connecting the devices.

 *Self Configuration Using the DIP Switch (page 3-39)*

- If the Machine Controller and the MPE720 are already connected, the self configuration can be performed by using the MPE720.

 *Self Configuration Using the MPE720 (page 3-42)*

### ◆ Self Configuration Using the DIP Switch

The procedure for executing self configuration using the DIP switch depends on whether self configuration is being done for the first time since the devices were connected, or if SERVOPACKs or other devices have been added.

Both procedures are described below.

#### ■ First Self Configuration after Connecting the Devices


The following procedure performs a new self configuration of all Modules, and creates new definition files.



Important


1. Before performing this procedure, turn ON the power supply to the SERVOPACKs and other devices.
2. This procedure will clear the following data:
  - All definition files
  - All user programs
  - All registers

1. Turn OFF the power supply to the CPU Unit.
2. Turn ON only the INIT and CNFG pins on the SW1 DIP switch on the CPU Unit.



3. Turn ON the power supply to the CPU Unit.  
Self configuration will be executed.
4. Confirm that the status indicators on the CPU Unit change in the following way:
  - RDY: Goes out, and then lights.
  - RUN: Goes out, flashes, and then lights.

5. Turn OFF the INIT and CNFG pins on the SW1 DIP switch on the CPU Unit.



Important

1. INIT Pin on the DIP Switch and RAM Data

If the power supply is turned OFF and ON again when the INIT pin on the Machine Controller SW1 DIP switch is turned ON, the data in RAM will be cleared.

If the power supply is turned OFF and ON again when the INIT pin is turned OFF, the data from the flash memory will be loaded and will overwrite the RAM data. Therefore, if the power supply must be turned OFF while writing or editing a program, make sure you save the data to the Machine Controller's flash memory to protect the RAM data.

2. Power Interruptions after Self Configuration

After performing self configuration, turn OFF the power supply to the Machine Controller only after the definition data is saved to the flash memory of the Machine Controller.

If by chance, the power supply is turned OFF before the data is saved, perform self configuration again.

Refer to the following manual for details on saving data to the flash memory.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

#### ■ After Adding SERVOPACKs, Optional Modules, and Other Devices


The following procedure will create the definitions for devices and Function Modules that are newly detected by MECHATROLINK communications. This procedure will not update any of the definitions that were made for existing devices and Function Modules. The definitions before self configuration will be retained.



Important


Before performing this procedure, turn ON the power supply to the SERVOPACKs and other devices.

1. Turn OFF the power supply to the CPU Unit.
2. Turn ON only the CNFG pin on the SW1 DIP switch on the CPU Unit.



3. Turn ON the power supply to the CPU Unit.  
Self configuration will be executed.

4. Confirm that the status indicators on the CPU Unit change in the following way:
  - RDY: Goes out, and then lights.
  - RUN: Goes out, flashes, and then lights.
5. Turn OFF the CNFG pin on the SW1 DIP switch on the CPU Unit.




Important

#### Power Interruptions after Self Configuration

After performing self configuration, turn OFF the power supply to the Machine Controller only after the definition data is saved to the flash memory of the Machine Controller.

If by chance, the power supply is turned OFF before the data is saved, perform self configuration again.

Refer to the following manual for details on saving data to the flash memory.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

### ◆ Self Configuration Using the MPE720

There are two types of self configuration that can be performed with the MPE720.

- Self configuration of all Modules: Use this mode when the system is being set up for the first time, or after the entire system has been changed.
- Self configuration of specified Modules: Use this mode when a part of the system has been changed. This process will automatically recognize all devices that have been added or removed, and automatically generate definition files for them.


### ■ Self Configuration of All Modules



Important

Before performing this procedure, turn ON the power supply to the SERVOPACKs and other devices.


#### 1. Click the **Module Configuration** Icon on the Start Tab Page.




The following Module Configuration Definition Tab Page will be displayed.

Module	Function Module/Slave	Status	Circuit No./Axis Address		Motion Register	Disabled	Register (Input/Output)			Com
			Start	Duplex, circ.			Start - End	Size	Scan	
01 CPU-201	---	---	---	---	---	---	---	---	---	---
02 218FD	Driving	---	Circuit No1	1	---	---	Input 0000 - 07FF[D]	2040	---	---
03 SVC02	Driving	---	Circuit No1	2	0000 - 0FFF[D]	---	Input 0000 - 08FF[D]	1024	---	---
04 SVR02	Driving	---	Circuit No3	2	9000 - 9FFF[D]	---	Output 0000 - 0C3F[D]	64	---	---
05 M-EXECUTOR	Driving	---	---	---	---	---	---	---	---	---
06 ---	---	---	---	---	---	---	---	---	---	---


2. Click the **Module** Button.



3. Click the **All modules** Button on the Launcher.



The MC-Configurator Dialog Box will be displayed.



4. Click the **OK** Button.  
Self configuration will be executed.


### ■ Self Configuration of Specified Modules




Important

Before performing this procedure, turn ON the power supply to the SERVOPACKs and other devices.

#### 1. Click the **Module Configuration** Icon on the Start Tab Page.




The following Module Configuration Definition Tab Page will be displayed.




#### 2. In the **Function Module/Slave** Column, select the Modules to configure using self configuration.

3. Click the **specified module** Button on the Launcher.



The MC-Configurator Dialog Box will be displayed.



4. Click the **OK** Button.  
Self configuration will be executed only for the new devices that are detected by MECHATROLINK communications.

## Definition Information Updated by Self Configuration

The definition information that is updated by self configuration is described below.



Note

This procedure will not update any of the definitions that were made for existing devices and Function Modules. The definitions before self configuration will be retained.

### ◆ I/O Registers

I/O registers are assigned to the Function Modules (218IFD, SVC32, SVR32, M-EXECUTOR, and CPUIF) in the CPU Unit as shown below.

I/O registers will also be automatically assigned to any Optional Modules mounted on the Base Unit.

Item		Settings after Self Configuration
218IFD		<ul style="list-style-type: none"> <li>• First I/O registers: IW00000 and OW00000</li> <li>• Last I/O registers: IW007FF and OW007FF (input registers: IW00000 to IW007FF, output registers: OW00000 to OW007FF)</li> </ul>
SVC	MECHA-TROLINK	<ul style="list-style-type: none"> <li>• First I/O registers: IW00800 and OW00800</li> <li>• Last I/O registers: IW00BFF and OW00BFF (input registers: IW00800 to IW00BFF, output registers: OW00800 to OW00BFF)</li> </ul>
	Motion parameters	<ul style="list-style-type: none"> <li>• First motion registers: IW08000 and OW08000</li> <li>• Last motion registers: IW087FF and OW087FF (input registers: IW08000 to IW087FF, output registers: OW08000 to OW087FF)</li> </ul>
SVR	Motion parameters	<ul style="list-style-type: none"> <li>• First motion registers: IW08800 and OW08800</li> <li>• Last motion registers: IW08FFF and OW08FFF (input registers: IW08800 to IW08FFF, output registers: OW08800 to OW08FFF)</li> </ul>
M-EXECUTOR		<ul style="list-style-type: none"> <li>• First I/O registers: IW00C00 and OW00C00</li> <li>• Last I/O registers: IW00C3F and OW00C3F (input registers: IW00C00 to IW00C3F, output registers: OW00C00 to OW00C3F)</li> </ul>
CPUIF (Assigned only when Sub CPU synchronization is used.)	For high-speed scan	<ul style="list-style-type: none"> <li>• First motion registers: IW20000 and OW20000</li> <li>• Last motion registers: IW207FF and OW207FF (input registers: IW20000 to IW207FF, output registers: OW20000 to OW207FF)</li> </ul>
	For low-speed scan	<p>No registers are assigned.</p> <p>If you need to use low-speed scan registers, manually set the register addresses to use with the <b>Start – End Boxes</b> under <b>I/O Registers</b> on the Module Configuration Definition Tab Page.</p>

### ◆ 218IFD Definition

Item	Settings after Self Configuration
Local IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway IP Address	0.0.0.0
Module Name Definition	CONTROLLER NAME
Engineering Port	9999 (UDP)
MEMOBUS Response Time	0 s
Count of Retry	0

Note: Self configuration sets up the 218IFD for an engineering communications connection with the MPE720.

If you want to use MEMOBUS message communications, manually set up automatic reception or I/O message communications, or use MSG-SNDE and MSG-RCVE functions.



## ◆ MECHATROLINK Communications Definition

### ■ When Set as the Master

Item	Settings after Self Configuration
Master/Slave	Master
My station address	0×0001
Communication Cycle	250 μs
Message Communications	Enabled
Number of Retry to Slaves	1
Number of connection	8
Slave synchronous function	Disabled

### ■ When Set as a Slave

Item	Settings after Self Configuration
Master/Slave	Slave
My station address	0×0003
Communication Cycle	–
Message Communications	Disabled
Number of Retry to Slaves	–
Number of connection	1
Slave synchronous function	Disabled

**Information** To use the Module as a slave, set the parameter settings in the MECHATROLINK communications definition to **Slave** before performing self configuration in the MPE720.

## ◆ SVC Definition

Refer to the following manual for details.

📖 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

## ◆ SVR Definition

Item	Settings after Self Configuration
Defined Axes	32 axes (unused axes)

## ◆ M-EXECUTOR Definition

Item	Settings after Self Configuration
Program Definition Number	8
Program Assignments	Not supported.
Control Register Assignments	Not supported.

## ◆ CPUIF Definition (Only when Sub CPU synchronization is used.)

Item	Settings after Self Configuration
For high-speed scan	Input registers: 64 words Output registers: 64 words
For low-speed scan	No registers are assigned.

## Communications Function Module (218IFD)

This Function Module is used for communications with a host device.

The following table describes the communication features.

Function Module	Features	Remarks
Ethernet	The MP3000 Controller supports multiple protocols to enable general-purpose Ethernet communications with PLCs and touch panels from various manufacturers without writing special applications.	<ul style="list-style-type: none"> <li>Supported Protocols MODBUS/TCP, OMRON, MELSEC A-compatible 1E/QnA-compatible 3E, Extended MEMOBUS, MEMOBUS, and TOYOPUC</li> </ul>

### Setting Method

Settings are made on the 218IFD Dialog Box after connecting the MP3000-series Controller to the host device. Use the following procedure to display the 218IFD Dialog Box. Refer to the following manual for details on settings.

📖 *MP3000 Series Communications User's Manual* (Manual No.: SIEP C880725 12)

1. Connect the Machine Controller to the PC, and start the MPE720.


Refer to the following manual for details.

📖 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)


2. Execute self configuration as required.

📖 *Operating Procedures* (page 3-39)


3. Click the **Module Configuration** Icon on the Start Tab Page.



The following Module Configuration Definition Tab Page will be displayed.



#### 4. Double-click the 218IFD cell.



The 218IFD Detail Definition Dialog Box will be displayed.

Refer to the following manual for details on settings.

*MP3000 Series Communications User's Manual* (Manual No.: SIEP C880725 12)

## Motion Control Function Modules (SVC32 and SVR32)

The Motion Control Function Module is used for communications with a MECHATROLINK communications device.

There are two Motion Control Function Modules, the SVC32 and SVR32. Both Modules can provide the following forms of motion control.

- Position control
- Synchronized phase control
- Torque control\*
- Speed control\*


\* The SVR32 contains some parameters that you cannot set or monitor.

**Information** Motion fixed and setting parameters must be set to use these controls.

The features of the SVC32 and SVR32 are described below.

Function Module	Features
SVC32	Controls MECHATROLINK-III-compatible interface devices, such as Servo Drives and I/O Modules.
SVR32	Provides an interface for virtual axes. This allows you to test programs and create references without connecting to physical motors.

Refer to the following manual for details.


 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

## Setting Method

Settings are made in the locations given below after the MP3000-series Controller is connected to the MECHATROLINK device.


- MECHATROLINK Dialog Box
- SVC Definition Tab Page

Use the following procedure to display the tab pages and dialog boxes. Refer to the following manual for details on settings.


 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

1. Connect the Machine Controller to the PC, and start the MPE720.


Refer to the following manual for details.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

2. Execute self configuration as required.


 *Operating Procedures* (page 3-39)

3. Click the **Module Configuration** Icon on the Start Tab Page.




The following Module Configuration Definition Tab Page will be displayed.

Module	Function Module/Slave	Status	Circuit No./Axis Address		Motion Register	Register (Input/Output)				
			Start	dupied circ.		Disabled	Start - End	Size	Scan	
01 CPU-201 : ---	--- UNDEFINED ---									
PSA-12										
01 CPU	Driving									
02 218FD	Driving		Circuit No1	1		Input	0000 - 07FF[H]	2048		
00 CPU201 [Driving]										
00 SVC32	Driving		Circuit No1	2	8000 - 0FFF[H]	Input	0800 - 0BFF[H]	1024		
04 SVR32	Driving		Circuit No3	2	9000 - 9FFF[H]	Output				
05 M-EXECUTOR	Driving									
06 --- UNDEFINED ---										
01 --- UNDEFINED ---										
02 --- UNDEFINED ---										
03 --- UNDEFINED ---										

4. Double-click the **SVC32** cell in the Module Configuration Definition Tab Page.

The MECHATROLINK Communications Definition Dialog Box is displayed.

**Information** If more than one Module is mounted, select the Module to be checked or set.




## 5. Set the MECHATROLINK communications definitions as required.

Refer to the following manual for details on settings.


*MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

6. Click the **Close** Button on the MECHATROLINK Communications Definition Dialog Box.


7. Select **View – Work Space** from the menu bar.



The Work Space Pane is displayed on the left side of the MC-Configurator Window.




8. Click the **Expand [+]** Button beside each program in the Work Space Pane to display motion parameters as shown below.




9. Double-click the motion parameter to set or monitor.

The Axis Display Selection Dialog Box (“Display in axis selected”) will be displayed.



10. Select the axis to set or monitor, and then click the **OK** Button.



The SVC Definition Tab Page for the selected motion parameters will be displayed.

**Information** To change which motion parameters are displayed, double-click the required motion parameters in the Work Space Pane.

The following examples show the SVC Definition Tab Page for each group of motion parameters.

- Fixed Parameters Tab Page

Module Configuration : [CPU-201]		Fixed Parameter : [CPU-201] - [Servo] ×	
		Circuit#01 Axis#01 SGDV-****21A Axis0101	
0	Selection of operation modes	0	Normal operation mode
1	Function selection flag 1	0000	[H]
2	Function selection flag 2	0000	[H]
4	Reference unit selection	0	pulse
5	Number of digits below decimal point	3	0.123
6	Travel distance per machine rotation	10000	[pulse]
8	Servo motor gear ratio	1	[rev]
9	Machine gear ratio	1	[rev]
10	Infinite length axis reset position(P...	360000	[pulse]
12	Positive software limit value	2147483647	[pulse]
14	Negative software limit value	-2147483648	[pulse]
30	Encoder selection	0	Incremental encoder
34	Rated motor speed	3000	[min <sup>-1</sup> ]
36	Number of pulses per motor rotation	65536	: 16Bit [pulse/rev]
38	Maximum number of absolute encod...	65534	[rev]
42	Feedback speed movement averagi...	10	[ms]
44	User Select Servo Driver User Con...	0000	[H]
45	User Select Servo Driver User Con...	1	[word]



• Setting/Monitor Parameters Tab Page

• Servo/Servo Monitor Parameters Tab Page

11. Set the SVC definitions as required.

Refer to the following manual for details on settings.

MP3000 Series Motion Control User's Manual (Manual No.: SIEP C880725 11)

## The M-EXECUTOR

This section describes the functionality of the M-EXECUTOR Motion Executor and the contents of its various displays.



Terms

The M-EXECUTOR is a software module that executes motion and sequence programs.

### Introduction

The M-EXECUTOR provides the following merits:

- Motion programs can be executed without using a ladder program.  
Motion programs can be executed without placing MSEE instructions in the ladder programs.


**Information** It is still possible to use MSEE instructions in the ladder programs.

- Motion programs can be controlled without using the ladder programs.  
Motion programs can be controlled directly from a host PLC.
- Sequence control can be written in motion language.  
A sequence program can be used in place of a ladder program.  
Refer to the following manuals for instructions that can be used in sequence programs.

*MP3000 Series Motion Programming Manual* (Manual No.: SIEP C880725 14)

**Information** The execution of a sequence program is completed in one scan.  
Sequence programs are written using the same text-based language as motion programs.


### Using the M-EXECUTOR




## Initializing the M-EXECUTOR

Use the following procedure to initialize the M-EXECUTOR.


1. Click the **Module Configuration** Icon on the Start Tab Page.




The Module Configuration Definition Tab Page will be displayed.



2. Double-click the **M-EXECUTOR** cell.




The M-EXECUTOR Definition Dialog Box will be displayed.



3. Click the **OK** Button.

The Detail Definition Dialog Box will be displayed.



4. Select **File – Save** from the toolbar.

The M-EXECUTOR definitions will be saved.

## M-EXECUTOR Detail Settings


The detailed settings for the M-EXECUTOR are performed on the Module Configuration Tab Page and the Detail Definition Dialog Box.

This section provides the procedures to display this tab page and dialog box, and describes their contents.


### ◆ Module Configuration Definition Tab Page

Use the following procedure to display the Module Configuration Definition Tab Page.

- Click the **Module Configuration** Icon on the Start Tab Page.



The following table describes the M-EXECUTOR items that are displayed on the Module Configuration Definition Tab Page.

No.	Item	Display/Setting Item	Editing	
①	Function Module/Slave	Displays whether the M-EXECUTOR is enabled. • UNDEFINED: Disabled • M-EXECUTOR: Enabled	Possible	
②	Status	Displays the status of the M-EXECUTOR.	Possible	
③	Circuit No./Axis Address	Start	Not used. “----” is always displayed.	Not possible
		Occupied circuits		
④	Motion Register	Not used. “----” is always displayed.	Not possible	
⑤	Register (Input/ Output)	Disabled	Not used. “----” is always displayed.	Not possible
⑥		Start- End	Displays the range of registers that is used as the I/O area. • Setting range: 00000 to 07FFF hex or 10000 to 17FFF hex Refer to the following section for details.  ◆ <i>Details on the I/O Registers (page 3-62)</i>	Possible
⑦		Size	The size of the I/O area is displayed in words. • Setting range: 64 to 128 Four words each of input registers and output registers are required to register a single motion program or sequence program in the M-EXECUTOR. If you need to register more than 16 programs, set the size with four additional words for each program to add. A maximum of 32 programs can be registered (maximum number of program definitions).	Possible
⑧		Scan	Not used. “----” is always displayed.	Not possible
⑨	Comment	Display the user comment. Enter a comment of up to 16 characters.	Possible	

### ◆ Details on the I/O Registers

The I/O registers that are assigned to the M-EXECUTOR are used to execute motion and sequence programs, as well as to monitor sequence programs.


The following tables give the contents of the M-EXECUTOR I/O registers.

M-EXECUTOR Input Registers			M-EXECUTOR Output Registers		
M-EXECUTOR Input Register	Item		M-EXECUTOR Output Register	Item	
IW□□□□ + 0	Definition No. 1	Status	OW□□□□ + 0	Definition No. 1	Program Number
IW□□□□ + 1		Reserved.	OW□□□□ + 1		Control Signals
IW□□□□ + 2		Reserved.	OW□□□□ + 2		Override
IW□□□□ + 3		Reserved.	OW□□□□ + 3		Reserved.
IW□□□□ + 4	Definition No. 2	Status	OW□□□□ + 4	Definition No. 2	Program Number
IW□□□□ + 5		Reserved.	OW□□□□ + 5		Control Signals
IW□□□□ + 6		Reserved.	OW□□□□ + 6		Override
IW□□□□ + 7		Reserved.	OW□□□□ + 7		Reserved.
⋮	⋮	⋮	⋮	⋮	⋮
IW□□□□ + 3C	Definition No. 16	Status	OW□□□□ + 3C	Definition No. 16	Program Number
IW□□□□ + 3D		Reserved.	OW□□□□ + 3D		Control Signals
IW□□□□ + 3E		Reserved.	OW□□□□ + 3E		Override
IW□□□□ + 3F		Reserved.	OW□□□□ + 3F		Reserved.
IW□□□□ + 40	Definition No. 17	Status	OW□□□□ + 40	Definition No. 17	Program Number
IW□□□□ + 41		Reserved.	OW□□□□ + 41		Control Signals
IW□□□□ + 42		Reserved.	OW□□□□ + 42		Override
IW□□□□ + 43		Reserved.	OW□□□□ + 43		Reserved.
⋮	⋮	⋮	⋮	⋮	⋮
IW□□□□ + 7C	Definition No. 32	Status	OW□□□□ + 7C	Definition No. 32	Program Number
IW□□□□ + 7D		Reserved.	OW□□□□ + 7D		Control Signals
IW□□□□ + 7E		Reserved.	OW□□□□ + 7E		Override
IW□□□□ + 7F		Reserved.	OW□□□□ + 7F		Reserved.

### ◆ Detail Definition Dialog Box

The Detail Definition Dialog Box has two tab pages, the Program Definition Tab Page and the Allocation Control Register Tab Page.

Use the following procedure to display the Detail Definition Dialog Box.


1. Click the **Module Configuration** Icon on the Start Tab Page.
2. Double-click the  Button in row 05 of the **Function Module/Slave** Column.



## ■ Program Definition Tab Page

Register the motion or sequence programs to execute.

This section describes the items that are displayed on the Program Definition Tab Page.



### ① Individual Display Button

Click this button to display the Program Execution Registration Dialog Box.

### ② Program Definition Number

Set the number of program definitions that can be registered in the M-EXECUTOR.

- Setting range: 0 to 32
- Default value: 8

### ③ No.

The execution order of the programs is displayed. Programs are executed in the scans in ascending order of their numbers.

### ④ D

Enable or disable the definitions.

- Not selected: Definition is enabled.
- Selected: Definition is disabled.

### ⑤ Execution Type

Set the execution type of the program.

Execution Type	Executed Programs	Execution Condition
-----	Not supported.	—
Startup sequence program	Sequence programs	Startup (These programs are executed once when the power supply is turned ON.)
L-scan sequence program		Started at a fixed interval. (These programs are executed once every low-speed scan cycle.)
H-scan sequence program		Started at a fixed interval. (These programs are executed once every high-speed scan cycle.)
Motion program	Motion programs	Request for Start of Program Operation control signal (The program is executed when the Request for Start of Program Operation is turned ON.)

## ⑥ Setting

Set the program designation method.

The designation method can be different for each program.

Designation Method	Motion Programs	Sequence Programs	Description
Direct designation	Possible	Possible	The program is specified with the program number. Examples: MPM001 or SPM002
Indirect designation	Possible	Not possible	The program is specified by specifying a register that contains the program number. Example: OW0C0C (If 1 is stored in OW0C0C, MPM001 will be called.)



## ⑦ Program

Set the program number.

Execution Type	Description
Sequence programs (Startup, L-scan, or H-scan)	If you enter <i>I</i> and press the <b>Enter</b> Key, SPM001 will be set automatically. You can specify a program that is not registered or leave the program number empty. In either case, no program will be executed.
Motion programs	Direct designation: If you enter <i>I</i> and press the <b>Enter</b> Key, MPM001 will be set automatically. You can specify a program that is not registered or leave the program number empty. In either case, no program will be executed.  Indirect designation: The O register of the M-EXECUTOR Module will be set automatically. Only the system can set this.

## ⑧ Execution Monitor Registers (S Registers)


If the execution type is set to a motion program, the range of the execution monitor registers (S registers) will be displayed. Refer to the following section for details on the execution monitor registers.

 4.3 CPU Unit Specifications –  Motion Program Execution Information (page 4-32)

## ■ Allocation Control Register Tab Page

This tab page is used to assign registers.

This section describes the items that are displayed on the Allocation Control Register Tab Page.



### ① M-EXECUTOR Control Registers

This column displays the I/O registers that are assigned to the M-EXECUTOR.

The M-EXECUTOR control registers are used to control or monitor the motion programs.

M-EXECUTOR Control Register	Application
Program Number	Sets the program number. This register is only used for indirect designation.
Status	Monitors the program execution status.
Control Signals	Controls the program.
Override	Sets the override value to use when executing interpolation motion instructions.

### ② Allocation Disable

Use these check boxes to enable or disable the assigned registers.

- Not selected: Definition is enabled.
- Selected: Definition is disabled.

### ③ Direction

This column displays the data I/O directions.

### ④ Allocation Register

Data is copied between the assigned registers and the M-EXECUTOR control registers according to the arrow in the **Direction** Column (③). You can assign any registers.

**Information** You can set word-type I, O, or M registers (except motion registers) in the **Allocation register** Column.

### ⑤ Allocation Contact Interlock

This contact controls copying data between the assigned registers and the M-EXECUTOR control registers. When the assigned interlock contact is ON, the data in the assigned registers and the M-EXECUTOR control registers is copied in the direction that is given by the arrow in the **Direction** Column (③).

Any register bit number can be assigned as the interlock contact.

**Information** You can set bit-type I, O, S, M, or C registers (except motion registers) in the **Allocation Contact interlock** Column.



Note

The assigned interlock contact is used to interlock motion program operation. If you assign a register, always assign an assigned interlock contact.

### ⑥ Status and Control Signal Details

Double-click the **Status** or the **Control signal** cell to display the Detail Dialog Box.

This dialog box is used to verify the status and the control signals.

- Status

Detail			
Program execution registration No.1			
Control signal		Status	
	M-Executor Control register	Allocation register	Status
Program is running	IB00C000	OB000000	○ : ON ● : OFF
Program is pausing	IB00C001	OB000001	○ : ON ● : OFF
Program stopped with program stop	IB00C002	OB000002	○ : ON ● : OFF
Program stopped under single block	IB00C004	OB000004	○ : ON ● : OFF
Program alarm has been generated	IB00C008	OB000008	○ : ON ● : OFF
Stopped at break point	IB00C009	OB000009	○ : ON ● : OFF
Debugging mode(EWS debugging)	IB00C00B	OB00000B	○ : ON ● : OFF
Start request signal history	IB00C00D	OB00000D	● : ON ○ : OFF
"No system work" error	IB00C00E	OB00000E	○ : ON ● : OFF
Main program number limit error	IB00C00F	OB00000F	○ : ON ● : OFF

OK

- Control Signals

Detail			
Program execution registration No.1			
Control signal		Status	
	M-Executor Control register	Allocation register	Status
Program start request	OB00C010	IB000010	○ : ON ● : OFF
Program pause request	OB00C011	IB000011	○ : ON ● : OFF
Program stop request	OB00C012	IB000012	○ : ON ● : OFF
Program single block mode selection	OB00C013	IB000013	○ : ON ● : OFF
Program single block start request	OB00C014	IB000014	○ : ON ● : OFF
Alarm reset request	OB00C015	IB000015	○ : ON ● : OFF
Program continuous operation start	OB00C016	IB000016	○ : ON ● : OFF
Skip1 information	OB00C018	IB000018	○ : ON ● : OFF
Skip2 information	OB00C019	IB000019	○ : ON ● : OFF
System work number setting	OB00C01D	IB00001D	○ : ON ● : OFF
Interpolation override setting	OB00C01E	IB00001E	○ : ON ● : OFF

OK


## Creating Motion Programs

Refer to the following manual for details.


*MP3000 Series Motion Programming Manual* (Manual No.: SIEP C880725 14)

## Registering Program Execution


This section gives the procedure to register the execution of programs.

1. Display the program to register for execution.
2. Click the **Task Allocation** (  ) icon.

The Task Allocation Dialog Box will be displayed.




**Information** You can also use the Task Allocation Dialog Box to change the settings. Refer to the following manual for details.

 *MP3000 Series Motion Programming Manual* (Manual No.: SIEP C880725 14)

3. Check that the settings match the contents of the Allocation Control Register Tab Page, and then click the **Set** Button.

The registered contents will be saved.




Refer to the following section for details on the Allocation Control Register Tab Page.

 **Allocation Control Register Tab Page** (page 3-65)

## Execution Scheduling

Programs that are registered in the M-EXECUTOR are executed in the order of their priority levels (execution types).

Programs that are registered in the M-EXECUTOR are executed immediately before processing the ladder programs.




The following is an execution example.

- M-EXECUTOR Program Execution Definitions

Example

Sequence Program Execution Example


The following figure shows an example of the sequence programs registered in the M-EXECUTOR.



■ Execution Timing

This section describes the execution timing of programs in the above example.

The following figure shows program and drawing execution that is based on the order of registration in the M-EXECUTOR program definitions.



## Data Logging

Data logging saves the values of specified registers in a log file according to the preset trigger timing and conditions.

The data is stored in the RAM in the CPU Unit or on the USB memory device.


Data Storage Location	Merits	Demerits
RAM in CPU Unit	The file writing speed is fast and the overhead that is placed on the scan is low.	<ul style="list-style-type: none"> <li>Data is lost when the power supply to the CPU Unit is turned OFF.</li> <li>Storage capacity is limited to 8 MB.</li> </ul>
USB memory	<ul style="list-style-type: none"> <li>Data can be stored for a long time.</li> <li>Logged data can be viewed easily by inserting the USB memory device into a PC.</li> </ul>	The file writing speed is slow and the overhead that is placed on the scan is high.

## Operating Procedure

This section describes how to perform data logging.

1. Connect the Machine Controller to the PC, and start the MPE720.


Refer to the following manual for details.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

2. Select **View – System** from the menu bar.


The System Pane will be displayed on the left side of the window.

3. Click the **Expand [+]** Button next to the **Logging** item to display the log files in the System Pane and double-click **Logging1**.






The Logging 1 Dialog Box will be displayed.



4. Click the **Format** Button.  
The Format Dialog Box will be displayed.
5. Set the format.



## ① Select the storage location.


Setting	Description
In the built-in RAM disk	Writes the sampled data to the built-in RAM disk in the CPU Unit.
USB memory	Writes the sampled data to the USB memory device in the CPU Unit.

## ② Select the file format.

Setting	Description
CSV	This file format can be opened in general-purpose applications such as Excel and Notepad.
Binary	This file format is not affected by the range of character codes. Binary files are smaller than CSV files, so they can be written faster and with less overhead on the scan.

## ③ Select the file information to output.

The selected items are appended to the header information in the output file.

Setting	Description
Data No.	The number that is assigned to the sampled data
DATE/TIME	The date and time down to the seconds when the data was sampled Make sure to set the calendar in advance. Refer to the following section for details.  <i>Calendar (page 3-93)</i>
Registered register name	Name of the register
Programs	Program name
Sampling period	The frequency at which data was sampled Set this in the Sampling and Trigger Dialog Box that is explained later in this section.

## ④ Enter the number of data items to output.

Enter the number of lines to write to a single file.

- Setting range: 1 to 32,767

## ⑤ Set the file name.

- Characters allowed: Alphabet A to Z and a to z, numerals 0 to 9, the minus sign, and the underscore.
- Maximum string length: 32 characters

**Information**

1. A five-digit index number that starts from 00001 is automatically added to the end of the specified file name.
2. Click the **Default** Button to enter “logging”.

## ⑥ Set the name of the folder to create.

- Characters allowed: Alphabet A to Z and a to z, numerals 0 to 9, the minus sign, and the underscore.
- Maximum string length: 32 characters\*

\* If you select **Year/Month/Day/Hour (YYYYMMDDHH)** in step ②, the maximum string length will be 31.

**Information**

If this box is left blank, a folder will not be created. Instead, the file will be created in the root directory of the specified storage location.

② Select whether to add date information to the folder name.

- To omit date information, clear the selection of the check box.
- To add date information, select the check box and select the date format from the list.

Setting	Description
Year (YYYY)	Adds the year to the specified folder name. Example: □□□2011
Year/Month (YYYYMM)	Adds the year and month to the specified folder name. Example: □□□201109
Year/Month/Day (YYYYMMDD)	Adds the year, month, and day to the specified folder name. Example: □□□20110920
Year/Month/Day/Hour (YYYYMMDDHH)	Adds the year, month, and day to the specified folder name and creates another folder directly below it named with the hour. Example: □□□20110920 └─ 12 The sampled data is stored in this folder.

**Information**

Click the **Cancel** Button to return to the Logging 1 Dialog Box without registering the settings.


6. Click the **OK** Button.

The Format Dialog Box closes.

7. Click the **File output** Button in the Logging 1 Dialog Box.

The File Output Dialog Box will be displayed.

8. Set the file output settings.



① Set the number of output files.\*1

- Settings: No restriction\*2, 1, 10, 50, 100, 500, or 1,000

\*1. This is the total number of files that are created from when the power supply is turned ON to when it is turned OFF.

\*2. If the built-in RAM disk is the storage location, the upper limit is 4,000 files.

If the USB memory device is the storage location, the upper limit is 10,000 files.

②Set the file overwrite settings.

Setting	Description
Overwrite	When the file number reaches the upper limit on the specified number of output files, older files will be deleted to allow the creation of new files.
Stop logging	When the file number reaches the upper limit of the specified number of output files, logging will stop.

**Information** Click the **Cancel** Button to return to the Logging 1 Dialog Box without registering the settings.


9. Click the **OK** Button.

The File Output Dialog Box closes.

10. Click the **Logging target** Button in the Logging 1 Dialog Box.

The Logging Target Dialog Box will be displayed.

11. Add the registers to log.



No.	Item	Description
①	Logging Target List	Displays a list of the registers that can be selected for logging. <ul style="list-style-type: none"> <li>Right-click in the Logging Target List to display the pop-up menu to select or deselect registers.</li> <li><b>Add to Trace</b> adds the selected register to the Trace Target List.</li> <li><b>Clear</b> deselects multiple registers that were selected by using the <b>Shift</b> or the <b>Ctrl</b> Keys.</li> <li><b>Select All</b> selects all registers shown on the tab page.</li> </ul>
②	<b>Add</b> Button	Adds the selected register to the list of registers to be logged.

Continued on next page.

Continued from previous page.

No.	Item	Description
③	<b>Delete</b> Button	Removes the selected registers from the list of registers to be logged.
④	Logging Target	<p>Displays a list of the registers that will be logged. Registers can be added to this list either by selecting them from the Logging Target List or by entering them directly.</p> <ul style="list-style-type: none"> <li>Right-click in the Logging Target Area to display a pop-up menu to edit the registers to be logged.</li> </ul> <p><b>Insert Row</b> inserts a blank row.</p> <p><b>Delete Row</b> deletes a row. If a logging target was added, then it will be deleted.</p>

**Information** The following register types can be logged.

- S, M, G, I, O, and D registers

**Information** Refer to the following table for the data size for each data type.

Data Type	Data Size
B: bit	1 word
W: integer	1 word
L: double-length integer	2 words
Q: quadruple-length integer	4 words
F: single-precision real number	2 words
F: double-precision real number	4 words

**Information** Click the **Cancel** Button to return to the Logging 1 Dialog Box without registering the settings.


**12. Click the **OK** Button.**

The Logging Target Dialog Box closes.

**13. Click the **Sampling and trigger** Button in the Logging 1 Dialog Box.**

The Sampling and Trigger Dialog Box will be displayed.

14. Set the sampling and trigger settings.



- ① Set the logging name.
  - Maximum name length: 32 characters
- ② Set the data sampling rate.

Setting	Description
High-speed scan	Samples data synchronized with the high-speed scan. Data is sampled immediately after completing execution of the DWGH ladder program.
Low-speed scan	Samples data synchronized with the low-speed scan. Data is sampled immediately after completing execution of the DWGL ladder program.

- ③ Set the data sampling period.
  - Specify the value and unit to control whether data is sampled every scan or once in more than one scan. To sample data every scan, specify the same value as the scan set value.

- ④ Specify whether data is to be logged synchronized or asynchronous with the scan.

Setting	Description	Merits	Demerits
Synchronous scanning	Data is written to the log synchronized with the scan	No data is lost.	This creates an overhead on the scan and can cause Watchdog Errors (E.001), or cause the CPU Unit to go down.
Asynchronous Scanning	Data is written to the log asynchronously with the scan.	There is no overhead on the scan.	If the scan setting is set to a fast rate or if the idle time of the scan is low, logging can fall behind or data can be missed if there are too many data points to sample.

Refer to the following section for guidelines on scan settings.

Scan Setting Guidelines (page 3-80)

⑤ to ⑫ Set the logging conditions using items ⑤ to ⑫.


No.	Item	Description														
⑤	Specify the start timing	If the check box is selected, register operation will control when logging starts. If conditions are set in items ⑧ and ⑩, logging will start when these conditions are met. If the check box is cleared, logging will start according to manual operation of the button displayed by the MPE720.														
⑥	Specify the stop timing	If the check box is selected, register operation will control when logging stops. If conditions are set in items ⑨ and ⑩, logging will stop when these conditions are met. If the check box is cleared, logging will stop according to manual operation of the button displayed by the MPE720.														
⑦	Add detailed output conditions of data	<ul style="list-style-type: none"> <li>If no detailed output conditions are specified: Clear the check box.</li> <li>If detailed output conditions are specified: Select the check box and specify the conditions for items ⑩, ⑪, and ⑫. Logging will start when these conditions are met. Even if logging stops when the output conditions are no longer met, it will start when the conditions are met again.</li> </ul>														
⑧	Start condition	Specify any S, M, G, I, or O register, and numeric value. The start condition is when the rising edge is detected (when the register changes from OFF to ON).														
⑨	Stop condition	The stop condition is detected by the state of the register. (If the register is ON, the condition is always detected.)														
⑩	Condition A and Condition B	Specify any S, M, G, I, or O register and numeric value. If a condition is entered for both condition A and condition B, specify the condition at ⑫).														
⑪	Condition	Select one of the following operators. <table border="1" data-bbox="683 1122 1469 1570"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>&gt;</td> <td>Condition is met when the left register value is greater than the right register value.</td> </tr> <tr> <td>&lt;</td> <td>Condition is met when the left register value is less than the right register value.</td> </tr> <tr> <td>=</td> <td>Condition is met when the left register value is equal to the right register value.</td> </tr> <tr> <td>&lt;&gt;</td> <td>Condition is met when the left register value is not equal to the right register value.</td> </tr> <tr> <td>&gt;=</td> <td>Condition is met when the left register value is greater than or equal to the right register value.</td> </tr> <tr> <td>&lt;=</td> <td>Condition is met when the left register value is less than or equal to the right register value.</td> </tr> </tbody> </table>	Setting	Description	>	Condition is met when the left register value is greater than the right register value.	<	Condition is met when the left register value is less than the right register value.	=	Condition is met when the left register value is equal to the right register value.	<>	Condition is met when the left register value is not equal to the right register value.	>=	Condition is met when the left register value is greater than or equal to the right register value.	<=	Condition is met when the left register value is less than or equal to the right register value.
Setting	Description															
>	Condition is met when the left register value is greater than the right register value.															
<	Condition is met when the left register value is less than the right register value.															
=	Condition is met when the left register value is equal to the right register value.															
<>	Condition is met when the left register value is not equal to the right register value.															
>=	Condition is met when the left register value is greater than or equal to the right register value.															
<=	Condition is met when the left register value is less than or equal to the right register value.															
⑫	Compound condition	If a condition is entered for both condition A and condition B, specify one of the following conditions. <table border="1" data-bbox="683 1693 1469 1939"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>No compound condition</td> <td>The compound condition is met when Condition A is met. Condition B will be ignored, even if it is specified.</td> </tr> <tr> <td>AND</td> <td>The compound condition is met when both condition A and condition B are met.</td> </tr> <tr> <td>OR</td> <td>The compound condition is met when either condition A or condition B is met.</td> </tr> </tbody> </table>	Setting	Description	No compound condition	The compound condition is met when Condition A is met. Condition B will be ignored, even if it is specified.	AND	The compound condition is met when both condition A and condition B are met.	OR	The compound condition is met when either condition A or condition B is met.						
Setting	Description															
No compound condition	The compound condition is met when Condition A is met. Condition B will be ignored, even if it is specified.															
AND	The compound condition is met when both condition A and condition B are met.															
OR	The compound condition is met when either condition A or condition B is met.															

**Example** To automatically start logging when the power supply is turned ON, set the Start Trigger to the following condition.

- When the saving destination is set to USB memory:  
Setting example: Start trigger SB006540 = ON  
Note: The SB006540 register turns ON when a USB memory device is detected.
- When the saving destination is set to built-in RAM disk:  
Setting example: Start trigger SB000001 or SB000003 = ON  
Note: The SB000001 register turns ON during the first scan of the high-speed scan.  
The SB000003 register turns ON during the first scan of the low-speed scan.

**Example** In the following example, the output conditions are set to log only the data in the shaded region.

Setting example: Condition A  $\geq$  Upper limit, Condition B  $\leq$  Lower limit, Compound condition = OR



**Information** Click the **Cancel** Button to return to the Logging 1 Dialog Box without registering the settings.

**15. Click the OK Button.**


The Sampling and Trigger Dialog Box closed.



**16.** Click the **Start** Button in the Logging 1 Dialog Box.

Logging starts. While logging is in progress, the following items are displayed in the Logging 1 Dialog Box.

- File update counter
- Latest record number
- Latest folder name
- Latest file name

**17.** Click the **Stop** Button in the Logging 1 Dialog Box.

Logging will stop.

The following table gives the range of each data and the timing at which logging is reset.

Data Name	Range		Reset Timing
File Name	When the saving destination is set to USB memory	logging00001 to logging10000	The file name resets to logging00001 when the power supply is turned ON. If a file already exists in memory, it will be overwritten.
	When the saving destination is set to built-in RAM disk	logging00001 to logging4000	
Latest record number	0 to 18,446,744,073,709,551,615		The latest record number is reset to 0 when logging starts after a stop.

## Scan Setting Guidelines

This section describes guidelines for the scan settings based on when data is logged.


### ◆ If Logging Is Synchronous with the Scan

The general logging overhead is given below. Set the scan setting to a value that is larger than this value.

Data Items		1 to 8	9 to 60	61 to 64
Storage Location	In the built-in RAM disk	1.0 ms	1.5 ms	2.0 ms
	USB memory	Due to the large overhead, USB memory cannot be used to log synchronously with the scan.		

Note: These overhead values are for word data without an application. Set the scan setting according to the application usage conditions (number of registers to log, register types, ladder programs, etc.).

This timing chart illustrates the logging process when performed synchronously with the scan.



The logging processes for sampling the data and writing it to a file are performed within the scan cycle. Therefore, the scan cycle (time period A in the figure on the previous page), must be set to a value greater than the current scan time (time period B in the figure on the previous page).

If the scan cycle is shorter than the current scan time, a Scan Time Over Limit error will occur and the count of SW00044 (High-speed Scan Over Limit Counter) or SW00046 (Low-speed Scan Over Limit Counter) will be incremented. This can also cause a Watchdog Error (E.001) or cause the CPU Unit to go down.

Set the scan time so that it is long enough to log the number of registered data items.


### ◆ If Logging Is Asynchronous with the Scan

The scan setting for logging asynchronously with the scan should be set as given below.

Storage Location	Scan Setting Guidelines
In the built-in RAM disk	0.250 ms or longer
USB memory	0.500 ms or longer

Note: These values are for word data without an application. Set the scan setting according to the application usage conditions (number of registers to log, register types, ladder programs, etc.).

This timing chart illustrates the logging process when performed asynchronously with the scan.



The logging process for sampling the data is performed within the scan, while the process of writing the data to a file is performed in background processing.

The background process is performed during the idle processing time of the scan. Therefore, the idle processing time (time period A in the above figure) must be longer than the logging overhead (time period B in the above figure).

If the logging overhead time is longer than the idle processing time of the scan, the file writing process can run into the next scan and cause an over limit error. The number of over limit errors can be checked in the over limit counter (SW24008).

## Monitoring the Logging Execution Status

You can monitor the execution status of data logging by checking the system registers. Refer to the following section for details.

📖 4.3 CPU Unit Specifications – ◆ Data Logging Execution Status (page 4-69)

## Viewing the Log Data

To view the log data in a PC, the data that is stored in the RAM in the CPU Unit or USB memory device must be transferred to the PC. Refer to the following section for details on data transfers.

📖 File Transfer (page 3-89)

## Analyzing Log Data

This section describes how the log data is formatted when viewed on a PC.

### ◆ CSV File Format


This example shows how log data that is stored in the CSV format appears when it is opened in Microsoft Excel.

①	[HeaderSize]	137	byte				
②	[ScanType]	H-Scan					
③	[ScanTime]	4	ms				
④	[Register]			MW0000	MW0001	GW0000	GW0002
⑤	[ProgramName]						
⑥		No.	DATE/TIME				
⑦		0	2011/06/23 18:02_19s	15544	0	49992	15544
		1	2011/06/23 18:02_19s	15545	0	49991	15545
		2	2011/06/23 18:02_19s	15546	0	49990	15546
		3	2011/06/23 18:02_19s	15547	0	49989	15547
		4	2011/06/23 18:02_19s	15548	0	49988	15548
		5	2011/06/23 18:02_19s	15549	0	49987	15549
		6	2011/06/23 18:02_19s	15550	0	49986	15550
		7	2011/06/23 18:02_19s	15551	0	49985	15551

#### • Header Details

No.	Item	Description	Corresponding Item in MPE720
①	HeaderSize	Gives the size of the header that is appended to the file.	–
②*	ScanType	The type of scan where the data was obtained (high-speed scan or low-speed scan) is displayed.	<b>Sampling period</b> on the Format Dialog Box.
③*	ScanTime	Gives the data sampling period.	
④*	Register	Gives the registers specified in the data settings.	<b>Registered register name</b> on the Format Dialog Box.
⑤*	ProgramName	Gives the program name specified in the data settings.	<b>Program</b> on the Format Dialog Box.
⑥*	No.	Gives the number of the data that was sampled.	<b>Data No.</b> on the Format Dialog Box.
⑦*	DATE/TIME	Gives the time down to the seconds when the data was sampled. This is a running value from 1970, which is the lower limit of the calendar setting.	<b>DATE/TIME</b> on the Format Dialog Box.

\*These items may not be given depending on the settings in the MPE720. Refer to the following section for details.

 *Operating Procedure (page 3-70)*

## ◆ Binary File Format

This example shows how log data that was stored in the binary format appears when it is opened in a text editor.

①

```
[HeaderSize],001
37,byte+[ScanType],H-Scan+[ScanTime],4.000,ms+[Register],,,MW0000,MW0001,GW0000,GW0002,[ProgramName],,,[No.],DATE/TIME,
```

②

```
G # G 慮
```

③

```
G 糖 G
# !G °外
G #
"G °クG
# #G ンク#
G #
$G ワク$G
# %G ロク%
G #
&G レク&G
# 'G ルク'
```

### ①Header

The header is given in ASCII characters.

Item	Description	Corresponding Item in MPE720
HeaderSize	Gives the size of the header that is appended to the file.	-
ScanType*	The type of scan where the data was obtained (high-speed scan or low-speed scan) is displayed.	<b>Sampling period</b> on the Format Dialog Box.
ScanTime*	Gives the data sampling period.	
Register*	Gives the registers specified in the data settings.	<b>Registered register name</b> on the Format Dialog Box.
ProgramName*	Gives the program name specified in the data settings.	<b>Program</b> on the Format Dialog Box.
No.*	Gives the number of the data that was sampled.	<b>Data No.</b> on the Format Dialog Box.
DATE/TIME*	Gives the time down to the seconds when the data was sampled. This is a running value from 1970, which is the lower limit of the calendar setting.	<b>DATE/TIME</b> on the Format Dialog Box.

\* These items may not be given depending on the settings in the MPE720. Refer to the following section for details.

*Operating Procedure (page 3-70)*

### ②Bit Pattern of Header Information

### ③Register Data

The register data is displayed here. The volume of data depends on the data types of the registers.

Data Type	Data Size
B: bit	2 bytes
W: integer	2 bytes
L: double-length integer	4 bytes
Q: quadruple-length integer	8 bytes
F: single-precision real number	4 bytes
F: double-precision real number	8 bytes

**Example**

The following example shows how the register data is given for the settings and conditions listed below.

**File Details to Output**

- **Data No.** and **DATE/TIME** are selected

**Target Register to Log**

- MW00000


**Status**

- **Data No.:** 000001
- **DATE/TIME:** 2011/06/23 18:02:19
- Value of MW00000 register: 100

**Actual Data**

The data is stored in little endian as shown below.

01 00 00 00 00 00 00 00 11 00 23 06 02 18 19 00 64 00



## USB Memory

You can transfer user application data between the RAM in the CPU Unit and the USB memory device.

Operation		Description	Reference
USB mem- ory batch transfer	Batch load	Loads all of the user application data that is saved in the USB memory device to the CPU Unit's RAM. The data is also saved to flash memory.	◆ <i>Batch Loading from USB Memory Device (page 3-85)</i>
	Batch save	Saves all of the user application data that is saved in the CPU Unit's RAM to the USB memory device.	◆ <i>Batch Saving to USB Memory (page 3-86)</i>
Data logging		Saves all of the logged data in the CPU Unit to the USB memory device.	<i>File Transfer (page 3-89)</i>
Import/ Export instructions	Batch load	Loads all of the user application data that is saved in the USB memory device to the CPU Unit's RAM from within a ladder program.	<i>MP3000 Series Ladder Programming Manual (Manual No.: SIEP C880725 13)</i>
	Batch save	Saves all of user application data that is saved in the CPU Unit's RAM to the USB memory device from within a ladder program.	

## Operating Procedures

This section describes the procedures for loading all of the data from the USB memory device and saving all of the data to the USB memory device.


### ◆ Batch Loading from USB Memory Device

1. Turn OFF the power supply to the CPU Unit.
2. Insert the USB memory device that contains the application data to be transferred into the USB connector on the CPU Unit.

**Information** Make sure that the folder hierarchy and file naming where the application data is to be stored is as shown below.



3. Turn ON only the LOAD pin on the mode switch 1 on the CPU Unit.



- Set the INIT pin on the mode switch 1 on the CPU Unit according to the register type to load.


Registers to Load	INIT Switch Setting	
	OFF	ON
M registers	Transferred.	Not transferred.
G registers	Not transferred regardless of DIP switch setting.	
S registers		
I registers		
O registers		
C registers	Always transferred regardless of DIP switch setting.	
# registers		
D registers		

- Turn ON the power supply to the CPU Unit.


The batch load operation starts.

**Information**

If the load operation fails, an error code will be displayed on the display on the CPU Unit. Refer to the following manual to troubleshoot the problem, then perform the batch load again.

 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

The progress of processing will be shown on the display during the batch load operation as follows:




- Turn OFF the power supply to the CPU Unit.
- Remove the USB memory device from the USB connector on the CPU Unit.
- Turn OFF the LOAD pin on the mode switch 1 on the CPU Unit.
- Turn ON the power supply to the CPU Unit.

◆ Batch Saving to USB Memory



When a save operation is performed to the USB memory device, any data that is stored on the USB memory device will be overwritten.

- Turn ON the power supply to the CPU Unit.
- Make sure the security password has not been set for the CPU Unit. Otherwise, any attempts to perform a batch save will fail. Refer to the following manual for details on the security password.  
 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)
- Insert the USB memory device that contains the application data to save into the USB connector on the CPU Unit.



4. Set the INIT pin on the mode switch 1 on the CPU Unit according to the register type to save.

Registers to Save	INIT Switch Setting	
	OFF	ON
M registers	Transferred.	Not transferred.
G registers	Transferred.	Not transferred.
S registers	Transferred.	Not transferred.
I registers	Transferred.	Not transferred.
O registers	Transferred.	Not transferred.
C registers	Always transferred regardless of DIP switch setting.	
# registers		
D registers		

5. Press and hold the STOP/SAVE switch on the CPU Unit for at least two seconds.

The batch save operation starts.

**Information** If the save operation fails, an error code will be displayed in the display on the CPU Unit. Refer to the following manual to troubleshoot the problem, then perform the batch save again.  
 📖 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

The progress of processing will be shown on the display during the batch save operation as follows:  
 The batch save operation has been completed when the normal operation display appears on the display (i.e., the lower right dot will flash).



6. Press the STOP/SAVE switch. Confirm that the USB status indicator changes from flashing to not lit and then remove the USB memory.

**Information** The hierarchy of the folders in which the application data was saved will be as shown below. Only the alarm history file will be in CSV format. It is stored with the following name: ALARM\_HISTORY.csv.



## Alarm History File


This section describes the data that is displayed when an alarm history file is checked on a PC.

### ◆ Alarm History File Format

The following example shows how the CSV file is displayed when it is opened in a text editor.

No,	Alarm Code,	Alarm Detail Format,	Date,	Rack,	Unit,	Slot,	Detail1,	Detail2,	Detail3,	Detail4,	Detail5
1,	A101H,	I/O error,	2000/01/01 00:00_40s,	1,	0,	0,	0000H,	0000H,	0000H,	0000H,	0000H
2,	A30BH,	Other error,	2000/01/01 00:00_56s,	1,	0,	0,	0000H,	0000H,	0000H,	0000H,	0000H

↑    ↑    ↑    ↑    ↑    ↑    ↑    ↑    ↑    ↑    ↑  
 ①   ②   ③   ④   ⑤ ⑥ ⑦   ⑧   ⑨   ⑩   ⑪   ⑫

No.	Item	Remarks
①	Index	Range: 1 to 100
②	Alarm Code	Refer to the following manual for details.  <i>MP3000 Series MP3200/MP3300 Troubleshooting Manual</i> (Manual No.: SIEP C880725 01)
③	Alarm Details Format Type	<ul style="list-style-type: none"> <li>• Operation error</li> <li>• I/O error</li> <li>• Other error</li> </ul>
④	Time when alarm occurred	yyyy/mm/dd/ hh:mm_ss
⑤	Alarm Rack Number	–
⑥	Alarm Unit Number	–
⑦	Alarm Slot Number	–
⑧	Alarm Detail 1	Alarm Details ③The information depends on the alarm details format type.
⑨	Alarm Detail 2	<ul style="list-style-type: none"> <li>• Operation Errors</li> </ul> Alarm detail 1: Error drawing number Alarm detail 2: Referenced drawing number
⑩	Alarm Detail 3	Alarm detail 3: Referenced drawing step number Alarm details 4 and 5: Reserved for system.
⑪	Alarm Detail 4	<ul style="list-style-type: none"> <li>• I/O Errors</li> </ul> Alarm details 1 to 5: Reserved for system.
⑫	Alarm Detail 5	<ul style="list-style-type: none"> <li>• Other Errors</li> </ul> Alarm details 1 to 5: Reserved for system.

## File Transfer

The functionality of an FTP server is provided so that you can transfer data between the RAM in the CPU Unit or the USB memory device and a remote device capable of acting as an FTP client.

Data to Transfer	Transfer Direction	Remarks	Reference
Log data	CPU Unit to Remote device	–	<i>Operating Procedure (page 3-70)</i>
Register data	CPU Unit to Remote device	Uses the Export instruction from a ladder program.*	<i>MP3000 Series Ladder Programming Manual (Manual No.: SIEP C880725 13)</i>
	Remote device to CPU Unit	Uses the Import instruction from a ladder program.*	

\* Can be used for the CPU Unit version 1.30 or higher and the MPE720 version 7.39 or higher.



Note


- The full path of the file to be transferred must be within 256 characters including all folder and file names.
- If you transfer too many files at the same time, a 426 error (connection closed; transfer aborted) will occur at the remote device and the files will not be transferred normally. If that occurs, separate the files into more than one transfer and transfer them again.

### Information

1. The FTP server supports up to five simultaneous connections.
2. You can transfer up to 8 MB when using the RAM in the CPU Unit. You can transfer up to 4 GB of data for the recommended USB memory device.
3. The IP address of the FTP server is the same as the IP address that is set on the 218IFD Detail Definition Dialog Box for the Communications Module or the IP address that is set on the rotary switches. Refer to the following manual or section for details.
  - 218IFD Detail Definition Dialog Box
    - 📖 *MP3000 Series Communications User's Manual (Manual No.: SIEP C880725 12)*
  - Rotary switches
    - 📖 *2.2 CPU Unit – Rotary Switches (page 2-10)*

## Folder Structure

This section describes the folder structure of the FTP server.



## Setting Up FTP Accounts

FTP accounts must be set up to allow FTP clients to access the FTP server. This section describes the default settings of an FTP account, and how to change those settings.

## ◆ Default

The default settings of an FTP account are given below.

User Name	Password	FTP Privileges
USER-A	USER-A	R/W*

\* R: Files can be read from the FTP client.

W: Files can be written from the FTP client.

## ◆ Setting Up FTP Accounts

If you need to change the default settings or add a new FTP account, use the MPE720. You can define up to five FTP accounts.

Use the following procedure.


1. Connect the Machine Controller to the PC, and start the MPE720.

Refer to the following manual for details.

 *MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

2. Select **File – Environment Setting** from the menu bar.

3. Select **Security** and then **User Registration**.



### Adding a New FTP Account

Click the **New** Button.

The User Registration Dialog Box will be displayed.

### Changing the Settings of an Existing FTP Account

Select the user name for the FTP account to be changed and click the **Modified** Button.

The User Registration Dialog Box will be displayed.

### Deleting an Existing FTP Account

Select the user name for the FTP account to be deleted and click the **Delete** Button.

The selected FTP account will be deleted. Proceed to step 5.

4. Set the FTP account information in the User Registration Dialog Box.

No.	Item	Description	Remarks
①	User Name	This is the name that the FTP client on the remote device must use to log in to perform a file transfer.	<ul style="list-style-type: none"> <li>You can enter up to 16 characters.</li> <li>The string is case sensitive.</li> </ul>
②	Password	This is the password that the FTP client on the remote device must use to log in to perform a file transfer.	<ul style="list-style-type: none"> <li>You can enter up to 16 characters.</li> <li>The string is case sensitive.</li> </ul>
③	User Privilege	Reserved for system.	Specify 0 for reading and writing.
④	Default Privilege	Reserved for system.	Specify 0 for reading and writing.
⑤	FTP Privilege	This is the file read and write privileges that the FTP client on the remote device will have during file transfers.	<ul style="list-style-type: none"> <li>Refer to the following section for details on the tasks that are affected by the FTP privilege settings. <ul style="list-style-type: none"> <li>■ <i>FTP Privileges and Applicable FTP Commands (page 3-92)</i></li> </ul> </li> <li>A client cannot be set to writing only.</li> </ul>

5. Click the **OK** Button.

6. Log off from the MPE720.

The settings are enabled.

### ■ FTP Privileges and Applicable FTP Commands

Item	Command	FTP Privileges		Description
		R	R/W	
Connection/Disconnection	bye	○	○	Disconnects and terminates the connection with the FTP server.
	close	○	○	Disconnects the connection with the FTP server.
	open	○	○	Starts a connection with the FTP server.
	quit	○	○	Disconnects and terminates the connection with the FTP server.
	user	○	○	Enters the user name when logging in to the FTP server.
File/Directory Operations	cd	○	○	Changes the current directory of the FTP server
	delete	×	○	Deletes a file on the FTP server.
	mdelete	×	○	Deletes multiple files on the FTP server.
	dir	○	○	Displays a list of the files in the current directory of the FTP server, including file names, sizes, and last revision dates.
	ls	○	○	Displays a list of the file names in the current directory of the FTP server.
	mkdir	×	○	Creates a directory in the FTP server.
	pwd	○	○	Displays the current directory of the FTP server.
	rename	×	○	Renames a file on the FTP server.
rmdir	×	○	Deletes a directory in the FTP server.	
File Transfers	get	○	○	Downloads a file from the FTP server.
	mget	○	○	Downloads multiple files from the FTP server.
	put	×	○	Uploads a file to the FTP server.
	mput	×	○	Uploads multiple files to the FTP server.

Note: ○: Allowed, ×: Not allowed.

## Accessing the FTP Server


This section describes how to access the FTP server from a Windows PC.

### 1. Enter the address in the address bar.

The address structure is as follows:


ftp://USER-A:USER-A@192.168.1.1

IP address of Controller  
Password  
User name



**2. Press the Enter Key.**

The folder of the FTP server will be displayed. That is, the contents of the USB memory device connected to the CPU Unit is displayed.



## Security

Security can be used to perform the following tasks.

- Set project passwords.
- Set program passwords.
- Set online passwords.

Refer to the following manual for operating details.

*MP2000/MP3000 Series Machine Controller System Setup Manual* (Manual No.: SIEP C880725 00)

## Calendar

The calendar is used to manage dates and times in the CPU Unit. If the calendar has been set, the date and time will be automatically recorded when an alarm occurs.

The calendar is powered by the Battery. This allows it to maintain the correct time even if the power to the CPU Unit is turned OFF. The calendar has an error of 1 minute a month.

The date and time information can be set, changed, and accessed through the system registers. Refer to the following sections for details.

*4.3 CPU Unit Specifications – ♦ System Service Registers – ■ Calendar (page 4-18)*

## 3.3 Multi-CPU Functions

The multi-CPU functions allow you to use more than one CPU Unit to control one system.


When you use more than one CPU Unit (i.e., when you use a multi-CPU function), you can divide the application programming of the Machine Controller. This distributes the application load among the CPU Units and increases the memory capacity.

There are the following two multi-CPU functions. Determine which function to use based on the number of CPU Units in the system, the distance between the Racks, etc.

- Sub CPU synchronization
- Slave CPU synchronization

Here, we describe the differences between Sub CPU synchronization and slave CPU synchronization and provide details on Sub CPU synchronization.


Refer to the following manual for details on slave CPU synchronization.

 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

**Information** You can use Sub CPU synchronization and slave CPU synchronization at the same time.

## Differences between Sub CPU Synchronization and Slave CPU Synchronization

The following tables gives the differences between Sub CPU synchronization and slave CPU synchronization.

Item	Sub CPU Synchronization	Slave CPU Synchronization
Connection Method	Connected through MP3000 bus	Connected with MECHATROLINK-III.
Maximum Number of CPU Units	5 (Main CPU Unit × 1 and Sub CPU Units × 4)	39 (Master CPU Unit × 1 and Slave CPU Units × 38)
Transmission Distance	Maximum distance between stations: 6 m	Maximum distance between stations: 100 m
Data Update Period between CPU Units	125 μs, 250 μs, ..., 32 ms	250 μs, ..., 32 ms Refer to the following manual for details.  <i>MP3000 Series Motion Control User's Manual</i> (Manual No.: SIEP C880725 11)
Communications Scans	Both the high-speed scan and low-speed scan can be used at the same time.	High-speed scan only
Size of Shared Registers	For both high-speed and low-speed scans <ul style="list-style-type: none"> <li>• Inputs: 2,048 words max.</li> <li>• Outputs: 2,048 words max.</li> </ul>	<ul style="list-style-type: none"> <li>• Inputs: 32 words max. (Two of those words are used by the system.)</li> <li>• Outputs: 32 words max. (Two of those words are used by the system.)</li> </ul>
Starting and Stopping CPU Units	The Main CPU Unit and Sub CPU Units are linked.	The Main CPU Unit and Sub CPU Units are not linked.
WDT Errors		
Turning Power ON/OFF		
Motion Control Functionality	Both the Main CPU Unit and Sub CPU Units can be used as motion control masters.	The Master CPU Unit can be used as a motion control master. A Slave CPU Unit cannot be used as a motion control master.



---

## Sub CPU Synchronization

---


The following information is provided.

- 📖 *Overview of Sub CPU Synchronization (page 3-95)*
- 📖 *Conditions for Using Sub CPU Synchronization (page 3-97)*
- 📖 *Precautions When Using Sub CPU Synchronization (page 3-98)*
- 📖 *Differences between the Main CPU Unit and Sub CPU Units (page 3-102)*
- 📖 *I/O Registers Used for Sub CPU Synchronization (page 3-104)*
- 📖 *Sub CPU Synchronization Data Transfer Timing (page 3-107)*
- 📖 *Scan Overhead Guidelines When Using Sub CPU Synchronization (page 3-108)*


### Overview of Sub CPU Synchronization

You can connect more than one CPU Unit through a bus to completely synchronize operation of the Main CPU Unit and Sub CPU Units. The locations of the CPU Units are used to automatically determine which CPU Unit is the Main CPU Unit and which CPU Units are the Sub CPU Units.

The following figure shows a system configuration example.



- You can have one Sub CPU Unit on the Main Rack and a total of three Sub CPU Units on Expansion Racks. You can therefore connect up to four Sub CPU Units in one system.
- The Optional Modules that are connected immediately to the right side of a CPU Unit are controlled by that CPU Unit.
- You can use the CPU interface registers for that CPU Unit to exchange up to 2,048 words of data each scan.
- You can completely synchronize the Main CPU Unit and Sub CPU Units. The following figure shows a timing chart.



## Conditions for Using Sub CPU Synchronization

To use Sub CPU synchronization, conditions for the product versions and for the high-speed scan set values must be met.

### ◆ Applicable Versions

You must use the following versions of the CPU Units and MPE720.

Name	Model	Abbreviation	Applicable Versions
CPU Units	JEPMC-CP3201-E	CPU-201	Version 1.06 or higher
	JEPMC-CP3202-E	CPU-202	All versions
MPE720	CPMC-MPE780	–	Version 7.21 or higher

### ◆ Scan Set Values

The settings of the high-speed scans of the CPU Units must satisfy one of the following equations.

- High-speed scan set value of Main CPU Unit = High-speed scan set values of Sub CPU Units
- High-speed scan set value of Main CPU Unit = Integral multiple of high-speed scan set value of Sub CPU Unit

If one of these equations is not satisfied, the Controller will operate without synchronizing the cycle between the Main CPU Unit and Sub CPU Units.

#### Information

You can check whether operation is currently synchronized or not in system register SB00040B (CPU Status) in the Sub CPU Units.

- 0: High-speed scans synchronized.
- 1: High-speed scans not synchronized.



#### Note

If you perform any of the following operations when the CPU Units are synchronized and the equations given in *Scan Set Values* (page 3-98) are no longer satisfied, the CPU Units will change to non-synchronous operation

1. Change the high-speed scan set value of the Main CPU Unit or a Sub CPU Unit.
2. Save the SVC Transmission Definition of a Sub CPU Unit.
3. Perform self configuration for a Sub CPU Unit.
4. Set bit C (network reset) in motion setting parameter OW□□□00 in a Sub CPU Unit to 1 (ON).

Also, if you perform any of items 2 to 4, above, MECHATROLINK communications will stop and the position information and zero point return completion information will be lost. This will disable the software limits.

If you lose synchronization or the software limits are disabled, use the following steps to reset the CPU Units.

- If necessary, set the high-speed scan set values again.
- Enable the software limits.
- Turn the power supply to the CPU Units OFF and ON again.

Refer to the following manual for the procedure to enable the software limits.

📖 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

## Precautions When Using Sub CPU Synchronization

This section provides precautions that must be followed when you use Sub CPU synchronization.

### ◆ Self Configuration

Self configuration is not performed for the Sub CPU Units even if you perform it for the Main CPU Unit. To perform self configuration for a Sub CPU Unit, use the DIP switch on the Sub CPU Unit or connect the MPE720 to the Sub CPU Unit. The procedure is the same as that for the Main CPU Unit. Refer to the following section for details.

📖 *Self Configuration* (page 3-38)

Refer to the following manual for the connection procedure between a Sub CPU Unit and the MPE720.

📖 *MPE720 Version 7 System Integrated Engineering Tool for MP2000/MP3000 Series Machine Controller User's Manual* (Manual No.: SIEP C880761 03)

### ◆ Behavior when CPU Units Stop

CPU Run/CPU Stop Setting		CPU Run/CPU Stop Status	
Main CPU Unit Setting	Sub CPU Unit Setting	Main CPU Unit Status	Sub CPU Unit Status
Run	Run	Run	Run
Stop	Run	Stop	Stop <sup>*1</sup>
Run	Stop	Run <sup>*2</sup>	Stop
Stop	Stop	Stop	Stop

\*1. The Sub CPU Units will stop when the Main CPU Unit stops.

\*2. The Main CPU Unit will not stop just because a Sub CPU Unit stops.

### ◆ Behavior for Watchdog Timer Timeouts

If a watchdog timer timeout (WDT) error occurs for the Main CPU Unit or any Sub CPU Unit and the CPU Unit goes down, the other CPU Units will have WDT errors and will go down.

### ◆ Behavior When Turning Power ON/OFF

In a system that uses an Expansion Rack, if the power supply to the Rack for either the Main CPU Unit or a Sub CPU Unit is turned ON or OFF, a hardware reset is performed for the other CPU Units and the power supply turns OFF and ON again.

### ◆ Behavior When Actual Hardware Does Not Agree with Module Configuration Definitions in MPE720

The locations of the CPU Units are used by the MPE720 to automatically determine which CPU Unit is the Main CPU Unit and which CPU Units are the Sub CPU Units. However, it will not be possible for the MPE720 to correctly recognize the CPU Units for the following conditions in the Module configuration.

Module Configuration Definitions <sup>*1</sup>	Main CPU Unit Behavior	Sub CPU Unit Behavior
When the Module configuration definitions of the Main CPU Unit are saved	The Main CPU Unit will operate correctly.	The scan service will stop. <sup>*2</sup> E.080 will be displayed on the CPU Unit's display.
When the Module configuration definitions of a Sub CPU Unit are saved	The scan service will stop. <sup>*2</sup> E.080 will be displayed on the CPU Unit's display.	The Sub CPU Unit will operate correctly.
When the Module configuration definitions are not saved (e.g., for INIT startup)	The Main CPU Unit will operate correctly.	The Sub CPU Unit will operate correctly.

\*1. You can check the Module configuration definitions in the Module Configuration Definition Tab Page on the MPE720.

\*2. The Sub CPU Unit will stop, but you will be able to batch-save data to the USB memory and will be able to use the MPE720 to batch-read data.


### ◆ Connecting the MPE720

You can simultaneously connect up to two PCs running the MPE720 directly to a Sub CPU Unit.



If you connect the MPE720 to Sub CPU Units through the Main CPU Unit, the MPE720 can successfully communicate with up to two Sub CPU Units at the same time. The MPE720 can actually communicate with up to five Sub CPU Units, but communications may become very slow. If you try to communicate with six or more Sub CPU Units, communications error may occur.

The following figure illustrates this feature.

Connecting the MPE720 Directly to a Sub CPU Unit



Connecting the MPE720 to a Sub CPU Unit through the Main CPU Unit




Refer to the following manual for the connection procedure between the MPE720 and a Sub CPU Unit.

📖 *MPE720 Version 7 System Integrated Engineering Tool for MP2000/MP3000 Series Machine Controller User's Manual*  
(Manual No.: SIEP C880761 03)

## ◆ MPE720 Project File Management


Manage all of the project files for the Main CPU Unit and Sub CPU Units as separate files.



## ◆ Sub CPU Unit Calendars

When you turn ON the power supply, the contents of the calendars in the Sub CPU Units will have the same settings as the calendar in the Main CPU Unit. Therefore, basically it is not necessary to set the calendars in the Sub CPU Units. However, you can use either of the following methods to set the calendars only in the Sub CPU Units.

- After communications are established between the Sub CPU Unit for which to change the settings with the MPE720, change the settings from the Environment Setting Dialog Box of the MPE720. Abbreviated operating procedure: **Environment Setting Dialog Box – Setup – System Setting – Calendar – Setting Group**
- Use the ladder programming in the Sub CPU Unit for which to change the settings and write the settings to SW00015 to SW00019 (system registers: calendar). Refer to the following section for details.

 **Calendar** (page 4-18)

## Information

Although the Main CPU Unit and Sub CPU Units will have the same calendar settings after the power supply is turned ON, thereafter they run on their own power supplies. This can cause error to occur between the calendar settings of the Main CPU Unit and Sub CPU Units as time passes. If that occurs, set only the Sub CPU Units.

## Differences between the Main CPU Unit and Sub CPU Units

The following table gives the differences between the Main CPU Unit and Sub CPU Units. Items for which there are no differences between the Main CPU Unit and Sub CPU Units have been omitted.

Item	Main CPU Unit	Sub CPU Unit
Connected Rack	Can be connected only to Rack 1.	Can be connected to Rack 1 or 5 to 7. If you connect the Sub CPU Unit to Rack 1, connect it to the right of the Main CPU Unit.
Function Modules in CPU Unit	<ul style="list-style-type: none"> <li>• CPU</li> <li>• 218IFD</li> <li>• SVC32</li> <li>• SVR32</li> <li>• M-EXECUTOR</li> </ul>	<ul style="list-style-type: none"> <li>• CPU</li> <li>• 218IFD</li> <li>• SVC32</li> <li>• SVR32</li> <li>• M-EXECUTOR</li> <li>• CPUIF</li> </ul>
Self Configuration	Recognizes Sub CPU Units.	Does not recognize the Main CPU Unit.
Starting and Stopping CPU Units	The Main CPU Unit can be started and stopped independently. Doing so will not cause the Sub CPU Units to start or stop.	A Sub CPU Unit can be started and stopped independently. However, the start/stop link with the Main CPU Unit will be given priority.
Calendar	<ul style="list-style-type: none"> <li>• Set with the MPE720.</li> <li>• Set with system registers.</li> </ul>	<ul style="list-style-type: none"> <li>• Calendar settings are synchronized with the Main CPU Unit when the power supplies are turned ON.</li> <li>• Set with the MPE720.</li> <li>• Set with system registers.</li> </ul>
Sub CPU Unit Status	Reported in system registers SW001475 to SW001482 (system status).	Reported in system registers SW00040 to SW00041 (system status).
Synchronization Status between CPU Units	Not reported in system registers.	Reported in system register SB00040B (synchronization status with Main CPU Unit).
WDT Errors	WDT error in Main CPU Unit	<ul style="list-style-type: none"> <li>• Error number E.001 is displayed on the CPU Unit.</li> <li>• Reported by placing 0001 hex (watchdog timer timeout) in system register SW00050 (32-bit error code).</li> </ul>
	WDT error in Sub CPU Unit	<ul style="list-style-type: none"> <li>• Error number E.051 is displayed on the CPU Unit.</li> <li>• Reported by placing 0051 hex (Module synchronization error) in system register SW00050 (32-bit error code).</li> </ul>
		<ul style="list-style-type: none"> <li>• Error number E.052 is displayed on the CPU Unit.</li> <li>• Reported by placing 0052 hex (Main CPU Unit system down detected) in system register SW00050 (32-bit error code).</li> </ul>
		<ul style="list-style-type: none"> <li>• Error number E.001 is displayed on the CPU Unit.</li> <li>• Reported by placing 0001 hex (watchdog timer timeout) in system register SW00050 (32-bit error code).</li> </ul>

Continued on next page.



Continued from previous page.

Item		Main CPU Unit	Sub CPU Unit
MPE720 Connections		Direct connection with MPE720 with Ethernet connector on Main CPU Unit	<ul style="list-style-type: none"> <li>• The Main CPU Unit connects directly to the MPE720 through the Ethernet connector on the Main CPU Unit.</li> <li>• The Sub CPU Unit connects to the MPE720 through the Main CPU Unit. The MPE720 is connected to the Ethernet connector on the Main CPU Unit.</li> </ul>
Controller Search Name		CPU-201	CPU-201SUB
Slave CPU Synchronization	Master	Supported.	Supported.
	Slave	Supported.	Not supported.

## I/O Registers Used for Sub CPU Synchronization

There are the following two types of registers for the Main CPU Unit and Sub CPU Units.

- High-speed scan CPU interface registers: Exchange data in the high-speed scan.
- Low-speed scan CPU interface registers: Exchange data in the low-speed scan.

These registers are assigned to CPU interface registers for the Safety CPU Unit service.

You can set the ranges of the CPU interface registers on the Module Configuration Definition Tab Page on the MPE720.

### Module Configuration Definition Tab Page for the Main CPU Unit

Module	Function Module/Slave	Status	Circuit No./Axis Address		Motion Register	Disabled	Register (Input/Output)			Comment
			Start	Occupied circuits			Start - End	Size	Scan	
01 [CPU-201] ---										
EXU-001										
PSA-12										
01 CPU										
02 2181FD			Circuit No1	1		<input type="checkbox"/> Input	0000 - 07FF[H]	2048		
03 SVCS2			Circuit No1	2	8000 - 8FFF[H]	<input type="checkbox"/> Input	0800 - 0BFF[H]	1024		
04 SVRS2			Circuit No3	2	9000 - 9FFF[H]	<input type="checkbox"/> Output				
05 M-EXECUTOR							0C00 - 0C3F[H]	64		
06 UNDEFINED ---										
01 UNDEFINED ---										
02 UNDEFINED ---										
03 UNDEFINED ---										
04 UNDEFINED ---										
05 EXIOIF ---										
01 EXIO			Circuit No1	1						
01 CPU201SUB[---]			Circuit No1	1	30000 - 207FF[H]		1000 - 17FF[H]	2048		
03 UNDEFINED ---										
04 UNDEFINED ---										
05 UNDEFINED ---										
02 Extension Rack										

### Module Configuration Definition Tab Page for the Sub CPU Unit

Module	Function Module/Slave	Status	Circuit No./Axis Address		Motion Register	Disabled	Register (Input/Output)			Comment
			Start	Occupied circuits			Start - End	Size	Scan	
01 [CPU-201SUB] ---										
01 CPUSUB										
02 2181FD			Circuit No1	1		<input type="checkbox"/> Input	0000 - 07FF[H]	2048		
03 SVCS2			Circuit No1	2	8000 - 8FFF[H]	<input type="checkbox"/> Input	0800 - 0BFF[H]	1024		
04 SVRS2			Circuit No3	2	9000 - 9FFF[H]	<input type="checkbox"/> Output				
05 M-EXECUTOR							0C00 - 0C3F[H]	64		
06 UNDEFINED ---										
01 UNDEFINED ---										
02 UNDEFINED ---										
03 UNDEFINED ---										
04 UNDEFINED ---										
05 UNDEFINED ---										
02 UNDEFINED ---										
03 UNDEFINED ---										
01 CPU201SUB[---]			Circuit No1	1	30000 - 207FF[H]		1000 - 107F[H]	128		

### ◆ CPU Interface Registers for High-speed Scan


When you set the circuit number on the Module Configuration Definition Tab Page, the ranges of CPU interfaces for the high-speed scan given in the following table are assigned. The default circuit number is 1.

**Information** You cannot set the same circuit number for more than one Sub CPU Unit on the Module Configuration Definition Tab Page for the Main CPU Unit. You can set the same circuit number for more than one Sub CPU Unit on the Module Configuration Definition Tab Page for a Sub CPU Unit.

Circuit Number	Default I/O Registers		Settable Range of I/O Registers	
	Register Addresses	Size	Register Addresses	Size
1	IW20000 to IW2003F and OW20000 to OW2003F	64 words each	IW20000 to IW207FF and OW20000 to OW207FF	2,048 words each
2	IW20800 to IW2083F and OW20800 to OW2083F	64 words each	IW20800 to IW20FFF and OW20800 to OW20FFF	2,048 words each
3	IW21000 to IW2103F and OW21000 to OW2103F	64 words each	IW21000 to IW217FF and OW21000 to OW217FF	2,048 words each
4	IW21800 to IW2183F and OW21800 to OW2183F	64 words each	IW21800 to IW21FFF and OW21800 to OW21FFF	2,048 words each

- Information**
1. If you change the register size, set a value that is an integral multiple of 16 words (32 bits).
  2. You can set register sizes of up to 2,048 words for both input and output registers, but the larger the register sizes, the longer the processing time.


Data for the registers assigned to the high-speed scan cycle is transferred in the high-speed scan of the Sub CPU Unit. The data transfer size is the I/O size of the Sub CPU Unit.



### ◆ CPU Interface Registers for Low-speed Scan

You can set register sizes of up to 2,048 words for both the input and output registers for the CPU interface registers for the low-speed scan. Set a value that is an integral multiple of 16 words (32 bits).

The data transfer size is the smaller of the I/O sizes of the Main CPU Unit and Sub CPU Unit. We recommend that you set the same I/O sizes for the Main CPU Unit and Sub CPU Units to make programming easier to understand.




## Sub CPU Synchronization Data Transfer Timing

This section describes the timing of data transfer for the CPU interface registers for the high-speed and low-speed scans.


### ◆ CPU Interface Registers for High-speed Scan

The following figures show the data transfer timing for CPU interface registers for the high-speed scans.

#### ■ When the Main CPU Unit and Sub CPU Unit Have the Same High-speed Scan Set Values



#### ■ When High-speed Scan Set Value of Main CPU Unit Is An Integral Multiple of High-speed Scan Set Value of Sub CPU Unit



### ◆ CPU Interface Registers for Low-speed Scan

The low-speed scans are not synchronized, so data transfer for the CPU interface registers for the low-speed scans is not performed periodically in the way it is for the high-speed scans. However, the Sub CPU Unit will never read the low-speed scan data that is being transferred from the Main CPU Unit during its current low-speed scan. Also, the Main CPU Unit will never read the low-speed scan data that is being transferred from the Sub CPU Unit during its current low-speed scan. In other words, exclusive control is performed for the data to ensure data concurrency.

## Scan Overhead Guidelines When Using Sub CPU Synchronization

This section provides guidelines for the scan overhead times for the sizes of CPU interface registers for high-speed and low-speed scans.


### ◆ CPU Interface Registers for High-speed Scan

This section describes the data transfer timing for CPU interface registers for the high-speed scans.

Item	I/O Size		
	512 Words	1,024 Words	2,048 Words
Guideline Times for CPU Interface Overhead	25 $\mu$ s	50 $\mu$ s	100 $\mu$ s

If the time set for the high-speed scan in the CPU Unit is shorter than the overhead time, a scan exceeded error will occur and SW00044 (H Scan Exceeded Count) will be incremented. If that occurs, adjust the high-speed scan set value based on the above table.

The following figure illustrates high-speed scan processing.




### ◆ CPU Interface Registers for Low-speed Scan

The following table gives approximate times for the low-speed scan overhead that is required for different sizes of CPU interface registers for the low-speed scan.

Item	I/O Size		
	512 Words	1,024 Words	2,048 Words
Guideline Times for CPU Interface Overhead	100 $\mu$ s	200 $\mu$ s	300 $\mu$ s

If the time set for the low-speed scan in the CPU Unit is shorter than the overhead time, a scan exceeded error will occur and SW00046 (L Scan Exceeded Count) will be incremented. If that occurs, adjust the low-speed scan set value based on the above table.

The following figure illustrates low-speed scan processing.



## Slave CPU Synchronization

Refer to the following manual for details on slave CPU synchronization.

📖 *MP3000 Series Motion Control User's Manual* (Manual No.: SIEP C880725 11)

# Specifications


# 4

This section provides the installation and usage conditions of the MP3200. It also provides detailed specifications of the MP3200.

<b>4.1</b>	<b>MP3200 Installation and Usage Conditions . . . . .</b>	<b>4-2</b>
	Control Panel Cooling Method . . . . .	4-2
<b>4.2</b>	<b>Power Supply Unit Specifications . . . . .</b>	<b>4-4</b>
<b>4.3</b>	<b>CPU Unit Specifications . . . . .</b>	<b>4-5</b>
	Hardware Specifications . . . . .	4-5
	Performance Specifications . . . . .	4-6
	Communications Specifications . . . . .	4-9
	Motion Control Function Module Specifications . . . . .	4-10
	M-EXECUTOR Specifications . . . . .	4-11
	USB Memory Specifications . . . . .	4-12
	System Register Specifications . . . . .	4-13
<b>4.4</b>	<b>Base Unit Specifications . . . . .</b>	<b>4-80</b>
<b>4.5</b>	<b>Rack Expansion Interface Unit Specifications . .</b>	<b>4-81</b>

## 4.1 MP3200 Installation and Usage Conditions

The installation and usage conditions for the MP3200 are given in the following table.

	Item	Specification
Environmental Conditions	Ambient Operating Temperature	0 to 55°C
	Ambient Storage Temperature	-25 to 85°C
	Ambient Operating Humidity	30% to 95% RH (with no condensation)
	Ambient Storage Humidity	5% to 95% RH (with no condensation)
	Pollution Level	Conforms to JIS B 3502 Pollution Degree 2.
	Corrosive Gas	There must be no combustible or corrosive gas.
	Operating Altitude	2,000 m max.
Mechanical Operating Conditions	Vibration Resistance	Conforms to JIS B 3502. • Continuous vibration: 5 to 9 Hz with single-amplitude of 1.75 mm 9 to 150 Hz with fixed acceleration of 4.9 m/s <sup>2</sup> • Intermittent vibration: 5 to 9 Hz with single-amplitude of 3.5 mm 9 to 150 Hz with fixed acceleration of 9.8 m/s <sup>2</sup> 10 sweeps each in X, Y, and Z directions for both intermittent and continuous vibration
	Shock Resistance	Size of shock: Peak acceleration of 147 m/s <sup>2</sup> (15 G) Duration: 11 ms 3 times each in X, Y, and Z directions
Electrical Operating Conditions	Noise Resistance	Conforming to EN 61000-6-2, EN 61000-6-4, EN 55011 (Group 1 Class A)
Installation Conditions	Ground	Ground to 100 Ω max.
	Cooling Method	Natural cooling or forced-air cooling Refer to the following section for details.  <i>Control Panel Cooling Method (page 4-2)</i>

## Control Panel Cooling Method

The components that are used in the Machine Controller require the ambient operating temperature to be between 0 and 55°C. Use one of the methods described below to ensure adequate cooling in the control panel.



Note

- If the ambient temperature exceeds 50°C, we recommend forced-air cooling.
- The CPU-202 uses forced-air cooling with a built-in Fan.



## Control Panels with Natural Cooling

- Do not mount the Machine Controller at the top of the control panel, where the hot air that is generated inside the panel collects.
- Leave sufficient space above and below the Units, and maintain adequate distances from other devices, cable ducts, and other objects to ensure suitable air circulation.
- Do not mount the Machine Controller in any direction other than the specified direction.
- Do not mount the Machine Controller on top of any device that generates a significant amount of heat.
- Do not subject the Machine Controller to direct sunlight.

## Control Panels with Forced-air Cooling

Use one of the following methods to ensure  $0.03 \text{ m}^3/\text{min}$  average airflow below the CPU Unit.


- Forced draft method (A fan or a similar device is used to circulate the air in the interior and the exterior of the panel.)
- Forced circulation method (A fan or a similar device is mounted to the airtight panel to circulate the air inside.)



Note



Use the following guideline when selecting the fan:

- CPU Unit's resistance to air flow:  $6 \times 10^6 \text{ (N}\cdot\text{s}^2/\text{m}^8)$
- The CPU-202 has a built-in Fan. You do not need to select or install a separate fan.



## 4.2 Power Supply Unit Specifications

The specifications of the Power Supply Unit are given in the following table.

Item		Specification								
		AC Power Supply Unit	DC Power Supply Unit							
Model		JEPMC-PSA3012-E	JEPMC-PSD3012-E							
Abbreviation		PSA-12	PSD-12							
Power Supply Section	Input Voltage	100/200 VAC	24 VDC							
	Allowable Input Voltage Range	85 to 132 VAC or 170 to 276 VAC	19.2 to 28.8 VDC							
	Allowable Frequency Range	47 to 63 Hz	–							
	Input Current	4.0 A max. (at rated input/output)	5.0 A max. (at rated input/output)							
	Inrush Current	25 A, 10 ms max. (fully discharged, 132-VAC input, rated output)	50 A, 10 ms max. (fully discharged, 28.8-VDC input, rated output)							
		50 A, 10 ms max. (fully discharged, 276-VAC input, rated output)								
	Allowable Power Loss Time	20 ms	1 ms							
	Rated Voltage	5.15 V								
	Rated Current	12.0 A								
	Output Current Range	0 to 12.0 A	0.2 to 12.0 A							
Constant Voltage Accuracy	5.15 V $\pm$ 2% max. (5.05 to 5.25 V)									
Status Output	<p>If the Power Supply Unit is mounted on the Main Rack, this output functions as normally closed contacts that are synchronized with the status of the CPU Unit.</p> <ul style="list-style-type: none"> <li>• Normal operation: Circuit closed.</li> <li>• Error: Circuit open.</li> </ul> <p>Contact Ratings</p> <table border="1"> <thead> <tr> <th>Input Voltage</th> <th>Current Capacity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">125 VAC</td> <td>0.4 A (resistive load)</td> </tr> <tr> <td>0.2 A (inductive load)</td> </tr> <tr> <td rowspan="2">24 VDC</td> <td>0.5 A (resistive load)</td> </tr> <tr> <td>0.25 A (inductive load)</td> </tr> </tbody> </table>		Input Voltage	Current Capacity	125 VAC	0.4 A (resistive load)	0.2 A (inductive load)	24 VDC	0.5 A (resistive load)	0.25 A (inductive load)
Input Voltage	Current Capacity									
125 VAC	0.4 A (resistive load)									
	0.2 A (inductive load)									
24 VDC	0.5 A (resistive load)									
	0.25 A (inductive load)									
Indicators	<p>POWER</p> <p>Refer to the following section for details.</p> <p> <i>Indicators (page 2-2)</i></p>									
Connectors	<ul style="list-style-type: none"> <li>• POWER: Power supply connector</li> <li>• RLY OUT: Relay contact connector</li> <li>• Unit connector</li> </ul> <p>Refer to the following section for details.</p> <p> <i>Connectors (page 2-3)</i></p>									




## 4.3

## CPU Unit Specifications

This section provides the specifications that are related to the performance, hardware, functionality, and registers of the CPU Unit.


## Hardware Specifications

The hardware specifications of the CPU Unit are given in the following table.

Item	Specification	
Model	JEPMC-CP3201-E	JEPMC-CP3202-E
Abbreviation	CPU-201	CPU-202
Flash Memory	Capacity: 40 MB (32 MB of user memory)	
SDRAM	Capacity: 128 MB	Capacity: 512 MB
SRAM	Capacity: 8 MB (battery backup)	
Calendar	Seconds, minutes, hour, day, week, month, year, day of week, and timing (battery backup)	
Battery	You can mount a memory backup Battery.	
Ethernet	10Base-T or 100Base-TX × 2 ports (hub)	
MECHATROLINK	<ul style="list-style-type: none"> <li>• MECHATROLINK-III: 1 circuit with 2 ports</li> <li>• Master</li> <li>• Slave</li> </ul>	
USB	<ul style="list-style-type: none"> <li>• USB 2.0 Type A host, 1 port</li> <li>• Compatible devices: USB storage</li> </ul>	
Indicators and Displays	<ul style="list-style-type: none"> <li>• Seven-segment display</li> <li>• Status indicators</li> <li>• USB status indicator</li> <li>• MECHATROLINK-III status indicators</li> <li>• Ethernet status indicators</li> </ul> Refer to the following section for details.  <i>Display and Indicators (page 2-6)</i>	
Switches	<ul style="list-style-type: none"> <li>• DIP switch: Mode switch 1</li> <li>• DIP switch: Mode switch 2</li> <li>• Rotary switches</li> <li>• STOP/SAVE switch</li> </ul> Refer to the following section for details.  <i>Switches (page 2-9)</i>	
Connectors	<ul style="list-style-type: none"> <li>• MECHATROLINK-III connectors</li> <li>• Ethernet connectors</li> <li>• USB connector</li> <li>• Unit connector</li> </ul> Refer to the following section for details.  <i>Connectors (page 2-11)</i>	

## Performance Specifications

The performance specifications of the CPU Unit are given in the following table.

Item		Specification		Remarks
		CPU-201	CPU-202	
System Configuration	Maximum Number of Racks	7		<ul style="list-style-type: none"> <li>• Main Rack</li> <li>• Expansion Racks added by using EXIOIF Modules: 3 max.</li> <li>• Expansion Racks added by using a Rack Expansion Interface Unit: 3 max.</li> </ul>
	Maximum Number of Units Connected on the Right of a CPU Unit	5		–
	Maximum Number of Base Units Controllable by One CPU Unit	Main CPU Unit: 4		You must use EXIOIF Modules to add Expansion Racks.
		Sub CPU Unit: 1		–
	Maximum Number of Optional Modules Controllable by the Main CPU Unit	35		<ul style="list-style-type: none"> <li>• Main Rack: 1 Base Unit × 8 slots</li> <li>• Expansion Racks added by using EXIOIF Modules: 3 Base Units × 9 slots</li> </ul> Note: If you use a Rack Expansion Interface Unit to add Optional Modules on Expansion Racks, the Optional Modules are controlled by the Sub CPU Units and not by the Main CPU Unit.
Number of Controlled Axes	SVC32	16 axes in 1 circuit or 32 axes in 2 circuits		Circuit number selected from 1 to 16. If two circuits are selected, only odd circuit numbers can be selected.
	SVR32	16 axes in 1 circuit or 32 axes in 2 circuits		Circuit number selected from 1 to 16. If two circuits are selected, only odd circuit numbers can be selected.
	Maximum Number of Controlled Axes	256 axes		Optional Modules (SVB-01 or SVC-01 Modules) must be mounted. Note: The number of controlled axes of the SVC32 and SVR32 given above are included.
Scan Time Settings	H Scan	0.125 to 32.0 ms (in 0.125-ms increments)		Refer to the following section for details.  3.1 Basic Functionality – Scans (page 3-32)
	L Scan	2.0 to 300 ms (in 0.5-ms increments)		–
	H Scan Default	4 ms		–
	L Scan Default	200 ms		–
Peripheral Devices	Calendar	Provided.		–
	Communications Interface	Ethernet		–
	USB	Provided.		–
Memory Capacity	DRAM	128 MB with ECC	512 MB with ECC	–
	SRAM (battery backup)	8 MB		Use up to 3 MB with battery backup for table data.
	Program Capacity	32 MB		Total capacity including definition data, ladder programs, table data, etc.

Continued on next page.

Continued from previous page.

Item	Specification		Remarks
	CPU-201	CPU-202	
Ladder Programs	Number of Startup Drawings (DWGA)	64	Number of steps per drawing: 4,000
	Number of Interrupt Drawings (DWGI)	64	
	Number of High-speed Scan Drawings (DWGH)	1000	
	Number of Low-speed Scan Drawings (DWGL)	2000	
	Number of User Function Drawings	2000	
Motion Programs	Number of Programs	512	Total of all programs listed below: <ul style="list-style-type: none"> <li>• Motion main programs</li> <li>• Motion subprograms</li> <li>• Sequence main programs</li> <li>• Sequence subprograms</li> </ul>
	Number of Groups	16	–
	Number of Tasks	32	–
	Number of Nesting Levels for IF Instructions	8	–
	Number of Nesting Levels for MSEE Instructions	8	–
	Number of Parallel Forks Per Task	8	Select from the following four options: <ul style="list-style-type: none"> <li>• Main: 4 forks, Sub: 2 forks</li> <li>• Main: 8 forks</li> <li>• Main: 2 forks, Sub: 4 forks</li> <li>• Sub: 8 forks</li> </ul>
	Number of Simultaneously Controlled Axes Per Task	32 axes	–
Registers	S Registers	64 Kwords	–
	M Registers	1 Mword	Battery backup
	G Registers	2 Mwords	No battery backup
	I/O Registers	64 Kwords	–
	Motion Registers	32 Kwords	–
	C Registers	16 Kwords	–
	# Registers	16 Kwords	–
	D Registers	16 Kwords	–
Data Types	Bit (B)	Supported.	0, 1
	Integer (W)	Supported.	-32,768 to 32,767
	Double-length Integer (L)	Supported.	-2,147,483,648 to 2,147,483,647
	Quadruple-length Integer (Q)	Supported.	-9,223,372,036,854,775,808 to 9,223,372,036,854,775,807
	Single-precision Real Number (F)	Supported.	$\pm (1.175\text{E}-38 \text{ to } 3.402\text{E}+38)$ , 0
	Double-precision Real Number (D)	Supported.	$\pm (2.225\text{E}-308 \text{ to } 1.798\text{E}+308)$ , 0
	Addresses (A)	Supported.	0 to 16,777,214
Index Registers	Subscript i	Supported.	Special registers for offsetting addresses. Subscripts i and j function identically.
	Subscript j	Supported.	
	Array Registers	Supported.	Used to handle registers as arrays

Continued on next page.

Continued from previous page.

Item		Specification		Remarks	
		CPU-201	CPU-202		
Data Tracing	Number of Groups	4		–	
	Trace Memory	1 Mword, 4 groups		–	
	Traceable Data Points	16 points per group		–	
	Trigger Types	>, <, =, <>, >=, <= and differential detection of the above conditions		–	
Data Logging	Number of Groups	4		–	
	Log Storage Location	Built-in RAM disk or USB memory device		–	
	Log File Formats	CSV file format or binary file format		–	
	Data Logging Points	64 points per group		–	
	Number of Log Files	Built-in RAM Disk	1 to 4000		–
		USB Memory	1 to 32,767 or unlimited		The ultimate upper limit is 10,000 files even if unlimited is selected.
	Trigger Types	>, <, =, <>, >=, <=		–	
Compatibility with MP2000-series Optional Modules	Type	Abbreviation		Compatible CPU Unit Version	
				CPU-201	CPU-202
	Motion Modules	SVB-01		Version 1.00 or higher	All versions
		MPU-01, PO-01, SVA-01, SVC-01		Version 1.01 or higher	All versions
	Communications Modules	260IF-01		Version 1.00 or higher	All versions
		215AIF-01, 217IF-01, 265IF-01		Version 1.01 or higher	All versions
		218IF-01, 218IF-02, 261IF-01, 262IF-01, 263IF-01, 264IF-01		Version 1.02 or higher	All versions
		266IF-01, 266IF-02		Version 1.06 or higher	–
	Communications Modules (from other manufacturers)	AFMP-01 (from Anywire Corporation)		Version 1.00 or higher	All versions
		AFMP-02-C, AFMP-02-CA (from Anywire Corporation)		Version 1.01 or higher	All versions
		MPANL00-0, MPALL00-0, MPAL000-0, MPAN000-0 (from ALGO System)		Version 1.03 or higher	All versions
		MPCUNET-0 (from ALGO System)		Version 1.05 or higher	–
	I/O Modules	LIO-01, LIO-02, LIO-04, LIO-05, LIO-06		Version 1.00 or higher	All versions
		AI-01, AO-01		Version 1.01 or higher	All versions
		DO-01, CNTR-01		Version 1.02 or higher	All versions
	Expansion Rack Module	EXIOIF		Version 1.06 or higher	All versions

## Communications Specifications

The specifications of the Communications Function Module that is built into the CPU Unit are given in the following table.

Item		Specification	Remarks	
Abbreviation		218IFD	—	
Common Items	Communications Interface	10Base-T or 100Base-TX	—	
	Number of Communications Ports (Connectors)	2	2-port hub	
	Communications Protocols	TCP, UDP, IP, ARP, or ICMP	—	
Ethernet Communications	Maximum Number of Communications Connections	20 + 2 (I/O message communications)	—	
	Maximum Number of Communications Channels	10 + 2 (I/O message communications)	—	
	Automatic Reception	Supported.	Not supported for no-protocol communications.	
	Maximum Number of Automatic Reception Connections	10	—	
	Maximum Size of Message Communications	MEMOBUS	Write: 100 words Read: 125 words	—
		Extended MEMOBUS	Write: 2,043 words Read: 2,044 words	—
		MELSEC (A-compatible 1E)	Write: 256 words Read: 256 words	—
		MELSEC (QnA-compatible 3E)	Write: 960 words Read: 960 words	—
		MODBUS/TCP	Write: 100 words Read: 125 words	—
		OMRON	Write: 996 words Read: 999 words	—
		TOYOPUC	Write: 1,022 words	—
		No-protocol	Write: 2,046 words	—
	Maximum Size of I/O Message Communications	MEMOBUS	Write: 100 words Read: 125 words	—
		Extended MEMOBUS	Write: 1,024 words Read: 1,024 words	—
		MELSEC (A-compatible 1E)	Write: 256 words Read: 256 words	—
		MELSEC (QnA-compatible 3E)	Write: 256 words Read: 256 words	—
		MODBUS/TCP	Write: 100 words Read: 125 words	—
OMRON		Write: 996 words Read: 999 words	—	
Receive Buffer Mode Selection for No-protocol Communications		Supported.	—	
Engineering Tool	Communications Platform	Ethernet	—	
	Controller Searches	Supported.	—	

## Motion Control Function Module Specifications

The specifications of the Motion Control Function Module that is built into the CPU Unit are given in the following table.

Item		Specification		Remarks	
		CPU-201	CPU-202		
MECHA-TROLINK communications settings	Communications ASIC	JL-100		–	
	Number of Communications Lines	1		–	
	Number of Communications Ports (Connectors)	2		–	
	Communications cycle (cycle for refreshing data)	250 $\mu$ s to 32.0 ms	125 $\mu$ s to 32.0 ms	–	
	Master	Communications Method	M-III		–
		Baud Rate	100 Mbps		–
		Communications Cycle	125 $\mu$ s/250 $\mu$ s/0.5 ms/1 ms/1.5 ms/2 ms/3 ms		–
		Number of Connected Stations	42 stations (up to 32 servo stations)		–
		Message Relaying	Supported.		–
		C2 Messages	Supported.		Automatically set by the system.
		Retries	Supported.		–
	Asynchronous Setting of High-speed Scan Cycle and Communications Cycle	Not supported.		An alarm will occur if setting is attempted.	
	Slave	Communications Method	M-III		–
		Communications Cycle	125 $\mu$ s to 3.0 ms		–
		Slave CPU synchronization	Supported.		–



## M-EXECUTOR Specifications

The specifications of the M-EXECUTOR in the CPU Unit are given in this section.

### Registerable Programs

Program Type		Number of Registered Programs
Motion Programs		32*
Sequence Programs	Startup	1
	Interrupt	Not possible.
	H Scan	32*
	L Scan	32*

\* The combined total of motion programs and sequence programs must not exceed 32.



### Program Control Methods

You can use the following control methods for the programs that are registered in the M-EXECUTOR:

Item	Motion Programs	Sequence Programs										
Execution method	Sequential execution	Startup: Event execution H scan: Scan execution L scan: Scan execution										
System work	<p>There is a one-to-one correspondence between the definition number and system work number.</p> <table border="1"> <thead> <tr> <th>Definition No.</th> <th>System Work Number</th> </tr> </thead> <tbody> <tr> <td>No.1</td> <td>1</td> </tr> <tr> <td>No.2</td> <td>2</td> </tr> <tr> <td>⋮</td> <td>⋮</td> </tr> <tr> <td>No.32</td> <td>32</td> </tr> </tbody> </table>		Definition No.	System Work Number	No.1	1	No.2	2	⋮	⋮	No.32	32
Definition No.	System Work Number											
No.1	1											
No.2	2											
⋮	⋮											
No.32	32											
Program designation method	Direct designation or indirect designation	Direct designation										
Program execution method	Register the program in the definitions and start execution by turning ON the start signal.	Execution is started when the program is registered in the definitions.										
Interpolation override setting	Supported.	Not supported.										
I/O link definitions	Supported.	Not supported.										
Motion program status reporting in S registers	Supported.											
Number of parallel forks	Up to 8 • Main: 4 forks, Sub: 2 forks • Main: 8 forks • Main: 2 forks, Sub: 4 forks • Sub: 8 forks	No forks										
Error diagram execution when an operation error occurs	Supported.											

## USB Memory Specifications

The specifications of the USB memory in the CPU Unit are given in the following table.

Item	Specification	Remarks
Supported Media	USB memory device	Refer to the following section for details.  <i>Recommended USB Memory Device (page 4-12)</i>
Applicable FAT	FAT16/32	–
Maximum number of nested directories	10	–
File information	Last update time-stamps are supported.	Uses the calendar in the Controller. Refer to the following section for details.  <i>3.2 Function Modules - Calendar (page 3-93)</i>
Maximum length for file name and directory names	256 characters	–
Current Directory Function	16	–
Maximum number of simultaneously open files	16	–
Formatting	Not supported.	Use a formatted USB memory device.

### Recommended USB Memory Device

The following USB memory device is recommended. It can be purchased from Yaskawa.

Model	Specification	Manufacturer
SFU24096D1BP1TO-C-QT-111-CAP	4 GB USB memory	Swissbit Japan Inc.

## System Register Specifications

This section provides the specifications of the system registers.



Note

Do not use the registers reserved for the system.

### Overall Configuration

The following table shows the overall configuration of the system registers.

You can read error information and the operating status of the system by specifying the system register address.

Register Address	Contents	Details
SW00000 to SW00029	System Service Registers	◆ <i>System Service Registers (page 4-15)</i>
SW00030 to SW00049	System Status	◆ <i>System Status (page 4-19)</i>
SW00050 to SW00079	System Error Status	◆ <i>System Error Status (page 4-20)</i>
SW00080 to SW00089	User Operation Error Status	◆ <i>User Operation Error Status (page 4-22)</i>
SW00090 to SW00103	System Service Execution Status	◆ <i>Detailed User Operation Error Status (page 4-25)</i>
SW00104 to SW00109	Reserved for system.	–
SW00110 to SW00189	Detailed User Operation Error Status	◆ <i>Detailed User Operation Error Status (page 4-25)</i>
SW00190 to SW00199	Reserved for system.	–
SW00200 to SW00503	System I/O Error Status	◆ <i>System I/O Error Status (page 4-26)</i>
SW00504 and SW00505	Reserved for system.	–
SW00506 and SW00507	Security Status	◆ <i>Security Status (page 4-26)</i>
SW00508 to SW00649	Reserved for system.	–
SW00650 to SW00667	USB-related System Status	◆ <i>USB-related System Status (page 4-27)</i>
SW00668 to SW00693	Reserved for system.	–
SW00694 to SW00697	Message Relaying Status	◆ <i>Message Relaying Status (page 4-27)</i>
SW00698 to SW00789	Interrupt Status	◆ <i>Interrupt Status (page 4-28)</i>
SW00790 to SW00799	Reserved for system.	–

Continued on next page.

Continued from previous page.

Register Address	Contents	Details
SW00800 to SW01095	Module Information	◆ <i>Module Information (page 4-29)</i>
SW01096 to SW01410	Reserved for system.	—
SW01411 to SW01442	MPU-01 Module Status	◆ <i>MPU-01 Module Status (page 4-31)</i>
SW01443 to SW03199	Reserved for system.	—
SW03200 to SW05119	Motion Program Information	◆ <i>Motion Program Execution Information (page 4-32)</i>
SW05120 to SW05247	Used by the system (system memory read).	—
SW05248 to SW08191	Reserved for system.	—
SW08192 to SW09215	Expansion Motion Program Information	◆ <i>Motion Program Execution Information (page 4-32)</i>
SW09216 to SW09559	Reserved for system.	—
SW09560 to SW13699	Expansion System I/O Error Status	◆ <i>Expansion System I/O Error Status (page 4-55)</i>
SW13700 to SW15795	Expanded Unit and Module Information	◆ <i>Expanded Unit and Module Information (page 4-59)</i>
SW15796 to SW15799	Reserved for system.	—
SW15800	Expansion System Status	◆ <i>Expansion System Status (page 4-64)</i>
SW15801 to SW15997	Reserved for system.	—
SW15998 to SW16011	Expansion System Service Execution Status	◆ <i>Expansion System Service Execution Status (page 4-64)</i>
SW16012 to SW16199	Reserved for system.	—
SW16200 to SW17999	Alarm History Information	◆ <i>Alarm History Information (page 4-65)</i>
SW18000 to SW19999	Reserved for system.	—
SW20000 to SW22063	Product Information	◆ <i>Product information (page 4-67)</i>
SW22064 to SW22999	Reserved for system.	—
SW23000 to SW23159	Unit and Rack Information	◆ <i>Unit and Rack Information (page 4-67)</i>
SW23160 to SW23999	Reserved for system.	—
SW24000 to SW24321	Data Logging Execution Status	◆ <i>Data Logging Execution Status (page 4-69)</i>
SW24322 to SW24999	Reserved for system.	—
SW25000 to SW25671	Automatic Reception Status for Ethernet Communications	◆ <i>Automatic Reception Status for Ethernet Communications (page 4-71)</i>
SW25672 to SW65534	Reserved for system.	—

## Details

This section gives details on the system registers.

### ◆ System Service Registers












The data in these registers give the execution status and specifications of the programs. The System Service Registers are reset to zero when the system is started.

#### ■ Shared by All Drawings

Register Address	Name	Remarks	
SW00000	SB000000	Reserved for system.	–
	SB000001	High-speed Scan	ON for only the first scan after high-speed scan is started.
	SB000002	Reserved for system.	–
	SB000003	Low-speed Scan	ON for only the first scan after low-speed scan is started.
	SB000004	Always ON	Always ON (set to 1).
	SB000005	High-speed Scan 2	Only ON for one scan when the high-speed scan starts after the CPU Unit is changed to RUN Mode.
	SB000006	Low-speed Scan 2	Only ON for one scan when the low-speed scan starts after the CPU Unit is changed to RUN Mode.
	SB000007	High-speed Scan in Progress	1: High-speed scan in progress
	SB000008	MP2000 Option Service Executing	ON (set to 1) during service scan for the MP2000-series Optional Modules.
	SB000009 to SB00000F	Reserved for system.	–












■ DWG.H Only

Operation starts when the high-speed scan starts.

Register Address	Name	Remarks
SW00001	SB000010	1-scan Flicker Relay 
	SB000011	0.5-s Flicker Relay 
	SB000012	1.0-s Flicker Relay 
	SB000013	2.0-s Flicker Relay 
	SB000014	0.5-s Sampling Relay 
	SB000015	1.0-s Sampling Relay 
	SB000016	2.0-s Sampling Relay 
	SB000017	60.0-s Sampling Relay 
	SB000018	1.0 s After Start of Scan Process 
SW00001	SB000019	2.0 s After Start of Scan Process 
	SB00001A	5.0 s After Start of Scan Process 
	SB00001B to SB00001F	Reserved for system.
SW00002	Reserved for system.	—

■ DWG.L Only

Operation starts when the low-speed scan starts.

Register Address	Name	Remarks
SW00003	SB000030	1-scan Flicker Relay 
	SB000031	0.5-s Flicker Relay 
	SB000032	1.0-s Flicker Relay 
	SB000033	2.0-s Flicker Relay 
	SB000034	0.5-s Sampling Relay 
	SB000035	1.0-s Sampling Relay 
	SB000036	2.0-s Sampling Relay 
	SB000037	60.0-s Sampling Relay 
	SB000038	1.0 s After Start of Scan Process 
	SB000039	2.0 s After Start of Scan Process 
	SB00003A	5.0 s After Start of Scan Process 
	SB00003B to SB00003F	Reserved for system.

### ■ System Execution Status

Register Address	Name	Remarks
SW00004	High-speed Scan Set Value	High-speed scan set value (0.1 ms)
SW00005	Current High-speed Scan Time	Current high-speed scan time (0.1 ms)
SW00006	Maximum High-speed Scan Time	Maximum high-speed scan time (0.1 ms)
SW00007	High-speed Scan Set Value 2	High-speed scan set value (μs)
SW00008	Current High-speed Scan Time 2	Current high-speed scan time (μs)
SW00009	Maximum High-speed Scan Time 2	Maximum high-speed scan time (μs)
SW00010	Low-speed Scan Set Value	Low-speed scan set value (0.1 ms)
SW00011	Current Low-speed Scan Time	Current low-speed scan time (0.1 ms)
SW00012	Maximum Low-speed Scan Time	Maximum low-speed scan time (0.1 ms)
SW00013	Reserved for system.	–
SW00014	Current Scan Time	Scan time of currently executing scan (0.1 ms)

### ■ Calendar

Register Address	Name	Remarks	Example
SW00015	Calendar year	Gives the last two digits of the year in BCD format.	2011: 0011
SW00016	Calendar Month and Day	Gives the month and day in BCD format.	December 31: 1231
SW00017	Calendar Hours and Minutes	Gives the hours and minutes in BCD format.	23 hours 59 minutes: 2359
SW00018	Calendar Seconds	Gives the seconds in BCD format.	59 seconds: 0059
SW00019	Calendar Week	Gives the day of the week as a number between 0 and 6. 0: Sunday, 1: Monday, 2: Tuesday, 3: Wednesday, 4: Thursday, 5: Friday, and 6: Saturday	–

### ■ System Program Software Version

Register Address	Name	Remarks
SW00020	System Program Software Version	Ver. □□.□□ (Gives the version in BCD format.)
SW00021 to SW00025	Reserved for system.	–

### ■ Remaining Program Memory Capacity

Register Address	Name	Remarks
SL00026	Remaining Program Memory Capacity	Bytes
SL00028	Total Memory Capacity	Bytes



### ◆ System Status

The data in these registers give the operating status of the system or provide information about errors. You can check the following system registers to determine whether the cause of the error is hardware or software related. The System Status Registers are reset to zero when the system is started.

Name	Register Address	Contents	
Reserved for system.	SW00030 to SW00039	-	
CPU Status	SW00040	SB000400	READY 0: Error, 1: Ready
		SB000401	RUN 0: Stopped, 1: Running
		SB000402	ALARM 0: Normal, 1: Alarm
		SB000403	ERROR 0: Normal, 1: Error
		SB000404	Reserved for system. -
		SB000405	M-ALM 0: Normal, 1: Axis alarm
		SB000406	FLASH 0: INIT Start, 1: Flash Operation
		SB000407	WEN 0: Writing disabled, 1: Writing enabled
		SB000408, SB000409	Reserved for system. -
		SB00040A	Flash Save Request from MPE720 0: Not saving data to flash memory 1: Saving data to flash memory
		SB00040B	Status of Synchronization with Main CPU Unit (Sub CPU Units only) 0: High-speed scans synchronized 1: High-speed scans not synchronized
		SB00040C	CPU Unit Mode 0: Main CPU Unit, 1: Sub CPU Unit
		SB00040D	Stop Operation Request from Main CPU Unit (Sub CPU Units only) 0: RUN selected, 1: STOP selected
		SB00040E	Operation Stop Request from MPE720 0: RUN selected, 1: STOP selected
		SB00040F	Run Switch Status at Power ON 0: STOP, 1: RUN
CPU Error Status	SW00041	SB000410	Serious Failure 0: Normal, 1: Serious failure
		SB000411, SB000412	Reserved for system. -
		SB000413	Exception Error 0: Normal, 1: Exception error
		SB000414 to SB000417	Reserved for system. -
		SB000418	User Operation Error 0: Normal, 1: User operation error
		SB000419	I/O Error 0: Normal, 1: I/O error
		SB00041A	MPU-01 Error 0: Normal, 1: MPU-01 error
		SB00041B	Sub CPU Unit Error (Main CPU Unit only) 0: Normal, 1: Sub CPU Unit error
		SB00041C	Reserved for system. -
		SB00041D	M-III Restrictions Error 0: Normal, 1: Restrictions error in MECHATROLINK-III communications cycle
		SB00041E	Fan Alarm 0: Normal, 1: Fan alarm
		SB00041F	Temperature Warning 0: Normal, 1: Temperature warning

Continued on next page.

Continued from previous page.

Name	Register Address		Contents	
H Scan Exceeded Counter	SW00044		H Scan Exceeded Count	
L Scan Exceeded Counter	SW00046		L Scan Exceeded Count	
Reserved for system.	SW00047	SB000470 to SB00047F	Reserved for system.	–
Hardware Configuration Status	SW00048	SB000480	D-RST	Mode switch 1 setting status: 0: OFF, 1: ON
		SB000481	LOAD	
		SB000482	CNFG	
		SB000483	INIT	
		SB000484	E-INIT	
		SB000485	STOP	
		SB000486	Reserved for system.	–
		SB000487	Battery Alarm	–
		SB000488, SB000489	Reserved for system.	–
		SB00048A	MNT	Mode switch 2 setting status: 0: OFF, 1: ON
		SB00048B	TEST	
		SB00048C	E-PM1	
		SB00048D	E-PM0	–
SB00048E, SB00048F	Reserved for system.	–		
Reserved for system.	SW00049	Reserved for system.		–

### ◆ System Error Status

The data in these registers give the error status of the system.

Name	Register Address	Contents	
32-bit Error Code	SW00050	0001 hex	Watchdog timeout error
		0051 hex	Module synchronization error
		0052 hex	Main CPU Unit System Down Detection (Sub CPU Units only)
	SW00051	For system error analysis	
32-bit Error Address	SW00052 and SW00053	For system error analysis	
Program Error Task	SW00054	0000 hex	system
		0001 hex	DWGA
		0002 hex	DWGI
		0003 hex	DWGH
		0005 hex	DWGL

Continued on next page.

Continued from previous page.

Name	Register Address	Contents	
Program Type	SW00055	0000 hex	system
		0001 hex	DWGA
		0002 hex	DWGI
		0003 hex	DWGH
		0005 hex	DWGL
		0008 hex	Function
		000F hex	Motion program or sequence program
Program Error Drawing Number	SW00056	FFFF hex	Ladder program parent drawing
		8000 hex	Ladder program function
		□□00 hex	Ladder program child drawing (□□ hex: Child drawing No.)
		□□□□ hex	Ladder program grandchild drawing □□□□ hex └──┬── Grandchild drawing number └──┬── Child drawing number
		F□□□ hex	Motion program or sequence program (□□□ hex: Program No.)
Drawing Type of Calling Program	SW00057	Type of the calling drawing in which the error occurred	
		0001 hex	DWGA
		0002 hex	DWGI
		0003 hex	DWGH
		0005 hex	DWGL
		0008 hex	Function
		000F hex	Motion program/sequence program
Drawing No. of Calling Program	SW00058	Number of the calling drawing in which the error occurred	
		FFFF hex	Parent drawing
		8000 hex	Function
		□□00 hex	Child drawing (□□ hex: Child drawing No.)
		xxyy hex	Grandchild drawing (xx hex: Child drawing No., yy hex: Grandchild drawing No.)
Drawing Step No. in Calling Program	SW00059	Step Number in the Calling Drawing in Which the Error Occurred This is set to 0 if the error occurs in the parent drawing.	



Continued on next page.

Continued from previous page.

Name	Register Address	Contents	
Error Data	SW00060 and SW00061	Reserved for system.	
	SW00062 to SW00065	Name of task that caused the error	
	SW00066 and SW00067	Reserved for system.	
	SW00068	Year When Error Occurred	
	SW00069	Month When Error Occurred	
	SW00070	Day of Week When Error Occurred	
	SW00071	Day When Error Occurred	
	SW00072	Hour When Error Occurred	
	SW00073	Minutes When Error Occurred	
	SW00074	Seconds When Error Occurred	
	SW00075	Milliseconds When Error Occurred	
	SW00076	xyzz hex	Slot Where the Module Synchronization Error Was Detected (x: Rack number from 1 to 7, y: unit number from 1 to 4, zz: slot number from 01 to 09)
	SW00077 to SW00079	Reserved for system.	

### ◆ User Operation Error Status

The data in these registers give details when an operation error occurs in a user program.

Drawing Type	Error Description	Register Address	Contents
DWGA	Error Count	SW00080	<ul style="list-style-type: none"> <li>Error Count</li> </ul> Gives the number of errors that have occurred.
	Error Code	SW00081	
DWGI	Error Count	SW00082	<ul style="list-style-type: none"> <li>Error Code</li> </ul> Gives the details of the error.
	Error Code	SW00083	
DWGH	Error Count	SW00084	0□□□ hex: Operation error  ■ User Operation Error Code -1: Operation Errors (page 4-23)
	Error Code	SW00085	
Reserved for system.		SW00086, SW00087	x□□□ hex (x = 1, 2, 3): Index error  ■ User Operation Error Code -2: Index Errors (page 4-24)
DWGL	Error Count	SW00088	
	Error Code	SW00089	

■ User Operation Error Code –1: Operation Errors

	Error Code	Error Description	Operation When an Error Occurs*		
Integer Operations	0001 hex	Integer operation underflow	[-32768]		
	0002 hex	Integer operation overflow	[32767]		
	0003 hex	Integer operation division error	[The A register stays the same.]		
	0009 hex	Double-length integer operation underflow	[-2147483648]		
	000A hex	Double-length integer operation overflow	[2147483647]		
	000B hex	Double-length integer operation division error	[The A register stays the same.]		
	000C hex	Quadruple-length integer operation underflow	[-9223372036854775808]		
	000D hex	Quadruple-length integer operation overflow	[9223372036854775807]		
	000E hex	Quadruple-length integer operation division error	[The A register stays the same.]		
	0101 hex to 010E hex	Integer operation error in Operation Error Drawing	[The A register stays the same.]		
Real Number Operations	0010 hex	Non-numerical integer storage error	Data is not stored. [00000]		
	0011 hex	Integer storage underflow	Data is not stored. [-32768]		
	0012 hex	Integer storage overflow	Data is not stored. [+32767]		
	0021 hex	Real number storage underflow	Data is not stored. [-1.0E+38]		
	0022 hex	Real number storage overflow	Data is not stored. [1.0E+38]		
	0023 hex	Real number operation division by zero error	Data is not stored. [F register stays the same]		
	0030 hex	Invalid real number operation (non-numeric)	Data is not stored.		
	0031 hex	Real number operation exponent underflow	0.0		
	0032 hex	Real number operation exponent overflow	Maximum Value		
	0033 hex	Real number operation division error (0/0)	Operation is not executed.		
	0034 hex	Real number storage exponent underflow	Stores 0.0.		
	0040 hex to 0059 hex	Real number operation error in standard system function		Operation is aborted and output is set to 0.0.	
		0040 hex: SQRT	0047 hex: EXP	004E hex: PD	0055 hex: SLAU
		0041 hex: SIN	0048 hex: LN	004F hex: PID	0056 hex: REM
0042 hex: COS		0049 hex: LOG	0050 hex: LAG	0057 hex: RCHK	
0043 hex: TAN		004A hex: DZA	0051 hex: LLAG	0058 hex: BSRCH	
0044 hex: ASIN		004B hex: DZB	0052 hex: FGN	0059 hex: SORT	
0045 hex: ACOS		004C hex: LIM	0053 hex: IFGN	—	
0046 hex: ATAN		004D hex: PI	0054 hex: LAU	—	

\* The numeric values given in brackets [ ] are set by the system in the Changed A Register or Changed F Register before the operation error drawing is executed.

### ■ User Operation Error Code –2: Index Errors

	Error Code	Error Description	Operation When an Error Occurs		
Integer and Real Number Operations	1000 hex	Index error in drawing	Re-executed as if i and j were set to 0. (Both i and j registers stay the same.)		
	2000 hex	Index error in function	Re-executed as if i and j were set to 0. (Both i and j registers stay the same.)		
	3000 hex	Index error in motion program or sequence program	Re-executed as if i and j were set to 0. (Both i and j registers stay the same.)		
Real Number Operations	x040 hex to x059 hex (x=1,2,3)	Real number operation error in standard system function	Operation is aborted and output is set to 0.0.		
		x040 hex: SQRT	x047 hex: EXP	x04E hex: PD	x055 hex: SLAU
		x041 hex: SIN	x048 hex: LN	x04F hex: PID	x056 hex: REM
		x042 hex: COS	x049 hex: LOG	x050 hex: LAG	x057 hex: RCHK
		x043 hex: TAN	x04A hex: DZA	x051 hex: LLAG	x058 hex: BSRCH
		x044 hex: ASIN	x04B hex: DZB	x052 hex: FGN	x059 hex: SORT
		x045 hex: ACOS	x04C hex: LIM	x053 hex: IFGN	-
		x046 hex: ATAN	x04D hex: PI	x054 hex: LAU	
Integer Operations	x060 hex to x0C9 hex (x=1,2,3)	Integer operation error in standard system function	Operation is aborted and output is set to input. [A register stays the same.]		
		x06D hex: PI	x091 hex: ROTR	x0A0 hex: BEXTEND	x0B1 hex: SPEND
		x06E hex: PD	x092 hex: MOV B	x0A1 hex: BPRESS	x0C0 hex: TBLBR
		x06F hex: PID	x093 hex: MOV W	x0A2 hex: SORT	x0C1 hex: TBLBW
		x070 hex: LAG	x094 hex: SETW	x0A4 hex: SORT	x0C2 hex: TBL SRL
		x071 hex: LLAG	x095 hex: XCHG	x0A6 hex: RCHK	x0C3 hex: TBL SRC
		x072 hex: FGN	x096 hex: LIMIT	x0A7 hex: RCHK	x0C4 hex: TBL CL
		x073 hex: IFGN	x097 hex: LIMIT	x0A8 hex: COPYW	x0C5 hex: TBL MW
		x074 hex: LAU	x098 hex: DZA	x0A9 hex: ASCII	x0C6 hex: QTBLR
		x075 hex: SLAU	x099 hex: DZA	x0AA hex: BINASC	x0C7 hex: QTBLRI
		x076 hex: FGN	x09A hex: DZB	x0AB hex: ASCBIN	x0C8 hex: QTBLW
		x077 hex: IFGN	x09B hex: DZB	x0AC hex: BSRCH	x0C9 hex: QTBLWI
		x08E hex: INS	x09C hex: PWM	x0AD hex: BSRCH	-
		x08F hex: OUTS	x09E hex: SHFTL	x0AE hex: TIMEADD	
		x090 hex: ROTL	x09F hex: SHFTR	x0AF hex: TIMSUB	

### ◆ Detailed User Operation Error Status

The data in these registers give details when a user operation error occurs in a user program.

Name	Register Address				Remarks
	DWG.A	DWG.I	DWG.H	DWG.L	
Error Count	SW00110	SW00126	SW00142	SW00174	<ul style="list-style-type: none"> <li>Error Drawing No. FFFF hex: Parent drawing □□00 hex: Child drawing (□□ hex: Child drawing No.) xxyy hex: Grandchild drawing (xx hex: Child drawing No., yy hex: Grandchild drawing No.) 8000 hex: Function F□□□ hex: Motion program or sequence program (□□□ hex: Program No.)</li> <li>Calling Drawing No. Number of the calling drawing in which the operation error occurred</li> <li>Calling Drawing Step No. Step number in the calling drawing in which the operation error occurred This number is set to 0 if the error occurs in the parent drawing.</li> <li>Error Step No. Step number when the operation error occurred</li> </ul>
Error Code	SW00111	SW00127	SW00143	SW00175	
Error A Registers	SW00112	SW00128	SW00144	SW00176	
	SW00113	SW00129	SW00145	SW00177	
Changed A Registers	SW00114	SW00130	SW00146	SW00178	
	SW00115	SW00131	SW00147	SW00179	
Error F Registers	SW00116	SW00132	SW00148	SW00180	
	SW00117	SW00133	SW00149	SW00181	
Changed F Registers	SW00118	SW00134	SW00150	SW00182	
	SW00119	SW00135	SW00151	SW00183	
Address Where Error Occurred	SW00120	SW00136	SW00152	SW00184	
	SW00121	SW00137	SW00153	SW00185	
Error Drawing No.	SW00122	SW00138	SW00154	SW00186	
Calling Drawing No.	SW00123	SW00139	SW00155	SW00187	
Calling Drawing Step No.	SW00124	SW00140	SW00156	SW00188	
Error Step No.	SW00125	SW00141	SW00157	SW00189	

### ◆ System Service Execution Status

The data in these registers give the execution status of the system.

Name	Register Address		Remarks
Reserved for system.	SW00090 to SW00097		—
Data Trace Definition Existence	SW00098	SB000980	Group 1
		SB000981	Group 2
		SB000982	Group 3
		SB000983	Group 4
		SB000984 to SB00098F	Reserved for system.
Data Trace Execution Status	SW00099	SB000990	Group 1
		SB000991	Group 2
		SB000992	Group 3
		SB000993	Group 4
		SB000994 to SB00099F	Reserved for system.
Group 1 Record No.	SW00100		Latest record number in group 1.
Group 2 Record No.	SW00101		Latest record number in group 2.
Group 3 Record No.	SW00102		Latest record number in group 3.
Group 4 Record No.	SW00103		Latest record number in group 4.

### ◆ System I/O Error Status

The data in these registers give the I/O errors in the system for Racks 1 to 4.

The details of the error status depend on the Modules that are mounted and the error code. Refer to the following manual for details.

📖 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

Name	Register Address	Remarks
I/O Error Count	SW00200	Number of I/O error occurrences
Input Error Count	SW00201	Number of input error occurrences
Input Error Address	SW00202	Latest input error address (register address in IW□□□□)
Output Error Count	SW00203	Number of output error occurrences
Output Error Address	SW00204	Latest output error address (register address in OW□□□□)
Reserved for system.	SW00205 to SW00207	–
I/O Error Status	SW00208 to SW00215	Error status of Rack 1, Slot 0
	SW00216 to SW00223	Reserved for system.
	SW00224 to SW00231	Error status of Rack 1, Slot 1 (Depends on the Module that is mounted and the error code.)
	SW00232 to SW00239	Error status of Rack 1, Slot 2 (Depends on the Modules that are mounted and the error code.)
	SW00240 to SW00247	Error status of Rack 1, Slot 3 (Depends on the Modules that are mounted and the error code.)
	SW00248 to SW00255	Error status of Rack 1, Slot 4 (Depends on the Modules that are mounted and the error code.)
	⋮	⋮
	SW00496 to SW00503	Error status of Rack 4, Slot 9 (Depends on the Modules that are mounted and the error code.)

**Information** The I/O error status data for Racks 5 to 7 is stored in SW10628 to SW13699. Refer to the following section for details.

📖 ◆ *Expansion System I/O Error Status* (page 4-55)

### ◆ Security Status

The data in these registers give the status of CPU Unit security.

Name	Register Address	Contents	
Security Status	SW00506	0: Security disabled, 1: Security enabled	
Security Read Protection Information	SW00507	SB005070 to SB005073	Restriction rights for file reading
		SB005074 to SB005076	Reserved for system.
		SB005077	File reading restriction
		SB005078 to SB00507F	Reserved for system.

□□□□ hex

Restriction rights level (0 to 7)  
Reserved for system.  
File reading restriction  
0: Not restricted  
1: Restricted  
Reserved for system.



### ◆ USB-related System Status

The data in these registers give information on the USB memory and give the error status.

Name	Register Address	Remarks
Available USB Memory	SL00650	Unit: Kilobytes
Total USB Memory	SL00652	
USB Status	SW00654	SB006540 0: No USB memory device 1: USB memory device inserted
		SB006541 0: Not supplying power 1: Supplying power
		SB006542 0: Cannot recognize USB memory device 1: Recognized USB memory device
		SB006543 0: Not accessing USB memory device 1: Accessing USB memory device
		SB006544 0: – 1: Checking FAT file system
		SB006545 to SB00654F Reserved for system.
FAT Type	SW00655	0002 hex   FAT16
		0003 hex   FAT32
Reserved for system.	SW00656 and SW00657	–
Batch Load and Batch Save	SW00658	SB006580 1: Batch load in progress
		SB006581 1: USB memory read error
		SB006582 1: Load file model mismatch error
		SB006583 1: Load file write error
		SB006584 1: Save to flash memory error
		SB006585 1: Folder for batch loading does not exist
		SB006586 1: Loading error due to program write protection
		SB006587 Reserved for system.
		SB006588 1: Batch save in progress
		SB006589 1: USB memory write error
		SB00658A 1: Save file read error
		SB00658B 1: Security error
SB00658C to SB00658F Reserved for system.		
Reserved for system.	SW00659 to SW00667	–

### ◆ Message Relaying Status


The data in these registers give the message relaying status in the CPU Unit.

Name	Register Address	Contents
Message Relaying Information	SW00694	Normally processed command message counter
	SW00695	Command message error counter
	SW00696	Normally processed response message counter
	SW00697	Response message error counter

## ◆ Interrupt Status



The data in these registers give the status of information provided by interrupts from each I/O Module.

### ■ Register Configuration

Name	Register Address	Remarks	
Interrupt Detection Count	SW00698	–	
Module Where an Interrupt Occurred	SW00699	Number of Modules with a single interrupt	
Interrupt Modules	SW00700 to SW00702	Interrupt Module 1	Refer to the following section for details.  ■ Details (page 4-28)
	SW00703 to SW00705	Interrupt Module 2	
	⋮	⋮	
	SW00787 to SW00789	Interrupt Module 30	

### ■ Details

The following table gives details on the Interrupt Module.

Register Address	Remarks
SW007□□ + 0	Rack No., Unit No., Slot No. □□□□ hex  <ul style="list-style-type: none"> <li>01 to 09: Gives the slot number where the Module in which the interrupt occurred is mounted.</li> <li>1 to 4: Gives the unit number of the Module in which the interrupt occurred is mounted.</li> <li>1 to 7: Gives the Rack number where the Module in which the interrupt occurred is mounted.</li> </ul>
SW007□□ + 1	Interrupt Type 1: Reserved for system. 2: DI interrupt for LIO-01, LIO-02, LIO-04, or LIO-05 3: Counter interrupt for LIO-01, LIO-02, LIO-06, or CNTR-01
SW007□□ + 2	Register value for hardware interrupt cause The contents depends on the hardware that is being used. Refer to the following manual for details.  MP3000 Series MP3200 Troubleshooting Manual (Manual No.: SIEP C880725 01)

### ◆ Module Information

The data in these registers give hardware information about the CPU Unit and Optional Modules on Racks 1 to 4.

Name	Register Address	Remarks			
CPU Unit Information	SW00800	CPU Module ID			
	SW00801	Hardware version (BCD)			
	SW00802	Software version (BCD)			
	SW00803	Number of sub-slots (hex)			
	SW00804	Function Module 1 ID (hex)			
	SW00805	Function Module 1 Status			
	SW00806	Function Module 2 ID (hex)			
	SW00807	Function Module 2 Status			
	SW00808	Function Module 3 ID (hex)			
	SW00809	Function Module 3 Status			
	SW00810	Function Module 4 ID (hex)			
	SW00811	Function Module 4 Status			
	SW00812	Function Module 5 ID (hex)			
	SW00813	Function Module 5 Status			
	SW00814	Function Module 6 ID (hex)			
SW00815	Function Module 6 Status				
Optional Module Information	SW00816	Rack 1	Unit 1	Slot 1	Module ID
	SW00817				Hardware version (BCD)
	SW00818				Software version (BCD)
	SW00819				Number of sub-slots
	SW00820				ID of Function Module 1
	SW00821				Status of Function Module 1
	SW00822				ID of Function Module 2
	SW00823				Status of Function Module 2
	SW00824 to SW00831			Slot 2	Same as above.
	SW00832 to SW00839			Slot 3	Same as above.
	SW00840 to SW00847			Slot 4	Same as above.
	SW00848 to SW00855			Slot 5	Same as above.
	SW00856 to SW00863			Slot 6	Same as above.
	SW00864 to SW00871			Slot 7	Same as above.
	SW00872 to SW00879			Slot 8	Same as above.
Reserved for system.	SW00880 to SW01095	—			

Continued on next page.

Continued from previous page.

Name	Register Address	Remarks			
Optional Module Information	SW00880 to SW00887	Rack 2	Unit 1	Slot 1	Same as above.
	SW00888 to SW00895			Slot 2	Same as above.
	SW00896 to SW00903			Slot 3	Same as above.
	SW00904 to SW00911			Slot 4	Same as above.
	SW00912 to SW00919			Slot 5	Same as above.
	SW00920 to SW00927			Slot 6	Same as above.
	SW00928 to SW00935			Slot 7	Same as above.
	SW00936 to SW00943			Slot 8	Same as above.
	SW00944 to SW00951			Reserved for system.	Reserved for system.
	SW00952 to SW00959	Rack 3	Unit 1	Slot 1	Same as above.
	SW00960 to SW00967			Slot 2	Same as above.
	SW00968 to SW00975			Slot 3	Same as above.
	SW00976 to SW00983			Slot 4	Same as above.
	SW00984 to SW00991			Slot 5	Same as above.
	SW00992 to SW00999			Slot 6	Same as above.
	SW01000 to SW01007			Slot 7	Same as above.
	SW01008 to SW01015			Slot 8	Same as above.
	SW01016 to SW01023			Reserved for system.	Reserved for system.
	SW01024 to SW01031	Rack 4	Unit 1	Slot 1	Same as above.
	SW01032 to SW01039			Slot 2	Same as above.
	SW01040 to SW01047			Slot 3	Same as above.
	SW01048 to SW01055			Slot 4	Same as above.
	SW01056 to SW01063			Slot 5	Same as above.
	SW01064 to SW01071			Slot 6	Same as above.
	SW01072 to SW01079			Slot 7	Same as above.
	SW01080 to SW01087			Slot 8	Same as above.
	SW01088 to SW01095			Reserved for system.	Reserved for system.

**Information**

The Optional Module information data for Racks 5 to 7 is stored in SW14260 to SW15795. Refer to the following section for details.

 *Expanded Unit and Module Information (page 4-59)*

### ◆ MPU-01 Module Status

The data in these registers give the status of the MPU-01 Multi-CPU Module.

Name	Register Address	Contents
MPU-01 Module Status	SW01411	Status of MPU-01 Module circuit number 1
	SW01412	Error status of MPU-01 Module circuit number 1
	SW01413	Status of MPU-01 Module circuit number 2
	SW01414	Error status of MPU-01 Module circuit number 2
	SW01415	Status of MPU-01 Module circuit number 3
	SW01416	Error status of MPU-01 Module circuit number 3
	SW01417	Status of MPU-01 Module circuit number 4
	SW01418	Error status of MPU-01 Module circuit number 4
	SW01419	Status of MPU-01 Module circuit number 5
	SW01420	Error status of MPU-01 Module circuit number 5
	SW01421	Status of MPU-01 Module circuit number 6
	SW01422	Error status of MPU-01 Module circuit number 6
	SW01423	Status of MPU-01 Module circuit number 7
	SW01424	Error status of MPU-01 Module circuit number 7
	SW01425	Status of MPU-01 Module circuit number 8
	SW01426	Error status of MPU-01 Module circuit number 8
	SW01427	Status of MPU-01 Module circuit number 9
	SW01428	Error status of MPU-01 Module circuit number 9
	SW01429	Status of MPU-01 Module circuit number 10
	SW01430	Error status of MPU-01 Module circuit number 10
	SW01431	Status of MPU-01 Module circuit number 11
	SW01432	Error status of MPU-01 Module circuit number 11
	SW01433	Status of MPU-01 Module circuit number 12
	SW01434	Error status of MPU-01 Module circuit number 12
	SW01435	Status of MPU-01 Module circuit number 13
	SW01436	Error status of MPU-01 Module circuit number 13
	SW01437	Status of MPU-01 Module circuit number 14
	SW01438	Error status of MPU-01 Module circuit number 14
	SW01439	Status of MPU-01 Module circuit number 15
	SW01440	Error status of MPU-01 Module circuit number 15
	SW01441	Status of MPU-01 Module circuit number 16
	SW01442	Error status of MPU-01 Module circuit number 16

## ◆ Motion Program Execution Information

The data in these registers give the execution status of the motion programs.

### ■ Register Configuration

Register Address	Name	Reference
SW03200	Number of Currently Executing Program for Work 1	–
SW03201	Number of Currently Executing Program for Work 2	–
SW03202	Number of Currently Executing Program for Work 3	–
SW03203	Number of Currently Executing Program for Work 4	–
SW03204	Number of Currently Executing Program for Work 5	–
SW03205	Number of Currently Executing Program for Work 6	–
SW03206	Number of Currently Executing Program for Work 7	–
SW03207	Number of Currently Executing Program for Work 8	–
SW03208	Number of Currently Executing Program for Work 9	–
SW03209	Number of Currently Executing Program for Work 10	–
SW03210	Number of Currently Executing Program for Work 11	–
SW03211	Number of Currently Executing Program for Work 12	–
SW03212	Number of Currently Executing Program for Work 13	–
SW03213	Number of Currently Executing Program for Work 14	–
SW03214	Number of Currently Executing Program for Work 15	–
SW03215	Number of Currently Executing Program for Work 16	–
SW03216	Number of Currently Executing Program for Work 17	–
SW03217	Number of Currently Executing Program for Work 18	–
SW03218	Number of Currently Executing Program for Work 19	–
SW03219	Number of Currently Executing Program for Work 20	–
SW03220	Number of Currently Executing Program for Work 21	–
SW03221	Number of Currently Executing Program for Work 22	–
SW03222	Number of Currently Executing Program for Work 23	–
SW03223	Number of Currently Executing Program for Work 24	–
SW03224	Number of Currently Executing Program for Work 25	–
SW03225	Number of Currently Executing Program for Work 26	–
SW03226	Number of Currently Executing Program for Work 27	–
SW03227	Number of Currently Executing Program for Work 28	–
SW03228	Number of Currently Executing Program for Work 29	–
SW03229	Number of Currently Executing Program for Work 30	–
SW03230	Number of Currently Executing Program for Work 31	–
SW03231	Number of Currently Executing Program for Work 32	–
SW03232 to SW03263	Program Running Bits	■ <i>Details (page 4-35)</i>
SW03264 to SW03321	Work 1 Program Information	System Work Numbers 1 to 8 (page 4-46)
SW03322 to SW03379	Work 2 Program Information	
SW03380 to SW03437	Work 3 Program Information	
SW03438 to SW03495	Work 4 Program Information	
SW03496 to SW03553	Work 5 Program Information	
SW03554 to SW03611	Work 6 Program Information	
SW03612 to SW03669	Work 7 Program Information	
SW03670 to SW03727	Work 8 Program Information	

Continued on next page.

Continued from previous page.

Register Address	Name	Reference
SW03728 to SW03785	Work 9 Program Information	<i>System Work Numbers 9 to 16 (page 4-49)</i>
SW03786 to SW03843	Work 10 Program Information	
SW03844 to SW03901	Work 11 Program Information	
SW03902 to SW03959	Work 12 Program Information	
SW03960 to SW04017	Work 13 Program Information	
SW04018 to SW04075	Work 14 Program Information	
SW04076 to SW04133	Work 15 Program Information	
SW04134 to SW04191	Work 16 Program Information	
SW04192 to SW04249	Work 17 Program Information	<i>System Work Numbers 17 to 24 (page 4-51)</i>
SW04250 to SW04307	Work 18 Program Information	
SW04308 to SW04365	Work 19 Program Information	
SW04366 to SW04423	Work 20 Program Information	
SW04424 to SW04481	Work 21 Program Information	
SW04482 to SW04539	Work 22 Program Information	
SW04540 to SW04597	Work 23 Program Information	
SW04598 to SW04655	Work 24 Program Information	
SW04656 to SW04713	Work 25 Program Information	<i>System Work Numbers 25 to 32 (page 4-53)</i>
SW04714 to SW04771	Work 26 Program Information	
SW04772 to SW04829	Work 27 Program Information	
SW04830 to SW04887	Work 28 Program Information	
SW04888 to SW04945	Work 29 Program Information	
SW04946 to SW05003	Work 30 Program Information	
SW05004 to SW05061	Work 31 Program Information	
SW05062 to SW05119	Work 32 Program Information	
SW08192 to SW08223	Work 1 Extended Program Information	<i>System Work Numbers 1 to 8 (page 4-46)</i>
SW08224 to SW08255	Work 2 Extended Program Information	
SW08256 to SW08287	Work 3 Extended Program Information	
SW08288 to SW08319	Work 4 Extended Program Information	
SW08320 to SW08351	Work 5 Extended Program Information	
SW08352 to SW08383	Work 6 Extended Program Information	
SW08384 to SW08415	Work 7 Extended Program Information	
SW08416 to SW08447	Work 8 Extended Program Information	
SW08448 to SW08479	Work 9 Extended Program Information	<i>System Work Numbers 9 to 16 (page 4-49)</i>
SW08480 to SW08511	Work 10 Extended Program Information	
SW08512 to SW08543	Work 11 Extended Program Information	
SW08544 to SW08575	Work 12 Extended Program Information	
SW08576 to SW08607	Work 13 Extended Program Information	
SW08608 to SW08639	Work 14 Extended Program Information	
SW08640 to SW08671	Work 15 Extended Program Information	
SW08672 to SW08703	Work 16 Extended Program Information	
SW08704 to SW08735	Work 17 Extended Program Information	<i>System Work Numbers 17 to 24 (page 4-51)</i>
SW08736 to SW08767	Work 18 Extended Program Information	
SW08768 to SW08799	Work 19 Extended Program Information	
SW08800 to SW08831	Work 20 Extended Program Information	
SW08832 to SW08863	Work 21 Extended Program Information	
SW08864 to SW08895	Work 22 Extended Program Information	
SW08896 to SW08927	Work 23 Extended Program Information	
SW08928 to SW08959	Work 24 Extended Program Information	

Continued on next page.

Continued from previous page.

Register Address	Name	Reference
SW08960 to SW08991	Work 25 Extended Program Information	<i>System Work Numbers 25 to 32 (page 4-53)</i>
SW08992 to SW09023	Work 26 Extended Program Information	
SW09024 to SW09055	Work 27 Extended Program Information	
SW09056 to SW09087	Work 28 Extended Program Information	
SW09088 to SW09119	Work 29 Extended Program Information	
SW09120 to SW09151	Work 30 Extended Program Information	
SW09152 to SW09183	Work 31 Extended Program Information	
SW09184 to SW09215	Work 32 Extended Program Information	



■ Details

The following table gives details on the Program Execution Bits from system register addresses SW03232 to SW03263.

Register Address	Contents		
SW03232	SB032320	MPM001 or MPS001	0: – 1: Program running
	SB032321	MPM002 or MPS002	
	SB032322	MPM003 or MPS003	
	SB032323	MPM004 or MPS004	
	SB032324	MPM005 or MPS005	
	SB032325	MPM006 or MPS006	
	SB032326	MPM007 or MPS007	
	SB032327	MPM008 or MPS008	
	SB032328	MPM009 or MPS009	
	SB032329	MPM010 or MPS010	
	SB03232A	MPM011 or MPS011	
	SB03232B	MPM012 or MPS012	
	SB03232C	MPM013 or MPS013	
	SB03232D	MPM014 or MPS014	
	SB03232E	MPM015 or MPS015	
	SB03232F	MPM016 or MPS016	
SW03233	SB032330	MPM017 or MPS017	
	SB032331	MPM018 or MPS018	
	SB032332	MPM019 or MPS019	
	SB032333	MPM020 or MPS020	
	SB032334	MPM021 or MPS021	
	SB032335	MPM022 or MPS022	
	SB032336	MPM023 or MPS023	
	SB032337	MPM024 or MPS024	
	SB032338	MPM025 or MPS025	
	SB032339	MPM026 or MPS026	
	SB03233A	MPM027 or MPS027	
	SB03233B	MPM028 or MPS028	
	SB03233C	MPM029 or MPS029	
	SB03233D	MPM030 or MPS030	
	SB03233E	MPM031 or MPS031	
	SB03233F	MPM032 or MPS032	

Continued on next page.

Continued from previous page.

Register Address	Contents		
SW03234	SB032340	MPM033 or MPS033	0: – 1: Program running
	SB032341	MPM034 or MPS034	
	SB032342	MPM035 or MPS035	
	SB032343	MPM036 or MPS036	
	SB032344	MPM037 or MPS037	
	SB032345	MPM038 or MPS038	
	SB032346	MPM039 or MPS039	
	SB032347	MPM040 or MPS040	
	SB032348	MPM041 or MPS041	
	SB032349	MPM042 or MPS042	
	SB03234A	MPM043 or MPS043	
	SB03234B	MPM044 or MPS044	
	SB03234C	MPM045 or MPS045	
	SB03234D	MPM046 or MPS046	
	SB03234E	MPM047 or MPS047	
SB03234F	MPM048 or MPS048		
SW03235	SB032350	MPM049 or MPS049	
	SB032351	MPM050 or MPS050	
	SB032352	MPM051 or MPS051	
	SB032353	MPM052 or MPS052	
	SB032354	MPM053 or MPS053	
	SB032355	MPM054 or MPS054	
	SB032356	MPM055 or MPS055	
	SB032357	MPM056 or MPS056	
	SB032358	MPM057 or MPS057	
	SB032359	MPM058 or MPS058	
	SB03235A	MPM059 or MPS059	
	SB03235B	MPM060 or MPS060	
	SB03235C	MPM061 or MPS061	
	SB03235D	MPM062 or MPS062	
	SB03235E	MPM063 or MPS063	
SB03235F	MPM064 or MPS064		
SW03236	SB032360	MPM065 or MPS065	
	SB032361	MPM066 or MPS066	
	SB032362	MPM067 or MPS067	
	SB032363	MPM068 or MPS068	
	SB032364	MPM069 or MPS069	
	SB032365	MPM070 or MPS070	
	SB032366	MPM071 or MPS071	
	SB032367	MPM072 or MPS072	
	SB032368	MPM073 or MPS073	
	SB032369	MPM074 or MPS074	
	SB03236A	MPM075 or MPS075	
	SB03236B	MPM076 or MPS076	
	SB03236C	MPM077 or MPS077	
	SB03236D	MPM078 or MPS078	
	SB03236E	MPM079 or MPS079	
SB03236F	MPM080 or MPS080		

Continued on next page.

Continued from previous page.

Register Address	Contents		
SW03237	SB032370	MPM081 or MPS081	
	SB032371	MPM082 or MPS082	
	SB032372	MPM083 or MPS083	
	SB032373	MPM084 or MPS084	
	SB032374	MPM085 or MPS085	
	SB032375	MPM086 or MPS086	
	SB032376	MPM087 or MPS087	
	SB032377	MPM088 or MPS088	
	SB032378	MPM089 or MPS089	
	SB032379	MPM090 or MPS090	
	SB03237A	MPM091 or MPS091	
	SB03237B	MPM092 or MPS092	
	SB03237C	MPM093 or MPS093	
	SB03237D	MPM094 or MPS094	
	SB03237E	MPM095 or MPS095	
SB03237F	MPM096 or MPS096	0: – 1: Program running	
SW03238	SB032380		MPM097 or MPS097
	SB032381		MPM098 or MPS098
	SB032382		MPM099 or MPS099
	SB032383		MPM100 or MPS100
	SB032384		MPM101 or MPS101
	SB032385		MPM102 or MPS102
	SB032386		MPM103 or MPS103
	SB032387		MPM104 or MPS104
	SB032388		MPM105 or MPS105
	SB032389		MPM106 or MPS106
	SB03238A		MPM107 or MPS107
	SB03238B		MPM108 or MPS108
	SB03238C		MPM109 or MPS109
	SB03238D		MPM110 or MPS110
	SB03238E	MPM111 or MPS111	
SB03238F	MPM112 or MPS112		
SW03239	SB032390		MPM113 or MPS113
	SB032391		MPM114 or MPS114
	SB032392		MPM115 or MPS115
	SB032393		MPM116 or MPS116
	SB032394		MPM117 or MPS117
	SB032395		MPM118 or MPS118
	SB032396		MPM119 or MPS119
	SB032397		MPM120 or MPS120
	SB032398		MPM121 or MPS121
	SB032399		MPM122 or MPS122
	SB03239A		MPM123 or MPS123
	SB03239B		MPM124 or MPS124
	SB03239C		MPM125 or MPS125
	SB03239D		MPM126 or MPS126
	SB03239E	MPM127 or MPS127	
SB03239F	MPM128 or MPS128		

Continued on next page.

Continued from previous page.

Register Address		Contents	
SW03240	SB032400	MPM129 or MPS129	
	SB032401	MPM130 or MPS130	
	SB032402	MPM131 or MPS131	
	SB032403	MPM132 or MPS132	
	SB032404	MPM133 or MPS133	
	SB032405	MPM134 or MPS134	
	SB032406	MPM135 or MPS135	
	SB032407	MPM136 or MPS136	
	SB032408	MPM137 or MPS137	
	SB032409	MPM138 or MPS138	
	SB03240A	MPM139 or MPS139	
	SB03240B	MPM140 or MPS140	
	SB03240C	MPM141 or MPS141	
	SB03240D	MPM142 or MPS142	
	SB03240E	MPM143 or MPS143	
SB03240F	MPM144 or MPS144		
SW03241	SB032410	MPM145 or MPS145	
	SB032411	MPM146 or MPS146	
	SB032412	MPM147 or MPS147	
	SB032413	MPM148 or MPS148	
	SB032414	MPM149 or MPS149	
	SB032415	MPM150 or MPS150	
	SB032416	MPM151 or MPS151	
	SB032417	MPM152 or MPS152	
	SB032418	MPM153 or MPS153	
	SB032419	MPM154 or MPS154	
	SB03241A	MPM155 or MPS155	
	SB03241B	MPM156 or MPS156	
	SB03241C	MPM157 or MPS157	
	SB03241D	MPM158 or MPS158	
	SB03241E	MPM159 or MPS159	
SB03241F	MPM160 or MPS160		
SW03242	SB032420	MPM161 or MPS161	
	SB032421	MPM162 or MPS162	
	SB032422	MPM163 or MPS163	
	SB032423	MPM164 or MPS164	
	SB032424	MPM165 or MPS165	
	SB032425	MPM166 or MPS166	
	SB032426	MPM167 or MPS167	
	SB032427	MPM168 or MPS168	
	SB032428	MPM169 or MPS169	
	SB032429	MPM170 or MPS170	
	SB03242A	MPM171 or MPS171	
	SB03242B	MPM172 or MPS172	
	SB03242C	MPM173 or MPS173	
	SB03242D	MPM174 or MPS174	
	SB03242E	MPM175 or MPS175	
SB03242F	MPM176 or MPS176		

0: –  
1: Program running

Continued on next page.

Continued from previous page.

Register Address	Contents		
SW03243	SB032430	MPM177 or MPS177	0: – 1: Program running
	SB032431	MPM178 or MPS178	
	SB032432	MPM179 or MPS179	
	SB032433	MPM180 or MPS180	
	SB032434	MPM181 or MPS181	
	SB032435	MPM182 or MPS182	
	SB032436	MPM183 or MPS183	
	SB032437	MPM184 or MPS184	
	SB032438	MPM185 or MPS185	
	SB032439	MPM186 or MPS186	
	SB03243A	MPM187 or MPS187	
	SB03243B	MPM188 or MPS188	
	SB03243C	MPM189 or MPS189	
	SB03243D	MPM190 or MPS190	
	SB03243E	MPM191 or MPS191	
SB03243F	MPM192 or MPS192		
SW03244	SB032440	MPM193 or MPS193	
	SB032441	MPM194 or MPS194	
	SB032442	MPM195 or MPS195	
	SB032443	MPM196 or MPS196	
	SB032444	MPM197 or MPS197	
	SB032445	MPM198 or MPS198	
	SB032446	MPM199 or MPS199	
	SB032447	MPM200 or MPS200	
	SB032448	MPM201 or MPS201	
	SB032449	MPM202 or MPS202	
	SB03244A	MPM203 or MPS203	
	SB03244B	MPM204 or MPS204	
	SB03244C	MPM205 or MPS205	
	SB03244D	MPM206 or MPS206	
	SB03244E	MPM207 or MPS207	
SB03244F	MPM208 or MPS208		
SW03245	SB032450	MPM209 or MPS209	
	SB032451	MPM210 or MPS210	
	SB032452	MPM211 or MPS211	
	SB032453	MPM212 or MPS212	
	SB032454	MPM213 or MPS213	
	SB032455	MPM214 or MPS214	
	SB032456	MPM215 or MPS215	
	SB032457	MPM216 or MPS216	
	SB032458	MPM217 or MPS217	
	SB032459	MPM218 or MPS218	
	SB03245A	MPM219 or MPS219	
	SB03245B	MPM220 or MPS220	
	SB03245C	MPM221 or MPS221	
	SB03245D	MPM222 or MPS222	
	SB03245E	MPM223 or MPS223	
SB03245F	MPM224 or MPS224		

Continued on next page.

Continued from previous page.

Register Address	Contents		
SW03246	SB032460	MPM225 or MPS225	0: – 1: Program running
	SB032461	MPM226 or MPS226	
	SB032462	MPM227 or MPS227	
	SB032463	MPM228 or MPS228	
	SB032464	MPM229 or MPS229	
	SB032465	MPM230 or MPS230	
	SB032466	MPM231 or MPS231	
	SB032467	MPM232 or MPS232	
	SB032468	MPM233 or MPS233	
	SB032469	MPM234 or MPS234	
	SB03246A	MPM235 or MPS235	
	SB03246B	MPM236 or MPS236	
	SB03246C	MPM237 or MPS237	
	SB03246D	MPM238 or MPS238	
	SB03246E	MPM239 or MPS239	
SB03246F	MPM240 or MPS240		
SW03247	SB032470	MPM241 or MPS241	
	SB032471	MPM242 or MPS242	
	SB032472	MPM243 or MPS243	
	SB032473	MPM244 or MPS244	
	SB032474	MPM245 or MPS245	
	SB032475	MPM246 or MPS246	
	SB032476	MPM247 or MPS247	
	SB032477	MPM248 or MPS248	
	SB032478	MPM249 or MPS249	
	SB032479	MPM250 or MPS250	
	SB03247A	MPM251 or MPS251	
	SB03247B	MPM252 or MPS252	
	SB03247C	MPM253 or MPS253	
	SB03247D	MPM254 or MPS254	
	SB03247E	MPM255 or MPS255	
SB03247F	MPM256 or MPS256		
SW03248	SB032480	MPM257 or MPS257	
	SB032481	MPM258 or MPS258	
	SB032482	MPM259 or MPS259	
	SB032483	MPM260 or MPS260	
	SB032484	MPM261 or MPS261	
	SB032485	MPM262 or MPS262	
	SB032486	MPM263 or MPS263	
	SB032487	MPM264 or MPS264	
	SB032488	MPM265 or MPS265	
	SB032489	MPM266 or MPS266	
	SB03248A	MPM267 or MPS267	
	SB03248B	MPM268 or MPS268	
	SB03248C	MPM269 or MPS269	
	SB03248D	MPM270 or MPS270	
	SB03248E	MPM271 or MPS271	
SB03248F	MPM272 or MPS272		

Continued on next page.

Continued from previous page.

Register Address	Contents		
SW03249	SB032490	MPM273 or MPS273	0: – 1: Program running
	SB032491	MPM274 or MPS274	
	SB032492	MPM275 or MPS275	
	SB032493	MPM276 or MPS276	
	SB032494	MPM277 or MPS277	
	SB032495	MPM278 or MPS278	
	SB032496	MPM279 or MPS279	
	SB032497	MPM280 or MPS280	
	SB032498	MPM281 or MPS281	
	SB032499	MPM282 or MPS282	
	SB03249A	MPM283 or MPS283	
	SB03249B	MPM284 or MPS284	
	SB03249C	MPM285 or MPS285	
	SB03249D	MPM286 or MPS286	
	SB03249E	MPM287 or MPS287	
SB03249F	MPM288 or MPS288		
SW03250	SB032500	MPM289 or MPS289	
	SB032501	MPM290 or MPS290	
	SB032502	MPM291 or MPS291	
	SB032503	MPM292 or MPS292	
	SB032504	MPM293 or MPS293	
	SB032505	MPM294 or MPS294	
	SB032506	MPM295 or MPS295	
	SB032507	MPM296 or MPS296	
	SB032508	MPM297 or MPS297	
	SB032509	MPM298 or MPS298	
	SB03250A	MPM299 or MPS299	
	SB03250B	MPM300 or MPS300	
	SB03250C	MPM301 or MPS301	
	SB03250D	MPM302 or MPS302	
	SB03250E	MPM303 or MPS303	
SB03250F	MPM304 or MPS304		
SW03251	SB032510	MPM305 or MPS305	
	SB032511	MPM306 or MPS306	
	SB032512	MPM307 or MPS307	
	SB032513	MPM308 or MPS308	
	SB032514	MPM309 or MPS309	
	SB032515	MPM310 or MPS310	
	SB032516	MPM311 or MPS311	
	SB032517	MPM312 or MPS312	
	SB032518	MPM313 or MPS313	
	SB032519	MPM314 or MPS314	
	SB03251A	MPM315 or MPS315	
	SB03251B	MPM316 or MPS316	
	SB03251C	MPM317 or MPS317	
	SB03251D	MPM318 or MPS318	
	SB03251E	MPM319 or MPS319	
SB03251F	MPM320 or MPS320		

Continued on next page.

Continued from previous page.

Register Address		Contents	
SW03252	SB032520	MPM321 or MPS321	0: – 1: Program running
	SB032521	MPM322 or MPS322	
	SB032522	MPM323 or MPS323	
	SB032523	MPM324 or MPS324	
	SB032524	MPM325 or MPS325	
	SB032525	MPM326 or MPS326	
	SB032526	MPM327 or MPS327	
	SB032527	MPM328 or MPS328	
	SB032528	MPM329 or MPS329	
	SB032529	MPM330 or MPS330	
	SB03252A	MPM331 or MPS331	
	SB03252B	MPM332 or MPS332	
	SB03252C	MPM333 or MPS333	
	SB03252D	MPM334 or MPS334	
	SB03252E	MPM335 or MPS335	
SB03252F	MPM336 or MPS336		
SW03253	SB032530	MPM337 or MPS337	
	SB032531	MPM338 or MPS338	
	SB032532	MPM339 or MPS339	
	SB032533	MPM340 or MPS340	
	SB032534	MPM341 or MPS341	
	SB032535	MPM342 or MPS342	
	SB032536	MPM343 or MPS343	
	SB032537	MPM344 or MPS344	
	SB032538	MPM345 or MPS345	
	SB032539	MPM346 or MPS346	
	SB03253A	MPM347 or MPS347	
	SB03253B	MPM348 or MPS348	
	SB03253C	MPM349 or MPS349	
	SB03253D	MPM350 or MPS350	
	SB03253E	MPM351 or MPS351	
SB03253F	MPM352 or MPS352		
SW03254	SB032540	MPM353 or MPS353	
	SB032541	MPM354 or MPS354	
	SB032542	MPM355 or MPS355	
	SB032543	MPM356 or MPS356	
	SB032544	MPM357 or MPS357	
	SB032545	MPM358 or MPS358	
	SB032546	MPM359 or MPS359	
	SB032547	MPM360 or MPS360	
	SB032548	MPM361 or MPS361	
	SB032549	MPM362 or MPS362	
	SB03254A	MPM363 or MPS363	
	SB03254B	MPM364 or MPS364	
	SB03254C	MPM365 or MPS365	
	SB03254D	MPM366 or MPS366	
	SB03254E	MPM367 or MPS367	
SB03254F	MPM368 or MPS368		

Continued on next page.



Continued from previous page.

Register Address	Contents		
SW03255	SB032550	MPM369 or MPS369	0: – 1: Program running
	SB032551	MPM370 or MPS370	
	SB032552	MPM371 or MPS371	
	SB032553	MPM372 or MPS372	
	SB032554	MPM373 or MPS373	
	SB032555	MPM374 or MPS374	
	SB032556	MPM375 or MPS375	
	SB032557	MPM376 or MPS376	
	SB032558	MPM377 or MPS377	
	SB032559	MPM378 or MPS378	
	SB03255A	MPM379 or MPS379	
	SB03255B	MPM380 or MPS380	
	SB03255C	MPM381 or MPS381	
	SB03255D	MPM382 or MPS382	
	SB03255E	MPM383 or MPS383	
	SB03255F	MPM384 or MPS384	
SW03256	SB032560	MPM385 or MPS385	
	SB032561	MPM386 or MPS386	
	SB032562	MPM387 or MPS387	
	SB032563	MPM388 or MPS388	
	SB032564	MPM389 or MPS389	
	SB032565	MPM390 or MPS390	
	SB032566	MPM391 or MPS391	
	SB032567	MPM392 or MPS392	
	SB032568	MPM393 or MPS393	
	SB032569	MPM394 or MPS394	
	SB03256A	MPM395 or MPS395	
	SB03256B	MPM396 or MPS396	
	SB03256C	MPM397 or MPS397	
	SB03256D	MPM398 or MPS398	
	SB03256E	MPM399 or MPS399	
	SB03256F	MPM400 or MPS400	
SW03257	SB032570	MPM401 or MPS401	
	SB032571	MPM402 or MPS402	
	SB032572	MPM403 or MPS403	
	SB032573	MPM404 or MPS404	
	SB032574	MPM405 or MPS405	
	SB032575	MPM406 or MPS406	
	SB032576	MPM407 or MPS407	
	SB032577	MPM408 or MPS408	
	SB032578	MPM409 or MPS409	
	SB032579	MPM410 or MPS410	
	SB03257A	MPM411 or MPS411	
	SB03257B	MPM412 or MPS412	
	SB03257C	MPM413 or MPS413	
	SB03257D	MPM414 or MPS414	
	SB03257E	MPM415 or MPS415	
	SB03257F	MPM416 or MPS416	

Continued on next page.

Continued from previous page.

Register Address		Contents	
SW03258	SB032580	MPM417 or MPS417	
	SB032581	MPM418 or MPS418	
	SB032582	MPM419 or MPS419	
	SB032583	MPM420 or MPS420	
	SB032584	MPM421 or MPS421	
	SB032585	MPM422 or MPS422	
	SB032586	MPM423 or MPS423	
	SB032587	MPM424 or MPS424	
	SB032588	MPM425 or MPS425	
	SB032589	MPM426 or MPS426	
	SB03258A	MPM427 or MPS427	
	SB03258B	MPM428 or MPS428	
	SB03258C	MPM429 or MPS429	
	SB03258D	MPM430 or MPS430	
	SB03258E	MPM431 or MPS431	
SB03258F	MPM432 or MPS432		
SW03259	SB032590	MPM433 or MPS433	0: – 1: Program running
	SB032591	MPM434 or MPS434	
	SB032592	MPM435 or MPS435	
	SB032593	MPM436 or MPS436	
	SB032594	MPM437 or MPS437	
	SB032595	MPM438 or MPS438	
	SB032596	MPM439 or MPS439	
	SB032597	MPM440 or MPS440	
	SB032598	MPM441 or MPS441	
	SB032599	MPM442 or MPS442	
	SB03259A	MPM443 or MPS443	
	SB03259B	MPM444 or MPS444	
	SB03259C	MPM445 or MPS445	
	SB03259D	MPM446 or MPS446	
	SB03259E	MPM447 or MPS447	
SB03259F	MPM448 or MPS448		
SW03260	SB032600	MPM449 or MPS449	
	SB032601	MPM450 or MPS450	
	SB032602	MPM451 or MPS451	
	SB032603	MPM452 or MPS452	
	SB032604	MPM453 or MPS453	
	SB032605	MPM454 or MPS454	
	SB032606	MPM455 or MPS455	
	SB032607	MPM456 or MPS456	
	SB032608	MPM457 or MPS457	
	SB032609	MPM458 or MPS458	
	SB03260A	MPM459 or MPS459	
	SB03260B	MPM460 or MPS460	
	SB03260C	MPM461 or MPS461	
	SB03260D	MPM462 or MPS462	
	SB03260E	MPM463 or MPS463	
SB03260F	MPM464 or MPS464		

Continued on next page.

Continued from previous page.


Register Address	Contents		
SW03261	SB032610	MPM465 or MPS465	0: – 1: Program running
	SB032611	MPM466 or MPS466	
	SB032612	MPM467 or MPS467	
	SB032613	MPM468 or MPS468	
	SB032614	MPM469 or MPS469	
	SB032615	MPM470 or MPS470	
	SB032616	MPM471 or MPS471	
	SB032617	MPM472 or MPS472	
	SB032618	MPM473 or MPS473	
	SB032619	MPM474 or MPS474	
	SB03261A	MPM475 or MPS475	
	SB03261B	MPM476 or MPS476	
	SB03261C	MPM477 or MPS477	
	SB03261D	MPM478 or MPS478	
	SB03261E	MPM479 or MPS479	
	SB03261F	MPM480 or MPS480	
SW03262	SB032620	MPM481 or MPS481	
	SB032621	MPM482 or MPS482	
	SB032622	MPM483 or MPS483	
	SB032623	MPM484 or MPS484	
	SB032624	MPM485 or MPS485	
	SB032625	MPM486 or MPS486	
	SB032626	MPM487 or MPS487	
	SB032627	MPM488 or MPS488	
	SB032628	MPM489 or MPS489	
	SB032629	MPM490 or MPS490	
	SB03262A	MPM491 or MPS491	
	SB03262B	MPM492 or MPS492	
	SB03262C	MPM493 or MPS493	
	SB03262D	MPM494 or MPS494	
	SB03262E	MPM495 or MPS495	
	SB03262F	MPM496 or MPS496	
SW03263	SB032630	MPM497 or MPS497	
	SB032631	MPM498 or MPS498	
	SB032632	MPM499 or MPS499	
	SB032633	MPM500 or MPS500	
	SB032634	MPM501 or MPS501	
	SB032635	MPM502 or MPS502	
	SB032636	MPM503 or MPS503	
	SB032637	MPM504 or MPS504	
	SB032638	MPM505 or MPS505	
	SB032639	MPM506 or MPS506	
	SB03263A	MPM507 or MPS507	
	SB03263B	MPM508 or MPS508	
	SB03263C	MPM509 or MPS509	
	SB03263D	MPM510 or MPS510	
	SB03263E	MPM511 or MPS511	
	SB03263F	MPM512 or MPS512	

### ■ Registers Used for System Work Numbers 1 to 32

The registers that are used for system work numbers 1 to 32 are given in the following table.

Two system registers are given in the register table for the alarm code, but we recommend that you use system registers SL26□□□. You can use the system registers that are given in parentheses to check for alarms in most cases, but they do not report all alarms.

Refer to the following manual for details on alarm codes.

 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

#### • System Work Numbers 1 to 8

System Work Number		Work 1	Work 2	Work 3	Work 4	Work 5	Work 6	Work 7	Work 8
Executing Main Program No.		SW03200	SW03201	SW03202	SW03203	SW03204	SW03205	SW03206	SW03207
Status		SW03264	SW03322	SW03380	SW03438	SW03496	SW03554	SW03612	SW03670
Control Signals		SW03265	SW03323	SW03381	SW03439	SW03497	SW03555	SW03613	SW03671
Fork 0	Program Number	SW03266	SW03324	SW03382	SW03440	SW03498	SW03556	SW03614	SW03672
	Block Number	SW03267	SW03325	SW03383	SW03441	SW03499	SW03557	SW03615	SW03673
	Alarm Code	SL26000 (SW03268)	SL26016 (SW03326)	SL26032 (SW03384)	SL26048 (SW03442)	SL26064 (SW03500)	SL26080 (SW03558)	SL26096 (SW03616)	SL26112 (SW03674)
Fork 1	Program Number	SW03269	SW03327	SW03385	SW03443	SW03501	SW03559	SW03617	SW03675
	Block Number	SW03270	SW03328	SW03386	SW03444	SW03502	SW03560	SW03618	SW03676
	Alarm Code	SL26002 (SW03271)	SL26018 (SW03329)	SL26034 (SW03387)	SL26050 (SW03445)	SL26066 (SW03503)	SL26082 (SW03561)	SL26098 (SW03619)	SL26114 (SW03677)
Fork 2	Program Number	SW03272	SW03330	SW03388	SW03446	SW03504	SW03562	SW03620	SW03678
	Block Number	SW03273	SW03331	SW03389	SW03447	SW03505	SW03563	SW03621	SW03679
	Alarm Code	SL26004 (SW03274)	SL26020 (SW03332)	SL26036 (SW03390)	SL26052 (SW03448)	SL26068 (SW03506)	SL26084 (SW03564)	SL26100 (SW03622)	SL26116 (SW03680)
Fork 3	Program Number	SW03275	SW03333	SW03391	SW03449	SW03507	SW03565	SW03623	SW03681
	Block Number	SW03276	SW03334	SW03392	SW03450	SW03508	SW03566	SW03624	SW03682
	Alarm Code	SL26006 (SW03277)	SL26022 (SW03335)	SL26038 (SW03393)	SL26054 (SW03451)	SL26070 (SW03509)	SL26086 (SW03567)	SL26102 (SW03625)	SL26118 (SW03683)
Fork 4	Program Number	SW03278	SW03336	SW03394	SW03452	SW03510	SW03568	SW03626	SW03684
	Block Number	SW03279	SW03337	SW03395	SW03453	SW03511	SW03569	SW03627	SW03685
	Alarm Code	SL26008 (SW03280)	SL26024 (SW03338)	SL26040 (SW03396)	SL26056 (SW03454)	SL26072 (SW03512)	SL26088 (SW03570)	SL26104 (SW03628)	SL26120 (SW03686)
Fork 5	Program Number	SW03281	SW03339	SW03397	SW03455	SW03513	SW03571	SW03629	SW03687
	Block Number	SW03282	SW03340	SW03398	SW03456	SW03514	SW03572	SW03630	SW03688
	Alarm Code	SL26010 (SW03283)	SL26026 (SW03341)	SL26042 (SW03399)	SL26058 (SW03457)	SL26074 (SW03515)	SL26090 (SW03573)	SL26106 (SW03631)	SL26122 (SW03689)
Fork 6	Program Number	SW03284	SW03342	SW03400	SW03458	SW03516	SW03574	SW03632	SW03690
	Block Number	SW03285	SW03343	SW03401	SW03459	SW03517	SW03575	SW03633	SW03691
	Alarm Code	SL26012 (SW03286)	SL26028 (SW03344)	SL26044 (SW03402)	SL26060 (SW03460)	SL26076 (SW03518)	SL26092 (SW03576)	SL26108 (SW03634)	SL26124 (SW03692)
Fork 7	Program Number	SW03287	SW03345	SW03403	SW03461	SW03519	SW03577	SW03635	SW03693
	Block Number	SW03288	SW03346	SW03404	SW03462	SW03520	SW03578	SW03636	SW03694
	Alarm Code	SL260014 (SW03289)	SL26030 (SW03347)	SL26046 (SW03405)	SL26062 (SW03463)	SL26078 (SW03521)	SL26094 (SW03579)	SL26110 (SW03637)	SL26126 (SW03695)
Logical Axis 1 Program Current Position		SL03290	SL03348	SL03406	SL03464	SL03522	SL03580	SL03638	SL03696
Logical Axis 2 Program Current Position		SL03292	SL03350	SL03408	SL03466	SL03524	SL03582	SL03640	SL03698

Continued on next page.

Continued from previous page.

System Work Number	Work 1	Work 2	Work 3	Work 4	Work 5	Work 6	Work 7	Work 8
Logical Axis 3 Program Current Position	SL03294	SL03352	SL03410	SL03468	SL03526	SL03584	SL03642	SL03700
Logical Axis 4 Program Current Position	SL03296	SL03354	SL03412	SL03470	SL03528	SL03586	SL03644	SL03702
Logical Axis 5 Program Current Position	SL03298	SL03356	SL03414	SL03472	SL03530	SL03588	SL03646	SL03704
Logical Axis 6 Program Current Position	SL03300	SL03358	SL03416	SL03474	SL03532	SL03590	SL03648	SL03706
Logical Axis 7 Program Current Position	SL03302	SL03360	SL03418	SL03476	SL03534	SL03592	SL03650	SL03708
Logical Axis 8 Program Current Position	SL03304	SL03362	SL03420	SL03478	SL03536	SL03594	SL03652	SL03710
Logical Axis 9 Program Current Position	SL03306	SL03364	SL03422	SL03480	SL03538	SL03596	SL03654	SL03712
Logical Axis 10 Program Current Position	SL03308	SL03366	SL03424	SL03482	SL03540	SL03598	SL03656	SL03714
Logical Axis 11 Program Current Position	SL03310	SL03368	SL03426	SL03484	SL03542	SL03600	SL03658	SL03716
Logical Axis 12 Program Current Position	SL03312	SL03370	SL03428	SL03486	SL03544	SL03602	SL03660	SL03718
Logical Axis 13 Program Current Position	SL03314	SL03372	SL03430	SL03488	SL03546	SL03604	SL03662	SL03720
Logical Axis 14 Program Current Position	SL03316	SL03374	SL03432	SL03490	SL03548	SL03606	SL03664	SL03722
Logical Axis 15 Program Current Position	SL03318	SL03376	SL03434	SL03492	SL03550	SL03608	SL03666	SL03724
Logical Axis 16 Program Current Position	SL03320	SL03378	SL03436	SL03494	SL03552	SL03610	SL03668	SL03726
Logical Axis 17 Program Current Position	SL08192	SL08224	SL08256	SL08288	SL08320	SL08352	SL08384	SL08416
Logical Axis 18 Program Current Position	SL08194	SL08226	SL08258	SL08290	SL08322	SL08354	SL08386	SL08418
Logical Axis 19 Program Current Position	SL08196	SL08228	SL08260	SL08292	SL08324	SL08356	SL08388	SL08420
Logical Axis 20 Program Current Position	SL08198	SL08230	SL08262	SL08294	SL08326	SL08358	SL08390	SL08422
Logical Axis 21 Program Current Position	SL08200	SL08232	SL08264	SL08296	SL08328	SL08360	SL08392	SL08424
Logical Axis 22 Program Current Position	SL08202	SL08234	SL08266	SL08298	SL08330	SL08362	SL08394	SL08426
Logical Axis 23 Program Current Position	SL08204	SL08236	SL08268	SL08300	SL08332	SL08364	SL08396	SL08428
Logical Axis 24 Program Current Position	SL08206	SL08238	SL08270	SL08302	SL08334	SL08366	SL08398	SL08430
Logical Axis 25 Program Current Position	SL08208	SL08240	SL08272	SL08304	SL08336	SL08368	SL08400	SL08432
Logical Axis 26 Program Current Position	SL08210	SL08242	SL08274	SL08306	SL08338	SL08370	SL08402	SL08434
Logical Axis 27 Program Current Position	SL08212	SL08244	SL08276	SL08308	SL08340	SL08372	SL08404	SL08436
Logical Axis 28 Program Current Position	SL08214	SL08246	SL08278	SL08310	SL08342	SL08374	SL08406	SL08438

Continued on next page.

Continued from previous page.

System Work Number	Work 1	Work 2	Work 3	Work 4	Work 5	Work 6	Work 7	Work 8
Logical Axis 29 Program Current Position	SL08216	SL08248	SL08280	SL08312	SL08344	SL08376	SL08408	SL08440
Logical Axis 30 Program Current Position	SL08218	SL08250	SL08282	SL08314	SL08346	SL08378	SL08410	SL08442
Logical Axis 31 Program Current Position	SL08220	SL08252	SL08284	SL08316	SL08348	SL08380	SL08412	SL08444
Logical Axis 32 Program Current Position	SL08222	SL08254	SL08286	SL08318	SL08350	SL08382	SL08414	SL08446

- System Work Numbers 9 to 16

System Work Number		Work 9	Work 10	Work 11	Work 12	Work 13	Work 14	Work 15	Work 16
Executing Main Program No.		SW03208	SW03209	SW03210	SW03211	SW03212	SW03213	SW03214	SW03215
Status		SW03728	SW03786	SW03844	SW03902	SW03960	SW04018	SW04076	SW04134
Control Signals		SW03729	SW03787	SW03845	SW03903	SW03961	SW04019	SW04077	SW04135
Fork 0	Program Number	SW03730	SW03788	SW03846	SW03904	SW03962	SW04020	SW04078	SW04136
	Block Number	SW03731	SW03789	SW03847	SW03905	SW03963	SW04021	SW04079	SW04137
	Alarm Code	SL26128 (SW03732)	SL26144 (SW03790)	SL26160 (SW03848)	SL26176 (SW03906)	SL26192 (SW03964)	SL26208 (SW04022)	SL26224 (SW04080)	SL26240 (SW04138)
Fork 1	Program Number	SW03733	SW03791	SW03849	SW03907	SW03965	SW04023	SW04081	SW04139
	Block Number	SW03734	SW03792	SW03850	SW03908	SW03966	SW04024	SW04082	SW04140
	Alarm Code	SL26130 (SW03735)	SL26146 (SW03793)	SL26162 (SW03851)	SL26178 (SW03909)	SL26194 (SW03967)	SL26210 (SW04025)	SL26226 (SW04083)	SL26242 (SW04141)
Fork 2	Program Number	SW03736	SW03794	SW03852	SW03910	SW03968	SW04026	SW04084	SW04142
	Block Number	SW03737	SW03795	SW03853	SW03911	SW03969	SW04027	SW04085	SW04143
	Alarm Code	SL26132 (SW03738)	SL26148 (SW03796)	SL26164 (SW03854)	SL26180 (SW03912)	SL26196 (SW03970)	SL26212 (SW04028)	SL26228 (SW04086)	SL26244 (SW04144)
Fork 3	Program Number	SW03739	SW03797	SW03855	SW03913	SW03971	SW04029	SW04087	SW04145
	Block Number	SW03740	SW03798	SW03856	SW03914	SW03972	SW04030	SW04088	SW04146
	Alarm Code	SL26134 (SW03741)	SL26150 (SW03799)	SL26166 (SW03857)	SL26182 (SW03915)	SL26198 (SW03973)	SL26214 (SW04031)	SL26230 (SW04089)	SL26246 (SW04147)
Fork 4	Program Number	SW03742	SW03800	SW03858	SW03916	SW03974	SW04032	SW04090	SW04148
	Block Number	SW03743	SW03801	SW03859	SW03917	SW03975	SW04033	SW04091	SW04149
	Alarm Code	SL26136 (SW03744)	SL26152 (SW03802)	SL26168 (SW03860)	SL26184 (SW03918)	SL26200 (SW03976)	SL26216 (SW04034)	SL26232 (SW04092)	SL26248 (SW04150)
Fork 5	Program Number	SW03745	SW03803	SW03861	SW03919	SW03977	SW04035	SW04093	SW04151
	Block Number	SW03746	SW03804	SW03862	SW03920	SW03978	SW04036	SW04094	SW04152
	Alarm Code	SL26138 (SW03747)	SL26154 (SW03805)	SL26170 (SW03863)	SL26186 (SW03921)	SL26202 (SW03979)	SL26218 (SW04037)	SL26234 (SW04095)	SL26250 (SW04153)
Fork 6	Program Number	SW03748	SW03806	SW03864	SW03922	SW03980	SW04038	SW04096	SW04154
	Block Number	SW03749	SW03807	SW03865	SW03923	SW03981	SW04039	SW04097	SW04155
	Alarm Code	SL26140 (SW03750)	SL26156 (SW03808)	SL26172 (SW03866)	SL26188 (SW03924)	SL26204 (SW03982)	SL26220 (SW04040)	SL26236 (SW04098)	SL26252 (SW04156)
Fork 7	Program Number	SW03751	SW03809	SW03867	SW03925	SW03983	SW04041	SW04099	SW04157
	Block Number	SW03752	SW03810	SW03868	SW03926	SW03984	SW04042	SW04100	SW04158
	Alarm Code	SL26142 (SW03753)	SL26158 (SW03811)	SL26174 (SW03869)	SL26190 (SW03927)	SL26206 (SW03985)	SL26222 (SW04043)	SL26238 (SW04101)	SL26254 (SW04159)
Logical Axis 1 Program Current Position		SL03754	SL03812	SL03870	SL03928	SL03986	SL04044	SL04102	SL04160
Logical Axis 2 Program Current Position		SL03756	SL03814	SL03872	SL03930	SL03988	SL04046	SL04104	SL04162
Logical Axis 3 Program Current Position		SL03758	SL03816	SL03874	SL03932	SL03990	SL04048	SL04106	SL04164
Logical Axis 4 Program Current Position		SL03760	SL03818	SL03876	SL03934	SL03992	SL04050	SL04108	SL04166
Logical Axis 5 Program Current Position		SL03762	SL03820	SL03878	SL03936	SL03994	SL04052	SL04110	SL04168
Logical Axis 6 Program Current Position		SL03764	SL03822	SL03880	SL03938	SL03996	SL04054	SL04112	SL04170
Logical Axis 7 Program Current Position		SL03766	SL03824	SL03882	SL03940	SL03998	SL04056	SL04114	SL04172

Continued on next page.

Continued from previous page.

System Work Number	Work 9	Work 10	Work 11	Work 12	Work 13	Work 14	Work 15	Work 16
Logical Axis 8 Program Current Position	SL03768	SL03826	SL03884	SL03942	SL04000	SL04058	SL04116	SL04174
Logical Axis 9 Program Current Position	SL03770	SL03828	SL03886	SL03944	SL04002	SL04060	SL04118	SL04176
Logical Axis 10 Program Current Position	SL03772	SL03830	SL03888	SL03946	SL04004	SL04062	SL04120	SL04178
Logical Axis 11 Program Current Position	SL03774	SL03832	SL03890	SL03948	SL04006	SL04064	SL04122	SL04180
Logical Axis 12 Program Current Position	SL03776	SL03834	SL03892	SL03950	SL04008	SL04066	SL04124	SL04182
Logical Axis 13 Program Current Position	SL03778	SL03836	SL03894	SL03952	SL04010	SL04068	SL04126	SL04184
Logical Axis 14 Program Current Position	SL03780	SL03838	SL03896	SL03954	SL04012	SL04070	SL04128	SL04186
Logical Axis 15 Program Current Position	SL03782	SL03840	SL03898	SL03956	SL04014	SL04072	SL04130	SL04188
Logical Axis 16 Program Current Position	SL03784	SL03842	SL03900	SL03958	SL04016	SL04074	SL04132	SL04190
Logical Axis 17 Program Current Position	SL08448	SL08480	SL08512	SL08544	SL08576	SL08608	SL08640	SL08672
Logical Axis 18 Program Current Position	SL08450	SL08482	SL08514	SL08546	SL08578	SL08610	SL08642	SL08674
Logical Axis 19 Program Current Position	SL08452	SL08484	SL08516	SL08548	SL08580	SL08612	SL08644	SL08676
Logical Axis 20 Program Current Position	SL08454	SL08486	SL08518	SL08550	SL08582	SL08614	SL08646	SL08678
Logical Axis 21 Program Current Position	SL08456	SL08488	SL08520	SL08552	SL08584	SL08616	SL08648	SL08680
Logical Axis 22 Program Current Position	SL08458	SL08490	SL08522	SL08554	SL08586	SL08618	SL08650	SL08682
Logical Axis 23 Program Current Position	SL08460	SL08492	SL08524	SL08556	SL08588	SL08620	SL08652	SL08684
Logical Axis 24 Program Current Position	SL08462	SL08494	SL08526	SL08558	SL08590	SL08622	SL08654	SL08686
Logical Axis 25 Program Current Position	SL08464	SL08496	SL08528	SL08560	SL08592	SL08624	SL08656	SL08688
Logical Axis 26 Program Current Position	SL08466	SL08498	SL08530	SL08562	SL08594	SL08626	SL08658	SL08690
Logical Axis 27 Program Current Position	SL08468	SL08500	SL08532	SL08564	SL08596	SL08628	SL08660	SL08692
Logical Axis 28 Program Current Position	SL08470	SL08502	SL08534	SL08566	SL08598	SL08630	SL08662	SL08694
Logical Axis 29 Program Current Position	SL08472	SL08504	SL08536	SL08568	SL08600	SL08632	SL08664	SL08696
Logical Axis 30 Program Current Position	SL08474	SL08506	SL08538	SL08570	SL08602	SL08634	SL08666	SL08698
Logical Axis 31 Program Current Position	SL08476	SL08508	SL08540	SL08572	SL08604	SL08636	SL08668	SL08700
Logical Axis 32 Program Current Position	SL08478	SL08510	SL08542	SL08574	SL08606	SL08638	SL08670	SL08702



- System Work Numbers 17 to 24

System Work Number		Work 17	Work 18	Work 19	Work 20	Work 21	Work 22	Work 23	Work 24
Executing Main Program No.		SW03216	SW03217	SW03218	SW03219	SW03220	SW03221	SW03222	SW03223
Status		SW04192	SW04250	SW04308	SW04366	SW04424	SW04482	SW04540	SW04598
Control Signals		SW04193	SW04251	SW04309	SW04367	SW04425	SW04483	SW04541	SW04599
Fork 0	Program Number	SW04194	SW04252	SW04310	SW04368	SW04426	SW04484	SW04542	SW04600
	Block Number	SW04195	SW04253	SW04311	SW04369	SW04427	SW04485	SW04543	SW04601
	Alarm Code	SL26256 (SW04196)	SL26272 (SW04254)	SL26288 (SW04312)	SL26304 (SW04370)	SL26320 (SW04428)	SL26336 (SW04486)	SL26352 (SW04544)	SL26368 (SW04602)
Fork 1	Program Number	SW04197	SW04255	SW04313	SW04371	SW04429	SW04487	SW04545	SW04603
	Block Number	SW04198	SW04256	SW04314	SW04372	SW04430	SW04488	SW04546	SW04604
	Alarm Code	SL26258 (SW04199)	SL26274 (SW04257)	SL26290 (SW04315)	SL26306 (SW04373)	SL26322 (SW04431)	SL26338 (SW04489)	SL26354 (SW04547)	SL26370 (SW04605)
Fork 2	Program Number	SW04200	SW04258	SW04316	SW04374	SW04432	SW04490	SW04548	SW04606
	Block Number	SW04201	SW04259	SW04317	SW04375	SW04433	SW04491	SW04549	SW04607
	Alarm Code	SL26260 (SW04202)	SL26276 (SW04260)	SL26292 (SW04318)	SL26308 (SW04376)	SL26324 (SW04434)	SL26340 (SW04492)	SL26356 (SW04550)	SL26372 (SW04608)
Fork 3	Program Number	SW04203	SW04261	SW04319	SW04377	SW04435	SW04493	SW04551	SW04609
	Block Number	SW04204	SW04262	SW04320	SW04378	SW04436	SW04494	SW04552	SW04610
	Alarm Code	SL26262 (SW04205)	SL26278 (SW04263)	SL26294 (SW04321)	SL26310 (SW04379)	SL26326 (SW04437)	SL26342 (SW04495)	SL26358 (SW04553)	SL26374 (SW04611)
Fork 4	Program Number	SW04206	SW04264	SW04322	SW04380	SW04438	SW04496	SW04554	SW04612
	Block Number	SW04207	SW04265	SW04323	SW04381	SW04439	SW04497	SW04555	SW04613
	Alarm Code	SL26264 (SW04208)	SL26280 (SW04266)	SL26296 (SW04324)	SL26312 (SW04382)	SL26328 (SW04440)	SL26344 (SW04498)	SL26360 (SW04556)	SL26376 (SW04614)
Fork 5	Program Number	SW04209	SW04267	SW04325	SW04383	SW04441	SW04499	SW04557	SW04615
	Block Number	SW04210	SW04268	SW04326	SW04384	SW04442	SW04500	SW04558	SW04616
	Alarm Code	SL26266 (SW04211)	SL26282 (SW04269)	SL26298 (SW04327)	SL26314 (SW04385)	SL26330 (SW04443)	SL26346 (SW04501)	SL26362 (SW04559)	SL26378 (SW04617)
Fork 6	Program Number	SW04212	SW04270	SW04328	SW04386	SW04444	SW04502	SW04560	SW04618
	Block Number	SW04213	SW04271	SW04329	SW04387	SW04445	SW04503	SW04561	SW04619
	Alarm Code	SL26268 (SW04214)	SL26284 (SW04272)	SL26300 (SW04330)	SL26316 (SW04388)	SL26332 (SW04446)	SL26348 (SW04504)	SL26364 (SW04562)	SL26380 (SW04620)
Fork 7	Program Number	SW04215	SW04273	SW04331	SW04389	SW04447	SW04505	SW04563	SW04621
	Block Number	SW04216	SW04274	SW04332	SW04390	SW04448	SW04506	SW04564	SW04622
	Alarm Code	SL26270 (SW04217)	SL26286 (SW04275)	SL26302 (SW04333)	SL26318 (SW04391)	SL26334 (SW04449)	SL26350 (SW04507)	SL26366 (SW04565)	SL26382 (SW04623)
Logical Axis 1 Program Current Position		SL04218	SL04276	SL04334	SL04392	SL04450	SL04508	SL04566	SL04624
Logical Axis 2 Program Current Position		SL04220	SL04278	SL04336	SL04394	SL04452	SL04510	SL04568	SL04626
Logical Axis 3 Program Current Position		SL04222	SL04280	SL04338	SL04396	SL04454	SL04512	SL04570	SL04628
Logical Axis 4 Program Current Position		SL04224	SL04282	SL04340	SL04398	SL04456	SL04514	SL04572	SL04630
Logical Axis 5 Program Current Position		SL04226	SL04284	SL04342	SL04400	SL04458	SL04516	SL04574	SL04632
Logical Axis 6 Program Current Position		SL04228	SL04286	SL04344	SL04402	SL04460	SL04518	SL04576	SL04634
Logical Axis 7 Program Current Position		SL04230	SL04288	SL04346	SL04404	SL04462	SL04520	SL04578	SL04636

Continued on next page.

Continued from previous page.

System Work Number	Work 17	Work 18	Work 19	Work 20	Work 21	Work 22	Work 23	Work 24
Logical Axis 8 Program Current Position	SL04232	SL04290	SL04348	SL04406	SL04464	SL04522	SL04580	SL04638
Logical Axis 9 Program Current Position	SL04234	SL04292	SL04350	SL04408	SL04466	SL04524	SL04582	SL04640
Logical Axis 10 Program Current Position	SL04236	SL04294	SL04352	SL04410	SL04468	SL04526	SL04584	SL04642
Logical Axis 11 Program Current Position	SL04238	SL04296	SL04354	SL04412	SL04470	SL04528	SL04586	SL04644
Logical Axis 12 Program Current Position	SL04240	SL04298	SL04356	SL04414	SL04472	SL04530	SL04588	SL04646
Logical Axis 13 Program Current Position	SL04242	SL04300	SL04358	SL04416	SL04474	SL04532	SL04590	SL04648
Logical Axis 14 Program Current Position	SL04244	SL04302	SL04360	SL04418	SL04476	SL04534	SL04592	SL04650
Logical Axis 15 Program Current Position	SL04246	SL04304	SL04362	SL04420	SL04478	SL04536	SL04594	SL04652
Logical Axis 16 Program Current Position	SL04248	SL04306	SL04364	SL04422	SL04480	SL04538	SL04596	SL04654
Logical Axis 17 Program Current Position	SL08704	SL08736	SL08768	SL08800	SL08832	SL08864	SL08896	SL08928
Logical Axis 18 Program Current Position	SL08706	SL08738	SL08770	SL08802	SL08834	SL08866	SL08898	SL08930
Logical Axis 19 Program Current Position	SL08708	SL08740	SL08772	SL08804	SL08836	SL08868	SL08900	SL08932
Logical Axis 20 Program Current Position	SL08710	SL08742	SL08774	SL08806	SL08838	SL08870	SL08902	SL08934
Logical Axis 21 Program Current Position	SL08712	SL08744	SL08776	SL08808	SL08840	SL08872	SL08904	SL08936
Logical Axis 22 Program Current Position	SL08714	SL08746	SL08778	SL08810	SL08842	SL08874	SL08906	SL08938
Logical Axis 23 Program Current Position	SL08716	SL08748	SL08780	SL08812	SL08844	SL08876	SL08908	SL08940
Logical Axis 24 Program Current Position	SL08718	SL08750	SL08782	SL08814	SL08846	SL08878	SL08910	SL08942
Logical Axis 25 Program Current Position	SL08720	SL08752	SL08784	SL08816	SL08848	SL08880	SL08912	SL08944
Logical Axis 26 Program Current Position	SL08722	SL08754	SL08786	SL08818	SL08850	SL08882	SL08914	SL08946
Logical Axis 27 Program Current Position	SL08724	SL08756	SL08788	SL08820	SL08852	SL08884	SL08916	SL08948
Logical Axis 28 Program Current Position	SL08726	SL08758	SL08790	SL08822	SL08854	SL08886	SL08918	SL08950
Logical Axis 29 Program Current Position	SL08728	SL08760	SL08792	SL08824	SL08856	SL08888	SL08920	SL08952
Logical Axis 30 Program Current Position	SL08730	SL08762	SL08794	SL08826	SL08858	SL08890	SL08922	SL08954
Logical Axis 31 Program Current Position	SL08732	SL08764	SL08796	SL08828	SL08860	SL08892	SL08924	SL08956
Logical Axis 32 Program Current Position	SL08734	SL08766	SL08798	SL08830	SL08862	SL08894	SL08926	SL08958

- System Work Numbers 25 to 32

System Work Number		Work 25	Work 26	Work 27	Work 28	Work 29	Work 30	Work 31	Work 32
Executing Main Program No.		SW03224	SW03225	SW03226	SW03227	SW03228	SW03229	SW03230	SW03231
Status		SW04656	SW04714	SW04772	SW04830	SW04888	SW04946	SW05004	SW05062
Control Signals		SW04657	SW04715	SW04773	SW04831	SW04889	SW04947	SW05005	SW05063
Fork 0	Program Number	SW04658	SW04716	SW04774	SW04832	SW04890	SW04948	SW05006	SW05064
	Block Number	SW04659	SW04717	SW04775	SW04833	SW04891	SW04949	SW05007	SW05065
	Alarm Code	SL26384 (SW04660)	SL26400 (SW04718)	SL26416 (SW04776)	SL26432 (SW04834)	SL26448 (SW04892)	SL26464 (SW04950)	SL26480 (SW05008)	SL26496 (SW05066)
Fork 1	Program Number	SW04661	SW04719	SW04777	SW04835	SW04893	SW04951	SW05009	SW05067
	Block Number	SW04662	SW04720	SW04778	SW04836	SW04894	SW04952	SW05010	SW05068
	Alarm Code	SL26386 (SW04663)	SL26402 (SW04721)	SL26418 (SW04779)	SL26434 (SW04837)	SL26450 (SW04895)	SL26466 (SW04953)	SL26482 (SW05011)	SL26498 (SW05069)
Fork 2	Program Number	SW04664	SW04722	SW04780	SW04838	SW04896	SW04954	SW05012	SW05070
	Block Number	SW04665	SW04723	SW04781	SW04839	SW04897	SW04955	SW05013	SW05071
	Alarm Code	SL26388 (SW04666)	SL26404 (SW04724)	SL26420 (SW04782)	SL26436 (SW04840)	SL26452 (SW04898)	SL26468 (SW04956)	SL26484 (SW05014)	SL26500 (SW05072)
Fork 3	Program Number	SW04667	SW04725	SW04783	SW04841	SW04899	SW04957	SW05015	SW05073
	Block Number	SW04668	SW04726	SW04784	SW04842	SW04900	SW04958	SW05016	SW05074
	Alarm Code	SL26390 (SW04669)	SL26406 (SW04727)	SL26422 (SW04785)	SL26438 (SW04843)	SL26454 (SW04901)	SL26470 (SW04959)	SL26486 (SW05017)	SL26502 (SW05075)
Fork 4	Program Number	SW04670	SW04728	SW04786	SW04844	SW04902	SW04960	SW05018	SW05076
	Block Number	SW04671	SW04729	SW04787	SW04845	SW04903	SW04961	SW05019	SW05077
	Alarm Code	SL26392 (SW04672)	SL26408 (SW04730)	SL26424 (SW04788)	SL26440 (SW04846)	SL26456 (SW04904)	SL26472 (SW04962)	SL26488 (SW05020)	SL26504 (SW05078)
Fork 5	Program Number	SW04673	SW04731	SW04789	SW04847	SW04905	SW04963	SW05021	SW05079
	Block Number	SW04674	SW04732	SW04790	SW04848	SW04906	SW04964	SW05022	SW05080
	Alarm Code	SL26394 (SW04675)	SL26410 (SW04733)	SL26426 (SW04791)	SL26442 (SW04849)	SL26458 (SW04907)	SL26474 (SW04965)	SL26490 (SW05023)	SL26506 (SW05081)
Fork 6	Program Number	SW04676	SW04734	SW04792	SW04850	SW04908	SW04966	SW05024	SW05082
	Block Number	SW04677	SW04735	SW04793	SW04851	SW04909	SW04967	SW05025	SW05083
	Alarm Code	SL26396 (SW04678)	SL26412 (SW04736)	SL26428 (SW04794)	SL26444 (SW04852)	SL26460 (SW04910)	SL26476 (SW04968)	SL26492 (SW05026)	SL26508 (SW05084)
Fork 7	Program Number	SW04679	SW04737	SW04795	SW04853	SW04911	SW04969	SW05027	SW05085
	Block Number	SW04680	SW04738	SW04796	SW04854	SW04912	SW04970	SW05028	SW05086
	Alarm Code	SL26398 (SW04681)	SL26414 (SW04739)	SL26430 (SW04797)	SL26446 (SW04855)	SL26462 (SW04913)	SL26478 (SW04971)	SL26494 (SW05029)	SL26510 (SW05087)
Logical Axis 1 Program Current Position		SL04682	SL04740	SL04798	SL04856	SL04914	SL04972	SL05030	SL05088
Logical Axis 2 Program Current Position		SL04684	SL04742	SL04800	SL04858	SL04916	SL04974	SL05032	SL05090
Logical Axis 3 Program Current Position		SL04686	SL04744	SL04802	SL04860	SL04918	SL04976	SL05034	SL05092
Logical Axis 4 Program Current Position		SL04688	SL04746	SL04804	SL04862	SL04920	SL04978	SL05036	SL05094
Logical Axis 5 Program Current Position		SL04690	SL04748	SL04806	SL04864	SL04922	SL04980	SL05038	SL05096
Logical Axis 6 Program Current Position		SL04692	SL04750	SL04808	SL04866	SL04924	SL04982	SL05040	SL05098
Logical Axis 7 Program Current Position		SL04694	SL04752	SL04810	SL04868	SL04926	SL04984	SL05042	SL05100

Continued on next page.

Continued from previous page.

System Work Number	Work 25	Work 26	Work 27	Work 28	Work 29	Work 30	Work 31	Work 32
Logical Axis 8 Program Current Position	SL04696	SL04754	SL04812	SL04870	SL04928	SL04986	SL05044	SL05102
Logical Axis 9 Program Current Position	SL04698	SL04756	SL04814	SL04872	SL04930	SL04988	SL05046	SL05104
Logical Axis 10 Program Current Position	SL04700	SL04758	SL04816	SL04874	SL04932	SL04990	SL05048	SL05106
Logical Axis 11 Program Current Position	SL04702	SL04760	SL04818	SL04876	SL04934	SL04992	SL05050	SL05108
Logical Axis 12 Program Current Position	SL04704	SL04762	SL04820	SL04878	SL04936	SL04994	SL05052	SL05110
Logical Axis 13 Program Current Position	SL04706	SL04764	SL04822	SL04880	SL04938	SL04996	SL05054	SL05112
Logical Axis 14 Program Current Position	SL04708	SL04766	SL04824	SL04882	SL04940	SL04998	SL05056	SL05114
Logical Axis 15 Program Current Position	SL04710	SL04768	SL04826	SL04884	SL04942	SL05000	SL05058	SL05116
Logical Axis 16 Program Current Position	SL04712	SL04770	SL04828	SL04886	SL04944	SL05002	SL05060	SL05118
Logical Axis 17 Program Current Position	SL08960	SL08992	SL09024	SL09056	SL09088	SL09120	SL09152	SL09184
Logical Axis 18 Program Current Position	SL08962	SL08994	SL09026	SL09058	SL09090	SL09122	SL09154	SL09186
Logical Axis 19 Program Current Position	SL08964	SL08996	SL09028	SL09060	SL09092	SL09124	SL09156	SL09188
Logical Axis 20 Program Current Position	SL08966	SL08998	SL09030	SL09062	SL09094	SL09126	SL09158	SL09190
Logical Axis 21 Program Current Position	SL08968	SL09000	SL09032	SL09064	SL09096	SL09128	SL09160	SL09192
Logical Axis 22 Program Current Position	SL08970	SL09002	SL09034	SL09066	SL09098	SL09130	SL09162	SL09194
Logical Axis 23 Program Current Position	SL08972	SL09004	SL09036	SL09068	SL09100	SL09132	SL09164	SL09196
Logical Axis 24 Program Current Position	SL08974	SL09006	SL09038	SL09070	SL09102	SL09134	SL09166	SL09198
Logical Axis 25 Program Current Position	SL08976	SL09008	SL09040	SL09072	SL09104	SL09136	SL09168	SL09200
Logical Axis 26 Program Current Position	SL08978	SL09010	SL09042	SL09074	SL09106	SL09138	SL09170	SL09202
Logical Axis 27 Program Current Position	SL08980	SL09012	SL09044	SL09076	SL09108	SL09140	SL09172	SL09204
Logical Axis 28 Program Current Position	SL08982	SL09014	SL09046	SL09078	SL09110	SL09142	SL09174	SL09206
Logical Axis 29 Program Current Position	SL08984	SL09016	SL09048	SL09080	SL09112	SL09144	SL09176	SL09208
Logical Axis 30 Program Current Position	SL08986	SL09018	SL09050	SL09082	SL09114	SL09146	SL09178	SL09210
Logical Axis 31 Program Current Position	SL08988	SL09020	SL09052	SL09084	SL09116	SL09148	SL09180	SL09212
Logical Axis 32 Program Current Position	SL08990	SL09022	SL09054	SL09086	SL09118	SL09150	SL09182	SL09214

### ◆ Expansion System I/O Error Status

The data in these registers give the I/O errors in the system for Racks 1 and 5 to 7.

The details of the error status depend on the Modules that are mounted and the error code. Refer to the following manual for details.

📖 *MP3000 Series MP3200 Troubleshooting Manual* (Manual No.: SIEP C880725 01)

Name	Register Addresses	Remarks			
I/O Error Count	SW09560	Number of I/O error occurrences			
Input Error Count	SW09561	Number of input error occurrences			
Input Error Address	SL09562	Latest input error address (register address in IW□□□□)			
Reserved for system.	SW09564	-			
Output Error Count	SW09565	Number of output error occurrences			
Output Error Address	SL09566	Latest output error address (register address in OW□□□□)			
Reserved for system.	SW09568 to SW09571	-			
Extended I/O Error Status	SW09572 to SW09603	Rack 1	CPU Unit		
	SW09604 to SW09635			Unit 1	Slot 1
	SW09636 to SW09667				Slot 2
	SW09668 to SW09699				Slot 3
	SW09700 to SW09731				Slot 4
	SW09732 to SW09763				Slot 5
	SW09764 to SW09795				Slot 6
	SW09796 to SW09827				Slot 7
	SW09828 to SW09859				Slot 8
	SW09860 to SW09891			Unit 2	Slot 1
	SW09892 to SW09923				Slot 2
	SW09924 to SW09955				Slot 3
	SW09956 to SW09987				Slot 4
	SW09988 to SW10019				Slot 5
	SW10020 to SW10051				Slot 6
	SW10052 to SW10083				Slot 7
	SW10084 to SW10115				Slot 8
	SW10116 to SW10147			Unit 3	Slot 1
	SW10148 to SW10179				Slot 2
	SW10180 to SW10211				Slot 3
	SW10212 to SW10243				Slot 4
	SW10244 to SW10275				Slot 5
	SW10276 to SW10307				Slot 6
	SW10308 to SW10339				Slot 7
	SW10340 to SW10371				Slot 8
	SW10372 to SW10403			Unit 4	Slot 1
	SW10404 to SW10435				Slot 2
	SW10436 to SW10467				Slot 3
	SW10468 to SW10499				Slot 4
	SW10500 to SW10531				Slot 5
	SW10532 to SW10563				Slot 6
	SW10564 to SW10595				Slot 7
SW10596 to SW10627	Slot 8				

Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks		
Extended I/O Error Status	SW10628 to SW10659	Rack 5	Slot 1	
	SW10660 to SW10691		Slot 2	
	SW10692 to SW10723		Slot 3	
	SW10724 to SW10755		Unit 1	Slot 4
	SW10756 to SW10787		Slot 5	
	SW10788 to SW10819		Slot 6	
	SW10820 to SW10851		Slot 7	
	SW10852 to SW10883		Slot 8	
	SW10884 to SW10915		Unit 2	Slot 1
	SW10916 to SW10947			Slot 2
	SW10948 to SW10979			Slot 3
	SW10980 to SW11011			Slot 4
	SW11012 to SW11043			Slot 5
	SW11044 to SW11075			Slot 6
	SW11076 to SW11107			Slot 7
	SW11108 to SW11139			Slot 8
	SW11140 to SW11171		Unit 3	Slot 1
	SW11172 to SW11203			Slot 2
	SW11204 to SW11235			Slot 3
	SW11236 to SW11267			Slot 4
	SW11268 to SW11299			Slot 5
	SW11300 to SW11331			Slot 6
	SW11332 to SW11363			Slot 7
	SW11364 to SW11395			Slot 8
	SW11396 to SW11427		Unit 4	Slot 1
	SW11428 to SW11459			Slot 2
	SW11460 to SW11491			Slot 3
	SW11492 to SW11523			Slot 4
	SW11524 to SW11555			Slot 5
	SW11556 to SW11587			Slot 6
	SW11588 to SW11619			Slot 7
	SW11620 to SW11651			Slot 8

Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks	
Extended I/O Error Status	SW11652 to SW11683	Rack 6	Unit 1 Slot 1
	SW11684 to SW11715		Slot 2
	SW11716 to SW11747		Slot 3
	SW11748 to SW11779		Slot 4
	SW11780 to SW11811		Slot 5
	SW11812 to SW11843		Slot 6
	SW11844 to SW11875		Slot 7
	SW11876 to SW11907		Slot 8
	SW11908 to SW11939		Unit 2 Slot 1
	SW11940 to SW11971		Slot 2
	SW11972 to SW12003		Slot 3
	SW12004 to SW12035		Slot 4
	SW12036 to SW12067		Slot 5
	SW12068 to SW12099		Slot 6
	SW12100 to SW12131		Slot 7
	SW12132 to SW12163		Slot 8
	SW12164 to SW12195		Unit 3 Slot 1
	SW12196 to SW12227		Slot 2
	SW12228 to SW12259		Slot 3
	SW12260 to SW12291		Slot 4
	SW12292 to SW12323		Slot 5
	SW12324 to SW12355		Slot 6
	SW12356 to SW12387		Slot 7
	SW12388 to SW12419		Slot 8
	SW12420 to SW12451		Unit 4 Slot 1
	SW12452 to SW12483		Slot 2
	SW12484 to SW12515		Slot 3
	SW12516 to SW12547		Slot 4
	SW12548 to SW12579		Slot 5
	SW12580 to SW12611		Slot 6
	SW12612 to SW12643		Slot 7
	SW12644 to SW12675		Slot 8


Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks		
Extended I/O Error Status	SW12676 to SW12707	Rack 7	Slot 1	
	SW12708 to SW12739		Slot 2	
	SW12740 to SW12771		Slot 3	
	SW12772 to SW12803		Unit 1	Slot 4
	SW12804 to SW12835		Slot 5	
	SW12836 to SW12867		Slot 6	
	SW12868 to SW12899		Slot 7	
	SW12900 to SW12931		Slot 8	
	SW12932 to SW12963		Unit 2	Slot 1
	SW12964 to SW12995			Slot 2
	SW12996 to SW13027			Slot 3
	SW13028 to SW13059			Slot 4
	SW13060 to SW13091			Slot 5
	SW13092 to SW13123			Slot 6
	SW13124 to SW13155			Slot 7
	SW13156 to SW13187			Slot 8
	SW13188 to SW13219		Unit 3	Slot 1
	SW13220 to SW13251			Slot 2
	SW13252 to SW13283			Slot 3
	SW13284 to SW13315			Slot 4
	SW13316 to SW13347			Slot 5
	SW13348 to SW13379			Slot 6
	SW13380 to SW13411			Slot 7
	SW13412 to SW13443			Slot 8
	SW13444 to SW13475		Unit 4	Slot 1
	SW13476 to SW13507			Slot 2
	SW13508 to SW13539			Slot 3
	SW13540 to SW13571			Slot 4
	SW13572 to SW13603			Slot 5
	SW13604 to SW13635			Slot 6
	SW13636 to SW13667			Slot 7
	SW13668 to SW13699			Slot 8

**Information**

The I/O error status data for Racks 2 to 4 is stored in SW00288 to SW00503. Refer to the following sections for details.

 ◆ *System I/O Error Status (page 4-26)*



### ◆ Expanded Unit and Module Information

The data in these registers give hardware information about the CPU Unit and Optional Modules on Racks 1 and 5 to 7.

Name	Register Addresses	Remarks
CPU Unit Information	SW13700	CPU Unit ID (Low)
	SW13701	CPU Unit ID (High)
	SW13702	Hardware version (BCD)
	SW13703	Software version (BCD)
	SW13704	Number of sub-slots (hex)
	SW13705 to SW13707	Reserved for system.
	SW13708	Function Module 1 ID (Low)
	SW13709	Function Module 1 ID (High)
	SW13710	Function Module 1 Status
	SW13711	Reserved for system.
	SW13712	Function Module 2 ID (Low)
	SW13713	Function Module 2 ID (High)
	SW13714	Function Module 2 Status
	SW13715	Reserved for system.
	SW13716	Function Module 3 ID (Low)
	SW13717	Function Module 3 ID (High)
	SW13718	Function Module 3 Status
	SW13719	Reserved for system.
	SW13720	Function Module 4 ID (Low)
	SW13721	Function Module 4 ID (High)
	SW13722	Function Module 4 Status
	SW13723	Reserved for system.
	SW13724	Function Module 5 ID (Low)
	SW13725	Function Module 5 ID (High)
	SW13726	Function Module 5 Status
	SW13727	Reserved for system.
	SW13728	Function Module 6 ID (Low)
	SW13729	Function Module 6 ID (High)
	SW13730	Function Module 6 Status
	SW13731	Reserved for system.
	SW13732	Function Module 7 ID (Low)
	SW13733	Function Module 7 ID (High)
	SW13734	Function Module 7 Status
	SW13735	Reserved for system.
	SW13736	Function Module 8 ID (Low)
	SW13737	Function Module 8 ID (High)
	SW13738	Function Module 8 Status
	SW13739	Reserved for system.
	SW13740	Function Module 9 ID (Low)
	SW13741	Function Module 9 ID (High)
	SW13742	Function Module 9 Status
	SW13743	Reserved for system.
	SW13744	Function Module 10 ID (Low)
	SW13745	Function Module 10 ID (High)
	SW13746	Function Module 10 Status
	SW13747	Reserved for system.

Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks			
Unit and Optional Module Information	SW13748	Rack 1	Unit 1	Slot 1	Optional Unit and Module ID (Low)
	SW13749				Optional Unit and Module ID (High)
	SW13750				Hardware version (BCD)
	SW13751				Software version (BCD)
	SW13752				Number of sub-slots (hex)
	SW13753 to SW13755				Reserved for system.
	SW13756				Function Module 1 ID (Low)
	SW13757				Function Module 1 ID (High)
	SW13758				Function Module 1 Status
	SW13759				Reserved for system.
	SW13760				Function Module 2 ID (Low)
	SW13761				Function Module 2 ID (High)
	SW13762				Function Module 2 Status
	SW13763				Reserved for system.
	SW13764 to SW13779				Slot 2
	SW13780 to SW13795		Slot 3		
	SW13796 to SW13811		Slot 4		
	SW13812 to SW13827		Slot 5		
	SW13828 to SW13843		Slot 6		
	SW13844 to SW13859		Slot 7		
	SW13860 to SW13875		Slot 8		
	SW13876 to SW13891		Slot 1		
	SW13892 to SW13907		Slot 2		
	SW13908 to SW13923		Slot 3		
	SW13924 to SW13939		Slot 4		
	SW13940 to SW13955		Slot 5		
	SW13956 to SW13971		Slot 6		
	SW13972 to SW13987		Slot 7		
	SW13988 to SW14003		Slot 8		
	SW14004 to SW14019		Slot 1		
	SW14020 to SW14035		Slot 2		
	SW14036 to SW14051		Slot 3		
	SW14052 to SW14067		Slot 4		
	SW14068 to SW14083		Slot 5		
	SW14084 to SW14099		Slot 6		
	SW14100 to SW14115		Slot 7		
	SW14116 to SW14131		Slot 8		

Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks			
Unit and Optional Module Informa- tion	SW14132 to SW14147	Rack 1	Unit 4	Slot 1	Same as above.
	SW14148 to SW14163			Slot 2	
	SW14164 to SW14179			Slot 3	
	SW14180 to SW14195			Slot 4	
	SW14196 to SW14211			Slot 5	
	SW14212 to SW14227			Slot 6	
	SW14228 to SW14243			Slot 7	
	SW14244 to SW14259			Slot 8	
	SW14260 to SW14275	Rack 5	Unit 1	Slot 1	Same as above.
	SW14276 to SW14291			Slot 2	
	SW14292 to SW14307			Slot 3	
	SW14308 to SW14323			Slot 4	
	SW14324 to SW14339			Slot 5	
	SW14340 to SW14355			Slot 6	
	SW14356 to SW14371			Slot 7	
	SW14372 to SW14387			Slot 8	
	SW14388 to SW14403		Unit 2	Slot 1	
	SW14404 to SW14419			Slot 2	
	SW14420 to SW14435			Slot 3	
	SW14436 to SW14451			Slot 4	
	SW14452 to SW14467			Slot 5	
	SW14468 to SW14483			Slot 6	
	SW14484 to SW14499			Slot 7	
	SW14500 to SW14515			Slot 8	
	SW14516 to SW14531		Unit 3	Slot 1	
	SW14532 to SW14547			Slot 2	
	SW14548 to SW14563			Slot 3	
	SW14564 to SW14579			Slot 4	
	SW14580 to SW14595			Slot 5	
	SW14596 to SW14611			Slot 6	
	SW14612 to SW14627			Slot 7	
	SW14628 to SW14643			Slot 8	
	SW14644 to SW14659	Unit 4	Slot 1		
	SW14660 to SW14675		Slot 2		
	SW14676 to SW14691		Slot 3		
	SW14692 to SW14707		Slot 4		
	SW14708 to SW14723		Slot 5		
	SW14724 to SW14739		Slot 6		
	SW14740 to SW14755		Slot 7		
	SW14756 to SW14771		Slot 8		

Continued on next page.

Continued from previous page.



Name	Register Addresses	Remarks			
Unit and Optional Module Informa- tion	SW14772 to SW14787	Rack 6	Unit 1	Slot 1	Same as above.
	SW14788 to SW14803			Slot 2	
	SW14804 to SW14819			Slot 3	
	SW14820 to SW14835			Slot 4	
	SW14836 to SW14851			Slot 5	
	SW14852 to SW14867			Slot 6	
	SW14868 to SW14883			Slot 7	
	SW14884 to SW14899			Slot 8	
	SW14900 to SW14915		Slot 1		
	SW14916 to SW14931		Slot 2		
	SW14932 to SW14947		Slot 3		
	SW14948 to SW14963		Slot 4		
	SW14964 to SW14979		Slot 5		
	SW14980 to SW14995		Slot 6		
	SW14996 to SW15011		Slot 7		
	SW15012 to SW15027		Slot 8		
	SW15028 to SW15043		Slot 1		
	SW15044 to SW15059		Slot 2		
	SW15060 to SW15075		Slot 3		
	SW15076 to SW15091		Slot 4		
	SW15092 to SW15107		Slot 5		
	SW15108 to SW15123		Slot 6		
	SW15124 to SW15139		Slot 7		
	SW15140 to SW15155		Slot 8		
	SW15156 to SW15171		Slot 1		
	SW15172 to SW15187		Slot 2		
	SW15188 to SW15203		Slot 3		
	SW15204 to SW15219		Slot 4		
	SW15220 to SW15235		Slot 5		
	SW15236 to SW15251		Slot 6		
	SW15252 to SW15267		Slot 7		
	SW15268 to SW15283		Slot 8		

Continued on next page.

Continued from previous page.

Name	Register Addresses	Remarks			
Unit and Optional Module Informa- tion	SW15284 to SW15299	Rack 7	Unit 1	Slot 1	Same as above.
	SW15300 to SW15315			Slot 2	
	SW15316 to SW15331			Slot 3	
	SW15332 to SW15347			Slot 4	
	SW15348 to SW15363			Slot 5	
	SW15364 to SW15379			Slot 6	
	SW15380 to SW15395			Slot 7	
	SW15396 to SW15411			Slot 8	
	SW15412 to SW15427		Unit 2	Slot 1	
	SW15428 to SW15443			Slot 2	
	SW15444 to SW15459			Slot 3	
	SW15460 to SW15475			Slot 4	
	SW15476 to SW15491			Slot 5	
	SW15492 to SW15507			Slot 6	
	SW15508 to SW15523			Slot 7	
	SW15524 to SW15539			Slot 8	
	SW15540 to SW15555		Unit 3	Slot 1	
	SW15556 to SW15571			Slot 2	
	SW15572 to SW15587			Slot 3	
	SW15588 to SW15603			Slot 4	
	SW15604 to SW15619			Slot 5	
	SW15620 to SW15635			Slot 6	
	SW15636 to SW15651			Slot 7	
	SW15652 to SW15667			Slot 8	
	SW15668 to SW15683		Unit 4	Slot 1	
	SW15684 to SW15699			Slot 2	
	SW15700 to SW15715			Slot 3	
	SW15716 to SW15731			Slot 4	
	SW15732 to SW15747			Slot 5	
	SW15748 to SW15763			Slot 6	
	SW15764 to SW15779			Slot 7	
	SW15780 to SW15795			Slot 8	

**Information** The Optional Module information data for Racks 2 to 4 is stored in SW00880 to SW01095. Refer to the following sections for details.

  *Module Information (page 4-29)*

### ◆ Expansion System Status

The data in these registers give the status of the Power Supply Units on Racks 1 and 5 to 7.

Name	Register Addresses	Name	Remarks	
Power Supply Status	SW15800	SB158000	RACK1 WARN1 0: No warning 1 for Rack 1 Power Supply Unit 1: Warning 1 for Rack 1 Power Supply Unit	
		SB158001	RACK1 WARN2 0: No warning 2 for Rack 1 Power Supply Unit 1: Warning 2 for Rack 1 Power Supply Unit	
		SB158002, SB158003	Reserved for system.	–
		SB158004	RACK5 WARN1 0: No warning 1 for Rack 5 Power Supply Unit 1: Warning 1 for Rack 5 Power Supply Unit	
		SB158005	RACK5 WARN2 0: No warning 2 for Rack 5 Power Supply Unit 1: Warning 2 for Rack 5 Power Supply Unit	
		SB158006	RACK5 PWOFF 0: Power ON to Rack 5 Power Supply Unit 1: Power OFF to Rack 5 Power Supply Unit	
		SB158007	Reserved for system.	–
		SB158008	RACK6 WARN1 0: No warning 1 for Rack 6 Power Supply Unit 1: Warning 1 for Rack 6 Power Supply Unit	
		SB158009	RACK6 WARN2 0: No warning 2 for Rack 6 Power Supply Unit 1: Warning 2 for Rack 6 Power Supply Unit	
		SB15800A	RACK6 PWOFF 0: Power ON to Rack 6 Power Supply Unit 1: Power OFF to Rack 6 Power Supply Unit	
		SB15800B	Reserved for system.	–
		SB15800C	RACK7 WARN1 0: No warning 1 for Rack 7 Power Supply Unit 1: Warning 1 for Rack 7 Power Supply Unit	
		SB15800D	RACK7 WARN2 0: No warning 2 for Rack 7 Power Supply Unit 1: Warning 2 for Rack 7 Power Supply Unit	
		SB15800E	RACK7 PWOFF 0: Power ON to Rack 7 Power Supply Unit 1: Power OFF to Rack 7 Power Supply Unit	
		SB15800F	Reserved for system.	–

### ◆ Expansion System Service Execution Status

The data in these registers give the execution status of the system when the Units are expanded.

Name	Register Addresses	Remarks
Data Trace Definition Existence	SB159980	Group 1
	SB159981	Group 2
	SB159982	Group 3
	SB159983	Group 4
	SB159984 to SB15998F	Reserved for system.
Data Trace Execution Status	SB159990	Group 1
	SB159991	Group 2
	SB159992	Group 3
	SB159993	Group 4
	SB159994 to SB15999F	Reserved for system.
Group 1 Record No.	SL16000	Latest record number in group 1.
Group 2 Record No.	SL16002	Latest record number in group 2.
Group 3 Record No.	SL16004	Latest record number in group 3.

Continued on next page.

Continued from previous page.


Name	Register Addresses	Remarks
Group 4 Record No.	SL16006	Latest record number in group 4.
Reserved for system.	SL16008	Reserved for system.
Reserved for system.	SL16010	Reserved for system.

### ◆ Alarm History Information

The data in these registers provide alarm history information for the system registers.


#### ■ Register Configuration

Name	Register Address	Remarks
Current Alarm	SW16200	Cleared when the power is turned ON.
Alarm History Entries	SW16201	Alarm history entries
Alarm Clear	SW16202	1: Alarm cleared 2: Current alarm and history cleared
Alarm History	SW16203 to SW16218	Alarm History Entry 1
	SW16219 to SW16234	Alarm History Entry 2
	:	:
	SW17787 to SW17802	Alarm History Entry 100
Reserved for system.	SW17803 to SW17999	–

Refer to the following section for details.  
 Details (page 4-65)


#### ■ Details

The registers for the alarm history entries are structured as shown below. This example shows the system register addresses for alarm history entry 1.

Register Address	Remarks	Register Address Example
SW□□□□□ + 0	 <p>□□□□ hex</p> <p>01 to 09: Gives the slot number where the Module in which the alarm occurred is mounted.</p> <p>1 to 4: Gives the unit number of the Module in which the alarm occurred is mounted.</p> <p>1 to 7: Gives the Rack number where the Module in which the alarm occurred is mounted.</p>	SW16203
SW□□□□□ + 1	Alarm Code	SW16204
SW□□□□□ + 2	Alarm Detail Format 1: Operation error 2: I/O error 3: Other error	SW16205
SW□□□□□ + 3	Year when alarm occurred	SW16206
SW□□□□□ + 4	Month when alarm occurred	SW16207

Continued on next page.

Continued from previous page.

Register Address	Remarks	Register Address Example
SW□□□□□ + 5	Day when alarm occurred	SW16208
SW□□□□□ + 6	Hour when alarm occurred	SW16209
SW□□□□□ + 7	Minutes when alarm occurred	SW16210
SW□□□□□ + 8	Seconds when alarm occurred	SW16211
SW□□□□□ + 9	Alarm details The information depends on the alarm details format.  ■ Alarm Details (page 4-66)	SW16212
SW□□□□□ + 10		SW16213
SW□□□□□ + 11		SW16214
SW□□□□□ + 12		SW16215
SW□□□□□ + 13		SW16216
SW□□□□□ + 14	Reserved for system.	SW16217
SW□□□□□ + 15	Reserved for system.	SW16218

### ■ Alarm Details

Alarm details are given based on the alarm details format.

#### • Alarm Detail Format = 1 (operation error)

Register Address	Remarks	Register Address Example
SW□□□□□ + 9	Error Drawing No.	SW16212
SW□□□□□ + 10	Calling Drawing No.	SW16213
SW□□□□□ + 11	Calling Drawing Step No.	SW16214
SW□□□□□ + 12	Reserved for system.	SW16215
SW□□□□□ + 13	Reserved for system.	SW16216

#### • Alarm Detail Format = 2 (I/O error)

Register Address	Remarks	Register Address Example
SW□□□□□ + 9	Depends on the specifications of the Optional Module.	SW16212
SW□□□□□ + 10	Depends on the specifications of the Optional Module.	SW16213
SW□□□□□ + 11	Depends on the specifications of the Optional Module.	SW16214
SW□□□□□ + 12	Depends on the specifications of the Optional Module.	SW16215
SW□□□□□ + 13	Depends on the specifications of the Optional Module.	SW16216

#### • Alarm Detail Format = 3 (other error)

Register Address	Remarks	Register Address Example
SW□□□□□ + 9	Reserved for system.	SW16212
SW□□□□□ + 10	Reserved for system.	SW16213
SW□□□□□ + 11	Reserved for system.	SW16214
SW□□□□□ + 12	Reserved for system.	SW16215
SW□□□□□ + 13	Reserved for system.	SW16216



### ◆ Product information



The data in these registers give information on the CPU Unit.

Name	Register Address	Remarks
Serial ID Information	SW20000	CPU Unit serial ID (15 ASCII characters + NULL character)
	SW20001	
	SW20002	
	SW20003	
	SW20004	
	SW20005	
	SW20006	
	SW20007	
	SW20008 to SW20015	Reserved for system.
Reserved for system.	SW20016 to SW22063	—

### ◆ Unit and Rack Information


The data in these registers give hardware information on the Racks and Units for Racks 1 and 5 to 7.

#### ■ Register Configuration

Name	Register Address	Remarks		
Unit and Rack Information	SW23000	Rack 1	0: Rack not mounted, 1: Rack mounted	
	SW23001		Rack Status Refer to the following section for details.  ■ <i>Rack Status Details (page 4-68)</i>	
	SW23002 to SW23007		Reserved for system.	
	SW23008		Rack Expansion Interface Unit	Unit ID (Low)
	SW23009			Unit ID (High)
	SW23010		Rack Expansion Interface Unit	Unit Status Refer to the following sections for details on the Unit status.  ■ <i>Unit Status Details (page 4-68)</i>
	SW23011			Reserved for system.
	SW23012 to SW23015		Power Supply Unit	Same as above.
	SW23016 to SW23019		CPU Unit	Same as above.
	SW23020 to SW23023		Unit 1	Same as above.
	SW23024 to SW23027		Unit 2	Same as above.
	SW23028 to SW23031		Unit 3	Same as above.
	SW23032 to SW23035		Unit 4	Same as above.
	SW23036 to SW23039		Unit 5	Same as above.

Continued on next page.

Continued from previous page.

Name	Register Address	Remarks		
Unit and Rack Information	SW23040	Rack 5	0: Rack not mounted, 1: Rack mounted	
	SW23041		Rack Status Refer to the following section for details.  ■ <i>Rack Status Details (page 4-68)</i>	
	SW23042 to SW23047		Reserved for system.	
	SW23048 to SW23051		Rack Expansion Interface Unit	Same as above.
	SW23052 to SW23055		Power Supply Unit	Same as above.
	SW23056 to SW23059		Unit 1	Same as above.
	SW23060 to SW23063		Unit 2	Same as above.
	SW23064 to SW23067		Unit 3	Same as above.
	SW23068 to SW23071		Unit 4	Same as above.
	SW23072 to SW23075		Unit 5	Same as above.
	SW23076 to SW23079		Unit 6	Same as above.
	SW23080 to SW23119		Rack 6	Same as above.
	SW23120 to SW23159		Rack 7	Same as above.

### ■ Rack Status Details

The possible Rack status values are listed in the following table.

Value	Status
0	No Rack has been set up.
1	A Rack has been set up, but has not been mounted.
2	A Rack has been set up, and a Rack that matches the settings has been mounted.
3 or more	Reserved for system.

**Information**

Refer to the Module Configuration Definitions Tab Page for details on Rack settings.

### ■ Unit Status Details

The possible Unit status values are listed in the following table.

Value	Status
0	No Unit has been set up.
1	A Unit has been set up, but it has not been mounted.
2	A Unit has been set up, and a Unit that matches the settings has been mounted.
3 and 4	Reserved for system.
5	A Unit has been set up, but the Unit mounted does not match the settings.
6 or more	Reserved for system.

**Information**

Refer to the Module Configuration Definitions Tab Page for details on Unit settings.

◆ Data Logging Execution Status

The data in these registers give the execution status of data logging.

Name	Register Address	Remarks	
Data Logging Definition Existence	SW24000	SB240000	0: Logging 1 definition does not exist, 1: Logging 1 definition exists
		SB240001	0: Logging 2 definition does not exist, 1: Logging 2 definition exists
		SB240002	0: Logging 3 definition does not exist, 1: Logging 3 definition exists
		SB240003	0: Logging 4 definition does not exist, 1: Logging 4 definition exists
		SB240004 to SB24000F	Reserved for system.
Data Logging Execution Status	SW24001	SB240010	0: Logging 1 is in progress, 1: Logging 1 is stopped
		SB240011	0: Logging 2 is in progress, 1: Logging 2 is stopped
		SB240012	0: Logging 3 is in progress, 1: Logging 3 is stopped
		SB240013	0: Logging 4 is in progress, 1: Logging 4 is stopped
		SB240014 to SB240017	Reserved for system.
		SB240018	0: Logging 1 is not waiting for trigger condition, 1: Logging 1 is waiting for trigger con- dition
		SB240019	0: Logging 2 is not waiting for trigger condition, 1: Logging 2 is waiting for trigger con- dition
		SB24001A	0: Logging 3 is not waiting for trigger condition, 1: Logging 3 is waiting for trigger con- dition
		SB24001B	0: Logging 4 is not waiting for trigger condition, 1: Logging 4 is waiting for trigger con- dition
		SB24001C to SB24001F	Reserved for system.



Continued on next page.

Continued from previous page.

Name		Register Address	Remarks
Data Logging Execution Sta- tus Details	Logging 1	SL24002	File update counter
		SQ24004	Latest record number
		SW24008	Overrun counter
		SW24009	Error Code 0000 hex: No error, 0001 hex: No USB memory device at start of logging, 0002 hex: No USB memory device while logging is in progress, 0003 hex: Directory creation error, 0004 hex: File creation error, 0005 hex: File write error
		SW24010 and SW24011	Reserved for system.
		SW24012 to SW24043	Latest folder name
		SW24044 to SW24065	Latest file name (includes extension such as .csv)
	Logging 2	SW24066 to SW24129	Same as Logging 1.
	Logging 3	SW24130 to SW24193	Same as Logging 1.
	Logging 4	SW24194 to SW24257	Same as Logging 1.
Reserved for system.		SW24258 to SW24321	–



### ◆ Automatic Reception Status for Ethernet Communications

The data in these registers give the execution status of automatic reception.

Name	Register Address	Contents	
Circuit Number 1	Common Status	SW25000	Rack No.
		SW25001	Unit No.
		SW25002	Slot No.
		SW25003	Sub-slot No.
	CH1 Status	SW25004	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25005	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25006	Transmission pass counter
		SW25007	Reception pass counter
		SW25008	Error counter
		SW25009 to SW25011	Reserved for system.
	CH2 Status	SW25012 to SW25019	Same as CH1 status.
	CH3 Status	SW25020 to SW25027	Same as CH1 status.
	CH4 Status	SW25028 to SW25035	Same as CH1 status.
	CH5 Status	SW25036 to SW25043	Same as CH1 status.
CH6 Status	SW25044 to SW25051	Same as CH1 status.	
CH7 Status	SW25052 to SW25059	Same as CH1 status.	
CH8 Status	SW25060 to SW25067	Same as CH1 status.	
CH9 Status	SW25068 to SW25075	Same as CH1 status.	
CH10 Status	SW25076 to SW25083	Same as CH1 status.	



Continued on next page.

Continued from previous page.

	Name	Register Address	Contents
Circuit Number 2	Common Status	SW25084	Rack No.
		SW25085	Unit No.
		SW25086	Slot No.
		SW25087	Sub-slot No.
	CH1 Status	SW25088	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25089	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25090	Transmission pass counter
		SW25091	Reception pass counter
		SW25092	Error counter
		SW25093 to SW25095	Reserved for system.
	CH2 Status	SW25096 to SW25103	Same as CH1 status.
	CH3 Status	SW25104 to SW25111	Same as CH1 status.
	CH4 Status	SW25112 to SW25119	Same as CH1 status.
	CH5 Status	SW25120 to SW25127	Same as CH1 status.
	CH6 Status	SW25128 to SW25135	Same as CH1 status.
	CH7 Status	SW25136 to SW25143	Same as CH1 status.
	CH8 Status	SW25144 to SW25151	Same as CH1 status.
	CH9 Status	SW25152 to SW25159	Same as CH1 status.
	CH10 Status	SW25160 to SW25167	Same as CH1 status.



Continued on next page.

Continued from previous page.

Name	Register Address	Contents	
Circuit Number 3	Common Status	SW25168	Rack No.
		SW25169	Unit No.
		SW25170	Slot No.
		SW25171	Sub-slot No.
	CH1 Status	SW25172	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25173	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25174	Transmission pass counter
		SW25175	Reception pass counter
		SW25176	Error counter
		SW25177 to SW25179	Reserved for system.
	CH2 Status	SW25180 to SW25187	Same as CH1 status.
	CH3 Status	SW25188 to SW25195	Same as CH1 status.
	CH4 Status	SW25196 to SW25203	Same as CH1 status.
	CH5 Status	SW25204 to SW25211	Same as CH1 status.
CH6 Status	SW25212 to SW25219	Same as CH1 status.	
CH7 Status	SW25220 to SW25227	Same as CH1 status.	
CH8 Status	SW25228 to SW25235	Same as CH1 status.	
CH9 Status	SW25236 to SW25243	Same as CH1 status.	
CH10 Status	SW25244 to SW25251	Same as CH1 status.	

Continued on next page.



Continued from previous page.

	Name	Register Address	Contents
Circuit Number 4	Common Status	SW25252	Rack No.
		SW25253	Unit No.
		SW25254	Slot No.
		SW25255	Sub-slot No.
	CH1 Status	SW25256	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25257	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25258	Transmission pass counter
		SW25259	Reception pass counter
		SW25260	Error counter
		SW25261 to SW25263	Reserved for system.
	CH2 Status	SW25264 to SW25271	Same as CH1 status.
	CH3 Status	SW25272 to SW25279	Same as CH1 status.
	CH4 Status	SW25280 to SW25287	Same as CH1 status.
	CH5 Status	SW25288 to SW25295	Same as CH1 status.
	CH6 Status	SW25296 to SW25303	Same as CH1 status.
	CH7 Status	SW25304 to SW25311	Same as CH1 status.
CH8 Status	SW25312 to SW25319	Same as CH1 status.	
CH9 Status	SW25320 to SW25327	Same as CH1 status.	
CH10 Status	SW25328 to SW25335	Same as CH1 status.	

Continued on next page.





Continued from previous page.

	Name	Register Address	Contents
Circuit Number 5	Common Status	SW25336	Rack No.
		SW25337	Unit No.
		SW25338	Slot No.
		SW25339	Sub-slot No.
	CH1 Status	SW25340	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25341	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25342	Transmission pass counter
		SW25343	Reception pass counter
		SW25344	Error counter
		SW25345 to SW25347	Reserved for system.
	CH2 Status	SW25348 to SW25355	Same as CH1 status.
	CH3 Status	SW25356 to SW25363	Same as CH1 status.
	CH4 Status	SW25364 to SW25371	Same as CH1 status.
	CH5 Status	SW25372 to SW25379	Same as CH1 status.
	CH6 Status	SW25380 to SW25387	Same as CH1 status.
	CH7 Status	SW25388 to SW25395	Same as CH1 status.
CH8 Status	SW25396 to SW25403	Same as CH1 status.	
CH9 Status	SW25404 to SW25411	Same as CH1 status.	
CH10 Status	SW25412 to SW25419	Same as CH1 status.	



Continued on next page.

Continued from previous page.

	Name	Register Address	Contents
Circuit Number 6	Common Status	SW25420	Rack No.
		SW25421	Unit No.
		SW25422	Slot No.
		SW25423	Sub-slot No.
	CH1 Status	SW25424	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25425	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25426	Transmission pass counter
		SW25427	Reception pass counter
		SW25428	Error counter
		SW25429 to SW25431	Reserved for system.
	CH2 Status	SW25432 to SW25439	Same as CH1 status.
	CH3 Status	SW25440 to SW25447	Same as CH1 status.
	CH4 Status	SW25448 to SW25455	Same as CH1 status.
	CH5 Status	SW25456 to SW25463	Same as CH1 status.
	CH6 Status	SW25464 to SW25471	Same as CH1 status.
	CH7 Status	SW25472 to SW25479	Same as CH1 status.
CH8 Status	SW25480 to SW25487	Same as CH1 status.	
CH9 Status	SW25488 to SW25495	Same as CH1 status.	
CH10 Status	SW25496 to SW25503	Same as CH1 status.	



Continued on next page.

Continued from previous page.

	Name	Register Address	Contents
Circuit Number 7	Common Status	SW25504	Rack No.
		SW25505	Unit No.
		SW25506	Slot No.
		SW25507	Sub-slot No.
	CH1 Status	SW25508	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25509	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25510	Transmission pass counter
		SW25511	Reception pass counter
		SW25512	Error counter
		SW25513 to SW25515	Reserved for system.
	CH2 Status	SW25516 to SW25523	Same as CH1 status.
	CH3 Status	SW25524 to SW25531	Same as CH1 status.
	CH4 Status	SW25532 to SW25539	Same as CH1 status.
	CH5 Status	SW25540 to SW25547	Same as CH1 status.
	CH6 Status	SW25548 to SW25555	Same as CH1 status.
	CH7 Status	SW25556 to SW25563	Same as CH1 status.
CH8 Status	SW25564 to SW25571	Same as CH1 status.	
CH9 Status	SW25572 to SW25579	Same as CH1 status.	
CH10 Status	SW25580 to SW25587	Same as CH1 status.	

Continued on next page.

Continued from previous page.

	Name	Register Address	Contents
Circuit Number 8	Common Status	SW25588	Rack No.
		SW25589	Unit No.
		SW25590	Slot No.
		SW25591	Sub-slot No.
	CH1 Status	SW25592	Transmission status Refer to the following section for details.  ■ <i>Transmission Status (page 4-78)</i>
		SW25593	Latest error status Refer to the following section for details.  ■ <i>Error Status (page 4-79)</i>
		SW25594	Transmission pass counter
		SW25595	Reception pass counter
		SW25596	Error counter
		SW25597 to SW25599	Reserved for system.
	CH2 Status	SW25600 to SW25607	Same as CH1 status.
	CH3 Status	SW25608 to SW25615	Same as CH1 status.
	CH4 Status	SW25616 to SW25623	Same as CH1 status.
	CH5 Status	SW25624 to SW25631	Same as CH1 status.
	CH6 Status	SW25632 to SW25639	Same as CH1 status.
	CH7 Status	SW25640 to SW25647	Same as CH1 status.
	CH8 Status	SW25648 to SW25655	Same as CH1 status.
	CH9 Status	SW25656 to SW25663	Same as CH1 status.
	CH10 Status	SW25664 to SW25671	Same as CH1 status.

#### ■ Transmission Status

Register Value	Status	Contents
0	–	Unused connection.
1	IDLE	Standby mode for executing message functions.
2	WAIT	Waiting to establish a connection.
3	CONNECT	Ready to send and receive data.

■ Error Status

Register Value	Status	Contents
0	No Error	Normal
1	Socket Creation Error	System error
2	Local Port Number Error	Setting error in local station port number (The same address is bound during disconnection of the TCP connection.)
3	Changing Socket Attribute Error	System error (for TCP)
4	M-SND Connection Error	Connection error (The connection was rejected by the remote station when establishing a connection with an unpassive open for TCP.)
5	M-RCV Connection Error	Connection error (connection with passive open for TCP)
6	System Error	System error
7	TCP Data Send Error	Data sending error (The remote station does not exist or has not started when using TCP.)
8	UDP Data Send Error	Data sending error (for UDP)
9	TCP Data Receive Error	Data reception error (The MP3000 received a request to disconnect from the remote station for TCP.)
10	UDP Data Receive Error	Data reception error (for UDP)
11	Changing Socket Option Error	System error
12	Data Conversion Error	Error in converting data

## 4.4 Base Unit Specifications


The specifications of the Base Units are listed in the following table.

Item	Specification		
	3 slots	5 slots	8 slots
Model	JEPMC-BUB3003-E	JEPMC-BUB3005-E	JEPMC-BUB3008-E
Abbreviation	MBU-B03	MBU-B05	MBU-B08
Number of Slots	3	5	8
Applicable Modules	MP2000-series Optional Modules		

## 4.5

## Rack Expansion Interface Unit Specifications

This table gives the hardware specifications of the Rack Expansion Interface Units.

Item	Specifications	
	For Main Rack	For Expansion Rack
Model	JEPMC-EXU3001-E	JEPMC-EXU3002-E
Abbreviation	EXU-001	EXU-002
Number of Ports	3	1
Applicable Racks	Main Rack	Expansion Rack
Rack Numbers	Rack 1 (Main Rack)	Racks are numbered as follows according to the connection port on the EXU-001. <ul style="list-style-type: none"> <li>• Connected to port 1: Rack 5</li> <li>• Connected to port 2: Rack 6</li> <li>• Connected to port 3: Rack 7</li> </ul>
Indicators and Displays	LKP1, LKP2, LKP3, and ERR	LKP1 and ERR
	Refer to the following section for details.  <i>Indicators (page 2-16)</i>	

**Information**

Turn ON the power for the Expansion Racks first, followed by the Main Rack. If the power for the Expansion Racks is turned ON after the Main Rack, a reset operation will cause the Main Rack to reset.

# External Dimensions

---




This section provides external diagrams and dimensions for the MP3200.

5.1	Power Supply Units . . . . .	5-2
5.2	CPU Units . . . . .	5-3
5.3	Base Units . . . . .	5-4
5.4	Rack Expansion Interface Units . . . . .	5-6



# 5.1 Power Supply Units





Approx. weight: 0.6 kg

## 5.2




## CPU Units

CPU-201



Approx. weight: 0.6 kg


CPU-202



Approx. weight: 0.7 kg


## 5.3 Base Units

Three-slot Base Unit




Approx. weight: 0.4 kg

Five-slot Base Unit






Approx. weight: 0.4 kg

Eight-slot Base Unit



Approx. weight: 0.4 kg

## 5.4 Rack Expansion Interface Units



Approx. weight: 0.2 kg

# Index

address	3-24	functions	3-5
Alarm Reset Request	3-12	standard system functions	3-6
array registers	3-30	user functions	3-6
<b>A</b>			
<b>B</b>			
background processing	3-31	global registers	3-19, 3-20
Base Units	2-14	grandchild drawings	3-3
appearance	2-14	<b>H</b>	
specifications	4-80	high-speed (H) scan	3-32
Battery	1-9	<b>I</b>	
bit	3-24	I/O Modules	1-13
<b>C</b>			
calendar	3-93	index registers	3-27
child drawings	3-3	integer	3-24
circuit numbers	1-15	Interpolation Override Setting	3-13
precautions when setting the circuit numbers	1-15	<b>L</b>	
Communications Function Module	3-48	ladder programs	3-2
specifications	4-9	local registers	3-19, 3-22
Communications Modules	1-12	low-speed (L) scan	3-34
CPU Unit	2-5	<b>M</b>	
appearance	2-5	Main CPU Unit	3-102
basic functionality	3-2	Main Rack	1-3
Function Modules	3-38	M-EXECUTOR	3-56
hardware specifications	4-5	detail settings	3-60
performance specifications	4-6	execution scheduling	3-68
CPU-201	4-5	initialization	3-57
CPU-202	4-5	registering program execution	3-67
<b>D</b>			
data logging	3-70	specifications	4-11
definition information updated by self configuration	3-46	Module Configuration Definition Tab Page	3-60
DIP switch	2-9	Motion Control Function Modules	3-50
double-length integer	3-24	specifications	4-10
double-precision real number	3-24	Motion Modules	1-12
DWGA	3-4	motion programs	3-6
DWGH	3-4	execution	3-8
DWGI	3-4	monitoring execution information	3-16
DWGL	3-4	specifying motion programs	3-9
<b>E</b>			
Expansion Rack	1-3	work registers	3-10
external dimensions		MP3200	1-2
Base Unit	5-4	list	1-11
CPU Units	5-3	precautions when combining products	1-14
Power Supply Unit	5-2	usage conditions	4-2
Rack Expansion Interface Units	5-6	multi-CPU functions	3-94
<b>F</b>			
file transfer	3-89	<b>O</b>	
		operation error drawings	3-3
		Optional Modules	1-12
		precautions when combining Optional Modules	1-14
		<b>P</b>	
		parent drawings	3-3
		power connector	2-3

Power Supply Units -----2-2  
 appearance-----2-2  
 specifications-----4-4  
 precautions when setting module configuration definitions ----1-15  
 Program Single-block Mode Selection -----3-12  
 Program Single-block Start Request-----3-12  
 programs -----3-2  
 types of programs -----3-2

Q

quadruple-length integer -----3-24

R

Rack Expansion Interface Unit -----2-15  
 appearance and part names -----2-15  
 specifications-----4-81  
 Racks-----1-3  
 real number -----3-24  
 registers -----3-19  
 data types-----3-24  
 register types -----3-20  
 structure of register addresses -----3-20  
 Request for Pause of Program -----3-12  
 Request for Start of Continuous Program Operation -----3-12  
 Request for Start of Program Operation -----3-12  
 Request for Stop of Program -----3-12  
 RLYOUT connector -----2-3

S

scans -----3-32  
 types of scans-----3-32  
 scheduling the execution of high-speed  
 and low-speed scan process drawings-----3-31  
 security -----3-93  
 self configuration -----3-38  
 specified Modules-----3-44  
 using the DIP switch-----3-39  
 using the MPE720 -----3-42  
 sequence programs -----3-17  
 execution -----3-17  
 specifying sequence programs -----3-18  
 work registers-----3-18  
 setting the high-speed and low-speed times-----3-34  
 Skip 1 Information -----3-12  
 Skip 2 Information -----3-12  
 slave CPU synchronization -----3-94  
 Sub CPU synchronization -----3-95  
 conditions -----3-97  
 data transfer timing-----3-107  
 I/O registers -----3-104  
 overview -----3-95  
 precautions-----3-98  
 scan overhead guidelines-----3-108  
 Sub CPU Units -----3-102

system configuration-----1-8  
 devices and components -----1-9  
 system registers -----4-13  
 alarm history information -----4-65  
 automatic reception status for Ethernet communications ---4-71  
 data logging execution status-----4-69  
 detailed user operation error status-----4-25  
 expanded unit and module information-----4-59  
 expansion system I/O error status-----4-55  
 expansion system service execution status -----4-64  
 expansion system status -----4-64  
 interrupt status -----4-28  
 message relaying status-----4-27  
 Module information -----4-29  
 motion program execution information-----4-32  
 MPU-01 Module status -----4-31  
 overall configuration-----4-13  
 product information -----4-67  
 Rack information -----4-67  
 security status-----4-26  
 system error status -----4-20  
 system I/O error status -----4-26  
 system service execution status -----4-25  
 system service registers-----4-15  
 system status -----4-19  
 USB-related system status-----4-27  
 user operation error status -----4-22  
 System Work Number Setting -----3-13

U

USB memory -----3-85

## Revision History

The date of publication, revision number, and web revision number are given at the bottom right of the back cover. Refer to the following example.

MANUAL NO. SIEP C880725 10A <0>-1  
 Published in Japan March 2012

WEB revision number  
 Revision number  
 Date of publication

Date of Publication	Rev. No.	WEB Rev. No.	Section	Revised Contents	
March 2018	<4>	0	–	Printed version of the manual that is available on the web (web version: SIEP C880725 10D <3>-3)	
			4.1	Revision: Noise Resistance	
			Back cover	Revision: Address	
March 2017	<3>	3	3.2	Revision: Correction of terms used in the table about batch saving to USB memory (Change from “Registers to Load” to “Registers to Save”.)	
February 2017			2	3.2	Addition: Information on versions that support file transfer for the CPU Unit and MPE720
				Back cover	Revision: Address
June 2016			1	3.2	Revision: Information on batch transfer and batch loading with USB memory.
November 2015			0	Front cover	Revision: Format
	3.2	Addition: Information related to the alarm history			
	Back cover	Revision: Address and format			
January 2014	<2>	0	–	Based on Japanese user’s manual, SIJP C880725 10D<4>-0, published in September 2013.	
			All chapters	Revision: Terminology (“Base Unit” changed to “MP3200.”)	
				Addition: Information related to Rack Expansion Interface Unit	
				Addition: Information related to the CPU-202 CPU Unit	
				Addition: Information related to the MBU-B03 Base Unit	
			Chapter 1	Addition: Information on JEPMC-OP3007-E Rack Reinforcement Bracket	
			3.3	Addition: Information related to multi-CPU functions	
Back cover	Revision: Address				
September 2012	<1>	0	–	Based on Japanese user’s manual, SIJP C880725 10B<1>-0, published in May 2012.	
March 2012	<0>	1	All chapters	Deletion: Description of Rack Expansion Interface Unit	
December 2011	–	–	–	First edition	



# Machine Controller MP3000 Series

# MP3200

# USER'S MANUAL

---

#### **IRUMA BUSINESS CENTER (SOLUTION CENTER)**

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan  
Phone: +81-4-2962-5151 Fax: +81-4-2962-6138  
<http://www.yaskawa.co.jp>

#### **YASKAWA AMERICA, INC.**

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.  
Phone: +1-800-YASKAWA (927-5292) or +1-847-887-7000 Fax: +1-847-887-7310  
<http://www.yaskawa.com>

#### **YASKAWA ELÉTRICO DO BRASIL LTDA.**

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil  
Phone: +55-11-3585-1100 Fax: +55-11-3585-1187  
<http://www.yaskawa.com.br>

#### **YASKAWA EUROPE GmbH**

Hauptstraße 185, 65760 Eschborn, Germany  
Phone: +49-6196-569-300 Fax: +49-6196-569-398  
<http://www.yaskawa.eu.com> E-mail: [info@yaskawa.eu.com](mailto:info@yaskawa.eu.com)

#### **YASKAWA ELECTRIC KOREA CORPORATION**

35F, Three IFC, 10 Gukjegeumyung-ro, Yeongdeungpo-gu, Seoul, 07326, Korea  
Phone: +82-2-784-7844 Fax: +82-2-784-8495  
<http://www.yaskawa.co.kr>

#### **YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.**

151, Lorong Chuan, #04-02A, New Tech Park, 556741, Singapore  
Phone: +65-6282-3003 Fax: +65-6289-3003  
<http://www.yaskawa.com.sg>

#### **YASKAWA ELECTRIC (THAILAND) CO., LTD.**

59, 1st-5th Floor, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand  
Phone: +66-2-017-0099 Fax: +66-2-017-0799  
<http://www.yaskawa.co.th>

#### **YASKAWA ELECTRIC (CHINA) CO., LTD.**

22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China  
Phone: +86-21-5385-2200 Fax: +86-21-5385-3299  
<http://www.yaskawa.com.cn>

#### **YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE**

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Ave.,  
Dong Cheng District, Beijing, 100738, China  
Phone: +86-10-8518-4086 Fax: +86-10-8518-4082

#### **YASKAWA ELECTRIC TAIWAN CORPORATION**

12F, No. 207, Sec. 3, Beishin Rd., Shindian Dist., New Taipei City 23143, Taiwan  
Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 or +886-2-8913-1519  
<http://www.yaskawa.com.tw>

---

## **YASKAWA**

**YASKAWA ELECTRIC CORPORATION**

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2011 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP C880725 10D <4>-0

Published in Japan March 2018  
17-4-13