

ENGINEERING PUBLICATION

MOTION CONTROL DIVISION

PRODUCT: JUSP-NS600 SIGMA II INDEXER

SUBJECT: USING THE DIGITAL OPERATOR WITH THE SIGMA II INDEXER

CATEGORY: TECH. NOTE

ENGINEER: Paul Zajac

DISTRIBUTION: YEA

Summary:

The following document describes how to use the digital operator with the JUSP-NS600 Sigma II Indexer. The digital operator can be used to monitor the status of the servo system, perform auxiliary functions, and read and write parameters, index table settings, jog speed table settings, and zone table settings, when connected to the CN7 communication port on the Indexer.

INDEXER JUSP-NS600

Using the Digital Operator

1. Connection - P.2
2. Status Display Screen - P.3
3. Switching the Basic Screen - P.4
4. Parameter Editing Screen- P.5
5. Monitor Screen - P.7

Un000	Motor Speed	P.8
Un002	Torque	P.8
Un003	No. of Speed Pulses	P.8
Un004	Electrical Angle	P.8
Un005	SGDH Input Signal	P.8
Un006	SGDH Output Signal	P.8
Un007	Reference Speed	P.8
Un008	Position Deviation	P.8
Un009	Cumulative Load Factor	P.9
Un00A	Regenerative Load Factor	P.9
Un00B	DB Load Factor	P.9
Un00C	Position Reference Counter	P.9
Un00D	Encoder Pulse Counter	P.9
Un800	Error	P.10
Un801	NS600 Input Signal	P.10
Un802	NS600 Output Signal	P.10
Un803	Status Flag	P.10
Un804	Current Position of Position Reference	P.10
Un805	Current Position of Motor	P.10
Un806	Positioning Target Position	P.11
Un807	Positioning Distance	P.11
Un808	Registration Target Position	P.11
Un809	Registration Range	P.11
Un80A	Program Step	P.11
Un80B	Elapsed Time Status of Event	P.11
Un80C	Execution Status of LOOP	P.11
Un80D	Serial Communication Received Character Trace	P.12


6. Auxiliary Function Execution Screen- P.14

Fn000	Alarm Trace Display	P.15
Fn001	Rigidity Setting	P.16
Fn002	JOG Operation	P.17
Fn003	Origin Search	P.18
Fn005	Parameter Initialization	P.20
Fn006	Alarm Traceback Initialization	P.21
Fn007	Store Inertia Ratio	P.22
Fn008	Reset Absolute Encoder	P.23
Fn00C	Analog Monitor Zero Adjustment	P.25
Fn00D	Analog Monitor Gain Adjustment	P.26
Fn00E	Motor Current Automatic Zero Adjustment	P.27
Fn00F	Motor Current Manual Zero Adjustment	P.28
Fn010	Write Protection Setting	P.29
Fn011	Motor Type Code Display	P.30
Fn012	SGDH Software Version Display	P.31
Fn013	Multi-Turn Limit Setting	P.32
Fn800	NS600 Software Version Display	P.34
Fn801	NS600 Model Code Display	P.35
Fn802	NS600 Unique Specification Number Display	P.36
Fn803	Save Program (Index) Table	P.37
Fn804	ZONE Table Storage	P.38
Fn805	Save JOG Speed Table	P.39

1. Connection

Connect to CN7 on the NS600.













Digital Operator
JUSP-OP02A




Key	Name	Function
	ALARM	This operates as an alarm reset in the status display screen.
	DSPL/SET	It is used to switch screens and operate auxiliary functions.
	DATA/ENTER	Used for numeric input.
	UP	Used for deleting numbers.
	DOWN	
	LEFT	Used for moving the cursor.
	RIGHT	
	JOG SVON	Used for switching the servo ON/OFF during JOG operation.

The digital operator can be connected/disconnected with the power


2. Status Display Screen

Display	Meaning	
	 bb bb: Base Block	Servo OFF state.
	 run	Servo ON state.
	 Pot P-OT: Positive-side Over Travel	P-OT state. Forward run prohibition by P-OT signal.
	 not N-OT: Negative-side Over Travel	N-OT state. Reverse run prohibition by N-OT signal.
	 PLS P-IS: Positive-side Limit Switch	P-IS state. Forward run prohibition by according to parameter
	 nLS N-IS: Negative-side Limit Switch	N-IS state. Reverse run prohibition according to parameter
	 Code A.xx	Alarm or warning state. A.xx:SGDH alarm or warning code
 Code ExxA	Alarm state. ExxA: NS600 Alarm Code	
 Code ExxE	2 Displayed for only 2 minutes upon alarm occurrence.	
 StorE Flashing	Storing to flash memory. Do not shut off control power at this time.	
 InIt Flashing	Initializing factory settings. Do not shut off control power at this time.	




In this screen  Only acts as an alarm reset.
At alarm occurrence, reset after removing the cause of the alarm.

3. Basic Screen Switching







4. Parameter Editing Screen















There are both online and offline parameters. Offline parameters are enabled after the control power is cycled.




















The parameter display methods are shown in the table below.










Number Type	Display Method	
5-digit Decimal	Exp: 	
4-digit Hexadecimal	Exp. : 	This display is a parameter in units of digits. For example, if Pn000.0 is stated, this indicates the last digit at the bottom of Pn000.
8-digit Decimal	Exp:  <p style="text-align: center;">← Switches the upper 3-digits and lower 5-digits screens →</p>	
8digit Signed Decimals	Exp:  <p style="text-align: center;">← Switches the upper 3-digits and lower 5-digits screens →</p>	




5. Monitor Screen






Monitor Number	Monitor Content	Example
Un000	Motor Speed [rpm]	Exp:  Displays the motor speed.
Un002	Torque [%]	Exp:  Displays the torque. Displays as a percentage [%] of rated torque.
Un003	No. of Speed Pulses	Exp:  Displays the number of encoder pulses counted from the start of the encoder C-phase.
Un004	Electrical Angle [deg]	Exp:  Displays the electrical angle of the motor.
Un005	SGDH Input Signal (CN1)	Displays whether each signal is ON/OFF. The ON/OFF logic is the input photocoupler ON/OFF state. Exp:  
Un006	SGDH Output Signal	Displays whether each signal is ON/OFF. The ON/OFF logic is the output photocoupler ON/OFF state. Exp:  
Un007	Reference Speed [rpm]	Exp:  Displays the reference speed of the position reference.
Un008	Position Deviation [Command Unit]	Exp: 6250 command   Displays the position deviation. Displays "SAT" when ± 9999 us exceeded. SAT


Monitor Number	Monitor Content	Example
Un009	Cumulative Load Factor	<p>Exp:  Displays the operating torque at 10sec intervals. Displays as a percentage [%] of rated torque.</p>
Un00A	Regenerative Load Factor	<p>Exp:  Displays the power consumption of the regen resistor at 10sec intervals.</p>
Un00B	DB Load Factor [%]	<p>Exp:  Displays the power consumption of the dynamic brake at 10sec intervals. Displays as a percentage [%] of allowable dynamic brake power consumption.</p>
Un00	Position Reference Counter	<p>Displays the position reference counter used in the monitor.</p> <p>Exp: 01234567 [Command]</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;">  Upper 2 </div> <div style="margin: 0 20px;">  or  ← Switches to the upper 2Bytes and lower 2Bytes screen. → </div> <div style="text-align: center;">  Lower 2 </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; width: fit-content; margin: 0 auto;"> <div style="display: flex; align-items: center; justify-content: center;">   →   </div> <p style="text-align: center; margin-top: 5px;">Pressing either one will clear the counter.</p> </div>
Un00	Encoder Pulse Counter [Pulses]	<p>Displays the encoder pulse counter used in the monitor.</p> <p>Exp: 89ABCDEF</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;">  Upper 2 </div> <div style="margin: 0 20px;">  or  ← Switches to the upper 2Bytes and lower 2Bytes screen. → </div> <div style="text-align: center;">  Lower 2 </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; width: fit-content; margin: 0 auto;"> <div style="display: flex; align-items: center; justify-content: center;">   →   </div> <p style="text-align: center; margin-top: 5px;">Pressing either one will clear the counter.</p> </div>





Monitor Number	Monitor Content	Example
Un800	Error	<p>Exp:  Displays the most recently occurred error. Displays "none" if no errors have ever occurred.</p>
Un801	NS600 Input Signal (CN4)	<p>Exp  Displays whether each signal is ON/OFF. The ON/OFF logic is the input photocoupler ON/OFF state.</p> 
Un802	NS600 Output Signal	<p>Exp  Displays whether each signal is ON/OFF. The ON/OFF logic is the input photocoupler ON/OFF state.</p> 
Un803	Status Flag	<p>Exp  Displays various flags showing the status.</p> 
Un804	Current Position of Position Reference	<p>Exp: +12345678[command]</p>  <p>Switches the upper 3-digits and lower 5-digits screens.</p>
Un805	Current Position of Motor	<p>Exp: -12345678[command]</p>  <p>Switches the upper 3-digits and lower 5-digits screens.</p>







Monitor Number	Monitor Content	Example
Un80	Serial Communication	<p>Shows the history of characters received in serial communication.</p> <p>Exp</p>  <p>These can be traced back up to 99 characters from the end.</p> <p>Reception</p> <p>Empty: No reception errors. The following values are calculated and displayed should there be an error.</p> <ul style="list-style-type: none"> 1: Overrun Error 2: Framing Error 4: Parity Error <p>Exp.</p>
Un80E	Serial Communication	<p>Exp.: 5</p>  <p>Shows the number of characters received in serial communication.</p>
Un80F	Serial Communication	<p>Exp.: 1</p>  <p>Shows the number of characters which resulted in reception errors in serial communication.</p>












Monitor Number	Monitor Content	Example
Un810	Serial Communication	<p>Shows the history of characters transmitted in serial communication.</p> <p>Exp.</p>  <p>These can be traced back up to 39 characters from the end.</p> 
Un811	Serial Communication	<p>Exp. : 17</p>  <p>Shows the number of characters transmitted in serial communication.</p>






6. Auxiliary Function Execution Screen





Auxiliary Number	Function	Example
Fn000	Alarm Trace Display	<p>Displays the history of previously generated alarms.</p> <p style="text-align: center;">E n 0 0 0</p> <div style="text-align: center;">  <p>Use this to enter the alarm trace display Pressing this again returns you to the auxiliary function screen.</p> </div> <p>Exp</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>9 E 2 3 A</p>  <p>These can be traced backup to nine instances.</p>  <p>1 A 5 1</p>  <p>0 A 0 9</p> </div> <div style="text-align: center;"> <p>3 A 5 1</p> <p>How many alarms Alarm Code</p> <p>n o n e</p> <p>none</p> <p>Displays "none" if there is no alarm</p> </div> </div>

Auxiliary Number	Function	Example
Fn001	Rigidity Setting	<p>This sets the machine rigidity.</p> <p>Upon execution, this updates the parameters Pn100, Pn101, Pn102, Pn401, and stores the data in the EEPROM</p>  <p>Pressing  without editing returns you to the auxiliary function number screen</p> <p>  Edit here (in this case change to "5".)</p> <p> Execute using this.</p> <p> Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example								
Fn002	JOG Operation	<p style="text-align: center;">Performs JOG operation.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">  Note </div> <p>P-OT, N-OT, P-LS, N-LS (Forward or reverse prohibition by signal or parameter) are disabled during JOG operation.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Use this to enter the JOG operation screen.</p> <p>Use this to switch the servo ON/OFF.</p> <p>This turns the motor forward.</p> <p>This turns the motor in reverse.</p> <p>The speed can be modified in parameter Pn304.</p> </div> <div style="border: 1px solid black; padding: 5px; width: 150px;"> <p style="text-align: center;">Supplement</p> <p>No servo ON in alarm state.</p> </div> </div> <p>Returns you To the auxiliary function number screen</p> <p>Returns you To the auxiliary function number screen</p> <p>Common error</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Display</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;"></td> <td>E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.</td> </tr> <tr> <td style="text-align: center;"></td> <td>E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.</td> </tr> <tr> <td style="text-align: center;"></td> <td>E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.</td> </tr> </tbody> </table>	Display	Meaning		E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.		E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.		E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.
Display	Meaning									
	E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.									
	E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.									
	E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.									


Auxiliary Number	Function	Example				
Fn003	Origin Search	<p>Turn the motor and search for the C-phase.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">  Note </div> <p>P-OT, N-OT, P-LS, N-LS (Forward or reverse prohibition by signal or parameter) are disabled during origin search.</p>  <p>The flowchart illustrates the sequence of operations for the origin search function. It starts with the display 'Fn003'. Pressing the DATA/ENTE key leads to the origin search mode, where the display shows 'E.0Sr'. The 'Csr' label indicates the current search position. Pressing the JOG/SVON key toggles the servo ON/OFF. Pressing the DATA/ENTE key again returns to the 'Fn003' screen. Pressing the up/down arrow keys rotates the motor forward/reverse at 60rpm. When the motor finds the C-phase, the display flashes 'E.0Sr'. Pressing the DATA/ENTE key returns to the 'Fn003' screen.</p> <p>Common errors</p> <table border="1" data-bbox="500 1816 1425 1969"> <thead> <tr> <th>Display</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td></td> <td>E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON.</td> </tr> </tbody> </table>	Display	Meaning		E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON.
Display	Meaning					
	E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON.					

	<p>E5CE: "Unexecutable with main power OFF" error. Cannot be executed while main power is OFF. Turn main power ON and try again.</p>
	<p>E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted. Try again after resetting program execution.</p>




Auxiliary Number	Function	Example				
Fn005	Parameter Initialization	<p>Initializes the parameters and returns to the factory settings.</p> <p>Important! Always displayed in the servo OFF state.</p> <p>Pressing DATA/ENTE without executing will return you to the auxiliary function number screen.</p> <p>Pressing DSPL/SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p> <p>Cycle the control power.</p> <p>End</p> <p>Common errors</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td></td> <td>E5AE: "Unexecutable in servo ON state" error. Cannot be executed while servo is ON. Turn servo OFF and try again.</td> </tr> </tbody> </table>	Display	Meaning		E5AE: "Unexecutable in servo ON state" error. Cannot be executed while servo is ON. Turn servo OFF and try again.
Display	Meaning					
	E5AE: "Unexecutable in servo ON state" error. Cannot be executed while servo is ON. Turn servo OFF and try again.					


Auxiliary Number	Function	Example
Fn006	Alarm Trace Initialize	<p>Clears the history of previously generated alarms.</p> <p>Use this to enter the alarm trace initialization screen.</p> <p>Execute using this.</p> <p>Pressing DATA/ENTE Without executing will return you to the auxiliary function number screen</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example
Fn007	Store Inertia Ratio	<p>Saves the inertia ratio requested in online autotuning into the parameters. When executed, it updates the inertia ratio requested in parameter Pn103 and stores it in the EEPROM</p> <p>Pressing DATA ENTE without executing will return you to the auxiliary function number screen.</p> <p>Pressing DSP/SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example
Fn008	Absolute Encoder Reset	<p>Resets the absolute encoder and clears the recorded position data.</p> <p>Perform in the following situations.</p> <ul style="list-style-type: none"> At first machine start-up When an encoder back-up alarm occurs When the encoder cable is disconnected  <p>The flowchart illustrates the steps for resetting the absolute encoder. It starts with the display showing 'Fn008'. Pressing the 'DATA ENTE' button leads to the 'PG000' screen. Pressing the 'PGCL' button leads to the 'PG005' screen. Pressing the 'DATA ENTE' button again leads to a flashing 'PG005' screen. Pressing the 'DSPL SET' button leads to a flashing 'done' screen. Pressing the 'DATA ENTE' button again returns the display to 'Fn008'. A note indicates that pressing 'DATA ENTE' without executing will return the user to the auxiliary function number screen. A final step is to cycle the control power, leading to 'End'.</p> <p>Pressing DATA ENTE without executing will return you to the auxiliary function number screen.</p> <p>Pressing DSPL SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p> <p>Cycle the control power.</p> <p>End</p>


Common errors


Display	Meaning
	E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.
	E61E: Encoder Mismatch Error Cannot be executed without absolute encoder.
 <p>nO</p>	Improper operation. Try again.


Auxiliary Number	Function	Example
Fn00C	Analog Monitor Zero Adjustment	<p>Executes analog monitor (offset voltage) zero adjustment.</p>  <p>CH1_ CH2_</p> <p>Exp 00005 This displays the current adjustment value.</p> <p>Adjusts the voltage.</p> <p>Returns you to the auxiliary function number screen.</p>










Auxiliary Number	Function	Example
Fn00D	Analog Monitor Gain Adjustment	<p>Performs gain adjustment on analog monitor.</p> <p>The process is as follows:</p> <ul style="list-style-type: none"> Initial display: Fn00d Press DATA/ENTE: This enters the channel selection screen. Display: CH1_000 Press DSPL/SET: Switches the channel. Display: CH2_000 Press Left Arrow: Enters the adjustment screen. Display: 0000. This displays the current adjustment value. Press Right Arrow: Returns to the channel selection screen. Display: CH1_000 Press Up/Down Arrow: Adjusts the voltage. Press DATA/ENTE: Returns you to the auxiliary function number screen. Display: Fn00d



Auxiliary Number	Function	Example						
Fn00E	Motor Current Automatic Zero	<p>Executes automatic motor current (offset current) zero adjustment.</p> <p>Because the offset adjustment for the motor current detection signal is adjusted prior to delivery by Yaskawa, it is normally not necessary for the customer to make adjustments. Use this only when the torque ripple based on the current offset is believed to be producing an excessive error, or when more precision is needed to further decrease the torque ripple.</p> <p>Important Careless execution of this function can lead to degradation of the performance characteristics. Perform this only if the torque ripple occurrences are obviously larger than in other servo amplifiers.</p> <p>Pressing DATA/ENTE Without executing returns you to the auxiliary function number screen.</p> <p>Pressing DSPI/SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p> <p>Common errors</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>E5AE</td> <td>E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.</td> </tr> <tr> <td>E5CE</td> <td>E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.</td> </tr> </tbody> </table>	Display	Meaning	E5AE	E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.	E5CE	E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.
Display	Meaning							
E5AE	E5AE: "Unexecutable in servo ON state" error Cannot be executed while servo is ON. Turn servo OFF and try again.							
E5CE	E5CE: "Unexecutable with main power OFF" error Cannot be executed while main power is OFF. Turn main power ON and try again.							

Auxiliary Number	Function	Example
Fn00F	Motor Current Manual Zero	<p>Executes manual motor current (offset current) zero adjustment.</p> <p>Because the offset adjustment for the motor current detection signal is adjusted prior to delivery by Yaskawa, it is normally not necessary for the customer to make adjustments. Use this only when the torque ripple based on the current offset is believed to be producing an excessive error, or when more precision is needed to further decrease the torque ripple.</p> <p>Important Careless execution of this function can lead to degradation of the performance characteristics. If the torque ripple occurrences are obviously larger than in other servo amplifiers, then perform automatic offset adjustment (Fn00E).</p> <p>Important During manual adjustment, rotate the motor at about 100rpm, and adjust so that the ripple in the torque monitor is minimized. It is necessary to well balance the motor U-phase current and V-phase current offset. Perform the adjustment on both sides</p>  <p>The flowchart illustrates the steps to perform manual motor current zero adjustment:</p> <ul style="list-style-type: none"> Start at the auxiliary function number screen: Fn00F Press DATA/ENTE to enter the channel selection screen. Use U-P to select the U-phase channel, displaying Cu1_o (0000). Use V-P to select the V-phase channel, displaying Cu2_o (0020). Press DSPL/SET to switch between channels. Press < ? > to enter the adjustment screen. The adjustment screen displays the current adjustment value: 0000.3. Use ^ and v to adjust the motor current. Press < ? > again to return to the channel selection screen. Press DATA/ENTE to return to the auxiliary function number screen.



Auxiliary Number	Function	Example
Fn010	Write Protection	<p>Sets write protection.</p> <p>When write protected, the program (index) table, ZONE table, JOG speed table, and parameters cannot be changed, and incomplete auxiliary functions cannot be executed.</p>  <p>The flowchart illustrates the steps to set write protection:</p> <ol style="list-style-type: none"> Start at the Auxiliary Function Number screen: <code>Fn0000</code>. Press DATA ENTE to enter the write-protection setting screen: <code>P0000</code>. This displays the current setting. Press DATA ENTE without executing to return to the auxiliary function number screen: <code>P0000</code>. Use the ^ and v edit keys to change the setting. A box shows the settings: <code>0001: Write-Protect</code> and <code>0000: Write-Protect</code>. Press DATA ENTE to save the setting. The screen flashes and says "done". Wait until flashing stops. Do not turn off control power during this time. Return to the Auxiliary Function Number Screen: <code>Fn0000</code>. Cycle the control power. End.


Auxiliary Number	Function	Example
Fn011	Motor Type Code Display	<p>Displays the motor type code, encoder type code, and SGDH special specification numbers.</p>  <p>The flowchart illustrates the navigation through the Motor Type Code Display screen. It starts with the initial display 'F.n0000'. Pressing the DATA/ENTE button enters the motor code display screen. Pressing DATA/ENTE again returns to the auxiliary function screen. The sequence of displays is as follows:</p> <ul style="list-style-type: none"> Exp F.0000 Motor Type Code Pressing DSPL/SET proceeds to the next item. Exp P.0000 Motor Pressing DSPL/SET proceeds to the next item. Exp E.0000 Encoder Type Code Pressing DSPL/SET proceeds to the next item. Exp 40000 SGDH Special Specification Numbers Pressing DSPL/SET returns to the auxiliary function screen.


Auxiliary Number	Function	Example
Fn012	SGDH Software Version Display	<p>Displays the SGDH and Encoder software versions.</p> <p style="text-align: center;">Fn012</p> <p style="text-align: center;">    </p> <p style="text-align: center;">Use this to enter the software version display screen. Pressing this again returns you to the auxiliary function screen.</p> <p>Exp  SGDh Encoder Software Version</p> <p style="text-align: center;">   </p> <p style="text-align: center;">This proceeds to the next item</p> <p>Exp  Encoder Software Version</p> <p style="text-align: center;">   </p> <p style="text-align: center;">Return using this.</p>



Auxiliary Number	Function	Example
Fn013	Multi-Turn Limit Setting	<p>Sets the multi-turn limit.</p> <p>Upon execution, updates the maximum multi-turn limit stored in the absolute encoder to the value in Pn205.</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: center;"> Danger</p> <ul style="list-style-type: none"> Multi-turn limit change is not necessary in application performing linear operation. It is dangerous to carelessly operate this function. If a multi-turn limit non-coincidence error is generated, always check first whether the servo amplifier parameter Pn205 is correct. Operating Fn013 with an incorrect value in Pn205 results in incorrect values being set into the encoder. Although no alarm will result, large position deviations will be detected, and there is a risk of the machine moving to an unmeasured position. </div>  <pre> graph TD A[Fn013] --> B[PGSE] B --> C[done] C --> D[Fn013] D --> E[End] A --> DATA ENTE B B --> DSPL SET C C --> DATA ENTE A </pre> <p>Pressing DATA ENTE without executing returns you to the auxiliary function number screen.</p> <p>Pressing DSPL SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p> <p>Cycle the control power.</p> <p>End</p>


Common errors




Display	Meaning
	<p>E61E: Encoder Mismatch Error Cannot be executed without absolute encoder.</p>
	<p>E62E: "Unexecutable unless A.CC" error. Cannot be executed without alarm A.CC. Alarm A.CC occurs only when the multi-turn maximum value stored in the absolute encoder does not coincide with the value in parameter Pn205.</p>


Auxiliary Number	Function	Example
Fn800	NS600 Software Version Display	<p>Displays the NS600 software version.</p> 





Auxiliary Number	Function	Example
Fn801	NS600 Device Codes Display	<p>Displays NS600 device codes.</p>  <p>Use this to enter the device code display screen. Pressing this again returns you to the auxiliary function screen.</p> <p>Device Codes</p>

Auxiliary Number	Function	Example
Fn802	NS600 Special Specification	<p>Displays NS600 special specification numbers.</p>  <p>Exp  Special Specification Number</p>

Auxiliary Number	Function	Example
Fn803	Program (Index) Table Save	<p>Saves the program (index) table.</p> <p>Upon execution, stores the program (Index) table on the RAM in the flash memory. The data stored in the flash memory remains even if power is cut off.</p>  <p>Pressing DATA/ENTE Without executing returns you to the auxiliary function number screen.</p> <p>Pressing DSPI/SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example
Fn804	ZONE Table Save	<p>Stores the ZONE speed table.</p> <p>Upon execution, stores the ZONE speed table on the RAM in the flash memory.</p>  <p>The enters you into the ZONE table storage screen.</p> <p>StorE</p> <p>Pressing  Without executing returns you to the auxiliary function number screen.</p> <p> Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>donE</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example
Fn805	JOG Speed Table Save	<p>Stores the JOG speed table.</p> <p>Upon execution, stores the JOG speed table on the RAM in the flash memory. The data stored in the flash memory remains even if power is cut off.</p>  <p>Pressing DATA/ENTE Without executing returns you to the auxiliary function number screen.</p> <p>Execute using this. DSP/SET</p> <p>Wait until flashing stops. Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example				
Fn806	Program (Index) Table Initialize	<p>This initializes the program (Index) table and returns to the factory settings.</p>  <p>Pressing DATA ENTE without executing returns you to the auxiliary function number screen.</p> <p>Pressing DSP/SET Execute using this.</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p> <p>Common errors</p> <table border="1" data-bbox="500 1438 1425 1591"> <thead> <tr> <th>Display</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td></td> <td>E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.</td> </tr> </tbody> </table>	Display	Meaning		E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.
Display	Meaning					
	E5EE: "Unexecuteable while program is running" error. Execution is not possible as the program is running or has been aborted.					

Auxiliary Number	Function	Example
Fn807	ZONE Table Initialize	<p>Initializes the ZONE table and returns to the factory settings.</p> <p>The enters you into the ZONE table initialization screen.</p> <p>Pressing DATA ENTE Without executing returns you to the auxiliary function number screen.</p> <p>Execute using this. DSPL SET</p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>

Auxiliary Number	Function	Example
Fn808	JOG Speed Table Initialize	<p>Initializes the JOG speed table and returns to the factory settings.</p> <p>Pressing returns you to the auxiliary function number screen.</p> <p>Execute using this. </p> <p>Wait until flashing stops Do not turn off control power during this time.</p> <p>Returns you to the Auxiliary Function Number Screen.</p>


7. Program (Index) Table Editing Screen

Displays each column with this symbol.

Po
SP
rd
rS
ou
EV
Lo
nE

PGMSTE	POS	SPD	RDST	RSPD	POUT	EVENT	LOOP	NEXT
0	POS000	SPD000	RDST000	RSPD000	POUT000	EVENT000	LOOP000	NEXT000
1	POS001	SPD001	RDST001	RSPD001	POUT001	EVENT001	LOOP001	NEXT001
⋮	⋮	⋮	⋮	⋮	⋮	⋮	⋮	⋮
127	POS127	SPD127	RDST127	RSPD127	POUT127	EVENT127	LOOP127	NEXT127

Moves between the rows and columns.



This enters the setting editing screen. Return by pressing a second time.

Exp


 Edit using this.


















StoP


Execute Fn803 so that the editing results are not erased at power OFF.









StorE

Common errors
























Display	Meaning
	<p>E5EE: "Unexecuteable while program is running" error.</p> <p>The program (Index) table cannot be modified while the program is running or when aborted.</p> <p>Modify after resetting the program operation.</p>


Column	Example
POS Positioning Target Position	<div style="text-align: center;">  <p>PGMSTE</p> </div> <div style="text-align: center; margin-top: 20px;">  <p>Enters the setting editing screen. Press a second time to return.</p> </div> <div style="margin-top: 40px;">  <p>Set to "-"</p> <p style="text-align: center;">-</p> <p style="text-align: center;">↑ ↓</p>  <p style="text-align: center;">↓ ↑</p>  <p>Set to "INFINITE"</p> <p style="text-align: center;">-InFI</p> <p style="text-align: center;">↑ ↓</p>  <p style="text-align: center;">↓ ↑</p>  <p>Set to "+INFINITE"</p> <p style="text-align: center;">+InFI</p> <p style="text-align: center;">↑ ↓</p>  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>I+123</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> <div style="text-align: center;">  <p>A+123</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> <div style="text-align: center;">  <p>45678</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> </div> <p style="text-align: center;">Exp. : Set to</p> <p style="text-align: center;">↑ ↓</p>  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>A+123</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> <div style="text-align: center;">  <p>A+12345678</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> <div style="text-align: center;">  <p>45678</p> <p style="text-align: center;">← →</p> <p>Mbve Cursor</p> </div> </div> <p style="text-align: center;">Exp. : Set to A+12345678</p> <p style="text-align: center;">↑ ↓</p>   <p>Set to "STOP"</p> <p style="text-align: center;">StoP</p> </div>














Column	Example
RDST Registration Distance	<div style="text-align: center;">  </div> <p style="text-align: center;">  Enters the setting editing screen. Press a second time to return. </p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Upper 3-digits</p> <p>Exp: </p> <p> Mdi fy</p> </div> <div style="text-align: center;"> <p> Mve Cursor</p> </div> <div style="text-align: center;"> <p>Lower 5-digits</p> <p></p> <p> Mdi fy</p> </div> </div> <div style="text-align: right; margin-top: 20px;"> <div style="border: 1px solid black; border-radius: 15px; padding: 10px; width: fit-content;">  <p style="text-align: center;">- Becomes "-" when smaller than zero.</p> </div> </div>

Column	Example
RSPD Registration Speed	<div style="text-align: center;"> </div>

Column	Example
POUT Programmable Output Signal	<div style="text-align: center;">  <p>PGMSTE</p> </div> <p style="text-align: center;">   Enters the setting editing screen. Press a second time to return. </p> <p style="text-align: center;">  </p> <p>Exp.: "::::"</p> <div style="text-align: center;">  <p>.....</p> </div> <p style="text-align: center;">   Move Cursor </p> <div style="text-align: center;">  <p>Set to ":"</p> <p>:</p> </div> <p style="text-align: center;">    Modify Setting </p> <p style="text-align: center;">  </p> <div style="text-align: center;">  <p>Set to "Z"</p> <p>Z</p> </div> <p style="text-align: center;">    Modify Setting </p> <p style="text-align: center;">  </p> <div style="text-align: center;">  <p>Set to "A"</p> <p>A</p> </div> <p style="text-align: center;">    Modify Setting </p> <p style="text-align: center;">  </p> <div style="text-align: center;">  <p>Set to "n"</p> <p>n</p> </div>





Column	Example
LOOP #. of Times Executed	<div style="text-align: center;">  </div> <div style="text-align: center; margin-top: 20px;">  <p>Enters the setting editing screen. Press a second time to return.</p> </div> <div style="text-align: center; margin-top: 20px;">  <p>Mbve Cursor</p> </div> <div style="text-align: center; margin-top: 20px;"> <p>Exp:</p>  </div> <div style="text-align: center; margin-top: 20px;">  <p>Mdify Setting</p> </div>



Column	Example
<p>NEXT Next PGMSTEP executed</p>	<div style="text-align: center;">  </div> <p style="text-align: center;">  Enters the setting editing screen. Press a second time to return. </p> <div style="text-align: center;">  <p>Mbve Cursor</p> </div> <p>Exp: </p> <div style="text-align: center;">  <p>Mdify Setting</p> </div> <div style="border: 1px solid black; border-radius: 15px; padding: 10px; margin: 20px auto; width: fit-content;"> <div style="text-align: center;">  <p>End</p> <p>Becomes "End" when smaller than zero.</p> </div> </div>


8. ZONE Table Editing Screen



Displays each row with this symbol.




 Moves between the rows and columns.






 This enters the setting editing screen. Return by pressing a second time.

Exp 

 Edit using this.

+000

Execute Fn804 so that the editing results are not erased at power OFF.





9. JOG Speed Table Editing Screen

Displays the row with this symbol.

JS


JOG Speed	JSPD
0	JSPD000
1	JSPD001
⋮	⋮
⋮	⋮
15	JSPD015



Moves between the rows.

JS0000

JOG Speed	JSPD
0	JSPD000
1	JSPD001



JS0000

JOG Speed	JSPD
0	JSPD000
1	JSPD001



This enters the setting editing screen. Return by pressing a second time.

Exp

0000

000












Edit using this.

Execute Fn805 so that the editing results are not erased at power OFF.

Fn805

Store

Store

Column	Example
JSPD	<div style="text-align: center;">  </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Upper</p> <p>Exp: </p> <p> </p> <p>Mve Cursor</p> <p> </p> <p>Mdify Setting</p> </div> <div style="text-align: center;"> <p>Lower 5-digits</p> <p></p> <p> </p> <p>Mdify Setting</p> </div> </div>