

Yes. On Sheet 2 of the E7B drawings, follow the "Drive Operation Mode Selection Table 2" with the following changes:

To change the speed reference to an analog input, add a jumper from S5-S6, and another jumper from S4-SN.

Set parameter b1-01='0', h1-02='3', h3-02='0'. In addition, please do one of the following:

For 0-10VDC: Set h3-08='0', and set Drive Control PCB SW. S1-2 to 'OFF'.

For 4-20mA: Set h3-08='2', and set Drive Control PCB SW. S1-2 to 'ON'.

Document: E7B-00

| OPTION PRESENT | | | | SPECIAL DRIVE PARAMETER SETTINGS | | | | | | DRIVE CONTROL BOARD SW. S1-2 SETTING | HAND MODE DRIVE SPEED REFERENCE | | | AUTO MODE DRIVE SPEED REFERENCE | | | | SEE NOTE |
|----------------|-----------------|-----------|-----|----------------------------------|-------|-------|-------|-------|-------|--------------------------------------|---------------------------------|-------|-----------|---------------------------------|----------|----------|--------------|----------|
| SERIAL COMM. | 3-15 PSI XDUCER | SPEED POT | | b1-01 | H1-03 | H3-02 | H3-08 | H3-09 | H3-13 | | d1-01 | d1-02 | SPEED POT | 4-20 MADC | 0-10 VDC | 3-15 PSI | SERIAL COMM. | |
| | | | | 1 | 3 | 0.0 | 2 | 0 | 1 | ON * | | YES | | YES | | | | |
| | | | | 1 | 3 | 0.0 | 0 | 0 | 1 | OFF | | YES | | YES | | | | |
| YES | | | | 0 | 6C | 0.0 | 2 | 2 | 0 | ON * | YES | | | | | YES | 7 | |
| YES | | | YES | 1 | 6C | 100.0 | 2 | 2 | 0 | ON * | | YES | | | | YES | 7 | |
| | YES | | | 0 | 6C | 0.0 | 2 | 2 | 0 | ON * | YES | | | | | YES | 7 | |
| | YES | | YES | 1 | 6C | 100.0 | 2 | 2 | 0 | ON * | | YES | | | | YES | 7 | |
| | | YES | | 1 | 3 | 0.0 | 2 | 0 | 1 | ON * | | YES | | | YES | | | |
| | | YES | YES | 1 | 3 | 100.0 | 2 | 2 | 1 | ON * | | YES | | | YES | | | |
| | | | YES | 1 | 3 | 100.0 | 2 | 2 | 1 | ON * | | YES | YES | | | | | |
| | | | YES | 1 | 3 | 100.0 | 0 | 2 | 1 | OFF | | YES | | YES | | | | |

* = FACTORY SETTING