

MP2000 Series Function Block Details

Please click a Function Block to jump to the details.

Motion Blocks

[AXISEND](#)

[CAM](#)

[CAM_RECV](#)

[CAMOFFST](#)

[CAMSCALE](#)

[CHNG_DYN](#)

[GEAR](#)

[HOME](#)

[LATCH](#)

[LTHTRGT](#)

[MOD_ENG](#)

[MOVABS](#)

[MOVADDTV](#)

[MOVINC](#)

[MOVVEL](#)

[SLAVEOFF](#)

[STOP](#)

[SVON](#)

[TUNING](#)

Administrative Blocks

[AENC_RST](#)

[ALMRST](#)

[DEF_POS](#)

[RDINIT1](#)

[RDINIT2](#)

[RDERROR](#)

[RDPARAM](#)

[WRTPARAM](#)

I/O Blocks

[ASCIIN](#)


[ASCIOUT](#)

[PLS](#)

Revision Level

As part of best practices, it is advised to keep track of the revision level of each function block for the ease of technical support and maintenance. Each block has a revision number that is defined in the first rung of function code. This value must be altered if the block is modified. The number is broken into two parts as follows.

Revision Number format: **XXYY**
XX = Revision by Yaskawa engineering and registered
YY - Revision by Non Yaskawa personnel and unregistered changes



The revision number uses an 'A' register to allow the value to be monitored. The revision level can be determined by looking at the last word from the base address including the base address, the revision can be seen.

If it is necessary to replace a function block with a newer revision, simply import the newer function block over the existing version. Doing this may clear all of the I/O fields. If this occurs, simply re-enter the input and output data into the block, then save and verify the project.


AXIS END function

Function block for MP2000 series

<AXISEND> Function Block Summary

This function block writes necessary values to the RDA at the end of the motion scan cycle. This block is essential if any of the Blocks in the set are to be used.

Function Block Diagram



<AXISEND> Function Block Operation Note

- **NOTE: SVON and AXISEND blocks must be used together, all motion type blocks for a specific axis must be placed between the SVON and AXISEND blocks. This block must be used in the High Speed Scan drawings, and should be the last block executed after all other motion function blocks within the scan.**
- This block writes values from RDA to specific axis control registers required for controlling motion. This block was created to reduce the overall volume of code in all other function blocks for multi axis. It handles circuit number and axis number within the circuit, and relates it to the logical axis number selected by the programmer from the RDAINIT blocks.
- Example: for axis #1, this block writes to OW8000 RUN mode, OW8003, the unit selection, OW8004 latch demand detection signal selection, OW8005 home position return, OW8008 motion command code, OW8009 motion command control flag, OL8010 speed reference, OL801C positioning command, OL802A latch zone lower limit of the interval setting, OL802C latch zone upper limit setting, OL8036 acceleration time, OL8038 deceleration time, (see RDA matrix for details)
- This block also writes to ERRORID1 and ERRORID2
- One word is used as working registers for this function, starting at the address in *Data01W*.

<AXISEND> Input and Output Register Map

Output Registers

The following registers are used from the function block as an output. To check the execution of the function, they can be monitored by the MPE720 program.

| Output | Type | Description |
|--------|------|---|
| ERROR | bit | If an error occurs during block execution, this output bit turns ON, but will reset if error condition goes away. |

Input Registers

The following registers are used to block the function as an input. It is necessary to select the option, define the parameter, and make these function if necessary by the user.

| Input | Type | Description | Range and state |
|-------|------|-----------------------------------|-----------------|
| AXIS | Word | Axis number related to the block. | 1 ~ 16 |

<AXISEND> Block Fault Condition:

The following table outlines several situations that may cause an error. The block error can be cleared by the *ENABLE* bit going low.

| Error bit of internal | Cause | Attention |
|-----------------------|---|--|
| axisinerr ZB000020 | The axis number entered on the input is not an acceptable value | Function blocks can only control 1 to 16 axes. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID. |

<AXISEND> Working Registers

This table outlines the data in the registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|-------------|---------|----------|---------------------------------------|
| AW00000 | Working | Revision | Revision Level of the function block. |


CAM function

Function block for MP2000 series

<CAM> Function Block Summary

The Cam block is a state block, different from the PLCopen spec in order to take advantage of the power of the MP products. Master/Slave pair is a numeric input indicating the master/slave source data from the Modulus Engine, and for the Cam Offset, Slave Offset, and Cam Scale. This block will position the slave based on the position of the master and the cam table. To operate, this block must have a Modulus Engine function block associated with the master/slave pair defined, to provide modulated master data. Slave offset, Cam offset, and Cam Scale function blocks can be used to make this block more flexible.

Function Block Diagram



<CAM> Function Block Operation Notes

- **IMPORTANT NOTE: If the CamScale value in the RDA (ML56**8) is zero the slave will not move.**
- Slave Offset, Cam Scale, Cam Offset, Mod Engine, and Change Dynamics function blocks may be useful when using this block.
- *ENABLE*: Rising edge of the *ENABLE* input initiates block operation, and several block input values will be read once. These inputs are: *AXIS*, *MSTRSLAV*, *TBLTYPE*, *TBLADDRS*. This event will also verify & set the accel & decel values in the servopack to zero, to guarantee tight response. Note that this only means that the MP controller will control the accel/decel rates as defined in the CAM Table Profile (and the servopack will not limit the accel/decel).
- *ENABLE*: If the *ENABLE* input goes off during operation, the block will stop operating and the axis will *immediately* hold on its last commanded position from the Cam table. Warning: This can cause a rapid deceleration, which may damage machine mechanisms!
- *CAMIN*: While *ENABLE* input is high, Rising edge of *CAMIN* input initiates camming operation, and *ENGAGPOS* input value is read. Slave will then wait to engage camming until the master reaches the engage position. *STATE* output will indicate the camming operation state.
- *CAMOUT*: While *ENABLE* input is high, Rising edge of *CAMOUT* input initiates cam stop operation, and *DISENGAG* input value is read. The slave axis will continue to cam until the disengage (*DISENGAG*) input position is reached by the master. Then the slave axis will hold on the position defined by the cam table referenced by the *master disengage position*.
- Speed: The maximum speed the slave axis can go is the Max speed, set in the RDA. If the master commands the slave to go faster than this speed, axis will travel at the max. speed, and will output and latch the *ERROR* output. Note that the slave will continue to cam.
- Master Data: Modulated master data (according to desired machine cycle), must come from the Mod Engine function block if *CAMSCALE*, *CAMOFFST*, or *SLAVEOFF* function blocks are used. See *MOD_ENG* function block.
- Scale: If the Cam Scale (ML56**8) value is 0 the slave will not move because this is a multiplier to the commanded position (1=0.01%). See *CAMSCALE* function block.
- Master Offset: The Cam Offset from the RDA is used to shift the value of the master as it's position relates to the slave. See *CAMOFFST* function block.
- Slave Offset: The slave offset from the RDA is used to shift the slave as its position as it relates to the Cam table. See *SLAVEOFF* function block.

- CAM Table: Cam table is expected to be in 32-bit long integer words. Hence, each CAM table master/slave pair entry will take up 4 16-bit regular words (two words for master, two words for slave). The first long word of every table contains the table size in points. Example of a cam table with 10 master/slave pairs consumes MW04000 thru MW04041 where ML04000=10, ML04002=first master position, ML04004=first slave position, ML04006=second master position, ML04038=tenth master position, ML04040=tenth slave position. The M register address range is 0000-29999.

Range of register:

MW00000 to MW29999 (M-register limit is 00000 – 29999 due to RDA)

CW00000 to CW16382 (C-register limit is 0-16382)

DW00000 to DW16382 (D-register limit is 0-16382)

- One-way vs Cyclic camming comment: If the first and last slave positions are identical then it is a cyclic cam, otherwise it is treated as a one-way cam, and the slave will be offset by the difference each end of profile is reached (this is to prevent it from jumping).
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc
- Internal Operation1: This block uses Motion Command Code. When the master reaches the engage position, the output of the function generator (FGN) function is assumed to be the current position of the slave. Any error in these positions is placed into an offset to avoid motor jumping. The slave command position (position control mode) is updated each scan from the function generator (FGN) output multiplied by cam scale and shifted by the slave offset. The result is placed in OL**1C position command register for the slave axis
- Internal Operation2: Under normal operation, the camming block operates in 'Interpolation mode' (OW**08=4). If a latch block is used to capture a latched position, the mode will be switched to 'Interpolation mode with latch' (OW**08=6). After the latch occurs, the block is returned to standard 'Interpolation mode'. This switching feature happens in the background without affecting intended slave camming motion
- Thirty-two words are used as working registers for this function, starting at the address in *Data32W*.

<CAM> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | TYPE | Content |
|----------|------|---|
| RUNNING | Bit | Bit goes on when slave is camming, and the slave is being controlled by the master (STATE = 2) |
| ENDPROFI | Bit | Puts out a single scan high pulse every time it reaches the end of the cam profile in either direction. |
| ERROR | Bit | This bit is latched ON when the EXECUTE input is high and an error occurred in the block. |
| STATUS | Word | The State of the block 0 = Disengaged 1 = Waiting to engage 2 = Camming 4 = Disengaging |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range and state |
|----------|---------|--|--|
| ENABLE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising Edge – see operation notes TRUE – Block enable FALSE – Block disable |
| CAMIN | Bit | Sets block to search for ENGAGE position in master. When reached axis begins camming | RISING EDGE- initiates search for engage position and sets up for camming |
| CAMOUT | Bit | Sets block to search for DISENGAG position in master. When reached axis stops and holds. | RISING EDGE- initiates search for disengage position and stops camming and holds when position is reached by master. |
| AXIS | Word | Axis number related to the block | 1 to 16 |
| M-S-PAIR | Word | Master Slave Pair as defined by the RDA | 1 to 10 integer. This value is needed to match the value of the MOD-ENG function block. |
| TBLTYPE | Word | Defines what register type the cam table will be in. CAM table consists of 32-bit long integer words | 1 = M registers 2 = C registers 3 = D registers |
| TBLADDRS | Word | Starting address number of the cam table. In case of D register table, this value is relative to the assigned data address at 'DATA31W'. TBLADDRS+DATA31W = Actual Starting Address | 0~3276 If the end of the table is greater than 32767, the an error will be set. (The limit of M-reg is MW00000 to MW29999) |
| ENGAGPOS | Long | Master position in counts to start the slave camming | 0 to the machine cycle value defined in the MOD-ENG block |
| DISENGAG | Long | Master position in counts to stop the slave camming | 0 to the machine cycle value defined in the MOD-ENG block |
| DATA32W | Address | Address of the first working register. | Thirty-two words of register space are used by this function. |

<CAM> Block Fault Condition

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW3**81 and MW3**82) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 200 for each axis. Example: Axis#1 stores to MW30181, Axis #20 stores to MW30381, etc (note that Master/Slave pair is irrelevant).

| Internal Fault bit | Cause | Note |
|-----------------------|---|---|
| msinrng AB000010 | Master/Slave pair input out of range | Value on input must be from 1 to 10. If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813 |
| ctlInrng AB000011 | Table type input is out of range. | Value on input must be from 1 to 3. If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813. |
| addrInRng AB000012 | Final address of table is beyond the range of the register. | Checks that final address of the table (Start address + size) does not exceed max register size (29999 for M, 16482 for D and C type registers). If this bit is low on the rising edge of execute an error will occur. This will also generate an error in the RDA at MB3**813. |
| mstErr AB00001F | Last value in Cam table is greater then machine cycle. | If the last master value in the cam table is greater then the machine cycle an error will occur. This will also generate an error in the RDA at MB3**81C. |
| Direr AB00001F | Direction not allowed by SVON | The direction commanded was not enabled by SVON function. This will also generate an error in the RDA at MB3**814. |
| CmndError AB00001E | Another block took control of axis | If another axis controlling block while this block is running. It will take control from this function. This does not set the RDA Error ID. |
| AxisInErr AB000050 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |

<CAM> Working Register

This table outlines the data in the thirty-three registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|-------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | EXECUTE | ENABLE input (XB000000) |
| Bit 1 | IN | CamIn | CAMIN input (XB000001) |
| Bit 2 | IN | CamOut | CAMOUT input (XB000002) |
| Bit 3 | Working | mRegister | Indicates table is in M register. |
| Bit 4 | Working | cRegister | Indicates table is in C register. |
| Bit 5 | Working | dRegister | Indicates table is in D register. |
| Bit 6 | Working | engaging | On when waiting for master to reach engage position. |
| Bit 7 | OUT | running | Directly controls YB000000 (RUNNING Output) |
| Bit 8 | OUT | endOfTrvl | Directly controls YB000001 (ENDPROFI Output) |
| Bit 9 | OUT | Mistake | Directly controls YB000002 (ERROR Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing axis when CAMIN input goes high. |
| Bit C | Working | oneshotC | Reserved |
| Bit D | IN | runInit | One shot coil for initializing axis when engage position is reached. |
| Bit E | IN | oneshotE | Reserved |
| Bit F | Working | oneshotF | Reserved |
| <i>AW00001</i> | | | |
| Bit 0 | Working | msinrng | Verifies Master/Slave input is in range. |
| Bit 1 | Working | ctlInrng | Verifies Table Type input is in range. |
| Bit 2 | Working | addrInRng | Verifies that the entire Cam Table is in the register and did not go beyond the register limits. |
| Bit 3 | Working | disengaging | On when camming and CAMOUT input goes high. |
| Bit 4 | Working | above_point | Reserved |
| Bit 5 | Working | d_abovepos | Reserved |
| Bit 6 | Working | oneWay | On when first and last value of cam table are not equal. |
| Bit 7 | Working | exeInIt | One shot coil on for first pass of block being executed. |
| Bit 8 | Working | disengaged | One shot coil for when disengage position is reached and called for. |
| Bit A | Working | mstrErr | On if last master value in cam table is greater then master machine cycle. |
| Bit B | Working | posout | Reserved |
| Bit C | Working | backwards. | Reserved |
| Bit D | Working | negOut | Reserved |

| | | | |
|---------|---------|-------------------|--|
| Bit E | Working | cmndError | One shot coil for when another block takes control from this block. |
| Bit F | Working | direrr | On if a direction is commanded that is not enabled by the SVON block. |
| AW00002 | Working | mstr_slave | MstrSlave [value of (XW00001) – 1] |
| AW00003 | Working | filter1 | Temporary values used to filter bits. |
| AW00004 | OUT | camstate | Directly controls YW00001 (STATE Output). |
| AW00005 | | | |
| Bit 0 | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| AL00006 | Working | yFirst | First position of slave in Cam table. |
| AL00008 | Working | yLast | Last position of slave in Cam table. |
| AL00010 | Working | xLast | Last position of Master in Cam table. |
| AL00012 | Working | lastAddress | Final register address of Cam table. |
| AL00014 | Working | Window | Tolerance value for engage and disengage position. Divide XLAST by 120. IE – this window is 0.8% of the machine cycle. |
| AL00016 | Working | masterpos | Value of Master after CAM shift. |
| AL00018 | Working | engage_difference | Distance from engage or disengage point. |
| AL00020 | Working | base_slave_pos | Reserved |
| AL00022 | Working | fgnOut | Value returned from Cam table function generator |
| AL00024 | Working | slave_Pos_Command | Reserved |
| AL00026 | Working | deltaY | Difference between first and last slave position in table, used if it's a one-way cam to offset the slave |
| AL00028 | Working | o pos_o | Reserved |
| AW00030 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00031 | Working | Revision | Revision Level of Block. |


CAM RECOVERY function

Function block for MP2000 series

<CAM_RECV> Function Block Summary

The Cam block is a state block, different from the PLCopen spec in order to take advantage of the power of the MP products. Master/Slave pair is a numeric input indicating the master/slave source data from the Modulus Engine, and for the Cam Offset, Slave Offset, and Cam Scale. This block will position the slave based on the position of the master and the cam table. To operate, this block must have a Modulus Engine function block associated with the master/slave pair defined, to provide modulated master data. Slave offset, Cam offset, and Cam Scale function blocks can be used to make this block more flexible. CAM_RECV function block has E-stop recovery capability in addition to the CAM Function Block.

Function Block Diagram



<CAM_RECV> Function Block Operation Notes

- **IMPORTANT NOTE: If the CamScale value in the RDA (ML56**8) is zero the slave will not move.**
- Slave Offset, Cam Scale, Cam Offset, Mod Engine, and Change Dynamics function blocks may be useful when using this block.
- *ENABLE*: Rising edge of the *ENABLE* input initiates block operation, and several block input values will be read once. These inputs are: *AXIS*, *MSTRSLAV*, *TBLTYPE*, *TBLADDRS*. This event will also verify & set the accel & decel values in the servopack to zero, to guarantee tight response. Note that this only means that the MP controller will control the accel/decel rates as defined in the CAM Table Profile (and the servopack will not limit the accel/decel).
- *ENABLE*: If the *ENABLE* input goes off during operation, the block will stop operating and the axis will *immediately* hold on its last commanded position from the Cam table. Warning: This can cause a rapid deceleration, which may damage machine mechanisms!
- *CAMIN*: While *ENABLE* input is high, Rising edge of *CAMIN* input initiates camming operation, and *ENGAGPOS* input value is read. Slave will then wait to engage camming until the master reaches the engage position. *STATE* output will indicate the camming operation state.
- *CAMOUT*: While *ENABLE* input is high, Rising edge of *CAMOUT* input initiates cam stop operation, and *DISENGAG* input value is read. The slave axis will continue to cam until the disengage (*DISENGAG*) input position is reached by the master. Then the slave axis will hold on the position defined by the cam table referenced by the *master disengage position*.
- Speed: The maximum speed the slave axis can go is the Max speed, set in the RDA. If the master commands the slave to go faster than this speed, axis will travel at the max. speed, and will output and latch the *ERROR* output. Note that the slave will continue to cam.
- Master Data: Modulated master data (according to desired machine cycle), must come from the Mod Engine function block if *CAMSCALE*, *CAMOFFST*, or *SLAVEOFF* function blocks are used. See *MOD_ENG* function block.
- Scale: If the Cam Scale (ML56**8) value is 0 the slave will not move because this is a multiplier to the commanded position (1=0.01%). See *CAMSCALE* function block.
- Master Offset: The Cam Offset from the RDA is used to shift the value of the master as it's position relates to the slave. See *CAMOFFST* function block.
- Slave Offset: The slave offset from the RDA is used to shift the slave as its position as it relates to the Cam table. See *SLAVEOFF* function block.

- CAM Table:** Cam table is expected to be in 32-bit long integer words. Hence, each CAM table master/slave pair entry will take up 4 16-bit regular words (two words for master, two words for slave). The first long word of every table contains the table size in points. Example of a cam table with 10 master/slave pairs consumes MW04000 thru MW04041 where ML04000=10, ML04002=first master position, ML04004=first slave position, ML04006=second master position, ML04038=tenth master position, ML04040=tenth slave position. The M register address range is 0000-29999.

Range of register:

 - MW00000 to MW29999 (M-register limit is 00000 – 29999 due to RDA)
 - CW00000 to CW16382 (C-register limit is 0-16382)
 - DW00000 to DW16382 (D-register limit is 0-16382)
- One-way vs Cyclic camming comment:** If the first and last slave positions are identical then it is a cyclic cam, otherwise it is treated as a one-way cam, and the slave will be offset by the difference each end of profile is reached (this is to prevent it from jumping).
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc
- Internal Operation1:** This block uses Motion Command Code. When the master reaches the engage position, the output of the function generator (FGN) function is assumed to be the current position of the slave. Any error in these positions is placed into an offset to avoid motor jumping. The slave command position (position control mode) is updated each scan from the function generator (FGN) output multiplied by cam scale and shifted by the slave offset. The result is placed in OL**1C position command register for the slave axis
- Internal Operation2:** Under normal operation, the camming block operates in 'Interpolation mode' (OW**08=4). If a latch block is used to capture a latched position, the mode will be switched to 'Interpolation mode with latch' (OW**08=6). After the latch occurs, the block is returned to standard 'Interpolation mode'. This switching feature happens in the background without affecting intended slave camming motion
- Thirty-two words are used as working registers for this function, starting at the address in *Data32W*.
- E-Stop Condition:** Control Power of both the Servo pack and the Controller are ON and Main power of the Servo Pack is OFF while CAM is engaged.
- E-Stop Recovery motion:** The Slave axis moves to the designated position based on the current Master position at the speed set in the RECVSPD [counts/sec].

<CAM_RECV> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | TYPE | Content |
|----------|------|---|
| RUNNING | Bit | Bit goes on when slave is camming, and the slave is being controlled by the master (STATE = 2) |
| ENDPROFI | Bit | Puts out a single scan high pulse every time it reaches the end of the cam profile in either direction. |
| ERROR | Bit | This bit is latched ON when the EXECUTE input is high and an error occurred in the block. |
| ESTOPED | Bit | This bit is latched ON when E-Stop condition occurs while CAM is engaged. This bit will be OFF when ENABLE input is OFF or recovery motion is done. |
| RECVRING | Bit | This bit is ON when the axis is in the recovery motion. |
| STATUS | Word | The State of the block 0 = Disengaged 1 = Waiting to engage 2 = Camming 4 = Disengaging |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range and state |
|----------|-----------|--|--|
| ENABLE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising Edge – see operation notes TRUE – Block enable FALSE – Block disable |
| CAMIN | Bit | Sets block to search for ENGAGE position in master. When reached axis begins camming | RISING EDGE- initiates search for engage position and sets up for camming |
| CAMOUT | Bit | Sets block to search for DISENGAG position in master. When reached axis stops and holds. | RISING EDGE- initiates search for disengage position and stops camming and holds when position is reached by master. |
| RECOVERY | Bit | Start Recovery Motion when E-stop occurred. | RISING EDGE- initiates the recovery motion. |
| AXIS | Word | Axis number related to the block | 1 to 16 |
| M-S-PAIR | Word | Master Slave Pair as defined by the RDA | 1 to 10 integer. This value is needed to match the value of the MOD-ENG function block. |
| TBLTYPE | Word | Defines what register type the cam table will be in. CAM table consists of 32-bit long integer words | 1 = M registers 2 = C registers 3 = D registers |
| TBLADDRS | Word | Starting address number of the cam table. In case of D register table, this value is relative to the assigned data address at 'DATA31W'. TBLADDRS+DATA31W = Actual Starting Address | 0~3276 If the end of the table is greater than 32767, the an error will be set. (The limit of M-reg is MW00000 to MW29999) |
| ENGAGPOS | Long | Master position in counts to start the slave camming | 0 to the machine cycle value defined in the MOD-ENG block |
| DISENGAG | Long | Master position in counts to stop the slave camming | 0 to the machine cycle value defined in the MOD-ENG block |
| DATA32W | Addresses | Address of the first working register. | Thirty-two words of register space are used by this function. |

<CAM_RECV> Block Fault Condition

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW3**81 and MW3**82) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 200 for each axis. Example: Axis#1 stores to MW30181, Axis #20 stores to MW30381, etc (note that Master/Slave pair is irrelevant).

| Internal Fault bit | Cause | Note |
|-----------------------|---|---|
| msinrng AB000010 | Master/Slave pair input out of range | Value on input must be from 1 to 10. If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813 |
| ctlInrng AB000011 | Table type input is out of range. | Value on input must be from 1 to 3. If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813. |
| addrInRng AB000012 | Final address of table is beyond the range of the register. | Checks that final address of the table (Start address + size) does not exceed max register size (29999 for M, 16482 for D and C type registers). If this bit is low on the rising edge of execute an error will occur. This will also generate an error in the RDA at MB3**813. |
| mstErr AB00001A | Last value in Cam table is greater then machine cycle. | If the last master value in the cam table is greater then the machine cycle an error will occur. This will also generate an error in the RDA at MB3**81C. |
| Direr AB00001F | Direction not allowed by SVON | The direction commanded was not enabled by SVON function. This will also generate an error in the RDA at MB3**814. |
| CmndError AB00001E | Another block took control of axis | If another axis controlling block while this block is running. It will take control from this function. This does not set the RDA Error ID. |
| AxisInErr AB000050 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |


<CAM_RECV> Working Register

This table outlines the data in the thirty-three registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|-------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | EXECUTE | ENABLE input (XB000000) |
| Bit 1 | IN | CamIn | CAMIN input (XB000001) |
| Bit 2 | IN | CamOut | CAMOUT input (XB000002) |
| Bit 3 | Working | mRegister | Indicates table is in M register. |
| Bit 4 | Working | cRegister | Indicates table is in C register. |
| Bit 5 | Working | dRegister | Indicates table is in D register. |
| Bit 6 | Working | engaging | On when waiting for master to reach engage position. |
| Bit 7 | OUT | running | Directly controls YB000000 (RUNNING Output) |
| Bit 8 | OUT | endOfTrvl | Directly controls YB000001 (ENDPROFI Output) |
| Bit 9 | OUT | Mistake | Directly controls YB000002 (ERROR Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing axis when CAMIN input goes high. |
| Bit C | Working | oneshotC | Reserved |
| Bit D | IN | runInit | One shot coil for initializing axis when engage position is reached. |
| Bit E | IN | oneshotE | Reserved |
| Bit F | Working | oneshotF | Reserved |
| <i>AW00001</i> | | | |
| Bit 0 | Working | msinrng | Verifies Master/Slave input is in range. |
| Bit 1 | Working | ctlInrng | Verifies Table Type input is in range. |
| Bit 2 | Working | addrInRng | Verifies that the entire Cam Table is in the register and did not go beyond the register limits. |
| Bit 3 | Working | disengaging | On when camming and CAMOUT input goes high. |
| Bit 4 | Working | above_point | Reserved |
| Bit 5 | Working | d_abovepos | Reserved |
| Bit 6 | Working | oneWay | On when first and last value of cam table are not equal. |
| Bit 7 | Working | exeInit | One shot coil on for first pass of block being executed. |
| Bit 8 | Working | disengaged | One shot coil for when disengage position is reached and called for. |
| Bit A | Working | mstrErr | On if last master value in cam table is greater then master machine cycle. |
| Bit B | Working | posout | Reserved |
| Bit C | Working | backwards. | Reserved |
| Bit D | Working | negOut | Reserved |

| | | | |
|---------|---------|-----------------------|--|
| Bit E | Working | cmndError | One shot coil for when another block takes control from this block. |
| Bit F | Working | direrr | On if a direction is commanded that is not enabled by the SVON block. |
| AW00002 | Working | mstr_slave | MstrSlave [value of (XW00001) – 1] |
| AW00003 | Working | filter1 | Temporary values used to filter bits. |
| AW00004 | OUT | camstate | Directly controls YW00001 (STATE Output). |
| AW00005 | | | |
| Bit 0 | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| AL00006 | Working | yFirst | First position of slave in Cam table. |
| AL00008 | Working | yLast | Last position of slave in Cam table. |
| AL00010 | Working | xLast | Last position of Master in Cam table. |
| AL00012 | Working | lastAddress | Final register address of Cam table. |
| AL00014 | Working | Window | Tolerance value for engage and disengage position. Divide XLAST by 120. IE – this window is 0.8% of the machine cycle. |
| AL00016 | Working | masterpos | Value of Master after CAM shift. |
| AL00018 | Working | engage_differe nce | Distance from engage or disengage point. |
| AL00020 | Working | base_slave_po s | Reserved |
| AL00022 | Working | fgnOut | Value returned from Cam table function generator |
| AL00024 | Working | slave_Pos_Cm nd | Reserved |
| AL00026 | Working | deltaY | Difference between first and last slave position in table, used if it's a one-way cam to offset the slave |
| AW00028 | | | |
| Bit 0 | Working | ESTOP_Latch | Latch E-stop Condition |
| Bit 1 | Working | RECV_MODE | In Recovery Motion |
| Bit 2 | Working | RECV_COMP | Recovery Motion Complete |
| Bit 3 | Working | Oneshot283 | Reserved |
| Bit 4 | Working | Oneshot284 | Reserved |
| Bit 5 | Working | RECV_SHOT | Reset Error after Recovery motion is done |
| AW00029 | Working | Timer | Positioning Completion Timer for E-Stop recovery |
| AW00030 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00031 | Working | Revision | Revision Level of Block. |

CAM_RECV Time Chart




CAM OFFSET function Block

Function block for MP2000 series

<CAMOFFST> Function Block Summary

The Cam Offset (CAMOFFST) block is used to shift the value of the master (for synchronizing or dwell) while camming. The rising edge of the *EXECUTE* input bit will cause the *OFFSET* value to be added to the RDA offset at the rate determined by the *DURATION* input. *DST-TIME* input bit determines whether the shift duration is base upon distance the master travels or based on time in milliseconds.

Function Block Diagram



<CAMOFFST> Function Block Operation Notes

- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, the block will stop executing (will not complete the change), the offset up to that point will remain, and all outputs will be set to zero.
- The RUNNING output bit will be held high until the Offset is completed, EXECUTE goes low, or an Error occurs.
- The DST-TIME bit must be set to TRUE to use the master position change or FALSE for the time duration.
- Distance mode note: Be sure to set the duration in the same direction as the master movement. Example: If the block is in Distance mode and the master is moving in the negative direction, and the DURATION is set positive, it will subtract the relative offset and hence the resulting offset will not complete. As a result, the DONE output will not go on because the full move is not complete in the correct direction.
- The 'Block Running' value will appear in the Master/Slave pair section of the RDA RDA(MW56**6).
- Issuing a STOP block on the slave axis will have no affect on the OFFSET block execution.
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc.
- Twenty-three words are used as working registers for this function, starting at the address in Data23W.

<CAMOFFST> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | Goes high while offset value is being updated in RDA and there are no errors |
| DONE | Bit | Goes high when offset change is complete in RDA |
| ERROR | Bit | Latches high if any block errors occur |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|----------|---------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| DST-TIME | Bit | Selects master or time for offset duration | TRUE – Master position is used for duration FALSE – Time is used for duration. |
| M-S-PAIR | Word | Defines which Master-Slave pair is updated in RDA | 1 to 10 value. Any other value will cause the error output to go on |
| DURATION | Long | Depends on DST-TIME setting. Either time in msec or distance master must travel to complete change in offset. | -2147483648 to 2147483647. If in time mode no negative numbers are allowed. |
| OFFSET | Long | Relative shift to be applied to the master. RDA will hold absolute offset value level (The RDA offset is ML56**4) | -2147483648 to 2147483647 |
| DATA23W | Address | Address of the first working register. | Twenty-three words of register space are used by this function. |

<CAMOFFST> Block Fault Condition

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the EXECUTE bit goes low, but the Error ID (MW3**81 and MW3**82) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

The following table outlines several situations that may cause an error.

| Internal Fault bit | Cause | Note |
|--------------------|----------------------------|--|
| Inrng1 AB00000E | MSTRSLV value out of range | Inrng1 must be high if execute is on or an error will occur. MSTRSLV must have a value from one to ten for this bit to be on. Sets RDA Error ID (MW30181) bit 3. |

<CAMOFFST> Working Register

This table outlines the data in the eight registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Description |
|----------------|---------|-----------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | Execute | EXECUTE input (XB000000) |
| Bit 1 | IN | Distmode | DST-TIME input (XB000001) |
| Bit 3 | Working | Zerodiv | If duration is set to zero for one scan change, this turns on for one scan (one-shot) |
| Bit 6 | Working | distShft_init | High for one scan to initialize for master position shifting if first pass is high and DISTMODE is high. To initialize for master position control of offset. |
| Bit 7 | OUT | Rining | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | Done | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | Eeror | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | OUT | OneshotA | Tied to rising edge of EXECUTE input (AB000000) |
| Bit B | Working | FirstPass | High for first scan of EXECUTE being high |
| Bit C | Working | OneshotC | One shot coil for resetting outputs. Controlled by (AB00000A) |
| Bit D | Working | timeshft_init | High for one scan to initialize for time based shifting if first pass is high and DISTMODE is low. |
| Bit E | Working | Inrng1 | On if EXECUTE is on and MSTSLAVE (XW000001) value is in range |
| <i>AW00001</i> | Working | scans_per_shift | Number of scannings necessary to complete shift of base at time |
| <i>AW00002</i> | Working | iStore | Storage of I |
| <i>AW00003</i> | Working | mstrSlv | MSTSLAVE input (XW000001) -1 |
| <i>AL00004</i> | Working | maxShift_scan | Maximum counts allowed to shift per scan on a time based scan. |
| <i>AL00006</i> | Working | posLAUlim | Positive definite of maxShift_scan |
| <i>AL00008</i> | Working | negLAUlim | Negative value of maxShift_scan |
| <i>AL00010</i> | Working | total_Shifted | Amount CAM Offset has changed during the execution of the block. |
| <i>AL00012</i> | Working | shiftvalue | Value to change the RDA (ML56**4) CAM offset for that scan. |
| <i>AL00014</i> | Working | startmaster | Value of Master counter at start of block for position based move. |
| <i>AL00016</i> | Working | masterDiff | How much the master has moved since the execution of the block. |
| <i>AL00018</i> | Working | desired_shift | Total amount needed to be shifted for the master position mode. |
| <i>AL00020</i> | Working | timemod | Reserved. |
| <i>AW00022</i> | Working | Revision | Revision Level of the function block. |


CAM SCALE function

Function block for MP2000 series

<CAMSCALE> Function Block Summary

The Cam Scale "CAMSCALE" block is used to scale the value of the Cam table output during camming. The rising edge of the *EXECUTE* input bit will cause the *OFFSET* value to be added to the RDA offset at the rate determined by the *DURATION* input. *DST-TIME* input bit determines whether the shift duration is base upon distance the master travels or based on time in milliseconds. 1 = 0.01% for scaling.

Function Block Diagram



<CAMSCALE> Function Block Operation Notes

- **IMPORTANT NOTE: If the CamScale value in the RDA (ML56**8) is zero the slave will not move.**
- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, the block will stop executing (will not complete the change), the offset (or relative scale change) up to that point will remain, and all outputs will be set to zero.
- The RUNNING output bit will be held high until the Offset (or relative scale change) is completed, EXECUTE goes low, or an Error occurs.
- The DST-TIME bit must be set to TRUE to use the master position change or FALSE for the time duration.

- Distance mode note: Be sure to set the duration in the same direction as the master movement. Example: If the block is in Distance mode and the master is moving in the negative direction, and the DURATION is set positive, it will subtract the relative offset and hence the resulting offset (or relative scale change) will not complete. Hence, because the master moves in the wrong direction, the cam scale change will not complete and the DONE output will not turn on.
- The SCALE input is an absolute value (RDA holds the absolute scale ML56**8). Note: 10000 is equal to a multiplier of 1 in the Cam block.
- The Block Running value will appear in the Master/Slave pair section of the RDA (MW56**6).
- Issuing a STOP block on the slave axis will have no affect on the OFFSET block execution.
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc.
- Twenty-three words are used as working registers for this function, starting at the address in *Data23W*.

<CAMSCALE> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | Goes high while offset scale value is being updated in RDA and there are no errors |
| DONE | Bit | Goes high when offset scale change is complete in RDA |
| ERROR | Bit | Goes high if any block errors occur |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| INPUT | TYPE | Content | Range and state |
|----------|---------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| DST-TIME | Bit | Selects master or time for offset duration | TRUE – Master position is used for duration FALSE – Time is used for duration |
| M-S-PAIR | Word | Defines which Master-Slave pair is updated in RDA | 1 to 10 value. Any other value will cause the error output to go on |
| DURATION | Long | Depends on DST-TIME setting. Either time in msec or distance master must travel in counts to complete change in offset. | -2147483648 to 2147483647 If in time mode no negative numbers are allowed. |
| SCALE | Long | Absolute scale to be applied to the slave. RDA will hold current scale level. (RDA offset is ML56**8) | 2147483648~2147483647 |
| DATA23W | Address | Address of the first working register. | Twenty-three words of register space are used by this function. |

<CAMSCALE> Block Fault Condition:

The following tables might cause the error, and outline some situations. If the EXECUTE input bit is turned off, the value is cleared.

| Internal Fault Bit | Cause | Note |
|--------------------|----------------------------|--|
| inrng1 AB00000E | MSTRSLV value out of range | Inrng1 must be high if execute is on or an error will occur. MSTRSLV must have a value from one to ten for this bit to be on. Sets RDA Error ID (MW3**81) bit 3. |

<CAMSCALE> Working Registers

This table outlines the data in the eight registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|--------------|---------|-----------------|---|
| AW00000 | | | |
| Bit 0 | IN | execute | EXECUTE input (XB000000) |
| Bit 1 | IN | distmode | DST-TIME input (XB000001) |
| Bit 3 | Working | zerodiv | If duration is set to zero for one scan change, this turns on for one scan (one-shot) |
| Bit 6 | Working | distShft_init | High for one scan to initialize for master position shifting if first pass is high and DISTMODE is high. To initialize for master position control of offset. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | High for first scan of EXECUTE being high |
| Bit D | Working | timeshft_init | High for one scan to initialize for time based shifting if first pass is high and DISTMODE is low. |
| Bit E | Working | inrng1 | On if Execute is on and MSTSLAVE (XW000001) value is in range |
| AW00001 | Working | scans_per_shift | Number of scans needed to complete a time based shift. |
| AW00002 | Working | iStore | Pass through value for i. |
| AW00003 | Working | mstrSlv | MSTSLAVE input (XW000001) – 1. |
| AL00004 | Working | maxShift_scan | Maximum counts allowed to scale per scan on a time based scan. |
| AL00006 | Working | posLAUlim | Positive value of maxShift_scan |
| AL00008 | Working | negLAUlim | Negative value of maxShift_scan |
| AL00010 | Working | total_Shifted | Amount Scale Offset has changed during the execution of the block. |
| AL00012 | Working | shiftvalue | Relative value to change the RDA (ML03**8) cam scale for that scan. |
| AL00014 | Working | startmaster | Value of Master counter at start of block for position based move. |
| AL00016 | Working | RelativeChange | Difference between set scale value and current scale value in RDA. |
| AL00018 | Working | desired_shift | Total amount needed to be scaled for the master position mode. |
| AL00020 | Working | timemod | Reserved. |
| AW00022 | Working | Revision | Revision Level of the function block. |


CHANGE DYNAMICS function

Function block for MP2000 series

<CHNGDYN> Function Block Summary

This function block sets acceleration, deceleration, S-Curve and the speed. Each parameter is set in the first execution scan.

Function Block Diagram



<CHNGDYN> Function Block Operation Notes

- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, the block will finish move but all outputs will be set to zero.
- The RUNNING output bit will be held high parameter change is completed, EXECUTE goes low or an Error occurs.
- If any of the inputs (absolute value) are greater than the Maximum value in the RDA an Error will occur.
- When parameter setting is completed, the DONE output is turned on.
- Each value (SPEED, ACCEL, DECEL, and SCURVE) is also set to the corresponding RDA.
- S-Curve value is for the running average filter. S-curve outputs literally "S" reference on acceleration and the deceleration.

- Five words are used as working registers for this function, starting at the address in *Data05W*.

<CHNGDYN> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| OUTPUT | TYPE | DESCRIPTION |
|---------|------|---|
| RUNNING | BIT | THE FUNCTION BLOCK EXECUTES (*O) IN. |
| DONE | BIT | THERE ARE NEITHER EXECUTION COMPLETION (ALL THE VALUES ARE SET) NOR ERROR GENERATION. |
| ERROR | BIT | ERROR GENERATION (THE INPUT VALUE IS OUTSIDE A SET RANGE) |

Input Registers

| Input | Type | Description | Range and state |
|---------|---------|--|--|
| EXECUTE | Bit | Block enable – see block operation notes. | Rising edge initiates block TRUE – continue executing FALSE – see block operation notes |
| AXIS | Word | Axis number related to the block. | 1~16 |
| TIME | Word | Timer setting | 1~32767[sec] |
| SCURVE | Long | S-Curve value to store in RDA and controller | Zero to Max value is limited to max value in RDA (ML3**34). Value is stored in milliseconds |
| ACCEL | Long | Acceleration value to store in RDA and controller. | Zero to Max value is limited to max value in RDA (ML3**22). Value is stored in counts/sec ² |
| DECEL | Long | Deceleration value to store in RDA and controller. | Zero to Max value is limited to max value in RDA (ML3**28). Value is stored in counts/sec ² |
| SPEED | Long | Velocity value to store in RDA and controller. | Max absolute value is limited to max value in RDA (ML3**28). Value is stored in counts/sec. |
| DATA05W | Address | Address of the first working register. | Five words of register space are used by this function. |

<CHNGDYN> Block Fault Condition

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW3**81 and MW3**82) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 200 for each axis. Example: Axis#1 stores to MW30181, Axis #2 stores to MW30381, etc.

| Internal Fault Bit | Cause | Note |
|-----------------------|---|---|
| JerkOut AB000001 | S-curve value is not within acceptable range. | Bit must be on or error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| AccelOut AB000002 | Acceleration value is not within acceptable range. | Bit must be on or error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| DecelOut AB000003 | Deceleration value is not within acceptable range | Bit must be on or error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| VelOut AB000004 | Speed value is not within acceptable range. | Bit must be on or error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| axisInErr AB000005 | The axis number entered on the input is not an acceptable value | The function block can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |

<CHNGDYN> Working Register

This table outlines the data of six registers used in the function block. The user is, and there is not a necessity and either is usually no what directly accessed any of these bits.

| Register No | TYPE | Name | Content |
|-------------|---------|-----------|---|
| AW00000 | | | |
| Bit 0 | IN | execute | Execute input (XB000000) |
| Bit 1 | Working | jerkOut | Verifies that the <i>SCURVE</i> input (XW00001) is in range. |
| Bit 2 | Working | accelOut | Verifies that the <i>ACCEL</i> input (XW00002) is in range. |
| Bit 3 | Working | decelOut | Verifies that the <i>DECEL</i> input (XW00003) is in range. |
| Bit 4 | Working | velOut | Verifies that the <i>SPEED</i> input (XW00004) is in range. |
| Bit 5 | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| Bit 7 | OUT | Running | Directly controls YB000000 (<i>Running</i> Output) |
| Bit 8 | OUT | done | Directly controls YB000001 (<i>Complete</i> Output) |
| Bit 9 | OUT | Mistake | Directly controls YB000002 (<i>BlkFault</i> Output) |
| Bit A | Working | osExecute | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing block on the rising edge of the Execute bit. |
| AW00001 | | | |

| | | | |
|---------|---------|-----------|--|
| Bit 0 | Working | holdCntrl | Goes High and remains high until block is complete or timer times out. |
| Bit 1 | Working | Reserved | Reserved |
| Bit 2 | Working | Reserved | Reserved |
| Bit 3 | Working | Reserved | Reserved |
| Bit 4 | Working | Reserved | Reserved |
| Bit 5 | Working | Reserved | Reserved |
| Bit 6 | Working | Reserved | Reserved |
| Bit 7 | Working | Time-out | Goes high when timer (TIME) runs out. |
| Bit 8 | Working | clrComnd | Reserved |
| Bit F | Working | oneshotF | Reserved |
| AW00002 | Working | Counter | Counter register for time out timer. |
| AW00003 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00004 | Working | Revision | Revision level of block. |

GEAR function

Function block for MP2000 series


<GEAR> Function Block Summary

The “Gear” block is used to slave the given axis to any defined real or virtual master pulse data. There are two gearing modes of operation, Rigid Gearing and Non-Rigid Gearing. In either mode, when the slave is successfully following the master position at the geared ratio (speed match event), the tracking output will turn on. Other features of ‘slave stop’ or ‘slave continue at current speed’, are also available when disengaging gearing. Refer to the attached timing chart for details.

Rigid gearing will phase lock the slave, following position to a specified ratio of the master position data, at the exact moment of the gear engage signal. If the master pulse is already moving, the slave will accelerate at a rate set by the RDA, and over-speed to catch up to the master position phase. The over-speed is limited to the maximum velocity set in the RDA.

Non-Rigid gearing will cause the slave to follow the speed of the master. If the master pulse is already moving, the slave will accelerate at a rate set by RDA, but will lag in position equal to the area under the acceleration curve (it will remain phase locked *after* speed is matched and in tracking mode).

Function Block Diagram



<GEAR> Function Block Operation Notes

- Slave Offset and Change Dynamics function blocks may be useful when using this block.
- Rising edge of EXECUTE input initiates block operation, and several block input values are read once. These inputs are: RIGID, AXIS, MSTR-SLV. This event will also verify & set the ACCEL & DECEL values in the servopack to zero. Note that this only means that the MP controller will control the ACCEL/DECEL rates as set in the RDA (acceleration time (ML3**46) and deceleration time (ML3**48)) and the servopack will not limit the accel/decel.
- **IMPORTANT NOTE:** Gearing sets Acceleration and Deceleration in the servopack to 0 ms. (acceleration time (ML3**46) →(OL**36), →(Pn80B), and deceleration time (ML3**48) →(OL**38) →(Pn80E)). In Gearing the Accel/Decel rates are controlled inside the Gearing block. **After the Gearing Block is used and its motion has stopped (motion command IW**08=0), before initiating any other motion blocks, a Change Dynamics block must be used to restore the Accel and Decel values in the servopack. This will restore the expected operation of the other motion blocks.**
- The following inputs are always read when EXECUTE bit is high: GEARIN, GEAROUT, RATIO-N, RATIO-D, RAW-DATA.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes OFF while axis is gearing, the block will set the axis in speed mode (Motion command 7(constant speed sending)) at the speed it was going at that moment, but all outputs will be set to zero.
- If the GEAROUT bit goes high while the execute bit is high, and the block is gearing, then the axis will decelerate to a stop, at the set deceleration in the RDA.
- The Slave offset value in the RDA is set to zero when the gearing block is engaged.
- If the RIGID input is set high, the slave axis will be set in a phase lock mode at GEARIN timing. The slave will over-speed (limited to max speed of slave) to catch up in position if necessary, when the slave axis matches the (master phase position)*(gear ratio), and (master speed)*(gear ratio), the tracking bit will turn on. See graph below.
- If the RIGID input is set low, the slave axis will only speed match. The slave axis will ramp up to speed, when the slave axis matches speed of the master, the tracking bit will turn on.
- The GEARING output bit will be held high as long as the EXECUTE input is held high and the GEAROUT bit stays low, and no other block takes control.
- The maximum speed the slave axis can operate at is limited by the RDA Maximum speed setting for that axis. If the master pulse input commands the slave to go faster than this speed, the axis will travel at the max. speed, set the ERROR output to high, and set the TRACKING output to low. The error bit will return to off state when commanded speed becomes less than max velocity setting. An error bit will be registered in the RDA. Note that this condition does not occur during acceleration over-speed for rigid gearing.

- Thirty-five words are used as working registers for this function, starting at the address in *Data35W*.

<GEAR> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------|------|---|
| GEARING | Bit | This bit is ON when gearing is active in the slave axis |
| TRACKING | Bit | This bit is ON when the slave is following the commanded phase and speed (multiplied by gear ratio) of the Master |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). This is Reset if EXECUTE bit goes low. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Gear function work as necessary.

- Gear ratio = (RATIO-N/RATIO-D)
- Example: for slave to follow at half the speed of the master, set RATIO-N=1 and RATIO-D=2.

| Input | Type | Description | Range and State |
|----------|------------------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. FALSE clears all outputs to zero or FALSE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, see block operation note for additional info |
| GEARIN | Bit | Sets the axis in gearing mode with the specified gear ratio. | Always read when EXECUTE=high RISING EDGE- If the execute bit is high this will set the axis to be in gearing mode. |
| GEAROUT | Bit | Takes the axis out of gearing mode and stops the axis with the set deceleration value from the RDA | Always read when EXECUTE=high RISING EDGE- If the execute bit is high this will set the axis to be in gearing mode. |
| RIGID | Bit | Determines weather the block will gear with phase lock or strictly speed matching. | Read only on EXECUTE rise edge TRUE – Rigid enable FALSE – Non-Rigid |
| AXIS | Word | Axis number related to the block. | Read only on EXECUTE rise edge 1 to 16 |
| M-S-PAIR | Word | Master Slave Pair as defined by the RDA | Read only on EXECUTE rise edge 1 to 10 integer. This value is needed to match the value of the Slave offset function block. |
| RATIO-N | Word | Numerator value of gear ratio * | Always read when EXECUTE=high -32768 to 32767 integer. |
| RATIO-D | Word | Denominator value of gear ratio * | Always read when EXECUTE=high -32768 to 32767 excluding zero. A zero will cause an error |
| RAW-DATA | Long | Pulse counter of master | Always read when EXECUTE=high The (change in this value * RATIO-N) / RATIO-D will be the commanded change in the Slave. |
| DATA35W | Addresses | Address of the first working register. | Thirty-five words of register space are used by this function. |

<GEAR> Block Error Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal error bit | Cause | Attention |
|-------------------------|--|--|
| notTracking AB000003 | IF the commanded change is faster then the axis is allowed to go | The max. speed set by the RDA can not be exceeded. This is the only error that will allow the axis to continue moving in this blocks control. This will also generate an error in the RDA at MB3**819. |
| inrng1 AB000004 | Master/Slave pair input out of range | Value on input must be between 1 and 10. If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813. |
| inrng2 AB000005 | Ratio-D input is set to zero | Cannot have a zero in the denominator If this bit goes low while execute is high an error will occur. This will also generate an error in the RDA at MB3**813. |
| dirError AB00000C | Direction not allowed by SVON | The direction commanded was not enabled by SVON function. This will also generate an error in the RDA at MB3**814. |
| cmndErr AB00000E | Another block took control of axis. | If another axis controlling block is executed it will take control from this function. This does not set the RDA Error ID. |
| axisInErr AB000304 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |

<GEAR> Working Registers

This table outlines the data in the thirty-four registers used by the Gear function block. There is not usually any need for the user to access any of these registers directly.


| Register No | TYPE | Name | Content |
|----------------|---------|--------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | gearin | <i>GEARIN</i> input (XB000001) |
| Bit 2 | IN | gearout | <i>GEAROUT</i> input (XB000002) |
| Bit 3 | Working | notTracking | <i>notTracking</i> bit goes high when commanded speed exceeds max. allowed |
| Bit 4 | Working | inrng1 | Goes high while <i>EXECUTE</i> input is high and master/slave MSTR-SLV value is in range |
| Bit 5 | Working | inrng2 | Goes high while <i>EXECUTE</i> input is high and RATIO-D value is in range |
| Bit 6 | Working | match | High when previous scanned command counts equal counts moved by slave. |
| Bit 7 | OUT | gearing | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | Working | oneshot8 | Reserved. |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Rising edge of <i>GEARIN</i> (AB000001) |
| Bit B | Working | firstPass | On for single scan to initiate gearing if all conditions are met. Sets OW**20=4 |
| Bit C | Working | dirError | Indicates BSVON has not enabled axis to run in that direction |
| Bit E | Working | cmndErr | One shot Goes high when another block takes control away |
| Bit F | Working | intrack | On if commanded move is within speed limits |
| AL00004 | Working | Master_Difer | Change in Master counts over one scan. |
| AL00006 | Working | ModVal | Reserved. |
| AL00010 | Working | oldoffset | Value of offset from RDA at last scan |
| AL00012 | Working | delta_Offset | Change in offset (AL0010) since last scan |
| AL00014 | Working | LastScan | Value of RAW-DATA (XL00004) at last scan |
| AL00016 | Working | Prev_Move | Move commanded last scan |
| AL00022 | Working | slv_oldPos | Store Target position (IL**10) |
| AL00024 | Working | Max_Chnge | Maximum count change per scan based on Max speed limit in RDA |
| AL00026 | Working | Max_limit | Positive max. count per scan allowed. |
| AL00028 | Working | Min_Limit | Negative max. count per scan allowed. |
| <i>AW00030</i> | | | |
| Bit 0 | Working | stopping | Goes high while in stopping mode (OW**08 = 7) |
| Bit 1 | Working | stopped | Goes high for one scan once axis has stopped moving (set OW**08 = 0) |
| Bit 2 | Working | speedset | Goes high for falling edge of <i>EXECUTE</i> (set OW**08 = 7) and (set OL**10 = current speed). |
| Bit 3 | Working | onePass | Goes High on rising edge of <i>Execute</i> for one scan |
| Bit 4 | Working | axisInErr | Axis number out of range |

TECHNICAL NOTE




| | | | |
|---------|---------|------------|---|
| Bit 5 | Working | RDA_Error | Reserved |
| Bit 6 | IN | atStop | <i>RIGID</i> input (XB000003) |
| Bit 8 | Working | speed_ok | High when speed is matched to master |
| Bit A | Working | oneshot30A | Reserved |
| Bit B | Working | oneshot30b | Reserved |
| Bit C | Working | oneshot30c | Reserved |
| Bit D | Working | oneshot30d | Reserved |
| Bit F | Working | oneshot30f | Reserved |
| AW00033 | Working | rDAmult | Value for address offset to locate proper RDA |
| AW00034 | Working | Revision | Revision level of block. |

<GEAR> Timing chart RIGID=ON



* Note that the commanded leads the master for PLC scan compensation. This is to insure that the slave actual position is precisely synchronized to master pulse reference.

<GEAR> Timing chart RIGID=OFF




HOME function

Function block for MP2000 series

<HOME> Function Block Summary

The HOME function is used to home the axis. Home is a position marked by a home switch input(DEC), over travel (POT, NOT) input signals and C phase pulses of the motor or ZERO signal. There are 13 kinds of methods of the home position return (Refer to the chapter of "Home position return method" for details). Only the incremental encoder is supported to this block.

Function Block Diagram



<HOME> Function Block Operation Notes

- This is *not* valid for Absolute Encoder application, only for Incremental encoder.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the *Execute* bit goes off during operation, all outputs will be set to zero and axis will remain in whatever state it was in when the *Execute* bit went low.
- The RUNNING output bit will be held high until homing is completed or an *Error* occurs.
- The motor will move at TRVSPD (speed of the rapid feed) to find the falling edge of the home switch input (DEC signal, the input to CN1 connector/DEC) when the TYPE input (home position return method) is "0" (DEC+C phase pulse). The rotation direction is selected by the REVERSE input. The searching motion decelerates to APRSPD (approach speed) when the falling edge of the DEC signal is detected, and decelerates to CRPSPD (creep speed) with the rising edge of the C phase pulse. OFFSET distance (final distance) is advanced from C phase pulse and the position is set to the OFFSET value.
- When the home process is completed, the DONE bit will turn ON and the RUNNING bit will turn OFF. If the time limit defined by TIMELIM expires before the homing process is completed, a *block Error* is generated.
- Eleven words are used as working registers for this function, starting at the address in *Data11W*.

<HOME> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | High while block has control and move is in progress. |
| DONE | Bit | Turns on when Homing process is completed |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range and State |
|---------|---------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| REVERSE | Bit | Determines direction of homing. | TRUE – Seek in reverse FALSE – Seek in forward |
| INPUT | Bit | “INPUT” signal for Homing type that uses it. | Only homing type 18 and 19 use the INPUT signal. |
| AXIS | Word | Axis number related to the block | 1~16 |
| TIME | Word | Maximum time to complete the homing, if timeout then ERROR. | Time in seconds. Range: 0 to 32767 integers |
| TRAVSPD | Long | Traverse speed of servo while searching for the home switch. In counts per second. | 0 to maximum speed (ML3**12) |
| APRSPD | Long | Approach speed reference unit/sec | 0 to maximum speed (ML3**12) |
| CRPSPD | Long | Creep rate reference unit/sec | 0 to maximum speed (ML3**12) |
| Offset | Long | Final moving distance. And the position will be this value. | Position in encoder counts. Range -2^{31} to 2^{30} integers |
| DATA11W | Address | Address of the first working register. | Eleven words of register space are used by this function. |

<HOME> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW3**81) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 200 for each axis. Example: Axis#1 stores to MW30181, Axis #2 stores to MW30281, etc.

| Internal error bit | Cause | Attention |
|-----------------------|--|--|
| axisInErr AB000006 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID. |
| cmndErr AB000007 | Another block took control of the axis. | If the block loses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| errStop AB000008 | Motion commanded and servo is disabled | If block is running and the servo is disabled the error bit will be set. Sets RDA Error ID (MW3**81) bit B on if error state exists. |
| OTAlarm AB00000C | Over travel Alarm | An over travel bit went low and <i>REVONOT</i> was FALSE. No home switch was found. Sets RDA Error ID (MW3**81) bit 0 on if error state exists. |
| VEL_ERROR AB00000D | Either the speed of rapid feed, approach speed or creep speed is not acceptable value. | Turns on when the set value is not acceptable. Sets RDA Error ID (MW3**81) bit 3 on if error state exist. |
| TimeOver AB00000F | Time Limit reached | The total time defined by the <i>TIMELIM</i> input word was exceeded. Sets RDA Error ID (MW3**81) bit 2 on if error state exists. |

<HOME> Homing Type

(1) Homing Type Option

The following table shows thirteen Homing Type. Please select the best one for the machine.


| TYPE | Name | Method | Note |
|------|-----------------------------|--|--|
| 0 | DEC1+C phase pulsed system | Three step deceleration method with deceleration limit switch and C phase pulse. | DEC1 signal: DEC signal of the servo amplifier. |
| 1 | ZERO signaling system | Homing method with ZERO signal. | ZERO signal: EXT1 signal of the servo amplifier. |
| 2 | DEC 1+ZERO signaling system | Three step deceleration method with deceleration limit switch and ZERO signal | DEC1 signal: DEC signal of the servo amplifier. ZERO signal: EXT1 signal of the servo amplifier. |
| 3 | C phase pulsed system | Homing method with C phase pulse | |
| 11 | C phase pulse | Method only with C phase pulse | |
| 12 | POT & C phase pulse | Method with positive OT signal and C phase pulse | POT: POT signal of the servo amplifier. |
| 13 | POT | Method only with positive OT signal | POT: POT signal of the servo amplifier. This method is not applicable if repeatability is required. |
| 14 | HOME LS&C phase pulse | Method with HOME signal and C phase pulse | HOME: EXT1 signal of the servo amplifier. |
| 15 | HOME LS | Method only with HOME signal | HOME: EXT1 signal of the servo amplifier. |
| 16 | NOT&C phase pulse | Method with reverse OT signal and C phase pulse | NOT: NOT signal of the servo amplifier. |
| 17 | NOT | Method only with reverse OT signal | NOT: NOT signal of the servo amplifier. This method is not applicable if repeatability is required. |
| 18 | INPUT & C phase pulse | Method with INPUT signal and C phase pulse | INPUT: INPUT signal |
| 19 | INPUT | Method only with INPUT signal | INPUT: INPUT signal This method is not applicable if repeatability is required. |

(2) Homing operation and parameters

The motion after the function is executed and parameters to be set at the execution of the function are shown below.

(a) DEC1+C phase pulse system

The movement starts at the speed of the homing, speed of the rapid feed, in the direction specified by the REVERSE input. When the rising edge of the DEC1 signal is detected, the speed is decelerated to the approach speed. The speed is decelerated to the creep speed when the first C phase pulse is detected after the DEC1 signal is passed and positioning is performed. The machine coordinate system is established with the position to be the HOME. Distance from C phase pulse is set in the OFFSET. If OT signal is detected while in Homing process, it becomes OT alarm.




- * 1. The SERVOPACK DEC signal.
- * 2. The SERVOPACK P-OT signal.
- * 3. The SERVOPACK N-OT signal.

| Input | Name | Set Content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT signal | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 0: "DEC+C phase pulse" The method is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(b) ZERO signal method

The movement starts at the approach speed in the direction specified by the parameter. Speed is decelerated to the creep speed at the rising edge of the ZERO signal and finishes positioning. The machine coordinate system is established with the position to be the HOME. The amount of the movement from the ZERO signal is set in the final travel distance of homing. When the OT signal is detected while in homing process, it becomes OT alarm.




- * 1. The SERVOPACK EXT1 signal.
- * 2. The SERVOPACK P-OT signal.
- * 3. The SERVOPACK N-OT signal.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 1: "ZERO signal" method is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Not used |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(c) DEC 1+ZERO signal method

The movement starts at the speed of the homing in the direction specified by the parameter. When the rising edge of the DEC1 signal is detected, speed is decelerated to the approach speed. Speed is decelerated to the creep speed at the rising edge of the ZERO signal after DEC1 is passed at the approach speed, and final positioning is performed. The machine coordinate system is established with the position to be the HOME . The amount of the movement from the ZERO signal is set in the final travel distance of homing. When the OT signal is detected while in homing process, it becomes OT alarm.




- * 1. The SERVOPACK DEC signal.
- * 2. The SERVOPACK EXT1 signal.
- * 3. The SERVOPACK P-OT signal.
- * 4. The SERVOPACK N-OT signal.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 2: "DEC+ZERO signal" method is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(d) C phase pulse method

The movement starts at the approach speed in the direction specified by the parameter. Speed is decelerated to the creep speed at the rising edge of C phase pulse, and final positioning is performed. The machine coordinate system is established with the position to be the HOME. The amount of the movement from C phase pulse is set in the final travel distance of homing. When the OT signal is detected while in homing process, it becomes OT alarm.




- * 1. The SERVOPACK P-OT signal.
- * 2. The SERVOPACK N-OT signal.


| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 3: "C phase pulsed system" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Not used |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(e) C phase pulse method

The movement starts at the creep speed in the direction specified by the parameter, and final positioning is performed at the rising edge of C phase pulse with the positioning speed. The machine coordinate system is established with the position to be the HOME. The amount of the movement from C phase pulse is set in the final travel distance of homing. The positioning speed is set in the rapid feed speed. OT signal does not cause an alarm when the is detected while moving at the creep rate, but reverses the direction. And homing process looks for C phase pulse. If OT signal is detected at the positioning speed, it becomes OT alarm.



OT Signal Detected during Creep Speed Operation



* 1. The SERVOPACK P-OT signal.

* 2. The SERVOPACK N-OT signal.


Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 11: "C phase pulse" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) |
| APRSPD | Approach speed | Not used |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(f) POT & C phase pulse method

The movement starts at the approach speed, and moves to the stroke limit in a positive direction. The movement is reversed when POT signal is detected at the creep speed. POT signal is passed in reversed direction and C pulse is detected, the final positioning is performed. The machine coordinate system is established with the position to be the HOME. The amount of the movement from C phase pulse is set in the final travel distance of homing. Positioning speed is set in the rapid feed speed. When the OT signal is detected while moving at the positioning speed, it becomes OT alarm.

Note: The stop method when the OT signal is detected follows the user constant setting of the servo amplifier.



* 1. The SERVOPACK P-OT signal.

* 2. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 12: "POT&C phase pulse" is selected |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(g) POT


The movement starts at the approach speed, and moves to the stroke limit in a positive direction. The movement reverses when the POT signal is detected. While in reverse motion at positioning speed and POT is cleared the final positioning is performed. The machine coordinate system is established with the position to be the HOME.

The amount of the movement from the change detection point of the POT signal status is set in the final travel distance of homing and the positioning speed is set in the rapid feed speed.


When the OT signal is detected while moving at the positioning speed, it becomes OT alarm.

Detection of the OT signal status change is done by the software. Therefore, positioning accuracy can not be guaranteed because of high-speed scan time and positioning speed.

Please do not use this method if repeatability is required for the home position.



Starting on the Positive Overtravel Limit (POT)



* 1. The SERVOPACK P-OT signal.


* 2. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.


| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 13: "POT" is set. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error. |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Not used. |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(h) HOME LS & C phase pulse method

The movement starts at the approach speed in the direction specified by the parameter. Speed is changed to the creep speed at the rising edge of the HOME signal. The final positioning is performed at the positioning speed after the first C phase pulse is detected after the falling edge of the HOME signal. The machine coordinate system is established with the position to be the HOME. The amount of the movement from C phase pulse is set in the final travel distance of homing. Positioning speed is set in the rapid feed speed. OT detection at the approach speed does not become an alarm, but the movement reverses, and looks for the HOME signal. If the OT signal is detected while moving at the positioning speed, it becomes OT alarm.



Detecting the OT Signal during Approach Speed Movement



* 1. The SERVOPACK EXT1 signal.

* 2. The SERVOPACK P-OT signal.


* 3. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.


| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 14: "HOME LS&C phase pulse" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(i) HOME LS

The movement starts at the creep speed in the direction specified by the parameter. At the rising edge of the HOME signal, the final positioning is performed at the positioning speed. The machine coordinate system is established with the position to be the HOME. The amount of the movement from the rising edge of the HOME signal is set in the final travel distance for homing and the positioning speed is set in setting the rapid feed speed. OT signal at the creep speed does not cause alarm but the movement is reversed and looks for the HOME signal. If OT signal is detected while moving at the positioning speed, it becomes OT alarm.



Detecting the OT Signal during Creep Speed Movement



- * 1. The SERVOPACK EXT1 signal.
- * 2. The SERVOPACK P-OT signal.
- * 3. The SERVOPACK N-OT signal.


Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 15: "HOME LS" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Not used |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(j) NOT & C phase pulse method

The movement starts at the approach speed, and moves to the stroke limit in a negative direction. When the NOT signal is detected, the movement is reversed and the speed is changed to the creep speed. When C phase pulse is detected in reversing after the NOT signal is passed the final positioning is performed.

The machine coordinate system is established with the position to be the HOME. The amount of the movement from C phase pulse is set in the final travel distance for homing and the positioning speed is set in the rapid feed speed. When the OT signal is detected while moving at the positioning speed, it becomes OT alarm.



* 1. The SERVOPACK P-OT signal.

* 2. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.


| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 16: "NOT&C phase pulse" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Not used |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) The movement direction is in positive. |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(k) NOT

The movement starts at the approach speed, and moves to the stroke limit in a negative direction. When the NOT signal is detected the movement reverses, at the positioning speed. The final positioning is performed when NOT signal is cleared in reversing. The machine coordinate system is established with the position to be the HOME.

The amount of the movement from the change detection point of the NOT signal status is set in the final travel distance of homing and the positioning speed is set in the rapid feed speed. When the OT signal is detected while moving at the positioning speed, it becomes OT alarm. It was changeable in the OT signal status by the software processing. Therefore, (*S) sets (*O) a high-speed scanning.

Detection of the OT signal status change is done by the software. Therefore, positioning accuracy can not be guaranteed because of high-speed scan time and positioning speed. Please do not use this method if repeatability is required for the home position.



* 1. The SERVOPACK P-OT signal.

* 2. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Not used |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 17: "NOT" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Not used |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |


(I) INPUT & C phase pulse

The movement starts at the approach speed in the direction specified by the parameter. Speed changes into the creep speed if the rising edge of the INPUT signal is detected. When the first C phase pulse after the INPUT signal falling edge is detected, the final positioning is performed at the positioning speed. The machine coordinate system is established with the position to be the HOME.

The amount of the movement from C phase pulse detection point is set in the final travel distance for homing and the positioning speed is set in the rapid feed speed.

If OT signal is detected while moving at the approach speed, it does not become an alarm, but the movement is reversed, and looks for the INPUT signal. When the OT signal is detected while moving at the positioning speed, it becomes OT alarm.

It is necessary to turn on the INPUT signal by the ladder program.



| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT signal | Allocation of INPUT signal Function block sets to OBxx05B. |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 18: "INPUT&C phase pulse" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Approach speed in count/second. 0-Max speed (ML3**12) |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

(m) INPUT

The movement starts at the creep speed in the direction of the sign of the creep speed. The final positioning is performed at the rising edge of the INPUT signal at the positioning speed. The machine coordinate system is established with the position to be the HOME.

The amount of the movement from the rising edge of the INPUT signal is set in the final travel distance of homing and the positioning speed is set in the rapid feed speed.

OT signal while moving at the creep speed does not cause alarm but the movement is reversed, and looks for the INPUT signal.


If OT signal is detected while moving at the positioning speed, it becomes OT alarm.

The INPUT signal is set to OBxx05B. A temporary home position can be set for the trial run since no actual sensor wiring is necessary. Detection of the rising of the INPUT signal is processed by the software.

Therefore, home position can be different by the high-speed scanning setting and the positioning speed.

Please do not use this method if repeatability is necessary for the home position.

INPUT signal must be controlled in the ladder program.



* 1. The SERVOPACK P-OT signal.

* 2. The SERVOPACK N-OT signal.

Note: The stopping method when the OT signal is detected depends on the setting of SERVOPACK parameters.

| Input | Name | Set content |
|---------|-----------------------------|---|
| EXECUTE | Execution | Block enable |
| REVERSE | Direction selection | The direction of the homing. 0: Seek in forward 1: Seek in reverse |
| INPUT | INPUT input | Allocation of INPUT signal Function block sets to OBxx05B. |
| AXIS | Axis setting | Axis number related to the block. 1~16 |
| TYPE | Home position return method | 19: "INPUT" is selected. |
| TIME | Timer limit setting | Maximum time to complete the Homing, if timeout then Error |
| TRAVSPD | Speed of rapid feed | Traverse speed in count/second. 0-Max speed (ML3**12) Moving direction follow the sign of the OFFSET. |
| APRSPD | Approach speed | Not used |
| CRPSPD | Creep rate | Creep speed in count/second. 0-Max speed (ML3**12) |
| OFFSET | Offset value | Final moving distance. And the position will be this value. If the value is positive, the final moving is in the same direction of homing. If it is negative the final moving will be in the opposite of homing |

<HOME> Working Registers

This table outlines the data in the ten registers used by the Home function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|-------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | EEXECUTE | EXECUTE input (XB000000) |
| Bit 1 | IN | REVERSE | REVERSE input (XB000001) |
| Bit 2 | IN | INPUT | INPUT signal (XB000002) |
| Bit 3 | IN | Reservation | Reserved |
| Bit 4 | IN | firstPass | Single shot input of ENABLE input to initialize axis and block |
| Bit 5 | Working | inrngAxis | Goes high for one scan if Axis input is in range. |
| Bit 6 | Working | inrngAxis | Goes high If the RDA register is not set appropriately. |
| Bit 7 | Working | cmndErr | Another block controlled the axis. |
| Bit 8 | Working | ErrSTOP | Servo not enabled when motion is commanded |
| Bit 9 | OUT | Blkfault | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit C | Working | OTalarm | Overtravel alarm |
| Bit D | Working | Vel_Err | Either Rapid feed speed, Approach speed or Creep speed is out of range. |
| Bit F | Working | TimeOver | Time expired will set <i>ERROR output</i> |
| <i>AW00001</i> | | | |
| Bit 1 | OUT | RUNNING | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 2 | OUT | COMPLETE | Directly controls YB000001 (<i>DONE</i> Output) |
| AW00002 | Working | Reserved | Reserved |
| AW00003 | Working | Reserved | Reserved |
| AW00004 | Working | Timer | Timer for limiting home time before <i>ERROR</i> . Tied to <i>TIMELIM</i> input (XW000003). |
| AL00005 | Working | Reserved | Reserved |
| AW00007 | Working | Reserved | Reserved |
| AW00008 | Working | Reserved | Reserved |
| AW00009 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00010 | Working | Revision | Revision Level of the function block. |


LATCH function

Function block for MP2000 series

<LATCH> Function Block Summary

The LATCH function block enables the high speed latch for a motor axis encoder. This block should be used any time the high-speed latch is required except when the Latch Target (Index Move) block is used.

Function Block Diagram



<LATCH> Function Block Operation notes

- Rising edge of EXECUTE input initiates block operation, and the following block input values are read once: AXIS.
- To use the function block, the EXECUTE bit must be held ON. During this, the STATE bit is constantly monitored (STATE indicates latch request from user).
- The RUNNING output bit will be held high until a latch is received, EXECUTE goes low, or an Error occurs. The block will continue to monitor the axis for errors as long as the EXECUTE input stays True.
- If it is EXECUTE=High, and STATE=High, the controller arms latch detection, and wait for the signal specified in the LTSEL be ON. DONE output bit becomes High when latch detection is completed. Latched data of the machine coordinate system is stored to IL**18.
- Latch speed is 30microsec or less.
- Latch detection signal is "/EXT1" if LTSEL=1 and SGDS-***12A (with M□) servo amplifier parameter is default. Input of latch sensor connected with SGDS 1CN connector pin10 can be monitored at IB**2E6
- The latch detection signal is selected by setting LTSEL. 0= C phase pulse, 1=/ EXT1, 2=/ EXT2 and 3=/ EXT3
- Five words are used as working registers for this function, starting at the address in Data05W.

<LATCH> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | This bit is ON when the function block is executing |
| DONE | Bit | This bit is latched ON when the Latch has been detected (IB**OC2=ON). |
| ERROR | Bit | Goes high when the error occurs in execution. Goes low when the error condition is released. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as

| INPUT | TYPE | Content | Range of setting and state |
|---------|---------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE | TRUE – Block enable FALSE – Block disable |
| STATE | Bit | Latch Enable or disable request from user | TRUE – Latch enabled FALSE – Latch disabled |
| AXIS | Word | Axis number related to the block | 1~16 |
| LTSEL | Word | Latch detection signal selection | 0: C phase pulse signal 1: /EXT1 (servo amplifier DI) 2: /EXT2 (servo amplifier DI) 3: /EXT3 (servo amplifier DI) |
| DATA05W | Address | Address of the first working register. | Five words of register space are used by this function. |

necessary.

<LATCH> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal error bit | Cause | Note |
|------------------------|---|---|
| input_OK AB00000E | LTSEL input is not an acceptable value | LTSEL input range is 0 through 3 integer. This error turns ON RDA Error ID(MW3**81) bit3. |
| outRngAxis AB00000F | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID |

<LATCH> Working Registers

This table outlines the data in the four registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | state | <i>STATE</i> input (XB000001) |
| Bit 4 | Working | inrngAxis | Goes high for one scan if Axis input is in range. |
| Bit 6 | Working | closePass | Function internal processing for execution next time. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | done | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved. |
| Bit B | Working | firstPass | One shot coil for initiating Latch and block |
| Bit C | Working | oneshotC | Reserved. |
| Bit E | Working | input_OK | Goes high for one scan if LTSEL input is in range. |
| Bit F | Working | outRngAxis | Goes high for one scan if Axis input is out of range. |
| AW00003 | Working | rDAmult | Value for address offset to locate proper RDA |
| AW00004 | Working | Revision | Revision Level of the function block. |

LATCH TO TARGET function

Function block for MP2000 series

<LTHTRGT> Function Block Summary

The Latch Target (LTHTRGT) block is used to detect a latch on an index move. The axis will be instructed to move a default distance (DFLTDIST), if a latch is received within the window during the index (window is defined between DISTSTRT and DISTEND), the final target position is changed to latch position plus a distance beyond (final target position = Latched position + DISTBYND), and the axis is commanded to move to this new position without interruption. See external timing diagram below for a graphical representation.

Function Block Diagram

| Name | | LTHTRGT | |
|------------|----------------|------------|----------|
| EXECUTE ? | IB04102 | RUNNING ? | DB000020 |
| AXIS | 00001 00001 | DONE ? | DB000021 |
| DISTSTRT ? | ML01200 | LATCHED ? | DB000022 |
| DISTEND ? | ML01202 | ERROR ? | DB000023 |
| DFLTDIST ? | ML01204 | DISTGONE ? | DL00010 |
| DISTBYND ? | ML01206 | | |
| LTSEL | 00001 00001 | | |
| DATA11W ? | DA00080 | | |

<LTHTRGT> Function Block Operation Notes

- Rising edge of EXECUTE input initiates block operation, and the following block input values are read once: AXIS, DISTSTRT, DISTEND, DFLTDIST, and DISTBYND.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, the block will finish move but all outputs will be set to zero.
- DISTBYND is only read at the Latch Event.
- The RUNNING output bit will be held high until: move is completed, EXECUTE goes low, or an Error occurs.
- LATCHED output will turn on if a latch was received within the window during the move (IB**0C2=ON).
- DONE bit turns on when the move is completed. (IW**08=0 running completion of operation).
- If the EXECUTE input bit goes off during operation, all outputs will go to zero and the axis will travel to the default distance unless the latch was detected prior to the bit going low. In that case the axis will go the distance beyond the Latch position.
- Latch is only active between the latch start and latch end window, defined by DISTSTRT and DISTEND inputs. If the latch occurs inside the window the axis will travel the DISTBYND input value beyond the latched position. If a latch occurs outside the window, it will be ignored because the latch is disabled (the motion command changes back). In this case, the axis will go the default distance DFLTDIST.
- If the Latch occurs during the deceleration part of the default distance curve (and it is within the defined window), the axis will accelerate at the defined rate to set speed to achieve the final distance move.
- All distance inputs are relative to the start position except the DISTBYND input. It is relative to the latch position.
- The Distance beyond value should be sufficient a distance for the axis to come to a stop with the set deceleration value or the axis will have to back up to the point desired.
- The latch detection signal is selected by LTSEL input. 0= C phase pulse, 1=/ EXT1, 2=/ EXT2 and 3=/ EXT3
- Eleven words are used as working registers for this function, starting at the address in Data11W.

<LTHTRGT> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function

| Output | Type | Description |
|----------|------|---|
| RUNNING | Bit | High while block has control and move is in progress. |
| DONE | Bit | Goes high when move is completed and remains high until execute is turned off or another block takes control. (IW**08=0 running completion of operation). |
| LATCHED | Bit | Goes high if the latch was detected within the specified window (IB**0C2=ON). |
| ERROR | Bit | Goes high if any error occurs in block or on the axis. Goes low if the error condition is released. |
| DISTGONE | Long | Current Distance in counts axis has traveled in this move. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| INPUT | TYPE | Content | Range and state |
|----------|---------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| DISTSTRT | Long | Sets the beginning of the latch activation window. Defined as distance in counts <i>from</i> the start position of the axis. Latch is armed between DISTSTRT and DISTEND. | 2147483648~2147483647 |
| DISTEND | Long | Sets the end of the latch activation window. Defined as distance in counts <i>from</i> the start position of the axis. Latch is armed between DISTSTRT and DISTEND. | 2147483648~2147483647 |
| DFLTDIST | Long | Default distance to travel in counts <i>from</i> the start position of the axis. This is the relative distance the axis will travel if a latch is not detected | 2147483648~2147483647 |
| DISTBYND | Long | Distance to travel in counts from the Latch position. This is the additional relative distance the axis will travel (from the latch detection position) if a latch is detected. | 2147483648~2147483647 |
| LTSEL | Word | Latch detection signal selection | 0: C phase pulse signal 1: /EXT1 (servo amplifier DI) 2: /EXT2 (servo amplifier DI) 3: /EXT3 (servo amplifier DI) |
| DATA11W | Address | Address of the first working register. | Eleven words of register space are used by this function. |

<LTHTRGT> Block error condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.


| Internal error bit | Cause | Attention |
|------------------------|--|--|
| errStop AB000005 | Motion commanded and servo is disabled. | If block is running and the servo is disabled the error bit will be set. Sets RDA Error ID (MW3**81) bit B on if error state exists. |
| commanderr AB00000E | Another block took control of the axis. | If the block loses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| direrror AB00000F | The direction commanded to travel is disabled from the SVON block. | The SVON block must be used and have the direction commanded enabled. Sets RDA Error ID (MW3**81) bit 4 on if error state exists. |
| axisInErr AB000083 | The axis number entered on the input is not an acceptable value | The SVB multiaxis blocks can only control 1 to 16 axes. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID.. |

<LTHTRGT> Working Registers

This table outlines the data in the twelve registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 3 | Working | latched | Goes high for one scan, if a latch occurs inside the latch activation window (one-shot) |
| Bit 4 | Working | oneshot | Reserved. |
| Bit 5 | Working | errStop | Goes high if servo faults out while running. |
| Bit 6 | OUT | Latched | Directly controls YB000002 (<i>LATCHED</i> Output) |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000003 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot coil for initiating axis and block. |
| Bit C | Working | oneshotC | Reserved. |
| Bit E | Working | commanderr | Rising Edge indicates another block took control. |
| Bit F | Working | direrror | Indicates direction commanded is not enabled. |
| AL00002 | Working | startpos | Value of axis position at start of move. |
| AL00004 | Working | distGone | Directly controls YL000001 (<i>DISTGONE</i> Output) |
| AW00009 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00010 | Working | Revision | Revision Level of the function block. |

<LTHTRGT> Timing chart




MODULUS ENGINE function

Function block for MP2000 series

<MOD_ENG> Function Block Summary

The “MOD-ENG” block is used to modulate any counter (true encoder or virtual counter) into a saw tooth shape pattern with a cycle equivalent to the machine cycle desired (see diagram below). The machine cycle is the highest value the output can go before it returns to zero. This block stores its data in the RDA based on its Master/Slave value. This block is required for the Cam function block to work.

Function Block Diagram



<MOD_ENG> Function Block Operation Notes

- This block should be used with CAM function block.
- To use the function block, the *ENABLE* bit must be held ON. The block will begin to execute (output the modulated RAWDATA input) on a rising edge from the *EXECUTE* bit.
- If the *ENABLE* bit goes off during operation, the Raw data as well as the modulated data will stop being sent to the RDA and all outputs will go to zero.
- The *RESET* bit sets the modulated data to zero.
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc
- Fourteen words are used as working registers for this function, starting at the address in *Data14W*.

<MOD_ENG> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|---|
| RUNNING | Bit | This bit is ON when the function block is executing. |
| ENDPRFL | Bit | End of cycle marker pulse. When the full length of the machine cycle has been reached from either direction this bit flickers goes on (one-shot). |
| ERROR | Bit | If an error occurs during block execution, this output latches ON. |
| MODDATA | Long | This is the modulated master output. The value of the modulated data is also stored in the RDA. |

Input register

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range of state |
|----------|---------|--|--|
| ENABLE | Bit | Block enable – Block cannot execute unless this is TRUE | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| EXECUTE | Bit | Starts the Modulus engine, modulates the master counter input. | Rising edge starts block modulation TRUE – modulation active FALSE – holds the modulated data |
| RESET | Bit | Sets the Modulated data to zero, also active when EXECUTE is on. | TRUE – Mod Data = 0 FALSE – Modulus engine free to run |
| M-S-PAIR | Word | Defines which Master-Slave pair is updated in RDA | 1 to 10 value. Any other value will cause the error output to go on. |
| MCHNCYCL | Long | Highest value in modulated data | 1~2147483647 |
| RAWDATA | Long | Input to be modulated (feed virtual counter or encoder here) | 2147483648~2147483647 |
| DATA14W | Address | Address of the first working register. | Fourteen words of register space are used by this function. |

<MOD_ENG> Block error condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.


| Fault bit | Cause | Note |
|----------------------|--|---|
| inOK AB00000D | Machine Cycle input is out of range | inOK must be high if enable is on or an error will occur. <i>MCHNCYCL</i> must be in range for this bit to be on. Sets RDA Error ID (MW30181) bit 3. |
| msSelect AB00000E | <i>M-S-PAIR</i> input value out of range | msSelect must be high if enable is on or an error will occur. <i>M-S-PAIR</i> must have a value from one to ten for this bit to be on. Sets RDA Error ID (MW30181) bit 3. |

<MOD_ENG> Working Registers

This table outlines the data in the eight registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | enable | <i>ENABEL</i> input (XB000000) |
| Bit 1 | IN | reset | <i>RESET</i> input (XB000002) |
| Bit 2 | IN | posOut | Reserved |
| Bit 3 | IN | negOut | Reserved |
| Bit 4 | OUT | endofTravl | Directly controls YB000001 (<i>ENDPRFL</i> Output) |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | Rising edge of <i>EXECUTE</i> (XB000001) |
| Bit D | Working | inOK | Verifies that the <i>MCHNCYCL</i> input (XW000002) is in range. |
| Bit E | Working | msSelect | Verifies that the <i>M-S-PAIR</i> input (XW000001) is in range. |
| AW00001 | Working | store_i | Reserved |
| AW00002 | Working | pairvalue | <i>M-S-PAIR</i> input (XW000001) - 1. |
| AL00003 | Working | o modpos_o | Reserved |
| AL00005 | Working | pos | Modulated data being stored |
| AL00007 | Working | lscratch | Reserved. |
| AL00009 | Working | offset | Reserved |
| AL00011 | Working | modData | Modulated data as read back from the RDA. |
| AW00013 | Working | Revision | Revision Level of the function block. |

<MOD_ENG> Timing chart




MOVE ABSOLUTE function

Function block for MP2000 series

<MOVEABS> Function Block Summary

This function block commands a controlled motion at a specified absolute position. The parameters are used at the time the motion is started. To modify any parameter it is necessary to put the correct SET of values in and to trigger again the motion.

Function Block Diagram



<MOVEABS> Function Block Operation Notes

- MOVABS must be in H drawing, and is executed after SVON and CHANGE DYNAMICS function.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- The RUNNING output bit maintains the operation in execution like High. The output bit becomes Low by the positioning completed, EXECUTE=Low or Error.
- The *RUNNING* output bit will be held high until move is completed (IB**0C1=ON), EXECUTE goes low, or an Error occurs.
- If another block takes control of the axis while the block is running a command error will occur. The ERROR output will go on, but the RDA will not indicate an error.
- The S-curve, Acceleration, Deceleration and the Speed will be set based on the values in the RDA, set by Change Dynamics Block.
- Seventeen words are used as working registers for this function, starting at the address in *Data17W*.

<MOVEABS> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| OUTPUT | TYPE | Content |
|----------|------|---|
| RUNNING | Bit | High while block has control and move is in progress. |
| DONE | Bit | Indicates Move Complete(IB**0C1=ON). When the servo has reached target position within "In-position" window(target position ± positioning completed width), this output bit turns ON. |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). This is Reset if EXECUTE bit goes low. |
| DISTGONE | Long | Distance in counts axis has traveled in this move, while this block has control. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary

| Input | Type | Description | Range and state |
|----------|----------------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| DIRECTIO | Word | Direction to travel | 1 = Positive direction 2 = Negative direction *3 = Continue in current direction *4 = shortest path *: Only can be used if axis is in rotary mode. |
| POSITION | Long | Absolute position in counts for axis to go to. | -2147483648 to 2147483647 [0 to 2147483647 for rotary axis] |
| DATA17W | Address | Address of the first working register. | Seventeen words of register space are used by this function. |

<MOVEABS> Block error condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal error bit | Cause | Attention |
|------------------------|---|--|
| inRng AB000005 | Direction input set out of range | The internal register is reverse logic, it must be ON to indicate the direction input is within valid range. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| errStop AB000143 | Servo Error while in motion | If the error occurs in the servo while the function is operating, this relay becomes on. Bit B of RDA Error ID(MW3**81) is turned on. |
| axisInErr AB00014A | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |
| commanderr AB00000E | Another block took control of the axis. | If the block loses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| direrror AB00000F | The direction commanded to travel is disabled from the SVON. | The SVON block must be used and have the direction commanded enabled. Sets RDA Error ID (MW3**81) bit 4 on if error state exists. |

<MOVEABS> Working Register

This table outlines the data in the eighteen registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | Enable input (XB000000) |
| Bit 1 | IN | shortest | Shortest direction mode is selected |
| Bit 2 | Working | posDir | Positive direction mode is selected |
| Bit 3 | Working | movback | If shortest path is selected and reverse direction is shortest |
| Bit 4 | Working | movfor | If shortest path is selected and positive direction is shortest |
| Bit 5 | Working | inRng | The input of DIRECTIO and POSITION is outside ranges. |
| Bit 6 | Working | negDir | Negative direction mode is selected |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>Running</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>Done</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>Error</i> Output) |
| Bit A | Working | oneshotA | Reserved. |
| Bit B | Working | firstPass | One shot coil for initiating axis |
| Bit C | Working | correntDir | Current direction mode is selected |
| Bit D | Working | movingneg | If in current direction mode and axis is currently going in negative direction. |
| Bit E | Working | commanderr | Rising Edge indicates another block took control. |
| Bit F | Working | direrror | Indicates direction commanded is not enabled. |

| | | | |
|----------------|---------|---------------|---|
| AW00001 | | | |
| <bit> 0 | Working | oneshot10 | Reserved |
| AL00002 | Working | startPos | Commanded position of axis at execution of block. |
| AL00004 | Working | distGone | Distance traveled by axis under the control of this block |
| AL00006 | Working | movPos | Commanded Position |
| AL00008 | Working | encoder_start | Fed back position at start. |
| AL00010 | Working | mcHalf | ½ machine cycle |
| AL00012 | Working | negMChalf | Negative ½ machine cycle |
| | | | |
| | | | |
| AW00014 | | | |
| Bit 0 | Working | posjump | Reserved |
| Bit 1 | Working | negJump | Reserved |
| Bit 2 | Working | oneshot2 | Reserved |
| Bit 3 | Working | errStop | Goes high if servo faults out while running. |
| Bit 4 | Working | oneshot4 | Reserved |
| Bit 5 | Working | comp_oneshot | Rising pulse of Positioning complete |
| Bit 6 | Working | poswrap | Reserved |
| Bit 7 | Working | negWrap | Reserved |
| Bit 8 | Working | oneshot148 | Reserved |
| Bit 9 | Working | inrngAxis | Goes high for one scan if Axis input is in range. |
| Bit A | Working | axisInErr | Latches high if Axis input is out of range. |
| Bit B | Working | onePass | One shot coil for initializing axis data |
| Bit C | Working | oneshot14c | Reserved |
| Bit D | Working | run | Run Command. |
| Bit E | Working | pos_comp | Confirmation of positioning completed. |
| Bit F | Working | closePass | Internal use for the next time execution. |
| AW00015 | Working | rDAmult | Value for address offset to locate proper RDA |
| AW00016 | Working | Revision | Revision Level of the function block. |


MOVE ADDITIVE function

Function block for MP2000 series

<MOVADDTV> Function Block Summary

This function block adds the set distance to the currently designated target position on the fly of discontinuous motion (MOVABS, MOVINC etc.).

Function Block Diagram



<MOVADDTV> Function Block operation Notes

- This block must be in H drawing, and adds the set distance to the currently designated target position on the fly of discontinuous motion (MOVABS, MOVINC etc.).
- Rising edge of EXECUTE input initiates block operation and input data of AXIS and DISTANCE are read. The EXECUTE input must be held ON while in operation.
- The RUNNING output bit will be held high until: the positioning completed, EXECUTE=Low or Error.
- The DONE bit turns on when positioning is completed (IB**0C1=ON). When distributing target position is done and the current position is within the range of the positioning completed (Original target position + DISTANCE – Position Feedback < ± Positioning complete width), the positioning completed bit becomes High.
- If another block takes control of the axis while the block is running, a command error will occur. The ERROR output will go on, but the RDA will not indicate an error.
- The S-curve, Acceleration, Deceleration, and the speed will be set based on the values in RDA, set by Change Dynamics Block.
- Eight words are used as working registers for this function, starting at the address in *Data08W*.

<MOVADDTV> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------|------|--|
| RUNNING | Bit | High while block has control and move is in progress. |
| DONE | Bit | Indicates Move Complete. When the servo has reached target position within “In-position” window, this output bit turns ON. (IB**0C1=ON). |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). |
| DISTGONE | Long | Distance in counts block has traveled in this move, while this block has control. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range of state |
|----------|---------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE | Rising edge initiates TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| DISTANCE | Long | Additional distance to current target position. | - 2147483648~2147483647 |
| DATA08W | Address | Address of the first working register. | Eight words of register space are used by this function. |

<MOVADDTV> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal error bit | Cause | Attention |
|------------------------|--|--|
| errStop AB00000D | Servo Error | If block is running and the servo faults the error bit will be set. Sets RDA Error ID (MW3**81) bit B on if error state exists the |
| axisInErr AB000002 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |
| Commanderr AB00000E | Another block took control of the axis.. | If the block looses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| Direrror AB00000F | The direction commanded to travel is disabled from the SVON block. | The SVON block must be used and have the direction commanded enabled. Sets RDA Error ID (MW3**81) bit 4 on if error state exists. |

<MOVADDTV> Working Registers

This table outlines the data in the nine registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|---------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | onepass | One shot on rising edge of EXECUTE input to set axis data. |
| Bit 2 | Working | axisInErr | Latches high if Axis input is out of range. |
| Bit 3 | Working | oneshot3 | Reserved |
| Bit 4 | Working | inrngaxis | Goes high for one scan if Axis input is in range. |
| Bit 5 | Working | oneshot5 | Reserved. |
| Bit 6 | Working | completeSet | Rising pulse of Positioning complete. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>EEROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot on rising edge of EXECUTE input to initialize axis. |
| Bit C | Working | oneshotC | Reserved |
| Bit D | Working | errStop | Goes ON when servo error occurs while running. |
| Bit E | Working | commanderr | Rising Edge indicates another block took control |
| Bit F | Working | direrror | Indicates direction commanded is not enabled.. |
| <i>AW00001</i> | | | |
| Bit 0 | Working | oneshot10 | Reserved |
| Bit 1 | Working | closepath | Function internal processing for execution next time. |
| Bit 2 | Working | second_Pass | Reserved |
| Bit 6 | Working | position_Mode | Confirmation of positioning mode. |
| Bit 7 | Working | move_Done | Confirmation of positioning completed. |
| Bit D | Working | oneshot1D | Reserved |
| | | | |
| | | | |
| | | | |
| AL00002 | Working | startpos | Position of axis at start of move. |
| AL00004 | Working | distGone | Directly controls YL000001 (<i>DISTGONE</i> Output) |
| AW00006 | Working | rdaMulti | Value for address offset to locate proper RDA |
| AW00007 | Working | revision | Revision Level of the function block. |


MOVE INCREMENTAL function

Function block for MP2000 series

<MOVINC> Function Block Summary

This function block commands a controlled motion of a specified distance relative to the actual position at the time of the execution.

Function Block Diagram



<MOVINC> Function Block Operation Notes

- MOVINC must be in H drawing, and to be executed after execution of SVON and CHANGE DYNAMICS function.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read.
- The *RUNNING* output bit will be held high until: move is completed, *EXECUTE* goes low, or an *Error* occurs
- DONE bit turns on when positioning is completed (IB**0C1=ON). When distributing target position and the current position is within the range of the positioning complete (target position \pm positioning completed width), the positioning completed becomes High.
- If another block takes control of the axis while the block is running a command error will occur. The *ERROR* output will go on, but the RDA will not indicate an error.
- The S-curve, Acceleration, Deceleration and the Speed will be set based on the values in the RDA, set by Change Dynamics Block.
- Eight words are used as working registers for this function, starting at the address in *Data08W*.

<MOVINC> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------|------|---|
| RUNNING | Bit | High while block has control and move is in progress.. |
| DONE | Bit | Indicates Move Complete. When the servo has reached target position within “In-position” window ON (IB**0C1=ON), this output bit turns. |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). |
| DISTGONE | Long | Distance in counts block has traveled in this move, while this block has control. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range and state |
|----------|---------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block. | 1~16 |
| DISTANCE | Long | Relative distance to travel in counts to complete move. | -2147483648~2147483647 |
| DATA08W | Address | Address of the first working register. | Eight words of register space are used by this function. |

<MOVINC> Block error condition:

The following tables might cause the error, and outline some situations. If the EXECUTE input bit is turned off, the value is cleared.

| Internal error bit | Cause | Attention |
|------------------------|--|--|
| errStop AB00000D | Motion commanded and servo is faulted | If block is running and the servo is faulted the error bit will be set. Sets RDA Error ID (MW3**81) bit B on if error state exists. |
| axisInErr AB000002 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID. |
| Commanderr AB00000E | Another block took control of the axis | If the block loses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| Direrror AB00000F | The direction commanded to travel is disabled from the SVON block. | The SVON block must be used and have the direction commanded enabled. Sets RDA Error ID (MW3**81) bit 4 on if error state exists. |

<MOVINC> Working Register

This table outlines the data of the register of eight that the function block use is done. The user is, and there is not a necessity and either is usually no what directly accessed any of these bits.

| Register No | TYPE | Name | Content |
|----------------|---------|---------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | onepass | One shot on rising edge of EXECUTE input to set axis data. |
| Bit 2 | Working | axisInErr | Latches high if Axis input is out of range. |
| Bit 3 | Working | oneshot3 | Reserved |
| Bit 4 | Working | inrngaxis | Goes high for one scan if Axis input is in range. |
| Bit 5 | Working | oneshot5 | Reserved |
| Bit 6 | Working | completeSet | Reserved |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>EEROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot on rising edge of EXECUTE input to initialize axis. |
| Bit C | Working | oneshotC | Reserved |
| Bit D | Working | errStop | Indicates axis faulted and is commanded to move. |
| Bit E | Working | commanderr | Rising Edge indicates another block took control. |
| Bit F | Working | direrror | Indicates direction commanded is not enabled. |
| <i>AW00001</i> | | | |
| Bit 0 | Working | oneshot10 | Reserved |
| Bit 1 | Working | closepath | Internal use for the next execution. |
| Bit 2 | Working | second_Pass | Reserved |
| Bit 6 | Working | position_Mode | Confirmation of positioning mode. |
| Bit 7 | Working | move_Done | Confirmation of positioning completed. |
| Bit D | Working | oneshot1D | Reserved |
| | | | |
| | | | |
| | | | |
| AL00002 | Working | startpos | Position of axis at start of move. |
| AL00004 | Working | distGone | Directly controls YL000001 (<i>DISTGONE</i> Output) |
| AW00006 | Working | rdaMulti | Value for address offset to locate proper RDA |
| AW00007 | Working | revision | Revision Level of the function block. |


MOVE VELOCITY “JOG” function

Function block for MP2000 series

<MOVVEL> Function Block Summary

This function block commands a never ending controlled motion at a specified velocity.

Function Block Diagram



<MOVVEL> Function Block Operation Notes

- MOVVEL must be in H drawing and to be executed after execution of SVON and CHANGE DYNAMICS function.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read once
- If the *EXECUTE* bit goes low the outputs will be set to zero. The block will loose control of the axis and the axis will continue to move at the set speed originally specified by the block.
- Motion is stopped by executing STOP block.
- Seven words are used as working registers for this function, starting at the address in *Data07W*.

<MOVVEL> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | High while block has control and move is in progress. |
| ATVEL | Bit | This bit is ON when the Axis feedback speed is at +/- 1% of the set speed. |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**04). |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|----------|---------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| DIRECTIO | Word | Direction to travel | 1 = Positive direction 2 = Negative direction 3 = Continue in current direction. |
| VELOCITY | Long | Speed in counts per second to travel. | 0 to Max. velocity (MW3**12) in RDA |
| DATA07W | Address | Address of the first working register. | Seven words of register space are used by this function. |

<MOVVEL> Block Fault Condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low

| Internal error bit | Cause | Attention |
|------------------------|---|--|
| inerr AB000004 | DIRECTIO and VELOCITY input are out of range. | Value must be in range or an error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| inspeed AB00000C | VELOCITY input is out of range. | Value must be in range or an error will occur. |
| mover AB00000E | Direction input is set to current direction and axis is not moving. | The axis has to be moving in a direction for this block to work in 'Continue in current direction' mode. This does not set the RDA Error ID. |
| errStop AB000042 | Motion commanded and servo is faulted. | If block is running and the servo is faulted the error bit will be set. Sets RDA Error ID (MW3**81) bit B on if error state exists. |
| axisInErr AB000045 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |
| commanderr AB000041 | Another block took control of the axis | If the block loses control of the axis while running an error will occur. This does not set the RDA Error ID. |
| direrror AB00000F | The direction commanded to travel is disabled from the SVON block. | The SVON block must be used and have the direction commanded enabled. Sets RDA Error ID (MW3**81) bit 4 on if error state exists. |

<MOVVEL> Working Registers

This table outlines the data in the eight registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | Working | positive | Positive direction mode is selected |
| Bit 2 | Working | negative | Negative direction mode is selected |
| Bit 3 | Working | inrng2 | Verifies <i>DIRECTIO</i> input is in range. |
| Bit 4 | Working | inerr | Goes High if inrng2 does not go high when block is executed. |
| Bit 5 | Working | currnet | Current direction mode is selected |
| Bit 6 | Working | movepos | If current direction mode is selected and axis is moving in a positive direction. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | | | Reserve. |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing axis. Goes High with rising edge of <i>EXECUTE</i> input. |
| Bit C | Working | inspeed | Velocity selected is out of range. |
| Bit D | | | Reserved |
| Bit E | Working | moverr | Latches on when current direction is called for and axis is not moving |
| Bit F | Working | direrror | SVON block did not allow this direction for the move |
| AL00002 | Working | | Speed set to RDA and controller. |
| <i>AW00004</i> | | | |
| Bit 0 | Working | oneshot10 | Reserved |
| Bit 1 | Working | commanderr | Rising Edge indicates another block took control. |
| Bit 2 | Working | errStop | Goes high if servo faults out while running |
| Bit 3 | Working | onepass | One shot coil for initiating axis data |
| Bit 4 | Working | inRngAxis | Goes high for one scan if Axis input is in range. |
| Bit 5 | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| Bit 6 | Working | oneshot46 | Reserved. |
| Bit 7 | Working | closepass | Internal use for the next execution. |
| Bit 8 | Working | atSpd | Directly controls YB000001(<i>ATVEL</i> Output) |
| Bit A | Working | oneshot4A | Reserved. |
| Bit D | Working | oneshot4D | Reserved. |
| AW00005 | Working | rdaMulti | Value for address offset to locate proper RDA |
| AW00006 | Working | revision | Revision Level of the function block. |


SLAVE OFFSET function

Function block for MP2000 series

<SLAVEOFF> Function Block Summary

The Slave Offset (SLAVEOFF) block is used to shift the slave axis while gearing or camming. The rising edge of the *EXECUTE* input bit will cause the *OFFSET* value to be added to the RDA offset at the rate determined by the *DURATION* input. *DST-TIME* input bit determines whether the shift duration is base upon distance the master travels or based on time in milliseconds.

Function Block Diagram



<SLAVEOFF> Function Block Operation Notes

- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, the block will stop executing (will not complete the change), the offset up to that point will remain, and all outputs will be set to zero.
- The RUNNING output bit will be held high until the Offset move is completed, EXECUTE goes low, or an Error occurs.
- The DST-TIME bit must be set to TRUE to use the master position change or FALSE for the time duration.
- Distance mode note: Be sure to set the duration in the same direction as the master movement. Example: If the block is in Distance mode and the master is moving in the negative direction, and the DURATION is set positive, it will subtract the relative offset and hence the resulting offset will not complete. As a result, the DONE output will not go on because the full move is not complete in the correct direction.
- The value <'of block in execution (Block Running)> is indicated in master/slave pair part RDA(MW56**6).
- Issuing a STOP block on the slave axis will have no affect on the OFFSET block execution.
- Note that the master/slave pairs are separated by 50 words in the RDA (up to 10 pairs). Example: Master/Slave pair #1 starts at MW56000, Master/Slave pair #2 starts at MW56050, Master/Slave pair #3 starts at MW56100, etc.
- Twenty-three words are used as working registers for this function, starting at the address in Data23W.

<SLAVEOFF> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | Goes high while offset value is being updated in RDA and there are no errors |
| DONE | Bit | Goes high when offset change is complete in RDA |
| ERROR | Bit | Goes high if any block errors occur |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| INPUT | TYPE | Content | Range of setting and state |
|----------|----------------|---|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| DST-TIME | Bit | Selects master position [count] or time [ms] for offset duration. | TRUE – Master position is used for duration FALSE – Time is used for duration |
| M-S-PAIR | Word | Defines which Master-Slave pair is updated in RDA | 1 to 10 value. Any other value will cause the error output to go on |
| DURATION | Long | Depends on DST-TIME setting. Either time or distance master must travel to complete change in offset. | Distance: 2147483648~2147483647 [count] Time: 0-2147483647 [ms] |
| OFFSET | Long | Total value offset in RDA will change. | -2147483648~2147483647 |
| DATA23W | Address | Address of the first working register. | Twenty-three words of register space are used by this function. |

<SLAVEOFF> Block Fault Condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal Fault Bit | Cause | Note |
|--------------------|----------------------------|--|
| inrng1 AB00000E | MSTRSLV value out of range | Inrng1 must be high if execute is on or an error will occur. MSTRSLV must have a value from one to ten for this bit to be on. Sets RDA Error ID (MW30181) bit 3. |

<SLAVEOFF> Working Register

This table outlines the data in the eight registers used by the Home function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|-----------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | distmode | <i>DST-TIME</i> input (XB000001) |
| Bit 3 | Working | zerodiv | If duration is set to zero for one scan change, this turns on for one scan (one-shot) |
| Bit 6 | Working | distShft_init | High for one scan to initialize for master position shifting if first pass is high and DISTMODE is high. To initialize for master position control of offset. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | complete | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | High for first scan of execute being high |
| Bit D | Working | timeshft_init | One shot coil for resetting outputs. Controlled by (AB00000A) |
| Bit E | Working | inrng1 | High for one scan to initialize for time based shifting if first pass is high and DISTMODE is low. |
| AW00001 | Working | scans_per_shift | Number of scans needed to complete a time based shift. |
| AW00002 | Working | iStore | Pass through value for i. |
| AW00003 | Working | mstrSlv | MSTSLAVE input (XW000001) – 1. |
| AL00004 | Working | maxShift_scan | Maximum counts allowed to shift per scan on a time based scan. |
| AL00006 | Working | posLAUlim | Positive value of maxShift_scan |
| AL00008 | Working | negLAUlim | Negative value of maxShift_scan |
| AL00010 | Working | total_Shifted | Amount Slave Offset has changed during the execution of the block. |
| AL00012 | Working | shiftvalue | Value to change the RDA (ML56**6) Slave offset for that scan. |
| AL00014 | Working | startmaster | Value of Master counter at start of block (AB0006=ON) for position based move. |
| AL00018 | Working | desired_shift | Total amount needed to be shifted for the master position mode. |
| AL00020 | Working | timemod | Reserved. |
| AW00022 | Working | Revision | Revision Level of the function block. |


STOP function

Function block for MP2000 series

<STOP> Function Block Summary

This function block commands a controlled motion stop and transfers the axis to the state “Stopping”. It aborts any ongoing function block execution. With the DONE output set, the state is transferred to the Stand Still. While the axis is in state Stopping, no other FB can perform any motion on the same axis.

Function Block Diagram



<STOP> Function Block Operation Notes

- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- To use the function block, the EXECUTE bit must be held ON. If the EXECUTE bit goes off during operation, all outputs will go low but the block will still stop the axis and prevent any other motion block from executing until axis has stopped.
- The stop block will force the axis operation mode to Speed mode (OW**08=7) and decelerate to zero velocity at a rate defined by the RDA Set Deceleration value (ML3**24)
- No other motion blocks can take control while this block is under execution or EXECUTE input remains high.
- Nine words are used as working registers for this function, starting at the address in Data09W.

<STOP> Input and Output Register Map

Output Registers

| Output | Type | Description |
|---------|------|---|
| RUNNING | Bit | High while block has control and move is in progress. |
| DONE | Bit | Goes high when the axis comes to a full stop. IE. actual speed feedback in RDA is zero (ML3**16=0), and motion command mode feedback indicates zero (IW3**16=0) When the axis stops completely, |
| ERROR | Bit | Latches high if any error occurs in block (see table below) or on the servo axis (see IL**02 and IL**04). This is Reset if EXECUTE bit goes low. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|---------|---------|--|--|
| Execute | Bit | Block enable | Rising edge executes block TRUE – nothing else can take control of the axis FALSE & Block Done - Block disabled, all outputs set to zero |
| AXIS | Word | Axis number related to the block. | 1~16 |
| DECEL | Long | Deceleration during stop in counts per second squared. | 1 to Max. Deceleration in RDA, (ML3**28). |
| DATA09W | Address | Address of the first working register. | Nine words of register space are used by this function. |

<STOP> Block Fault Condition

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW3**81) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 200 for each axis. Example: Axis#1 stores to MW30181, Axis #2 stores to MW30281, etc.

| Internal error bit | Cause | Attention |
|-----------------------|---|--|
| axisinerr AB00000F | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |

<STOP> Working Registers

This table outlines the data in the seven registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|--------------|---|
| <i>AW00000</i> | | | |
| Bit0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit1 | Working | InRangeAxis | The set Axis number is within 1 through 16. |
| Bit2 | OUT | Running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit3 | OUT | done. | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit4 | IN | Interruption | If aborting from Discrete motion (RDA axis state MW3**49 was 4), this bit goes on |
| Bit5 | Working | inrng | The set deceleration rate is in normal range. |
| Bit6 | Working | Oneshot06 | Reserved |
| Bit7 | Working | closePass | One scan ON at Execute input transition On to Off. |
| Bit8 | Working | Execute2 | On while Execution is demanded. |
| BitA | Working | oneshotA | Reserved |
| BitB | Working | firstPass | One shot coil to initialize axis and block. |
| BitC | Working | oneshot | Reserved |
| BitF | Working | axisInErr | Goes high if Axis input is out of range. |
| <i>AW00001</i> | Working | Filter | Reserved |
| Bit3 | Out | Complete | On when Stopping is completed |
| AF00002 | Working | speedMEMO | Speed Memory at Stopping starts[count/sec] |
| AW00004 | Working | rdaMult | Value for address offset to locate proper RDA |
| AL00006 | IN | DECEL | Set Deceleration (XL0002) |
| AW00008 | Work | revision | |


SERVO ENABLE POWER function

Function block for MP2000 series

<SVON> Function Block Summary

This function block controls the power stage (on or off) of the axis as well as monitoring and updating the RDA with Actual Position, Actual Velocity, Actual acceleration, Actual deceleration and Actual S-curve. This block is essential if any of the Blocks that control motion to be used. This block also enables the user to limit the direction the axis can go..

Function Block Diagram



<SVON> Function Block Operation Notes

- This block must be used in the High Speed Scan drawings, and should be the first block executed before any other motion function blocks.
- Interlock parameters used inside SVON block, the servo will not enable until all of the following conditions are clear:
 - SVCRDY (IB**000): Motion Controller SVB/SVA Module Run Ready. This is high when the run preparation for motion module have been completed. This is low when major fault occurred, axis set to not used, motion fixed parameter setting error or has changed, in asynchronous communication state and MPE720 are accessing the servo amplifier parameter and the motion parameter screen is opened by MPE720.
 - ALM (IB**2C0): Servo Axis alarm bit (high state indicates alarm occurred)
 - PON (IB**2C4): Servo amplifier main power ON. This is high when the main circuit power of the servo amplifier is on.
 - HS-1SEC (SB000018): H-Scan delay-on service register (off for one second after first H-Scan executes when control power is applied. After one second it is always on).
- Upon Rising edge of ENABLE, the following two events will occur. ENABLE input must remain high to maintain servo enable.

- Servo will enable only if axis is normal (SVCRDY=high, ALM=low, PON=high), and HS-1SEC=high.
- The S-Curve filter type will be set to moving average.
- If the *ENABLE* input goes off during operation, the servo will be disabled but its position in the RDA will continue to update. Note that all outputs will be off or zero.
- If a servo fault occurs and the servo is enabled the ERROR output will go high.
- Positive and Negative direction operation enable inputs (POSENABL and NEGENABL) inputs are constantly monitored when the ENABLE input is ON, and sets the RDA (MB003**770 servo on, MB03**771 pos enable, MB3**772 neg enable). Each motion block will then monitor the RDA status bits to insure proper direction operation.
- All of the motion function blocks rely on data computed in this block (Actual Position, Actual Velocity, Actual acceleration, Actual deceleration, Actual S-curve, updates latched position, handles rotary mode positioning, monitors over-travel status). Data computed in this block is stored to the RDA.
- Input feedback from specific axis registers are read into the RDA from this function block. Example – for axis #1 the following is read and written to RDA:
 - IW8000 run status (motion controller operation ready, servo enabling, system busy, servo ready)
 - IW800C position management status (position compete, latch complete, home complete).
 - IW802C network servo status (servo alarm, servo enabled, main power on, pos complete, latch complete, speed lim, etc)
 - IL8010 target position (CPOS)
 - IL8018 latch position (LPOS)
 - IL8016 motor actual feedback position (APOS)
 - IW8009 motion command status (command executing, holding, error, reset abs enc done).
 - IW8008 motion command code response
 - IL8004 alarm (servo err, POT, NOT, soft POT, soft NOT, excessive spd or following error or timeout, homing error, servo comm. err, servo mismatch)
 - IL8002 Warnings (parameter setting warning, following error warning, comm. warning, POT/NOT warnings, servo enable warning)
 - IW802D servo alarm code
 - IW802E servo DI monitor (CN1 input signal status level)
 - IL8020 speed reference
 - IL8040 feedback speed

For more information on these registers, see MP2300/2200 Motion Module Users Manual SIEPC88070016A, section 4.3.3 (Motion Monitoring Parameter Details).

See below for a table of RDA values:

Table: Axis #1 RDA values from SVON Axis Mapping

| | | |
|--------------------|---------|----------------------------------|
| Run Status-1 | MW30200 | IW8000 - Run Status |
| Run Status-2 | MW30201 | IW800C - Position Status |
| Servo Status | MW30202 | IW802C - Servo Status |
| | MW30203 | - |
| Target Position | ML30204 | IL8010 - Target Position |
| Latched Position | ML30206 | IL8018 - Latched Position |
| Actual Position | ML30208 | IL8016 - Actual Position |
| Command Status | MW30210 | IW8009 - Motion Command Status |
| Command Response | MW30211 | IW8008 - Motion Command Response |
| Alarms | ML30212 | IL8004 - Alarm |
| Warning | ML30214 | IL8002 - Warning |
| Servo Alarm Code | MW30216 | IW802D - Servo Alarm Code |
| Servo DI Monitor | MW30217 | IW802E - Servo DI Monitor |
| Speed Ref. Monitor | ML30218 | IL8020 - Speed Reference Monitor |
| Feedback Speed | ML30220 | IL8040 - Feedback Speed Monitor |

- If the servo is disabled while motion is in progress (OW**08<>0), the servo axis will generate an error (IB**2C0), and an error bit will be set in the RDA (MB3**81D). A SVON block fault will not occur until the next enable attempt. To correct this, clear the alarm using the alarm reset function block, BALRMRST.
- The AXISEND block MUST be used in conjunction with this function block.
- Forty-six words are used as working registers for this function, starting at the address in *Data46W*.

<SVON> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| OUTPUT | TYPE | Content |
|--------|------|--|
| STATUS | Bit | This bit is ON when the servo is enabled (Axis normal, Servo is enabled, S-curve filter is set) |
| ERROR | Bit | If an error occurs during block execution (see table below) or on the servo axis (see IL **04), this output bit turns ON, but will reset if error condition goes away. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| INPUT | TYPE | Content | Range of setting and state |
|----------|-------------|---|--|
| ENABLE | Bit | Servo enable – This will control the servo enable | Rising Edge – enables servo (see operation notes for conditions) TRUE – Hold Servo enable FALSE – Servo disable |
| POSENABL | Bit | Enable Axis in the positive direction. This input is always active. | TRUE – Axis can be commanded in the positive direction FALSE – Axis can <i>not</i> be commanded in the positive direction |
| NEGENABL | Bit | Enable Axis in the negative direction. This input is always active. | TRUE – Axis can be commanded in the negative direction FALSE – Axis can <i>not</i> be commanded in the negative direction |
| AXIS | Word | Axis number related to the block | 1to 16 |

<SVON> Block Fault Conditions:

The following table outlines several situations that may cause an error. The block error can be cleared by the *ENABLE* bit going low.

| Internal error bit | Cause | Attention |
|--|---|--|
| rdaError AB000004 | The RDA is not properly set up. | If Motor Rated Speed (MW3**73) or Encoder resolution (ML3**74) is not appropriately set up in the RDA, an error will occur. Sets bit A of RDA Error ID (MW3**81) if error state exists. |
| axisinerr AB000028 | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID. |
| RDA_Error AB000026 | The module or axis number in the RDA is not acceptable | RDA module number MW3**83 refers to the address of Module on the rack, and can be from 1 to 16. The axis number MW3**84 refers to the axis location on the module and can be from 1-16. This typically would occur if an RDAINIT function block is not used for that axis. |
| Servo_Alarm/POWER_OFF IB**2C0/IB**2C4 | Servo Alarm | Servo amplifier fault occurred or main power lost. Sets RDA Error ID (MW3**81) bit 6 on if no motor power, and bit 7 if there is a servo alarm. |

<SVON> Working Register

This table outlines the data in the forty-five registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|------------------|-----------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN _s | Enable | <i>ENABLE</i> input (XB000000) |
| Bit 1 | IN _s | posEnable | <i>POSENABL</i> input (XB000001) |
| Bit 2 | IN _s | negEnable | <i>NEGENABL</i> input (XB000002) |
| Bit 3 | IN _s | Normal | Servo has main power (IB**2C4), no servo alarm (IB**2C0), and motion controller is ready (IB**000) |
| Bit 4 | IN _s | rdaError | Goes high if the RDA registers are not set properly |
| Bit 5 | | Moving | High when motion is commanded |
| Bit 6 | OUT _s | rotary | Goes high if RDA calls for Rotary mode |
| Bit 7 | OUT _s | State | Directly controls YB000000 (<i>STATUS</i> Output). Must be normal (AB000003), Servo on must be true (IB**002), and filter set must be on (AB00002C). |
| Bit 9 | OUT _s | Mistake | Directly controls YB000001 (<i>ERROR</i> Output) |
| Bit A | Working | osEnable | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing Axis and block on for the rising edge of enable input |
| Bit C | Working | osDisable | Reserved |
| AW00001 | Working | Filter | Rreserved. |
| <i>AW00002</i> | | | |

TECHNICAL NOTE



| | | | |
|---------|---------|------------------|--|
| Bit 0 | Working | latchedfirst | High when Latch is detected |
| Bit 1 | Working | rdaSpdErr | RDA error. Motor rated speed is set to zero |
| Bit 2 | Working | rdaResErr | RDA error. Encoder resolution is set to zero |
| Bit 3 | Working | inrngAxis | Goes high for one scan if Axis input is in range. |
| Bit 4 | Working | rdaMODok | Goes high for one scan if RDA Module value is in range. |
| Bit 5 | Working | rdaAXISok | Goes high for one scan if RDA Axis value is in range. |
| Bit 6 | Working | rdaAxisErr | Goes High if RDA module or axis number is not in range. |
| Bit 7 | Working | delaypulse | Goes high for one scan one second after first high scan. |
| Bit 8 | Working | axisinerr | Goes high for one scan if Axis input is out of range. |
| Bit 9 | Working | offSwch | Goes high for one scan after execute bit goes low or the servo faults out. |
| Bit A | Working | oneshot38a | Reserved |
| Bit B | Working | Oneshot2b | Reserved |
| AL00003 | Working | posLast | Axis position on last scan. |
| AL00005 | Working | cntPPulse | Counts moved each scan. |
| AL00007 | Working | scancomp | Adjusted value due to scan time delay. |
| AL00009 | Working | IScratch | Reserved |
| AL00011 | Working | oldTarget | Commanded position Last scan (ILC**10) |
| AL00013 | Working | targetChange | Change in target position between scans |
| AL00015 | Working | oldChange | Change in target position last scan |
| AL00017 | Working | Speed | Actual velocity stored to RDA ML3**16 in Counts per sec. |
| AW00019 | Working | Reservation. | Reserved |
| AF00020 | Working | temp1 | Reserved |
| AF00022 | Working | scanTime | Scan time in milliseconds |
| AL00024 | Working | o mpos_o | Reserved |
| AL00026 | Working | oldCommand | Commanded position previous scan |
| AL00028 | Working | deltaCommand | Change from previous scan |
| AL00030 | Working | o mpos_Commanded | Reserved |
| AL00032 | Working | mPosCommanded | Actual Set position stored in RDA ML3**08 |
| AL00034 | Working | latchpos | Latched position value converted for rotary mode and stored in RDA ML3**46 |
| AL00036 | Working | velChange | Change in velocity from the previous scan |
| AL00038 | Working | oldVelocity | Velocity at previous scan |
| AL00040 | Working | accel | Actual acceleration or deceleration stored to RDA |
| AW00042 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00043 | Working | axisMult | Value for address offset to locate proper Axis |

TECHNICAL NOTE



| | | | |
|---------|---------|----------|---------------------------------------|
| AW00044 | Working | Timer | Timer for error detection of servo on |
| AW00045 | Working | Revision | Revision Level of the function block. |

TUNING function

Function block for MP2000 series

<TUNING> Function Block Summary

This function block sets the speed feed forward, speed loop gain, position loop gain, speed loop integral time constant and the position loop integral time constant in the motion setup parameter and the servo amplifier user constant.

Function Block Diagram



<TUNING> Function Block Operation Notes

- This function can be executed while in motion by another function block. But it is possible that the motor occasionally does unexpected operation by changing the parameter. So it is recommended to execute this block while the motor is stopped.
- To use the function block, the *EXECUTE* bit must be high. If the *EXECUTE* bit goes low the outputs will be set to zero.
- If any of the input values are out of range, an error will occur.
- When the EXECUTE input becomes High, the speed feed forward, speed loop gain, position loop gain, speed loop integral time constant, and position loop integral time constant can be set in the motion set parameter and the servo amplifier user constant.
- RDA will be set after each value (FEEDFWD, SPDLOOP, POSLOOP) is set in the servo amplifier.

- Six words are used as working registers for this function, starting at the address in *Data06W*.

<TUNING>Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|---|
| RUNNING | Bit | This bit is ON when the function block is executing. |
| DONE | Bit | This bit is ON when the function block is complete and there are no errors |
| ERROR | Bit | This bit is ON when one of the values is out of range. However, if the error condition is cleared, this output is reset to OFF. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| INPUT | TYPE | Content | Range of setting and state |
|---------|---------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| FEEDFWD | Word | Speed Feed forward | 0~100[%] Set parameter OWxx30 |
| SPDLOOP | Word | Speed loop gain | 1~2000[Hz] Set parameter OWxx2F |
| POSLOOP | Word | Position loop gain | 10~20000[0.1/s] Set parameter OWxx2E |
| SPD-TI | Word | Speed loop integral time constant | 15~32767[0.01ms] Set parameter OWxx34 |
| POS-TI | Word | Position loop integral time constant | 0~5000[ms] Set parameter OWxx32 |
| DATA06W | Address | Address of the first working register. | Six words of register space are used by this function. |

<TUNING> Block Fault Condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Internal Fault Bit | Cause | Note |
|------------------------|--|--|
| feedfwdOut AB000001 | Feed forward value is not within acceptable range. | Goes high if the set value is in range. Sets bit3 of RDA Error ID(MW3**81) if error occurs. |
| spdLoopOut AB000002 | Speed loop gain value is not within acceptable range. | Goes high if the set value is in range. Sets bit3 of RDA Error ID(MW3**81) if error occurs |
| posLoopOut AB000003 | Position loop gain value is not within acceptable range. | Goes high if the set value is in range. Sets bit3 of RDA Error ID(MW3**81) if error occurs. |
| SPDTiout AB000019 | Speed loop integration time value is not within acceptable range. | Goes high if the set value is in range. Sets bit3 of RDA Error ID(MW3**81) if error occurs |
| PosTiOut AB00001A | Position loop integration time value is not within acceptable range. | Goes high if the set value is in range. Sets bit3 of RDA Error ID(MW3**81) if error occurs |
| axisInErr AB00014A | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. his does not set the RDA Error ID. |
| RDA_Error AB000006 | The module or axis number in the RDA is not acceptable. | Goes high if the Motor Rated Speed (MW3**73) or Encoder resolution (ML3**74) is not appropriately set up in RDA. Sets bit A of RDA Error ID(MW3**81) if error occurs.. |

<TUNING> Working Registers

This table outlines the data in the six registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|----------------|---------|------------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | EXECUTE input (XB000000) |
| Bit 1 | Working | feedfwdOut | Goes high for one scan if FEEDFWD input is out of range. |
| Bit 2 | Working | spdLoopOut | Goes high for one scan if SPDLOOP input is out of range. |
| Bit 3 | Working | posLoopOut | Goes high for one scan if POSLOOP input is out of range. |
| Bit 5 | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| Bit 6 | Working | RDA_Error | Goes High if RDA module or axis number is not in range. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | osExecute | Reserved |
| Bit B | Working | firstPass | One shot coil for initializing block on the rising edge of the EXECUTE input. |
| <i>AW00001</i> | | | |
| Bit 9 | Working | SPDTiout | Goes high for one scan if SPD-TI input is out of range. |
| Bit A | Working | PosTiOut | Goes high for one scan if POS-TI input is out of range. |
| Bit C | Working | oneshot1c | Reserved |
| Bit D | Working | Done_latch | Directly controls YB000001 (<i>DONE</i> Output) |
| AW00003 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00004 | Working | axisMult | Value for address offset to locate proper Axis |
| AW00005 | Working | revision | Revision level of block. |


ABSOLUTE ENCODER RESET Function Block

Function block for MP2000 Series SVB Module

<AENC_RST> Function Block Summary

This function block commands a clear of an Absolute encoder's multi-turn counter and (if required) will clear a A.81 (Absolute backup loss) alarm.

Function Block Diagram



<AENC_RST> Function Block Operation Notes

- This is valid for MP2x00 SVB module
- Rising edge of EXECUTE input initiates block operation, and all block input values are read.
- To use the function block, the *EXECUTE* input must be held ON at least until the *DONE* output bit turns ON or the *ERROR* output bit turns ON.
- The *RUNNING* output bit will be held high until: the entire operation is complete. This means the *RUNNING* output bit will turn OFF when *DONE* is ON, *EXECUTE* becomes low, or an *ERROR* occurs.
- *DONE* bit turns ON when the Absolute encoder position reset is complete. This happens when the MP2x00 controller confirms the ABS_RST (Motion Command Code #22) followed by an alarm reset.
 - For a SIGMA 2 Servopack (SGDH-□ □ □ E) with NS100 or NS115 option card, Servopack control power and MP2x00 power must be cycled.
 - For a Sigma 3 Mechatrolink II Servopack (SGDS-□ □ □ 1 A) no power cycle, on any device, is required.
- The function block operation can only happen with the Servo Off and after all motion has stopped. If another block has control of the axis or a move is not finished, and the *EXECUTE* was turned ON, the *ERROR* output will go ON. The when the *ERROR* output is on, the RDA will not indicate an error.

- If EXECUTE has been turned ON, But the Absolute encoder rest operation does not complete within 5 seconds, ERROR output bit will turn ON. For the time between the EXECUTE ON and the ERROR output bit turns ON, the RUNNING output bit will be ON
- Five words are used as working registers for this function, starting at the address in *Data05W*

<AENC_RST> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------------|------|---|
| <i>RUNNING</i> | Bit | High while block has control and Absolute Encoder Reset Procedure is in process |
| <i>DONE</i> | Bit | Indicates the Absolute Encoder Reset Procedure has completed successfully |
| <i>ERROR</i> | Bit | Latches high if any error occurs in block. |

Input Registers

The following registers are used as inputs to the function block. They select the options and

| Input | Type | Description | Range and state |
|----------------|-----------|--|--|
| <i>EXECUTE</i> | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| <i>AXIS</i> | Word | Axis number related to the block. | 1 to 16 |
| <i>DATA05W</i> | Addresses | Address of the first working register. | Five (5) words of register space are used by this function. |
| | | | |

<AENC_RST> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW***81) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 300 for each axis. Example: Axis#1 stores to MW30181, Axis #2 stores to MW30481, etc.

| Internal Fault Bit | Cause | Note |
|-----------------------------|---|--|
| TimeOut_Error AB000010 | Absolute encoder rest operation does not complete within 5 seconds | It is possible there is no absolute encoder. It is a Sigma I (SGD-xxxN or SGDB-xxxN) Mechatrolink I system, and the operation can not be done. The operation already occurred and can not happen a second time, with out a power cycle (Sigma II) or some motion (SigmaIII) |
| RDA_Range_Error AB000012 | Axis number is out of range. | |
| CmdCode_Error AB000014 | Motion Command Code (MCC) was other than Zero (NOP) when EXECUTE transitioned from OFF -> ON. | This is determined by monitoring the Motion Command Code response register (IWxx08) for Zero. |
| Svon_Error AB000015 | If was ON when EXECUTE transitioned from OFF -> ON. | This side effect of this operation is loss of Mechatrolink II synchronization. Synchronization is reestablished by the function block after it commands an Alarm Reset. If Servo was ON, it would be turned OFF as due to the loss of synchronization. It is better that the Servo is off before the operation begins. |

<AENC_RST> Working Registers


This table outlines the data in the five registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|-------------------|--|
| <i>AW00000</i> | | WORKING_REG0 | |
| Bit 0 | IN | EXECUTE_TRUE | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | IN | EXECUTE_1stPASS | One shot on <u>rising</u> edge of Execute input to set axis data. |
| Bit 2 | Working | Operate | Start operation |
| Bit 3 | Working | EXECUTE_TRANS_OFF | One shot on <u>falling</u> edge of Execute input to set axis data. |
| Bit 4 | Working | InRDA_Range | Goes high for one scan if “AXIS” input is in range. |
| Bit 5 | Working | MCC_RESP_ABS_RST | Goes High when Motion Command Code (MCC) Response Register (IWxx08) is equal to 22, “ABS_RST” operation has happened |
| Bit 6 | Working | Send_ABS_RST_MCC | Goes High when it is time to send MCC 22 “ABS_RST” |
| Bit 7 | Working | MCC_RESPONCE_NOP | Goes High when Motion Command Code (MCC) Response Register (IWxx08) is equal to 0, “NOP” (No Operation) is true |

| | | | |
|----------------|---------|-------------------|--|
| Bit 8 | Working | START_STEP2 | Goes High at the start of Step 2. Step1 and Step2 operation are different if A81 alarm exist or not. |
| Bit 9 | Working | OneShotAB09 | Reserved |
| Bit A | Working | Running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit B | Working | Step2_Complete | Goes High at the end of Step 2. Step1 and Step2 operation are different if A81 alarm exist or not. |
| Bit C | Working | OneShotAB0C | Reserved |
| Bit D | Working | OneShotAB0D | Reserved |
| Bit E | Working | NWORK_SVPACK_ALM | Goes ON if any Network Servopack alarms exist. |
| Bit F | Working | ABS_ENCODER_A81 | Goes ON if Network Servo alarm is an A.81 – Absolute Encoder Backup Alarm. |
| AW00001 | | WORKING_REG1 | |
| Bit 0 | Working | TimeOut_Error | Goes high for second scan of Block only. |
| Bit 1 | Working | OneShotAB11 | Reserved |
| Bit 2 | Working | RDA_Range_Error | Goes ON If RDA is out of range |
| Bit 3 | Working | ALARM_CLR_STEP3 | Issue of step 3: and Alarm clear |
| Bit 4 | Working | CmdCode_Error | On first pass, MCC was other than Zero |
| Bit 5 | Working | Svon_Error | On first pass, Servo was ON (enabled) |
| Bit 6 | - | Unused | |
| Bit 7 | _ | Unused | |
| Bit 8 | OUT | Op_Error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit 9 | | OneShotAB19 | Reserved |
| Bit A | OUT | Op_Done | Directly controls YB000001 (<i>DONE</i> Output) |
| Bit B | | OneShotAB1B | Reserved |
| Bit C | Working | Op_DoneOneShot | Operation Done Flag |
| Bit D | _ | Unused | |
| Bit E | Working | Step1 | Step one has started and in operation |
| Bit F | Working | Step1_Complete | Step one as completed |
| AW00002 | Working | OFFSET_STORAGE | Value for address offset to locate proper RDA |
| AW00003 | Working | DRIVE_STAUS_LOCAL | State of Network Servo Axis (bit by bit) from RDA ¹ |
| Bit 1 | Working | Svon_FB | Axis Servo ON (enabled) |
| AW00004 | Working | Revision | Revision Level of the function block. |

¹ This register (AW00003) holds the entire bit by bit value of motion Monitor Parameter IWxx01. Only one bit is used in this function block: Servo ON (Enabled), bit 1.

<AENC_RST> Flow Chart




ALARM RESET Function Block

Function block for MP2000 series

<ALMRST> Function Block Summary

The “ALMRST” block is used to reset any servo alarm as well as RDA errors in MW3**81 and MW3**82. Not all errors can be cleared from the reset clock. Some errors will require cycling the power.

Function block diagram



<ALMRST> Function block Operation Notes

- To use the function block, the *EXECUTE* input must see a rising edge. The reset bit (ACR) will go on as long as the *EXECUTE* input is on.
- Related Function Blocks: Errors that can be reset with this block can be detected by Read Error Function Block (RDERROR).
- Alarm Indication and Reset Registers Used:
 - ACR (OBxx00F): Alarm Clear, used to clear alarms in system
 - Warning (Ilsx02): Warning information on the axis displayed in the bit.
 - Alarm (Ilsx04): Alarm information on the axis displayed in the bit.
 - Servo driver alarm (IBxx2C0): Servo driver alarm
 - Servo alarm code (IWxx2D): Refer to the manual of the servo amplifier for details of the servo amplifier alarm code.
 - CPU error (SW00041): CPU Error Status System Register. This is not used for the detection purpose, but can be used to help the user determine more information about the alarm. This register indicates bitwise: Serious failure, Program memory error, User operation error, I/O error, and Transmission errors. Refer to Chapter 10 of the user's manual (Trouble shoot) for details.
- The servo alarm: This block will set ACR to initiate alarm clear. The ACR bit is reset request of the alarm to the controller. If the alarm is not cleared within 500msec, the block will error out and the *ERROR* output will turn on. If the alarm is cleared, the *DONE* output will be latched on.
- RDA alarms: : This block will set MW3xx81(ERRID1) and MW3xx82(ERRID2) both to zero.

- This block will also set SW00041=0 (CPU error status system register). Note that this register is not used to trigger any alarms. It is only reset.
- Four words are used as working registers for this function, starting at the address in *Data04W*.

<ALRMRST> Input and Output Register Map

Output Registers

The following registers are used from the function block as an output. To check the execution of the function, they can be monitored by the MPE720 program.

| Output | Type | Description |
|--------|------|---|
| DONE | Bit | This bit is ON when the function block is Complete in resetting axis. |
| ERROR | Bit | Latches high if any block errors occur |

Input Registers

The registers are used as inputs to the function block.

| Input | Type | Description | Range and state |
|---------|-----------|---|--|
| EXECUTE | Bit | Block executes reset when rising edge occurs. As long as execute input is on, then OB**00F is on. | RISING EDGE – Block executes TRUE – OB**00F is on FALLING EDGE – Reset input (OB**00F) gets set back to zero. |
| AXIS | Word | Axis number related to the block | 1~31 |
| DATA04W | Addresses | Address of the first working register. | Four words of register space are used by this function. |

<ALMRST> Block Error Condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit.

| Internal Fault Bit | Cause | Note |
|----------------------|---|---|
| axisout AB00000C | Axis specified by user is out of range | Valid range is 1 to 16. Will not write to RDA |
| Time-out AB00000D | Alarm condition did not clear within default timeout (500msec). | Alarm condition may still exist. Will not write to RDA. May need to cycle power on controller and servopacks to clear the error, set-up parameter may be out of range, or hardware failure may exist. |

<ALMRST> Working Registers

This table outlines the data in the four registers used by the Alarm Reset function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Description |
|----------------|---------|-----------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | EXECUTE | EXECUTE input (XB000000) |
| Bit 8 | OUT | DONE | DONE output (YB000000) |
| Bit 9 | OUT | ERROR | ERROR output (YB000001) |
| Bit A | Working | oneshotA | Rising edge |
| Bit B | Working | firstPass | Initialize block |
| Bit C | Working | axisout | Indicates axis input is out of range |
| Bit D | Working | Time-out | Indicates that the alarm did not reset within a specified (500msec default) timeout period. |
| <i>AW00001</i> | Working | Counter | Timer for pausing post reset |
| <i>AW00002</i> | Working | rdaMult | Value for address offset to locate proper RDA |
| <i>AW00003</i> | Working | Revision | Revision level for block |


DEFINE POSITION Function Block

Function Block for MP2000 Series

<DEF_POS> Function Block Summary

This function block adjusts the absolute position offset of the defined axis. It will also handle the position of a rotary load.

Function Block Diagram



<DEF_POS> Function Block Operation Notes

- This is valid for MP2x00 family of products.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read.
- If the ABSENC input is FALSE The Offset register will be cleared every power up, even if EXECUTE input is FALSE.
- To use the function block, the EXECUTE input must be held ON at least until the DONE output bit turns ON or the ERROR output bit turns ON.
- The RUNNING output bit will be held high until: the entire operation is complete. This means the RUNNING output bit will turn OFF when DONE is ON, EXECUTE becomes low, or an ERROR occurs.
- DONE bit turns ON when the new position is set.
- If another block has control of the axis or a move is not finished, and the EXECUTE was turned ON, the ERROR output will go ON. The when the ERROR output is on, the RDA will not indicate an error.
- If EXECUTE has been turned ON, The Axis is defined in the RDA as rotary, and the REQPOSIT is negative or larger than the RDA defined PERIOD, ERROR output bit will turn ON.
- If an Absolute encoder is present then ABSENC input must be ON.

- Ten words are used as working registers for this function, starting at the address in *Data10W*

<DEF_POS> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------------|------|--|
| <i>DONE</i> | Bit | Indicates the Define Position Procedure has completed successfully |
| <i>RUNNING</i> | Bit | Indicates the Define Position Procedure is in process. |
| <i>ERROR</i> | Bit | Latches high if any error occurs in block. |

Input Registers

The following registers are used as inputs to the function block. They select the options and set necessary parameters internally.

| Input | Type | Description | Range and State |
|-----------------|---------|---|--|
| <i>EXECUTE</i> | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| <i>ABENC</i> | Bit | For power up operational purposes the existence of Absolute Encoder on this axis needs to be known. | TRUE – An absolute encoder is mounted on the servomotor for this axis. FALSE – An incremental encoder is mounted on the servomotor for this axis. |
| <i>AXIS</i> | Word | Axis number related to the block. | 1 to 16 |
| <i>REQPOSIT</i> | Long | The Desired Position the Axis is to be set at. | For linear axis, the value can be -2^{31} to $(2^{31}-1)$ For a Rotary Axis the value must be 0 to the PERIOD (ML***06) defined in the RDA |
| <i>DATA10W</i> | Address | Address of the first working register. | Ten (10) words of register space are used by this function. |

<DEF_POS> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low, but the Error ID (MW***81) will remain in the RDA. To reset the Error ID, use the Alarm Reset Function Block.

Note that each axis has its own Error ID stored in its RDA axis section, offset by 300 for each axis. Example: Axis#1 stores to MW30181, Axis #2 stores to MW30481, etc.


| Internal Fault Bit | Cause | Note |
|------------------------------|---|---|
| Rotary_ReqPosOK AB000001 | IF this bit is OFF, when EXECUTE transitioned from OFF -> ON., an error will occur. REQPOSIT is outside range. | See note above for the “REQPOSIT input.) |
| IN_RDA_RANGE AB000007 | IF this bit is OFF, when EXECUTE transitioned from OFF -> ON., an error will occur. Axis number is outside range. | See above note for the “AXIS” input. |
| No_Alarms AB000008 | IF this bit is OFF, when EXECUTE transitioned from OFF -> ON, an error will occur. The axis was in an error or had an Alarm. | This bit Monitors RDA MLxxx12 (ILxx04) |
| No_MCC_Requested AB000009 | IF this bit is OFF, when EXECUTE transitioned from OFF -> ON, an error will occur. Motion Command Code (MCC) <u>in execution</u> was other than Zero (NOP). | This is determined by monitoring the Motion Command Code response register (IWxx08) for Zero. |
| No_MCC_InQue AB00000A | If was OFF when EXECUTE transitioned from OFF -> ON,an error will occur. Motion Command Code (MCC) <u>requested</u> was other than Zero (NOP). | This is determined by monitoring the Motion Command Code request register (OWxx08) for Zero. |
| No_OpInQue AB00000B | If was OFF when EXECUTE transitioned from OFF -> ON,an error will occur. The Axis is BUSY, in HOLD, or aprevious motion command FAILED. | This is determined by monitoring specific BITS in the Motion Command status register (IWxx09). The Bits are :0, 1, and 3 BUSY, HOLD, and FAILED respectively. |

<DEF_POS> Working Registers

This table outlines the data in the ten registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|----------------------|---|
| <i>AW00000</i> | | Working_Register0 | |
| Bit 0 | IN | Execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | Working | Rotary_ReqPosOK | |
| Bit 2 | Working | FirstFB_Scan | One shot on <u>rising</u> edge of Execute input to set axis data. |
| Bit 3 | Working | LastFBScan | One shot on <u>falling</u> edge of Execute input to set axis data. |
| Bit 4 | Working | | Reserved |
| Bit 5 | Working | | Reserved |
| Bit 6 | IN | AbsEnc_Present | <i>ABSENC</i> input (XB000001) |
| Bit 7 | Working | IN_RDA_RANGE | Goes High when Motion Command Code (MCC) Response Register (IWxx08) is equal to 0, "NOP" (No Operation) is true |
| Bit 8 | Working | No_Alarms | Goes High when there are no Alarms |
| Bit 9 | Working | No_MCC_Requested | Goes High when Motion Command Code (MCC) Response Register (IWxx08) is equal to 0, "NOP" (No Operation) is true |
| Bit A | Working | No_MCC_InQue | Goes High when Motion Command Code (MCC) Request Register (OWxx08) is equal to 0, "NOP" (No Operation) is true |
| Bit B | Working | No_OpInQue | Goes High when the axis is NOT BUSY, NOT IN HOLD And NOT FAIED |
| Bit C | Working | Allow_DefPosExe | This bit is true if the conditions are correct to allow a define position operation. |
| Bit D | Working | Exec_DefPos | Goes High when the actual Define position operation happens. |
| Bit E | Working | AxisIsRotary | This is TRUE if the Axis is defined as Rotary in the RDA |
| Bit F | Working | Set_OffsetToZero | This bit is only true on power up If the "ABSENC" input is FALSE. |
| <i>AW00001</i> | Working | Working_Register1 | |
| Bit 0 | OUT | Op_Done | DONE Output (YB000000) |
| Bit 1 | OUT | OpError | ERROR Output (YB000002) |
| Bit 2 | Working | RotaryReqPos_InRange | Result of Range Check on "REPOSIT" Input value. Only used if axis is rotary. |
| Bit 3 | OUT | OpRunning | RUNNING Output (YB000001) |
| <i>AW00002</i> | Working | rdaMult | Value for address offset to locate proper RDA |
| <i>AW00003</i> | Working | Working_Register3 | Unused (For expansion) |
| <i>AL00004</i> | IN | Requested_Position | The "REQPOSIT" input that the axis position will be set to. |
| <i>AW00006</i> | Working | Work_Register6 | Unused (For expansion) |
| <i>AW00007</i> | Working | Working_Regester7 | Unused (For expansion) |
| <i>AW00008</i> | Working | Working_Regester8 | Unused (For expansion) |
| <i>AW00009</i> | Working | Revision | Revision Level of the function block. |

<DEF_POS> Flow Chart




RDA INITIALIZATION #1 Function

Function block for MP2000 series

<RDAINIT1> Function Block Summary

The Reserved Data Area (RDA) Initialization function block (RDAINIT1) block is used to initialize the values in the RDA for a specific axis. Without the proper values in the RDA the some motion blocks may not work properly. The RDAINIT2 block must also be used to complete the initialization of all mandatory RDA values.

Function Block Diagram



<RDAINIT1> Function Block Operation Notes

- To use the function block, it must be placed in an 'A' drawing.
- Both RDA init 1 and 2 blocks should be used together for each axis. RDA Init 1 block sets Linear or Rotary positioning mode, Maximum Speed/Accel/Decel/Jerk values, and the rotary position period.
- This drawing uses no drawing registers to run.

<RDAINIT1> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|--|
| RUNNING | Bit | Goes high while block is updating RDA. Updating completes in one scan. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|----------|------|---|--|
| LINEAR | Bit | Defines if axis is in linear mode or rotary mode. | TRUE – axis is linear FALSE – axis is rotary |
| HARDOT | Bit | This determines if hard over travels should be alarmed and indicated in the RDA. This will result in SVON block writing to ErrorID1 (MW3**81) | TRUE – write OT alarm status to ErrorID1. FALSE – don't write OT alarm status to ErrorID1. |
| AXISRDA | Word | Axis number related to the block. | 1~16 |
| MAXSPEED | Long | Maximum speed the axis is allowed to travel (counts per second) | 1 to 2147483647. The physical limitations of the motor and encoder resolution will make this number smaller. |
| MAXACCEL | Long | Maximum acceleration the axis is allowed to travel (in counts per second ²) | 1 to 2147483647. The physical limitations of the motor and encoder resolution will make this number smaller. |
| MAXDECEL | Long | Maximum deceleration the axis is allowed to travel (in counts per second ²) | 1 to 2147483647. The physical limitations of the motor and encoder resolution will make this number smaller. |
| MAXJERK | Long | More accurately defined as the S-Curve time in milliseconds. The greater the number the slower to ramp to the desired acceleration or deceleration. | 1 to 2147483647. The number may go down based on scan rate. The smoothest S-Curve allowed is 255 scans if the scan time is 2 millisecond. Then the max time will be MAXJERK = 510 msec |
| POSPRIOD | Long | For Rotary mode only. This is the largest value the axis position can reach before rolling over to zero. | 1 to 2147483647. |


RDA INITIALIZATION #2 function

Function block for MP2000 series

<RDAINIT2> Function Block Summary

The Reserved Data Area (RDA) Initialization function block (RDAINIT2) block is used to initialize the values in the RDA for a specific axis. Without the proper values in the RDA the some motion blocks may not work properly. The RDAINIT1 block must also be used to complete the initialization of all mandatory RDA values.

Function Block Diagram



<RDAINIT2> Function Block Operation Notes

- To use the function block, it must be placed in an 'A' drawing.
- Both RDA init 1 and 2 blocks should be used together for each axis. RDAINIT2 block sets the hardware module number, the axis number within the module, rated speed, and post-quad axis encoder resolution.
- This function uses no drawing registers to run.

<RDAINIT2> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | TYPE | Content |
|---------|------|--|
| RUNNING | Bit | Goes high while block is updating RDA, Updating completes in one scan. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|----------|------|--|--|
| AXISRDA | Word | Logical axis number related to the block | 1 to 16 |
| MODULE | Word | Module address given to SVA-01 or SVB. This is same as 'Circuit Number' defined in module configuration. This links to the AXISRDA which is used in all motion blocks. | 1 to 16 |
| AXIS-NUM | Word | Axis number axis is plugged into on SVA-01 or SVB module. This is same as "Axis Number" within the defined "Circuit Number". This links to the AXISRDA which is used in all motion blocks. | 1to 2 (SVA-01 module) 1 to 16 (SVB-01 module) |
| MTRSPD | Word | Rated speed of motor on axis on RPM. This is necessary for calculating accels and decels. | 1 to 32767 |
| RESOLUTN | Long | Resolution of motors encoder (post-quad). This is necessary to convert units for counts and revs. | 1 to 2147483647. |


READ SERVO ERROR function

Function block for MP2000 series

<RDERROR> Function Block Summary

This function block displays servo alarm BIT and the servo alarm code in this function block regardless to other function blocks. BALRMRST function is used to reset the alarm. Some alarm need cycle power to clear it. Please refer to Chapter 10 of MP2200/MP2300 motion module user's manual SIJPC88070016 for the content of the alarm.

Function block diagram



<RDERROR> Function Block Operation Notes

- Related function blocks are: SVON and ALRMRST.
- Rising edge of EXECUTE input initiates block operation, and all block input values are read once.
- The block will continue to monitor the axis for errors as long as the EXECUTE input stays True. If the EXECUTE bit goes off during operation, all outputs will be set to zero.
- The AXIS-ERR output will go on if servo alarm (IB**2C0=ON) occurs.
- The ERROR-ID output data can be referenced by the servo alarm code, IW**2D. Further information regarding alarm can be viewed by examining bits in IL**04. Please see appendix for details
- This block will not report any alarms until 5 seconds after the first execution of the low scan. This gives the system time to stabilize.
- Four words are used as working registers for this function, starting at the address in Data04W

<RDERROR> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------|------|--|
| RUNNING | Bit | This bit is ON when the function block is executing. |
| ERROR | Bit | If axis number is incorrect the ERROR output will go high. Also RDA Error ID (MW3**81) bit 3 is turned on. |
| AXIS-ERR | Bit | If the servo alarm (IB**2C0=ON) error occurs while the block is in execution, this output is on. However, if the error condition is released, this output is also reset. |
| ERROR-ID | Word | If an error occurs on the axis, this output will read the exact integer value in IW**2D error register. See appendix for alarm code meaning. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|---------|---------|--|---|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | TRUE – Block enable FALSE – Block disable |
| AXIS | Word | Axis number related to the block. | 1to16 |
| DATA04W | Address | Address of the first working register. | Four words of register space are used by this function. |

<RDERROR> Axis Fault Condition:

The following table outlines several situations that may cause an error. The block error can be cleared by the *EXECUTE* bit going low.


| Internal error bit | Cause | Attention |
|-----------------------|---|---|
| IDerror AB000003 | RDA ERROR | Will go high if Error ID <> 0 (MW3**81) |
| fault AB00012 | Servo Alarm | If Servo alarm condition exists. Sets RDA Error ID (MW3**81) bit 7 on if error state exists. |
| axisInErr AB00000F | The axis number entered on the input is not an acceptable value | The functions blocks can only control 1 to 16 axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |

<RDERROR> Working Registers

This table outlines the data in the five registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|----------------|---------|-----------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 1 | Working | inrngAxis | Goes high for one scan if Axis input is in range. |
| Bit 3 | Working | IDerror | Goes high if RDA Error ID (MW3**81) <> 0. |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot coil to initialize RDA of blocks execution |
| Bit F | Working | axisInErr | Goes high for one scan if Axis input is out of range. |
| <i>AW00001</i> | | | |
| Bit 2 | OUT | fault | Directly controls YB000002(<i>AXIS-ERR</i> Output). |
| <i>AW00002</i> | Working | rdaMult | Value for address offset to locate proper RDA |
| <i>AW00003</i> | Working | Revision | Revision Level of the function block. |

<RDERROR> Appendix:



Σ-III Series

| Name | Register Number | Code | Meaning |
|------------------|-----------------|------|--|
| Servo Alarm Code | IW□□2□ | 000 | Normal |
| | | 900 | Excessive Position Error |
| | | 901 | Excessive Position Error at Servo ON |
| | | 910 | Overload |
| | | 911 | Vibration |
| | | 920 | Regeneration Overload |
| | | 930 | Absolute Encoder Battery Error |
| | | 941 | Parameter Change Requiring Power Recycling |
| | | 94A | Data Setting Warning 1 (Parameter Number) |
| | | 94B | Data Setting Warning 2 (Outside Data Range) |
| | | 94C | Data Setting Warning 3 (Calculation Error) |
| | | 94D | Data Setting Warning 4 (Parameter Size) |
| | | 95A | Command Warning 1 (Command Conditions Not Met) |
| | | 95B | Command Warning 2 (Unsupported Command) |
| | | 95C | Command Warning 3 |
| | | 95D | Command Warning 4 |
| | | 95E | Command Warning 5 |
| | | 960 | MECHATROLINK Communication Warning |
| | | 020 | Parameter Checksum Error 1 |
| | | 021 | Parameter Format Error 1 |
| | | 022 | System Constant Checksum Error 1 |
| | | 023 | Parameter Password Error 1 |
| | | 02A | Parameter Checksum Error 2 |
| | | 02B | System Constant Checksum Error 2 |
| | | 030 | Main Circuit Detector Error |
| | | 040 | Parameter Setting Error 1 |
| | | 04A | Parameter Setting Error 2 |
| | | 041 | Divided Pulse Output Setting Error |
| | | 042 | Parameter Combination Error |
| | | 050 | Combination Error |
| | | 100 | Overcurrent or Heat Sink Overheat |
| | | 300 | Regeneration Error |
| | | 320 | Regeneration Overload |
| | | 330 | Main Circuit Wiring Error |
| | | 400 | Overvoltage |
| | | 410 | Undervoltage |
| | | 510 | Overspeed |
| | | 511 | Divided Pulse Output Overspeed |
| | | 520 | Vibration Alarm |
| | | 710 | Overload (Instantaneous Maximum Load) |
| | | 720 | Overload (Continuous Maximum Load) |
| | | 730 | DB Overload |
| | | 740 | Inrush Resistance Overload |
| | | 7A0 | Heat Sink Overheat |
| | | 810 | Encoder Backup Alarm |
| | | 820 | Encoder Checksum Alarm |

| Name | Register Number | Code | Meaning |
|------------------|-----------------|------|--|
| Servo Alarm Code | IW□□2D | 830 | Encoder Battery Alarm |
| | | 840 | Encoder Data Alarm |
| | | 850 | Encoder Over Speed |
| | | 860 | Encoder Overheat |
| | | 870 | Full-closed Serial Encoder Checksum Alarm |
| | | 880 | Full-closed Serial Encoder Data Alarm |
| | | 8A0 | Full-closed Serial Encoder Scale Error |
| | | 8A1 | Full-closed Serial Encoder Module Error |
| | | 8A2 | Full-closed Serial Encoder Sensor Error (Incremental) |
| | | 8A3 | Full-closed Serial Encoder Position Error (Absolute Value) |
| | | B31 | Current Detection Error 1 |
| | | B32 | Current Detection Error 2 |
| | | B33 | Current Detection Error 3 |
| | | BF0 | System Alarm 0 |
| | | BF1 | System Alarm 1 |
| | | BF2 | System Alarm 2 |
| | | BF3 | System Alarm 3 |
| | | BF4 | System Alarm 4 |
| | | C10 | Servo Run-away |
| | | C80 | Encoder Clear Error Multiturn Limit Setting Error |
| | | C90 | Encoder Communication Error |
| | | C91 | Encoder Communication Position Data Acceleration Error |
| | | C92 | Encoder Communication Timer Error |
| | | CA0 | Encoder Parameter Error |
| | | CB0 | Encoder Echoback Error |
| | | CC0 | Multiturn Limit Mismatch |
| | | CF1 | Full-closed Serial Conversion Unit Communication Error (Reception Failure) |
| | | CF2 | Full-closed Serial Conversion Unit Communication Error (Timer Stopped) |
| | | D00 | Excessive Position Error |
| | | D01 | Excessive Position Error Alarm at Servo ON |
| | | D02 | Excessive Position Error Alarm for Speed Limit at Servo ON |
| | | D10 | Excessive Error between Motor Load and Position |
| | | E00 | COM Alarm 0 |
| | | E01 | COM Alarm 1 |
| | | E02 | COM Alarm 2 |
| | | E07 | COM Alarm 7 |
| | | E40 | MECHATROLINK-II Transmission Cycle Setting Error |
| | | E50 | MECHATROLINK-II Sync Error |
| | | E51 | MECHATROLINK-II Sync Failure |
| | | E60 | MECHATROLINK-II Communication Error |
| | | E61 | MECHATROLINK-II Transmission Cycle Error |
| | | EA0 | DRV Alarm 0 |
| | | EA1 | DRV Alarm 1 |
| | | EA2 | DRV Alarm 2 |
| | | ED0 | Internal Command Error |
| | | F10 | Phase Open on Power Line |

| | | | |
|----------------------------|---------|---|---|
| IL□□02 | Warning | <p>These bits store information on the current warnings. The axis will not stop moving when a warning occurs. Warnings that are not cleared automatically will be cleared when alarms clear operation is performed after their cause has been eliminated. Normally, however, most of warnings are cleared automatically when their cause has been eliminated.</p> | |
| | | Bit 0: Excessively Following Error | <p>This bit turns ON if the following error exceeds the value set for setting parameter OL□□22 (Deviation Abnormal Detection Value) when excessively following error is set to be treated as warnings by setting the Deviation Abnormal Detection Error Level to 1 in Mode 1 (setting parameter OW□□01, bit 0).</p> |
| | | Bit 1: Setting Parameter Error | <p>This bit turns ON when one or more of the motion setting parameters value is set outside the setting range. The number of the parameter that value is out of range is stored as the Over Range Parameter Number (monitoring parameter IW□□01).</p> |
| | | Bit 2: Fixed Parameter Error | <p>This bit turns ON when one or more of the motion fixed parameters value is set outside the setting range. The number of the parameter that value is out of range is stored as the Over Range Parameter Number (monitoring parameter IW□□01).</p> |
| | | Bit 3: Servo Driver Error | <p>This bit turns ON when there is a warning in the SERVOPACK for a MECHATROLINK Servo. The content of the warning can be confirmed using the Servo Alarm Code (monitoring parameter IW□□2D).</p> |
| | | Bit 4: Motion Command Setting Error | <p>This bit turns ON when a motion command that cannot be used is set.</p> |
| | | Bit 5: Not used | |
| | | Bit 6: Positive Overtravel | <p>This bit turns ON when positive overtravel is disabled in the fixed parameter settings and the positive overtravel signal is input.</p> |
| | | Bit 7: Negative Overtravel | <p>This bit turns ON when negative overtravel is disabled in the fixed parameter settings and the negative overtravel signal is input.</p> |
| | | Bit 8: Servo Not ON | <p>This bit turns ON when the Servo ON bit in the Run Commands (setting parameter OW□□00, bit 0) is ON but the SERVOPACK is not Servo ON condition.</p> |
| | | Bit 9: Servo Driver Communication Warning | <p>This bit turns ON if a communication error is detected in communication with the MECHATROLINK Servo. This bit is cleared automatically when communication are performed normally.</p> |
| Bit 10 to Bit 31: Not used | | | |

| | | | |
|------------------------------------|--|---|--|
| IL□□04 | Alarm | These bits store information on the current alarms. The axis will stop moving when an alarm occurs. Alarms are cleared when the alarm clear operation is performed after their cause has been eliminated. | |
| | | Bit 0: Servo Driver Error | This bit turns ON when there is an alarm in the SERVOPACK for a MECHATROLINK Servo. The content of the alarm can be confirmed using the Servo Alarm Code (monitoring parameter IW□□2D). |
| | | Bit 1: Positive Overtravel | This bit turns ON when the positive overtravel signal is input and a move command is executed in the positive direction. |
| | | Bit 2: Negative Overtravel | This bit turns ON when the negative overtravel signal is input and a move command is executed in the negative direction. |
| | | Bit 3: Positive Soft Limit | This bit turns ON if a move command that exceeds the positive soft limit is executed with the following conditions: <ul style="list-style-type: none"> • Zero point return has been completed • The positive soft limit function is enabled • An infinite length axis is selected. |
| | | Bit 4: Negative Soft Limit | This bit turns ON if a move command that exceeds the negative soft limit is executed with the following conditions: <ul style="list-style-type: none"> • Zero point return has been completed • The negative soft limit function is enabled • An infinite length axis is selected. |
| | | Bit 5: Servo OFF | This bit turns ON when a move command is executed with the Servo OFF status. |
| | | Bit 6: Positioning Time Over | This bit turns ON when positioning is not completed within the specified time after the pulse distribution end. The time is set for the Position Complete Timeout (setting parameter OW□□26). |
| | | Bit 7: Excessive Positioning Moving Amount | This bit turns ON when a moving amount is specified that exceeds the setting range for the positioning moving amount. |
| | | Bit 8: Excessive Speed | This bit turns ON when a speed is set that exceeds the setting range for the speed reference. |
| | | Bit 9: Excessively Following Error | This bit turns ON if the following error exceeds the value set for the Deviation Abnormal Detection Value (setting parameter OL□□22) when Excessively Following Error is set to be treated as alarm by setting the Deviation Abnormal Detection Error Level to 0 in Mode 1 (setting parameter OW□□01, bit 0). |
| | | Bit 10: Filter Type Change Error | This bit turns ON if the filter type is changed when the pulses are still distributing. |
| | | Bit 11: Filter Time Constant Change Error | This bit turns ON if the filter time constant is changed when the pulses are still distributing. |
| | | Bit 12: Not used | |
| | | Bit 13: Zero Point Not Set | This bit turns ON if a move command (except for JOG or STEP) is performed when an infinite length axis is set and the zero point has not been set. |
| | | Bit 14: Zero Point Set during Travel | This bit turns ON if the zero point is set during axis moving. |
| | | Bit 15: Servo Driver Parameter Setting Error | This bit turns ON if a failure occurs while changing MECHATROLINK Servo parameter settings. |
| | | Bit 16: Servo Driver Synchronization Communication Error | This bit turns ON if a synchronization communication error is detected with the MECHATROLINK Servo. |
| | | Bit 17: Servo Driver Communication Error | This bit turns ON if two communication errors are detected consecutively in communication with the MECHATROLINK Servo. |
| | | Bit 18: Servo Driver Command Timeout Error | This bit turns ON if a command sent to the MECHATROLINK Servo is not completed within a specific amount of time. |
| Bit 19: ABS Encoder Count Exceeded | This bit turns ON if the number of turns from the absolute encoder exceeds the range that the MP2300 can handle. This parameter is valid when using an absolute encoder and an infinite length axis. | | |
| Bit 20 to Bit 31: Not used | | | |


READ RDA PARAMETER function

Function block for MP2000 series

<RDPARAM> Function Block Summary

This function block reads the parameters of the RDA. The output is always a long even if the parameter is a word or a bit. For bits the value will be a 1 for true and a 0 for false. The parameter input value is the RDA number from the PLC Open Specification.

Function Block Diagram



<RDPARAM> Function Block Operation Notes

- To use the function block, the *EXECUTE* bit must be True, and *AXIS* and *PARAMETER* will be constantly read.
- The block will continue to monitor the RDA for Values as long as the *EXECUTE* input stays True. If the *EXECUTE* bit goes low the outputs will be set to zero.
- Even though the *VALUE* output is a long it will also represent the bits and words.
- Six words are used as working registers for this function, starting at the address in *Data06W*.

<RDPARAM> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|--------|------|---|
| DONE | Bit | This bit is ON when the function block has a valid value from the RDA. |
| ERROR | Bit | If an error occurs during block execution, this output bit Latches ON. If the error condition is cleared, this output is reset. |
| VALUE | Long | The value from the RDA. For bit conditions 1 = TRUE 0 = FALSE |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|-----------|---------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block. | 1~16 |
| PARAMET R | Word | RDA parameter number. | The number is specified by the PLCOpen and Yaskawa specification. |
| DATA06W | Address | Address of the first working register. | Six words of register space are used by this function. |

<RDPARAM> Block Fault Condition:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will cleared if the *EXECUTE* bit goes low.

| Fault Bit | Cause | Note |
|-----------------------|---|---|
| axisInErr AB00014A | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16 axes. Any value greater or smaller than this will cause an error. This does not set the RDA Error ID. |
| error AB000009 | Parameter specified is not a valid RDA number | The number specified must be either the Yaskawa specified RDA area or the PLCOpen specified area. This block can not monitor Master/Slave data. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |

<RDPARAM> Working Register

This table outlines the data in the six registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No. | Type | Name | Description |
|--------------|---------|----------|---|
| AW00000 | Working | Reserved | Reserved |
| AW00001 | Working | Reserved | Reserved |
| AW00002 | Working | iStore | Reserved |
| AW00003 | Working | ivalue | Reserved |
| AW00004 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00005 | Working | Revision | Revision Level of the function block. |

<RDPARAM> Parameter List

The following tables show the accessible parameters by RDPARAM. # 001-#999 are PLC Open specification and above # 1000 are Yasukawa specification.

| RDA# | Data name | Details |
|------|--------------------|---|
| 005 | Movement Type | 0: Rotary 1: Liner |
| 006 | Position Period | Length of Period for rotational systems. [count] |
| 007 | Set Position | Commanded position. [count] |
| 008 | Act Position | Actual position. [count] |
| 009 | Max Velocity | Maximum velocity. [count/sec] |
| 010 | Set Velocity | Commanded velocity. [count/sec] |
| 011 | Act Velocity | Actual Velocity of axes. [count/sec] |
| 012 | Set Acceleration | Commanded acceleration. [count/sec ²] |
| 013 | Act Acceleration | Actual acceleration. [count/sec ²] |
| 014 | Max Acceleration | Maximum acceleration. [count/sec ²] |
| 015 | Set Deceleration | Commanded deceleration. [count/sec ²] |
| 016 | Act Deceleration | Actual deceleration. [count/sec ²] |
| 017 | Max Deceleration | Maximum deceleration. [count/sec ²] |
| 018 | Set S-Curve Filter | Commanded S-Curve Filter [ms] (S curve time) |
| 019 | Act S-Curve Filter | Actual S-Curve Filter [ms] (S curve time) |
| 020 | Max S-Curve Filter | Maximum S-Curve filter [ms] (S curve time) |
| 021 | Act Torque | Actual Torque [0.01% of rated torque] |
| 027 | HW Limit Enable | Enable / disable hardware end switch (to be used after |
| 028 | Capt Position | Capture position [count] |
| 029 | Capture Occurred | Capture signal occurred (reset with writing) |
| 030 | Ramp Shape | Shape of Acc/Dec profile. 0 = Trapezoid; 1= S-Shape; rest supplier dependent |
| 031 | Axis State | State of the Axis 0: reserved for power off situation 1:ErrorStopped Motion 2: Stopped Motion 3: Standstill 4: Discrete motion 5: Continuous motion |

| | | |
|------|----------------------|--|
| 1000 | Clear Pending Action | |
| 1001 | Abort | Stop axis discontinuous motion (RDA#031) |
| 1002 | Command Bit | One Scan Pulse of Motion Block Execution |
| 1003 | Accelerating | The motion is in acceleration. |
| 1004 | Decelerating | The motion is in deceleration. |
| 1005 | Steady | ? |
| 1006 | Ext Pos. Captured | Registration occurred |
| 1033 | Motor Rated Speed | Rated speed of servo motor [rpm] |
| 1034 | Encoder Resolution | Servo motor PG post-quad resolution value [pulse/rev] resolution |
| 1035 | Factor FF | Feed Forward gain (1000=100%) |
| 1036 | Enable Type | bit0: Servo ON, bit1: Positive Enabled, bit2: Negative Enabled |
| 1037 | Move State | The last motion commanded; 0:Stop, 1:MOVVEL, 2:MOVINC, 3:MOVABS, 4:MOVADDTV, 5:HOME, 6:LTCHTGT, 7:GEAR, 8:CAM |
| 1038 | Block Running | The last executed Function block Number. |
| 1039 | STATUS | Bit0:Running, Bit1:Error, bit2:Interruption |
| 1040 | Error ID 1 | bit0: No Home Switch, bit1: Over travel, bit2: Time-out, bit3: Value to Great, bit4: Direction Not Allowed, bit5: Position error, bit6: No Motor Power, bit7: Servo alarm bit8: Spare, bit9: Track Fail, bitA: RDA error, bitB: Error stop, bitC: Table error, bitD: Servo off |
| 1041 | Error ID 2 | Spare |
| 1043 | Ext Pos. Captured | Registered position [count] |
| 1044 | Module number | Module No |
| 1045 | Axis number | Axis No |

| | | |
|------|--------------------|---|
| 1060 | CAM type | OFF: Return, ON: One way |
| 1061 | Positive Cycle End | On when CAM Master position, includes CAM-Shift, rolled over in positive direction. |
| 1062 | Negative Cycle End | On when CAM Master position, includes CAM-Shift, rolled over in Negative direction. |
| 1092 | CAM state | State of CAMing. bit0: Disengaged, bit1:Waiting to Engage, bit2:CAMing is locked, bit3:Waiting to disengage |
| 1093 | TABLE size | Cam Table Size |
| 1094 | CAM shift | Absolute CAM Shift amount [count] |
| 1095 | SLAVE offset | Absolute Offset amount [count] |
| 1096 | CAM scale | Absolute Acale amount [0.01%] |
| 1097 | Machine Cycle | Machine Cycle [count] |
| 1098 | Data Counter | Raw master data for master-slave pair [count] |
| 1099 | Mod Data | Modulated master data for master/slave pair. [count] |
| 1105 | GEAR state | State of Gearing. bit0:Disengaged, bit1:Accelerating, bit2:Gearing is locked and synched, bit3:Decelerating |


WRITE RDA PARAMETER function

Function block for MP2000 series

<WRTPARAM> Function Block Summary

This function block writes values to the RDA parameter. The value set is always a long even if the parameter calls to a bit. In case of bit information, ON=1 and OFF=0. The input value of PARAMETR is RDA number of the PLC Open specification.

Function Block Diagram



<WRTPARAM> Function Block operation Notes

- To use the function block, the *EXECUTE* bit must be True.
- The block will write the value to the parameter in the RDA only on the rising edge of the Execute input and if there is no errors reported in the block.
- If the *EXECUTE* bit goes low the outputs will be set to zero.
- To set a bit in the RDA, enter the value of a one in the VALUESET input and execute block. A zero in the VALUESET input will reset the bit.
- Even though this block may write to a parameter care must be taken that the parameter not be one that is controlled by another block. (ie. Actual position is written to by the SVON block. Any changes to this value will cause the value to be over written by the SVON block the very next scan.
- Six words are used as working registers for this function, starting at the address in *Data06W*.

<WRTPARAM> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|--------|------|--|
| DONE | Bit | When the value has been successfully stored and the execute input is high, this bit will go high |
| ERROR | Bit | If an error occurs during block execution, this output bit Latches ON. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range and state |
|-----------|---------|--|---|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Rising edge initiates block TRUE – Block enable FALSE – Block disable, set all outputs to zero and off |
| AXIS | Word | Axis number related to the block | 1~16 |
| PARAMETER | Word | RDA parameter number | It must be RDA number of the PLC Open or Yasukawa specification |
| VALUESET | Long | Value to be stored in the RDA | Since a long is used for all RDA parameters an Error will occur if the value is too great for the word or bit that is being set. For bit, ON=1 and OFF=0. |
| DATA06W | Address | Address of the first working register. | Six words of register space are used by this function. |

<WRTPARAM> Block Fault Condition:

The following table outlines several situations that may cause an error. The block error can be cleared by the *EXECUTE* bit going low

| Fault Bit | Cause | Note |
|-----------------------|---|---|
| axisInErr AB00000F | The axis number entered on the input is not an acceptable value | The function blocks can only control 1 to 16axis. Any value greater or smaller then this will cause an error. This does not set the RDA Error ID. |
| Notspec AB00000E | Parameter specified is not a valid RDA number | The number specified must be either the Yaskawa specified RDA area or the PLCOpen specified area. This block can not monitor Master/Slave data. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| valueOut AB00000D | Value out of range for the RDA | Value must be within range of value being stored or error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |

<WRTPARAM> Working Registers

This table outlines the data in the six registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Content |
|-------------|---------|----------|---|
| AW00000 | Working | Reserved | Reserved |
| AW00001 | Working | Reserved | Reserved |
| AW00002 | Working | iStore | Reserved |
| AW00003 | Working | ivalue | Reserved |
| AW00004 | Working | rdaMult | Value for address offset to locate proper RDA |
| AW00005 | Working | Revision | Revision Level of the function block. |

<WRTPARAM> Parameter list

The following table shows the accessible parameters by RDPARAM. #001 through #999 are PLCOpen specification and above #1000 are supplier specific..

| RDA# | Data name | Details |
|------|--------------------|---|
| 005 | Movement Type | 0: Rotor 1: Liner |
| 006 | Position Period | Length of Period for rotational systems. [count] |
| 007 | Set Position | Commanded position. [count] |
| 008 | Act Position | Actual position. [count] |
| 009 | Max Velocity | Maximum velocity. [count/sec] |
| 010 | Set Velocity | Commanded velocity. [count/sec] |
| 011 | Act Velocity | Actual Velocity of axes. [count/sec] |
| 012 | Set Acceleration | Commanded acceleration. [count/sec ²] |
| 013 | Act Acceleration | Actual acceleration. [count/sec ²] |
| 014 | Max Acceleration | Maximum acceleration. [count/sec ²] |
| 015 | Set Deceleration | Commanded deceleration. [count/sec ²] |
| 016 | Act Deceleration | Actual deceleration. [count/sec ²] |
| 017 | Max Deceleration | Maximum deceleration. [count/sec ²] |
| 018 | Set S-Curve Filter | Commanded S-Curve Filter [ms] (S curve time) |
| 019 | Act S-Curve Filter | Actual S-Curve Filter [ms] (S curve time) |
| 020 | Max S-Curve Filter | Maximum S-Curve filter [ms] (S curve time) |
| 021 | Act Torque | Actual Torque [0.01% of rated torque] |
| 027 | HW Limit Enable | Enable / disable hardware end switch (to be used after |
| 028 | Capt Position | Capture position [count] |
| 029 | Capture Occurred | Capture signal occurred (reset with writing) |
| 030 | Ramp Shape | Shape of Acc/Dec profile. 0 = Trapezoid; 1= S-Shape; rest supplier dependent |
| 031 | Axis State | State of the Axis 0: reserved for power off situation 1:ErrorStopped Motion 2: Stopped Motion 3: Standstill 4: Discrete motion 5: Continuous motion |

| | | |
|------|----------------------|--|
| 1000 | Clear Pending Action | |
| 1001 | Abort | Stop axis discontinuous motion (RDA#031) |
| 1002 | Command Bit | One Scan Pulse of Motion Block Execution |
| 1003 | Accelerating | The motion is in acceleration. |
| 1004 | Decelerating | The motion is in deceleration. |
| 1005 | Steady | ? |
| 1006 | Ext Pos. Captured | Registration occurred |
| 1033 | Motor Rated Speed | Rated speed of servo motor [rpm] |
| 1034 | Encoder Resolution | Servo motor PG post-quad resolution value [pulse/rev] resolution |
| 1035 | Factor FF | Feed Forward gain (1000=100%) |
| 1036 | Enable Type | bit0: Servo ON, bit1: Positive Enabled, bit2: Negative Enabled |
| 1037 | Move State | The last motion commanded; 0:Stop, 1:MOVVEL, 2:MOVINC, 3:MOVABS, 4:MOVADDTV, 5:HOME, 6:LTCHTGT, 7:GEAR, 8:CAM |
| 1038 | Block Running | The last executed Function block Number. |
| 1039 | STATUS | Bit0:Running, Bit1:Error, bit2: Interruption |
| 1040 | Error ID 1 | bit0: No Home Switch, bit1: Over travel, bit2: Time-out, bit3: Value to Great, bit4: Direction Not Allowed, bit5: Position error, bit6: No Motor Power, bit7: Servo alarm bit8: Spare, bit9: Track Fail, bitA: RDA error, bitB: Error stop, bitC: Table error, bitD: Servo off |
| 1041 | Error ID 2 | Spare |
| 1043 | Ext Pos. Captured | Registered position [count] |
| 1044 | Module number | Module No |
| 1045 | Axis number | Axis No |

| | | |
|------|--------------------|---|
| 1060 | CAM type | OFF: Return, ON: One way |
| 1061 | Positive Cycle End | On when CAM Master position, includes CAM-Shift, rolled over in positive direction. |
| 1062 | Negative Cycle End | On when CAM Master position, includes CAM-Shift, rolled over in Negative direction. |
| 1092 | CAM state | State of CAMing. bit0: Disengaged, bit1:Waiting to Engage, bit2:CAMing is locked, bit3:Waiting to disengage |
| 1093 | TABLE size | Cam Table Size |
| 1094 | CAM shift | Absolute CAM Shift amount [count] |
| 1095 | SLAVE offset | Absolute Offset amount [count] |
| 1096 | CAM scale | Absolute Acale amount [0.01%] |
| 1097 | Machine Cycle | Machine Cycle [count] |
| 1098 | Data Counter | Raw master data for master-slave pair [count] |
| 1099 | Mod Data | Modulated master data for master/slave pair. [count] |
| 1105 | GEAR state | State of Gearing. bit0:Disengaged, bit1:Accelerating, bit2:Gearing is locked and synched, bit3:Decelerating |


ASCII CHARACTER INPUT Function Block

Function block for MP2000 series

<ASCIIIN> Function Block Summary

This function block receives a sequence of 7-bit or 8-bit ASCII characters of a specified size through the controllers serial port, RS232 or RS422/485 from a transmitter device. This sequence of characters is then stored in table format at an offset global MW register location.

Function Block Diagram



<ASCIIIN> Function Block Operation Notes

- To use the function block, the *EXECUTE* bit must be held ON.
- If the *EXECUTE* bit goes off during operation, the block will stop receiving data.
- On the rising edge of the *EXECUTE* input, the following two are executed. The *EXECUTE* input should be maintained ON while in operation.
 - The set value of *START* and *SIZE* are read.
 - The storage table is initialized by data H2020(Null).
- *ERROR-ID* output has been added to better troubleshoot communication problems. A zero in the value means no errors or block disabled.
- Protocol settings must be configured in controller module setup and transmitter setup, and must match (baud rate, parity, stop bit, # data bits).
- This ASCIIin function block uses a MSG-RCV an embedded function. Since the transmission protocol is set to none (internal setting =3(no procedure 2)(The data of each byte is transferred according to a no procedure)), the Master/Slave setting in module configuration is not necessary.

- This function expects the characters to be received from the source in a continuous stream (Note: if testing is performed by typing in one character at a time from a keyboard, the data reception MSG-RCV will time-out, and only the first character will be received, and the DONE signal will come on).
- Thirty words are used as working registers for this function, starting at the address in *Data30W*

<ASCIIN> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| OUTPUT | TYPE | Content |
|----------|------|---|
| BUSY | Bit | High while block is receiving data and there are no errors. |
| DONE | Bit | Goes high when receiving is completed and remains high until execute is turned off. |
| ERROR | Bit | Goes high if any error occurs in block or on the axis |
| ERROR-ID | Word | Displays the value of the error in block. |
| NUMCHRIN | Word | Displays the number of characters received. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| INPUT | TYPE | Content | Range of State |
|---------|----------------|--|---|
| EXECUTE | | Block enable – Block cannot execute unless this is TRUE. | TRUE – Block enable FALSE – Block disable |
| START | Word | Starting address to store ASCII set. This is fed directly into Param12 of MSG-RCV function. This is the address for an M-register type | 0-29999(unused M register area) and 30000 and higher have been reserved by the RDA parameter. |
| SIZE | Word | Maximum number of ASCII characters to be received. Start + Size is fed directly into Param13 of MSG-RCV function | 0~28767 |
| CIR | Word | Which port is to transmitted from | For 2171F-01 1=Port 1 (RS-232C) 2=Port 2 (RS-422/485) |
| DATA30W | Address | Address of the first working register. | Thirty words of register space are used by this function. |

<ASCIIN> Block Fault Conditions:

The following table outlines several situations that may cause an error. The block error can be cleared by the *EXECUTE* bit going low.

| Internal Fault Bit | Cause | Note |
|----------------------|-----------------------|---|
| rcverror AB00001F | MSG-RCV has an error. | The MSG-RCV internal function has an error. Refer to ERROR-ID output for value. 81= Function code error 82= Address set error 83= Data size error 84= Line number setting error 85= Channel number error 86= Station Address error 88= Transmission unit error 89= Device selection error |

<ASCIIN> Working Registers

This table outlines the data in the Thirty registers used by the function block. There is not usually any need for the user to access any of these bits directly. The MSG-RCV type registers can be further understood by referencing the MSG-RCV function block in the on line help.

| Register No. | Type | Name | Description |
|----------------|---------|------------|--|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | <i>EXECUTE</i> input (XB000000) |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | done | Directly controls YB000001 (<i>COMPLETE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot on rising edge of EXECUTE input to initialize axis. |
| AW00001 | MSG-RCV | Reserved | Reserved |
| AW00002 | MSG-RCV | Reserved | Reserved |
| AW00003 | MSG-RCV | slave | Called station # (Param2) |
| AW00004 | MSG-RCV | Reserved | Reserved |
| AW00005 | MSG-RCV | Reserved | Reserved |
| AW00006 | MSG-RCV | startAdd | Data address (Param05) |
| AW00007 | MSG-RCV | size | Data size (Param06) |
| AW00008 | MSG-RCV | called_CPU | Called CPU# (Param7) |
| AW00009 | MSG-RCV | Reserved | Reserved |

| | | | |
|---------|---------|----------------|--|
| AW00010 | MSG-RCV | Reserved | Reserved |
| AW00011 | MSG-RCV | Reserved | Reserved |
| AW00012 | MSG-RCV | holding_offset | Value to shift data in register (Param11, this is meaningless for non-protocol mode) |
| AW00013 | MSG-RCV | starAddress | First address of M register to store data (This sets Param12) |
| AW00014 | MSG-RCV | endAdd | End address of M register to store data (this sets param13) |
| AW00015 | MSG-RCV | system | Reserved |
| AW00016 | MSG-RCV | Reserved | Reserved |
| AW00017 | MSG-RCV | Reserved | Reserved |
| AW00018 | Working | Reserved | Reserved |
| AW00019 | Working | Reserved | Reserved |
| AW00020 | OUT | errorID | Directly controls <i>ERROR-ID</i> output (YW00001) |
| AW00021 | Working | iStore | Reserved |
| AW00022 | Working | step | Reserved |
| AW00023 | Working | endAddress | Final M register to store data |
| AW00024 | Working | Reserved | Reserved |
| AW00025 | Working | Reserved | Reserved |
| AW00026 | Working | filterLow | Reserved |
| AW00027 | Working | filterHigh | Reserved |
| AW00028 | OUT | chrCount | Number of Characters received Directly controls <i>ERROR-ID</i> output (YW00001). |
| AW00029 | Working | Revision | Revision Level of the function block. |


<ASCIIIN> Example of application:

The following examples illustrates how to receive ASCII characters from PC COM1 to Port#1 of the MP2300 217IF-01 module (In the First Slot) via RS-232C. MotionWorks is used to monitor the received Character data in registers MW04032 through MW04039 (16 characters). Hyper-terminal™ is used to send the character string in a Text file.

Hardware setup

Yaskawa W5211-03 cable connects PC COM2 and MP2300 217IF-01 module (the second slot) Port#1 for MotionWorks.


PC COM1 and MP2300 217IF-01 module (The first slot) Port#1 is connected for ASCII communication.



MP2300 MotionWorks Software Module Setup

Set the MP2300 217IF-01 module Port#1 (The first slot) serial interface for ASCII communication. Note that Transmission protocol is set to None. Master/Slave and Serial I/F settings are not used so they will be ignored. Protocol settings are as follows:


- Transmission protocol: No procedure
- Transmission mode: None
- Data length: 8bit
- Parity bit: Even
- Stop bit: 1 Stop
- Baud rate: 9600bps



Hyper-Terminal Serial Port (PC COM1) Setup

Setting the serial interface on the PC COM1 for ASCII communication is as follows. (Hyper-Terminal is used)


- Baud rate:9600bps
- Data length:8bit
- Parity bit:Even number
- Stop bit:1 Stop
- Flow control:Hardware



Setup of ASCII-IN function

The ASCII-IN function block is inserted in the Low Speed drawing L01, called from L using the LadderWorks editor (see block on right). It is important to also note that the function block uses 30 words of local registers, care must be taken not to overwrite those registers. In this example, local I/O is used to control the function block execution.

Note that the "START" input is set to 4032. With the "SIZE" input set to 16, the Character table source is then setup from MW04032 through MW04039 (8 16-bit words holds 16 ASCII characters), The CIR input is set to 1 to indicate Port#1 will be used to receive ASCII characters from the PC Htperterminal. Also MW30000 and higher are reserved for function block operation (RDA). Avoid using RDA area for ASCII character table.




Making of ASCII file (TEXT file)

The character string can be created in a Text file like Notepad.



Test of program operation

Execution of the function block is started by switching 'on' input bit IB04100. Then send the Text file with the HyperTerminal. The received characters are seen in the Register List.




ASCII CHARACTER OUTPUT function

Function block for MP2000 series

<ASCIIOUT> Function Block Summary

This function block sends a sequence of 7-bit or 8-bit ASCII characters of a specified size through the controllers serial port, RS232 or RS422/485 to a receiver device. This sequence of characters is stored in table format at an offset global MW register location. A carriage return (CR) and line feed (LF) can be added to the end of the table if needed.

Function Block Diagram



<ASCIIOUT> Function Block Operation Notes

- Character transmission starts at positive edge of *EXECUTE* input .
- To use the function block, the *EXECUTE* input must be held ON.
- If a carriage return (CR) and line feed (LF) are needed on the end of the table the *CRLF* bit must be set high. Note that this will insert the Carriage Return and Line Feed (which takes up 8 bits each) at the end of the table. The last 16 bit word data-point in the table will be over written with this before it is sent out the serial port. In this case *SIZE* indicates the total size of the data to be *transmitted*, including CrLf.
- *ERROR-ID* output has been added to better troubleshoot communication problems. A zero in the value means no errors or block disabled.
- Protocol settings must be configured in controller module setup and receiver setup, and must match (baud rate, parity, stop bit, # data bits).
- This ASCIIout function block uses a MSG-SEND an embedded function. Since the transmission protocol is set to none (version 3, unit is by byte), the Master/Slave setting in module configuration is not necessary.
- Twenty-three words are used as working registers for this function, starting at the address in *Data23W*.

<ASCIIOUT> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|----------|------|--|
| BUSY | Bit | High while block is transmitting data and there are no errors. |
| DONE | Bit | Goes high when transmission is completed and remains high until execute is turned off. |
| ERROR | Bit | Goes high if any error occurs in block or on the axis |
| ERROR-ID | Word | Displays the value of the error in block. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the function work as necessary.

| Input | Type | Description | Range of State |
|---------|----------------|--|---|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | Pos Edge – Block execute TRUE – Block enable FALSE – Block disable |
| CRLF | Bit | <i>Inserts a Carriage return and line feed to the end of the table (takes up one 16-bit word, table size remains the same (note this will overwrite the last word of the table with the CrLf).</i> | TRUE – CR and LF are added FALSE – no addition |
| START | Word | Starting address of ASCII set. This is directly written to Param5 of MSG-SND function. It will represent the address of an M-register type. | 0-29999(unused M register area). 30000 and higher have been reserved by the RDA parameter. |
| SIZE | Word | Number of ASCII characters to be sent (number of bites), also indicates table size This is directly written to Param6 of MSG-SND function | 0~28767 |
| CIR | Word | Indicates the circuit number or port number to send the characters | For 217IF-01 1=Port 1 (RS-232C) 2=Port 2 (RS-422/485) |
| SLAVE | Word | Destination Station Number This value is set in PARAM02 of the MSG-SND function. | 1~256 |
| DATA23W | Address | Address of the first working register. | Twenty-three words of register space are used by this function. |

<ASCIIOUT> Block Fault Conditions:

The following table outlines several situations that may cause an error, and will turn on the blocks “Error” output bit. The block “Error” output will OFF if the *EXECUTE* bit goes low.

| Internal Fault Bit | Cause | Note |
|--------------------|------------------------------------|---|
| inRng1 AB000003 | Improper cir number. Out of range. | On the initial pass of the block the bit must be high or an error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| inRng2 AB000004 | Improper slave address | On the initial pass of the block the bit must be high or an error will occur. Sets RDA Error ID (MW3**81) bit 3 on if error state exists. |
| snderr AB00001F | MSG-SND has an error. | The MSG-SND internal function has an error. Refer to ERROR-ID output for value. 81= function code error 82= address set error 83= data size error 84= line number set error 85= channel number set error 86= station address error 88= transmission part error 89= device selection error |

<ASCIIOUT> Working Register

This table outlines the data in the Twenty-three registers used by the function block. There is not usually any need for the user to access any of these bits directly. The MSG-SND type registers can be further understood by referencing the MSG-SND function block in the on line help.

| Register No | Type | Name | Description |
|----------------|---------|-----------|---|
| <i>AW00000</i> | | | |
| Bit 0 | IN | execute | EXECUTE input (XB000000) |
| Bit 1 | Working | crlf | If True, a carriage return and Line feed are inserted at the end of the table. |
| Bit 2 | Working | oddnum | Reserved |
| Bit 3 | OUT | inRng1 | Verifies that <i>CIR-NUM</i> input (XW000003) is in range |
| Bit 4 | OUT | inRng2 | Verifies that <i>SLAVE</i> input (XW000004) is in range |
| Bit 7 | OUT | running | Directly controls YB000000 (<i>RUNNING</i> Output) |
| Bit 8 | OUT | done | Directly controls YB000001 (<i>COMPLETE</i> Output) |
| Bit 9 | OUT | error | Directly controls YB000002 (<i>ERROR</i> Output) |
| Bit A | Working | oneshotA | Reserved |
| Bit B | Working | firstPass | One shot on rising edge of EXECUTE input to initialize RDA & sets parameters in the message send function |

| | | | |
|---------|---------|----------------|--|
| AW00001 | MSG-SND | Reserved | Reserved |
| AW00002 | MSG-SND | Reserved | Reserved |
| AW00003 | MSG-SND | slave | Called station # (Param2) |
| AW00004 | MSG-SND | Reserved | Reserved |
| AW00005 | MSG-SND | Reserved | Reserved |
| AW00006 | MSG-SND | startAdd | Data address, starting address of data to be sent out (Param5) |
| AW00007 | MSG-SND | size | Data size, number of characters to be sent out (Param6) |
| AW00008 | MSG-SND | called_CPU | Called CPU# (Param7) |
| AW00009 | MSG-SND | Reserved | Reserved |
| AW00010 | MSG-SND | Reserved | Reserved |
| AW00011 | MSG-SND | Reserved | Reserved |
| AW00012 | MSG-SND | holding_offset | Holding register offset (Param11) |
| AW00013 | MSG-SND | sys_send | For system (Param12) |
| AW00014 | MSG-SND | Reserved | Reserved |
| AW00015 | MSG-SND | Reserved | Reserved |
| AW00016 | MSG-SND | Reserved | Reserved |
| AW00017 | MSG-SND | Reserved | Reserved |
| AW00018 | Working | Reserved | Reserved |
| AW00019 | Working | Reserved | Reserved |
| AW00020 | OUT | errorID | Directly controls <i>ERROR-ID</i> output (YW00001) |
| AW00021 | Working | mod | Reserved |
| AW00022 | Working | Revision | Revision Level of the function block. |


<ASCIIOUT> Application Example:

The following example illustrates how to send characters from Port #1 of an MP2300 217IF-01 module (in the first slot) to COM1 of a PC via RS232 . MotionWorks is used to set the Character table data in registers MW04000 through MW04007 (16 characters). Hyper-terminal™ is used to receive and display the character string.

Hardware setup

Yaskawa W5311-03 cable is connected from Port#1 of the MP2300 217IF-01 module (the second slot) to PC COM2 for MotionWorks interface software.


Port#1 of the MP2300 217IF-01 module (the first slot) and PC COM1 are connected for ASCII communication (refer to the user's manual for wiring).



MP2300 MotionWorks Software Module setup

Setting the serial interface of MP2300 217IF-01 module Port#1 (the first slot) for ASCII communication is as follows. Note that Transmission protocol is set to None. Master/Slave and Serial I/F settings are not used so they will be ignored . Protocol settings are as follows:

- Transmission protocol: No procedure
- Transmission mode: None
- Data length: 8bit
- Parity bit: Even
- Stop bit: 1 Stop
- Baud rate: 9600bps




TECHNICAL NOTE



Hyper-Terminal Serial Port Setup

A terminal session was opened up called “test”. The serial port configuration for Com1 is set up identical to the MP2300 217IF-01 (the first slot) Port#1 settings
Baud rate:9600bps
Data length:8bit
Parity bit:Even number
Stop bit:1 Stop
Flow control:Hardware




MotionWorks Application Software Setup

The ASCIIOUT function block is inserted in the LOW Speed drawing L01, called from L using the LadderWorks editor (see block on right). It is important to also note that the function block uses 23 words of local registers, care must be taken not to overwrite those registers. In this example, local I/O is used to control the function block execution, CR/LF select.

With setting “START” as 4000 and “SIZE” as 16, the character table source is then setup from MW04000 to MW04007 (ASCII character 16 characters are stored in the register of eight words) If CR/LF is used, then two more characters will be inserted at the end of the table, decreasing the user character table size to MW4000 to MW4006 (7-16-bit words holds 14 ASCII characters).


The “CIR” input is set to 1 to indicate Port#1 of the module will be used to send ASCII characters to the PC Hyper-Terminal.

MW30000 and higher are RDA parameter. Avoid using RDA for ASCII character table.




Character Table Setup

The character table can be set up easily through the 'quick reference' window. In this case 16 ASCII characters are typed in at MW04000 as "This is a test!". The HEX representation can be viewed by 'register list' tool, as shown. Note that each character takes up 8 bits which is two HEX digits. Each 16 bit word can hold two characters.



Application Test Run:

Execution of the function block is started by switching 'on' input bit IB00001. The HyperTerminal window shows the text output. Note that the data that is sent to the PC and displayed is exactly what is stored in the ASCII character table.



General use note:

To communicate to any device using ASCII characters, a slave ID and protocol wrapper may need to be developed. This will need to be loaded in the ASCII character register table.


PLS – PROGRAMMABLE LIMIT SWITCH function

Function block for MP2000 series

<PLS> Function Block Summary

The “PLS” block is used to turn a bit on and off based on a range the axis is in.

Functional Block Diagram



<PLS> Function Block Operation Notes

- To use the function block, the *EXECUTE Input* must be held ON.
- If the *EXECUTE input* goes off during operation, the outputs will go to zero or false.
- The *COUNTER* input can be any long register designated to control the state of the *OUTPUT*.
- If the value of the *COUNTER* input is within the *LOWLIMIT* and the *HILIMIT* then the *OUTPUT* output bit will be True.
- Two words are used as working registers for this function, starting at the address in *Data02W*.

<PLS> Input and Output Register Map

Output Registers

The following registers are used as outputs from the function block. They can be monitored by the LadderWorks program to check the execution of the function.

| Output | Type | Description |
|---------|------|---|
| RUNNING | Bit | Goes true if block is enabled. |
| OUTPUT | Bit | Goes true when <i>Counter</i> input value is within the <i>LOWLIMIT</i> and <i>HILIMIT</i> inputs and the <i>EXECUTE</i> input is True. |

Input Registers

The following registers are used as inputs to the function block. They select the options and define the parameters that the user needs to make the Home function work as necessary.

| Input | Type | Description | Range and state |
|----------|-----------|--|--|
| EXECUTE | Bit | Block enable – Block cannot execute unless this is TRUE. | True-effective False-invalidity |
| LOWLIMIT | Long | Defines the output enable window. Minimum value of counter for <i>OUTPUT</i> output to go TRUE | -2147483648~2147483647 |
| HILIMIT | Long | Defines the output enable window. Maximum value of counter for <i>OUTPUT</i> output to go TRUE | -2147483648~2147483647 |
| COUNTER | Long | The controlling counter for the bit | A long register containing the counter value. |
| DATA02W | Addresses | Address of the first working register. | Two words of register space are used by this function. |

<PLS> Working Register

This table outlines the data in the two registers used by the function block. There is not usually any need for the user to access any of these bits directly.

| Register No | TYPE | Name | Description |
|-------------|---------|-----------|--|
| AW00000 | | | |
| Bit 0 | IN | execute | EXECUTE input (XB000000) |
| Bit A | IN | oneshotA | Reserved |
| Bit B | IN | firstPass | One shot coil from rising edge of EXECUTE input to initiate block. |
| AW00002 | Working | Revision | Revision Level of the function block. |