


YASKAWA AC Drive Option

# LonWorks

# Technical Manual

Model SI-W3

To correctly use the product, read this manual thoroughly and keep it for easy reference, inspection, and maintenance. Make sure that the end user receives this manual.



---

**This Page Intentionally Blank**

# Table of Contents

|   |    |
|---|----|
| 1. Preface and Safety . . . . .                             | 7  |
| Applicable Documentation . . . . .                          | 7  |
| Glossary . . . . .  | 7  |
| Registered Trademarks . . . . .                             | 7  |
| Supplemental Safety Information . . . . .                   | 7  |
| Section Safety . . . . .                                    | 8  |
| 2. Overview . . . . .                                       | 8  |
| About This Option . . . . .                                 | 8  |
| Compatible Products . . . . .                               | 8  |
| 3. Receiving . . . . .                                      | 9  |
| Option Package Contents . . . . .                           | 9  |
| Installation Tools . . . . .                                | 10 |
| 4. Option Components . . . . .                              | 11 |
| Option . . . . .  | 11 |
| Terminal block CN1 . . . . .                                | 11 |
| Connector CN3 for Keypad . . . . .                          | 11 |
| Service Switch . . . . .                                    | 11 |
| Neuron ID . . . . .   | 12 |
| Initializing Bind Data . . . . .                            | 12 |
| Option LED States . . . . .                                 | 12 |
| 5. Installation Procedure . . . . .                         | 13 |
| Section Safety . . . . .                                    | 13 |
| Procedures to Install and Wire Options on a Drive . . . . . | 13 |
| Procedure A . . . . .                                       | 13 |
| Procedure B . . . . .                                       | 17 |
| Procedure C . . . . .                                       | 20 |
| Procedure D . . . . .                                       | 23 |
| Option Connection Diagram . . . . .                         | 27 |
| Electrical Interference Countermeasures . . . . .           | 27 |
| Communication Cable Topology . . . . .                      | 28 |
| Termination Resistor Connection . . . . .                   | 28 |
| XIF Files, Resource Files . . . . .                         | 29 |
| 6. Related Drive Parameters . . . . .                       | 29 |
| 7. Basic Operation . . . . .                                | 30 |
| Run Command and Frequency Reference Selection . . . . .     | 30 |

|   |           |
|---|-----------|
| Selecting the Reference . . . . .   | 30        |
| <b>8. Network Variables . . . . .</b>                                       | <b>31</b> |
| Drive and Network Variables . . . . .                                       | 31        |
| Node Objects . . . . .  | 32        |
| Object Requests . . . . .   | 32        |
| Object Status . . . . .   | 34        |
| VSD Input Network Variables . . . . .                                       | 35        |
| Drive Speed Setpoint (Drive Speed Operation Command) . . . . .              | 35        |
| Drive Frequency Reference (Hz) (Drive Frequency Reference) . . . . .        | 35        |
| Drive Speed SetFreq (%) (Drive Speed Reference) . . . . .                   | 36        |
| Drive Run Reference (Drive Run Reference) . . . . .                         | 36        |
| Drive Operation Commands (Drive Control Commands) . . . . .                 | 36        |
| Drive Speed Setpoint Scaling (Drive Speed Scaling) . . . . .                | 37        |
| Drive Emergency (Drive Emergency Stop) . . . . .                            | 37        |
| Drive Fault Reset Command (Drive Error Reset) . . . . .                     | 37        |
| Drive Energy Clear (Cumulative Power Value Clear) . . . . .                 | 37        |
| Drive Parameter Read (Drive Constant Read Request) . . . . .                | 38        |
| Drive Parameter Write (Drive Constant Write Request) . . . . .              | 38        |
| Drive Parameter Write Data (Drive Constant Write Data) . . . . .            | 38        |
| VSD Output Network Variables . . . . .                                      | 39        |
| Drive Speed Feedback (%) (Drive Speed Monitoring) . . . . .                 | 39        |
| Drive Run Status (Drive Run Monitoring) . . . . .                           | 39        |
| Drive Output Frequency (Drive Output Frequency Monitoring) . . . . .        | 40        |
| Drive Output Current (Output Current Monitoring) . . . . .                  | 40        |
| Drive Output Voltage (Output Voltage Monitoring) . . . . .                  | 40        |
| Drive DC Voltage (DC Bus Voltage Monitoring) . . . . .                      | 40        |
| Drive Output Power (Output Power Monitoring) . . . . .                      | 41        |
| Cumulative Drive Energy (Cumulative Power Monitoring) . . . . .             | 41        |
| Drive Total Running Hours (Total Running Hours Monitoring) . . . . .        | 41        |
| Drive Fault Status (Drive Fault Monitoring) . . . . .                       | 41        |
| Drive Alarm Status (Drive Alarm Monitoring) . . . . .                       | 42        |
| Drive Parameter Read Data (Drive Constant Read Data) . . . . .              | 42        |
| Drive Parameter Error (Drive Constant Access Error) . . . . .               | 42        |
| Drive Speed Setpoint Feedback 1 (Drive Speed Reference Monitor 1) . . . . . | 43        |
| Drive Speed Setpoint Feedback 2 (Drive Speed Reference Monitor 2) . . . . . | 43        |
| Drive Status (Drive Status Monitoring) . . . . .                            | 43        |
| Drive Fault Status 1 (Drive Fault Status Monitor 1) . . . . .               | 44        |
| Drive Fault Status 2 (Drive Fault Status Monitor 2) . . . . .               | 44        |
| Drive Fault Status 3 (Drive Fault Status Monitor 3) . . . . .               | 45        |
| Drive Emerg Status (Drive Emergency Stop Status) . . . . .                  | 45        |
| Setting Drive Constants from the Network . . . . .                          | 46        |
| Reading Drive Constants . . . . .   | 46        |
| Writing Drive Constants . . . . .   | 46        |
| <b>9. Configuration Properties . . . . .</b>                                | <b>47</b> |
| Drive Related Network Configuration Properties . . . . .                    | 47        |
| Maximum Motor Speed . . . . .   | 47        |
| Minimum Motor Speed . . . . .   | 48        |
| Send Heartbeat Time . . . . .   | 48        |
| Nominal Motor Speed in RPM (Motor Rated Rotation Frequency) . . . . .       | 48        |
| Nominal Motor Frequency (Motor Rated Frequency) . . . . .                   | 48        |
| Drive Ramp Up Time (Drive Acceleration Time) . . . . .                      | 48        |
| Minimum Ramp Down Time (Minimum Deceleration Time) . . . . .                | 48        |
| Receive Heartbeat Time . . . . .  | 49        |
| Minimum Send Time . . . . .   | 49        |
| Location Label . . . . .  | 49        |
| Power Delay Timer . . . . .   | 49        |



|   |           |
|---|-----------|
| Output Frequency Monitor Minimum Change Range Setting 1 | 49        |
| Output Frequency Monitor Minimum Change Range Setting 2 | 49        |
| nvInvSetFreq Default                                    | 50        |
| nvInvSetFreq Default                                    | 50        |
| nviDrvSpeedRef Default                                  | 50        |
| Cumulative Power Monitor Upper Limit                    | 50        |
| Cumulative Power Monitor Minimum Change Range Setting   | 50        |
| Reference Selection Mode                                | 50        |
| Run Command Status Mode                                 | 51        |
| <b>10. Troubleshooting</b>                              | <b>51</b> |
| Drive-Side Error Codes                                  | 51        |
| Faults  | 51        |
| Minor Faults and Alarms                                 | 52        |
| Option Compatibility                                    | 53        |
| <b>11. Function Modules</b>                             | <b>53</b> |
| Functions   | 53        |
| Connection of Keypad for DDC Functionality via JVOP-182 | 53        |
| Keypad Display  | 54        |
| Menu Structure for Keypad                               | 55        |
| List of Functions                                       | 57        |
| Items Common to Functions                               | 58        |
| Logic Operation Function                                | 58        |
| Function Block Image                                    | 58        |
| Network Variables and Parameters                        | 58        |
| Operation   | 59        |
| Analog Operation Function                               | 59        |
| Function Image  | 59        |
| Network Variables and Parameters                        | 59        |
| Operation   | 60        |
| Select Operation Function                               | 63        |
| Function Image  | 63        |
| Network Variables and Parameters                        | 63        |
| Operation   | 64        |
| Comparison Operation Function                           | 64        |
| Function Image  | 64        |
| Network Variables and Parameters                        | 64        |
| Operation   | 65        |
| Step Output Operation Function                          | 65        |
| Function Image  | 65        |
| Network Variables and Parameters                        | 65        |
| Operation   | 67        |
| Delay Timer Function                                    | 68        |
| Function Image  | 68        |
| Network Variables and Parameters                        | 69        |
| Operation   | 69        |
| Deviation Output Function                               | 69        |
| Function Image  | 70        |
| Network Variables and Parameters                        | 70        |
| Operation   | 70        |
| PID Function  | 71        |
| Function Image  | 71        |
| Network Variables and Parameters                        | 71        |
| Operation   | 71        |

---

|   |           |
|---|-----------|
| Constant Output Function . . . . .                | 71        |
| Function Image . . . . .                          | 71        |
| Network Variables and Parameters . . . . .        | 72        |
| Operation . . . . .                               | 72        |
| Variable Type Conversion Function . . . . .       | 72        |
| Function Image . . . . .                          | 72        |
| Network Variables and Parameters . . . . .        | 72        |
| Operation . . . . .                               | 73        |
| Save Data Function . . . . .                      | 74        |
| Function Image . . . . .                          | 74        |
| Network Variables and Parameters . . . . .        | 74        |
| Operation . . . . .                               | 74        |
| Standard Network Variable Types (SNVTs) . . . . . | 74        |
| <b>12. European Standards . . . . .</b>           | <b>76</b> |
| EMC Directive Compliance . . . . .                | 76        |
| Option Installation . . . . .                     | 76        |
| <b>13. Specifications . . . . .</b>               | <b>78</b> |
| Specifications . . . . .                          | 78        |
| <b>14. Disposal . . . . .</b>                     | <b>78</b> |
| Disposal Instructions . . . . .                   | 78        |
| WEEE Directive . . . . .                          | 79        |
| <b>Revision History . . . . .</b>                 | <b>80</b> |

# 1 Preface and Safety

YASKAWA Electric supplies component parts for use in a wide variety of industrial applications. The selection and application of YASKAWA products remain the responsibility of the equipment designer or end user.

YASKAWA accepts no responsibility for the way its products are incorporated into the final system design. Under no circumstances should any YASKAWA product be incorporated into any product or design as the exclusive or sole safety control. Without exception, all controls should be designed to detect faults dynamically and fail safely under all circumstances. All products designed to incorporate a component part manufactured by YASKAWA must be supplied to the end user with appropriate warnings and instructions as to the safe use and operation of that part. Any warnings provided by YASKAWA must be promptly provided to the end user. YASKAWA offers an express warranty only as to the quality of its products in conforming to standards and specifications published in the manual. **NO OTHER WARRANTY, EXPRESS OR IMPLIED, IS OFFERED.** YASKAWA assumes no liability for any personal injury, property damage, losses, or claims arising from misapplication of its products.

## ◆ Applicable Documentation

These manuals are available for the option:

| Document  | Description   |
|---|---|
| Yaskawa AC Drive Option LonWorks Installation Manual  | Read this manual first.<br>The manual provides information about wiring, settings, functions, and troubleshooting. The manual is packaged together with the product.  |
| YASKAWA AC Drive Option LonWorks Technical Manual<br>Manual No.: SIEP C730600 93<br>(This book) | The technical manual contains detailed information about the option.<br>Access the following sites to obtain the technical manual:<br>U.S.: <a href="http://www.yaskawa.com">http://www.yaskawa.com</a><br>Europe: <a href="http://www.yaskawa.eu.com">http://www.yaskawa.eu.com</a><br>Japan: <a href="http://www.e-mechatronics.com">http://www.e-mechatronics.com</a><br>Other areas: Check the back cover of these manuals.<br>For questions, contact Yaskawa or a Yaskawa representative.  |
| YASKAWA AC Drive Manuals  | Refer to the drive manual to connect with the option.<br>Drive manuals contain basic installation and wiring information in addition to detailed parameter setting, fault diagnostic, and maintenance information.<br>The manuals also include important information about parameter settings and tuning the drive.<br>The Quick Start Guides are packaged with the drive.<br>The most recent versions of these manuals are available for download on our documentation websites:<br>U.S.: <a href="http://www.yaskawa.com">http://www.yaskawa.com</a><br>Europe: <a href="http://www.yaskawa.eu.com">http://www.yaskawa.eu.com</a><br>Japan: <a href="http://www.e-mechatronics.com">http://www.e-mechatronics.com</a><br>Other areas: Check the back cover of these manuals.<br>For questions, contact Yaskawa or a Yaskawa representative. |

## ◆ Glossary

| Terms                      | Definition   |
|----------------------------|--|
| Option                     | YASKAWA AC Drive Option SI-W3 LonWorks   |
| Keypad                     | <ul style="list-style-type: none"> <li>• HOA Operator</li> <li>• LCD Operator</li> <li>• LED Operator</li> <li>• HOA Keypad</li> <li>• LCD Keypad</li> <li>• LED Keypad</li> </ul> |
| Hex. (Example: 900 (Hex.)) | Identifies a unit for hexadecimal number format.   |

## ◆ Registered Trademarks

- LonWorks and LonTalk are registered trademarks of Echelon Corporation.
- Trademarks are the property of their respective owners.

## ◆ Supplemental Safety Information

Read and understand this manual before installing, operating, or servicing this option. The option must be installed according to this manual and local codes.

The following conventions are used to indicate safety messages in this manual. Failure to heed these messages could result in serious or possibly even fatal injury or damage to the products or to related equipment and systems.

**⚠ DANGER** This signal word identifies a hazard that will cause serious injury or death if you do not prevent it.

**⚠ WARNING** This signal word identifies a hazard that can cause death or serious injuries if you do not prevent it.

**⚠ CAUTION** This signal word identifies a hazardous situation, which, if not avoided, can cause minor or moderate injury.

**NOTICE** This signal word identifies a property damage message that is not related to personal injury.

## ■ Section Safety

| General Precautions  |
|--|
| <ul style="list-style-type: none"> <li>The diagrams in this section may include options and drives without covers or safety shields to illustrate details. Be sure to reinstall covers or shields before operating any devices. The option should be used according to the instructions described in this manual.</li> <li>The diagrams in this manual are provided as examples only and may not pertain to all products covered by this manual.</li> <li>The products and specifications described in this manual or the content and presentation of the manual may be changed without notice to improve the product and/or the manual.</li> <li>Contact Yaskawa or a Yaskawa representative and provide the manual number shown on the front cover to order new copies of the manual.</li> </ul> |

**⚠ DANGER** Do not ignore the safety messages in this manual. If you ignore the safety messages in this manual, it will cause serious injury or death. The manufacturer is not responsible for injuries or damage to equipment.

**⚠ WARNING** *Electrical Shock Hazard.* Do not modify the drive or option circuitry. Failure to obey can cause serious injury or death, or cause damage to the drive or option and will void warranty. Yaskawa is not responsible for modifications of the product made by the user.

**NOTICE** *Damage to Equipment.* Do not use steam or other disinfectants to fumigate wood for packaging the drive. Use alternative methods, for example heat treatment, before you package the components. Gas from wood packaging fumigated with halogen disinfectants, for example fluorine, chlorine, bromine, iodine or DOP gas (phthalic acid ester), can cause damage to the drive.

## 2 Overview

### ◆ About This Option

The LonWorks Communication Option (Model SI-W3) is based on LonTalk. It acts as an interface for connecting an AC drive to a LonWorks network using the LonTalk protocol.

When you install the option to the drive, you can use the LonTalk protocol to do these operations:

- Operate the drive
- Monitor the drive operation status
- Change drive parameter settings

### ◆ Compatible Products

You can use the option with these products:

**Table 2.1 Compatible Products**

| Drive  | Model                  | Software Version <sup>*1</sup> |
|--------|------------------------|--------------------------------|
| A1000  | CIMR-Ax2Axxxx          | ≥ 1020                         |
|        | CIMR-Ax4A0002 - 4A0675 |                                |
|        | CIMR-Ax4A0930, 4A1200  | ≥ 3015                         |
|        | CIMR-Ax5Axxxx          | ≥ 5040<br>≥ 1020               |
| U1000  | CIMR-UxxAxxxx          | ≥ 1010                         |
|        | CIMR-UxxExxxx          |                                |
|        | CIMR-UxxPxxxx          |                                |
|        | CIMR-UxxWxxxx          |                                |
| U1000L | CIMR-UxxLxxxx          | ≥ 6210                         |
|        | CIMR-UxxFxxxx          |                                |
|        | CIMR-UxxRxxxx          |                                |
|        | CIMR-UxxSxxxx          |                                |

| Drive  | Model          | Software Version <sup>*1</sup> |
|--------|----------------|--------------------------------|
| Z1000  | CIMR-ZxxAxxxx  | ≥ 1014                         |
| Z1000U | CIMR-ZxxAxxxx  | ≥ 6110                         |
|        | CIMR-ZxxExxxx  |                                |
|        | CIMR-ZxxPxxxx  |                                |
|        | CIMR-ZxxWxxxx  |                                |
| GA700  | CIPR-GA70xxxxx | ≥ 1010                         |
| GA800  | CIPR-GA80xxxxx | ≥ 9010                         |
| HV600  | CIPR-HV60xxxxx | ≥ 1011                         |
| FP605  | CIPR-FP65xxxxx | ≥ 1010                         |

\*1 Refer to “PRG” on the drive nameplate for the software version number.

**Note:**

- Refer to the option package labeling in the field designated “PRG (four digit number)” or the option labeling in the field designated “C/N (S + four digit number)” to identify the option software version.
- For Yaskawa customers in the North or South America region:  
If your product is not listed in [Table 2.1](#), refer to the web page below to confirm this manual is correct for your product. The web page provides a list of option manuals by product, and a direct link to download a PDF of the manual.  
**Scan QR code Or refer to:** <http://www.yaskawa.com/optionlookup>







## 3 Receiving





After receiving the option package:

- Make sure that the option is not damaged and no parts are missing.  
Contact your sales outlet if there is damage to the option or other parts. Contact your sales outlet if there is damage to the option or other parts.
- NOTICE** *Damage to Equipment. Do not use damaged parts to connect the drive and the option. Failure to comply could damage the drive and option.*
- Make sure that the model number on the option nameplate and the model number on the purchase order are the same. Refer to [Figure 4.1](#) for more information.
  - Contact the distributor where you purchased the option or contact Yaskawa or a Yaskawa representative about any problems with the option.

### ◆ Option Package Contents

Table 3.1 Contents of Package

| Option Contents           |   | Quantity        |
|---------------------------|---|-----------------|
| Option                    |                         | 1               |
| Ground Wire <sup>*1</sup> |                         | 1               |
| Screws (M3)               |                         | 3 <sup>*2</sup> |
| LED Labels                | 1000-Series, Z1000U<br> | 1               |

| Option Contents |  | Quantity  |   |
|-----------------|--|---|---|
|                 | GA700, GA800   |  | 1 |
|                 | Z1000, HV600, and FP605 *3   |  | 1 |
| Bar Code Label  |  | 1   |   |
| Manuals         |   | 1   |   |

\*1 GA700 and GA800 drives do not use the ground wire.

\*2 GA700, GA800, HV600, and FP605 drives use two screws only.

\*3 LED label has transparent background and white letters. Please make sure that you use the correct label for Z1000, HV600, or FP605.

## ◆ Installation Tools

You can use these tools to install the option to the drive:

- A Phillips screwdriver or slotted screwdriver (blade depth: 0.4 mm (0.02 in), width: 2.5 mm (0.1 in)) \*1.
- A flat-blade screwdriver (blade depth: 0.4 mm (0.02 in.), width: 2.5 mm (0.1 in.)).
- A pair of diagonal cutting pliers.
- A small file or medium-grit sandpaper.


\*1 Phillips screw sizes are different for different drive capacities. Prepare different screwdrivers for different screw sizes.

**Note:**

If you create a connector on the communication cable side, a separate tool is necessary.

## 4 Option Components

### ◆ Option



- |                              |  |
|------------------------------|--|
| <b>A - Connector (CN5)</b>   | <b>H - LED (SERVICE)</b>                                 |
| <b>B - Installation hole</b> | <b>I - Service switch</b>                                |
| <b>C - LED (ERR) *1</b>      | <b>J - Keypad connector (CN3) *3</b>                     |
| <b>D - LED (RUN) *1</b>      | <b>K - Product dependent</b>                             |
| <b>E - LED (TX) *1</b>       | <b>L - Ground terminal (FE) and installation hole *2</b> |
| <b>F - LED (RX) *1</b>       | <b>M - Terminal block CN1</b>                            |
| <b>G - Neuron ID</b>         |  |


Figure 4.1 Option

- \*1 Refer to [Option LED States on page 12](#) for more information about the LEDs.
- \*2 Connect the included ground wire during installation. The ground wire is not necessary for installation on GA700 and GA800 drives.
- \*3 Keypad model JVOP-182 is required for Direct Digital Control (DDC) functionality via connector CN3. Refer to [Connector CN3 for Keypad on page 11](#) for more information. The Z1000 and Z1000U product series do not support this connector and associated DDC functions.

### ◆ Terminal block CN1

The communication connector on the option is a pluggable terminal block designated CN1. You can remove the communication connector from the circuit board.

Table 4.1 Terminal Descriptions

| Terminal  | Terminal No. | Name | Description   |
|---|--------------|------|---------------|
|  | 1            | A    | Signal Line A |
|   | 2            | SLD  | Shield        |
|   | 3            | B    | Signal Line B |

### ◆ Connector CN3 for Keypad

**Note:**

- The Z1000 and Z1000U do not support this connector and associated DDC functions.
- Digital operator model JVOP-180 and JVOP-183 are not compatible.

**⚠ DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, remove the covers before measuring for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*

Use an RJ-45 cable to connect a digital operator (model: JVOP-182) to connector CN3 to set Direct Digital Control (DDC) function parameters.

### ◆ Service Switch

The service switch is a neuron ID output switch. Push this switch to output the neuron ID to the network.

■ **Neuron ID**

A label showing the neuron ID is on the option PCB. Refer to page [Figure 4.1](#) for more information. A bar code label for the neuron ID is on the option and there are additional labels in the packaging.

■ **Initializing Bind Data**

To clear the bind data and reset the configuration properties to the default settings, hold down the service switch and cycle power.


**Note:**

Do not turn off the power to the drive while you initialize the bind data. RUN, RX, TX, and ERR LEDs are lit (ON) during initialization of the bind data.

◆ **Option LED States**

The option has five LEDs:

The operational status of the option LEDs after the power-up diagnostic LED sequence is complete are described in [Table 4.2](#).



**Figure 4.2 Option LED Labels**

\*1 LED label has transparent background and white letters. Please make sure that you use the correct label for Z1000, HV600, or FP605.

**Table 4.2 Option LED States**

| LED Name | Indication |             | Operating State                    | Description   |
|----------|------------|-------------|------------------------------------|---|
|          | Color      | Display     |                                    |   |
| RUN      | Green      | ON          | No Fault                           | The option is operating normally.   |
|          |            | Flashing    | Network status is not configured   | You have not configured the LonWorks network.   |
|          |            | OFF         | Power supply off<br>Hardware fault | Power is not being supplied to the drive.<br>The option detected a fatal (unrecoverable) error. If the unit does not recover after you cycle power, you may need to replace the option. |
| RX       | Green      | ON/Flashing | Receiving                          | Receiving node data   |
|          |            | OFF         | Node data not yet received         | No input signal   |
| TX       | Green      | ON/Flashing | Sending                            | Sending data  |
|          |            | OFF         | Not sending data                   | No data is being sent   |
| ERR      | Red        | ON          | Hardware fault                     | The option detected a fatal (unrecoverable) error. If the unit does not recover after you cycle power, you may need to replace the option.  |
|          |            | Flashing    | Comm error                         | The option detected a <i>CALL</i> or <i>BUS</i> error.  |
|          |            | OFF         | No Fault                           | The option is operating normally.   |
| SERVICE  | Green      | ON          | Service switch active              | Service switch is being held down.  |
|          |            |             | Hardware fault                     | The option detected a fatal (unrecoverable) error. If the unit does not recover after you cycle power, you may need to replace the option.  |
|          |            | Flashing    | Network status is not configured   | You have not configured the LonWorks network.   |
|          |            | OFF         | No Fault                           | The option is operating normally.   |

**Note:**

RUN, RX, TX, and ERR LEDs are lit (ON) during initialization of the bind data.



## 5 Installation Procedure

### ◆ Section Safety

**⚠ DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, measure for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*

**⚠ WARNING** *Electrical Shock Hazard. Do not operate the drive when covers are missing. Replace covers and shields before you operate the drive. Use the drive only as specified by the instructions. Some figures in this section include drives without covers or safety shields to more clearly show the inside of the drive. If covers or safety shields are missing from the drive, it can cause serious injury or death.*

**⚠ WARNING** *Electrical Shock Hazard. Only let approved personnel install, wire, maintain, examine, replace parts, and repair the drive. If personnel are not approved, it can cause serious injury or death.*

**⚠ WARNING** *Electrical Shock Hazard. Do not remove covers or touch circuit boards while the drive is energized. If you touch the internal components of an energized drive, it can cause serious injury or death.*

**⚠ WARNING** *Electrical Shock Hazard. Do not use damaged wires, put too much force on the wiring, or cause damage to the wire insulation. Damaged wires can cause serious injury or death.*

**⚠ WARNING** *Fire Hazard. Tighten all terminal screws to the correct tightening torque. Connections that are too loose or too tight can cause incorrect operation and damage to the drive. Incorrect connections can also cause death or serious injury from fire.*

**NOTICE** *Damage to Equipment. When you touch the option, make sure that you observe correct electrostatic discharge (ESD) procedures. If you do not follow procedures, it can cause ESD damage to the drive circuitry.*

**NOTICE** *Damage to Equipment. Do not de-energize the drive while the drive is outputting voltage. Incorrect equipment sequencing can cause damage to the drive.*

**NOTICE** *Do not operate a drive or connected equipment that has damaged or missing parts. You can cause damage to the drive and connected equipment.*

**NOTICE** *Use Yaskawa connection cables or recommended cables only. Incorrect cables can cause the drive or option to function incorrectly.*

**NOTICE** *Damage to Equipment. Correctly connect the connectors. Incorrect connections can cause malfunction or damage to the equipment.*

**NOTICE** *Damage to Equipment. Make sure that all connections are correct after you install the drive and connecting peripheral devices. Incorrect connections can cause damage to the option.*

### ◆ Procedures to Install and Wire Options on a Drive

Procedures to install and wire the option are different for different drive models.

Refer to the following table to check the procedures to install and wire the option on a drive.

**Table 5.1 Procedures to Install and Wire Options on a Drive**


| Drive  | Procedures to Install and Wire Options on a Drive | Reference Page |
|--------|---|----------------|
| A1000  | Procedure A                                       | 13             |
| U1000  | Procedure A                                       | 13             |
| U1000L | Procedure A                                       | 13             |
| Z1000  | Procedure B                                       | 17             |
| Z1000U | Procedure A                                       | 13             |
| GA700  | Procedure C                                       | 20             |
| GA800  | Procedure C                                       | 20             |
| HV600  | Procedure D                                       | 23             |
| FP605  | Procedure D                                       | 23             |

#### ■ Procedure A

This section shows the procedure to install and wire the option on a 1000-series drive.

**Prepare the Drive for the Option**

Correctly wire the drive as specified by the manual packaged with the drive. Make sure that the drive functions correctly. For information about drive connection and wiring, refer to the manuals for the drive on which you will use this option.



- A - Insertion point for CN5 connector
- B - Option
- C - Drive front cover
- D - Keypad
- E - LED label
- F - Drive terminal cover
- G - Removable tabs for wire routing
- H - Included screws
- I - Ground wire
- J - Terminal Block
- K - Drive grounding terminal (FE)
- L - Connector CN5-A
- M - Connector CN5-B (Not available for communication option installation.)
- N - Connector CN5-C (Not available for communication option installation.)

Figure 5.1 Drive Components with Option

**Install the Option**

Use this procedure to install the option.


**DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, measure for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*

1. Remove the keypad (B), front cover (A), and terminal cover (C).

Shut off power to the drive and wait for the time specified on the drive warning label at a minimum. Make sure that the charge indicator LED is not illuminated, then remove the keypad and front cover. Refer to the drive manuals for more information.

You can only install this option into the CN5-A connector on the drive control board.


**NOTICE** *Damage to Equipment. When you touch the option, make sure that you observe correct electrostatic discharge (ESD) procedures. If you do not follow procedures, it can cause ESD damage to the drive circuitry.*



- A - Drive front cover
- B - Keypad
- C - Drive terminal cover

Figure 5.2 Remove the Keypad, Front Cover, and Terminal Cover

- Put the LED label (B) in the correct position on the drive front cover (A).




**A - Drive front cover**

**B - LED label**

**Figure 5.3 Put the LED Label on the Drive Front Cover**

- Install the option (A) into the CN5-A connector (C) on the drive and use one of the included screws (B) to put it in place.



**A - Option**

**B - Included screw**


**C - Connector CN5-A**

**Figure 5.4 Install the Option**

- Use one of the remaining included screws (B) to connect one end of the ground wire (C) to the ground terminal (A). Use the last remaining included screw (B) to connect the other end of the ground wire (C) to the remaining ground terminal and installation hole on the option (A).

Tighten the screws to a correct tightening torque:

- 0.5 to 0.6 N•m (4.4 to 5.3 in•lb)



- A - Option
- B - Included screws
- C - Ground wire
- D - Drive grounding terminal (FE)

**Figure 5.5 Connect the Ground Wire**


**Note:**

The drive has only two ground terminal screw holes. When you connect three options, two options will share one ground terminal.

5. Route the option wiring.
  - Procedures to wire the option are different for different drive models.
  - You can route the option wiring through openings on the front cover of some models. Remove the perforated tabs on the left side of the front cover as shown in [Figure 5.6-A](#) to create the necessary openings on these models. To prevent damage to the cable from the cut end, treat the cut surface with sandpaper.
  - Route the option wiring inside the enclosure as shown in [Figure 5.6-B](#). Refer to the drive manuals for more information.

**Note:**

Isolate communication cables from main circuit wiring and other electrical and power lines.




- A - Route wires through the openings provided on the left side of the front cover. \*1
- B - Use the open space provided inside the drive to route option wiring.

**Figure 5.6 Wire Routing Examples**

\*1 If there is wiring outside the enclosure, the drive will not meet Enclosed wall-mounted type (IP20/UL Type 1) requirements.

6. Firmly connect the LonWorks communication cable to terminal block (CN1).
  - Isolate communication cables from main circuit wiring and other electrical and power lines. Make sure that you firmly connect the cable end. (Refer to [Figure 5.28](#)). Refer to [Communication Cable Topology on page 28](#) for more information.
7. Reattach the front cover (A), terminal cover (C), and keypad (B). Refer to the drive manuals for more information.

**NOTICE** Do not pinch cables between the front covers and the drive. Failure to comply could cause erroneous operation.



A - Drive front cover  
B - Keypad

C - Drive terminal cover

**Figure 5.7 Replace the Front Cover, Terminal Cover, and Keypad**


8. Set drive parameters in [Related Drive Parameters on page 29](#) for correct option performance.

### ■ Procedure B

This section shows the procedure to install and wire the option on a Z1000 drive.

#### Prepare the Drive for the Option

Correctly wire the drive as specified by the manual packaged with the drive. Make sure that the drive functions correctly. For information about drive connection and wiring, refer to the manuals for the drive on which you will use this option.



A - Drive grounding terminal (FE)  
B - Option  
C - Included screws  
D - Drive front cover  
E - Keypad

F - LED label  
G - Ground wire  
H - Option modular connector CN1  
I - Insertion point for CN5 connector  
J - Connector CN5

**Figure 5.8 Drive Components with Option**

#### Install the Option


Use this procedure to install the option.

**⚠ DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, measure for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*

1. Remove the keypad (B) and front cover (A).

Shut off power to the drive and wait for the time specified on the drive warning label at a minimum. Make sure that the charge indicator LED is unlit, then remove the keypad and front cover. Refer to the drive manuals for more information.

**NOTICE** *Damage to Equipment. When you touch the option, make sure that you observe correct electrostatic discharge (ESD) procedures. If you do not follow procedures, it can cause ESD damage to the drive circuitry.*




A - Drive front cover

B - Keypad

**Figure 5.9 Remove the Front Cover and Keypad**

2. Put the LED label (B) in the correct position on the drive front cover (A).



A - Drive front cover


B - LED label

**Figure 5.10 Put the LED Label on the Drive Front Cover**

3. Install the option (A) into the CN5 connector (C) on the drive and use one of the included screws (B) to put it in place.

**Note:**

The drive has only two ground terminals. When you install three options to the drive, connect two ground wires to share one drive ground terminal.




A - Option  
B - Included screw

C - Connector CN5

**Figure 5.11 Install the Option**

4. Use one of the remaining included screws (B) to connect one end of the ground wire (C) to the ground terminal (A). Use the last remaining included screw (B) to connect the other end of the ground wire (C) to the remaining ground terminal and installation hole on the option (A).  
Tighten the screws to a correct tightening torque:
  - 0.5 to 0.6 N•m (4.4 to 5.3 in•lb)



A - Drive grounding terminal (FE)  
B - Included screws


C - Ground Wire

**Figure 5.12 Connect the Ground Wire**

5. Firmly connect the LonWorks communication cable to terminal block (CN1).  
Isolate communication cables from main circuit wiring and other electrical and power lines. Make sure that you firmly connect the cable end. (Refer to [Figure 5.28](#)). Refer to [Communication Cable Topology on page 28](#) for more information.
6. Reattach the drive front cover (A) and the keypad (B).  
Refer to the drive manuals for more information.

**NOTICE** Do not pinch cables between the front covers and the drive. Failure to comply could cause erroneous operation.





A - Drive front cover

B - Keypad

Figure 5.13 Replace the Front Cover and Keypad


7. Set drive parameters in [Related Drive Parameters on page 29](#) for correct option performance.

### ■ Procedure C

This section shows the procedure to install and wire the option on a GA700 or GA800 drive.

#### Prepare the Drive for the Option

Correctly wire the drive as specified by the manual packaged with the drive. Make sure that the drive functions correctly. For information about drive connection and wiring, refer to the manuals for the drive on which you will use this option.



A - Insertion point for CN5 connector

B - Option

C - Included screws

D - Drive front cover

E - LED label

F - Keypad

G - Terminal Block

H - LED Status Ring board

I - Connector CN5-A

J - Connector CN5-B (Not available for communication option installation.)

K - Connector CN5-C (Not available for communication option installation.)

Figure 5.14 Drive Components with Option


#### Install the Option

Use this procedure to install the option.

**⚠ DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, measure for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*



1. Put the LED label (A) in the correct position on the drive front cover (B).



A - LED label

B - Drive front cover

**Figure 5.15 Put the LED Label on the Drive Front Cover**

2. Remove the keypad (E) and front cover (D).


Shut off power to the drive and wait for the time specified on the drive warning label at a minimum. Make sure that the charge indicator LED is unlit, then remove the keypad and front cover. Refer to the drive manuals for more information.

You can only install this option into the CN5-A connector on the drive control board.

**NOTICE** *Damage to Equipment.* When you touch the option, make sure that you observe correct electrostatic discharge (ESD) procedures. If you do not follow procedures, it can cause ESD damage to the drive circuitry.

**Note:**

1. Remove the keypad, then move the keypad connector to the holder on the drive, then remove the front cover.
2. Put the keypad connector tab into the holder when you install the keypad connector to the holder.



A - Holder

B - Keypad connector tab

C - Keypad connector

D - Drive front cover


E - Keypad

**Figure 5.16 Remove the Front Cover and Keypad**

3. Carefully remove the LED Status Ring board (A) and put it in the temporary placement holes (B) on the right side of the drive.

Refer to the drive manuals for more information.

**NOTICE** *Do not remove the LED Status Ring board cable connector. If you disconnect the LED Status Ring board, it can cause incorrect operation and damage to the drive.*



A - LED Status Ring board

B - Temporary placement holes

Figure 5.17 Remove the LED Status Ring Board


4. Install the option (A) into the CN5-A connector (C) on the drive and use the included screws (B) to put it in place.

Tighten the screws to a correct tightening torque:

- 0.5 to 0.6 N•m (4.4 to 5.3 in•lb)

**Note:**

1. A ground wire is not necessary. Do not use the ground wire.
2. Only two screws are necessary to install the option on a GA700 and GA800 drive.



A - Option

B - Included screws

C - Connector CN5-A


Figure 5.18 Install the Option

5. Firmly connect the LonWorks communication cable to terminal block (CN1).  
Isolate communication cables from main circuit wiring and other electrical and power lines. Make sure that you firmly connect the cable end. (Refer to [Figure 5.28](#)). Refer to [Communication Cable Topology on page 28](#) for more information.
6. Reattach the LED Status Ring board (E), front cover (C), and keypad (D).  
Refer to the drive manuals for more information.

**NOTICE** Do not pinch cables between the front cover or the LED Status Ring board and the drive. Failure to comply could cause erroneous operation.

**Note:**

Replace the keypad connector then install the keypad.



A - Keypad connector tab  
 B - Keypad connector  
 C - Drive front cover

D - Keypad  
 E - LED Status Ring board

Figure 5.19 Install the LED Status Ring board, Front Cover, and Keypad


7. Set drive parameters in [Related Drive Parameters on page 29](#) for correct option performance.

## ■ Procedure D

This section shows the procedure to install and wire the option on an HV600 or FP605 drive.

### Prepare the Drive for the Option

Correctly wire the drive as specified by the manual packaged with the drive. Make sure that the drive functions correctly. For information about drive connection and wiring, refer to the manuals for the drive on which you will use this option.



A - Drive grounding terminal (FE)  
 B - Option  
 C - Included screws  
 D - Ground screw  
 E - Drive front cover  
 F - Keypad

G - LED label  
 H - Ground wire  
 I - Option modular connector CN1  
 J - Insertion point for connector (HV600: CN5, FP605: CN5-A)  
 K - Connector (HV600: CN5, FP605: CN5-A)

Figure 5.20 Drive Components with Option

### Install the Option


Use this procedure to install the option.

**⚠ DANGER** *Electrical Shock Hazard. Do not examine, connect, or disconnect wiring on an energized drive. Before servicing, disconnect all power to the equipment and wait for the time specified on the warning label at a minimum. The internal capacitor stays charged after the drive is de-energized. The charge indicator LED extinguishes when the DC bus voltage decreases below 50 Vdc. When all indicators are OFF, measure for dangerous voltages to make sure that the drive is safe. If you do work on the drive when it is energized, it will cause serious injury or death from electrical shock.*

1. Remove the keypad (B) and front cover (A).

Shut off power to the drive and wait for the time specified on the drive warning label at a minimum. Make sure that the charge indicator LED is unlit, then remove the keypad and front cover. Refer to the drive manuals for more information.

**NOTICE** *Damage to Equipment. When you touch the option, make sure that you observe correct electrostatic discharge (ESD) procedures. If you do not follow procedures, it can cause ESD damage to the drive circuitry.*




A - Drive front cover

B - Keypad

**Figure 5.21 Remove the Front Cover and Keypad**

2. Put the LED label (B) in the correct position on the drive front cover (A).




A - Drive front cover

B - LED label

**Figure 5.22 Put the LED Label on the Drive Front Cover**

- Remove the screw (B) installed in the drive grounding terminal (A).



**A - Drive grounding terminal (FE)**


**B - Ground screw**

**Figure 5.23 Remove the Screw from the Drive Grounding Terminal**

- Use the screw (B) installed in the FE ground terminal of the drive (A) to connect one end of the included ground wire (C) to the ground terminal on the drive.  
Tighten the screw to a correct tightening torque:
  - 0.5 N·m to 0.6 N·m (4.4 in-lb to 5.3 in-lb)

**Note:**

Route ground wire on the right side of the stud (D).



**A - Drive grounding terminal (FE)**

**B - Ground screw**

**C - Ground wire**


**D - Stud**

**Figure 5.24 Connect the Ground Wire**

- Install the option (A) into the connector (C) (HV600: CN5, FP605: CN5-A) on the drive and use the included screws (B) to put it in place.  
Tighten the screw to a correct tightening torque:
  - 0.5 N·m to 0.6 N·m (4.4 in-lb to 5.3 in-lb)

**Note:**

Only two screws are necessary to install the option on HV600 and FP605 drives.



**A - Option**

**B - Included screw**

**C - Connector CN5**

**Figure 5.25 Install the Option**


6. Use one of the remaining included screws (B) to connect the ground wire (A) to the ground terminal and installation hole on the option.

Tighten the screw to a correct tightening torque:

- 0.5 N·m to 0.6 N·m (4.4 in·lb to 5.3 in·lb)

**Note:**

Wire the ground wire as specified by [Figure 5.26](#).



**A - Ground wire**


**B - Included screw**

**C - Crimp terminal**

**Figure 5.26 Connect the Ground Wire**

7. Firmly connect the LonWorks communication cable to terminal block (CN1).  
Isolate communication cables from main circuit wiring and other electrical and power lines. Make sure that you firmly connect the cable end. (Refer to [Figure 5.28](#)). Refer to [Communication Cable Topology on page 28](#) for more information.
8. Reattach the drive front cover (A) and the keypad (B).  
Refer to the drive manuals for more information.

**NOTICE** Do not pinch cables between the front covers and the drive. Failure to comply could cause erroneous operation.



A - Drive front cover

B - Keypad

Figure 5.27 Replace the Front Cover and Keypad

9. Set drive parameters in [Related Drive Parameters on page 29](#) for correct option performance.

## ◆ Option Connection Diagram




Figure 5.28 Option Connection Diagram

- \*1 If there is electrical interference in the communication signals, install an EMI/RFI filter to the input lines and a zero-phase reactor to the output lines. Refer to [Electrical Interference Countermeasures on page 27](#) for more information.
- \*2 Connect the included ground wire for installations on 1000-series, HV600, and FP605 drives.  
The ground wire is not necessary for installation on GA700 or GA800 drives.
- \*3 Do not connect the shield line directly to the SLD terminal or the drive ground terminal. Failure to obey can cause electrical interference.

## ◆ Electrical Interference Countermeasures

If there is electrical interference in the communication signals, install an EMI/RFI filter to the input lines and a zero-phase reactor to the output lines.

## 5 Installation Procedure

Refer to the appropriate drive catalog for information on selecting the correct EMI/RFI filter for the input line and zero-phase reactor for the output line.


| Filter Install Location        | Filter Type        | Series/Part Number           |
|--------------------------------|--------------------|------------------------------|
| Main circuit (input)           | Noise filter       | LNFD series                  |
| Main circuit (output to motor) | Zero-Phase Reactor | F6054GB, F11080GB, F200160PB |

### ◆ Communication Cable Topology

Use only a dedicated LonWorks communication cable.

Route the option wiring as specified by these procedures.

1. Prepare the communication cables as shown in [Figure 5.29](#).



**A - Sheath**  
**B - Shield**

**C - Use electrical tape or shrink tubing to insulate the cable.**

**Figure 5.29 Prepare Ends of Shielded Cable**

2. Connect the communication cables to the terminal block as shown in [Figure 5.30](#).

Make sure that the terminal block CN1 is firmly fixed when you connect the terminal block CN1 to the circuit board.

Tighten the screws to a correct tightening torque:


- 0.22 to 0.25 N•m (0.0 to 0.0 in•lb)

3. Make sure that you correctly connect the wires and that you did not accidentally pinch wire insulation in the terminals.

Trim any frayed wires.

**⚠ WARNING** *Fire Hazard. Tighten all terminal screws to the correct tightening torque. Connections that are too loose or too tight can cause incorrect operation and damage to the drive. Incorrect connections can also cause death or serious injury from fire.*

**NOTICE** *Do not let wire shields touch other signal lines or equipment. Insulate the wire shields with electrical tape or shrink tubing. If you do not insulate the wire shields, it can cause a short circuit and damage the drive.*



**Figure 5.30 Prepare and Connect Communication Cable Wiring**

### ◆ Termination Resistor Connection

You must terminate a free topology segment. You can terminate the segment anywhere.






Figure 5.31 RC Network ( $R_a = 52.3 \Omega \pm 1\%$ , 1/8W)

## ◆ XIF Files, Resource Files

XIF files and dedicated resource files for the option are not packaged with the option.

Contact Yaskawa or your nearest sales representative. You can download drive manuals from the Yaskawa product and technical information website shown on the back cover of this manual.

## 6 Related Drive Parameters

These parameters set the drive for operation with the option. Confirm correct parameter settings in this table before you start network communications.

### Note:

Hex.: MEMOBUS addresses that you can use to change parameters over network communication are represented in hexadecimal numbers.

| No. (Hex.)      | Name                            | Description   | Default (Range) |
|-----------------|---------------------------------|---|-----------------|
| b1-01<br>(0180) | Frequency Reference Selection 1 | <p>Selects the input method for frequency reference.</p> <p>0 : Keypad<br/>1 : Analog Input<br/>2 : Memobus/Modbus Communications<br/>3 : Option PCB<br/>4 : Pulse Train Input</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Set <math>b1-02 = 3</math> [Run Command Selection 1 = Option PCB] to use the master device and serial communications to start and stop the drive. Set <math>b1-01 = 3</math> to use the master device to control the frequency reference of the drive.</li> <li>The default setting is different for different drives. Refer to the instruction manual of your specific drive for more information.</li> </ul>  | 1<br>(0 - 4)    |
| b1-02<br>(0181) | Run Command Selection 1         | <p>Selects the input method for the Run command.</p> <p>0 : Keypad<br/>1 : Digital Input<br/>2 : Memobus/Modbus Communications<br/>3 : Option PCB<br/>7 : AUTO Command + Term Run<br/>8 : AUTO Command + Serial Run<br/>9 : AUTO Command + Option Run</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Set <math>b1-02 = 3</math> to start and stop the drive with the master device using serial communications. Set <math>b1-01 = 3</math> [Frequency Reference Selection 1 = Option PCB] to use the master device to control the frequency reference of the drive.</li> <li>Settings 7 to 9 are available in HV600 software versions PRG: 1011 and later.</li> </ul>   | 1<br>(0 - 9)    |
| F6-01<br>(03A2) | Communication Error Selection   | <p>Selects drive response when the drive detects a <i>bUS</i> [Option Communication Error] error during communications with the option.</p> <p>0 : Ramp to Stop<br/>1 : Coast to Stop<br/>2 : Fast Stop (Use C1-09)<br/>3 : Alarm Only<br/>4 : Alarm - Run at d1-04<br/>5 : Alarm - Ramp Stop</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>When you set this parameter to 3 or 4, the drive will continue operation after it detects a fault. Separately prepare safety protection equipment and systems, for example fast-stop switches.</li> <li>Refer to the drive manual to know if settings 4 and 5 are available. Settings 4 and 5 are available in A1000 software versions PRG: 1021 and later.</li> </ul> | 1<br>(0 - 5)    |

## 7 Basic Operation

| No. (Hex.)   | Name                             | Description   | Default (Range) |
|--------------|----------------------------------|---|-----------------|
|              |                                  | <ul style="list-style-type: none"> <li>The setting range for 1000-Series drives is different for different software versions. Refer to the Peripheral Devices &amp; Options section of the drive instruction manual for more information.</li> </ul>  |                 |
| F6-02 (03A3) | Comm External Fault (EF0) Detect | Selects the conditions at which <i>EF0 [Option Card External Fault]</i> is detected.<br>0 : Always Detected<br>1 : Detected during RUN Only   | 0 (0, 1)        |
| F6-03 (03A4) | Comm External Fault (EF0) Select | Selects the operation of the drive when <i>EF0 [Option Card External Fault]</i> is detected.<br>0 : Ramp to Stop<br>1 : Coast to Stop<br>2 : Fast Stop (Use C1-09)<br>3 : Alarm Only<br><b>Note:</b><br>When you set this parameter to 3, the drive will continue operation after it detects a fault. Separately prepare safety protection equipment and systems, for example fast stop switches.   | 1 (0 - 3)       |
| F6-06 (03A7) | Torque Reference/Limit by Comm   | Sets the function that enables and disables the torque reference and torque limit received from the communication option.<br>0 : Disabled<br>1 : Enabled<br><b>Note:</b> <ul style="list-style-type: none"> <li>Control method availability of this parameter is different for different product series.               <ul style="list-style-type: none"> <li>–1000-Series<br/>                   Parameter is available in <i>A1-02 = 3, 6, 7 [Control Method Selection = Closed Loop Vector, PM Advanced Open Loop Vector, PM Closed Loop Vector]</i>.<br/>                   When you enable this parameter, <i>d5-01 [Torque Control Selection]</i> sets the drive to read the value as the Torque Limit value or the Torque Reference value.<br/> <i>d5-01 = 0</i>: Torque Limit<br/> <i>d5-01 = 1</i>: Torque Reference<br/>                   When <i>A1-02 = 6 [Control Method Selection = PM Advanced Open Loop Vector]</i>, the drive reads this value as the Torque Limit.</li> <li>–GA700, GA800<br/>                   Parameter is available in <i>A1-02 = 2, 3, 4, 6, 7, 8 [Control Method Selection = Open Loop Vector, Closed Loop Vector, Advanced Open Loop Vector, PM Advanced Open Loop Vector, PM Closed Loop Vector, EZ Vector Control]</i>.<br/>                   When you enable this parameter, <i>d5-01 [Torque Control Selection]</i> sets the drive to read the value as the Torque Limit value or the Torque Reference value.<br/> <i>d5-01 = 0</i>: Torque Limit<br/> <i>d5-01 = 1</i>: Torque Reference<br/>                   When <i>A1-02 = 2, 8 [Control Method Selection = Open Loop Vector, EZ Vector Control]</i>, the drive reads this value as the Torque Limit.</li> <li>–HV600, FP605<br/>                   Parameter is available in <i>A1-02 = 8 [Control Method Selection = EZ Vector Control]</i>.<br/>                   When <i>A1-02 = 8 [Method Selection = EZ Vector Control]</i>, the drive reads this value as the Torque Limit.</li> </ul> </li> <li>If the PLC does not supply a torque reference or torque limit when <i>F6-06 = 1 [Torque Reference/Limit by Comm = Enabled]</i>, the motor cannot rotate.</li> </ul> | 0 (0, 1)        |
| F6-07 (03A8) | Multi-Step Ref @ NetRef/ComRef   | 0 : MultiStep References Disabled<br>1 : MultiStep References Enabled   | 0 (0, 1)        |
| F6-08 (036A) | Comm Parameter Reset @Initialize | Selects whether communication-related parameters <i>F6-xx</i> and <i>F7-xx</i> are set back to original default values when you use parameter <i>A1-03 [Initialize Parameters]</i> to initialize the drive.<br>0 : No Reset - Parameters Retained<br>1 : Reset - Back to Factory Default<br><b>Note:</b><br>When you set <i>F6-08</i> to 1 and you then use <i>A1-03</i> to initialize the drive, the drive will not change this setting value.   | 0 (0, 1)        |

## 7 Basic Operation

### ◆ Run Command and Frequency Reference Selection

The keypad, external terminals, or network communication send Run commands and frequency references to the drive. Only one method is active at a time.

Drive parameter settings determine the enabled method.

The default drive parameter settings use external terminals for Run commands and frequency references.

### ■ Selecting the Reference

#### Selecting by Drive Parameters

Change *b1-01 [Frequency Reference Selection 1]*, and *b1-02 [Run Command Selection 1]* as shown below to select the Run command and frequency reference.

| Parameter                               | Operator | External Terminals | MEMOBUS | LonWorks (Option) |
|---|----------|--------------------|---------|-------------------|
| b1-01 [Frequency Reference Selection 1] | 0        | 1 (Default)        | 2       | 3                 |
| b1-02 [Run Command Selection 1]         | 0        | 1 (Default)        | 2       | 3                 |

### Selecting from the Network (1)

Set the nciOpMode variable from 0 to 3 (default: 0) to select the Run command and frequency reference. Parameter settings do not have an effect.

| nciOpMode Set Value | 0 (Default)         | 1                   | 2                   | 3        |
|---------------------|---------------------|---------------------|---------------------|----------|
| Frequency Reference | Determined by b1-01 | LonWorks            | Determined by b1-01 | LonWorks |
| Run Command         | Determined by b1-02 | Determined by b1-02 | LonWorks            | LonWorks |

### Selecting from the Network (2)

Use the nviWriteParam and nviWriteParamVal variables to change *b1-01* and *b1-02* to select the Run command and frequency reference.

To change the frequency reference from external terminals to communications:

1. Set 0180 (Hex.) (the *b1-01* register number) for nviWriteParam.
2. Set 3 (reference Option PCB) for nviWriteParamVal.
3. When you change the setting correctly, it will set 3 (the data written in step 2 above).
4. If you cannot change the setting correctly, it will set an error code in nvoErrCode.

### Selecting from Control Circuit Terminals (S1 to S8)

**Note:**

This function is not available with HV600.

Drive control circuit terminals S1 to S8 set the Run command and frequency reference selections.

1. Set *b1-01* [Frequency Reference Selection 1] to 0 [Keypad] or 1 [Analog Input].
2. Set *b1-02* [Run Command Selection 1] to 0 [Keypad] or 1 [Digital Input].
3. Set any of *H1-01* to *H1-08* [Multi-function Digital Input Terminal S1 to S8 Function Selection] to 2 [External reference 1/2 selection].

| Terminal Status | Frequency Reference and Run Command Selection                                      |
|-----------------|--|
| OFF             | Drive (Determined by b1-01 and b1-02.)   |
| ON              | Option (SI-W3) (Frequency reference and Run command from the network are enabled.) |

## 8 Network Variables

### ◆ Drive and Network Variables

Figure 8.1 outlines the relationship between drive and network variables.




Figure 8.1 Drive and Network Variables

◆ Node Objects

■ Object Requests

Iput: FSNVT\_obj\_request nviRequest

Requests the status for each object in a node.

| Member Name | Description      |             |
|-------------|------------------|-------------|
| object_id   | Object ID number |             |
|             | 0                | Entire node |
|             | 1                | VSD         |
|             | 2                | logic [0]   |
|             | 3                | logic [1]   |
|             | 4                | logic [2]   |
|             | 5                | logic [3]   |
|             | 6                | logic [4]   |
|             | 7                | logic [5]   |
|             | 8                | logic [6]   |
|             | 9                | logic [7]   |
|             | 10               | Analog [0]  |
|             | 11               | Analog [1]  |
| 12          | Analog [2]       |             |

| Member Name | Description |               |              |
|-------------|-------------|---------------|--------------|
|             | 13          | Analog [3]    |              |
|             | 14          | Analog [4]    |              |
|             | 15          | Analog [5]    |              |
|             | 16          | Analog [6]    |              |
|             | 17          | Analog [7]    |              |
|             | 18          | Analog [8]    |              |
|             | 19          | Analog [9]    |              |
|             | 20          | Select [0]    |              |
|             | 21          | Select [1]    |              |
|             | 22          | Select [2]    |              |
|             | 23          | Select [3]    |              |
|             | 24          | Select [4]    |              |
|             | 25          | Select [5]    |              |
|             | 26          | Select [6]    |              |
|             | 27          | Select [7]    |              |
|             | 28          | Compare [0]   |              |
|             | 29          | Compare [1]   |              |
|             | 30          | Compare [2]   |              |
|             | 31          | Compare [3]   |              |
|             | 32          | Compare [4]   |              |
|             | 33          | Compare [5]   |              |
|             | 34          | Compare [6]   |              |
|             | 35          | Compare [7]   |              |
|             | 36          | Stepout [0]   |              |
|             | 37          | Dlytimer [0]  |              |
|             | 38          | Dlytimer [1]  |              |
|             | 39          | Deviation [0] |              |
|             | 40          | Pidmodule [0] |              |
|             | 41          | Pidmodule [1] |              |
|             | 42          | Pidmodule [2] |              |
|             | 43          | Pidmodule [3] |              |
|             | 44          | Constout [0]  |              |
|             | 45          | Constout [1]  |              |
|             | object_id   | 46            | Constout [2] |
|             |             | 47            | Constout [3] |
|             |             | 48            | Constout [4] |
|             |             | 49            | Constout [5] |
|             |             | 50            | Convtype [0] |
|             |             | 51            | Convtype [1] |
|             |             | 52            | Convtype [2] |
|             |             | 53            | Convtype [3] |
|             |             | 54            | Savedata [0] |
|             |             | 55            | Savedata [1] |
|             |             | 56            | Savedata [2] |
|             |             | 57            | Savedata [3] |
| Other       | invalid_id  |               |              |

| Member Name    | Description |  |  |
|----------------|-------------|--|--|
| object_request | 0           | RQ_NORMAL  | Enables the object.                                |
|                | 1           | RQ_DISABLED  | Disable the object.                                |
|                | 2           | RQ_UPDATE_STATUS                                   | Not supported. (Normal response)                   |
|                | 3           | RQ_SELF_TEST                                       | Not supported. (Normal response)                   |
|                | 4           | RQ_UPDATE_ALARM                                    | Not supported. (Normal response)                   |
|                | 5           | RQ_REPORT_MASK                                     | Not supported. (Returns message: invalid_request.) |
|                | 6           | RQ_OVERRIDE  | Not supported. (Returns message: invalid_request.) |
|                | 7           | RQ_ENABLE  | Enables the object.                                |
|                | 8           | RQ_RMV_OVERRIDE                                    | Not supported. (Returns message: invalid_request.) |
|                | 9           | RQ_CLEAR_STATUS                                    | Not supported. (Returns message: invalid_request.) |
|                | 10          | RQ_CLEAR_ALARM                                     | Not supported. (Returns message: invalid_request.) |
|                | 11          | RQ_ALARM_NOTIFY_ENABLED                            | Not supported. (Returns message: invalid_request.) |
|                | 12          | RQ_ALARM_NOTIFY_DISABLED                           | Not supported. (Returns message: invalid_request.) |
|                | 13          | RQ_MANUAL_CTRL                                     | Not supported. (Returns message: invalid_request.) |
|                | 14          | RQ_REMOTE_CTRL                                     | Not supported. (Returns message: invalid_request.) |
|                | 15          | RQ_PROGRAM   | Not supported. (Returns message: invalid_request.) |
| 0xff           | RQ_NUL      | Not supported. (Returns message: invalid_request.) |  |

■ Object Status

Output: FSNVT\_obj\_status nvoStatus

Shows the status of objects in a node.

| Member Name | Description                             |  |
|-------------|---|--|
| object_id   | Object ID (refer to the object request) |  |
| bit 31      | invalid_id                              | Turns ON if the object_id specified by nviRequest is invalid.  |
| bit 30      | invalid_request                         | Turns ON if the object_request specified by nviRequest is invalid.                                     |
| bit 29      | disabled                                | Indicates whether or not a given object is enabled for operation. Turns ON when an object is disabled. |
| bit 28      | out_of_limits                           | Not supported. (Always 0)  |
| bit 27      | open_circuit                            | Not supported. (Always 0)  |
| bit 26      | out_of_service                          | Not supported. (Always 0)  |
| bit 25      | mechanical_fault                        | Not supported. (Always 0)  |
| bit 24      | feedback_failure                        | Not supported. (Always 0)  |
| bit 23      | over_range                              | Not supported. (Always 0)  |
| bit 22      | under_range                             | Not supported. (Always 0)  |
| bit 21      | electrical_fault                        | Not supported. (Always 0)  |
| bit 20      | unable_to_measure                       | Not supported. (Always 0)  |
| bit 19      | comm_failure                            | Not supported. (Always 0)  |
| bit 18      | fail_self_test                          | Not supported. (Always 0)  |
| bit 17      | self_test_in_progress                   | Not supported. (Always 0)  |
| bit 16      | locked_out                              | Not supported. (Always 0)  |
| bit 15      | manual_control                          | Not supported. (Always 0)  |
| bit 14      | in_alarm                                | Not supported. (Always 0)  |
| bit 13      | in_override                             | Not supported. (Always 0)  |
| bit 12      | report_mask                             | Not supported. (Always 0)  |
| bit 11      | programming_mode                        | Not supported. (Always 0)  |
| bit 10      | programming_fail                        | Not supported. (Always 0)  |

| Member Name | Description           |                           |
|-------------|-----------------------|---------------------------|
| bit 9       | alarm_notify_disabled | Not supported. (Always 0) |
| bit 8 to 0  | reserved              | Always 0                  |

## ◆ VSD Input Network Variables

| Name             | Variable Type    | Description                    |
|------------------|------------------|--------------------------------|
| nviDrvSpeedStpt  | SNVT_switch      | Drive Speed Setpoint           |
| nviInvSetFreq    | SNVT_freq_hz     | Drive Frequency Reference (Hz) |
| nviDrvSpeedRef   | SNVT_lev_percent | Drive Speed SetFreq (%)        |
| nviRunCommand    | SNVT_switch      | Drive Run Reference            |
| nviOpCommands    | SNVT_state       | Drive Operation Commands       |
| nviDrvSpeedScale | SNVT_lev_percent | Drive Speed Setpoint Scaling   |
| nviEmergOverride | SNVT_hvac_emerg  | Drive Emergency                |
| nviFltRstCommand | SNVT_switch      | Drive Speed Setpoint Scaling   |
| nviDrvEnergyClr  | SNVT_switch      | Drive Speed Setpoint Scaling   |
| nviReadParamNum  | SNVT_count       | Drive Parameter Read           |
| nviWriteParamNum | SNVT_count       | Drive Parameter Write          |
| nviWriteParamVal | SNVT_count_inc   | Drive Parameter Write Data     |

### ■ Drive Speed Setpoint (Drive Speed Operation Command)

|   |   |
|---|---|
| Input   | SNVT_switch nviDrvSpeedStpt   |
| Default   | state = FF; value = 0<br>Frequency reference = nviDrvSpeedStpt (%) × nviDrvSpeedScale (%) × nciNmIFreq (Hz)<br><b>Note:</b><br>When you set values greater than the maximum output frequency and less than 400 Hz, operation is executed at the maximum output frequency.<br>Values greater than 400 Hz are not set in the drive. |
| Related network variables, configuration properties | nciRcvHrtBt   |

This network variable sets drive Run/Stop commands and frequency references.

| State   | Value      | Command              |
|---------|------------|----------------------|
| 0       | NA         | Drive stop           |
| 1       | 0.0        | Zero-speed operation |
| 1       | 1 to 200   | 0.5 to 100.0%        |
| 1       | 201 to 255 | 100.0%               |
| FF (-1) | NA         | Disable              |

### ■ Drive Frequency Reference (Hz) (Drive Frequency Reference)

|   |  |
|---|--|
| Input   | SNVT_freq_hz nviInvSetFreq   |
| Setting range                                       | 0.0 - 6,553.5 Hz (Effective range: 0.0 - 400.0 Hz <i>*1</i> )  |
| Default   | nciInvSetFreq set value<br>The maximum output frequency and the upper limit frequency set in the drive limit the frequency reference values.<br>Frequency reference = nviInvSetFreq (Hz) |
| Related network variables, configuration properties | nciRcvHrtBt  |

\*1 Effective range is 0.0 - 240.0 Hz for Z1000.

This network variable sets drive frequency reference values in Hz.

#### Note:

When you set values greater than the maximum output frequency and less than 400 Hz *Drive Frequency Reference (Hz) (Drive Frequency Reference) on page 35*, operation is executed at the maximum output frequency. Values greater than 400 Hz *Drive Frequency Reference (Hz) (Drive Frequency Reference) on page 35* are not set in the drive.

\*1 When you use Z1000, set values greater than the maximum output frequency and less than 240 Hz.

After you turn ON the power, “CALL” is shown on the operator until it receives data.

When you set a receive heartbeat time, if no data is received in that time period, a communications error is generated and “BUS” is shown on the operator.

**■ Drive Speed SetFreq (%) (Drive Speed Reference)**

|   |   |
|---|---|
| Input   | SNVT_lev_percent nviDrvSpeedRef   |
| Setting range                                       | -163.840 - 163.835% (Effective range: 0.0 - 400.0 Hz <i>*1</i> )  |
| Default   | nciDrvSpeedRef set value<br>Speed reference value = nviDrvSpeedRef (%) × nviDrvSpeedScale (%) × nciNmlFreq (Hz) |
| Related network variables, configuration properties | nciRcvHrtBt   |

\*1 Effective range is 0.0 - 240.0 Hz for Z1000.

This network variable sets drive speed reference values in percentages.

**Note:**

When you set values greater than the maximum output frequency and less than 400 Hz, operation is executed at the maximum output frequency. Values greater than 400 Hz are not set in the drive.

\*1 When you use Z1000, set values greater than the maximum output frequency and less than 240 Hz.

After you turn ON the power, “CALL” is shown on the operator until it receives data.

When you set a receive heartbeat time, if no data is received in that time period, a communications error is generated and “BUS” is shown on the operator.

**■ Drive Run Reference (Drive Run Reference)**

|   |  |
|---|--|
| Input   | SNVT_switch nviRunCommand  |
| Default   | state = FF; value = 0<br>Speed reference value = nviDrvSpeedRef (%) × nviDrvSpeedScale (%) × nciNmlFreq (Hz) |
| Related network variables, configuration properties | nciRcvHrtBt  |

This network variable sets drive Run and Stop commands.

| State        | Value | Command    |
|--------------|-------|------------|
| 0            | NA    | Drive stop |
| 1            | NA    | Drive run  |
| FF (Default) | NA    | Drive stop |

After you turn ON the power, “CALL” is shown on the operator until it receives data.


When you set a receive heartbeat time, if no data is received in that time period, a communications error is generated and “BUS” is shown on the operator.

**■ Drive Operation Commands (Drive Control Commands)**

|         |                          |
|---------|--------------------------|
| Input   | SNVT_state nviOpCommands |
| Default | 0000 0000 0000 0000      |

These network variables control operations, for example running and stopping the drive.





There is a logical OR relationship between commands using these variables and other Run command-related network variables and multi-function control terminals.

### ■ Drive Speed Setpoint Scaling (Drive Speed Scaling)

|   |   |
|---|---|
| Input   | SNVT_lev_percent nviDrvSpeedScale   |
| Setting range                                       | -163.840% - 163.830% (0.005%)<br>163.835% is taken as 100%.<br>Frequency reference = nviDrvSpeedStpt (or nviDrvspeedfref) × nviDrvSpeedScale × nciNmIfreq |
| Default   | nciDrvSpeedScale set value  |
| Related network variables, configuration properties | nciRcvHrtBt   |

This network variable adjusts the motor rotation direction and speed.

### ■ Drive Emergency (Drive Emergency Stop)

|            |  |
|------------|--|
| Input      | SNVT_hvac_emerg nviEmergOverride                             |
| Data range | 0: Emergency stop clear<br>4: Emergency stop<br>FF: Disabled |
| Default    | FF   |

This network variable does drive emergency stops from the network. When the drive does an emergency stop, *EFF* is shown on the drive.

### ■ Drive Fault Reset Command (Drive Error Reset)

|            |   |
|------------|---|
| Input      | SNVT_switch nviFltRstCommand  |
| Data range | value *** NA, state ***-1,0,1   |
| Default    | value *** 0, state *** -<br>Errors are cleared in state1, and not in 0 or -1. |

This network variable does a reset from the network when a drive error occurs.

### ■ Drive Energy Clear (Cumulative Power Value Clear)

|   |  |
|---|--|
| Input   | SNVT_switch nviDrvEnergyClr  |
| Data range  | value *** NA, state *** -1 (FF (Hex.)),0,1   |
| Default   | value *** 0, state *** -1 (FF (Hex.))<br>Accumulated power values are cleared in state1, and not in 0 or -1 (FF (Hex.)). |
| Related network variables, configuration properties | nvoDrvEnergy, nciDrvEngylim, nciEngyMinDelta   |

This network variable clears accumulated power values.

### ■ Drive Parameter Read (Drive Constant Read Request)

|   |   |
|---|---|
| Input   | SNVT_count nviReadParamNum  |
| Data range  | 0000 to FFFFH   |
| Default   | 0<br>For register numbers, refer to the Drive instruction manual. |
| Related network variables, configuration properties | nviWriteParamNum, nvoReadParamVal, nvoParamErr                    |

This network variable is used to read drive constants.

Set the register number of the constant that is to be read. After the drive receives the data, it sets the data for that register number in nvoReadParamVal to be output.

### ■ Drive Parameter Write (Drive Constant Write Request)

|   |  |
|---|--|
| Input   | SNVT_count nviWriteParamNum                    |
| Data range  | 0000 - FFFF (Hex.)                             |
| Default   | 0  |
| Related network variables, configuration properties | nviReadParamNum, nvoWriteParamVal, nvoParamErr |

This network variable writes drive constants.

Set the register number of the constant that is to be written. Then set the changed data in nviWriteParamVal. After the drive receives the data, it sets the data for that register number in nvoReadParamVal to be output.

**Note:**

If no data is set in nviWriteParamVal in 30 seconds after this network variable has been set, an error code is stored in nvoParamErr and the data set in nviWriteParamNum is changed to 0.

### ■ Drive Parameter Write Data (Drive Constant Write Data)

|   |  |
|---|--|
| Input   | SNVT_count_inc nviWriteParamVal                |
| Setting range                                       | -32,768 to 32,767                              |
| Default   | 0  |
| Related network variables, configuration properties | nviReadParamNum, nvoWriteParamNum, nvoParamErr |

This network variable writes drive constants.

Set the constant data that is to be changed. After the drive receives the new constant data, it makes the change and then sets the changed constant data in nvoReadParamVal to be output.

### Run Command and Frequency Reference Combinations and Priority

The drive provides multiple network variables for Run commands and frequency references, but you can only use them one at a time.

This section describes various combinations of network variables and their orders of priority.

- Network Variable Combinations for Run Commands and Frequency References

|                             | Combination 1 | Combination 2           | Combination 3   |
|-----------------------------|---------------|-------------------------|-----------------|
| Frequency (speed) reference | nviInvSetFreq | nviDrvSpeedStpt (value) | nviDrvSpeedFref |
| Run command                 | nviRunCommand | nviDrvSpeedStpt (state) | nviRunCommand   |

- Order of priority  
Combination 1 > Combination 2 > Combination 3 (Default: All disabled)

- Network Variable

Do not execute binding for these network variables.

- Combination 1 Set the network variables as follows:

nviDrvSpeedStpt (state) = FF

nviDrvSpeedRef = 7FFF

Do not execute binding for these network variables.

- Combination 2 Set the network variables as follows:

nviInvSetFreq = 7FFF (default)

nviDrvSpeedRef = 7FFF (default)

nviRunCommand (state) = FF (default)

Do not execute binding for these network variables.

- Combination 3 Set the network variables as follows:

nviDrvSpeedStpt (state) = FF

nviInvSetFreq = 7FFF

Do not execute binding for these network variables.

## ◆ VSD Output Network Variables

| Name            | Variable Type    | Description                    |
|-----------------|------------------|--------------------------------|
| nvoDrvSpeed     | SNVT_lev_percent | Drive Speed Feedback (%)       |
| nvoRunStatus    | SNVT_switch      | Drive Run Status               |
| nvoInvOutFreq   | SNVT_freq_hz     | Drive Output Frequency         |
| nvoDrvCurrent   | SNVT_amp         | Drive Output Current           |
| nvoDrvVolt      | SNVT_volt        | Drive Output Voltage           |
| nvoDCBUS        | SNVT_volt        | Drive DC Voltage               |
| nvoDrvPwr       | SNVT_power_kilo  | Drive Output Power             |
| nvoDrvEnergy    | SNVT_elec_kwh_1  | Cumulative Drive Energy        |
| nvoDrvRunHours  | SNVT_time_hour   | Drive Total Running Hours      |
| nvoInvFault     | SNVT_switch      | Drive Fault Status             |
| nvoInvAlarm     | SNVT_switch      | Drive Alarm Status             |
| nvoReadParamVal | SNVT_count_inc   | Drive Parameter Read Data      |
| nvoParamErr     | SNVT_count       | Drive Parameter Error          |
| nvoSpdStptFb    | SNVT_lev_percent | Drive Speed Setpoint Feedback1 |
| nvoSpdCmd       | SNVT_lev_percent | Drive Speed Setpoint Feedback2 |
| nvoDrvStatus    | SNVT_state       | Drive Status                   |
| nvoFltstatus1   | SNVT_state       | Drive Fault Status1            |
| nvoFltstatus2   | SNVT_state       | Drive Fault Status2            |
| nvoFltstatus3   | SNVT_state       | Drive Fault Status3            |
| nvoEmergStatus  | SNVT_hvac_emerg  | Drive Emerg Status             |

### ■ Drive Speed Feedback (%) (Drive Speed Monitoring)

|              |                               |
|--------------|-------------------------------|
| Output       | SNVT_lev_percent nvoDrvSpeed  |
| Data range   | -163.840% - 163.830% (0.005%) |
| Service type | Default: Authentication type  |

This network variable outputs the drive output frequency as a percentage of the standard motor frequency.

| Output Timing   | Explanation  |
|-----------------|--|
| Event driven    | Sent to network when data changes.   |
| nciSndHrtBt     | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm     | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |
| nciFreqMinDelta | Output when the frequency is outside of the recently changed frequency range.  |

### ■ Drive Run Status (Drive Run Monitoring)

|               |                              |
|---------------|------------------------------|
| Output        | SNVT_switch nvoRunStatus     |
| Default       | State = 0                    |
| Service type  | Default: Authentication type |
| Output timing | Event driven, nciSndHrtBt    |

This network variable monitors drive Run and Stop status.

| State        | Value | Command       |
|--------------|-------|---------------|
| 0            | NA    | Drive stopped |
| 1            | NA    | Drive running |
| FF (Default) | NA    | None          |

| Output Timing | Explanation   |
|---------------|---|
| Event driven  | Sent to network when data is changed.                                       |
| nciSndHrtBt   | When you set a send heartbeat time, the data is output in that time period. |

### ■ Drive Output Frequency (Drive Output Frequency Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_freq_hz nvoInvOutFreq   |
| Data range   | 0 to 6553.4Hz (0.1Hz)        |
| Service type | Default: Authentication type |

This network variable outputs drive output frequency.

| Output Timing    | Explanation  |
|------------------|--|
| Event driven     | Sent to network when data is changed.  |
| nciSndHrtBt      | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm      | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |
| nciFrefMinDelta2 | Output when the frequency is outside of the recently changed frequency range.  |

### ■ Drive Output Current (Output Current Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_amp nvoDrvCurrent       |
| Data range   | 0 to 3,276.6 A               |
| Service type | Default: Authentication type |

This network variable outputs drive output current.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Sent to network when data is changed.  |
| nciSndHrtBt   | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm   | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |

### ■ Drive Output Voltage (Output Voltage Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_volt nvoDrvVolt         |
| Data range   | 0 to 3276.7 V (Unit: 0.1 V)  |
| Service type | Default: Authentication type |

This network variable outputs drive output voltage.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Sent to network when data is changed.  |
| nciSndHrtBt   | When you set a send heartbeat time, the data is output in that time period.  |
| ciMinOutTm    | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |

### ■ Drive DC Voltage (DC Bus Voltage Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_volt nvoDCBus           |
| Data range   | 0 to 3276.7 V (Unit: 0.1 V)  |
| Service type | Default: Authentication type |

This network variable outputs DC bus voltage.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Sent to network when data is changed.  |
| nciSndHrtBt   | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm   | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |

### ■ Drive Output Power (Output Power Monitoring)

|              |  |
|--------------|--|
| Output       | network output SNVT_power_kilo nvoDrvPwr |
| Data range   | 0 - 6,553.4 kW (Unit: 0.1 kW)            |
| Service type | Default: Authentication type             |

This network variable outputs drive output power.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Sent to network when data is changed.  |
| nciSndHrtBt   | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm   | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |

### ■ Cumulative Drive Energy (Cumulative Power Monitoring)

|   |  |
|---|--|
| Output  | SNVT_elec_kwh_1 nvoDrvEnergy   |
| Cumulative period                                   | 100 ms ± 10% (Varies slightly depending on the amount of data sent and received in the network.) |
| Data range  | 0 - 429496729.4 kwh (Unit: 0.1 kwh)  |
| Service type  | Default: Authentication type   |
| Related network variables, configuration properties | nviDrvEnergyClr, nciDrvEngylimit, nciEngyMinDelta  |

This network variable outputs drive cumulative power.

Cumulative power value = Previous cumulative power value + [Present output power data × (Present output power value acquire time – Previous output power value acquire time)]

| Output Timing   | Explanation  |
|-----------------|--|
| Event driven    | Sent to network when data is changed.  |
| nciSndHrtBt     | When you set a send heartbeat time, the data is output in that time period.  |
| nciMinOutTm     | When you set a minimum output refresh time, data that is changed during the specified time period is not output until that time period is expired. |
| nciEngyMinDelta | Output when changed outside of fixed change range.   |

#### Note:

Do not use this monitoring for accounting systems because it calculates the charges for power.

### ■ Drive Total Running Hours (Total Running Hours Monitoring)

|              |  |
|--------------|--|
| Output       | SNVT_time_hour nvoDrvRunHours  |
| Data range   | 0 to 65,534 hours (Unit: 1 hour)<br><b>Note:</b><br>The data is invalid when set to FFFF = 65,535 hours. |
| Service type | Default: Authentication type   |

This network variable outputs the drive's accumulated running time.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Sent to the network when the data changes by more than 1 hour. |

### ■ Drive Fault Status (Drive Fault Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_switch nvoInvFault      |
| Default      | state = FF                   |
| Service type | Default: Authentication type |

This network variable is used to monitor drive fault status.

| State        | Value | Command   |
|--------------|-------|---|
| 0            | NA    | Drive normal (after fault cleared)                      |
| 1            | NA    | Drive fault occurring                                   |
| FF (Default) | NA    | Drive normal (from turning ON power until fault occurs) |

| Output Timing | Explanation                                       |
|---------------|---|
| Event driven  | Sent when fault occurs and when fault is cleared. |

### ■ Drive Alarm Status (Drive Alarm Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_switch nvoInvAlarm      |
| Default      | state = FF                   |
| Service type | Default: Authentication type |

This network variable monitors drive alarm status.

| State        | Value | Command   |
|--------------|-------|---|
| 0            | NA    | Drive normal (after alarm cleared)                      |
| 1            | NA    | Drive alarm occurring                                   |
| FF (Default) | NA    | Drive normal (from turning ON power until alarm occurs) |

| Output Timing | Explanation                                       |
|---------------|---|
| Event driven  | Sent when alarm occurs and when alarm is cleared. |

### ■ Drive Parameter Read Data (Drive Constant Read Data)

|   |   |
|---|---|
| Input   | SNVT_count_inc nvoReadParamVal                      |
| Data range  | -32,768 to 32,767                                   |
| Default   | 0   |
| Related network variables, configuration properties | nviReadParamNum, nviWriteParamNum, nviWriteParamVal |

This network variable sets and outputs data for constant numbers requested by nviReadParamNum.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | The constant data is sent after normal reception of nviReadParamNum. |

### ■ Drive Parameter Error (Drive Constant Access Error)

|   |   |
|---|---|
| Input   | SNVT_count nvoParamErr                              |
| Related network variables, configuration properties | nviReadParamNum, nviWriteParamNum, nviWriteParamVal |

This network variable sets an error code when inappropriate data is set for nviReadParamNum, nviWriteParamNum, or nviWriteParamVal, or when a drive constant access-related error occurs.

Table 8.1 Error Codes

| Error Code | Explanation   |
|------------|---|
| 0 (00H)    | Normal  |
| 2 (02H)    | Invalid register number <ul style="list-style-type: none"> <li>An attempt was made to access a non-existent register number.</li> </ul>   |
| 33 (21H)   | Data setting error <ul style="list-style-type: none"> <li>A simple upper limit or lower limit error has occurred in the control data or when writing constants.</li> <li>When writing constants, the constant setting was invalid.</li> </ul> |
| 34 (22H)   | Write mode error <ul style="list-style-type: none"> <li>An attempt was made to change a constant during operation.</li> <li>An attempt was made to write read-only data.</li> </ul>   |
| 35 (23H)   | Writing during <i>U<sub>v</sub></i> [Undervoltage] error <ul style="list-style-type: none"> <li>An attempt was made to change a constant during a <i>U<sub>v</sub></i> [Undervoltage] alarm.</li> </ul>                                       |

| Error Code | Explanation  |
|------------|--|
| 36 (24H)   | An attempt was made to change a constant while it was being processed at the drive.  |
| 255 (FFH)  | Command input time over <ul style="list-style-type: none"> <li>More than 30 seconds elapsed at the input interval for nvoWriteParamNum or nvoWriteParamVal.</li> </ul> |

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Constant data is sent after normal reception of nviReadParamNum. |

### ■ Drive Speed Setpoint Feedback 1 (Drive Speed Reference Monitor 1)

|              |                               |
|--------------|-------------------------------|
| Output       | SNVT_lev_percent nvoSpdStptFb |
| Default      | 0 to 163.830% (0.005%)        |
| Service type | Default: Authentication type  |

This network variable sets and outputs speed reference values from the network.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Constant data is sent after normal reception of nviReadParamNum. |

### ■ Drive Speed Setpoint Feedback 2 (Drive Speed Reference Monitor 2)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_lev_percent nvoSpdCmd   |
| Default      | 0 to 163.835% (0.005%)       |
| Service type | Default: Authentication type |

This network variable sets and outputs speed reference values that are set for the drive.

It outputs reference values from the places that have frequency reference rights (for example, external terminals, keypad, or communications).


Criteria is nciNmlFreq.

| Output Timing | Explanation  |
|---------------|--|
| Event driven  | Constant data is sent after normal reception of nviReadParamNum. |

### ■ Drive Status (Drive Status Monitoring)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_state nvoDrvStatus      |
| Service type | Default: Authentication type |

This network variable outputs drive status.




| Output Timing | Explanation                  |
|---------------|------------------------------|
| Event driven  | Sent when status is changed. |

### ■ Drive Fault Status 1 (Drive Fault Status Monitor 1)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_state nvoFltstatus1     |
| Service type | Default: Authentication type |

This network variable outputs drive fault status.




| Output Timing | Description                              |
|---------------|--|
| Event driven  | Sent when any of the above faults occur. |

### ■ Drive Fault Status 2 (Drive Fault Status Monitor 2)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_state nvoFltStatus2     |
| Service type | Default: Authentication type |

This network variable outputs drive fault status.






| Output Timing | Explanation                              |
|---------------|--|
| Event driven  | Sent when any of the above faults occur. |

### ■ Drive Fault Status 3 (Drive Fault Status Monitor 3)

|              |                              |
|--------------|------------------------------|
| Output       | SNVT_state nvoFltStatus3     |
| Service type | Default: Authentication type |

This network variable outputs drive fault status.



| Output Timing | Explanation                              |
|---------------|--|
| Event driven  | Sent when any of the above faults occur. |

### ■ Drive Emerg Status (Drive Emergency Stop Status)

|              |                                |
|--------------|--------------------------------|
| Output       | SNVT_hvac_emerg nvoEmergStatus |
| Default      | State = FF                     |
| Service type | Default: Authentication type   |

This network variable monitors drive Run and Stop status.

| Data         | Name           | Explanation    |
|--------------|----------------|----------------|
| 0            | EMERG_NORMAL   | Normal         |
| 4            | EMERG_SHUTDOWN | Emergency stop |
| FF (Default) | EMERG_NUL      | -              |

| Output Timing | Explanation                                    |
|---------------|--|
| Event driven  | Sent when any of the above major faults occur. |

## ◆ Setting Drive Constants from the Network


### ■ Reading Drive Constants

1. Set the register number of the drive constant that is to be read to `nviReadParamNum` in hexadecimal.
2. When the `nviReadParamNum` data is refreshed, the drive will set the data contents of the applicable drive constant in `nvoReadParamVal` for output.
3. If you set invalid data in `nviReadParamNum` because of, for example, a register number that is specified for a non-existent drive constant, it will set an error code in `nvoParamErr` for output.

Refer to [Drive Parameter Error \(Drive Constant Access Error\) on page 42](#) for more information.

- Example: Reading the Setting for *b1-01 [Frequency Reference Selection 1]*

- *b1-01 [Frequency Reference Selection 1]: 384 (180 (Hex.))*
- *b1-01 setting: 3 [Option PCB]*



Use the MEMOBUS register number listed on the drive instructions for the drive constant.

### ■ Writing Drive Constants

**Note:**

Make sure that you send data to `nviWriteParamNum` and `nviWriteParamVal` in the order described in steps 1 and 2 below. If the order is incorrect, the intended settings will not be correct.


1. Set the register number of the drive constant that is to be changed to `nviWriteParamNum` in hexadecimal.
2. Enter the settings in `nviWriteParamVal`.  
If the `nviWriteParamVal` data is not received in 30 seconds after the `nviWriteParamNum` data is received, the drive will discard the `nviWriteParamNum` data.
3. The drive will process the constant change when it receives `nviWriteParamNum` and `nviWriteParamVal`. The changed data is set in `nvoReadParamVal` for output when the change is completed normally.
4. If you cannot change settings because of, for example, a register number that is specified for a non-existent drive constant, it will set an error code in `nvoParamErr` for output.

Refer to [Drive Parameter Error \(Drive Constant Access Error\) on page 42](#) for more information.

- Example: Changing the *C1-01 [Acceleration Time 1] Setting*
  - *C1-01: 512 (200 (Hex.))*
  - *C1-01 setting: Changed from 10.0 s to 35.0 s.*

**Note:**

To set 35.0 s, set 350 with the decimal point omitted.



Refer to [Table 8.1](#) for error codes.

## 9 Configuration Properties

### ◆ Drive Related Network Configuration Properties

Table 9.1 Drive Configuration Properties

| Name             | Variable Type    | Description   |
|------------------|------------------|---|
| nciMaxSpeed      | SNVT_lev_percent | Maximum Motor Speed   |
| nciMinSpeed      | SNVT_lev_percent | Minimum Motor Speed   |
| nciSndHrtBt      | SNVT_time_sec    | Send Heartbeat Time   |
| nciNmlSpeed      | SNVT_rpm         | Nominal Motor Speed in RPM (Motor Rated Rotation Frequency) |
| nciNmlFreq       | SNVT_freq_hz     | Nominal Motor Frequency (Motor Rated Frequency)             |
| nciRampUpTm      | SNVT_time_sec    | Drive Ramp Up Time (Drive Acceleration Time)                |
| nciRampDownTm    | SNVT_time_sec    | Minimum Ramp Down Time (Minimum Deceleration Time)          |
| nciRcvHrtBt      | SNVT_time_sec    | Receive Heartbeat Time                                      |
| nciMinOutTm      | SNVT_time_sec    | Minimum Send Time   |
| nciLocation      | SNVT_str_asc     | Location Label  |
| nciPwupOutTm     | SNVT_time_sec    | Power delay Timer   |
| nciFreqMinDelta1 | SNVT_lev_percent | Output Frequency Monitor Minimum Change Range Setting 1     |
| nciFreqMinDelta2 | SNVT_freq_hz     | Output Frequency Monitor Minimum Change Range Setting 2     |
| nciDrvSpeedScale | SNVT_lev_percent | nviDrvSpeedScale Default                                    |
| nciInvSetFreq    | SNVT_freq_hz     | nviInvSetFreq Default                                       |
| nciDrvSpeedRef   | SNVT_lev_percent | nviDrvSpeedRef Default                                      |
| nciDrvEngylimit  | SNVT_elec_kwh_l  | Cumulative Power Monitor Upper Limit: nciDrvEngylimit       |
| nciEngyMinDelta  | SNVT_elec_kwh_l  | Cumulative Power Monitor Minimum Change Range Setting       |
| nciOpMode        | SNVT_count       | Reference Selection Mode                                    |
| nciDrvRunMode    | SNVT_switch      | Run Command Status Mode                                     |

### ■ Maximum Motor Speed

|                      |                              |
|----------------------|------------------------------|
| Network input config | SNVT_lev_percent nciMaxSpeed |
| Setting range        | 0.000 - 110.000%             |
| Default              | 100.000%                     |
| SCPT Reference       | SCPTmaxSetpoint (50)         |

Set the motor frequency reference upper limit with *E1-04 [Maximum Output Frequency]* taken as 100%.

This value will be saved in drive constant *d2-01 [Frequency Reference Upper Limit]*. It will not be saved during operation.

Set the minimum speed and the maximum speed as follows:

$$0 \leq \text{minimum speed} \leq \text{maximum speed} \leq 110.000$$

**■ Minimum Motor Speed**

|                      |                              |
|----------------------|------------------------------|
| Network input config | SNVT_lev_percent nciMinSpeed |
| Setting range        | 0.000 - 110.000%             |
| Default              | 0%                           |
| SCPT Reference       | SCPTminSetpoint (53)         |

Set the motor frequency reference lower limit with *E1-04 [Maximum Output Frequency]* taken as 100%. This value will be saved in drive constant *d2-02 [Frequency Reference Lower Limit]*. It will not be saved during operation.

Set the minimum speed and the maximum speed as follows:

$$0 \leq \text{minimum speed} \leq \text{maximum speed} \leq 110.000$$

**■ Send Heartbeat Time**

|                      |   |
|----------------------|---|
| Network input config | SNVT_time_sec nciSndHrtBt   |
| Setting range        | 0.0 - 6,553.5 s (0.1 s)<br><b>Note:</b><br>6,553.5 s is handled as 0 s. |
| Default              | 0 s (Invalid)   |
| SCPT Reference       | SCPTmaxSendTime (49)  |

Set the scheduled output time for the output network variable. When this setting is made, the monitor data is output in fixed cycles.

**■ Nominal Motor Speed in RPM (Motor Rated Rotation Frequency)**

|                      |   |
|----------------------|---|
| Network input config | SNVT_rpm nciNmISpeed                                |
| Setting range        | 0 - 65,534 min <sup>-1</sup> (1 min <sup>-1</sup> ) |
| Default              | 1800 min <sup>-1</sup>                              |
| SCPT Reference       | SCPTnomRPM (158)                                    |

Set the motor rated rotation frequency.

**■ Nominal Motor Frequency (Motor Rated Frequency)**

|                      |                         |
|----------------------|-------------------------|
| Network input config | SNVT_freq_hz nciNmIFreq |
| Setting range        | 0 - 100 Hz (1 Hz)       |
| Default              | 60 Hz                   |
| SCPT Reference       | SCPTnomFreq (159)       |

Set the motor rated frequency.

**■ Drive Ramp Up Time (Drive Acceleration Time)**

|                      |                           |
|----------------------|---------------------------|
| Network input config | SNVT_time_sec nciRampUpTm |
| Setting range        | 0.0 - 6,000.0 s (0.1 s)   |
| Default              | 10.0 s                    |
| SCPT Reference       | SCPTrampUpTm (160)        |

Set the motor ramp up time. This value is saved in drive constant *C1-01 [Acceleration Time 1]*.

**■ Minimum Ramp Down Time (Minimum Deceleration Time)**

|                      |                             |
|----------------------|-----------------------------|
| Network input config | SNVT_time_sec nciRampDownTm |
| Setting range        | 0.0 to 6000.0 s (0.1 s)     |
| Default              | 10.0 s                      |
| SCPT Reference       | SCPTrampDownTm (161).14     |

Set the motor ramp down time. This value is saved in drive constant *CI-02 [Deceleration Time 1]*.

### ■ Receive Heartbeat Time

|                      |  |
|----------------------|--|
| Network input config | SNVT_time_sec nciRcvHrtBt  |
| Setting range        | 0.0 to 6,553.4 s (0.1 s)<br>If the set value is 0, the drive will not detect communications error "bUS". |
| Default              | 0 s (Invalid)  |
| SCPT Reference       | SCPTmaxRcvTime (48)  |

Set the maximum reception interval for *nviDrvSpeedStpt*. A "bUS" communications error will be displayed if data is not received in this set time period.

### ■ Minimum Send Time

|                      |  |
|----------------------|--|
| Network input config | SNVT_time_sec nciMinOutTm  |
| Setting range        | 0.0 - 6,553.4 s (0.1 s)<br>When the set value is 0, monitor data output is event-driven. |
| Default              | 0.5 s  |
| SCPT Reference       | SCPTminSendTime (52)   |

Set the minimum output time for monitor data. The monitor data will be output after the set time is expired after a change to the data.

### ■ Location Label

|                      |                          |
|----------------------|--------------------------|
| Network input config | SNVT_str_ase nciLocation |
| Setting range        | 0 - 31 bytes             |
| Default              | \0 (Null)                |
| SCPT Reference       | SCPT_location (17)       |

You can set information about the physical position of a node separately from the neuron ID (6 bytes).

### ■ Power Delay Timer

|                      |                            |
|----------------------|----------------------------|
| Network input config | SNVT_time_sec nciPwUpOutTm |
| Setting range        | 0 - 65534 (1 s)            |
| Default              | FFFF (Invalid)             |
| SCPT Reference       | SCPT_Pwrupdelay (72)       |

Set the delay time from when the power is turned ON until network variable output is started.

### ■ Output Frequency Monitor Minimum Change Range Setting 1

|                      |  |
|----------------------|--|
| Network input config | SNVT_lev_percent nciFreqMinDelta1  |
| Setting range        | -163.840% - 163.830 (0.005%)<br>If the set value is 7FFF, it is set as invalid data. |
| Default              | 0%   |
| SCPT Reference       | SCPTdefScale (162)   |

Set the minimum output change range for *nvoDrvSpeed*.

Set the value for when the power is turned ON.

### ■ Output Frequency Monitor Minimum Change Range Setting 2

|                      |   |
|----------------------|---|
| Network input config | SNVT_freq_hz nciFreqMinDelta2   |
| Setting range        | 0.0 to 400.0 (Hz)<br>If the set value is 7FFF, it is set as invalid data. |
| Default              | 7FFF (Invalid)  |

Set the minimum output change range for *nvoInvOutFreq*.

■ **nviInvSetFreq Default**

|                      |   |
|----------------------|---|
| Network input config | SNVT_freq_hz nciInvSetFreq  |
| Setting range        | 0.0 - 6553.5 (Hz)<br>If the set value is FFFF, it is set as invalid data. |
| Default              | 3276.7 (7FFF)   |
| SCPT Reference       | 7FFF (Invalid)  |

Set the value for nviInvSetFreq for when the power is turned ON.

■ **nviInvSetFreq Default**

|                      |   |
|----------------------|---|
| Network input config | SNVT_freq_hz nciInvSetFreq  |
| Setting range        | 0.0 - 6553.5 (Hz)<br>If the set value is FFFF, it is set as invalid data. |
| Default              | 3276.7 (7FFF)   |
| SCPT Reference       | 7FFF (Invalid)  |

Set the value for nviInvSetFreq for when the power is turned ON.

■ **nviDrvSpeedRef Default**

|                      |   |
|----------------------|---|
| Network input config | SNVT_lev_percent nciDrvSpeedRef   |
| Setting range        | -163.840% to 163.835 (0.005%)<br>If the set value is 7FFF = +163.835%, it is set as invalid data. |
| Default              | 7FFF (Invalid)  |

Set the value for nviDrvSpeedRef for when the power is turned ON.

■ **Cumulative Power Monitor Upper Limit**

|                      |   |
|----------------------|---|
| Network input config | SNVT_elec_kwh_l nciDrvEngylimit   |
| Setting range        | -214,748,364.8 to 214,748,364.6 kwh   |
| Invalid value        | 0x7FFFFFFF (214,748,364.7)<br>If the set value is invalid, the nvoDrvEnergy value accumulates until the maximum value.<br>If the set value is for less than 0, it is treated as 0 and the cumulative power value does not accumulate. |
| Default              | 0x7FFFFFFF (214,748,364.7) (Invalid)  |

Set the cumulative power monitor (nvoDrvEnergy) upper limit. When the cumulative power monitor value exceeds this set value, the accumulation will restart from 0. (Example: When the set value is 1,000.0, the next number after 999.9 will be 0.)

■ **Cumulative Power Monitor Minimum Change Range Setting**

|                      |  |
|----------------------|--|
| Network input config | SNVT_elec_kwh_l nciEngyMinDelta  |
| Setting range        | -214,748,364.8 to 214,748,364.6 kwh  |
| Valid range          | 0.1 - 214,748,364.6 (No value greater than nvoDrvEngylimit can be set.)<br>If nciDrvEngylimit ≤ nciEngyMinDelta, the data will be ignored and the set value will not be changed. |
| Default              | 1.0 kwh  |

Set the minimum change range for the output from the cumulative power monitor (nvoDrvEnergy).

■ **Reference Selection Mode**

|                      |                      |
|----------------------|----------------------|
| Network input config | SNVT_count nciOpMode |
|----------------------|----------------------|

You can select and switch Run command and frequency reference rights from the network. The selection can be changed as shown below by setting nciOpMode (default: 0) from 0 to 3.


| nciOpMode Set Value        | 0 (Default)     | 1               | 2               | 3        |
|----------------------------|-----------------|-----------------|-----------------|----------|
| Reference selection        | b1-01 set value | LonWorks        | b1-01 set value | LonWorks |
| Operation method selection | b1-02 set value | b1-02 set value | LonWorks        | LonWorks |

## ■ Run Command Status Mode

|                      |                           |
|----------------------|---------------------------|
| Network input config | SNVT_switch nciDrvRunMode |
| Default              | State = 0 x FF            |

If the drive stops during operation for a reason other than a Stop command from the network, determine whether the Run command is to be forced OFF in the SI-W3 from communications or whether the Run command status is to be held as-is.

| State        | Value | Command     |
|--------------|-------|-------------|
| 0            | NA    | Status hold |
| 1            | NA    | OFF         |
| FF (Default) | NA    | Status hold |



## 10 Troubleshooting

### ◆ Drive-Side Error Codes

Drive-side error codes appear on the drive keypad. *Faults on page 51* lists causes of the errors and possible corrective actions. Refer to the drive Technical Manual for additional error codes that can appear on the drive keypad.

### ■ Faults

Both *bUS [Option Communication Error]* and *EF0 [Option Card External Fault]* can appear as a fault. When a fault occurs, the digital characters shown on the keypad does not flash but stay lit. The keypad ALM LED also stays lit. When an alarm occurs, the ALM LED flashes.

#### Note:

Normally, *o2-24 = 2 [LED Light Function Selection = Keypad LED Light Disable]* is set as a factory default, so the ALM LED does not light.

If communication stops while the drive is running, use these questions as a guide to help remove the fault:

- Is the option properly installed?

- Is the communication line properly connected to the option? Is it loose?
- Did a momentary power loss interrupt communications?

| Code           | Name                                 | Causes   | Possible Solutions  |
|----------------|--------------------------------------|--|---|
| bUS            | Option Communication Error           | The drive did not receive a signal from the controller.                                | <ul style="list-style-type: none"> <li>• Check for wiring errors.</li> <li>• Correct the wiring.</li> </ul>   |
|                |                                      | The communications cable wiring is incorrect.  |   |
|                |                                      | An existing short circuit or communications disconnection                              | Check disconnected cables and short circuits and repair as needed   |
|                |                                      | A data error occurred due to electric interference                                     | <ul style="list-style-type: none"> <li>• Prevent noise in the control circuit, main circuit, and ground wiring.</li> <li>• If you identify a magnetic contactor as a source of noise, install a surge absorber to the contactor coil.</li> <li>• Use only recommended cables or other shielded line. Ground the shield on the controller side or the drive input power side.</li> <li>• Separate all communication wiring from drive power lines. Install an EMC noise filter to the drive power supply input.</li> <li>• Counteract noise in the master controller (PLC).</li> </ul> |
|                |                                      | Option is damaged  | If there are no problems with the wiring and the error continues to occur, replace the option.  |
|                |                                      | Connection Time-out  | The option Receive Heartbeat timer timed out. <ul style="list-style-type: none"> <li>• Make sure that Receive Heartbeat time is set properly.</li> <li>• Check the option connection and communication signal.</li> </ul>   |
| EF0            | Option Card External Fault           | The option received an external fault from the controller.                             | <ol style="list-style-type: none"> <li>1. Find the device that caused the external fault and remove the cause.</li> <li>2. Clear the external fault input from the controller.</li> </ol>   |
|                |                                      | A programming error occurred on the controller side.                                   | Examine the operation of the controller program.  |
| oFA00          | Option Not Compatible with Port      | The option connected to connector CN5-A is not compatible.                             | Connect the option to the correct connector. <ul style="list-style-type: none"> <li>• Use connector CN5-A when you connect the option. To use other options, refer to those option manuals.</li> </ul>  |
| oFA01          | Option Card Fault (CN5-A)            | The option connected to option port CN5-A was changed during run.                      | <ol style="list-style-type: none"> <li>1. De-energize the drive.</li> <li>2. Connect the option to the correct option port.</li> </ol>  |
| oFA03, oFA04   | Option Card Error (CN5-A)            | A fault occurred in the option.  | <ol style="list-style-type: none"> <li>1. De-energize the drive.</li> <li>2. Make sure that the option is correctly connected to the connector.</li> <li>3. If the problem continues, replace the option.</li> </ol>  |
| oFA30 to oFA43 | Option Card Connection Error (CN5-A) | A fault occurred in the option.  | <ol style="list-style-type: none"> <li>1. De-energize the drive.</li> <li>2. Make sure that the option is correctly connected to the connector.</li> <li>3. If the problem continues, replace the option.</li> </ol>  |
| oFb00          | Option Not Compatible with Port      | The option connected to connector CN5-B is not compatible.                             | Connect the option to the correct connector. <ul style="list-style-type: none"> <li>• Use connector CN5-A when you connect the option. To use other options, refer to those option manuals.</li> </ul>  |
| oFb02          | Option Fault                         | An option of the same type is already installed in option port CN5-A, CN5-B, or CN5-C. | Connect the option to the correct option port.  |
| oFC00          | Option Fault (CN5-B)                 | The option connected to connector CN5-C is not compatible.                             | Connect the option to the correct connector. <ul style="list-style-type: none"> <li>• Use connector CN5-A when you connect the option. To use other options, refer to those option manuals.</li> </ul>  |
| oFC02          | Option Fault                         | An option of the same type is already installed in option port CN5-A, CN5-B, or CN5-C. | Connect the option to the correct option port.  |

### ■ Minor Faults and Alarms

| Code | Name                             | Causes  | Possible Solutions   |
|------|----------------------------------|---|--|
| CALL | Serial Comm Transmission Error   | The communications cable wiring is incorrect.             | <ul style="list-style-type: none"> <li>• Examine for wiring errors.</li> <li>• Correct the wiring.</li> </ul>  |
|      |                                  | An existing short circuit or communications disconnection |  |
|      |                                  | Programming error on the master side                      | Check communications at start-up and correct programming errors.   |
|      |                                  | There is damage to the communication circuitry.           | <ul style="list-style-type: none"> <li>• Do a self-diagnostics check.</li> <li>• If the problem continues, replace either the control board or the entire drive. For instructions on how to replace the control board, contact Yaskawa or a Yaskawa representative.</li> </ul> |
| CyPo | Cycle Power to Active Parameters | Comm. Option Parameter Not Upgraded                       | Re-energize the drive to update the communication option parameters.   |



## ◆ Option Compatibility

You can connect a maximum of 3 options at the same time depending on the type of option.

**Note:**

- You can only connect one option to Z1000 and HV600 drives. Connect the option to the CN5 connector.
- You can connect two options to an FP605 drive. Connect the communication option to the CN5-A connector.
- Compatible communication options are different for different models. Refer to the drive manuals for more information.

**Table 10.1 Option Compatibility**

| Option  | Connector       | Number of Options Possible |
|---|-----------------|----------------------------|
| PG-B3 *1, PG-X3 *1  | CN5-B, C        | 2 *2                       |
| PG-RT3 *1 *3 *4, PG-F3 *1 *3 *4   | CN5-C           | 1                          |
| DO-A3 *5, AO-A3 *5  | CN5-A, B, and C | 1                          |
| SI-C3, SI-N3, SI-P3, SI-S3, SI-T3, SI-ET3,<br>SI-ES3, SI-B3, SI-M3,<br>SI-W3 *4, SI-EM3 *4, SI-EN3 *4, SI-EP3, JOHB-SMP3,<br>AI-A3 *5 *6, DI-A3 *5 *6 | CN5-A           | 1                          |

\*1 Not available for GA500, HV600, or FP605 drives.

\*2 To connect two PG options, use the CN5-C and CN5-B connectors. To connect only one PG option, use the CN5-C connector.

\*3 If you use the motor switching function, you cannot use this option.

\*4 Not available for 1000-Series drive models with capacities between 450 and 630 kW (650 to 1000 HP).

\*5 Not available for GA500 or HV600 drives.

\*6 To use AI-A3 and DI-A3 input statuses as monitors, connect the options to CN5-A, CN5-B, or CN5-C.

## 11 Function Modules

### ◆ Functions

Keypad models JVOP-182 or JVOP-KPLEA04AAA are necessary to do Direct Digital Control (DDC).


DDC is the automated control of a condition or process by a digital device. Connect the JVOP-182 to the CN3 port on the SI-W3 option to configure the various functions described in this section via the JVOP-182 LED display. Additionally, functions can be configured via a network connection to terminals A, B and SLD on the SI-W3.

**Note:**


- Keypad model JVOP-180, JVOP-183, and JVOP-KPLCB04AEB are not compatible.
- The Z1000 and Z1000U do not support these functions.

Do not turn off the power to the drive for at least 10 seconds after setting the functions with the keypad. Failure to comply could cause *EEP* error occurs to circuitry. Initialize the bind data when an *EEP* error occurs.

### ◆ Connection of Keypad for DDC Functionality via JVOP-182




◆ Keypad Display



| Display      |       | Description                                 |
|--------------|-------|---|
| <i>onLn</i>  | onLn  | Option in online status                     |
| <i>oFFLn</i> | oFFLn | Option in offline status                    |
| <i>UnCFG</i> | UnCFG | Network in unconfigured status              |
| <i>CALL</i>  | CALL  | Option in standby status for communications |
| <i>CPF88</i> | CPF88 | Option in error status                      |
| <i>bUS</i>   | bUS   | Option in communications error status       |
| <i>EEP</i>   | EEP   | EEPROM error                                |

■ Menu Structure for Keypad

1000-Series Menu Structure for Keypad



Switching the signs + and -


For data with signs, each time is pressed, the sign is switched between - and +.

Positive data: REV LED is unlit.










Negative data: REV LED is lit.

For data without sign, the sign switching function is not available.

GA700 and GA800 Menu Structure for Digital Operator



## ◆ List of Functions

| Name                       | Display                                    | Parameter      | Function Image  | Operation  | Default | Register Number       |
|----------------------------|--|----------------|---|--|---------|-----------------------|
| Logic Operation            | LgC-x<br>x: 0 - 7<br>No. of modules:<br>8  | PA000 - PA700  |    | The following operation modes can be selected by setting PAX00. <ul style="list-style-type: none"> <li>• 0: AND</li> <li>• 1: OR</li> <li>• 2: Inversion (INV)</li> <li>• 3: Reverse</li> </ul>  | 1       | 1001 - 1008<br>(Hex.) |
| Analog Operation           | ANA-x<br>x: 0 - 9<br>No. of modules:<br>10 | Pb000 - Pb928  |    | The following operation modes can be selected by setting Pbx02. <ul style="list-style-type: none"> <li>• 0: Ratio/Bias (R/B)</li> <li>• 1: Analog scheduler (ANA/SCH)</li> <li>• 2: Variation ratio limiter (LIM)</li> <li>• 3: Primary delay filter (FIL)</li> </ul>  | 1       | 1110 - 1209<br>(Hex.) |
| Selection Operation        | SEL-x<br>x: 0 - 7<br>No. of modules:<br>8  | PC000 - PC701  |    | The following operation modes can be selected by setting PCx01. <ul style="list-style-type: none"> <li>• 0: State data based select (SEL)<br/>The data of either nviSELxAin1 or nviSELxAin2 is output according to the state data of nviSELxDin.</li> <li>• 1: High select (Hi)<br/>The larger of two values is output.</li> <li>• 2: Low select (Lo)<br/>The smaller of two values is output.</li> </ul>      | 1       | 120A - 1219<br>(Hex.) |
| Comparison Operation       | Cp-x<br>x: 0 - 7<br>No. of modules:<br>8   | Pd000 - Pd702  |    | The following operation modes can be selected by setting Pdx01. <ul style="list-style-type: none"> <li>• 0: Forward operation<br/>The output turns ON when nviCMPxAin1 ≥ nviCMPxAin2.</li> <li>• 1: Reverse operation<br/>The output turns ON when nviCMPxAin1 ≤ nviCMPxAin2.</li> </ul>   | 0       | 121A - 1231<br>(Hex.) |
| Step Output Operation      | SP-x<br>x: 0<br>No. of modules:<br>1       | PE000 - PE018  |  | The following operation modes can be selected by setting PEx01. <ul style="list-style-type: none"> <li>• 0: First In Last Out (FILO)<br/>The outputs nvoStepxDout1 through 4 turn ON or OFF according to the value of nviStepxAin in FILO order.</li> <li>• 1: First In First Out (FIFO)<br/>The output nvoStepxDout1 through 4 turn ON or OFF according to the value of nviStepxAin in FIFO order.</li> </ul> | 0       | 1232 - 123C<br>(Hex.) |
| Delay Timer                | dt-x<br>x: 0, 1<br>No. of modules:<br>2    | PF000 - PF104  |  | The following operation modes can be selected by setting PFx00. <ul style="list-style-type: none"> <li>• 0: ON delay<br/>The output nvoTIMx turns ON when the set time period has passed after the input nviTIMx turned ON.</li> <li>• 1: OFF delay<br/>The output nvoTIMx turns OFF when the set time period has passed after the input nviTIMx turned OFF.</li> </ul>  | 0       | 123D - 1244<br>(Hex.) |
| Deviation Output Operation | dv-x<br>x: 0<br>No. of modules:<br>1       | PG000 - PG013  |  | The following operation modes can be selected by setting PGx01. <ul style="list-style-type: none"> <li>• 0: Outputs with 3 deviations<br/>Three data with the bias set in the data of nviDevxAin are output.</li> <li>• 1: Outputs with 2 deviations<br/>Two data with the bias set in the data of nviDevxAin are output.</li> </ul>   | 0       | 1245 - 124A<br>(Hex.) |
| PID                        | pid-x<br>x: 0 - 3<br>No. of modules:<br>4  | Ph000 to Ph305 |  | The following operation modes can be selected by setting PHx01. <ul style="list-style-type: none"> <li>• 0: Forward operation<br/>PI control on forward operation using the input feedback nviPIDxAin1.</li> <li>• 1: Reverse operation<br/>PI control on reversed operation using the input feedback nviPIDxAin1.</li> </ul>  | 0       | 124B - 1266<br>(Hex.) |
| Constant Output            | fno-x<br>x: 0 - 5<br>No. of modules:<br>6  | PJ000 - PJ501  |  | The data set in the parameter PJx01 is output.   | 0       | 1267 - 1272<br>(Hex.) |

| Name                     | Display                                   | Parameter     | Function Image | Operation   | Default | Register Number    |
|--------------------------|---|---------------|----------------|---|---------|--------------------|
| Variable Type Conversion | typ-x<br>x: 0 - 3<br>No. of modules:<br>4 | PL000 - PL320 |                | The following operation modes can be selected by setting PLx02.<br>• 0: ANA → ANA<br>• 1: ANA → DIG<br>• 2: DIG → ANA | 0       | 1273 - 12BA (Hex.) |
| Save Data                | dtl-x<br>x: 0 - 3<br>No. of modules:<br>4 | Po000 - Po300 |                | The data is saved in EEPROM when inputting data. The saved data will not be cleared whenever the power turns OFF.     | 0       | 12BB - 12BE (Hex.) |

■ Items Common to Functions

Sending Data

- Each Function Module outputs response data according to its own function using an output network variable after receiving an input network variable.
- You can change the output method of output network variables for each module using the common configuration properties nciAoutMinOutTm and nciAoutSendHrtBt and the minDelta prepared at each module.

Configuration Properties Common to All Function Modules


| Configuration Property | Explanation  | Applicable NVs            |
|------------------------|--|---------------------------|
| nciAoutMinOutTm        | Sets a minimum output time of analog data. Analog data is output after the set time period is expired after a change in the data.      | ANA data of each Function |
| nciAoutSendHrtBt       | Sets a cycle time to output an analog data. Analog data is output in the set cycle time.   | ANA data of each Function |
| nciDoutSendHrtBt       | Sets a cycle time to output the output network variables whose variable type is SNVT_switch. DIG data is output in the set cycle time. | DIG data of each Function |

Configuration Properties for Each Function Module

| Configuration Property             | Explanation                          | Applicable Function |
|------------------------------------|--------------------------------------|---------------------|
| nciPID0MinDelta to nciPID3MinDelta | Sets a minimum delta of analog data. | PID Function        |

◆ Logic Operation Function

■ Function Block Image



Number of modules: 8 (0 to 7)

■ Network Variables and Parameters

The Logic Operation Function carries out an operation in a number of stages according to the amount of data stored in the input network variable and saves the result in the network variable.

Network Variables

| Network Variable | Variable Type | Type Change | Name and Function   |
|------------------|---------------|-------------|---|
| nviLgcxDin1      | SNVT_switch   | Impossible  | DIG input 1   |
| nviLgcxDin2      | SNVT_switch   | Impossible  | DIG input 2   |
| nvoLgcxDout      | SNVT_switch   | Impossible  | DIG output<br>Outputs the result of logic operation.<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |

## Parameters

| Parameter      | Name                     | Explanation  | Default |
|----------------|--------------------------|--|---------|
| PA000 to PA700 | Operation mode selection | 0: AND<br>1: OR<br>2: Inversion (INV)<br>3: Non-equivalence (EQ) | 1       |

## ■ Operation

The Logic Operation Function has four operation modes: AND, OR, Reverse, and Inversion (INV). Set parameter PAX01 to select a mode.

The table below shows the output conditions of each operation mode.

| Function        | Set Value in PAX01 | Input                     |         |                           |         | Output                    |       |
|-----------------|--------------------|---------------------------|---------|---------------------------|---------|---------------------------|-------|
|                 |                    | nviLgcxDin1 (SNVT_switch) |         | nviLgcxDin2 (SNVT_switch) |         | nvoLgcxDout (SNVT_switch) |       |
|                 |                    | Value                     | State   | Value                     | State   | Value                     | State |
| AND             | 0                  | NA                        | 1       | NA                        | 1       | 100                       | 1     |
|                 |                    | NA                        | 1       | NA                        | 0 or -1 | 0                         | 0     |
|                 |                    | NA                        | 0 or -1 | NA                        | 1       | 0                         | 0     |
|                 |                    | NA                        | 0 or -1 | NA                        | 0 or -1 | 0                         | 0     |
| OR              | 1                  | NA                        | 1       | NA                        | 1       | 100                       | 1     |
|                 |                    | NA                        | 1       | NA                        | 0 or -1 | 100                       | 1     |
|                 |                    | NA                        | 0 or -1 | NA                        | 1       | 100                       | 1     |
|                 |                    | NA                        | 0 or -1 | NA                        | 0 or -1 | 0                         | 0     |
| Reverse         | 2                  | NA                        | 1       | NA                        | 1       | 100                       | 1     |
|                 |                    | NA                        | 1       | NA                        | 0       | 0                         | 0     |
|                 |                    | NA                        | 0       | NA                        | 1       | 0                         | 0     |
|                 |                    | NA                        | 0       | NA                        | 0       | 100                       | 1     |
|                 |                    | NA                        | -1      | NA                        | -1      | 0                         | 0     |
| Inversion (INV) | 3                  | NA                        | 1       | -                         | -       | 0                         | 0     |
|                 |                    | NA                        | 0       | -                         | -       | 100                       | 1     |
|                 |                    | NA                        | -1      | -                         | -       | 0                         | 0     |

### Note:

x: Indicates the module number 0 to 7.

Data is sent in event-driven timing, which sends data when the state changes.

Changes to parameter settings are immediately reflected in the operation results in the output network variable.

## ◆ Analog Operation Function

### ■ Function Image



Number of modules: 10 (0 to 9)

### ■ Network Variables and Parameters

The Analog Operation Function carries out an operation in a number of stages or steps according to the amount of data stored in the input network variable and saves the result in the output network variable.

## Network Variables

| Network Variable | Variable Type    | Type Change | Name and Function  |
|------------------|------------------|-------------|--|
| nviPxAin         | SNVT_lev_percent | Possible    | Executes the operation on the base of the data set in this variable according to the operation mode. |
| nvoPxAout        | SNVT_lev_percent | Possible    | Outputs the operation result.  |

## Parameters

| Parameter | Name                           | Explanation  | Default |
|-----------|--------------------------------|--|---------|
| Pbx00     | Variable type                  | Indicates the variable type of nviPxAin. Cannot be set from the keypad.              | 0       |
| Pbx01     | Variable type                  | Indicates the variable type of nvoPxAout. Cannot be set from the keypad.             | 0       |
| Pbx02     | Operation mode selection       | 0: Ratio/Bias<br>1: Scheduler<br>2: Variation ratio limit<br>3: Primary delay filter | 1       |
| Pbx03     | Output cycle                   | Operation output cycle of nvoPxAout.   | 1.0 s   |
| Pbx04     | Variation ratio limit value    | Limits the variation of nvoPxAout.   | 0       |
| Pbx05     | Delay time                     | Used for operation with primary delay filter.  | 0       |
| Pbx06     | Operation after initialization | 0: Calculates as the previous output was 0.<br>1: Outputs the input value as it is.  | 0       |
| Pbx07     | Ratio                          | Sets a inclination when Pbx02 = 0.   | 1.0     |
| Pbx08     | Bias                           | Sets the bias when Pbx02 = 0.  | 0       |
| Pbx11     | Reference point 1X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx12     | Reference point 2X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx13     | Reference point 3X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx14     | Reference point 4X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx15     | Reference point 5X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx16     | Reference point 6X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx17     | Reference point 7X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx18     | Reference point 8X coordinates | Sets the coordinate value x (input).   | 0       |
| Pbx21     | Reference point 1Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx22     | Reference point 2Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx23     | Reference point 3Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx24     | Reference point 4Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx25     | Reference point 5Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx26     | Reference point 6Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx27     | Reference point 7Y coordinates | Sets the coordinate value y (input).   | 0       |
| Pbx28     | Reference point 8Y coordinates | Sets the coordinate value y (input).   | 0       |

## ■ Operation

The Analog Operation Function has four operation modes that can be selected by setting parameter Pbx02: Ratio/Bias, Analog Schedule, Variation Ratio Limiter, Primary Delay Filter.

The table below shows the output conditions of each operation mode.



| Operation Function      | Related Parameters | Explanation                    | Setting           |
|-------------------------|--------------------|--------------------------------|-------------------|
| Ratio/Bias              | Pbx02              | Operation mode selection       | 0                 |
|                         | Pbx07              | Ratio                          | -3276.8 to 3276.7 |
|                         | Pbx08              | Bias                           | *1                |
| Analog Scheduler        | Pbx02              | Operation mode selection       | 1                 |
|                         | Pbx11 to x18       | Coordinate value x (input)     | *1                |
|                         | Pbx21 to x28       | Coordinate value y (output)    | *1                |
| Variation Ratio Limiter | Pbx02              | Operation mode selection       | 2                 |
|                         | Pbx03              | Output cycle                   | 0.1 to 60.0 s     |
|                         | Pbx04              | Variation ratio limit value    | *1                |
|                         | Pbx06              | Operation after initialization | 0 or 1            |
| Primary Delay Filter    | Pbx02              | Operation mode selection       | 3                 |
|                         | Pbx03              | Output cycle                   | 0.1 to 60.0 s     |
|                         | Pbx05              | Delay time                     | 0 - 65534 s       |
|                         | Pbx06              | Operation after initialization | 0 or 1            |


\*1 Depends on variable types.

### Sending Data

The data is sent in event-driven timing or using nciAoutSndHrtBt and nciMinSendTim.


### Ratio/Bias

The data in the input network variable is calculated using the following equation, and the result is sent to the output network variable:



### Analog Scheduler


The analog data of the input network variable is compensated using the line graph shown below, and the compensated result is sent to the output network variable.



**Note:**

1. Set the analog input data parameters Pbx11 to Pbx18 in ascending order.
2. If any of the parameters Pbx11 to Pbx18 are not set in ascending order, only the setting values of those parameters set in ascending order are valid and all others are invalid.  
The results from the nvoPx Aout are output and used with the values for the Y-axis set values in correspondence to the parameter set values that were set in ascending order.

- Example: When  $Pbx13 > Pbx14$ , the line graph will chart as shown in the example below. The set values of parameters  $Pbx14$  and higher are invalid, and the set value of  $Pbx13$  is used for operation.



**Note:**


1. For the value of  $nviPxAin$ , the value of  $nvoPxAout$  shown with a solid line is output.
2. Parameter  $Pbx14$  was set out of ascending order, so the set values of parameters  $Pbx14$  to  $Pbx18$  and  $Pbx24$  to  $Pbx28$  are invalid. If the value of  $nviPxAin$  is larger than the setting of  $Pbx13$ , as shown in this case,  $nvoPxAout = Pbx23$ .

- When parameters  $Pbx14$  to  $Pbx18$  are set in ascending order:

- If  $nviPxAin < Pbx11$ ,  $nvoPxAout = Pbx21$
- If  $nviPxAin > Pbx18$ ,  $nvoPxAout = Pbx28$

**Variation Ratio Limiter**

The output variation ratio limit is executed on the analog data of input network variable as shown below, and the result is sent to the output network variable.



When the value of  $nviPxAin$  changes from  $nviPxAin$  (previous value) to  $nviPxAin$  (current value), the variation ratio limit value is added to the value of  $nvoPxAout$  every output cycle so that the final value of  $nvoPxAout$  is equal to the current value of  $nviPxAin$ .


Example:  $nvoPxAout$  data process when the value of  $nvoPxAin$  changes from 30.000 to 65.000

Input and output network variable type: lev\_percent

Parameter settings: As shown in the table below

| Parameter | Explanation                 | Setting |
|-----------|-----------------------------|---------|
| Pbx02     | Operation mode selection    | 2       |
| Pbx03     | Output cycle                | 1.5 s   |
| Pbx04     | Variation ratio limit value | 10.000  |

After the value of  $nviPxAin$  changes from 30.000 to 65.000, the value of  $nvoPxAout$  becomes equal to the value of  $nviPxAin$  in six seconds.



**Primary Delay Filter**

The data of input network variable is calculated using the equation below, and the result is sent to the output network variable:

$$nvoPxAout(t) = nvoPxAout(t-1) + Ts / (Ts + TL) \times (nviPxAin - nvoPxAout(t-1))$$

nvoPxAout(t): Current output value

nvoPxAout(t-1): Previous output value

nviPxAin: Input value

Ts: Output cycle (Pbx03)

TL: Delay time (Pbx05)

When  $Ts > TL$ , it is judged as  $Ts = TL$ .

**◆ Select Operation Function**

**■ Function Image**



Number of modules: 8 (0 to 7)

**■ Network Variables and Parameters**

The Select Operation Function has three operation modes that can be selected with parameter PCx01: State Data Based Select, Hi Select, and Lo Select.

**Network Variables**

| Network Variable | Variable Type    | Type Change | Name and Function   |
|------------------|------------------|-------------|---|
| nviSELxDin       | SNVT_switch      | Impossible  | Executes the operation on the base of the data in this parameter according to the operation mode. |
| nviSELxAin1      | SNVT_lev_percent | Possible    | Input data 1  |
| nviSELxAin2      | SNVT_lev_percent | Possible    | Input data 2  |
| nvoSELxAout      | SNVT_lev_percent | Possible    | Outputs the selected data.  |

**Parameters**

| Parameter | Name              | Explanation  | Default |
|-----------|-------------------|--|---------|
| PCx00     | Variable type     | Indicates the variable type of nviSELxAin1 and 2. You cannot use the keypad to set this parameter. | 0       |
| PCx01     | Operation setting | 0: State data based select<br>1: Hi select (Hi)<br>2: Lo select (Lo)                               | 1       |

**■ Operation**

The Select Operation Function has three operation modes that can be selected with parameter PCx01: State Data Based Select, Hi Select, and Lo Select.

The table below shows the input conditions of each operation mode.

| Function                | PCx01 Setting | Input Condition           |       | Output Data nvoSELxAout |
|-------------------------|---------------|---------------------------|-------|-------------------------|
| State Data Based Select | 0             | nviSELxDin (SNVT_switch)  |       | -                       |
|                         |               | value                     | state |                         |
|                         |               | NA                        | 1     |                         |
|                         |               | NA                        | 0     |                         |
|                         |               | NA                        | -1    | nviSELxAin1             |
| Hi Select               | 1             | nviSELxAin1 ≥ nviSELxAin2 |       | nviSELxAin1             |
|                         |               | nviSELxAin1 < nviSELxAin2 |       | nviSELxAin2             |
| Lo Select               | 2             | nviSELxAin1 < nviSELxAin2 |       | nviSELxAin1             |
|                         |               | nviSELxAin1 ≥ nviSELxAin2 |       | nviSELxAin2             |

**State Data Based Select**

The data of the input network variables nviSELxAin1 or nviSELxAin2 is selected according to the state data of nviSELxDin, and the data of the selected input network variable is sent to the output network variable nvoSELxAout.

When nviSELxDin (STATE) = 0, nvoSELxAout = nviSELxAin1

When nviSELxDin (STATE) = 1, nvoSELxAout = nviSELxAin2

When nviSELxDin (STATE) = -1, nvoSELxAout = nviSELxAin1

**Hi Select**

The data of the input network variables nviSELxAin1 and nviSELxAin2 are compared, and the data of the bigger value is output to the output network variable nvoSELxAout.

The input network variable nviSELxDin is not used.


**Lo Select**

The data of the input network variables nviSELxAin1 and nviSELxAin2 are compared, and the data of the smaller value is sent to the output network variable nvoSELxAout.

The input network variable nviSELxDin is not used.

**◆ Comparison Operation Function**

**■ Function Image**



Number of modules: 8 (0 to 7)

**■ Network Variables and Parameters**

The data of the input network variable nviCMPxAin2 is compared to nviCMPxAin1. The result is sent to the output network variable according to the forward and the reverse operation.

**Network Variables**

| Network Variable | Variable Type    | Type Change | Name and Function                        |
|------------------|------------------|-------------|--|
| nviCMPxAin1      | SNVT_lev_percent | Possible    | Base data for comparison                 |
| nviCMPxAin2      | SNVT_lev_percent | Possible    | Data to compare                          |
| nvoCMPxDout      | SNVT_switch      | Impossible  | Outputs according to the operation mode. |

**Parameters**


| Parameter | Name                     | Explanation  | Default |
|-----------|--------------------------|--|---------|
| Pdx00     | Variable type            | Indicates the variable type of nviCMPxAin1 and nviCMPxAin2. You cannot use the keypad to set this parameter. | 0       |
| Pdx01     | Operation mode selection | 0: Forward operation<br>1: Reverse operation   | 0       |
| Pdx02     | Hysteresis               | Sets the hysteresis of output variation  | 0       |

**■ Operation**

**Forward Operation**


When the value of nviCMPxAin2 is greater than nviCMPxAin1, then nvoCMPxDout (STATE) = 1 (ON).

When the value of nviCMPxAin2 is less than “nviCMPxAin1 – Pbx02”, then nvoCMPxDout (STATE) = 0 (OFF).




**Reverse Operation**

When the value of nviCMPxAin2 is less than nviCMPxAin1, then nvoCMPxDout (STATE) = 1 (ON). When the value of nviCMPxAin2 is greater than “nviCMPxAin1 + Pbx02”, then nvoCMPxDout (STATE) = 0 (OFF).



**◆ Step Output Operation Function**

**■ Function Image**



Number of modules: 1 (0)

**■ Network Variables and Parameters**

The Step Output Operation Function carries out an operation in a number of stages according to the amount of data stored in the input network variable and saves the result in the output network variable.


**Network Variables**

| Network Variable | Variable Type    | Type Change | Name and Function  |
|------------------|------------------|-------------|--|
| nviSTEPxDin      | SNVT_switch      | Impossible  | Output interlock<br>state = 0, -1: Interlock<br>state = 1: Release interlock |
| nviSTEPxAin      | SNVT_lev_percent | Possible    | Input data<br>Compares with the reference value, and outputs in order.       |
| nvoSTEPxDout1    | SNVT_switch      | Impossible  | Step output 1<br>When ON: state = 1, value = 100.0                           |

| Network Variable | Variable Type | Type Change | Name and Function  |
|------------------|---------------|-------------|--|
|                  |               |             | When OFF: state = 0, value = 0.0   |
| nvoSTEPxDout2    | SNVT_switch   | Impossible  | Step output 2<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |
| nvoSTEPxDout3    | SNVT_switch   | Impossible  | Step output 3<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |
| nvoSTEPxDout4    | SNVT_switch   | Impossible  | Step output 4<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |

**Parameters**

| Parameter | Name  | Explanation   | Default |
|-----------|---|---|---------|
| PEX00     | Variable type   | It is not possible to change this parameter using the keypad.   | 0       |
| PEX01     | Operation mode selection                              | 0: FILO (First In Last Out)<br>1: FIFO (First In First Out)   | 0       |
| PEX02     | Hysteresis  | Sets the hysteresis to the reference point to turn OFF the output signal.   | 0       |
| PEX11     | STEP 1 reference value                                | The reference value to turn ON the output signal.   | 0       |
| PEX12     | STEP 2 reference value                                | The reference value to turn ON the output signal.   | 0       |
| PEX13     | STEP 3 reference value                                | The reference value to turn ON the output signal.   | 0       |
| PEX14     | STEP 4 reference value                                | The reference value to turn ON the output signal.   | 0       |
| PEX15     | Timer to increment/decrement the number of ON outputs | When the value of nviSTEPxAin is greater than the reference value or less than the value "Reference value - Hysteresis value," the timer starts counting and the number of ON outputs increases or decreases by 1 after the set time.<br>(If the value of nviSTEPxAin does not satisfy the conditions needed to start the timer, the timer is reset.) | 10      |
| PEX16     | Timer after the output turned ON                      | The value of nviSTEPxAin is discarded in this set time after the output has turned ON.  | 60      |
| PEX17     | Timer after the output turned OFF                     | The value of nviSTEPxAin is discarded in this set time after the output has turned OFF.   | 30      |
| PEX18     | Base output position                                  | Set the output network variable that turns ON first.<br>1: nvoSTEPxDout1<br>2: nvoSTEPxDout2<br>3: nvoSTEPxDout3<br>4: nvoSTEPxDout4  | 1       |



**Note:**

The STEP reference values must be set in ascending order. If they are not set in ascending order, only the values that are set in ascending order are valid.

STEP 1 reference value < STEP 2 reference value < STEP 2 reference value < STEP 4 reference value

## ■ Operation

### First In Last Out (FILO)

With this method, the nvoSTEPxDout that was turned ON first is turned OFF last.

The nvoSTEPxDout that turns ON first can be specified using the parameter PEx18 (base output position).

- Example 1: Order of output priority when the base output position is 1.

| Output Position | ON Output Priority | OFF Output Priority |
|-----------------|--------------------|---------------------|
| nvoSTEPxDout1   | 1                  | 4                   |
| nvoSTEPxDout2   | 2                  | 3                   |
| nvoSTEPxDout3   | 3                  | 2                   |
| nvoSTEPxDout4   | 4                  | 1                   |

- Example 2: Order of output priority when the base output position is 3.

| Output Position | ON Output Priority | OFF Output Priority |
|-----------------|--------------------|---------------------|
| nvoSTEPxDout1   | 3                  | 2                   |
| nvoSTEPxDout2   | 4                  | 1                   |
| nvoSTEPxDout3   | 1                  | 4                   |
| nvoSTEPxDout4   | 2                  | 3                   |

While the output is interlocked, all the outputs turns OFF. When the interlock is released, the output turns ON in order from the base output position.

### First In First Out (FIFO)

With this method, the nvoSTEPxDout that was turned ON first is turned OFF first.

After interlocking, the position of the signal to be turned ON first for the next operation is the next one for the position whose signal was last turned ON.

- Example 1: Order of output priority when the base output position is 1.

| Output Position | ON Output Priority | OFF Output Priority |
|-----------------|--------------------|---------------------|
| nvoSTEPxDout1   | 1                  | 1                   |
| nvoSTEPxDout2   | 2                  | 2                   |
| nvoSTEPxDout3   | 3                  | 3                   |
| nvoSTEPxDout4   | 4                  | 4                   |

- Example 2: Output start position when interlocked (Base output position: 1).

STEP 1 reference value: 10.000%

STEP 2 reference value: 30.000%

STEP 3 reference value: 50.000%

STEP 4 reference value: 70.000%

| Operation Pattern | Output Position      | nvoSTEPxDout1 | nvoSTEPxDout2 | nvoSTEPxDout3 | nvoSTEPxDout4 | Data of nviSTEPxAin |
|-------------------|----------------------|---------------|---------------|---------------|---------------|---------------------|
| 1                 | 0-stage output       | ○             | ○             | ○             | ○             | 5.000%              |
| 2                 | 1-stage output       | ●             | ○             | ○             | ○             | 12.000%             |
| 3                 | On being interlocked | ○             | ○             | ○             | ○             | 35.000%             |
| 4                 | 1-stage output       | ○             | ●             | ○             | ○             | 35.000%             |
| 5                 | 2-stage output       | ○             | ●             | ●             | ○             | 35.000%             |
| 6                 | 3-stage output       | ○             | ●             | ●             | ●             | 50.000%             |
| 7                 | On being interlocked | ○             | ○             | ○             | ○             | 50.000%             |
| 8                 | 1-stage output       | ●             | ○             | ○             | ○             | 20.000%             |
| 9                 | 2-stage output       | ●             | ●             | ○             | ○             | 40.000%             |
| 10                | 3-stage output       | ●             | ●             | ●             | ○             | 80.000%             |
| 11                | 4-stage output       | ●             | ●             | ●             | ●             | 80.000%             |
| 12                | 3-stage output       | ○             | ●             | ●             | ●             | 60.000%             |

| Operation Pattern | Output Position      | nvoSTEPxDout1 | nvoSTEPxDout2 | nvoSTEPxDout3 | nvoSTEPxout4 | Data of nviSTEPxAin |
|-------------------|----------------------|---------------|---------------|---------------|--------------|---------------------|
| 13                | 2-stage output       | ○             | ○             | ●             | ●            | 40.000%             |
| 14                | On being interlocked | ○             | ○             | ○             | ○            | 40.000%             |
| 15                | 1-stage output       | ●             | ○             | ○             | ○            | 40.000%             |
| 16                | 2-stage output       | ●             | ●             | ○             | ○            | 40.000%             |


●: Output signal ON, ○: Output signal OFF

The details of the operation pattern described in the table above are in order as follows:

1. All the output signals are OFF because the value of the data of nviSTEPxAin is less than the STEP 1 reference value.
2. The output Dout1 turns ON first as the base output position is 1.
3. All the outputs are turned OFF by setting the interlock to 0.
4. The operation restarts when the interlock is released. The position that turns ON first is not the position set for the base output position, but the output step next to the output (nvoSTEPxDout1) that turned ON last before the outputs have been interlocked in pattern 3. This means nvoSTEPxDout2.
5. As the value of nviSTEPxAin increases, the nvoSTEPxDout3 and nvoSTEPxDout4 turn ON in order.
6. The operation pattern is the same as pattern 5.
7. All the outputs are turned OFF by setting the interlock to 0.
8. In the same way as in pattern 4, the operation restarts when the interlock is released. The position that turns ON first is not the position set for the base output position, but the output next to the output (nvoSTEPxDout4) that turned ON last before the outputs have been interlocked in pattern 7: nvoSTEPxDout1. This means nvoSTEPxDout1.
9. As the value of nviSTEPxAin increases, the nvoSTEPxDout2, nvoSTEPxDout3, and nvoSTEPxDout4 turn ON in order.
10. The operation pattern is the same as pattern 5.
11. The operation pattern is the same as pattern 5.
12. The value of the input data of nviSTEPxAin becomes less than the STEP 4 reference value. The output nvoSTEPxDout1 that turned ON first among four outputs turns OFF first.
13. The value of nviSTEPxAin becomes less than the STEP 3 reference value. The output nvoSTEPxDout2 turns OFF.
14. All the outputs are turned OFF by setting the interlock to 0.
15. In the same way as in patterns 4 and 8, the operation restarts when the interlock is released. The position that turns ON first is not the position set for the base output position, but the output next to the output (nvoSTEPxDout4) that turned ON last before the outputs have been interlocked in process 11: nvoSTEPxDout1. This means nvxSTEPoDout1.
16. The value of nviSTEPxAin is not changed but more than the STEP 2 reference value. The nvoSTEPxDout2 turns ON after the set time of the timer.

## ◆ Delay Timer Function

### ■ Function Image





## ■ Network Variables and Parameters

### Network Variables

| Network Variable | Variable Type | Type Change | Name and Function   |
|------------------|---------------|-------------|---|
| nviTIMxDin       | SNVT_switch   | Impossible  | Timer start input<br>state = -1: Output OFF<br>state = 0: Depends on the operation mode<br>state = 1: Depends on the operation mode |
| nvoTIMxDout      | SNVT_switch   | Impossible  | Output 1<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0   |


### Parameters

| Parameter | Name                              | Explanation  | Default |
|-----------|-----------------------------------|--|---------|
| PFx00     | Operation mode selection          | 0: ON delay<br>1: OFF delay  | 0       |
| PFx01     | ON delay time                     | Sets the ON delay time. Units: 1 s   | 0       |
| PFx02     | ON delay time                     | Sets the OFF delay time. Units: 1 s  | 0       |
| PFx04     | Operation when the power turns ON | 0: nvoTIMxDout turns ON when the set delay time is expired after nviTIMxDin turned ON.<br>1: nvoTIMxDout turns ON when nviTIMxDin turns ON without waiting for the set delay time. | 0       |

## ■ Operation

### ON/OFF Delay


The ON/OFF Delay mode delays the timing to turn ON/OFF the output network variable nvoTIMxDout according to the data of the input network variable nviTIMxDin for the set time period as shown in the following figure for details:




## ◆ Deviation Output Function

### ■ ON/OFF Delay

The ON/OFF Delay mode delays the timing to turn ON/OFF the output network variable nvoTIMxDout according to the data of the input network variable nviTIMxDin for the set time period as shown in the following figure for details:



■ **Function Image**



■ **Network Variables and Parameters**

The value of the deviation added to or subtracted from the analog data (set value) of the input network variable is sent to the foutput network variable.

**Network Variables**

| Network Variable | Variable Type    | Type Change | Name and Function   |
|------------------|------------------|-------------|---|
| nviDevxDin       | SNVT_switch      | Impossible  | Used for the operation mode "Outputs with 2 deviation". Refer to 61 for more information.   |
| nviDevxAin       | SNVT_lev_percent | Possible    | Input data<br>The base data for the data to be output.  |
| nviDevxAout1     | SNVT_lev_percent | Possible    | The deviation is added to or subtracted from the value according to the operation mode, and the result is sent to the nviDevxAin. |
| nvoDevxAout2     | SNVT_lev_percent | Possible    | The deviation is added to or subtracted from the value according to the operation mode, and the result is sent to the nviDevxAin. |
| nvoDevxAout3     | SNVT_lev_percent | Possible    | The deviation is added to or subtracted from the value according to the operation mode, and the result is sent to the nviDevxAin. |

**Parameters**

| Parameter | Name                     | Explanation  | Default |
|-----------|--------------------------|--|---------|
| PGx00     | Variable type            | Impossible to set from the Operator                          | 0       |
| PGx01     | Operation mode selection | 0: Outputs with 3 deviations<br>1: Outputs with 2 deviations | 0       |
| PGx11     | Deviation a              | Sets a deviation.  | 0       |
| PGx12     | Deviation b              | Sets a deviation.  | 0       |
| PGx13     | Deviation c              | Sets a deviation.  | 0       |

■ **Operation**

**Outputs with 3 Deviations**

Three deviations set in PGx11, PGx12, PGx13 are added to or subtracted from the data of nviDevxAin as shown below, and the results are sent to nviDevxAout1, 2, and 3. Each output network variable is calculated using the equation below:

$$\begin{aligned} nviDevxAout1 &= nviDevxAin - PGx11 \\ nvoDevxAout2 &= nviDevxAin + PGx12 \\ nvoDevxAout3 &= nviDevxAin + PGx13 \end{aligned}$$

**Outputs with 2 Deviations**

Two output data are set as follows according to the status of nviDevxDin:


- When nviDevxDin = OFF,  
nviDevxAout1 = 0 (Fixed)  
nvoDevxAout2 = nviDevxAin - PGx13  
nvoDevxAout3 = nviDevxAin
- When nviDevxDin = ON,  
nviDevxAout1 = nviDevxAin  
nvoDevxAout2 = nviDevxAin + PGx11  
nvoDevxAout3 = 100 (Fixed)

**Note:**

If the result of the above operation becomes out of the effective data range, the maximum or minimum value will be output.

## ◆ PID Function

### ■ Function Image



### ■ Network Variables and Parameters

The PID function executes PI control using the data of two input network variables, and is sent to the output network variable.

#### Network Variables

| Network Variable | Variable Type    | Type Change | Name and Function   |
|------------------|------------------|-------------|---|
| nviPIDxDin       | SNVT_switch      | Impossible  | Output interlock<br>0: Interlock<br>1: Start control  |
| nviPIDxAin1      | SNVT_lev_percent | Possible    | Sets value data (SP)  |
| nviPIDxAin2      | SNVT_lev_percent | Possible    | Process input value (Feedback data) (PV)  |
| nvoPIDxAout      | SNVT_lev_percent | Impossible  | Outputs the output amount calculated on the base of feedback data.<br>Output range: -5.00 to +105.00% |

#### Parameters

| Parameter | Name                     | Explanation   | Default |
|-----------|--------------------------|---|---------|
| PHx00     | Variable type            | Impossible to set from the Operator   | 0       |
| PHx01     | Operation mode selection | 0: Forward operation<br>1: Reversed operation   | 0       |
| PHx02     | Proportional band        | 0 - 6553.5 s<br>However, when the input network variable type is set to SNVT_flow or SNVT_ppm, the value below the decimal point is rounded up for operation. | 1.0     |
| PHx03     | Integral time            | 0 - 6553.5 s  | 1.0     |
| PHx04     | Output when interlocked  | The value of the PID output when interlocked  | 0       |
| PHx05     | Reference point          | The reference point to be used for operation  | 50      |

### ■ Operation

The PID output when interlocked can be calculated using the following equation:

Forward operation:  $P = P_{(0)} - \{(100 / P_b) \times e_i\} - \{(100 \times \theta) / (T_i \times P_b)\} \times e_i$

Reverse operation:  $P = P_{(0)} + \{(100 / P_b) \times e_i\} + \{(100 \times \theta) / (T_i \times P_b)\} \times e_i$

P: PID output (%) (-5 - +105%)

$P_{(0)}$ : Reference point (PHx05)

$P_b$ : Proportional band (PHx02)


$\theta$ : Operation cycle (100 ms)

$T_i$ : Integral time (PHx03)

$e_i$ : Deviation (nviPIDxAin1 - nviPIDxAin2)

## ◆ Constant Output Function

### ■ Function Image



### ■ Network Variables and Parameters

The data set in the parameter is output.

#### Network Variables

| Network Variable | Variable Type    | Type Change | Name and Function  |
|------------------|------------------|-------------|--|
| nvoFnoxAout      | SNVT_lev_percent | Possible    | The data set in the parameter is output when the power turns ON. |

#### Parameters


| Parameter | Name          | Explanation  | Default |
|-----------|---------------|--|---------|
| PJx00     | Variable type | It is not possible to set this parameter using the keypad. | 0       |
| PJx01     | Constant      | Set a desired numerical value.                             | 0       |

### ■ Operation

The constant set in the parameter is sent to the network variable.

## ◆ Variable Type Conversion Function

### ■ Function Image



### ■ Network Variables and Parameters

The Variable Type Conversion Function converts DIGIN to ANAOUT, and ANA\_IN to DIG\_OUT.

#### Network Variables

| Network Variable | Variable Type    | Type Change | Name and Function   |
|------------------|------------------|-------------|---|
| nviTypxDin1      | SNVT_switch      | Impossible  | -   |
| nviTypxDin2      | SNVT_switch      | Impossible  | -   |
| nviTypxDin3      | SNVT_switch      | Impossible  | -   |
| nviTypxAin       | SNVT_lev_percent | Possible    | -   |
| nvoTypxDout1     | SNVT_switch      | Impossible  | DIG output 1<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |
| nvoTypxDout2     | SNVT_switch      | Impossible  | DIG output 2<br>When ON: state = 1, value = 100.0<br>When OFF: state = 0, value = 0.0 |
| nvoTypxAout      | SNVT_lev_percent | Possible    | -   |

#### Parameters


| Parameter | Name                     | Explanation   | Default |
|-----------|--------------------------|---|---------|
| PLx00     | Variable type            | You cannot use the keypad to set this parameter.                  | 0       |
| PLx01     | Variable type            | You cannot use the keypad to set this parameter.                  | 0       |
| PLx02     | Input range 1            | Sets the input range when converting from ANA to ANA.             | 0       |
| PLx03     | Input range 2            | Sets the input range when converting from ANA to ANA.             | 0       |
| PLx04     | Output range 1           | Set the output range when converting from ANA to ANA.             | 0       |
| PLx05     | Output range 2           | Set the output range when converting from ANA to ANA.             | 0       |
| PLx06     | Operation mode selection | 0: ANA → ANA<br>1: ANA → DIG<br>2: DIG → ANA                      | 0       |
| PLx10     | Input reference data     | The value to turn ON nvoTypxDout1 when converting from ANA to DIG | 999     |

| Parameter | Name                  | Explanation   | Default |
|-----------|-----------------------|---|---------|
| PLx11     | Input reference data  | The value to turn ON nvoTypxDout1 when converting from ANA to DIG     | 999     |
| PLx12     | Input reference data  | The value to turn ON nvoTypxDout1 when converting from ANA to DIG     | 999     |
| PLx13     | Input reference data  | The value to turn ON nvoTypxDout1 when converting from ANA to DIG     | 999     |
| PLx14     | Input reference data  | The value to turn ON nvoTypxDout2 when converting from ANA to DIG     | 999     |
| PLx15     | Input reference data  | The value to turn ON nvoTypxDout2 when converting from ANA to DIG     | 999     |
| PLx16     | Input reference data  | The value to turn ON nvoTypxDout2 when converting from ANA to DIG     | 999     |
| PLx17     | Input reference data  | The value to turn ON nvoTypxDout2 when converting from ANA to DIG     | 999     |
| PLx18     | Output reference data | The data to be sent if nviTypxDin1=ON when converting from DIG to ANA | -       |
| PLx19     | Output reference data | The data to be sent if nviTypxDin2=ON when converting from DIG to ANA | -       |
| PLx20     | Output reference data | The data to be sent if nviTypxDin3=ON when converting from DIG to ANA | -       |

### ■ Operation

#### Conversion from ANA to ANA (PLx02 (operation mode selection) = 0)

- Example: Conversion from percent to Temp



#### Conversion from ANA to DIG (PLx02 (operation mode selection) = 1)

The value of nviTypxAin is compared with the set values of PLx10 to 17, and when the value of nviTypxAin agrees with a set value of PLx10 to 17, the Dout corresponding to the parameter of the agreed value turns ON. If an invalid data is input, the outputs turn OFF.

- Example: Conversion from SNVT\_lev\_percent to SNVT\_switch  
 PLx10: 10.000%, PLx11: 30.000%, PLx12: 50.000%, PLx13: 70.000%,  
 PLx14: 20.000%, PLx15: 40.000%, PLx16: 60.000%, PLx17: 80.000%

| ON Output    | Data of nviTypxAin (SNVT_lev_percent) |   |    |    |    |    |    |    |    |    |
|--------------|---------------------------------------|---|----|----|----|----|----|----|----|----|
|              | 0                                     | 5 | 10 | 20 | 25 | 30 | 35 | 40 | 80 | 75 |
| nvoTypxDout1 | ○                                     | ○ | ●  | ○  | ○  | ●  | ○  | ○  | ○  | ○  |
| nvoTypxDout2 | ○                                     | ○ | ○  | ●  | ○  | ○  | ○  | ●  | ●  | ○  |

●: Output signal ON, ○: Output signal OFF

- Example: Conversion from SNVT\_hvac\_mode to SNVT\_switch  
 PLx10: 1 (HEAT), PLx11: 3 (COOL), PLx12: 0 (AUTO), PLx13: 2 (WRMUP),  
 PLx14: 2 (WRMUP), PLx15: 6 (OFF), PLx16: 999, PLx17: 999

| ON Output    | Data of nviTypxAin (SNVT_lev_percent) |   |   |   |   |   |   |   |   |    |
|--------------|---------------------------------------|---|---|---|---|---|---|---|---|----|
|              | 0                                     | 4 | 6 | 2 | 1 | 6 | 2 | 7 | 3 | FF |
| nvoTypxDout1 | ●                                     | ○ | ○ | ● | ● | ○ | ● | ○ | ● | ○  |
| nvoTypxDout2 | ○                                     | ○ | ● | ● | ○ | ● | ● | ○ | ○ | ○  |


- : Output signal ON, ○: Output signal OFF

**Conversion from DIG to ANA (PLx02 (operation mode selection) = 2)**

When nviTypxDin1 is ON, the set value of PLx18 is output to nvoTypxAout.  
 When nviTypxDin2 is ON, the set value of PLx19 is output to nvoTypxAout.  
 When nviTypxDin3 is ON, the set value of PLx20 is output to nvoTypxAout.

◆ **Save Data Function**

■ **Function Image**



■ **Network Variables and Parameters**

The Save Data function saves the input data at reception. The saved data is not cleared after the power turns OFF.

**Network Variables**

| Network Variable | Variable Type    | Type Change | Name and Function |
|------------------|------------------|-------------|-------------------|
| nviDtlxAin       | SNVT_lev_percent | Possible    | -                 |
| nvoDtlxAout      | SNVT_lev_percent | Possible    | -                 |

**Parameters**

| Parameter | Name          | Explanation                         | Default |
|-----------|---------------|-------------------------------------|---------|
| Pox00     | Variable type | Impossible to set from the Operator | 0       |

■ **Operation**

The analog input data is saved in the EEPROM to prevent losing the data following a power failure. Usually, the data of nviDtlxAin is sent to nvoDtlxAout.

**NOTICE** *Damage to Equipment. Do not change the input network variables of Save Data Function unless absolutely necessary. Failure to comply will greatly shorten the life of EEPROM.*

◆ **Standard Network Variable Types (SNVTs)**

The following five standard network variable types can be selected from the Operator for SNVT regarded as the data.

| Parameter Setting | Name                                   | Variable Type    | Description  |
|-------------------|--|------------------|--|
| 0                 | Percent<br>(Humidity, frequency, etc.) | SNVT_lev_percent | SNVT#: 81<br>Measurement: Percent Level or Humidity<br>Data type: Fixed Point Scalar - signed long<br>Data size: 2 bytes<br>Data range (Resolution): -163.84 to 163.83% (0.005%/bit).<br>The value 0x7FFF represents invalid data. |
| 1                 | Pressure                               | SNVT_Press       | SNVT#: 30<br>Measurement: Gauge Pressure<br>Data type: Fixed Point Scalar - signed long<br>Data size: 2 bytes<br>Data range (Resolution):<br>-3,276.8 to 3,276.7 kilopascals (0.1 kPa)   |
| 2                 | Pressure                               | SNVT_Press_p     | SNVT#: 113<br>Measurement: Gauge Pressure<br>Data type: Fixed Point Scalar - signed long<br>Data size: 2 bytes<br>Data range (Resolution):<br>-32,768 to 32,766 Pascals (1 Pa).<br>The value 0x7FFF represents invalid data.       |

| Parameter Setting | Name   | Variable Type  | Description   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
|-------------------|--|--|---|--|--|--|---|------------|--|---|------------|--------------|---|------------------|--------------------------------------|---|------------|--------------|---|-------------------|----------------------------------|---|----------------|-------------------------------|---|-----------|------------------------------------|---|------------|------------------------|---|------------------|---------------------------------|---|----------------|------------------------------------|----|-----------------|-------------------------------------|----|-----------|-----------------|------|-----------|
| 3                 | Flow   | SNVT_flow  | SNVT#: 15<br>Measurement: Flow<br>Data type: Fixed Point Scalar - unsigned long<br>Data size: 2 bytes<br>Data range (Resolution):<br>0 to 65,534 l/s (1 l/s).<br>The value 0xFFFF represents invalid data.                                |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 4                 | Temperature  | SNVT_temp_p  | SNVT#: 105<br>Measurement: Temperature<br>Data type: Fixed Point Scalar - signed long<br>Data size: 2 bytes<br>Data range (Resolution):<br>-273.17 to 327.66°C (0.01°C).<br>The value 0x7FFF represents invalid data.                     |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 5                 | Concentration  | SNVT_ppm   | SNVT#: 29<br>Measurement: Concentration<br>Data type: Fixed Point Scalar - unsigned long<br>Data size: 2 bytes<br>Data range (Resolution):<br>0 .. 65,535 parts per million (1 ppm)<br>The value 0xFFFF (65,535) represents invalid data. |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 6                 | HVAC mode  | SNVT_HVAC_mode   | SNVT#: 108<br>Contents: HVAC mode<br>Data type: Enumeration Scalar<br>Data size: 1 bytes<br>Data range (Resolution): hvac_t Enumeration<br>Typedef File: SNVT_HV.H  |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
|                   | Enum Definitions<br>• Value Identifier <table border="1"> <thead> <tr> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>HVAC_AUTO:</td> <td>Controller automatically changes between application modes</td> </tr> <tr> <td>1</td> <td>HVAC_HEAT:</td> <td>Heating only</td> </tr> <tr> <td>2</td> <td>HVAC_MRNG_WRMUP:</td> <td>Application-specific morning warm-up</td> </tr> <tr> <td>3</td> <td>HVAC_COOL:</td> <td>Cooling only</td> </tr> <tr> <td>4</td> <td>HVAC_NIGHT_PURGE:</td> <td>Application-specific night purge</td> </tr> <tr> <td>5</td> <td>HVAC_PRE_COOL:</td> <td>Application-specific pre-cool</td> </tr> <tr> <td>6</td> <td>HVAC_OFF:</td> <td>Controller not controlling outputs</td> </tr> <tr> <td>7</td> <td>HVAC_TEST:</td> <td>Equipment being tested</td> </tr> <tr> <td>8</td> <td>HVAC_EMERG_HEAT:</td> <td>Emergency heat mode (heat pump)</td> </tr> <tr> <td>9</td> <td>HVAC_FAN_ONLY:</td> <td>Air not conditioned, fan turned on</td> </tr> <tr> <td>10</td> <td>HVAC_FREE_COOL:</td> <td>Cooling with compressor not running</td> </tr> <tr> <td>11</td> <td>HVAC_ICE:</td> <td>Ice-making mode</td> </tr> <tr> <td>0xFF</td> <td>HVAC_NUL:</td> <td>Value not available</td> </tr> </tbody> </table> |  |   |  |  |  | 0 | HVAC_AUTO: | Controller automatically changes between application modes | 1 | HVAC_HEAT: | Heating only | 2 | HVAC_MRNG_WRMUP: | Application-specific morning warm-up | 3 | HVAC_COOL: | Cooling only | 4 | HVAC_NIGHT_PURGE: | Application-specific night purge | 5 | HVAC_PRE_COOL: | Application-specific pre-cool | 6 | HVAC_OFF: | Controller not controlling outputs | 7 | HVAC_TEST: | Equipment being tested | 8 | HVAC_EMERG_HEAT: | Emergency heat mode (heat pump) | 9 | HVAC_FAN_ONLY: | Air not conditioned, fan turned on | 10 | HVAC_FREE_COOL: | Cooling with compressor not running | 11 | HVAC_ICE: | Ice-making mode | 0xFF | HVAC_NUL: |
|                   |  |  |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 0                 | HVAC_AUTO:   | Controller automatically changes between application modes |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 1                 | HVAC_HEAT:   | Heating only   |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 2                 | HVAC_MRNG_WRMUP:   | Application-specific morning warm-up                       |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 3                 | HVAC_COOL:   | Cooling only   |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 4                 | HVAC_NIGHT_PURGE:  | Application-specific night purge                           |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 5                 | HVAC_PRE_COOL:   | Application-specific pre-cool                              |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 6                 | HVAC_OFF:  | Controller not controlling outputs                         |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 7                 | HVAC_TEST:   | Equipment being tested                                     |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 8                 | HVAC_EMERG_HEAT:   | Emergency heat mode (heat pump)                            |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 9                 | HVAC_FAN_ONLY:   | Air not conditioned, fan turned on                         |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 10                | HVAC_FREE_COOL:  | Cooling with compressor not running                        |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 11                | HVAC_ICE:  | Ice-making mode  |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 0xFF              | HVAC_NUL:  | Value not available  |   |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |
| 7                 | HVAC mode  | SNVT_HVAC_state  | SNVT#: 112<br>Contents: HVAC status<br>Data type: Structure<br>Data size: 12 bytes  |  |  |  |   |            |  |   |            |              |   |                  |                                      |   |            |              |   |                   |                                  |   |                |                               |   |           |                                    |   |            |                        |   |                  |                                 |   |                |                                    |    |                 |                                     |    |           |                 |      |           |

| Parameter Setting | Name   | Variable Type | Description |
|-------------------|--|---------------|-------------|
|                   | <pre> Structure typedef struct { hvac_t mode; signed longheat_output_primary; signed longheat_output_secondary; signed longcool_output; signed longecon_output; signed longfan_output; unsignedin_alarm; } SNVT_hvac_status; Field Definitions Field Units Valid Range Notes modehvac_tcompatible with SNVT_hvac_mode heat_output_primarySNVT_lev_percent-163.83 .. +163.83% primary heat output heat_output_secondarySNVT_lev_percent-163.83 .. +163.83% secondary heat output cool_outputSNVT_lev_percent-163.83 .. +163.83% cooling output econ_outputSNVT_lev_percent-163.83 .. +163.83% economizer output fan_outputSNVT_lev_percent-163.83 .. +163.83% fan output in_alarmboolean0 .. 11 means unit is in alarm                     </pre> |               |             |

## 12 European Standards



**Figure 12.1 CE Mark**

The CE mark indicates compliance with European safety and environmental regulations.

European standards include the Machinery Directive for machine manufacturers, the Low Voltage Directive for electronics manufacturers, and the EMC Directive for controlling noise.

It is required for engaging in business and commerce in Europe.

This option displays the CE mark based on the EMC guidelines.

EMC Directive: 2014/30/EU

Drives used in combination with this option and devices used in combination with the drive must also be CE certified and display the CE mark.

When using drives displaying the CE mark in combination with other devices, it is ultimately the responsibility of the user to ensure compliance with CE standards. Verify that conditions meet European standards after setting up the device.

### ◆ EMC Directive Compliance

This option is tested according to European standard EN 61800-3:2004/A1:2012 and complies with the EMC Directive. The CE marking is declared based on the harmonized standards.


### ■ Option Installation

Verify the following installation conditions to make sure that other devices and machinery used with this option and drive also comply with EMC guidelines:


1. Use dedicated shield cable for the option and external device (encoder, I/O device, master), or run the wiring through a metal conduit.




2. Keep wiring as short as possible and ground the largest possible surface area of the shield to the metal panel according to [Figure 12.2](#) and [Figure 12.3](#).



**Figure 12.2 Option Installation for CE Compliance: 1000-Series, GA700, GA800**




**Figure 12.3 Option Installation for CE Compliance: HV600**



**Figure 12.4 Option Installation for CE Compliance: FP605**

3. Ground the largest possible surface area of the shield to the metal panel.  
Yaskawa recommends using cable clamps.



A - Braided shield cable  
B - Metal panel

C - Cable clamp (conductive)

Figure 12.5 Ground Area

## 13 Specifications

### ◆ Specifications

Table 13.1 Option Specifications

| Items                         | Specifications   |
|-------------------------------|--|
| Model                         | SI-W3  |
| Node Type                     | Host Application Node  |
| Communication Speed           | 78 kbps  |
| Communication IC              | Neuron chip FT3120   |
| Communication Driver          | FT-X1 (free topology)  |
| Communication Protocol        | LonTalk protocol node  |
| Network Variable              | Total: 236<br>Standard Network Variable Types (SNVT): Variable Speed Motor Drive function profile Ver1.1   |
| Network Variable Alias        | Maximum: 50  |
| Maximum Number of Connections | 64 (in one segment)  |
| Total Wiring Length           | Max 500 m  |
| Ambient Temperature           | -10°C - +50°C (14°F - 122°F)   |
| Humidity                      | Up to 95% RH (no condensation)   |
| Storage Temperature           | -20°C - +60°C (-4°F - 140°F) allowed for short-term transport of the product   |
| Area of Use                   | Indoors and free from: <ul style="list-style-type: none"> <li>• Oil mist, corrosive gas, flammable gas, and dust</li> <li>• Radioactive materials or flammable materials, including wood</li> <li>• Harmful gas or fluids</li> <li>• Salt</li> <li>• Direct sunlight</li> <li>• Falling foreign objects</li> </ul> |
| Altitude                      | Up to 1000 m (3280 ft)   |

## 14 Disposal

### ◆ Disposal Instructions

Correctly dispose of the product and packing material as specified by applicable regional, local, and municipal laws and regulations.

---

**◆ WEEE Directive**

The wheelie bin symbol on this product, its manual, or its packaging identifies that you must recycle it at the end of its product life.

You must discard the product at an applicable collection point for electrical and electronic equipment (EEE). Do not discard the product with usual waste.

---

## Revision History

| Date of Publication | Revision Number | Section    | Revised Content  |
|---------------------|-----------------|------------|--|
| November 2021       | 3               | All        | Addition: Information on FP605<br>Revision: Reviewed and corrected entire documentation      |
| February 2020       | 2               | All        | Addition: Applicable product series<br>Revision: Reviewed and corrected entire documentation |
|                     |                 | Chapter 14 | Addition: Disposal   |
| August 2018         | 1               | All        | Addition: Applicable product series  |
| December 2016       | -               | -          | First Edition  |



# YASKAWA AC Drive Option LonWorks Technical Manual

---

## **DRIVE CENTER (INVERTER PLANT)**

2-13-1, Nishimiyaichi, Yukuhashi, Fukuoka, 824-8511, Japan  
Phone: +81-930-25-2548 Fax: +81-930-25-3431  
[www.yaskawa.co.jp](http://www.yaskawa.co.jp)

## **YASKAWA ELECTRIC CORPORATION**

New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minatoku, Tokyo, 105-6891, Japan  
Phone: +81-3-5402-4502 Fax: +81-3-5402-4580  
[www.yaskawa.co.jp](http://www.yaskawa.co.jp)

## **YASKAWA AMERICA, INC.**

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.  
Phone: +1-800-YASKAWA (927-5292) or +1-847-887-7000 Fax: +1-847-887-7310  
[www.yaskawa.com](http://www.yaskawa.com)

## **YASKAWA ELÉTRICO DO BRASIL LTDA.**

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil  
Phone: +55-11-3585-1100 Fax: +55-11-3585-1187  
[www.yaskawa.com.br](http://www.yaskawa.com.br)

## **YASKAWA EUROPE GmbH**

Hauptstraße 185, 65760 Eschborn, Germany  
Phone: +49-6196-569-300 Fax: +49-6196-569-398  
E-mail: [info@yaskawa.eu.com](mailto:info@yaskawa.eu.com)  
[www.yaskawa.eu.com](http://www.yaskawa.eu.com)

## **YASKAWA ELECTRIC KOREA CORPORATION**

35F, Three IFC, 10 Gukjegeumyung-ro, Yeongdeungpo-gu, Seoul, 07326, Korea  
Phone: +82-2-784-7844 Fax: +82-2-784-8495  
[www.yaskawa.co.kr](http://www.yaskawa.co.kr)

## **YASKAWA ASIA PACIFIC PTE. LTD**

30A, Kallang Place, #06-01, 339213, Singapore  
Phone: +65-6282-3003 Fax: +65-6289-3003  
[www.yaskawa.com.sg](http://www.yaskawa.com.sg)

## **YASKAWA ELECTRIC (THAILAND) CO., LTD.**

59, 1F-5F, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand  
Phone: +66-2-017-0099 Fax: +66-2-017-0799  
[www.yaskawa.co.th](http://www.yaskawa.co.th)

## **YASKAWA ELECTRIC (CHINA) CO., LTD.**

22F, Link Square 1, No.222, Hubin Road, Shanghai, 200021, China  
Phone: +86-21-5385-2200 Fax: +86-21-5385-3299  
[www.yaskawa.com.cn](http://www.yaskawa.com.cn)

## **YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE**

Room 1011, Tower W3 Oriental Plaza, No. 1, East Chang An Avenue,  
Dong Cheng District, Beijing, 100738, China  
Phone: +86-10-8518-4086 Fax: +86-10-8518-4082

## **YASKAWA ELECTRIC TAIWAN CORPORATION**

12F, No. 207, Section 3, Beishin Road, Shindian District, New Taipei City 23143, Taiwan  
Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 or +886-2-8913-1519  
[www.yaskawa.com.tw](http://www.yaskawa.com.tw)


## **YASKAWA INDIA PRIVATE LIMITED**

#17/A, Electronics City, Hosur Road, Bengaluru, 560 100 (Karnataka), India  
Phone: +91-80-4244-1900 Fax: +91-80-4244-1901  
[www.yaskawaindia.in](http://www.yaskawaindia.in)

---

# YASKAWA

YASKAWA ELECTRIC  
CORPORATION



\*SIEPC73060093\*

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2016 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP C730600 93D <3>-0  
Published in Japan November 2021  
20-2-22  
Original Instructions