


## YASKAWA Z1000 Bypass Option Ethernet/IP Single and Dual-Port Technical Manual

Type: SI-EN3/SI-EN3D

Applicable Products : Z1B1-

To properly use the product, read this manual thoroughly and retain for easy reference, inspection, and maintenance. Ensure the end user receives this manual.



[Download PDF](#)



Copyright © 2016 YASKAWA AMERICA, INC. All rights reserved.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

# Table of Contents

---



1	PREFACE AND SAFETY.....	4
2	PRODUCT OVERVIEW.....	7
3	RECEIVING.....	9
4	OPTION COMPONENTS.....	10
5	INSTALLATION PROCEDURE.....	12
6	RELATED BYPASS PARAMETERS.....	23
7	COMMON TASKS.....	25
8	CONFIGURING MESSAGING.....	27
9	OUTPUT ASSEMBLIES (DRIVE CONSUMES).....	28
10	INPUT ASSEMBLIES (DRIVE PRODUCES).....	36
11	GENERAL CLASS OBJECTS.....	47
12	VENDOR-SPECIFIC (YASKAWA) CLASS OBJECTS.....	57
13	WEB INTERFACE.....	59
14	TROUBLESHOOTING.....	66
15	SPECIFICATIONS.....	69

# 1 Preface and Safety

Yaskawa manufactures products used as components in a wide variety of industrial systems and equipment. The selection and application of Yaskawa products remain the responsibility of the equipment manufacturer or end user. Yaskawa accepts no responsibility for the way its products are incorporated into the final system design. Under no circumstances should any Yaskawa product be incorporated into any product or design as the exclusive or sole safety control. Without exception, all controls should be designed to detect faults dynamically and fail safely under all circumstances. All systems or equipment designed to incorporate a product manufactured by Yaskawa must be supplied to the end user with appropriate warnings and instructions as to the safe use and operation of that part. Any warnings provided by Yaskawa must be promptly provided to the end user. Yaskawa offers an express warranty only as to the quality of its products in conforming to standards and specifications published in the Yaskawa manual. **NO OTHER WARRANTY, EXPRESS OR IMPLIED, IS OFFERED.** Yaskawa assumes no liability for any personal injury, property damage, losses, or claims arising from misapplication of its products.

## ◆ Applicable Documentation

The following manuals are available for the SI-EN3/SI-EN3D option:

	<p>Yaskawa Bypass 1000-Series Option Single and Dual-Port SI-EN3/SI-EN3D Technical Manual (This manual)</p> <p>The Technical Manual contains information required to install the option and set up related bypass parameters.</p>
	<p>Z1000 Bypass Technical Manual (SIEPYAIZ1B01)</p> <p>This manual provides detailed information on parameter settings and bypass functions. Use this manual to expand bypass functionality and to take advantage of higher performance features. This manual is available for download on our documentation website, <a href="http://yaskawa.com">yaskawa.com</a>.</p>

## ◆ Terms

**Note:** Indicates supplemental information that is not related to safety messages.

**Bypass:** Yaskawa Z1000 Bypass Unit

**Drive:** Yaskawa 1000-Series AC Drive

**Option:** Yaskawa 1000-Series SI-EN3 EtherNet/IP Option and SI-EN3D Dual-Port EtherNet/IP Option

## ◆ Registered Trademarks

- EtherNet/IP is a trademark of the ODVA.
- All trademarks are the property of their respective owners.

## ◆ Supplemental Safety Information

Read and understand this manual before installing, operating, or servicing this option. The option must be installed according to this manual and local codes.

The following conventions are used to indicate safety messages in this manual. Failure to heed these messages could result in serious or possibly even fatal injury or damage to the products or to related equipment and systems.

**⚠ DANGER**

**Indicates a hazardous situation, which, if not avoided, will result in death or serious injury.**

**⚠ WARNING**

Indicates a hazardous situation, which, if not avoided, could result in death or serious injury.

**WARNING!** may also be indicated by a bold key word embedded in the text followed by an italicized safety message.

**⚠ CAUTION**

Indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury.

**CAUTION!** may also be indicated by a bold key word embedded in the text followed by an italicized safety message.

**NOTICE**

Indicates a property damage message.

**NOTICE:** may also be indicated by a bold key word embedded in the text followed by an italicized safety message.

**■ General Safety****General Precautions**

- The diagrams in this manual may be indicated without covers or safety shields to show details. Replace the covers or shields before operating the drive and run the drive according to the instructions described in this manual.
- Any illustrations, photographs, or examples used in this manual are provided as examples only and may not apply to all products to which this manual is applicable.
- The products and specifications described in this manual or the content and presentation of the manual may be changed without notice to improve the product and/or the manual.
- When ordering a new copy of the manual due to damage or loss, contact your Yaskawa representative or the nearest Yaskawa sales office and provide the manual number shown on the front cover.
- If nameplate becomes worn or damaged, order a replacement from your Yaskawa representative or the nearest Yaskawa sales office.

**⚠ DANGER**

**Heed the safety messages in this manual.**

Failure to comply will result in death or serious injury.

The operating company is responsible for any injuries or equipment damage resulting from failure to heed the warnings in this manual.

**Electrical Shock Hazard**

**Do not connect or disconnect wiring while the power is on.**

Failure to comply will result in death or serious injury.

Failure to comply will result in death or serious injury. Before servicing, disconnect all power to the equipment. The internal capacitor remains charged even after the power supply is turned off. The charge indicator LED will extinguish when the DC bus voltage is below 50 Vdc. To prevent electric shock, wait for at least the time specified on the warning label once all indicators are OFF, and then measure the DC bus voltage level to confirm it has reached a safe level.

**NOTICE**

**Observe proper electrostatic discharge procedures (ESD) when handling the drive and circuit boards.**

Failure to comply may result in ESD damage to the drive circuitry.

**Do not perform a withstand voltage test on any part of the drive.**

Failure to comply could result in damage to the sensitive devices within the drive.

**Do not operate damaged equipment.**

Failure to comply could result in further damage to the equipment.

Do not connect or operate any equipment with visible damage or missing parts.

### NOTICE

**Do not expose the drive to halogen group disinfectants.**

Failure to comply may cause damage to the electrical components in the drive.

Do not pack the drive in wooden materials that have been fumigated or sterilized.

Do not sterilize the entire package after the product is packed.

## 2 Product Overview

### ◆ About this Product

The option provides a communications connection between the bypass and an ODVA EtherNet/IP network. The option connects the bypass to an EtherNet/IP network and facilitates the exchange of data.

This manual explains the handling, installation and specifications of this product.

EtherNet/IP is a communications link to connect industrial devices (such as smart motor controllers, operator interfaces, and variable frequency drives) as well as control devices (such as programmable controllers and computers) to a network. EtherNet/IP is a simple, networking solution that reduces the cost and time to wire and install factory automation devices, while providing interchangeability of like components from multiple vendors.

EtherNet/IP is an open device network standard.

By installing the option to a bypass unit, it is possible to do the following from an EtherNet/IP master device:

- Operate the bypass
- Operate the drive
- Monitor bypass status
- Monitor drive status
- Change bypass parameter settings



### ◆ Applicable Models

The option can be used with the bypass models in [Table 1](#).


**Table 1 Applicable Models**

Drive Series	Bypass Model Z1B1	Software Version <1>
Z1000	D002 to D273	VST800298 and later
	B001 to B304	

<1> See “PRG” on the drive nameplate for the software version number.

◆ **Bypass Nameplate**

The nameplate is located on the inside right wall of the Z1000 bypass enclosure.




- A – Input specifications**
- B – Output specifications**
- C – Replacement fuse specifications**
- D – Serial number**
- E – Bypass model number**
- F – Schematic document number**

Figure 1 Bypass Nameplate Information Example

◆ **Bypass Software Version Number**

The software version label for the bypass is located on the bypass PCB. The bypass PCB is located on the inside left wall of the Z1000 Bypass enclosure.



- A – Bypass PCB**
- B – Bypass Software Version Label**


Figure 2 Bypass Software Version Label

## 3 Receiving

Perform the following tasks upon receipt of the option:

- Inspect the option for damage. Contact the shipper immediately if the option appears damaged upon receipt.
- Verify receipt of the correct model by checking the model number printed on the name plate of the option package. *Refer to Option Components on page 10.*
- Contact your supplier if you have received the wrong model or the option does not function properly.

### ◆ Option Package Contents

Description	Option	Ground Wire	Screws (M3)	LED Label	Installation Manual
-		 </>	 </>	 </>	
Quantity	1	1	3	1	1

<1> The ground wire, ground wire screw (1) and LED labels are not required for option card installation to bypass units.

### ◆ Tools Required for Installation


A Phillips screwdriver (M3 metric or #1, #2 U.S. standard) is required to install the option and remove bypass front covers. Screw sizes vary by drive capacity. Select a screwdriver appropriate for the bypass capacity.

Use a short-shaft, magnetic screwdriver when installing the option card into the narrow enclosure models Z1B1D002 to Z1B1D074 and Z1B1B001 to Z1B1B077.

**Note:** Tools required to prepare the option cables for wiring are not listed in this manual.

## 4 Option Components

### ◆ SI-EN3 Single Port EtherNet/IP Option



- |   |   |
|---|---|
| <b>A – Option Connector (CN5)</b>               | <b>F – Communication connector CN1 (RJ45)</b> |
| <b>B – Installation hole</b>                    | <b>G – LED (LINK/ACT) &lt;2&gt;</b>           |
| <b>C – LED (MS) &lt;2&gt;</b>                   | <b>H – LED (10/100) &lt;2&gt;</b>             |
| <b>D – LED (NS) &lt;2&gt;</b>                   | <b>I – Option Nameplate</b>                   |
| <b>E – Grounded installation hole &lt;1&gt;</b> |   |

**Figure 3 Option Components (Single Port)**

- <1> The ground wire packaged loose in the option shipping package is not required for installation to Z1000 bypass units.
- <2> The LEDs are not visible when used in a bypass configuration. Use parameters U6-80 through U6-99 to monitor operation status. [Refer to Option Monitors on page 24.](#)

## ◆ SI-EN3D Dual-Port EtherNet/IP Option




Figure 4 Option Components (Dual-Port)

- <1> The ground wire packaged loose in the option shipping package is not required for installation to Z1000 bypass units.
- <2> The LEDs are not visible when used in a bypass configuration. Use parameters U6-80 through U6-99 to monitor operation status. [Refer to Option Monitors on page 24.](#)

# 5 Installation Procedure

This section explains how to properly mount and install the communication option card to the Z1000 Bypass.

### ◆ Section Safety

#### DANGER

##### Electrical Shock Hazard

**Do not connect or disconnect wiring while the power is on.**

Failure to comply will result in death or serious injury.

Disconnect all power to the bypass and wait at least the amount of time specified on the bypass front cover safety label. After all indicators are off, measure the DC bus voltage to confirm safe level, and check for unsafe voltages before servicing. The internal capacitor remains charged after the power supply is turned off.

#### WARNING

##### Electrical Shock Hazard

**Do not remove the front covers of the bypass while the power is on.**

Failure to comply could result in death or serious injury.

The diagrams in this section may include options and bypass units without covers or safety shields to show details. Be sure to reinstall covers or shields before operating any devices. The option should be used according to the instructions described in this manual.

**Do not allow unqualified personnel to use equipment.**

Failure to comply could result in death or serious injury.

Maintenance, inspection, and replacement of parts must be performed only by authorized personnel familiar with installation, adjustment, and maintenance of this product.

**Do not touch circuit boards while the power is on.**

Failure to comply could result in death or serious injury.

**Do not use damaged wires, stress the wiring, or damage the wire insulation.**

Failure to comply could result in death or serious injury.

**Do not use damaged wires, place excessive stress on wiring, or damage the wire insulation.**

Failure to comply could result in death or serious injury.

##### Fire Hazard

**Tighten all terminal screws to the specified tightening torque.**

Loose electrical connections could result in death or serious injury by fire due to overheating of electrical connections.

#### NOTICE

**Observe proper electrostatic discharge procedures (ESD) when handling the bypass and circuit boards.**

Failure to comply may result in ESD damage to the bypass circuitry.

**Never shut the power off while the bypass is outputting voltage.**

Failure to comply may cause the application to operate incorrectly or damage the bypass.

**Do not operate damaged equipment.**

Failure to comply may cause further damage to the equipment.

Do not connect or operate any equipment with visible damage or missing parts.

## NOTICE

**Do not use unshielded cable for control wiring.**

Failure to comply may cause electrical interference resulting in poor system performance.

Use shielded twisted-pair wires and ground the shield to the ground terminal of the bypass.

**Properly connect all pins and connectors.**

Failure to comply may prevent proper operation and possibly damage equipment.

**Check wiring to ensure that all connections are correct after installing the option and connecting any other devices.**

Failure to comply could result in damage to the option.

◆ **Prior to Installing the Option**

**NOTICE:** Install communications options on the bypass control PCB. Do not install communications options on the Z1000 drive PCB. Improperly connected communications options will cause erroneous operation.

■ **Verify Bypass Operation**

Verify that the bypass functions normally without the option installed. Refer to the Z1000 Bypass Technical Manual (SIEPYAIZ1B01) for information on wiring and connecting the bypass unit.


■ **Prepare Network Cables**

Determine the length of cable required to connect from the option to a network device and attach all connectors to network cables before installing the option. Refer to [Table 3 Communication Cable Specifications](#) for details.

The communication connection point on the option is designated CN1. CN1 may have 2 ports depending on the option type.

CN1 is the connection point for a customer-supplied network communication cable with a modular RJ45 connector.

**Table 2 8-Way Modular Connector (Customer-Supplied)**

Male 8-Way Modular Connector	Pin	Description
	1 (Pair 2)	Transmit data (TXD) +
	2 (Pair 2)	Transmit data (TXD) -
	3 (Pair 3)	Receive data (RXD) +
	4 (Pair 1)	Not used <1>
	5 (Pair 1)	Not used <1>
	6 (Pair 3)	Receive data (RXD) -
	7 (Pair 4)	Not used <1>
	8 (Pair 4)	Not used <1>

<1> Not used for 10 Mbps and 100 Mbps networks.


**Table 3 Communication Cable Specifications**

Communication Protocol	Description
EtherNet/IP	Only use cable recommended for EtherNet/Industrial Protocol (EtherNet/IP™). Using a cable not specifically recommended may cause the option or bypass to malfunction. Refer to the ODVA website for more information on network cabling ( <a href="http://www.odva.org">www.odva.org</a> ).

### ■ Bypass Unit Components

*Figure 5* shows a front view of the bypass control board with the option connection terminals and related components for reference.

**Note:** Bypass PCB location varies by model.



**A – Bypass PCB**

**B – Option card connector (CN5)**

**C – Bypass software version number**

**D – Communications port CN2**

**Figure 5 Front View of Bypass PCB**

## ◆ Remove the Bypass Front Cover

**WARNING!** *Electrical Shock Hazard. Do not open the front cover of the bypass while the power is on. Failure to comply may result in death or serious injury. Make sure that the disconnect handle is in the “OFF” position before attempting to open the front cover.*

### ■ Models Z1B1D002 to D074 and Z1B1B001 to B077

1. Turn the disconnect handle to the “OFF” position and wait the appropriate amount of time for voltage to dissipate. Verify using a multimeter and follow all appropriate lockout/tagout procedures.

**NOTICE:** *Damage to Equipment. Observe proper electrostatic discharge procedures (ESD) when handling the option, bypass, and circuit boards. Failure to comply may result in ESD damage to circuitry.*




Figure 6 Disconnect Power

## 5 Installation Procedure

2. Remove the two front cover screws using a #2 Phillips screwdriver.




Figure 7 Remove Front Cover Screws

3. Lift the cover up and gently pull forward to remove the front cover.

**NOTICE:** Do not damage the Cat5e cable that connects the keypad to the bypass control PCB when removing the front cover. Failure to comply may cause erroneous operation.





Figure 8 Lift and Remove Front Cover

**Models Z1B1D088 to D273 and Z1B1B096 to B302**


1. Turn the disconnect handle to the “OFF” position and wait the appropriate amount of time for voltage to dissipate. Verify using a multimeter and follow all appropriate lockout/tagout procedures.

**NOTICE:** *Damage to Equipment. Observe proper electrostatic discharge procedures (ESD) when handling the option, bypass, and circuit boards. Failure to comply may result in ESD damage to circuitry.*



**Figure 9 Disconnect Power**

2. Turn the flat head screw fasteners on the front cover 1/2 turn counter-clockwise.



**Figure 10 Turn Front Cover Fasteners**

## 5 Installation Procedure

---

3. Carefully swing open the bypass front cover door.

**NOTICE:** Do not damage the Cat5e cable that connects the keypad to the bypass control PCB when removing the front cover. Failure to comply may cause erroneous operation.




Figure 11 Swing Open Door

## ◆ Install the Option

**DANGER! Electrical Shock Hazard.** Do not connect or disconnect wiring while the power is on. Failure to comply could result in death or serious injury. Before installing the option, disconnect all power to the bypass and wait at least the amount of time specified on the bypass front cover safety label. After all indicators are off, measure the DC bus voltage to confirm safe level, and check for unsafe voltages before servicing. The internal capacitor remains charged after the power supply is turned off.

1. Fasten the option card to the metal standoffs on the bypass PCB using two screws included in the option kit. Use a short-shaft, magnetic screwdriver for narrow enclosure models Z1B1D002 to Z1B1D074 and Z1B1B001 to Z1B1B077. Tighten each screw to 0.5 to 0.6 N•m (4.4 to 5.3 in lbs).




Figure 12 Insert Option into Bypass PCB CN5 Connector Port - Model Z1B1D002

## 5 Installation Procedure

- For single-port connections using SI-EN3, connect the customer-supplied Cat5e network cable to the option by firmly inserting the RJ45 8-pin connector into the CN1 modular connector port on the option board. For dual-port connections using SI-EN3D, skip to Step 3.




Figure 13 Connect Network Cable to Option

**NOTICE:** Separate control circuit wiring from main circuit wiring and other high-power lines. Improper wiring practices could result in bypass malfunction due to electrical interference.

### IGMP Snooping

Switches implementing IGMP Snooping are strongly recommended to limit devices to only receive the multicast packets in which they are interested.

### Option Connection Diagram




Figure 14 Option Connection Diagram (Single Port CN1 Connection)

- For dual-port connections using SI-EN3D, connect the customer-supplied Cat5e network cables to the option by firmly inserting the RJ45 8-pin connectors into the CN1 modular connector ports on the option board.




Figure 15 Connect Network Cables to Option (Dual-Port CN1 Connection)

**NOTICE:** Separate control circuit wiring from main circuit wiring and other high-power lines. Improper wiring practices could result in bypass malfunction due to electrical interference.

### IGMP Snooping

Switches implementing IGMP Snooping are strongly recommended to limit devices to only receive the multicast packets in which they are interested.

### Option Connection Diagram




Figure 16 Option Connection Diagram (Dual-Port CN1 Connection)

### Dual-Port CN1 Connection

The dual CN1 network ports on the option board act as a switch to allow for flexibility in cabling topology. For example, a traditional star network topology may be employed by using a single port on the option board. Alternatively, a daisy-chained approach may be employed by using both CN1 ports. The daisy-chained approach reduces the requirements of central switch ports. A ring topology is also possible.




Figure 17 Topology Options

4. Replace and secure the bypass front cover.
5. Make sure no cables are pinched between the front covers and the bypass when replacing the covers.
6. Set bypass parameters according to Section [6 Related Bypass Parameters](#) on page [23](#).

### ◆ EDS Files for Use with Ethernet

For easy network implementation of bypass units equipped with the option, an EDS file can be obtained from:

U.S.: [yaskawa.com](http://yaskawa.com)

Europe: [yaskawa.eu.com](http://yaskawa.eu.com)

Japan: [e-mechatronics.com](http://e-mechatronics.com)

Other areas: Contact a Yaskawa representative.

**Note:** Download the option EDS file. The option will not function as a slave in the network without the appropriate EDS file.

### ◆ Option LED Display

The LEDs are not visible when used in a bypass configuration. Use parameters U6-80 through U6-99 to monitor operation status. [Refer to Option Monitors on page 24](#) for details.

## 6 Related Bypass Parameters

The following parameters are used to set up the bypass for operation with the option. Parameter setting instructions can be found in the drive manual.

Confirm proper setting of the parameters in [Table 4](#) before starting network communications. After changing parameter settings, cycle power to the bypass for the new settings to take effect.

**Table 4 Related Parameters**

No. (Addr. Hex)	Name	Description	Values
F6-02 (03A3)	External Fault from Comm. Option Detection Selection	0: Always detected 1: Detection during run only	Default: 0 Range: 0, 1
F6-03 (03A4)	External Fault from Comm. Option Operation Selection	0: Ramp to stop. Decelerate to stop using the deceleration time in C1-02. 1: Coast to stop 2: Fast Stop. Decelerate to stop using the deceleration time in C1-09. 3: Alarm only <↔>	Default: 1 Range: 0 to 3
Z1-07 (85CC)	Speed Reference Select <↔>	0: Operator 1: Analog Input 2: Bypass Serial 3: Option Board (CN5)	Default: 1 Range: 0 to 3
Z1-08 (85CD)	Run Command Select <↔>	0: Operator 1: Bypass Controller Digital Input 2: Bypass Serial 3: Option Board (CN5)	Default: 1 Range: 0 to 3
Z1-38 (85EB)	HOA Source Select	0: Operator 1: Digital Inputs 2: Ser Comm & Opt	Default: 0 Range: 0 to 2
Z1-39 (85EC)	Drive/Bypass Source Select	0: Operator 1: Digital Inputs 2: Serial Communications	Default: 0 Range: 0 to 2
Z4-01 (8700)	IP Address 1	Sets the most significant octet of network static IP address.	Default: 192 Range: 0 to 255
Z4-02 (8701)	IP Address 2	Sets the second most significant octet of network static IP address.	Default: 168 Range: 0 to 255
Z4-03 (8702)	IP Address 3	Sets the third most significant octet of network static IP address.	Default: 1 Range: 0 to 255
Z4-04 (8703)	IP Address 4	Sets the fourth most significant octet of network static IP address.	Default: 20 Range: 0 to 255
Z4-05 (8704)	Subnet Mask 1	Sets the most significant octet of network static subnet mask.	Default: 255 Range: 0 to 255
Z4-06 (8705)	Subnet Mask 2	Sets the second most significant octet of network static subnet mask.	Default: 255 Range: 0 to 255
Z4-07 (8706)	Subnet Mask 3	Sets the third most significant octet of network static subnet mask.	Default: 255 Range: 0 to 255
Z4-08 (8707)	Subnet Mask 4	Sets the fourth most significant octet of network static subnet mask.	Default: 0 Range: 0 to 255
Z4-09 (8708)	Gateway IP Address 1	Sets the most significant octet of network gateway address.	Default: 192 Range: 0 to 255
Z4-10 (8709)	Gateway IP Address 2	Sets the second most significant octet of network gateway address.	Default: 168 Range: 0 to 255
Z4-11 (870A)	Gateway IP Address 3	Sets the third most significant octet of network gateway address.	Default: 1 Range: 0 to 255
Z4-12 (870B)	Gateway IP Address 4	Sets the fourth most significant octet of network gateway address.	Default: 1 Range: 0 to 255
Z4-13 (870C)	IP Address Mode Select	0: User-Defined (Static IP) 1: BOOTP Setting 2: DHCP	Default: 2 Range: 0 to 2
Z4-14 (870D)	Duplex Select	0: Forced Half Duplex 1: Auto Negotiate Duplex Mode and Communication Speed 2: Forced Full Duplex	Default: 1 Range: 0 to 2
Z4-15 (870E)	Speed Mode Setting	10: 10 Mbps 100: 100 Mbps	Default: 10 Range: 10, 100

## 6 Related Bypass Parameters

No. (Addr. Hex)	Name	Description	Values
Z4-16 (870F)	Communication Loss Timeout	Control connection timeout value for detection of communication loss.	Default: 0 s Min.: 0 Max.: 300
Z4-17 (8710)	Ethernet Speed Scale	AC/DC Drive Object, Instance 1, Attribute 22	Default: 0 Min.: -15 Max.: 15
Z4-18 (8711)	Ethernet Current Scale	AC/DC Drive Object, Instance 1, Attribute 23	Default: 0 Min.: -15 Max.: 15
Z4-19 (8712)	Ethernet Torque Scale	AC/DC Drive Object, Instance 1, Attribute 24	Default: 0 Min.: -15 Max.: 15
Z4-20 (8713)	Ethernet Power Scale	AC/DC Drive Object, Instance 1, Attribute 26	Default: 0 Min.: -15 Max.: 15
Z4-21 (8714) <b>RUN</b>	Ethernet Voltage Scale	AC/DC Drive Object, Instance 1, Attribute 27	Default: 0 Min.: -15 Max.: 15
Z4-22 (8715)	Ethernet Time Scale	AC/DC Drive Object, Instance 1, Attribute 28	Default: 0 Min.: -15 Max.: 15
Z4-23 to Z4-32 (8716 to 871F)	Dynamic Output Assembly Parameters DOA116 1 to DOA116 10	Parameters used in Dynamic Output PZD	Default: 0 Range: 0 to FFFF
Z4-33 to Z4-42 (8720 to 8729)	Dynamic Input Assembly Parameters DIA166 1 to DIA166 10	Parameters used in Dynamic Input PZD	Default: 0 Range: 0 to FFFF

<1> When set to 3, the drive will continue to operate when a fault is detected. Take safety measures, such as installing an emergency stop switch.

<2> Available in bypass controller software versions VST800400 and later.

**Table 5 Option Monitors**

No.	Name	Description	Value Range
U6-80 to U6-83	Online IP Address	IP Address currently available; U6-80 is the most significant octet	0 to 255
U6-84 to U6-87	Online Subnet	Subnet currently available; U6-84 is the most significant octet	0 to 255
U6-88 to U6-91	Online Gateway	Gateway currently available; U6-88 is the most significant octet	0 to 255
U6-92	Online Speed	Link Speed	10: 10 Mbps 100: 100 Mbps
U6-93	Online Duplex	Duplex Setting	0: Half, 1: Full
U6-94	Port 2 Speed	Port 2 Link Speed	10: 10 Mbps 100: 100 Mbps
U6-95	Port 2 Duplex	Port 2 Duplex Setting	0: Half, 1: Full
U6-97	Option Software Version	Option Software Version	–
U6-98	First Fault	First Option Fault	–
U6-99	Current Fault	Current Option Fault	–

## 7 Common Tasks

This section describes common tasks when using an SI-EN3 or SI-EN3D option kit on a Z1000 bypass.

### ◆ Accessing Drive and Bypass Monitors and Parameters

Drive and Bypass monitors and parameters can be accessed using one of two methods.

- Explicit commands through Drive Parameter Object 100 and Monitor Control Object 125. The register addresses can be found in the Z1000 Bypass Technical Manual, SIEPYAIZ1B01. Details of how to access these through EtherNet/IP can be found in Section *12 Vendor-Specific (Yaskawa) Class Objects* on page 57.
- The register addresses can be programmed into the dynamic input or output parameters to place them into the IO of the PLC. Assembly pairs that contain dynamic IO include: 116-166, 117-167, 118-168, 119-169, and 120-170. Use parameters Z4-23 through Z4-42 to program the addresses.

Register addresses can be found in the Z1000 Bypass Technical Manual SIEPYAIZ1B01, MEMOBUS/Modbus Data Table section.

### ◆ Monitor Statuses

**Table 6 Monitor Various Statuses**

Status	Description	Drive Mode	Bypass Mode
Run	Read this status using the predefined bits in various assemblies or explicitly through drive register 0x4B.	x	-
	Read this status using address 8785H (bit 1). Read the status explicitly or enter 8785 into one of the dynamic input parameters.	-	x
Fault	Read this status using address 8785H (bit 2). Read the status explicitly or enter 8785 into one of the dynamic input parameters. <i>Table 7</i> shows what is returned based on bypass software version.	x	x
	Read this status with pre-defined IO assembly bits.	x	x <1>
Output Frequency	Read scaling determined by o1-03 in the IO assemblies.	x	-
	Read scaling in the IO assemblies.	-	x
Output Current	Read this status in assemblies 151, 155, and 166. Read the status explicitly using address 0026H (scaling = 0.1 A).	x	x <1>
	Read this status using register 8780H (scaling = 0.1A). Enter 8780 into a dynamic input parameter.	-	x <2>
Other Drive-specific Statuses	Read drive-specific statuses and monitors (U1-01 to U6-40) by placing them into acyclic commands or through dynamic input and output parameters. Refer to Z1000 Bypass Technical Manual (SIEPYAIZ1B01 ) for a list of monitors and their register addresses. Drive-specific addresses are valid only when the drive is energized. The drive may not be energized when in Bypass mode or when the service disconnect switch is OFF.	x	-
Bypass-specific Statuses	All other bypass-specific statuses and monitors can be read by placing them into the dynamic input and output parameters. Refer to Z1000 Bypass Technical Manual (SIEPYAIZ1B01 ) for a list of monitors and their register addresses.	-	x

<1> Available in bypass controller software versions VST800400 and later.

<2> Available in bypass controller software versions VST800299 and earlier.

**Table 7 Fault Status Bit**

Software Version	Pre-defined IO Assembly Bits	Bypass Address 8785 (bit 2)
VST800299 and earlier	Drive faults only	Drive or bypass faults
VST800400	Drive or bypass faults	Drive or bypass faults

### ◆ Issuing Bypass Commands

**Table 8 Issue Various Commands**

Command	Description
Frequency Reference	Set parameter Z1-07 to 3. Frequency reference is written using the predefined control word in the various IO assemblies (scaling determined by o1-03). It can also be written explicitly to register 0x0002.
Run/Stop	Set parameter Z1-08 to 3. Run/Stop command is written using the predefined Run control bits in the various assemblies. It can also be written explicitly to register 0x0001. <b>Note:</b> Bits 0 and 1 of BypCmd (8400H) are not valid for option cards.
Fault Reset	Fault Reset is written using the pre-defined control bits in the various assemblies or explicitly written to address 8400H (bit D) or Drive Register 0001H (bit 3).
Other Bypass Commands	Other bypass commands are written to addresses 8400H to 8407H. Refer to Z1000 Bypass Technical Manual (SIEPYAIZ1B01).

### ◆ Restrictions Using an SI-EN3 or SI-EN3D Option Card with a Bypass Unit

- NetRef and NetCtrl bits in the assemblies do not function on the bypass.
- bUS fault conditions such as link loss and connection timeouts declared by the option card will always fault the bypass and are not configurable to be alarms.
- bUS fault delay functionality is not available in bypass mode.

## 8 Configuring Messaging

This section provides information on methods used to control the drive with the option installed.

### ◆ Drive Polled Configuration

The assemblies in [Table 9](#) are available for polled I/O:

**Table 9 Supported Polled I/O Assemblies**

Assembly Number (Hex)	Description	Type	Bytes	Page
20 (14)	Basic Speed Control Output	Output	4	<a href="#">28</a>
21 (15)	Extended Speed Control Output	Output	4	<a href="#">28</a>
22 (16)	Speed and Torque Control Output	Output	6	<a href="#">29</a>
23 (17)	Extended Speed and Torque Control Output	Output	6	<a href="#">29</a>
70 (46)	Basic Speed Control Input	Input	4	<a href="#">36</a>
71 (47)	Extended Speed Control Input	Input	4	<a href="#">36</a>
72 (48)	Speed and Torque Control Input	Input	6	<a href="#">37</a>
73 (49)	Extended Speed and Torque Control Input	Input	6	<a href="#">37</a>
100 (64)	(Vendor Specific Yaskawa Electric (YE) Assy)-MEMOBUS/Modbus Message Output	Output	5	<a href="#">30</a>
101 (65)	(Vendor Specific Yaskawa Electric (YE) Assy)-Speed/Torque Control Output	Output	8	<a href="#">30</a>
115 (73)	(Vendor Specific Yaskawa Electric (YE) Assy)-Extended Speed/Torque Control Output	Output	40	<a href="#">32</a>
116 (74)	(Vendor Specific Yaskawa Electric (YE) Assy)-High Speed/Torque Control Output	Output	44	<a href="#">33</a>
150 (96)	(Vendor Specific Yaskawa Electric (YE) Assy)-MEMOBUS/Modbus Message Input	Input	5	<a href="#">38</a>
151 (97)	(Vendor Specific Yaskawa Electric (YE) Assy)-Speed/Torque Status Input	Input	8	<a href="#">39</a>
155 (9B)	(Vendor Specific Yaskawa Electric (YE) Assy)- Extended Speed/ Torque Status Input	Input	40	<a href="#">40</a>
166 (A6)	(Vendor Specific Yaskawa Electric (YE) Assy)-High Speed/Torque Status Input	Input	44	<a href="#">43</a>

## 9 Output Assemblies (Drive Consumes)

**Note:** The convention in this manual is from the PLC perspective. As such, an assembly is called an “Output Assembly” when outputted from the PLC and received by this node. This section details “Output Assemblies” that are “Consumed” by this drive.

### ◆ Basic Speed Control Output - 20 (0x14)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
20	0	0	–	–	–	–	–	Fault Reset	–	Run Fwd	
		1	–								
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Fault Reset	Fault Reset (0 to 1 transition: Fault Reset)
Speed Reference	Speed Command Sets drive speed reference. Speed reference data: Frequency reference/2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF Example: setting a reference of 4096 with a speed scale of 2: Speed reference data = 4096/2 <sup>2</sup> = 1024 = 0x0400 Hex or 10.24 Hz Unit depends on o1-03.

### ◆ Extended Speed Control Output - 21 (0x15)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
21	0	0	–	NetRef	NetCtrl	–	–	Fault Reset	Run Rev	Run Fwd	
		1	–								
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Run Rev	Reverse Run Command 0: Stop 1: Reverse Run
Fault Reset	Fault Reset (0 to 1 transition: Fault Reset)
NetCtrl	Run command from Network 0: Depends on b1-02 1: Enables the run command from network
NetRef	Speed reference from Network 0: Depends on b1-01 1: Enables the speed reference from network
Speed Reference	Speed Command Sets drive speed reference. Speed reference data: Frequency reference/2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF Example: setting a reference of 4096 with a speed scale of 2: Speed reference data = 4096/2 <sup>2</sup> = 1024 = 0x0400 Hex Unit depends on o1-03.

◆ Speed and Torque Control Output - 22 (0x16)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
22	0	0	-	-	-	-	-	Fault Reset	-	Run Fwd	
		1	-								
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								
	2	4	Torque Reference/Torque Limit (Low Byte)								
		5	Torque Reference/Torque Limit (High Byte)								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Fault Reset	Fault Reset (0 to 1 transition: Fault Reset)
Speed Reference	Speed Command Sets drive speed reference. Speed reference data: Frequency reference/2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF Example: setting a reference of 4096 with a speed scale of 2: Speed reference data = 4096/2 <sup>2</sup> = 1024 = 0x0400 Hex Unit depends on o1-03.
Torque Reference/Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit in units of 0.1%. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0). The Torque Reference and Torque Limit are disabled with F6-06 = 0.

◆ Extended Speed and Torque Control Output - 23 (0x17)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
23	0	0	-	NetRef	NetCtrl	-	-	Fault Reset	Run Rev	Run Fwd	
		1	-								
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								
	2	4	Torque Reference/Torque Limit (Low Byte)								
		5	Torque Reference/Torque Limit (High Byte)								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Run Rev	Reverse Run Command 0: Stop 1: Reverse Run
Fault Reset	Fault Reset (0 to 1 transition: Fault Reset)
NetCtrl	Run command from Network 0: Depends on b1-02 1: Enables the run command from network
NetRef	Speed reference from Network 0: Depends on b1-01 1: Enables the speed reference from network
Speed Reference	Speed Command Sets drive speed reference. Speed reference data: Frequency reference/2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF Example: setting a reference of 4096 with a speed scale of 2: Speed reference data = 4096/2 <sup>2</sup> = 1024 = 0x0400 Hex Unit depends on o1-03.

## 9 Output Assemblies (Drive Consumes)

Name	Description
Torque Reference/Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit in units of 0.1%. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0). The Torque Reference and Torque Limit are disabled with F6-06 = 0.

### ◆ MEMOBUS/Modbus Message Output (Vendor Specific Yaskawa Electric (YE) Assy) - 100 (0x64)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
100	0	0	Function Code							
		1	Register Number (High Byte)							
	1	2	Register Number (Low Byte)							
		3	Register Data (High Byte)							
	2	4	Register Data (Low Byte)							

**Note:** This is a paired assembly (100/150).

Name	Description
Function Code	MEMOBUS/Modbus Function Code
Register Number	MEMOBUS/Modbus Register Number
Register Data	MEMOBUS/Modbus Register Data

**Table 10 Function Code Decode Table**

Function Code	MEMOBUS/Modbus Function
0x00	No Operation
0x03	Read Register
0x10	Write Register

**Note:** Refer to the MEMOBUS/Modbus Data Table in the MEMOBUS/Modbus Communications chapter of the drive manual for a list of monitor data using the MEMOBUS/Modbus message area.

### ◆ Speed/Torque Control Output (Vendor Specific Yaskawa Electric (YE) Assy) - 101 (0x65)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
101	0	0	Multi-Function Input 8	Multi-Function Input 7	Multi-Function Input 6	Multi-Function Input 5	Multi-Function Input 4	Multi-Function Input 3	Run Rev	Run Fwd
		1	Multi-Function Photo-coupler 2	Multi-Function Photo-coupler 1	Multi-Function Digital Output	-	-	-	Fault Reset	External Fault
	1	2	Speed Reference (Low Byte)							
		3	Speed Reference (High Byte)							
	2	4	Torque Reference/Torque Limit (Low Byte)							
		5	Torque Reference/Torque Limit (High Byte)							
	3	6	Torque Compensation (Low Byte)							
		7	Torque Compensation (High Byte)							

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Run Rev	Reverse Run Command 0: Stop 1: Reverse Run
Multi-Function Input 3	Terminal S3 Function Input 0: Terminal S3 Function (H1-03) OFF 1: Terminal S3 Function (H1-03) ON

Name	Description
Multi-Function Input 4	Terminal S4 Function Input 0: Terminal S4 Function (H1-04) OFF 1: Terminal S4 Function (H1-04) ON
Multi-Function Input 5	Terminal S5 Function Input 0: Terminal S5 Function (H1-05) OFF 1: Terminal S5 Function (H1-05) ON
Multi-Function Input 6	Terminal S6 Function Input 0: Terminal S6 Function (H1-06) OFF 1: Terminal S6 Function (H1-06) ON
Multi-Function Input 7	Terminal S7 Function Input 0: Terminal S7 Function (H1-07) OFF 1: Terminal S7 Function (H1-07) ON
Multi-Function Input 8	Terminal S8 Function Input 0: Terminal S8 Function (H1-08) OFF 1: Terminal S8 Function (H1-08) ON
External Fault	External Fault EF0 0: No External Fault (EF0) 1: External Fault (EF0)
Fault Reset	Fault Reset 0: No Fault Reset 1: Fault Reset
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.
Multi-Function Photocoupler 1	Terminal P1 0: P1 OFF 1: P1 ON This function is enabled only when H2-02 is set to F.
Multi-Function Photocoupler 2	Terminal P2 0: P2 OFF 1: P2 ON This function is enabled only when H2-03 is set to F.
Speed Reference	Speed Command Sets drive speed reference. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Torque Reference/Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit in units of 0.1%. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0). The Torque Reference and Torque Limit are disabled with F6-06 = 0.
Torque Compensation	Sets the amount of Torque Compensation Sets in units of 0.1%.

◆ Extended Speed/Torque Control Output (Vendor Specific Yaskawa Electric (YE) Assy) - 115 (0x73)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
115	0	0	Multi-Function Input 8	Multi-Function Input 7	Multi-Function Input 6	Multi-Function Input 5	Multi-Function Input 4	Multi-Function Input 3	Run Rev	Run Fwd	
		1	Multi-Function Photo-coupler 2	Multi-Function Photo-coupler 1	Multi-Function Digital Output	-	-	-	Fault Reset	External Fault	
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								
	2	4	Torque Reference/Torque Limit (Low Byte)								
		5	Torque Reference/Torque Limit (High Byte)								
	3	6	Torque Compensation (Low Byte)								
		7	Torque Compensation (High Byte)								
	4/5	8-11	Reserved								
	6	12	Analog Output 1 (Low Byte)								
		13	Analog Output 1 (High Byte)								
	7	14	Analog Output 2 (Low Byte)								
		15	Analog Output 2 (High Byte)								
	8	16	Digital Outputs (Low Byte)								
		17	Digital Outputs (High Byte)								
	9-20	18-39	Reserved								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Run Rev	Reverse Run Command 0: Stop 1: Reverse Run
Multi-Function Input 3	Terminal S3 Function Input 0: Terminal S3 Function (H1-03) OFF 1: Terminal S3 Function (H1-03) ON
Multi-Function Input 4	Terminal S4 Function Input 0: Terminal S4 Function (H1-04) OFF 1: Terminal S4 Function (H1-04) ON
Multi-Function Input 5	Terminal S5 Function Input 0: Terminal S5 Function (H1-05) OFF 1: Terminal S5 Function (H1-05) ON
Multi-Function Input 6	Terminal S6 Function Input 0: Terminal S6 Function (H1-06) OFF 1: Terminal S6 Function (H1-06) ON
Multi-Function Input 7	Terminal S7 Function Input 0: Terminal S7 Function (H1-07) OFF 1: Terminal S7 Function (H1-07) ON
Multi-Function Input 8	Terminal S8 Function Input 0: Terminal S8 Function (H1-08) OFF 1: Terminal S8 Function (H1-08) ON
External Fault	External Fault EF0 0: No External Fault (EF0) 1: External Fault (EF0)
Fault Reset	Fault Reset 0: No Fault Reset 1: Fault Reset
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.

Name	Description
Multi-Function Photocoupler 1	Terminal P1 0: P1 OFF 1: P1 ON This function is enabled only when H2-02 is set to F.
Multi-Function Photocoupler 2	Terminal P2 0: P2 OFF 1: P2 ON This function is enabled only when H2-03 is set to F.
Speed Reference	Speed Command Sets drive speed reference. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Torque Reference/Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit in units of 0.1%. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0). The Torque Reference and Torque Limit are disabled with F6-06 = 0.
Torque Compensation	Sets the amount of Torque Compensation Sets in units of 0.1%.
Analog Output 1	MEMOBUS/Modbus (0x0007)
Analog Output 2	MEMOBUS/Modbus (0x0008)
Digital Outputs	MEMOBUS/Modbus (0x0009)

◆ **High Speed/Torque Control Output (Vendor Specific Yaskawa Electric (YE) Assy) - 116 (0x74)**

This assembly is dynamic and can be configured as to what parameters are used. The first 20 Bytes (0-19) are fixed and the next 20 Bytes can be configured using parameters F7-23 to F7-32. If an error occurs while trying to write to the dynamic parameters, the appropriate error bit in Assembly 166 will be set. If more information is needed as to the nature of the error, the extended error status can be read explicitly through Class 4, Instance 0xA6, Attribute 0x64. This will return 20 Bytes with each dynamic parameter in Assembly 116 having a Byte dedicated to its extended error status. *Refer to Input Assemblies (Drive Produces) on page 36* for more information.

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
116	0	0	Multi-Function Input 8	Multi-Function Input 7	Multi-Function Input 6	Multi-Function Input 5	Multi-Function Input 4	Multi-Function Input 3	Run Rev	Run Fwd	
		1	Multi-Function Photo-coupler 2	Multi-Function Photo-coupler 1	Multi-Function Digital Output	-	-	-	Fault Reset	External Fault	
	1	2	Speed Reference (Low Byte)								
		3	Speed Reference (High Byte)								
	2	4	Torque Reference/Torque Limit (Low Byte)								
		5	Torque Reference/Torque Limit (High Byte)								
	3	6	Torque Compensation (Low Byte)								
		7	Torque Compensation (High Byte)								
	4	8	Reserved								
		9	-	-	-	-	Multi-Function Input 12	Multi-Function Input 11	Multi-Function Input 10	Multi-Function Input 9	
	5	10	-	-	-	-	-	-	NetCtrl	NetRef	
		11	-	-	-	-	-	-	-	-	
	6	12	Analog Output 1 (Low Byte)								
		13	Analog Output 1 (High Byte)								

## 9 Output Assemblies (Drive Consumes)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
116	7	14	Analog Output 2 (Low Byte)							
		15	Analog Output 2 (High Byte)							
	8	16	Digital Outputs (Low Byte)							
		17	Digital Outputs (High Byte)							
	9	18	Reserved							
		19	Reserved							
	10	20-21	Programmable Bytes Defined by F7-23 Default: Not Used							
	11	22-23	Programmable Bytes Defined by F7-24 Default: Not Used							
	12	24-25	Programmable Bytes Defined by F7-25 Default: Not Used							
	13	26-27	Programmable Bytes Defined by F7-26 Default: Not Used							
	14	28-29	Programmable Bytes Defined by F7-27 Default: Not Used							
	15	30-31	Programmable Bytes Defined by F7-28 Default: Not Used							
	16	32-33	Programmable Bytes Defined by F7-29 Default: Not Used							
	17	34-35	Programmable Bytes Defined by F7-30 Default: Not Used							
18	36-37	Programmable Bytes Defined by F7-31 Default: Not Used								
19	38-39	Programmable Bytes Defined by F7-32 Default: Not Used								

Name	Description
Run Fwd	Forward Run Command 0: Stop 1: Forward Run
Run Rev	Reverse Run Command 0: Stop 1: Reverse Run
Multi-Function Input 3	Terminal S3 Function Input 0: Terminal S3 Function (H1-03) OFF 1: Terminal S3 Function (H1-03) ON
Multi-Function Input 4	Terminal S4 Function Input 0: Terminal S4 Function (H1-04) OFF 1: Terminal S4 Function (H1-04) ON
Multi-Function Input 5	Terminal S5 Function Input 0: Terminal S5 Function (H1-05) OFF 1: Terminal S5 Function (H1-05) ON
Multi-Function Input 6	Terminal S6 Function Input 0: Terminal S6 Function (H1-06) OFF 1: Terminal S6 Function (H1-06) ON
Multi-Function Input 7	Terminal S7 Function Input 0: Terminal S7 Function (H1-07) OFF 1: Terminal S7 Function (H1-07) ON
Multi-Function Input 8	Terminal S8 Function Input 0: Terminal S8 Function (H1-08) OFF 1: Terminal S8 Function (H1-08) ON

Name	Description
External Fault	External Fault EF0 0: No External Fault (EF0) 1: External Fault (EF0)
Fault Reset	Fault Reset 0: No Fault Reset 1: Fault Reset
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.
Multi-Function Photocoupler 1	Terminal P1 0: P1 OFF 1: P1 ON This function is enabled only when H2-02 is set to F.
Multi-Function Photocoupler 2	Terminal P2 0: P2 OFF 1: P2 ON This function is enabled only when H2-03 is set to F.
Speed Reference	Speed Command Sets drive speed reference. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Torque Reference/Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit in units of 0.1%. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0). The Torque Reference and Torque Limit are disabled with F6-06 = 0.
Torque Compensation	Sets the amount of Torque Compensation Sets in units of 0.1%.
Digital Inputs	MEMOBUS/Modbus (0x49). Monitor parameter U1-10
NetRef	Network sets reference
NetCtrl	Network sets control
Analog Output 1	MEMOBUS/Modbus (0x0007)
Analog Output 2	MEMOBUS/Modbus (0x0008)
Digital Outputs	MEMOBUS/Modbus (0x0009)
Programmable Bytes	Contains the data to be written to the MEMOBUS/Modbus address defined in the given parameter. A value of 0 in the given parameter means it is not used, therefore the value received for this given parameter will not be written to any MEMOBUS/Modbus register. If the PPA is Input Assembly 166, then any errors occurring during a write will be flagged. <i>Refer to High Speed/Torque Status Input (Vendor Specific Yaskawa Electric (YE) Assy) - 166 (0xA6) on page 43</i> for details.

## 10 Input Assemblies (Drive Produces)

**Note:** The convention in this manual is from the PLC perspective. An “Input Assembly” is outputted from this node and read by the PLC. This section details “Input Assemblies” that are “Produced” by this drive.

### ◆ Basic Speed Control Input - 70 (0x46)

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
70	0	0	–	–	–	–	–	Running 1 (FWD)	–	Faulted	
		1	–								
	1	2	Speed Actual (Low Byte)								
		3	Speed Actual (High Byte)								

Name	Description
Faulted	Faulted 0: No Faults Occurred 1: Fault Occurred
Running 1 (FWD)	Forward Running 0: Stop or Reverse Running 1: Forward Running
Speed Actual	Actual Drive Speed Monitors drive output frequency. Speed actual data: Output frequency x 2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF For example, when output frequency of 1024 with a speed scale of 2: Speed actual data = 1024 x 2 <sup>2</sup> = 4096 = 0x1000 Unit depends on o1-03.

### ◆ Extended Speed Control Input - 71 (0x47)

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
71	0	0	At Speed	Ref from Net	Ctrl from Net	Ready	Running 2 (REV)	Running 1 (FWD)	Warning	Faulted	
		1	Drive State								
	1	2	Speed Actual (Low Byte)								
		3	Speed Actual (High Byte)								

Name	Description
Faulted	Faulted 0: No Faults Occurred 1: Fault Occurred
Warning	Warning 0: No Warning Occurred 1: Warning Occurred
Running 1 (FWD)	Forward Running 0: Stop or Reverse Running 1: Forward Running
Running 2 (REV)	Reverse Running 0: Stop or Forward Running 1: Reverse Running
Ready	Drive Ready 0: Not Ready 1: Ready
Ctrl from Net	Status of Run command from Network 0: Run command is not from network 1: Run command is from network
Ref from Net	Status of Speed reference from Network 0: Speed reference is not from network 1: Speed reference is from network
At Speed	Speed Agree 0: No Speed Agree 1: Speed actual at speed reference

Name	Description
Drive State	Contains the value from the Control Supervisor (Class 0x29) Instance 1 Attribute 6.
Speed Actual	Actual Drive Speed Monitors drive output frequency. Speed actual data: Output frequency x 2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF For example, when output frequency of 1024 with a speed scale of 2: Speed actual data = 1024 x 2 <sup>2</sup> = 4096 = 0x1000 Unit depends on o1-03.

◆ Speed and Torque Control Input - 72 (0x48)

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
72	0	0	-	-	-	-	-	Running 1 (FWD)	-	Faulted	
		1	-								
	1	2	Speed Actual (Low Byte)								
		3	Speed Actual (High Byte)								
	2	4	Torque Actual (Low Byte)								
		5	Torque Actual (High Byte)								

Name	Description
Faulted	Faulted 0: No Faults Occurred 1: Fault Occurred
Running 1 (FWD)	Forward Running 0: Stop or Reverse Running 1: Forward Running
Speed Actual	Actual Drive Speed Monitors drive output frequency. Speed actual data: Output frequency x 2 <sup>SS</sup> (SS: Speed scale) Setting range: 0 to 0xFFFF For example, when output frequency of 1024 with a speed scale of 2: Speed actual data = 1024 x 2 <sup>2</sup> = 4096 = 0x1000 Unit depends on o1-03.
Torque Actual	Output Torque Shows the Torque Reference. Value displays in 0.1% units.

◆ Extended Speed and Torque Control Input - 73 (0x49)

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
73	0	0	At Speed	Ref from Net	Ctrl from Net	Ready	Running 2 (REV)	Running 1 (FWD)	Warning	Faulted	
		1	Drive State								
	1	2	Speed Actual (Low Byte)								
		3	Speed Actual (High Byte)								
	2	4	Torque Actual (Low Byte)								
		5	Torque Actual (High Byte)								

Name	Description
Faulted	Faulted 0: No Faults Occurred 1: Fault Occurred
Warning	Warning 0: No Warning Occurred 1: Warning Occurred
Running 1 (FWD)	Forward Running 0: Stop or Reverse Running 1: Forward Running

## 10 Input Assemblies (Drive Produces)

Name	Description
Running 2 (REV)	Reverse Running 0: Stop or Forward Running 1: Reverse Running
Ready	Drive Ready 0: Not Ready 1: Ready
Ctrl from Net	Status of Run command from Network 0: Run command is not from network 1: Run command is from network
Ref from Net	Status of Speed reference from Network 0: Speed reference is not from network 1: Speed reference is from network
At Speed	Speed Agree 0: No Speed Agree 1: Speed actual at speed reference
Drive State	Contains the value from the Control Supervisor (Class 0x29) Instance 1 Attribute 6.
Speed Actual	Actual Drive Speed Monitors drive output frequency. Speed actual data: Output frequency $\times 2^{SS}$ (SS: Speed scale) Setting range: 0 to 0xFFFF For example, when output frequency of 1024 with a speed scale of 2: Speed actual data = $1024 \times 2^2 = 4096 = 0x1000$ Unit depends on o1-03.
Torque Actual	Output Torque Shows the Torque Reference. Value displays in 0.1% units.

### ◆ MEMOBUS/Modbus Message Input (Vendor Specific Yaskawa Electric (YE) Assy) - 150 (0x96)

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
150	0	0	Function Code							
		1	Register Number (High Byte)							
	1	2	Register Number (Low Byte)							
		3	Register Data (High Byte)							
	2	4	Register Data (Low Byte)							

**Note:** This is a paired assembly (100/150).

**Table 11 Reply Mapping – 150**

Byte	Write Success	Read Success	Write Failure	Read Failure	Invalid Function Code	Function Code Equals Zero
0	0x10	0x03	0x90	0x83	Function Code Or-ed with 0x80	0
1	Output Assembly Register Number (High Byte)	0				
2	Output Assembly Register Number (Low Byte)	0				
3	0	Read Data (High Byte)	0	0	0	0
4	0	Read Data (Low Byte)	Error Code	Error Code	1	0

**Table 12 Error Replies – 150**

Error Code	Description
0x01	Invalid Function Code
0x02	Invalid Register Number
0x21	Upper/Lower Limit Error

Error Code	Description
0x22	Option generated busy event. The MEMOBUS/Modbus requested operation is in the process loop but the drive is not done. Writing "Enter" when drive is running. Attempt to write data that is read only. Attempt to write a parameter when drive is running. During a CPF03 event attempting to write to registers other than A1-00 to A1-05, E1-03, o2-04.
0x23	Attempting to write during a drive undervoltage (Uv) event.
0x24	Attempting to write while the drive is storing data.

**Note:** Refer to the MEMOBUS/Modbus Data Table in the MEMOBUS/Modbus Communications chapter of the drive manual for a list of monitor data using the MEMOBUS/Modbus message area.

◆ **Speed/Torque Status Input (Vendor Specific Yaskawa Electric (YE) Assy) - 151 (0x97)**

Input Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
151	0	0	Faulted	Alarm	Ready	Speed Agree	Reset	REV Running	ZSP	Running
		1	ZSV	-	Multi-Function Photo-coupler 2	Multi-Function Photo-coupler 1	Multi-Function Digital Output	LOCAL/REMOTE	Uv	oPE
	1	2	Output Frequency (Low Byte)							
		3	Output Frequency (High Byte)							
	2	4	Torque Actual (Low Byte)							
		5	Torque Actual (High Byte)							
	3	6	Current Actual (Low Byte)							
		7	Current Actual (High Byte)							

Name	Description
Running	Running 0: Stop 1: Forward or Reverse Running
ZSP	Zero Speed 0: Running 1: Stop or DC Injection Braking
REV Running	Reverse Running 0: Not Reverse Running 1: Reverse Running
Reset	Reset 0: No Reset 1: Reset
Speed Agree	Speed Agree 0: No Speed Agree 1: Speed Actual at speed reference
Ready	Drive Ready 0: Not Ready 1: Ready
Alarm	Drive Alarm 0: No Drive Alarm 1: Alarm
Faulted	Drive Fault 0: No Drive Fault 1: Fault
OPE	OPE Fault 0: No oPE Fault 1: oPE
UV	Undervoltage 0: No Undervoltage 1: Undervoltage
LOCAL/REMOTE	Status of Run command from Network 0: Run command is not from network 1: Run command is from network

## 10 Input Assemblies (Drive Produces)

Name	Description
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.
Multi-Function Photocoupler 1	Terminal P1 0: Terminal P1 OFF 1: Terminal P1 ON
Multi-Function Photocoupler 2	Terminal P2 0: Terminal P2 OFF 1: Terminal P2 ON
ZSV	Zero Servo Completed 0: – 1: Completed
Output Frequency	Actual Drive Speed Monitors drive output frequency. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Torque Actual	Output Torque Shows the Torque Reference. Value displays in 0.1% units.
Current Actual	Actual Output Current Monitors drive output current. Unit is 0.01 A. Unit is not affected by Current Scale CS.

### ◆ Extended Speed/Torque Status Input (Vendor Specific Yaskawa Electric (YE) Assy) - 155 (0x9B)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
155	0	0	Faulted	Alarm	Ready	Speed Agree	Fault Reset	REV Running	ZSP	Running	
		1	ZSV	–	Multi-Function Photocoupler 2	Multi-Function Photocoupler 1	Multi-Function Digital Output	LOCAL/REMOTE	Uv	oPE	
	1	2	Motor Speed (Low Byte)								
		3	Motor Speed (High Byte)								
	2	4	Torque Actual (Low Byte)								
		5	Torque Actual (High Byte)								
	3	6	PG Count Value (Low Byte)								
		7	PG Count Value (High Byte)								
	4	8	Frequency Command (Low Byte)								
		9	Frequency Command (High Byte)								
	5	10	Output Frequency (Low Byte)								
		11	Output Frequency (High Byte)								
	6	12	Output Current (Low Byte)								
		13	Output Current (High Byte)								
	7	14	Parameter F7-35 Default: Terminal A2 Input (Low Byte)								
		15	Parameter F7-35 Default: Terminal A2 Input (High Byte)								
	8	16	Main Circuit DC Voltage (Low Byte)								
		17	Main Circuit DC Voltage (High Byte)								
	9	18	Error Code (Low Byte)								
		19	Error Code (High Byte)								

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
155	10	20 <1>	Parameter F7-33 Default: Alarm Code (Low Byte)							
		21 <1>	Parameter F7-33 Default: Alarm Code (High Byte)							
	11	22 <1>	Parameter F7-34 Default: Output Power (Low Byte)							
		23 <1>	Parameter F7-34 Default: Output Power (High Byte)							
	12	24 <1>	Parameter F7-37 Default: Terminal A3 Input (Low Byte)							
		25 <1>	Parameter F7-37 Default: Terminal A3 Input (High Byte)							
	13	26 <1>	Parameter F7-36 Default: Terminal S1 to S8 Input (Low Byte)							
		27 <1>	Parameter F7-36 Default: Terminal S1 to S8 Input (High Byte)							
	14	28 <1>	Terminal A1 Input (Low Byte)							
		29 <1>	Terminal A1 Input (High Byte)							
	15	30 <1>	Parameter F7-38 Default: PG Counter (Ch2) (Low Byte)							
		31 <1>	Parameter F7-38 Default: PG Counter (Ch2) (High Byte)							
	16-19	32-39	Reserved							

<1> Selectable with F7-33 to F7-42.

Name	Description
Running	Running 0: Stop 1: Forward or Reverse Running
Zero Speed	Zero Speed 0: Running 1: Stop or DC Injection Braking
REV Running	Reverse Running 0: Not Reverse Running 1: Reverse Running
Fault Reset	Fault Reset command from Network 0: Fault Reset command is not from network 1: Fault Reset command is from network
Speed Agree	Speed Agree 0: No Speed Agree 1: Speed Actual at speed reference
Ready	Drive Ready 0: Not Ready 1: Ready
Alarm	Drive Alarm 0: No Drive Alarm 1: Alarm
Faulted	Drive Fault 0: No Drive Fault 1: Fault
oPE	oPE Fault 0: No oPE Fault 1: oPE
Uv	Undervoltage 0: No Undervoltage 1: Undervoltage
LOCAL/REMOTE	Status of Run command from Network 0: Run command is not from network 1: Run command is from network

## 10 Input Assemblies (Drive Produces)

Name	Description
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.
Multi-Function Photocoupler 1	Terminal P1 0: Terminal P1 OFF 1: Terminal P1 ON
Multi-Function Photocoupler 2	Terminal P2 0: Terminal P2 OFF 1: Terminal P2 ON
ZSV	Zero Servo Completed 0: – 1: Completed
Motor Speed	Monitor parameter U1-05
Torque Actual	Output Torque Shows the Torque Reference. Value displays in 0.1% units.
PG Count Value	Contained MEMOBUS/Modbus Address
Frequency Command	Monitor parameter U1-01
Output Frequency	Actual Drive Speed Monitors drive output frequency. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Output Current	Actual Output Current Monitors drive output current. Unit is 0.01 A Unit is not affected by Current Scale CS.
Drive Terminal A1 Input	MEMOBUS/Modbus (0x46) Monitor parameter U1-13
Main DC Voltage	Main Circuit DC Voltage Monitor parameter U1-07
Error Code	U2-01 converted using fault code table
F7-33 Alarm Code	Programmable: MEMOBUS/Modbus (0x7F)
F7-35 Terminal A2 Input	Programmable: MEMOBUS/Modbus (0x4F) Monitor parameter U1-14
F7-36 Drive Terminal S1 to S8	Programmable: MEMOBUS/Modbus (0x49) Monitor parameter U1-10
F7-37 Terminal A3 Input	Programmable: MEMOBUS/Modbus (0x50)
F7-38 PG Count Value (CH 2)	Programmable: MEMOBUS/Modbus (0xF1) Serial interface Control Response

◆ High Speed/Torque Status Input (Vendor Specific Yaskawa Electric (YE) Assy) - 166 (0xA6)

If an error occurs while trying to read from the dynamic parameters, the appropriate error bit in Assembly 166 will be set. If more information about the nature of the error is needed, the extended error status can be read explicitly through Class 4, Instance 0xA6, Attribute 0x64. This will return 20 Bytes with each dynamic parameter in Assembly 166 having a Byte dedicated to its extended error status.

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
166	0	0	Faulted	Alarm	Ready	Speed Agree	Fault Reset	REV Running	ZSP	Running	
		1	ZSV	-	Multi-Function Photo-coupler 2	Multi-Function Photo-coupler 1	Multi-Function Digital Output	LOCAL/REMOTE	Uv	oPE	
	1	2	Motor Speed (Low Byte)								
		3	Motor Speed (High Byte)								
	2	4	Torque Actual (Low Byte)								
		5	Torque Actual (High Byte)								
	3	6	PG Count Value (Low Byte)								
		7	PG Count Value (High Byte)								
	4	8	Frequency Command (Low Byte)								
		9	Frequency Command (High Byte)								
	5	10	Output Frequency (Low Byte)								
		11	Output Frequency (High Byte)								
	6	12	Output Current (Low Byte)								
		13	Output Current (High Byte)								
	7	14	Parameter F7-35 Default: Terminal A2 Input (Low Byte)								
		15	Parameter F7-35 Default: Terminal A2 Input (High Byte)								
	8	16	Main Circuit DC Voltage (Low Byte)								
		17	Main Circuit DC Voltage (High Byte)								
	9	18	Error Code (Low Byte)								
		19	Error Code (High Byte)								
	10	20 </>	Parameter F7-33 Default: Alarm Code (Low Byte)								
21 </>		Parameter F7-33 Default: Alarm Code (High Byte)									

## 10 Input Assemblies (Drive Produces)

Output Instance	Word	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
166	11	22 <I>	Parameter F7-34 Default: Output Power (Low Byte)								
		23 <I>	Parameter F7-34 Default: Output Power (High Byte)								
	12	24 <I>	Parameter F7-35 Default: Terminal A2 Input (Low Byte)								
		25 <I>	Parameter F7-35 Default: Terminal A2 Input (High Byte)								
	13	26 <I>	Parameter F7-36 Default: Terminal S1 to S8 Input (Low Byte)								
		27 <I>	Parameter F7-36 Default: Terminal S1 to S8 Input (High Byte)								
	14	28 <I>	Parameter F7-37 Default: Terminal A3 Input (Low Byte)								
		29 <I>	Parameter F7-37 Default: Terminal A3 Input (High Byte)								
	15	30 <I>	Parameter F7-38 Default: PG Counter (Ch2) (Low Byte)								
		31 <I>	Parameter F7-38 Default: PG Counter (Ch2) (High Byte)								
	16	32 <I>	Parameter F7-39 Default: NetRef and NetCtrl (Low Byte)								
		33 <I>	–	–	–	–	–	–	–	NetCtrl	NetRef
	17	34 <I>	Parameter F7-40 Default: Drive Software Version (Low Byte)								
		35 <I>	Parameter F7-40 Default: Drive Software Version (High Byte)								
	18	36 <I>	Parameter F7-41 Default: Not Used								
		37 <I>	Parameter F7-33 Default: Not Used								
	19	38 <I>	Parameter F7-33 Default: Not Used								
		39 <I>	Parameter F7-42 Default: Not Used								
	20	40	–	–	–	–	–	–	–	Assy. 116 F7-32 Error	Assy. 116 F7-31 Error
		41	Assy. 116 F7-30 Error	Assy. 116 F7-29 Error	Assy. 116 F7-28 Error	Assy. 116 F7-27 Error	Assy. 116 F7-26 Error	Assy. 116 F7-25 Error	Assy. 116 F7-24 Error	Assy. 116 F7-23 Error	Assy. 116 F7-22 Error
21	42	–	–	–	–	–	–	–	Assy. 166 F7-42 Error	Assy. 166 F7-41 Error	
	43	Assy. 166 F7-40 Error	Assy. 166 F7-39 Error	Assy. 166 F7-38 Error	Assy. 166 F7-37 Error	Assy. 166 F7-36 Error	Assy. 166 F7-35 Error	Assy. 166 F7-34 Error	Assy. 166 F7-33 Error	Assy. 166 F7-32 Error	

<I> Selectable with F7-33 to F7-42.

Name	Description
Running	Running 0: Stop 1: Forward or Reverse Running
Zero Speed	Zero Speed 0: Running 1: Stop or DC Injection Braking
REV Running	Reverse Running 0: Not Reverse Running 1: Reverse Running

Name	Description
Fault Reset	Fault Reset command from Network 0: Fault Reset command is not from network 1: Fault Reset command is from network
Speed Agree	Speed Agree 0: No Speed Agree 1: Speed Actual at speed reference
Ready	Drive Ready 0: Not Ready 1: Ready
Alarm	Drive Alarm 0: No Drive Alarm 1: Alarm
Faulted	Drive Fault 0: No Drive Fault 1: Fault
oPE	oPE Fault 0: No oPE Fault 1: oPE
Uv	Undervoltage 0: No Undervoltage 1: Undervoltage
LOCAL/REMOTE	Status of Run command from Network 0: Run command is not from network 1: Run command is from network
Multi-Function Digital Output	Terminal M1/M2 0: M1/M2 OFF 1: M1/M2 ON This function is enabled only when H2-01 is set to F.
Multi-Function Photocoupler 1	Terminal P1 0: Terminal P1 OFF 1: Terminal P1 ON
Multi-Function Photocoupler 2	Terminal P2 0: Terminal P2 OFF 1: Terminal P2 ON
ZSV	Zero Servo Completed 0: – 1: Completed
Motor Speed	Monitor parameter U1-05
Torque Actual	Output Torque Shows the Torque Reference. Value displays in 0.1% units.
PG Count Value	Contained MEMOBUS/Modbus Address
Frequency Command	Monitor parameter U1-01
Output Frequency	Actual Drive Speed Monitors drive output frequency. Unit depends on o1-03. Unit is not affected by Speed Scale SS.
Output Current	Actual Output Current Monitors drive output current. Unit is 0.01 A Unit is not affected by Current Scale CS.
Drive Terminal A1 Input	MEMOBUS/Modbus (0x46) Monitor parameter U1-13
Main DC Voltage	Main Circuit DC Voltage Monitor parameter U1-07
Error Code	U2-01 converted using fault code table
F7-33 Alarm Code	Programmable: MEMOBUS/Modbus (0x7F)
F7-35 Terminal A2 Input	Programmable: MEMOBUS/Modbus (0x4F) Monitor parameter U1-14
F7-36 Drive Terminal S1 to S8	Programmable: MEMOBUS/Modbus (0x49) Monitor parameter U1-10
F7-37 Terminal A3 Input	Programmable: MEMOBUS/Modbus (0x50)

## 10 Input Assemblies (Drive Produces)

Name	Description
F7-38 PG Count Value (CH 2)	Programmable: MEMOBUS/Modbus (0xF1) Serial interface Control Response
F7-39 NetRef (Status)	Status of reference command from Network 0: Reference command is not from network 1: Reference command is from network
F7-40 Drive Software Version	Programmable: MEMOBUS/Modbus (0x4D) Monitor parameter U1-25

Possible extended error codes are listed in [Table 13](#) and [Table 14](#). If an error occurs, extended error code 0x02 (Register number failure) is usually set.

**Table 13 Extended Error Codes for Assembly 116/166**

Error Code	Description
0x00	No error
0x01	Sub function code failure
0x02	Register number failure
0x21	Limit check error failure
0x22	Write failure
0x23	Write failure at Uv
0x24	Write failure at busy

**Table 14 Extended Error Codes in Class 0x04 Instance 0xA6 Attribute 0x64**

Dynamic Parameter	Byte Containing Extended Error Code
F7-23	Byte 0
F7-24	Byte 1
F7-25	Byte 2
F7-26	Byte 3
F7-27	Byte 4
F7-28	Byte 5
F7-29	Byte 6
F7-30	Byte 7
F7-31	Byte 8
F7-32	Byte 9
F7-33	Byte 10
F7-34	Byte 11
F7-35	Byte 12
F7-36	Byte 13
F7-37	Byte 14
F7-38	Byte 15
F7-39	Byte 16
F7-40	Byte 17
F7-41	Byte 18
F7-42	Byte 19

## 11 General Class Objects

### ◆ Identity Object 1 (Class 0x01)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
01	Get Attribute All
05	Reset
0E	Get Attribute Single

#### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Identity Object software revision	O	–	Word	–	1
1	1	Vendor ID	Manufacturer code. 44 (2C H): Yaskawa Electric	O	–	Word	–	44 (Yaskawa)
1	2	Device Type	Device profile. The profile for this product is an AC drive. 2: AC drive	O	–	Word	–	2 (AC drives)
1	3	Product Code	Product codes determined by the manufacturer.	O	–	Word	–	<I>
1	4	Revision	Software revision for the option.	O	–	Word	–	Depends on software
1	5	Status	Shows the communication status for the drive.	O	–	Word	–	0
1	6	Serial Number	Option serial number	O	–	Long	–	Each unit is unique
1	7	Product Name	Product name	O	–	String (14 Bytes)	–	Product-dependent (i.e., CIMR-X)
1	8	State	Operation status of the drive. 3: Drive ready 4: Fault	O	–	Byte	–	3 State of the drive

<I> Product code is 2 Bytes. The first Byte is the drive type and the second Byte is the model number of the drive.

### ◆ Assembly Object 4 (Class 0x04)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single

#### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Show the EtherNet Object software revision.	O	–	Word	–	2
20	3	Data	Same function as the Basic Speed Control (Output Assembly)	O	O	Array 4 Bytes	–	00 00 00 00
21	3	Data	Same function as the Extended Speed Control (Output Assembly)	O	O	Array 4 Bytes	–	00 00 00 00
22	3	Data	Same function as the Speed and Torque Control (Output Assembly)	O	O	Array 6 Bytes	–	00 00 00 00 00 00



## ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Motor Data Object software revision.	O	–	Word	–	1
1	3	Motor Type	Differs depending on selected motor control mode. When set to OLV/PM (A1-02 = 5), value becomes 3 (PM motor). When set to V/f (A1-02 = 0) or OLV (A1-02 = 2), value becomes 7 (squirrel cage motor).	O	–	Byte	–	Depends on A1-02, Control Method Selection
1	6	Rated Current [0.1 A]	Motor rated current. Displayed in 0.1 A units. Changes according to the current scale (CS).	O	O	Byte	–	Depends on capacity
1	7	Rated Voltage [1V]	Motor rated voltage. Displayed in 1 V units. Changes according to the voltage scale (VS).	O	O	Byte	–	Depends on capacity

## ◆ Control Supervisor Object 41 (Class 0x29)

### ■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single
05	Reset

### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of the Control Supervisor Object.	O	–	Word	–	1
1	3	Run 1 (Forward Run Command)	Forward Running 0: Stop 1: Forward Running	O	O	Byte	0, 1	0
1	4	Run 2 (Reverse Run Command)	Reverse Running 0: Stop 1: Reverse Running	O	O	Byte	0, 1	0
1	5	NetCtrl (Command)	Run command from Network 0: Depends on b1-02 1: Enables the run command from network	O	O	Byte	0, 1	0
1	6	State	Drive Status 2: Not Ready 3: Ready (Stopped) 4: Enabled (Run command present) 5: Deceleration to Stop 6: Fault Stop 7: Fault	O	–	Byte	–	3
1	7	Running 1 (FWD)	Forward Running 0: Stop 1: Forward Running	O	–	Byte	–	0
1	8	Running 1 (REV)	Reverse Running 0: Stop 1: Reverse Running	O	–	Byte	–	0
1	9	Ready	Drive Ready 0: Not Ready 1: Ready	O	–	Byte	–	1
1	10	Faulted	Drive Fault 0: No Drive Fault 1: Fault	O	–	Byte	–	0

## 11 General Class Objects

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	11	Warning	Warning 0: No Warning 1: Warning	O	-	Byte	-	0
1	12	Fault Reset	Fault Reset 0: No Fault Reset 1: Fault Reset	O	O	Byte	0, 1	0
1	13	Fault Code	Current Fault <i>Refer to Option Fault Code Conversion Table on page 50</i> for details.	O	-	Word	-	0000
1	15	Control from Net (Status)	Run Command from the option 0: The Run command is not from the option 1: Enables the Run command from option	O	-	Byte	-	0
1	16	NetFaultMode	Normal 2 (Vendor Specific)	O	-	Byte	-	2
1	17	Force Fault	External Fault 0: No External Fault 1: External Fault (EF0) Triggered by the rising edge of the signal.	O	O	Byte	0, 1	0
1	18	Force Status	External Fault status 0: No External Fault 1: External Fault (EF0) Triggered by the rising edge of the signal.	O	-	Byte	-	0

### ■ Option Fault Code Conversion Table

Drive Fault Code (Hex) (MEMOBUS/Modbus 0080 Hex)	Option Fault Code (Hex)	Description
0	0	None
2	3220	DC Bus Undervolt (Uv1)
3	5110	CTL PS Undervolt (Uv2)
4	3222	MC Answerback (Uv3)
6	2120	Ground Fault (GF)
7	2300	Over Current (oC)
8	3210	DC Bus Overvoltage (ov)
9	4200	Heatsink Overtemp (oH)
10	4210	Heatsink Max Temp (oH1)
11	2220	Motor Overload (oL1)
12	2200	Drive Overload (oL2)
13	2221	Overtorque Det 1 (oL3)
14	2222	Overtorque Det 2 (oL4)
15	7110	DynBrk Transistor (rr)
16	7112	DynBrk Resistor (rH)
17	9000	External Fault 3 (EF3)
18	9000	External Fault 4 (EF4)
19	9000	External Fault 5 (EF5)
20	9000	External Fault 6 (EF6)
21	9000	External Fault 7 (EF7)
22	9000	External Fault 8 (EF8)
24	7310	Overspeed Det (oS)
25	7310	Speed Deviation (dEv)
26	7301	PG Open (PGo)
27	3130	Input Phase Loss (PF)
28	3130	Output Phase Loss (LF)

Drive Fault Code (Hex) (MEMOBUS/Modbus 0080 Hex)	Option Fault Code (Hex)	Description
29	5210	Motor Overheat 1 (PTC Input) (oH3)
30	5300	Operator Disconnected (oPr)
31	6320	EEPROM R/W Error (Err)
32	3210	Motor OverHeat 2 (PTC Input) (oH4)
33	7500	MEMBOUS/Modbus Com Fault (CE)
34	7500	EtherNet/IP Communication Error (bUS)
37	8321	Out of Control (CF)
39	9000	External Fault 0 (EF0)
40	8000	PID Feedback Loss (FbL)
41	8000	Undertorque Detection 1 (UL3)
42	8000	Undertorque Detection 2 (UL4)
43	8000	High Slip Braking oL (oL7)
50	8000	Z Pulse Fault Detection (dv1)
51	8000	Z Pulse Noise Fault Detection (dv2)
52	8000	Inversion Detection (dv3)
53	8000	Inversion Prevention Detection (dv4)
54	8000	Current Imbalance (LF2)
55	8000	Pull-Out Detection (STo)
56	7000	PG Hardware Fault (PGoH)
59	1000	Too Many Speed Search Restarts (SEr)
65	8000	Excessive PID Feedback (FbH)
66	9000	External Fault (input terminal S1) (EF1)
67	9000	External Fault (input terminal S2) (EF2)
38	8000	Mechanical Weakening Detection 1 (oL5)
39	8000	Mechanical Weakening Detection 2 (UL5)
70	5000	Current Offset Fault (CoF)
73	8000	DriveWorksEZ Fault (dwFL)
77	5000	Output Voltage Detection Fault (voF)
78	7000	Braking Resistor Fault (rF)
79	7000	Braking Transistor Overload Fault (boL)
–	1000	Other faults

◆ AC/DC Drive Object 42 (Class 0x2A)

■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single

■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of AC/DC drive object	O	–	Word	–	1
1	3	AtReference	Speed Agree 0: – 1: Speed Agree	O	–	Byte	–	0
1	4	NetRef (Command)	Status of reference command from EtherNet/ IP 0: Reference command not from option 1: Reference command from the option	O	–	Byte	–	0

## 11 General Class Objects

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	6	Drive Mode	Drive control mode. 0: OLV, OLV for PM (Read only), Advanced OLV for PM (Read only) 1: V/f 2: V/f with PG 3: CLV, CLV for PM (Read only)	O	O	Byte	0 to 3	0
1	7	Speed Actual	Actual drive speed. Unit is not affected by Speed Scale (SS).	O	-	Word	-	3
1	8	Speed Reference	Frequency Reference. Monitors the drive frequency reference. Unit is not affected by Speed Scale (SS).	O	O	Word	-	0
1	9	Current Actual	Actual Output Current. Display is in the following units: 2A0004 to 2A0040, 4A0002 to 4A0023, 5A0007 to 5A0017: 0.01 A units. 2A0056 to 2A0415, 4A0031 to 4A0675, 5A0022 to 5A0242: 0.1 A units. 4A0930 and 4A1200: 1 A units. Unit is not affected by Current Scale (CS).	O	-	Word	-	0
1	11	Torque Actual	Drive Output Torque Unit is affected by Torque Scale (TS)	O	-	Word	-	0
1	12	Torque Reference/ Torque Limit	Torque Reference/Torque Limit Sets the Torque Reference/Torque Limit. The units are determined by the Torque Scale. Sets the Torque Reference when using Torque Control (d5-01 = 1). Sets the Torque Limit when using Speed Control (d5-01 = 0) The Torque Reference/Torque Limit are disabled when F6-06 = 0.	O	O	Word	-	0
1	15	Power Actual (W)	Drive Output Power Unit is affected by Power Scale (PS).	O	-	Word	-	0
1	16	Input Voltage (V)	Drive Input Voltage Unit is affected by Voltage Scale (VS).	O	-	Word	-	Dep. on capacity
1	17	Output Voltage (V)	Drive Output Voltage Unit is affected by Voltage Scale (VS).	O	-	Word	-	0
1	18	Accel Time (ms)	Acceleration Time 1 (C1-01) Units set in parameter C1-10. Unit is affected by Time Scale (TS).	O	O	Word	-	2710H
1	19	Decel Time (ms)	Acceleration Time 1 (C1-02) Units set in parameter C1-10. Unit is affected by Time Scale (TS).	O	O	Word	-	2710H
1	20	Low Speed Limit Percent of Max Speed	Frequency Reference Lower Limit (d2-02)	O	O	Word	0 to 1100	0
1	21	High Speed Limit Percent of Max Speed	Frequency Reference Upper Limit (d2-01)	O	O	Word	0 to 1100	3E8H
1	22	Speed Scale (-15 to 15)	Setting for F7-17, scale of units for speed related data.	O	O	Byte	-15 to 15	0
1	23	Current Scale (-15 to 15)	Setting for F7-18, scale of units for current related data.	O	O	Byte	-15 to 15	0
1	24	Torque Scale (-15 to 15)	Setting for F7-19, scale of units for torque related data.	O	O	Byte	-15 to 15	0
1	26	Power Scale (-15 to 15)	Setting for F7-20, scale of units for power related data.	O	O	Byte	-15 to 15	0

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	27	Voltage Scale (-15 to 15)	Setting for F7-21, scale of units for voltage related data.	O	O	Byte	-15 to 15	0
1	28	Time Scale (-15 to 15)	Setting for F7-22, scale of units for speed related data.	O	O	Byte	-15 to 15	0
1	29	Reference from Net (Status)	Status of Reference Command (1 = Network). 0: As set by the drive parameters 1: Network	O	-	Byte	-	0

## ◆ DLR Object 71 (Class 0x47)

Device Level Ring (DLR) is a layer 2 protocol allowing for redundancy in EtherNet/IP based ring topology networks. DLR allows devices to be placed in a ring to reduce the need for switch hardware and cabling and allow for the detection and recovery of faults in the ring. This option is a beacon based ring node implementation.

To set up a DLR network, configure a supervisor on the network prior to connecting and powering on all devices in the ring. Establishing a ring without an active supervisor may cause a loss of communication to devices on the ring.

The supervisor precedence must be configured when setting up the supervisor. Typically, the default beacon rate is 400 ms to allow for faster fault detection and recovery period and should be fast enough for devices to recover on the ring without losing an I/O connection. The precedence value for the supervisor is used when more than one supervisor is present. When two supervisors are on the network, the supervisor with the higher MAC address will become the supervisor and the other will become a backup supervisor.

Yaskawa recommends that all devices in the ring be DLR capable. Add non-DLR devices to the ring through a DLR-capable device, such as a 3-port ETAP.

Ensure that non-DLR devices placed in the ring meet the following requirements:

- Disable MAC address learning
- Do not use multicast filtering
- Preserve VLAN tags.

Make sure that all switches in the ring are DLR-aware. Switches in the ring that are not DLR-aware may cause undesired behavior due to MAC address learning of the supervisor beacon packets being received on two different switch ports.

Be sure to set the RPI only as fast as needed to limit the network traffic. Yaskawa supports RPIs down to 10 ms. However, if a slower level of control is acceptable, a slower RPI setting will reduce network traffic.

Yaskawa also recommends setting up and configuring all devices prior to completing the ring by leaving one cable disconnected. Make the last connection after configuring the nodes and supervisor.

**Note:** DLR is supported in option software versions VST800341 and later.

## ■ Services Supported

Service Code No. (Hex)	Service Name
01	Get Attribute All
10	Set Attribute Single

## ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of the DLR Object	O	-	Word	-	3
1	1	Network Topology	Current network topology mode 0: Linear 1: Ring	O	-	Byte	0, 1	0
1	2	Network Status	Current status of network 0: Normal 1: Ring fault 2: Unexpected loop detected 3: Partial network fault 4: Rapid fault/restore cycle	O	-	Byte	0 to 4	-

## 11 General Class Objects

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	10	Active Supervisor Address	Struct of: Supervisor IP Address = Long Supervisor MAC Address = Array of bytes	O	-	Struct	-	-
1	12	Capability Flags	Describes DLR capabilities	O	-	Long	-	0x00000002

Note: "Get Attribute All" Service shall report in attribute ascending order.

### ◆ QoS Object 72 (Class 0x48)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single

#### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of the QoS Object	O	-	Word	-	1
1	4	DCSP Urgent	DSCP value for CIP transport class 0/1 Urgent priority messages	O	O	Byte	0 to 63	55
1	5	DSCP Scheduled	DSCP value for CIP transport class 0/1 Scheduled priority messages	O	O	Byte	0 to 63	47
1	6	DSCP High	DSCP value for CIP transport class 0/1 High priority messages	O	O	Byte	0 to 63	43
1	7	DSCP Low	DSCP value for CIP transport class 0/1 Low priority messages	O	O	Byte	0 to 63	31
1	8	DSCP Explicit	DSCP value for CIP explicit messages and all other EtherNet/IP encapsulation messages	O	O	Byte	0 to 63	27

### ◆ TCP/IP Object 245 (Class 0xF5)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
01	Get Attribute All
0E	Get Attribute Single
10	Set Attribute Single

#### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of the TCP/IP Object	O	-	Word	-	1
1	1	Status	Bits 0-3 = Interface Status 0: Interface has not been configured 1: Interface Configuration is valid, obtained from BOOTP, DHCP, or NVRAM 2: Interface Configuration is valid and obtained from hardware settings 3: Reserved Bit 4 = Multicast Pending Bits 5-31 = Reserved	O	-	DWord	-	-

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	2	Configuration Capability	Bit 0 = BOOTP Client Bit 1 = DNS Client Bit 2 = DHCP Client Bit 3 = DHCP-DNS Update Bit 4 = Configuration Settable Bits 5-31 = Reserved	O	-	DWord	-	-
1	3	Configuration Control	Bits 0-3 = Startup Configuration 0: NVRAM 1: BOOTP 2: DHCP 3: Reserved Bit 4 =DNS Enabled (not supported) Bits 5-31 = Reserved	O	O	DWord	-	-
1	4	Physical Link	Struct of: Path Size: 0 Path: 0	O	-	Struct	-	02H 00H 20H F6H 24H 01H
1	5	Interface Configuration	Struct of: IP Address = Long Subnet Mask = Long Gateway Address = Long Name Server1 = Long Name Server2 = Long Domain Name = STRING	O	O	Struct	-	-
1	6	Host Name	Host Name	O	O	STRING	64 char	Null
1	10	Select ACD	Activates use of ACD 0: Disable ACD 1: Enable ACD	O	O	BOOL	0, 1	1
1	11	Last Conflict Detected	Structure containing information related to the last conflict detected. Struct of: Bit 0: ACD Activity Bits 1-7: Remote MAC Bits 8-36: ARP PDU	O	O	Struct	-	-

**Note:** “Get Attributes All” Service shall report in attribute ascending order.

## ◆ Ethernet Link Object 246 (Class 0xF6)

### ■ Services Supported

Service Code No. (Hex)	Service Name
01	Get Attribute All
0E	Get Attribute Single
10	Set Attribute Single

### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Revision number of the TCP/IP Object	O	-	Word	-	3
0	2	Max Instance	-	O	-	UINT	-	2
0	3	Number of Instances	-	O	-	UINT	-	2
1	1	Interface Speed	Interface speed currently in use	O	-	UDINT	-	-

## 11 General Class Objects

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
1	2	Interface Flags	Bit 0 = Link Status Bit 1 = Duplex (0: Half/1: Full) Bits 2-4 = Negotiation Status 0: In progress 1: Auto-negotiate failed 2: Speed found, duplex not found 3: Successful 4: Not attempted Bit 5 = Manual Setting requires restart Bit 6 = Local hardware fault Bits 7-31 = Reserved	O	-	DWord	-	-
1	3	Physical Address (MAC)	MAC address	O	-	Array of 6 Bytes	-	-
1	6	Interface Control	Struct of: Control Bits: Word Bit 0 = Auto-negotiate Bit 1 = Forced Duplex Mode Bits 2-15 = Reserved Forced Int Speed: Word	-	O	Struct	-	-
1	10	Interface Label	-	O	-	Short String	-	Port 1
2	1	Interface Speed	Interface speed currently in use	O	-	UDINT	-	-
2	2	Interface Flags	Bit 0 = Link Status Bit 1 = Duplex (0: Half/1: Full) Bits 2-4 = Negotiation Status 0: In progress 1: Auto-negotiate failed 2: Speed found, duplex not found 3: Successful 4: Not attempted Bit 5 = Manual Setting requires restart Bit 6 = Local hardware fault Bits 7-31 = Reserved	O	-	DWord	-	-
2	6	Interface Control	Struct of: Control Bits: Word Bit 0 = Auto-negotiate Bit 1 = Forced Duplex Mode Bits 2-15 = Reserved Forced Int Speed: Word	-	O	Struct	-	-
2	10	Interface Label	-	O	-	Short String	-	Port 2

**Note:** “Get Attributes All” Service shall report in attribute ascending order.

## 12 Vendor-Specific (Yaskawa) Class Objects

### ◆ Yaskawa Drive Parameters Object 100 (Class 0x64)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single

This is a dynamic explicit Class Object. With this Class object any drive parameter with a MEMOBUS/Modbus address greater than 0x00FF can be accessed. The mapping of Class Object instance/attribute to MEMOBUS/Modbus address is as follows.

Given a typical MEMOBUS/Modbus Address of 0xXXYY

The EtherNet/IP Instance value is equal to XX

The EtherNet/IP Attribute value is equal to YY

As an example, to access parameter b5-12 (MEMOBUS/Modbus Address =0x01B0)

Class Object is 100 (0x64) (Always for this Class Object)

Instance = 0x01

Attribute = 0xB0

#### ■ Storing Changed Parameters

Writing a zero to 0x0900 (Enter) stores changed parameters to the non-volatile memory of the drive. Writing a 0 to 0x0910 (Accept) allows the drive to use the changed parameters. Reading Enter Command 0x0900 or Accept Command 0x910 will always return a value of 0x0001.

#### Performing a RAM-ENTER to Store Register Data

Parameter H5-11 is used to decide whether a RAM-ENTER will be done on the writes to registers in the drive. If H5-11 = 1 (default), the option will issue the RAM-ENTER with the parameter writes. If H5-11 = 0, no RAM-ENTER is issued and an ENTER command must be explicitly sent by the user for the parameter to be activated after a write.

Explicit writes to RAM-ENTER (0x910) and ROM-ENTER (0x900) are handled as special cases. If a user writes a 0 to RAM-ENTER or ROM-ENTER, the command will be executed in the drive. If a user writes a 1 to those registers, the command will not be executed but returns a success to the explicit write on the network. Writing a value other than 0 or 1 will result in an error response of Invalid Attribute Value on the network.

**Note:** Performing the RAM-ENTER increases the processing time of the writes and increases the response time to explicit writes.

#### ■ Attributes Supported

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
0	1	Object Software Revision	Yaskawa Drive Parameters object software revision	O	–	Word	–	1
1	00	MEMOBUS/Modbus Register 0x0100	Language selection	O	O	Word	0 to 2	1
1	01	MEMOBUS/Modbus Register 0x0101	Parameter access level	O	O	Word	0 to 2	2
1	YY	MEMOBUS/Modbus Registers 0x0100 to 0x01FF	MEMOBUS/Modbus Registers 0x0100 to 0x01FF	O	O	Word	–	–
2	YY	MEMOBUS/Modbus Registers 0x0200 to 0x02FF	MEMOBUS/Modbus Registers 0x0200 to 0x02FF	O	O	Word	–	–

## 12 Vendor-Specific (Yaskawa) Class Objects

Instance ID	Attribute	Name	Description	Get	Set	Size	Range	Default
...	...	...	...	...	O	Word	–	–
255	YY	MEMOBUS/ Modbus Registers 0xFF00 to 0xFFFF	MEMOBUS/Modbus Registers 0xFF00 to 0xFFFF	O	O	Word	–	–

- Note:**
1. Attempting to set a read-only parameter results in an EtherNet/IP error code of 0x0E, Attribute Not Settable.
  2. Attempting to access an invalid parameter results in an EtherNet/IP error code of 0x09, Invalid Attribute Value.
  3. Refer to the MEMOBUS/Modbus Data Table in the MEMOBUS/Modbus Communications chapter of the drive manual for a list of monitor data using the MEMOBUS/Modbus message area.

### ◆ Yaskawa Monitor/Control Object 125 (Class 0x7D)

#### ■ Services Supported

Service Code No. (Hex)	Service Name
0E	Get Attribute Single
10	Set Attribute Single

This is a dynamic explicit Class Object. With this Class object any parameter with a MEMOBUS/Modbus address less than 0x0100 can be accessed. This class is similar to the Drive Parameters Object Class 100, Object Class 100 differs slightly from Object Class 125. In Object Class 125 the most significant byte of MEMOBUS/Modbus address is always zero and the Instance ID remains at 1.

Given a typical MEMOBUS/Modbus Address of 0x00YY

The EtherNet/IP Instance value is equal to 0x01

The EtherNet/IP Attribute value is equal to YY

As an example, to access Drive Status (MEMOBUS/Modbus Address = 0x002C)

Class Object is 125 (0x7D) (Always for this Class Object)

Instance = 0x01

Attribute = 0x2C

#### ■ Attributes Supported

Instance ID	Attribute	MEMOBUS/ Modbus Address	Description	Get	Set	Size	Range	Default
0	1	–	Object Software Revision	O	–	Word	–	1
1	1	0x0001	Drive Command Bits	O	O	Word	–	0
1	2	0x0002	Frequency Instruction	O	O	Word	–	4
..	..	..	..	O	O	Word	–	–
1	255	0x00FF	Unused	O	O	Word	–	–

- Note:**
1. Attempting to set a read-only parameter results in an EtherNet/IP error code of 0x0E, Attribute Not Settable.
  2. Attempting to access an invalid parameter results in an EtherNet/IP error code of 0x09, Invalid Attribute Value.
  3. Refer to the MEMOBUS/Modbus Data Table in the MEMOBUS/Modbus Communications chapter of the drive manual for a list of monitor data using the MEMOBUS/Modbus message area.

## 13 Web Interface

The option contains a series of web pages that allow for viewing of status and diagnostic information through a standard web browser.

The web page is accessed through a self-contained web server at port 80. Access the home page by typing the IP address of the option in a web browser. Example: "http://192.168.1.20"

The IP address of the option can be read using monitors U6-80 to U6-83 on the digital operator if it is unknown. *Refer to [Option Monitors on page 24](#)* for details.

The home page is an HTML-based page providing basic drive and option data and a link to an enhanced web page requiring a Java© enabled web browser.

Enhanced Web Page Notes:

- The Enhanced Web Pages use a series of Java© applets.
- PCs must have Java SE 6 Update 14 or later installed to view the enhanced web pages.
- The Java© applets require an internet connection to check the revocation status.
- When no internet connection is available, disable the revocation check by changing a Java setting in the PC: All Programs / Java / Configure Java / Advanced Tab. Set "Perform certificate checks on" to "Do not check".

Enhanced Web Page Tab	Page
Main Tab	<a href="#">60</a>
Drive Status Tab	<a href="#">61</a>
Network Tab	<a href="#">61</a>
Email Alerts Tab <a href="#">&lt;1&gt;</a>	<a href="#">62</a>
Parameter Access Tab <a href="#">&lt;1&gt;</a> <a href="#">&lt;2&gt;</a>	<a href="#">63</a>
Configuration Tab <a href="#">&lt;1&gt;</a> <a href="#">&lt;2&gt;</a>	<a href="#">64</a>
Custom Tab <a href="#">&lt;1&gt;</a>	<a href="#">65</a>

[<1>](#) Available on SI-EN3D Dual-port only.

[<2>](#) Accessible after entering a valid password.

### ◆ HTML Home Page (SI-EN3D Dual-port)

The HTML home page provides basic drive and option data and a link to an enhanced web page.




Figure 18 HTML Home Page (Dual-Port)

### ◆ Main Tab

The Main tab shows basic option information such as IP address, MAC address, and firmware version.




Figure 19 Main Tab View

## ◆ Drive Status Tab

The Drive Status tab shows basic I/O information and drive state information.




Figure 20 Drive Status Tab View

## ◆ Network Tab

The Network tab shows the status of the option network traffic and the status of open I/O connections.




Figure 21 Network Tab View

Table 15 Network Monitor Descriptions

Network Monitor	Explanation
Msg Tx OK	Cumulative number of messages transmitted successfully from the option.
Msg Rx OK	Cumulative number of messages received successfully to the option.
Current Connections	Current number of open connections.
Msg Tx Dropped	Cumulative number of messages dropped due to output network buffer being full and unable to hold the new message.

## 13 Web Interface

Network Monitor	Explanation
Msg Rx Dropped	Cumulative number of messages dropped due to input network buffer being full and unable to hold the new message.
Collisions	Cumulative number of collisions (half duplex only) reported by the MAC/PHY (Media Access Control/Physical Connection).
Msg Tx Errors	Cumulative number of transmit underruns and transmit stops reported by the MAC/PHY.
Msg Rx Errors	Cumulative number of receive overruns, receive stops, and receive error frames reported by the MAC/PHY.
Tx Retry	Cumulative number of transmits in which the 1st attempt was delayed due to busy medium reported by the MAC/PHY.
Originator IP Address <>	The IP address of the network node making this connection.
Time out Multiplier <>	The value here specifies the multiplier applied to the expected packet rate (API) to obtain the value used by the inactivity timer for this connection.
O2T_RPI <>	Originator to Target (ie, PLC to SI-EN3) Requested Packet Interval for I/O messaging, in milliseconds, for this connection.
O2T_API <>	Originator to Target (ie, PLC to SI-EN3) Actual Packet Interval for I/O messaging, in milliseconds, for this connection.
Consume Msg Cnt <>	Number of I/O messages consumed (ie, received) from the SI-EN3 since the connection was established or statistics were reset for this connection.
T20_RPI <>	Target to Originator (ie, SI-EN3 to PLC) Requested Packet Interval for I/O messaging, in milliseconds, for this connection.
T20_API <>	Target to Originator (ie, SI-EN3 to PLC) Actual Packet Interval for I/O messages, in milliseconds, for this connection.
Produce Msg Cnt <>	Number of IO messages produced (ie, transmit) from the SI-EN3 since the connection was established or statistics were reset for this connection.
Reset Statistics Connection1 <>	Clicking this resets the Consume Msg Cnt and the Produce Msg Cnt for this connection to start counting from zero.

<1> SI-EN3D Dual-port only.

<2> SI-EN3 Single-port only.

### ◆ Email Alerts Tab (SI-EN3D Dual-port)

The Email Alerts tab allows the user to configure four Email Fault/Alarm conditions. When the condition is true, one email will be sent to the provided email address. Another email will not be sent until the condition becomes false and then true again. A 30-second timer prevents emails from being sent when conditions reoccur immediately after being removed. The timer helps limit the amount of emails sent regarding the same intermittent condition and helps to reduce network traffic by reducing emails about reoccurring errors.

Figure 22 Email Alerts Tab View (Dual-Port)

## ■ Conditional Email Set-up

1. Define the condition that will trigger the email by selecting a monitor parameter, a comparator, and a value. Set up comparator values for the range of values to check in the chosen condition. If choosing only one condition and no OR or AND are needed, set the “OR/AND” drop-down selection to “NotUsed”.
2. Enter the email address where the alert will be sent.
3. Enter the message that will appear in the email contents.
4. Enter the email subject.
5. Click the “Email Active” check box to enable the alert.

Clicking “Save to device” will save the entered information into the option memory.

Clicking “Cancel and reload” will cancel any pending edits and display the most recently saved settings from the option board.

## ◆ Parameter Access Tab (SI-EN3D Dual-port)

The Parameter Access tab allows the user to read and write parameters from the drive. Write access is restricted until a valid password is entered.

**Figure 23 Parameter Access Tab View (Dual-Port)**

The MEMOBUS/Modbus address for the drive parameter being accessed must be entered in hexadecimal. The number must begin with “0x” to signify hexadecimal. Clicking “Read” will load and display the current value of the given MEMOBUS/Modbus Address.

Clicking “Set” will save the given value to the given MEMOBUS/Modbus address.

After a “Read” or “Set” command is given, Status will display “Waiting” while the action is being carried out, then “Complete” is displayed when finished.

## ◆ Configuration Tab (SI-EN3D Dual-port)

The Configuration tab sets web page behavior parameters. Access is restricted unless a valid password is entered.

Figure 24 Configuration Tab View (Dual-Port)

### ■ Security Login

Enter a valid password and click “Log in”. The button text changes to “Log out” and the status changes to “Logged in”.

**Note:** The default security password is “yaskawa”.

This password can be changed in the “Change Password” section of the tab. Entering a valid password allows access to the settings in the Configuration tab, Email Alerts tab, and the Parameter Access tab.

### ■ Change Password

To change the password, enter the new password in the “New Password:” and “Confirm Password:” text boxes then click “Change password”. The Status display will change to “Idle” then “Changing Password” then “Password Changed”. If the passwords in the two text boxes do not match, the Status will display “Passwords don’t match”.

### ■ Option Card

The values displayed in the various tabs are refreshed at the rate defined in the “Applet Refresh Rate (ms)” text box. Enter values in the range of 1000 ms to 65.535 seconds.

Parameter Security can be enabled or disabled by clicking one of the radio buttons. When “Disabled” is selected, no password is necessary and all functions in the web pages will be available. When “Enabled” is selected, a valid password must be entered to edit email settings and to write parameters.

### ■ Email Settings

The “Email Server IP” text box must contain the IP address of the email server. The subnet address is configured in drive parameters F7-05 through F7-08. The configured email alerts will use the server at this address when sending emails.

Enter the email server port in the “Email Port” text box.

The value in the “From Email Address” text box identifies the origin of the email alerts to the recipient.

Click “Submit Email Parameters” to save the email settings to the option.

Click “Save Configuration Parameters to Flash” to save the entered values from this tab into non-volatile memory. These values will then be remembered after cycling power.

### ■ General Settings

Click “Save Options Card Parameters” to save the Applet Refresh Rate and the Parameter Security settings to the option.

## ◆ Custom Tab (SI-EN3D Dual-port)

The Custom tab displays a selection of quick setting parameters.




Figure 25 Custom Tab View (Dual-Port)

## 14 Troubleshooting

### ◆ Drive-Side Error Codes

Drive-side error codes appear on the bypass digital operator. Causes of the errors and corrective actions are listed below. Refer to the drive manual for additional error codes that may appear on the bypass digital operator.

#### ■ Faults

Both FB12 (option communication fault) and EF0 (option external fault) can appear as a fault. When a fault occurs, the digital operator ALM LED remains lit. When an alarm occurs, the ALM LED flashes.

If communication stops while the drive is running, use the following questions as a guide to help remedy the fault:

- Is the option properly installed?
- Are the communication lines properly connected to the option? Are the wires loose?
- Is the controller program working? Has the controller/PLC CPU stopped?
- Did a momentary power loss interrupt communications?

Digital Operator Display		Fault Name
<i>EF0</i>	EF0	Option Card External Fault
Cause		Possible Solutions
An external fault was received from the PLC and F6-03 is set to a value other than 3.		<ul style="list-style-type: none"> <li>• Remove the cause of the external fault.</li> <li>• Remove the external fault input from the PLC.</li> </ul>

Digital Operator Display		Fault Name
<i>Fb12</i>	Fb12	Option Communication Error
Cause		Possible Solution
Master controller (PLC) has stopped communicating		<ul style="list-style-type: none"> <li>• Check that power is supplied to the PLC</li> <li>• Check that PLC is not in program mode</li> </ul>
Communication cable is not connected properly		<ul style="list-style-type: none"> <li>• Check for faulty wiring</li> <li>• Correct any wiring problems</li> </ul>
A data error occurred due to noise		<ul style="list-style-type: none"> <li>• Check the various options available to minimize the effects of noise</li> <li>• Counteract noise in the control circuit, main circuit, and ground wiring</li> <li>• If a magnetic contactor is identified as a source of noise, install a surge absorber to the contactor coil</li> <li>• Make sure the cable used meets requirements</li> <li>• Make sure the option ground wire is connected between option FE terminal and the drive ground terminal connected to earth ground</li> </ul>
The option is not properly connected to the drive.		Reinstall the option.
Option is damaged		If there are no problems with the wiring and the error continues to occur, replace the option.
Connection Time-out		<ul style="list-style-type: none"> <li>• The option Requested Packet Interval (RPI) timer timed out.</li> <li>• Make sure that RPI time is set properly.</li> </ul>
Duplicate IP Address		Check if the option shares IP Address with at least one other node. Check the setting values of F7-01 to F7-04 (IP Address).

## Minor Faults and Alarms

Digital Operator Display		Minor Fault Name	
[ 4P0	CyPo	Cycle Power to Active Parameters	
		Comm. Option Parameter Not Upgraded	
Cause		Possible Solutions	Minor Fault (H2-□□ = 10)
Drive is not compatible with the option software version.		Turn off the power and upgrade the communication option parameters. <b>Note:</b> An alarm is triggered when the option software version is earlier or an incompatible option is installed to the drive.	YES

## bUS Fault Tolerance

### bUS Fault Auto-Restart

Parameter F6-14, bUS Fault Auto Reset Select, will appear when the option is installed.

Setting F6-14 = 0 (Disabled) or F6-01 = 3 or greater (Alarm only) will not affect standard default drive behavior.

Setting F6-14 = 1 (Enabled) AND F6-01 ≠ 3 (Fault) will cause the following operation: The bUS fault occurs after the F7-16 delay and the Run command is removed from the drive. Then the option throws a bUS fault to the drive. When the condition is removed, the option commands a fault reset and returns control of the drive to the EtherNet/IP network.

**Note:** The option will only read parameter F6-01 and F6-14 from the drive during power-up.

### bUS Fault Delay

Parameter F7-16, Communications Loss Detection Time Delay, will appear when the option is installed.

The setting value of F7-16 is the length of time that the option will delay sending the bUS fault to the drive.

The status LEDs on the option are not affected by the delay time set in F7-16; the LEDs will indicate the bUS condition immediately.

**Note:** The option will only read parameter F7-16 from the drive during power-up.

## Explicit Message Communications Errors

When there is a problem with a request message sent from the master in explicit communications, the drive will return one of the following error codes.

**Table 16 Communications Errors and Solutions**

Error Code (Hex)	Description	Cause	Possible Solution
08	Service not supported	The service code is incorrect.	Correct the service code.
09	Invalid attribute value	The attribute is incorrect.	Correct the attribute.
0C	Object state conflict	Attempted to change a drive constant that cannot be changed while the drive is running.	Stop the drive.
0E	Attribute not settable	Attempted to change a read-only attribute.	Correct the service code or attribute setting.
13	Not enough data	The data size is incorrect.	Correct the data size.
14	Attribute not supported	Attempted to execute a service not defined for the attribute.	Correct the service code or attribute setting.
15	Too much data	The data size is incorrect.	Correct the data size.
16	Object does not exist	An unsupported object was specified.	Correct the class or instance setting.
1F	Vendor-specific error	Attempted to change a drive constant that cannot be changed while the drive is running. Attempted to change a drive constant to a value outside the setting range.	Stop the drive. Specify a value within the setting range.
20	Invalid parameter	Attempted to change to a data value outside the setting range.	Specify a data value within the setting range.

**Note:** Refer to the MEMOBUS/Modbus Data Table in the MEMOBUS/Modbus Communications chapter of the drive manual for a list of monitor data using the MEMOBUS/Modbus message area.

### ◆ Option Error Codes

#### ■ Option Fault Monitors U6-98 and U6-99

The option can declare error/warning conditions via bypass monitor parameters on the bypass digital operator as shown in [Table 17](#).

**Table 17 Option Fault Monitor Descriptions**

Fault Condition	Fault Declared	Status Value (U6-98/U6-99)	Description
No Fault	n/a	0	No faults
Force Fault	EF0	3	Network sent a message to force this node to the fault state.
Network Link Down	BUS ERROR	1100	No network link to option.
Connection Timeout	BUS ERROR	1101	The node timer (Requested Packet Interval) timed out.
Duplicate IP Address	BUS ERROR	1102	This node and at least one other node have the same IP Address.
Default MAC Address	None	1103	Factory default MAC Address programmed into the option. Return for reprogramming.

Two bypass monitor parameters, U6-98 and U6-99 assist the user in network troubleshooting.

- U6-98 displays the first declared fault since the last power cycle. U6-98 is only cleared upon drive power-up.
- U6-99 displays the present option status. U6-99 is cleared upon a network-issued fault reset and upon power-up.

If another fault occurs while the original fault is still active, parameter U6-98 retains the original fault value and U6-99 stores the new fault status value.

# 15 Specifications

**Table 18 Option Specifications**

Item	Specification
<b>Model</b>	SI-EN3, SI-EN3D
<b>Supported Messages</b>	Explicit: Explicit Class 3, Unconnected I/O: Class 1, Listen Only, Input Only
<b>I/O Assembly Instance</b>	Input: 8 types (4 to 44 Bytes) Output: 8 types (4 to 44 Bytes)
<b>EtherNet/IP Conformance Level</b>	Composite Test Revision: CT12 Passed
<b>ODVA CIP Profile</b>	AC Drive
<b>Connector Type</b>	RJ45 8-pin Straight Connector STP Cat5e cable
<b>Physical Layer Type</b>	Isolated Physical Layer TCP Protocol Transformer Isolated
<b>IP Address Setting</b>	Programmable from drive keypad or network
<b>Communication Speed</b>	Programmable from drive keypad or network: 10/100 Mbps, auto-negotiate
<b>Number of Connections</b>	I/O: 2 Explicit: 6
<b>Duplex Mode</b>	Half-forced, Auto-negotiate, Full-forced
<b>Address Startup Mode</b>	Static, BOOTP, DHCP
<b>Ambient Temperature</b>	-10 °C to +50 °C (14 °F to 122 °F)
<b>Humidity</b>	95% RH or lower with no condensation
<b>Storage Temperature</b>	-20 °C to +60 °C (-4 °F to +140 °F) allowed for short-term transport of the product
<b>Area of Use</b>	Indoor (free of corrosive gas, airborne particles, etc.)
<b>Altitude</b>	1000 m (3280 ft.) or lower





# YASKAWA Z1000 Bypass Option Ethernet/IP Single and Dual-Port Technical Manual

---

**YASKAWA AMERICA, INC.**

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.  
Phone: 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax: 1-847-887-7310  
<http://www.yaskawa.com>

**DRIVE CENTER (INVERTER PLANT)**

2-13-1, Nishimiyaichi, Yukuhashi, Fukuoka, 824-8511, Japan  
Phone: 81-930-25-3844 Fax: 81-930-25-4369  
<http://www.yaskawa.co.jp>

**YASKAWA ELECTRIC CORPORATION**

New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minatoku, Tokyo, 105-6891, Japan  
Phone: 81-3-5402-4502 Fax: 81-3-5402-4580  
<http://www.yaskawa.co.jp>

**YASKAWA ELÉTRICO DO BRASIL LTDA.**

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil  
Phone: 55-11-3585-1100 Fax: 55-11-3585-1187  
<http://www.yaskawa.com.br>

**YASKAWA EUROPE GmbH**

185, Hauptstraße, Eschborn, 65760, Germany  
Phone: 49-6196-569-300 Fax: 49-6196-569-398  
<http://www.yaskawa.eu.com>

**YASKAWA ELECTRIC KOREA CORPORATION**

9F, Kyobo Securities Bldg., 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea  
Phone: 82-2-784-7844 Fax: 82-2-784-8495  
<http://www.yaskawa.co.kr>

**YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.**

151, Lorong Chuan, #04-02A, New Tech Park, 556741, Singapore  
Phone: 65-6282-3003 Fax: 65-6289-3003  
<http://www.yaskawa.com.sg>

**YASKAWA ELECTRIC (THAILAND) CO., LTD.**

252/125-126, 27th Floor, Muang Thai-Phatra Tower B, Rachadapisek Road, Huaykwang, Bangkok, 10310, Thailand  
Phone: 66-2693-2200 Fax: 66-2693-4200  
<http://www.yaskawa.co.th>

**YASKAWA ELECTRIC (CHINA) CO., LTD.**

22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China  
Phone: 86-21-5385-2200 Fax: 86-21-5385-3299  
<http://www.yaskawa.com.cn>

**YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE**

Room 1011, Tower W3 Oriental Plaza, No. 1, East Chang An Ave.,  
Dong Cheng District, Beijing, 100738, China  
Phone: 86-10-8518-4086 Fax: 86-10-8518-4082

**YASKAWA ELECTRIC TAIWAN CORPORATION**

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwan  
Phone: 886-2-2502-5003 Fax: 886-2-2505-1280

**YASKAWA INDIA PRIVATE LIMITED**

#17/A, Electronics City, Hosur Road, Bangalore, 560 100 (Karnataka), India  
Phone: 91-80-4244-1900 Fax: 91-80-4244-1901  
<http://www.yaskawaindia.in>

---

# YASKAWA

## YASKAWA AMERICA, INC.

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2016 YASKAWA AMERICA, INC. All rights reserved.



SIEPYAICOM22

MANUAL NO. SIEPYAICOM22 Rev: A0

Published in USA August 2016 16-8