

VCD 723 Product Guide





Revision History

The following table shows all pages that have been revised since the first issue of this manual.

Revision Date	Affected Pages
9/15/93	Initial

Related Documents List

The following publications provide additional information on the VCD 723 drives. Each is available from MagneTek. Please use the form provided at the back of this manual to place your order.

- Maintenance Guide TM 6723-10
- PCDU Guide TM 6723-20
- MicroTrac® LAN Network Guide TM 6723-30

Additional copies of this manual can also be ordered by specifying the VCD 723 Product Guide (TM 6723).





Warranty Standard products manufactured by MagneTek are warranted to be free from defects in workmanship and material for a period of one year from date of shipment and any products which are defective in workmanship or material will be repaired or replaced, at MagneTek's option, at no charge to the Buyer. Final determination as to whether a product is actually defective rests with MagneTek. The obligation of MagneTek hereunder shall be limited solely to repair or replace, at MagneTek's discretion, products that fall within the foregoing limitations, and shall be conditioned upon receipt by MagneTek or written notice of any alleged defects or deficiency promptly after discovery and within the warranty period, and in the case of components or units purchased by MagneTek, the obligations of MagneTek shall not exceed the settlement that MagneTek is able to obtain from the supplier thereof. No products shall be returned to MagneTek without its prior consent. Products which MagneTek consents to have returned shall be shipped prepaid f.o.b. MagneTek's factory. MagneTek cannot assume responsibility or accept invoices for unauthorized repairs to its components, even though defective. The life of the products of MagneTek depends, to a large extent, upon the usage thereof, and MAGNETEK MAKES NO WARRANTY AS TO FITNESS OF ITS PRODUCTS FOR THE SPECIFIC APPLICATIONS BY THE BUYER NOR AS TO PERIOD OF SERVICE UNLESS MAGNETEK SPECIFICALLY AGREES OTHERWISE IN WRITING AFTER THE PROPOSED USAGE HAS BEEN MADE KNOWN TO IT.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE AND BUYER HEREBY WAIVES ANY AND ALL CLAIMS THEREFORE.

Limitation Of Liability IN NO EVENT SHALL MAGNETEK BE LIABLE FOR LOSS OF PROFIT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL DAMAGES WHETHER ARISING OUT OF WARRANTY, BREACH OF CONTRACT OR TORT.



Table of Contents

Page

Introduction	1
How To Use This Manual	1
Controls and Indicators	1
Safety Statements	2
How To Contact MagneTek	2
Drive Description	3
Ratings and Specifications	5
System Considerations	12
Installation and Start-up	15
Pre-Installation Considerations	15
Physical Installation	15
Electrical Connection	19
Pre-Power Check	25
Drive Start-up	27
Operation	31
Controls and Indicators	31
Start-up Operation	32
General Operation	34
Parameter Functions	35
Monitor Functions	36
Error Handling/Reporting	36
Non-Volatile RAM-Access	40
Load Defaults Function	42
Upload/Download of Program or Parameters	43
Hex Monitor	49
Troubleshooting/Maintenance	51
Fault and Error Conditions	51
Troubleshooting Flowcharts.....	59
Diode and Transistor Module Resistance Test	73
Spare Parts List	75
Appendices	78
VCM Motor/PG (Digital Tachometer) Connection	78
Motor Parameters	81
Node, Channel and Subchannel Assignments	84
Glossary	103



List of Illustrations	Figure Number	Title	Page
	1	Typical MicroTrac System Diagram	14
	2	VCD 723 Dimensions	16
	3	VCD 723 Basic Interconnection Diagram	20
	4	VCD 723 External Connections Diagram.....	21
	5	Proper Grounding of Three VCD 723 Drives.....	25
	6	Voltage Selection in 460V VCD 723, 15HP and Above	26
	7	Local Control Display Unit (LCDU)	31
	8	VCD 723 to IBM PC Compatible Computer Interconnect Diagram	43

List of Tables	Table Number	Title	Page
	1	Motor Control Specifications	5
	2	Terminal I/O Specifications	9
	3	Digital Feedback Tachometer Connector CA1 Terminal Specifications.....	11
	4	Summary of Option Cards.....	11
	5	Closed Loop Connectors and Wire Sizes for Terminal Screws	23
	6	Wire Sizing for Main Circuit	23
	7	Function Number Assignments	34
	8	Standard Error and Fault Descriptions	51
	9	AC MicroTrac Circuit Card Test Points	72
	10	Diode Module Resistances	73
	11	Transistor Module Resistances	74
	12	Spare Parts List - 230 Volt Drives.....	75
	13	Spare Parts List - 460 Volt Drives.....	76
	14	Connection of VCM.....	78
	15	TB1 - PG (Digital Tachometer) Connection	79
	16	Connections on PG (Digital Tachometer) Card	79



How To Use This Manual

MagneTek has made this product guide an easy to use reference. To help you use this manual, we have provided the following guides:

- The top of each page has an identification of the section. For example, notice that at the top of this page

Introduction	1
--------------	---

 appears. This identifies the page as part of Section 1, Introduction. There are four sections in this manual: Introduction, Installation and Start-Up, Operation and Troubleshooting/ Maintenance.
- Each section is organized into one or more major subject headings. These are the main topics covered in that section. You will recognize major subject headings by their distinctive appearances. The next line illustrates an example:

This is an example of a major subject heading from Section 3.

Controls and Indicators

Each major subject heading may have one or more minor topics that are covered. The next line illustrates an example:

Status LEDs

This is a minor topic covered under “Controls and Indicators.”

Each minor topic may have one or more descriptive headings. These identify items covered within the minor topic. The next line illustrates an example:

Ready

This is a descriptive heading covered under “Status LEDs.”

At the bottom of each page is the name of the first major subject heading covered on that page. The page number and revision date are also included. For example, at the bottom of this page, the information indicates that “How to Use This Manual” is the first major subject heading. It was last revised September 15, 1993.

Using the information on the top of the page to find the section, the bottom of the page to find the major subject heading and the left margin to find the minor topics and descriptive headings, you can easily page through the manual to find the information you need.

A table of contents is also included. The Table of Contents can be used to locate section and major topics. A glossary is provided to define terms which may be unfamiliar.



Safety Statements

In addition to notes, the following types of precautionary statements appear in this manual.

IMPORTANT

A statement of conditions which should be observed during drive setup or operation to ensure dependable service.

CAUTION

A statement of conditions which must be observed to prevent undesired equipment faults or degraded drive system performance.

WARNING

A statement of conditions which MUST BE OBSERVED to prevent personal injury or serious equipment damage.

How To Contact MagneTek

For additional information, contact any MagneTek Representative, Authorized Distributor, or our Technical Support Staff at:

MagneTek
16555 West Ryerson Road
New Berlin, WI 53151

(800) 541-0939 (414) 782-0200
FAX: (414) 782-1283

- Drive Description** The MicroTrac name is used to describe MagneTek's family of digital system drives and the compatible products used to create systems. This manual describes the MicroTrac compatible VCD 723 AC motor drive.
- Performance* The VCD 723 is a high performance, sine-coded, Pulse Width Modulated (PWM) AC motor drive which generates an adjustable three phase output for complete speed or torque control of a compatible AC induction motor. The VCD 723 can maintain a 150% current overload for 60 seconds with automatic stall prevention and voltage boost to prevent nuisance tripping during load or line side transient conditions. The VCD 723 will not induce any voltage line notching distortion to the utility line and maintains a displacement power factor of approximately 0.98 throughout its speed range.
- Flexibility* The VCD 723 drive is totally software configurable to the application through a high level graphical language, called Programmable Application Control (PAC). PAC provides complete flexibility without having to make hardware adjustments. Interface to other equipment is provided with local Input/Output (I/O) or a high speed Local Area Network (LAN). Use of the LAN means that a single coaxial cable eliminates multiple conductor cables and provides high noise immunity. Extensive diagnostic and setup capability are provided through two control/display units. The Local Control/Display Unit (LCDU) is mounted flush with the drive cover and consists of a Liquid Crystal Display (LCD) with two lines of sixteen alphanumeric characters, five pushbuttons, and five status Light Emitting Diodes (LED's). The LCDU can be used for all setup functions and many diagnostics. The Portable Control/Display Unit (PCDU) is an optional hand-held device that can be plugged into any MicroTrac compatible drive and used for all the same functions as the LCDU plus some advanced diagnostics. The PCDU has two lines of sixteen alphanumeric characters and a thirty-key keypad.
- Accuracy* The distributed control architecture of the MicroTrac system means that each drive performs its own regulation calculations synchronized to a common high accuracy crystal master. Thus, even minute crystal drift will not affect multiple drive tracking. This allows a MicroTrac system to maintain the drift between sections to 0.00% at steady state. The fully digital nature of the regulation means that an individual drive can maintain a 0.00% average difference between set and actual speed from no-load to full-load when using digital tachometer speed feedback. Digital setup and performance assure exact process line and finished product duplication shift to shift and month to month. Speeds, tensions, ratios, draws, limits, ranges, alarms, and other control parameters can be set as percentages or exact numerical values via keypad or thumbwheel switches with up to six digits of resolution. Parameters are entered and displayed in plain and understandable English. The drive can be completely set up prior to actual running and changes can be made during operation. Keypad entry of changed parameters, protected memory, and factory default values allow the operator to modify data with minimum risk to the process.



Useability The VCD 723 drive is composed of several major components. The base component is the MagneTek VCD 703 drive, with special software. To this is added the MicroTrac circuit card, which provides graphical PAC programming environment, LAN communications and extra local I/O. The other components are the Local and Portable Control/Display Units, which allow user friendly interface for drive setup and provides extensive diagnostic capabilities. In addition, optional circuit cards can be added for expanded local I/O capabilities and added functionality.

Versatility The VCD 723 can be set up to operate in one of two major modes based on the level of regulation enabled. The first mode allows the drive to run as if it were a VCD 703 drive, but the input for the constants come from the PAC environment instead of from the Digital Operator. In addition to utilizing the speed control logic of the VCD 703 drive to control the motor, this mode adds the extra I/O capabilities that are present on the MicroTrac circuit card. This also allows for all of the advantages and flexibility of utilizing the PAC programming language. In this mode, the inputs and outputs on the VCD 723 behave in the same way that they would have had this been a VCD 703 drive, however, the An, Bn, Cn, Dn, On, Sn, and Un constants are entered via the PAC environment.

The second major operating mode of the VCD 723 has the VCD 703 drive operate as a slave to the MicroTrac circuit card. In this mode, the PAC programmer has complete freedom in how the motor should be controlled, including which inputs/outputs should perform a specific function.

Characteristics The VCD 723 is mounted in a NEMA 1 wall mount enclosure, with other power/control components required for VCD/VCM interconnection.

When properly installed, operated and maintained, the VCD 723 can provide years of troublefree service. It is important that the person who operates, inspects, or maintains this equipment thoroughly read and understand this manual before proceeding.



Ratings and Specifications

Control Specifications

Table 1. Motor Control Specifications

SECTION A. 208/230V												
Drive												
General Use	Model VCD 723-	A003	A005	A7P5	A010	A015	A020	A030		A050		
	Capacity	HP	3	5	7.5	10	15	20	30		50	
	Input Current	Motor HP	3	5	7.5	10	15	20	25	30	40	50
		A	11	18	26	35	53	70	97	106	140	211
Continuous Rated Current	A	9.6	16	24	32	48	64	96		160		
Circuit Breaker (MCCB) Rating		A	20	30	50	60	100	100	150		300	
Low Noise Operation ⁽¹⁾	Model VCD 723-	A003	A005	A7P5	A010	A015	A020	A030		N/A		
	Capacity	HP	3	5	7.5	10	15	20	30			
	Continuous Rated Current	A	7.68	12.8	19.2	25.6	38.4	51.2	76.8			
Rated Output Voltage		180V										
Overload Current Rating		150% for one minute ⁽²⁾										
Input Power	Voltage/Frequency		3-Phase 208V, 50Hz 208/230V, 60Hz									
	Allowable Fluctuation	V	± 10%									
		F	± 5%									
Motor (VCM)												
Capacity	HP (KW)	3 (2.2)	5 (3.7)	7.5 (5.5)	10 (7.5)	15 (11)	20 (15)	25 (18.5)	30 (22)	40 (30)	50 (37)	
Model	VMA__	003	005	7P5	010	015	020	025	030	040	050	
Rated Speed	rpm	1750 rpm (4-pole, 60Hz)										
Rated Voltage	3-phase 190 VAC											
Rated Current	A	9.6	16.0	22.8	29.4	44.0	57.0	69.0	82.0	120	148	
Rated Torque	lb-ft	9	15	22.5	30	45	60	75	90	120	150	
WK ²	lb-ft ²	0.183	0.264	0.543	0.680	1.253	1.617	3.260	4.050	5.96	7.5	
Frame No.		182T	184T	213T	215T	254T	256T	284T	286T	324T	326T	

See notes on page 8.



Table 1. Motor Control Specifications - Continued

SECTION B1. 380/415/460V; 3-60 HP														
Drive														
General Use	Model VCD 723-		B001	B003	B005	B010		B015	B020	B030		B040	B060	
	Capacity HP		1	3	5	10		15	20	30		40	60	
	Input Current	Motor HP	1	3	5	7.5	10	15	20	25	30	40	50	60
		A	2.82	5	9	14	18	26	35	42	53	70	97	106
Continuous Rated Current		A	2.56	4.8	8	16		24	32	48		64	96	
Circuit Breaker (MCCB) Rating		A	5	10	20	30		50	60	100		100	150	
Low Noise Operation ⁽¹⁾	Model VCD 723-		B001	B003	B005	B010		B015	B020	B030		B040	B060	
	Capacity HP		1	3	5	10		15	20	30		40	60	
	Continuous Rated Current		A	2.05	3.84	6.4	12.8		19.2	25.6	38.4		51.2	76.8
Rated Output Voltage			360V											
Overload Current Rating			150% for one minute ⁽²⁾											
Input Power	Voltage/Frequency		3-Phase 380/415/460V, 50/60Hz											
	Allowable Fluctuation	V	± 10%											
		F	± 5%											
Motor (VCM)														
Capacity		HP (KW)	1 (0.7)	3 (2.2)	5 (3.7)	7.5 (5.5)	10 (7.5)	15 (11)	20 (15)	25 (18.5)	30 (22)	40 (30)	50 (37)	60 (45)
Model		VMB	001	003	005	7P5	010	015	020	025	030	040	050	060
Rated Speed		rpm	1750 rpm (4-pole, 60Hz)											
Rated Voltage			3-phase 380 VAC											
Rated Current		A	1.63	4.8	8	11.4	14.7	22	28.5	34.5	41	60	74	82
Rated Torque		lb-ft	3	9	15	22.5	30	45	60	75	90	120	150	180
WK ²		lb-ft ²	0.074	0.183	0.264	0.543	0.680	1.253	1.617	3.260	4.050	5.960	7.500	9.340
Frame No.			143T	182T	184T	213T	215T	254T	256T	284T	286T	324T	326T	364T

See notes on page 8.



Table 1. Motor Control Specifications - Continued

SECTION B2. 380/415/460V; 75-400 HP										
Drive										
General Use	Model VCD 723-		B075	B100	B150	B200	B250	B300	B400	
	Capacity		HP	75	100	150	200	250	300	400
	Input Current	Motor HP	A	75	100	150	200	250	300	400
				A	141	211	246	330	374	496
Continuous Rated Current		A	128	165	224	300	340	450	600	
Circuit Breaker (MCCB) Rating			A	225	300	400	600	600	800	1000
Rated Output Voltage			360V							
Overload Current Rating			150% for one minute ⁽²⁾							
Input Power	Voltage/Frequency		3-Phase 380/415/460V, 50/60Hz							
	Allowable Fluctuation	V	± 10%							
		F	± 5%							
Motor (VCM)										
Capacity	HP (KW)		75 (55)	100 (75)	150 (110)	200 (160)	250 (185)	300 (220)	400 (300)	
Model	VMB		075	100	150	200	250	300	400	
Rated Speed	rpm	1750 rpm (4-pole, 60Hz)								
Rated Voltage	3-phase 380 VAC									
Rated Current	A		103	142	206	272	338	398	525	
Rated Torque	lb-ft		225	300	450	600	750	900	1200	
WK ²	lb-ft ²		11.77	17.6	37.0	69.58	74.22	88.14	97.42	
Frame No.			365T	404T	444T	445T	447T	449T	449T	

See notes on page 8.



Table 1. Motor Control Specifications - Continued

SECTION C. All VCD 723's			
Control Characteristics	Control Method	Digital flux vector, Sine-coded PWM	
	Speed Control	Range	1:1000 operation possible even at stall
		Precision	Digital ref.: ± 0.01% (-10 to +40°C, +14 to +140°F) Analog ref.: ± 0.1% (25 ± 10°C, 77 ± 50°F)
	Speed Reference Setting Resolution	Digital Operator reference: 0.01 Hz (12 bits) Analog reference: 0.06 Hz/60Hz (10 bits)	
	Auto Speed Reference Signal	0 to +10 VDC (20k Ω), or 4 to 20 mA (250 Ω)	
	Accel / Decel Time	0 to 3000 sec (resolution: 0.1 sec.) (Accel / Decel times set independently)	
	Torque Limit	Setting range: 0 to 300%. Forward/Reverse set independently	
Selectable Functions	Multi-step speed operation (9 steps max.), S-curve accel/decel, zero speed control, servo lock, arbitrary torque detection, etc.		
Protective Functions	Inverter	Overcurrent, overvoltage, cooling fin overheat, undervoltage, cooling fan failure, grounding, etc.	
	Motor	Overload, overheat, overspeed	
	System	Excessive speed deviation, open-phase detection, continuous operation during momentary power loss (immediate stop at end of programmed ride-thru time, 2 sec. max.) (See Note 3)	
Environmental Conditions	Ambient Temperature	-10 to +45°C (+14 to +113°F)	
	Storage Temperature (See Note 4)	-20 to +60°C (-4 to +140°F)	
	Humidity	90% RH (no condensation)	
	Vibration	1 G at less than 20 Hz, up to 0.2 G at 20 to 50 Hz.	
SECTION D. All VCM's			
Rated speed	1750 rpm (4 poles)		
Pulse Generator	1024 ppr (standard) Higher rates are available.		
Thermistor	Standard		
Load Connection	Direct coupling or belt drive		
Insulation Type	Class F		
Ambient Temperature	-20 to +40°C (-4 to +104°F)		
Location	Indoor		

NOTES:

- (1) Low noise operation can be selected by setting of Sn-09 : 0XXX = General Use (low carrier frequency - 2.08 kHz); 1XXX = Low Noise Operation (high carrier frequency - 12.5 kHz). Rated current is 80% of General Use rated current.
- (2) 100% reference current is Continuous Rated Current for Low Noise Operation or General Use.
- (3) For a drive rated 230V 5HP or less, or 460V 3HP or less, standard max. ride-thru time is 1 sec (1000 msec). The max. ride-thru time can be extended to 2 sec (2000 msec) by adding an optional external mounting capacitor unit.
- (4) Temperature during shipping. Storing in this temperature for a long period may deteriorate main circuit capacitor.



Terminal Functions and Control Signal Specifications

There are various types of I/O available in the VCD 723. The terminal I/O specifications are listed in Table 2. The digital feedback tachometer connector specifications are listed in Table 3. A diagram of these connections can be found in Figure 4.

Table 2. Terminal I/O Specifications

TERMINAL	FUNCTION	DESCRIPTION
1,2,4,5,6,7,8	Logic inputs	The input is off (logic 0) when the input is open, and on (logic 1) when the input is connected to Logic Input Common (0V). If input is from a relay contact, the contact rating must be: 30 VDC min 100 mA min If input is from an open collector, the rating must be: 35 VDC min 100 mA min
3	Logic inputs	This is always used for external fault generation. This input cannot be reassigned. The SN12 constant can be used to set this input to Normally Open or Normally Closed. If Normally Open is selected, a fault is indicated when the contact closes and if Normally Closed is selected an open contact indicates the fault.
9,10	Logic output, normally open relay contact	Normally open relay contact. Contact capacity: 250 VAC at 1A or below. 30 VDC at 1A or below.
11	Logic input common	Common (0V) for use in wiring Logic Inputs.
12	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
13	Analog input	Non-isolated 0 to 10 VDC analog input. Input has 20K ohms of impedance. Resolution is 10 bits.
14	Analog input	Non-isolated 4 to 20 mA analog input. Input has 250 ohms of impedance. Resolution is 10 bits.
15	Analog input power supply	Control power supply for analog input: +15 VDC at 20 mA max.
16	Analog input	Non-isolated 0 to 10 VDC analog input. Input has 20K ohms of impedance. Resolution is 10 bits.
17	Analog input common	Common (0V) for use in wiring analog inputs.
18,19,20	Logic output, form C relay contact	18 is Normally Open, 19 is Normally Closed, and 20 is Common. Contact Capacity: 250 VAC at 1A or below. 30 VDC at 1A or below.
21,22	Analog output	Non-isolated 0 to 11 VDC analog output. Maximum sourcing current is 2 mA. 21 is positive with respect to 22. Resolution is 8 bits.
23,24	Current monitor analog output	Non-isolated analog output. Approximately 5 VDC at rated output current.
25,26	Logic outputs, open collector	Photocoupler isolated output. Capacity of +48 VDC max at 50 mA max.
27	Open collector output common	Common (0V) for use in wiring multi-function open collector outputs.



Table 2. Terminal I/O Specifications - Continued

TERMINAL	FUNCTION	DESCRIPTION
28,29	Logic outputs, open collector	Photocoupler isolated output. Capacity of +48 VDC max at 50 mA max.
30	Motor thermistor input	Motor temperature feedback.
31	Motor thermistor input common	Common (0V) for use in wiring motor thermistor input.
32	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
51	+10VREF output	Reference voltage output for use with MicroTrac card analog inputs. 10 mA max capacity.
52	-10VREF output	Reference voltage output for use with MicroTrac card analog inputs. 10 mA max capacity.
53	I/O common	Common (0V) for use with MicroTrac card I/O.
54	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
55,56	Analog outputs	Non-isolated -10 to +10 VDC analog outputs. Maximum sourcing current is 2 mA. Resolution is 12 bits.
57	I/O common	Common (0V) for use with MicroTrac card I/O.
58	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
59,60,61,62	Analog input	Non-isolated differential analog input. Input has over 100K ohms of impedance. Resolution is 12 bits. Input voltage range is -600 to +600 mV when terminals 60 (+) and 61 (-) are used. Input voltage range is -10 to +10 VDC when terminals 59 (+) and 62 (-) are used.
63	I/O common	Common (0V) for use with MicroTrac card I/O.
64	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
65,66,67,68	Analog input	Non-isolated differential analog input. Input has over 100K ohms of impedance. Resolution is 12 bits. Input voltage range is -600 to +600 mV when terminals 66 (+) and 67 (-) are used. Input voltage range is -10 to +10 VDC when terminals 65 (+) and 68 (-) are used.
69	I/O common	Common (0V) for use with MicroTrac card I/O.
70	Shield tie point	Shield sheath tie point which is connected to Chassis Common.
71,72,73,74	Digital Tachometer inputs	The quadrature encoder A (terminal 71), /A (terminal 72), B (terminal 73), and /B (terminal 74) signals are connected here. There is 100 ohms of impedance between each pair of encoder input signals. Input differential voltage of 5 VDC max. The maximum input frequency is 300KHz.
Connector CA1	Digital Tachometer Connector	Isolated +12 VDC power supply to quadrature encoder and quadrature encoder signal inputs.

**Table 3. Digital Feedback Tachometer Connector
CA1 Terminal Specifications**

TERMINAL	FUNCTION	DESCRIPTION
1	Isolated power supply	Isolated power supply for digital tachometer: +12 VDC at 200 mA max.
2	Isolated power supply common	Common (0V) for digital tachometer isolated power supply.
3,4,5,6	Digital Tachometer inputs	The quadrature encoder A (terminal 3), /A (terminal 4), B (terminal 5), and /B (terminal 6) signals are connected here. There is 560 ohms of impedance between each signal pair, pair A and /A and pair B and /B. Input differential voltage of 5 VDC max. The maximum input frequency is 300KHz.
7	Shield tie point	Shield sheath tie point which is connected to Chassis Common.

Option Cards

There are various option cards available to provide additional capability. The option cards are each described in detail in a separate User Reference Sheet. A summary of available option cards is contained in Table 4.

Table 4. Summary of Option Cards

OPTION CARD	FUNCTION
Analog Monitor, AO-8	Has two analog output channels with 8 bit resolution. Each output voltage is from 0 to +10 VDC and is non-isolated.
Analog Monitor, AO-12	Has two analog output channels with 12 bit resolution. Each output voltage is from 0 to +10 VDC and is non-isolated.
Digital Output, DO-8	Has six photocoupler output channels with a single common. Also has two independent relay contact output channels.
Torque Control, TRQ-A	Closes the torque control loop for higher accuracy torque control.



System Considerations

When operating in a system application, the VCD 723 can be used with other MagneTek devices with which it will communicate by means of the MicroTrac Local Area Network (LAN). Refer to Figure 1 for a typical MicroTrac System.

Each of the following remote devices (board or assembly) is described in detail in a separate User Reference Sheet.

- **Remote Display Controller LAN Node PCB (RDC)** – This board provides a means for the MicroTrac system to have system operating parameters displayed at locations remote from the MicroTrac drive. The RDC communicates with the drive through the LAN. A single RDC can support up to 31 Remote Display Units (RDUs). By means of a Portable Display/Control Unit (PCDU), the RDC allows the selected display for each RDU to be changed at anytime.
- **Remote Display Unit (RDU)** – Designed for mounting in a panel cutout, the RDU provides a two-line LED display (16 character alphanumeric, and 5-1/2 digit numeric). Consisting of a terminal, the information on its display is transmitted by a Remote Display Controller LAN Node PCB.
- **Remote Keyboard Assembly** – Designed for mounting on a panel with or near a Remote Display Unit, the Remote Keyboard allows initiation of RDU display changes without the need for a Portable Display/Control Unit.
- **Remote I/O [Input/Output] Controller LAN Node PCB (RIO)** – This board provides a means for the MicroTrac system to have inputs or outputs at locations remote from the drive. The RIO communicates with the drive through the LAN. A single RIO can support up to 6 Remote I/O boards, using any combination of the following:
 1. **Remote Logic I/O PCB (LOGI/O)** – This board provides remote logic signal input/output capability for the MicroTrac system. It is connected to a Remote I/O Controller LAN Node PCB for communication with the drive.
 2. **Remote Analog I/O PCB (ANI/O)** – This board provides remote analog signal input/output capability for the MicroTrac system. It is connected to a Remote I/O Controller LAN Node PCB for communication with the drive.
 3. **Remote Thumbwheel Switch I/O PCB (TWIO)** – This board provides remote thumbwheel switch input/output capability for the MicroTrac system. It can support up to 9 Thumbwheel Switch Assemblies. This board is connected to a Remote I/O Controller LAN Node PCB for communication with the drive.

- **Remote Programmable Logic Controller (PLC) Interface** – Available for a variety of PLCs. These devices allow bi-directional communication via the MicroTrac LAN between drives and the PLC. Both logic and numeric data can be transferred.
- **Remote Power Supply** – The Remote Power Supply produces control level voltages for use by a Remote LAN Node PCB or a Remote Display Unit.
- **Remote Serial Communication Controller LAN Node PCB (RSC)** – This board provides a means for the MicroTrac system to have input from or output to other equipment that uses RS-232 serial communication. The RSC communicates with the drive through the LAN.




Figure 1. Typical MicroTrac System Diagram

Pre-installation Considerations

Location of the VCD 723 is important to achieve proper performance and normal operating life. The unit should be installed in an area where it will be protected from the following:

- Direct sunlight, rain or extreme (condensing) moisture.
- Corrosive gases or liquids.
- Vibration, airborne dust or metallic particles.

Receipt of Shipment

All equipment is tested against defect at the factory. Any damages or shortages evident when the equipment is received must be reported immediately to the commercial carrier who transported the equipment. Assistance, if required, is available from your MagneTek representative. Always refer to the order number, equipment description, and serial number when contacting MagneTek.

Unpacking

Remove the protective shipping material from around the equipment. Remove all packing material. Inspect for loose wiring. Make sure all contact wedges and other shipping devices have been removed.

Repacking


For long periods of storage, equipment should be covered to prevent corrosion, and should be placed in a clean, dry, location. If possible, equipment should be stored in its original crating. Periodic inspection should be made to ensure that the equipment is dry and that no condensation has accumulated. The equipment warranty does not cover damage due to improper storage. Assistance, if required, is available from your MagneTek representative.

Physical Installation

For effective cooling as well as proper maintenance, the VCD 723 must be installed vertically. Use the holes provided on the back of the drive for installation. There **MUST** be a **MINIMUM** 6 inch clearance above and below the VCD 723 enclosure. A **MINIMUM** 3 inch clearance is required on the left side of the VCD 723 enclosure. See Figure 2 for physical dimensions.



VCD 723 Standard Protected Chassis



LA-12


INPUT	HP (kW)	ENCLOSURE DIMENSIONS IN INCHES (mm)							MTG HOLE DIMENSIONS IN INCHES (mm)		WEIGHT LBS. (KG)
		H	W	D	A	B	C	K	H1	W1	
208 / 230V	3 (2.2) 5 (3.7)	11.97 (304)	8.05 (204)	8.86 (225)	.48 (12)	.39 (10)	1/4-20 (M6)	1.57 (40)	11.22 (285)	7.09 (180)	21 (10)
	7.5 (5.5) 10 (7.5)	13.94 (354)	8.05 (204)	10.04 (255)	.48 (12)	.39 (10)	1/4-20 (M6)	1.57 (40)	13.19 (335)	7.09 (180)	27 (12)
380 / 415 / 460V	3 (2.2)	13.94 (354)	8.05 (204)	8.66 (220)	.48 (12)	.39 (10)	1/4-20 (M6)	1.57 (40)	13.19 (335)	7.09 (180)	27 (12)
	5 (3.7) 10 (7.5)	13.94 (354)	8.05 (204)	10.04 (255)	.48 (12)	.39 (10)	1/4-20 (M6)	1.57 (40)	13.19 (335)	7.09 (180)	27 (12)

Note: Consult Factory for Shipping Weights.

Figure 2. VCD 723 Dimensions (Sheet 1 of 3)



VCD 723 Standard Protected Chassis



LA-13


INPUT	HP (kW)	ENCLOSURE DIMENSIONS IN INCHES (mm)							MTG HOLE DIMENSIONS IN INCHES (mm)		WEIGHT LBS. (KG)
		H	W	D	A	B	C	K	H1	W1	
208 / 230V	15 (11)	19.69 (500)	9.84 (250)	10.04 (255)	.96 (25)	.30 (7.5)	1/4 (M6)	4.11 (104)	19.09 (485)	7.87 (200)	52 (24)
	20 (15) 30 (22)	21.65 (550)	12.80 (325)	9.65 (245)	.96 (25)	.30 (7.5)	1/4 (M6)	3.37 (86)	21.06 (535)	10.83 (275)	76 (35)
	10.04 (255)										
	40 (30) 50 (37)	31.50 (800)	18.70 (475)	11.02 (280)	1.97 (50)	.39 (10)	7/16 (M10)	4.30 (109)	30.71 (780)	14.76 (375)	105 (48)
380 / 415 / 460V	15 (11) 20 (15)	19.69 (500)	9.84 (250)	10.04 (255)	.96 (25)	.30 (7.5)	1/4 (M6)	2.58 (66)	19.09 (485)	7.87 (200)	54 (25)
	30 (22)	21.65 (550)	12.80 (325)	10.04 (255)	1.19 (30)	.30 (7.5)	1/4 (M6)	3.37 (86)	21.06 (535)	10.43 (265)	76 (35)
	40 (30) 50 (37) 60 (45)	28.54 (725)	13.78 (350)	11.02 (280)	1.97 (50)	.30 (7.5)	3/8 (M8)	4.14 (105)	27.76 (705)	9.84 (250)	105 (48)
	75 (55) 100 (75) 150 (110)	36.42 (925)	22.64 (575)	11.02 (280)	1.97 (50)	.49 (12.5)	7/16 (M10)	4.30 (109)	35.43 (900)	18.70 (475)	199 (90)
	12.99 (330)			234 (106)							
	200 (160)	53.54 (1360)	23.62 (600)	17.72 (450)	1.97 (50)	.69 (17.5)	1/2 (M12)	5.90 (150)	52.16 (1325)	21.65 (550)	379 (172)
	300 (220)	57.09 (1450)	37.40 (950)	17.12 (435)	3.94 (100)	.98 (25)	1/2 (M12)	4.05 (103)	55.12 (1400)	29.53 (750)	797 (362)
	400 (300)	63.00 (1600)	37.80 (960)	17.72 (450)	4.13 (105)	.98 (25)	1/2 (M12)	4.05 (103)	61.02 (1550)	29.53 (750)	905 (411)

Note: Consult Factory for Shipping Weights.

Figure 2. VCD 723 Dimensions (Sheet 2 of 3)



VCM Motor - Foot Mount




ALL DIMENSIONS IN INCHES

HP	FRAME	BA	C	D*	E	2F	H
3	182T	2.75	20.50	4.50	3.75	4.50	.406
5	184T	2.75	21.50	4.50	3.75	5.50	.406
7.5	213T	3.50	24.26	5.25	4.25	5.50	.406
10	215T	3.50	25.76	5.25	4.25	7.00	.406
15	254T	4.25	29.25	6.25	5.00	8.25	.531
20	256T	4.25	31.00	6.25	5.00	10.00	.531
25	284T	4.75	32.50	7.00	5.50	9.50	.531
30	286T	4.75	34.00	7.00	5.50	11.00	.531
40	324T	5.25	34.63	8.00	6.25	10.50	.656
50	326T	5.25	36.13	8.00	6.25	12.00	.656
60	364T	5.88	41.94	9.00	7.00	11.25	.657
75	365T	5.88	42.94	9.00	7.00	12.25	.657
100	405T	6.63	45.62	10.00	8.00	13.75	.828
150	444T	7.50	48.25	11.00	9.00	14.50	.828
200	445T	7.50	50.25	11.00	9.00	16.50	.828
300	447T	7.50	54.00	11.00	9.00	20.00	.828
400	449T	7.50	67.75	11.00	9.00	22.00	.828

*** DIMENSION TOLERANCES**

DIM. D	TOL.	DIM. U	TOL.
UP TO 8.00	+ .00 - .03	UP TO 1.5000	+ .0000 - .0005
OVER 8.00	+ .00 - .06	OVER 1.5000	+ .000 - .001



LA-14


FRAME	U*	V	N-W	U Keyway
180	1.1250	2.50	2.75	.250 x .125
210	1.3750	3.12	3.38	.312 x .156
250	1.625	3.75	4.00	.375 x .188
280	1.875	4.38	4.62	.500 x .250
320	2.125	5.00	5.25	.500 x .250
360	2.375	5.75	5.88	.625 x .312
400	2.875	7.00	7.25	.750 x .375
440	3.375	8.25	8.50	.875 x .438

Figure 2. VCD 723 Dimensions (Sheet 3 of 3)

Electrical Connection

All basic connections are shown in Figure 3 and the drive's external connection locations are shown in Figure 4. Most of the control I/O are shown in a general fashion for an example of proper wiring. Because of the flexibility of the VCD 723, many of the control functions (i.e., RUN, Speed Reference, etc.) are not permanently assigned to a specific I/O point. The function that many of the I/O points serve is dependent upon the designer. See schematic and interconnection diagrams for specific connections.

It is very important that voltage isolation be maintained with all the I/O points which are not already isolated. For example, the analog outputs are not isolated. Therefore, if an analog output is driving a meter movement, then the movement must be in reference to the VCD 723 I/O common and not to any other common (i.e., earth common). On the other hand, if the analog output is connected to a non-isolated analog input of some test equipment, then analog isolation is necessary. The analog isolation must be performed with components not supplied with the VCD 723.



LA-15

Figure 3. VCD 723 Basic Interconnection Diagram




Figure 4. VCD 723 External Connections Diagram



Wire Sizes and Connections

Ensure that wire size and disconnect devices conform to the installation contractor's drawings and to all applicable codes. Refer to Tables 5 and 6 for proper wire sizes and interconnecting information.

CAUTION

- Use only factory supplied installation instructions to install dynamic braking resistors. Failure to do so may cause equipment damage or personnel injury.
- Use 600 volt vinyl-sheathed wire or equivalent. Wire size should be determined considering ampacity and codes.
- **Never** connect AC main power to output terminals T1(U), T2(V), and T3(W).
- **NEVER** allow wire leads to contact the VCD 723 enclosure. Short-circuit may result.
- **NEVER** connect power factor correction capacitors or noise filter to VCD 723 output.
- Size of control wire must be suitable for Class I circuits.
- Use only closed loop (ring lug) connectors sized for the selected wire gauge. The connectors are to be installed using the correct crimp tool recommended by the connector manufacturer.

Observe the following precautions when making wiring connections:

- Separate the leads used for control I/O (i.e., the signals on terminals 1 through 32, terminals 51 through 76, connector CA1, etc.) from those used for the power signals (i.e., L1(R), L2(S), L3(T), T1(U), T2(V), T3(W)). Do not run these two groups in the same conduit or wire trough.
- Provide shielded and twisted leads as indicated on the schematic and interconnection diagrams. Connect shield sheath **AT THE VCD 723 END ONLY**. The far end should be dressed neatly and left unconnected. Twisted shielded pair wire should be used for long runs.
- Lead length should **NOT EXCEED** 164 feet (50 meters).
- The contact output control leads from terminals 9, 10, 18, 19, and 20 must be separated from the other control leads.
- If the drive is being used in a LAN, use a BNC "T" connector to connect the LAN coaxial cable to the drive.



Table 5. Closed Loop Connectors and Wire Sizes for Terminal Screws

WIRE SIZE		TERMINAL SCREW SIZE	CLOSED LOOP CONNECTOR
AWG	mm ²		
20	0.5	M3.5	1.25 - 3.5
18	0.75		
16	1.25	M4	1.25 - 4
14	2	M4	2 - 4
		M5	2 - 5
12	3.5	M4	3.5 - 4
		M5	3.5 - 5
10	5.5	M4	5.5 - 4
		M5	5.5 - 5
8	8	M5	8 - 5
		M6	8 - 6
6	14	M6	14 - 6
4	22	M8	22 - 8
1	38	M8	38 - 8
1	38	M10	38 - 10
2/0	60		60 - 10
3/0	80		80 - 10
4/0	100		100 - 10
4/0	100	M12	100 - 10
MCM300	150		150 - 12
MCM400	200		200 - 12

Table 6. Wire Sizing for Main Circuit

DRIVE MODEL VCD 723-	TERMINAL SYMBOL	TERMINAL SCREW SIZE	WIRE SIZE	
			AWG	MM ²
SECTION A. 208/230 V				
A003, A005	L1(R), L2(S), L3(T), N, B1/P, B2, T1(U), T2(V), T3(W)	M4	12 - 10	3.5 - 5.5
	G(E)	M4	14 - 10	2 - 5.5
A7P5, A010	L1(R), L2(S), L3(T), N, B1/P, B2, T1(U), T2(V), T3(W)	M5	10 - 8	5.5 - 8
	G(E)	M5	14 - 10	2 - 5.5
A015	L1(R), L2(S), L3(T), P1, P3, T1(U), T2(V), T3(W), N	M6	8 - 6	8 - 14
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ (s)	M4	20 - 14	0.5 - 2
A020	L1(R), L2(S), L3(T), P1, P3, T1(U), T2(V), T3(W), N	M8	8 - 4	8 - 22
	G(E)	M8	14 - 10	2 - 5.5



Table 6. Wire Sizing for Main Circuit - Continued

DRIVE MODEL VCD 723-	TERMINAL SYMBOL	TERMINAL SCREW SIZE	WIRE SIZE	
			AWG	MM ²
SECTION A. 208/230 V (Continued)				
A025, A030	L1(R), L2(S), L3(T), P1, P3, T1(U), T2(V), T3(W), N	M8	4 - 2	22 - 38
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ (s)	M4	20 - 14	0.5 - 2
A040, A050	L1(R), L2(S), L3(T), P1, P3, T1(U), T2(V), T3(W), N	M10	1 - 4/0	38 - 100
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ (s)	M4	20 - 14	0.5 - 2
SECTION B. 380/415/460V				
B001, B003	L1(R), L2(S), L3(T), N, B1/P, B2, T1(U), T2(V), T3(W)	M4	12 - 10	3.5 - 5.5
	G(E)	M4	14 - 10	2 - 5.5
B005, B010	L1(R), L2(S), L3(T), N, B1/P, B2, T1(U), T2(V), T3(W)	M4	12 - 10	3.5 - 5.5
	G(E)	M5	14 - 10	2 - 5.5
B015, B020	L1(R), L2(S), L3(T), N, B1/P, B2, T1(U), T2(V), T3(W), P3	M5	10 - 8	5.5 - 8
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2
B030	L1(R), L2(S), L3(T), N, P1, P3, T1(U), T2(V), T3(W)	M6	8 - 6	8 - 14
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2
B040, B060	L1(R), L2(S), L3(T), N, P1, P3, T1(U), T2(V), T3(W)	M8	4 - 3	22 - 38
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2
B075, B100, B150	L1(R), L2(S), L3(T), N, P1, P3, T1(U), T2(V), T3(W)	M10	1 - 4/0	38 - 100
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2
B200, B250	L1(R), L2(S), L3(T), N, P1, P3, T1(U), T2(V), T3(W)	M12	4/0 - MCM400	100 - 200
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2
B300, B400	L1(R), L2(S), L3(T), N, P1, P3, T1(U), T2(V), T3(W)	M12	MCM650 x 2P	325 x 2P
	G(E)	M8	14 - 10	2 - 5.5
	l ₁ (r), l ₂ 200(s200), l ₂ 400(s400), x, y	M4	20 - 14	0.5 - 2

Grounding The VCD 723 must be solidly grounded using the main circuit ground terminal G (E).

- Ground wire resistance should be 100 ohms or less.
- NEVER ground the VCD 723 in common with welding machines, motors, or other large current electrical equipment. Run the ground lead in a separate conduit from leads for large current electrical equipment.
- Use ground lead size listed in table 6, and make the length as short as possible.
- Where several VCD 723 drives are used side by side, all should be grounded directly, or daisy chained to earth ground (see Figure 5). DO NOT FORM A LOOP WITH THE GROUND LEADS.




Figure 5. Proper Grounding of Three VCD 723 Drives

Pre-Power Check

CAUTION

To prevent damage to the drive, the following checks must be performed before applying input power.

- Make sure wires are properly connected.
- Verify ground connections to the drive.
- Disconnect motor from its load. To ensure safety, prior to test operation, disconnect the coupling or belt which connects the motor with the machine so that motor operation is isolated. If an operation must be performed while the motor is directly connected to the machine, use great care to avoid any possible hazardous condition.
- For 460V, 15HP and above verify that the power voltage select connector in the VCD 723 is positioned correctly for the input power line voltage (see Figure 6). Voltage is preset to 460V at the factory. Reposition if required.
- Check that all mechanical connections inside VCD 723 are tight.




Figure 6. **Voltage Selection in 460V VCD 723, 15HP and Above**

- Remove any excess packing material.
- Check that all shipping devices and relay wedges have been removed. Manually operate all contactors and relays to ensure that they move freely.
- Verify that all electrical connections are secure.
- Verify that all transformers are connected for proper voltage, according to the drive system schematic diagram.
- Verify that the PG-X tachometer card is installed.
- Verify the EPROM inserted in the VCD 703 control board is labeled according to the drawings supplied.
- Verify that all connections are made per the schematic.
- Verify that the three phase power connections are secure.

CAUTION

Verify that incoming power IS NOT connected to the drive's output terminals. (Terminals T1, T2, and T3). Improper connection will cause severe damage to the drive when energized.

Drive Start-up

- ❑ Verify the motor, blower, thermistor, and PG (Digital Tachometer) wiring for proper voltage and phase sequence. If the motor is a MagneTek Vector Control Motor (VCM), then see the appendix for proper wiring. If the motor is not a MagneTek VCM, then see the manufacturer supplied drawings.
- ❑ Apply three phase input power to the drive.
- ❑ Verify that the “CHARGE” lamp inside the drive is lit.
- ❑ The first message that will be displayed on the Local Control Display Unit is the following:

**Verifying the
CRC-16. Wait . . .**

This is an indication that the CPU is verifying the program loaded in its memory is valid. The check takes approximately 5 seconds. After the check, one of a number of messages will be displayed.

- ❑ When the program and non-volatile memory is valid, the following message will be displayed on the Local Control Display Unit:

**Powered Up
and Ready**

In addition, the Ready LED will be lit.

- ❑ The following is a list of abnormal display conditions that may occur, and the actions necessary to correct the situation:
 - If there is an invalid program in memory, then the following message will be displayed on the Local Control Display Unit:

**Select BAUD rate
19200 UP,DWN,ENT**

If this occurs, a new program must be uploaded into memory. See Section 3 for the proper program upload procedure.

- Check that no faults are indicated on the drive’s display. A fault is indicated by the Fault LED being lit and a fault message appearing on the Local Control Display Unit. See Section 3 for more detailed information regarding fault reporting and clearing.



- As part of the program's start-up procedure, the validity of the nonvolatile parameters are checked. If the values are invalid, the following message is displayed on the Local Control display Unit:

**BAD NVRAM CRC
ENT FOR DEFAULTS**

If this occurs, press the ENT key. The factory programmed default values will then be loaded into non-volatile memory.

- ❑ The parameter values should be checked for proper settings. The settings will be shown on the Function list supplied with the order documentation. Refer to Section 3 to find the operating procedure necessary to view and change parameter values. These parameter values include the following:
 - Speed Reference Setting Constants (i.e., Main Speed Reference, Jog Speed Reference).
 - Application Constants (i.e., Accel Time, Decel Time, Forward Side Torque Limit).
 - Control Constants (i.e., Speed Reference Input Limit, Pulse Generator Pulses Per Motor Revolution, Motor Overload Detection starting Current).
 - Motor Constants (i.e., Base Speed, Number of Motor Poles, Motor Rated Current, Rated Slip Frequency).
 - Order Constants (i.e., Select Control with or without Pulse Generator Feedback, Select Control with or without motor thermistor).
 - System Constants (i.e., MagneTek Vector Control Motor Selection, Input/Output Function Assignments, Control Behavior Selections, Carrier Frequency Selection).
 - Any other values that may be job specific (i.e., Empty Roll Diameter for winder applications, Follower Pulse Generator Pulses Per Revolution).
- ❑ Check the Pulse Generator's (PG) rotation.
 - Select the parameter to view the PG Feedback (function number 604).
 - Manually rotate the shaft counter clockwise, as viewed from the shaft end. Verify that the displayed PG feedback is positive.

If the display does not change from "0", check the PG cable connections. If the problem persists, check for pulses at test points "PA" and "PB" on the right-hand side of the PG-X card, with an oscilloscope.

If the PG feedback shows a negative sign ("-"), reverse the polarity by reversing the wiring between the A and B channels. This is accomplished by switching the wire labeled A+ with wire labeled B+, then switching wire labeled A- with wire labeled B-.

- Manually rotate the shaft clockwise, as viewed from the shaft end. Verify that the displayed PG feedback is negative (“-”).
- Check the motor rotation.
 - Check that the drive is in the forward rotation mode.
 - Start the motor at a slow speed by using the JOG input if one is present. Check that the motor accelerates smoothly and that the speed feedback is the same as the speed reference.
 - If the motor does not accelerate smoothly or oscillates, check or perform the following:
 - ① Reverse any two motor leads.

IMPORTANT

If leads are reversed, re-identify and record the fact that the leads were reversed.

- ② If the speed feedback does not read the same as the speed reference, verify that the pulse generator’s Pulse Per Revolution constant (function number 46) is set to the proper value for your pulse generator.
- ③ Again start the motor at a slow speed by using the JOG input if one is present. If instability is still present, check for a noise related problem:

Program the drive for open loop mode by disabling the Pulse Generator input.

Start the motor at low speed again by using the JOG input if one is present. If instability disappears, the problem is noise related.

Program the drive for closed loop mode by enabling the Pulse Generator input.

- ④ To verify that noise is the source of the problem, perform the following:

Change the drive constant, which changes the carrier frequency, from 2.08 KHz to 12.5 KHz.

- Using the LCDU change the appropriate constants.
- Using the LCDU save the changes to NVRAM.



- Power the drive down long enough for the charge light to go out.
- Power up the drive.

Run the drive at low speed by using the JOG input if one is present. If instability increases, the problem is noise related.

Return the carrier frequency to its original setting.

- ⑤ If it has been determined that noise is the source of the problem, check for grounding problems:

Motor must be grounded.

Drive must be grounded.

Check shield connections.

Power leads from the line and to the motor should be isolated from the pulse generator signals.

External power supply connections for tachometer common should be isolated from the earth ground.

External signals, if used, should be isolated from earth ground.

- ⑥ If noise is not the problem (instability is not related to carrier frequency), contact MagneTek Service about adjusting regulator constants.

- Perform a motor test run. The test run should be in both the forward and reverse direction.
- Connect the motor coupling, or belt, to the load.

Parameter Verification

- Verify once again that the VCD 723 parameter values are set to their proper values. Refer to section 3 to find the operating procedure necessary to view and change parameter values.
- Record any parameter values that were changed from their factory default values.
- Operate the drive using external control signal inputs shown on the system schematic and verify proper operation.

Controls and Indicators

Accessible through the front cover of the VCD 723 are local controls and indicators. Figure 7 shows the Local Control Display Unit.




Figure 7. Local Control Display Unit (LCDU)

At the top of the LCDU is a liquid crystal display. Two lines of sixteen alphanumeric characters can be displayed. This allows for English language legends and units while entering or viewing data.

Status LEDs There are five light emitting diodes on the LCDU. These are used as a quick indication of the drive's status.

Ready Indicates that the drive is ready to operate.

Run Drive is controlling motor speed.

Torque Limit Drive is demanding more torque than is available.

Overload Motor current is in the overload region.



Fault Indicates that a drive fault exists. The Fault/Error Code List (see Table 8 located in the Troubleshooting/Maintenance section) defines what conditions the drive will recognize as faults.

IMPORTANT

Clearing a Fault from the Fault List is NOT THE SAME as resetting the fault. Some faults are transient in nature and require no further action after clearing the fault from the Fault List. Others require additional action to allow the drive to continue to run. See the Fault/Error Code List for further details.

All status lights are under the control of the application specific software. The PAC program for this drive must be consulted to determine the actual meaning for each light.

Local Control Display Unit (LCDU)

There are five keypad keys on the LCDU. These allow for the entry and viewing of data. They can also be used for operating the drive.

ESC Allows you to “back out” of an operation. For example, if a mistake is made while entering numerical data, the ESC key can be pressed before the data is entered, allowing the operator to start over.

Up Arrow Scrolls to the next higher number. The number may be a specific function number or the modification of the value of a parameter.

Down Arrow Scrolls to the next lower number. The number may be a specific function number or the modification of the value of a parameter.

ENT Completes an operation. It may be pressed to enter a modified parameter’s value, or to go “deeper into” a function.

RST Used to clear the fault list. There are other methods that can be used to clear the fault list, but this key provides a shortcut. Any time this key is pressed, the fault list will be cleared. Depending on the nature of the fault and the PAC program loaded, this button can also clear the fault condition as well as the record of the fault.

An optional Portable Control Display Unit (PCDU) can be plugged into a telephone style jack at the side of the VCD 723 drive (reference figure 4). If your drive is equipped with this option, refer to the PCDU guide provided with the unit for operating procedures.

Start-up Operation

- After applying power, the first message displayed on the Local Control Display Unit is the following:

**Verifying the
CRC-16. Wait...**

This is an indication that the CPU is verifying the program loaded in memory is valid. The check takes approximately 5 seconds. After the check, one of a number of messages will be displayed.

- When the program and non-volatile memory are valid, the following message will be displayed on the Local Control Display Unit:

**Powered Up
and Ready**

In addition, the Ready LED will be lit.

- The following is a list of abnormal display conditions that may occur, and the actions necessary to correct the situation:
 - If there is an invalid program in memory, then the following message will be displayed on the Local Control Display Unit:

**Select BAUD rate
19200 UP,DWN,ENT**

If this occurs, a new program must be uploaded into memory. The program upload procedure is explained later in this section.

- A fault condition may have occurred, in which case a fault message will be displayed. An example of a fault message would be as follows:

**Divide by Zero
F103 Blk:00170**

A fault message is always displayed in this fashion. The top line of the LCDU display contains a description of the fault. The bottom line of the LCDU display contains the Fault assigned number and other information that will help determine the cause of the fault. In the example given above, the extra information shows which PAC block was being executed. If the block number is 0000 the fault occurred in the kernel code. When the fault is related to the MicroTrac LAN, instead of the PAC block number, a Local Area Network Node number will appear (i.e., Node:002), which will identify the device on the MicroTrac LAN with which the fault is associated.



When a fault message is displayed, the source of the fault should be corrected. After the fault source is corrected, the fault may be cleared by pressing the RST key on the LCDU.

- As part of the program’s startup procedure, it checks the validity of the parameters that are stored in non-volatile memory. If the values are invalid, then the following message is displayed on the Local Control Display Unit:

**BAD NVRAM CRC
ENT FOR DEFAULTS**

If this occurs, press the ENT key. The factory programmed default values will then be loaded into non-volatile memory.

**General
Operation**

After the drive has powered up and the display is showing “Powered Up and Ready”, or a fault number, the LCDU can be used to enter new values for parameters, monitor drive functions, and perform certain drive diagnostics. Every operation that the LCDU performs is called a “function”. Each function is assigned a unique number. Function numbers and descriptions are listed in Table 7.

Table 7. Function Number Assignments

Function Number	Description
000	Fault Display/Clear
1 to 599	PAC Dependent Parameter Values
600-799	PAC Dependent Monitor Only Values
800	Error Display
801	Modify Fault and Error Declarations
802-899	Reserved for Advanced Fault and Error Control
900-979	Reserved for Diagnostics and Tests
980 (P)	PAC Block Trace Monitor
981-991	Reserved for Diagnostics and Tests
992 (L)	Upload/Download of Program or Parameters
993 (P)	Reset All Non-Volatile RAM
994	Save/Restore Non-Volatile RAM Parameters
995	Load Defaults
996-998	Reserved for Diagnostics and Tests
999	Hex Monitor

- (P) These functions are only available through use of the optional Portable Control Display Unit (PCDU).
- (L) These functions are only available through use of the Local Control Display Unit (LCDU).

Parameter Functions

The functions numbered 1 through 599 are reserved for settable parameters. The function numbers for these settable parameters depend on the PAC program, although some function numbers may be standardized. Examples of settable parameters are Accel Times, Regulator Gains, and Rated Speed.

The following steps explain how to modify a given parameter value via the LCDU display:

- ❑ Press the Up or Down Arrow keys to select the desired function number. The display shows a description of the function on the top line, and the present value, units, and function number on the bottom line.

```
TACH COUNTS
1024. PPR P068
```

- ❑ Press the ENT key to allow the currently displayed parameter to be modified. After the ENT key is pressed, a prompt will be given to indicate that the modify mode is active.

```
TACH COUNTS
1024. PPR EDIT
```

- ❑ Press the Up or Down keys to change the value of the parameter. The least significant digit of the parameter will be changed by 1 for every keypress. Holding the key down will result in an auto repeat of the keypress. If a minimum or maximum limit is exceeded for the parameter value, then the message “vLIMv” or “^LIM^” will be displayed, respectively.
- ❑ At this point, the ENT key or the ESC key may be pressed.

Press the ENT key to accept the currently entered value for the displayed parameter. If the value is within the minimum and maximum limits for the parameter, it is accepted and the modify prompt disappears. If the value has exceeded a limit when the ENT key is pressed, the limit is accepted and the modify prompt disappears.

A modified parameter is retained only as long as power is applied. Function #994 is used to save the new value in nonvolatile memory.

Press the ESC key to exit the modify mode without changing the parameter value. The modify prompt will disappear and the original value will return.



Monitor Functions

Functions numbered 600 through 799 are reserved for parameters that may be viewed, but not modified. The function numbers for these displayable parameters depend on the PAC program, although some function numbers may be standardized. Examples of displayable parameters are Speed Feedback, Actual Motor RPM, and Inverter Output Current.

The following steps explain how to display a given parameter via the LCDU display:

- ❑ Press the Up or Down Arrow keys to select the desired function number. The display shows a description of the function on the top line, and the present value, units, and function number on the bottom line.

SPEED
0.000 PU M600

Error Handling/Reporting

The drive has two methods for reporting errors and faults. Each condition may utilize one, both, or neither of the reporting methods.

1. The most conventional method is called fault reporting. Each occurrence of a fault is recorded in an area of memory called the Fault List. At the moment a fault condition occurs, the red FAULT light will light and a unique fault number will appear on the LCDU. The Fault List stores the 16 oldest faults and stops recording faults as soon as the list is filled. This list is erased when the drive is powered down or reset. Whether or not the drive stops or continues to run is dependent on the way the particular fault is implemented within the PAC diagram. Most standard faults are set so that the drive will stop if a fault occurs.
2. The second method is called error reporting. Each occurrence of an error is recorded in an area of memory called the Error List. Error reporting differs from fault reporting in several respects. First, at the moment an error condition occurs, the red FAULT light will NOT light and a unique error number will NOT appear on the LCDU. Second, the Error List stores the 16 most recent errors and always overwrites the oldest error when the list is filled. Third, the Error List is stored in Non-Volatile Memory and is retained when the drive is powered down or reset. Lastly, the drive operation is NOT affected when an error condition occurs.

**Fault Reporting
(F0)**

Function number “0” is used to display and clear the Fault List. The following steps explain how to display and clear faults via the LCDU display:

- ❑ Press the Up or Down Arrow keys to select the desired function number, 0. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**DISPLAY FAULTS
(press ENT) F000**

- ❑ Press the ENT key. If there are no faults in the list, then a no fault message will be displayed.

**No Faults
(press ESC)**

If there are faults in the list, then a top of fault list message will be displayed.

**TOP OF FLT LIST
RST clears all**

- ❑ Press the Down Arrow key to view the faults in the list. For example:

**MATH UNDERFLOW
F102 Blk:00702**

The top line describes the fault, and the bottom line displays the fault code along with the PAC block that was executing when the fault occurred. A PAC block number of “00000” indicates that the fault was declared by the Kernel software and not by the execution of a PAC block.

The oldest fault is on the top of the list. Therefore, pressing the Down Arrow key displays a newer fault, and pressing the Up Arrow key displays an older fault. The end of the list is reached when the Down Arrow key is pressed enough times and the end of fault list is displayed.

**END OF FLT LIST
Press INC**

- ❑ Press the ESC key to return to the function entry mode.

**DISPLAY FAULTS
(press ENT) F000**

- ❑ Press the RST key at any time to clear all of the faults currently stored in the fault list. The FAULT light will be turned off and the list will be cleared.



Error Reporting (F800)

Function number 800 is used to display the Error List. The following steps explain how to display errors via the LCDU display:

- ❑ Press the Up or Down Arrow keys to select the desired function number, 800. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**VIEW ERROR LIST
(press ENT) F800**

- ❑ Press the ENT key. If there are no errors in the list, then a no error message will be displayed.

**No ERRORS yet
(press ESC)**

If there are errors in the list, then the first error in the list will be displayed.

- ❑ Press the Down Arrow key to view the errors in the list. For example:

**MATH UNDERFLOW
05:35:12 *B00702**

The top line describes the error, and the bottom line displays the elapsed time since the error occurred along with the PAC block that was being executed.

The elapsed time is a measurement of how long the drive has been powered up since the error occurred. There are two formats in which the elapsed time will be displayed; HH:MM:SS (for hours, minutes, and seconds) if the error occurred within 24 hours, and DDD-HH:MM (for days, hours, and minutes) if the error occurred more than 24 hours ago.

The “*” character before the B on the bottom line marks a fixed entry in the error list. Only that one error list entry will display the “*” character. There is no start to the error list since it may be overwritten at any time. The “*” character is used to show when one complete loop of the error list has been viewed.

A PAC block number of “00000” indicates that the error was declared by the Kernel software and not by the execution of a PAC block.

The newest error is on the top of the list. Pressing the Up Arrow key displays a newer error, and pressing the Down Arrow key displays an older error. When the end (or start) of the list is reached, pressing the corresponding Down (or Up) Arrow key will loop to the start (or end) of the list.

- ❑ Press the ESC key to return to the function entry mode.

**VIEW ERROR LIST
(press ENT) F800**

Fault and Error Report Setup (F801)

Function number 801 is used to indicate which conditions should be reported as a fault, an error, or both. The list of possible conditions is referred to as the disposition list. The following steps explain how to display and modify the disposition list via the LCDU display:

- ❑ Press the Up or Down Arrow keys to select the desired function number, 801. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**MODIFY DISP LIST
(press ENT) F801**

- ❑ Press the ENT key. The last accessed condition will be displayed. For example:

**DIVIDE BY ZERO
#017 Error Fault**

The top line contains a description of the condition. The bottom line contains the condition number and how the condition should be reported when it occurs.

- ❑ Press the Up or Down Arrow keys until the condition that is to be modified is displayed. For example:

**MATH OVERFLOW
#101 Error Fault**



- ❑ Press the ENT key to modify how the condition is to be reported. A modify prompt will appear to indicate that keypresses will now affect how this condition is reported.
- ❑ Press the Up or Down Arrow keys to cycle through all of the combinations of disposition. The combinations of disposition are that the condition not be reported (neither Error nor Fault appear), be reported only as an Error (only Error appears), be reported only as a Fault (only Fault appears), or report the condition as both an Error and a Fault (both Error and Fault appear).
- ❑ At this point, the ENT key or the ESC key may be pressed.

Press the ENT key to accept the currently entered disposition combination for the displayed condition. The modify prompt will disappear.

Press the ESC key to exit the modify mode without changing the disposition for the displayed condition. The modify prompt will disappear and the original disposition combination will return.

- ❑ Press the ESC key after all modifications are made to return to the function entry mode.

**MODIFY DISP LIST
(press ENT) F801**

Non-Volatile RAM-Access (T994)

Every parameter the drive uses has three areas in memory associated with it. First, there is an active memory area (RAM) where the value is stored and used by the run-time software. Second, there is a read-only memory area (ROM) where the factory-set default value is permanently stored. Last, there is an area in non-volatile memory (NVRAM) where the value is saved and remembered for the next power up or reset. This multi-level approach makes it possible to return to the last set of “stable” parameters in tuning of the active drive parameters.

Function number 994 is used to transfer parameter values between the non-volatile memory area and the active memory area. The following steps explain how to copy data to or from the non-volatile memory area:

- ❑ Press the Up or Down Arrow keys to select the desired function number, 994. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**NVRAM ACCESS
(press ENT) T994**

- ❑ Press the ENT key. A message will appear that will state the actions that may be performed.

**UP:Rest DN:Save
NV->RAM RAM->NV**

- ❑ At this point, the ESC key, the Up Arrow key, or the Down Arrow key may be pressed.

Press the ESC key to return to the function entry mode without performing any value transfers.

**NVRAM ACCESS
(press ENT) T994**

Press the Up Arrow key to restore the parameter values in the active memory area (RAM) from the values in the last saved memory area (NVRAM). A message will appear showing that the restore is taking place. This will be followed by a message explaining that the restoration is complete. Press the ESC key to return to the function entry mode.

Restoring data

**Restore is done,
press ESC key.**

Press the Down Arrow key to save the parameter values in the active memory area (RAM) to the last saved memory area (NVRAM). A message will appear explaining that the save is complete. Press the ESC key to return to the function entry mode.

**Save completed,
press ESC key.**



Load Defaults Function (T995)

Every parameter in the drive has a factory-set default value that is loaded when the drive is powered up for the first time. These default values may not be optimal values for a specific application; however, they will allow the drive to function properly. It is possible to reload these default parameter values. For instance, when the drive is operating erratically and is suspected that one or more parameters were improperly set.

Function number 995 is used to transfer the factory-set default values to the parameter values in the active memory area. The following steps explain how to load default values to the active memory area:

- ❑ Press the Up or Down Arrow keys to select the desired function number, 995. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**LOAD DEFAULTS
(press ENT) T995**

- ❑ Press the ENT key. A message will appear that will state the actions that may be performed.

**IF SURE (enter)
ELSE (ESC) T995**

- ❑ At this point, the ESC key or the ENT key may be pressed.

Press the ESC key to return to the function entry mode without performing any value transfers.

**LOAD DEFAULTS
(press ENT) T995**

Press the ENT key to load the factory-set default values into the active parameter values. A message will appear explaining that the loading of the default values is complete. Press the ESC key to return to the function entry mode.

**Defaults loaded,
press ESC key.**

Upload/ Download of Program or Parameters (T992)

The VCD 723 has the ability to pass program and parameter information between the drive's memory and a computer with a serial port. The direction of data flow is defined as Upload (from the computer to the drive) or Download (from the drive to the computer). Figure 8 shows the electrical connections required to connect the serial port of the VCD 723 to the serial port (COM1) of an IBM PC™ compatible computer. The PC utilized must have a serial port and disk drive.




Figure 8. VCD 723 to IBM PC Compatible Computer Interconnect Diagram

In addition to the electrical connections, a serial communications program must be utilized by the computer to access data through the serial port. A serial communications program which supports the Y Modem Batch file transfer protocol, such as ProComm™ or Qmodem™ must be installed on the PC. The Y Modem Batch file transfer protocol is the protocol that must be used when communicating with the VCD 723. In uploading and downloading of files, the drive behaves like a bulletin board service to the PC. A file upload means that a file is sent from the PC to the drive. A file download means that a file is sent from the drive to the PC.

There are two file types associated with upload and download. One is the PAC program file (i.e., the file with the .PRG extension). The other is the parameter file (i.e., the file with the .PAR extension). The PAC program file is the file that contains the executable instructions that determines the application characteristics of the drive. The parameter file is a file of all the parameter settings of a drive at the time the .PAR file was captured (from a previous parameter download).



Program upload is defined as the process of a computer sending the VCD 723 drive a new PAC program (i.e., the .PRG file) through the drive's serial port. This process may be required when upon application of power the drive finds that the PAC program loaded into memory is invalid. This process may also be used when it is desired to change the PAC program from what was previously loaded. Some of the steps shown below are skipped when the PAC program in memory is found to be invalid upon application of power.

Program download is defined as the process of the VCD 723 drive sending a computer its PAC program (i.e., the .PRG file) through the drive's serial port. This process can be used for memory backup.

Parameter upload is defined as the process of a computer sending the VCD 723 drive all of its settable parameters (i.e., the .PAR file). This process can be used to set up the drive with a set of tuned constants.

Parameter download is defined as the process of the VCD 723 drive sending a computer all of its settable parameter values (i.e., the .PAR file). This process can be used for memory backup. A parameter download is the only data transfer process that can occur while the drive is in RUN mode.

The VCD 723 can not be in RUN mode while an upload or a program download is occurring. Furthermore, the PAC program stops executing while the upload or program download is happening.

Function number 992 is used to upload and download PAC programs and parameters. The following steps explain how to perform an upload or download:

- Press the Up or Down Arrow keys to select the desired function number, 992. The display shows a description of the function on the top line, and the action that may be performed on the bottom line.

**UPLOAD/DOWNLOAD
(press ENT) T992**

- Press the ENT key. A message will appear that will state the actions that may be performed.

**DRIVE → PC
UP, DOWN, or ENT**

- At this point, the ESC key, the Up Arrow key, or the Down Arrow key may be pressed.

Press the ESC key to return to the function entry mode without performing any data transfers.

**UPLOAD/DOWNLOAD
(press ENT) T992**

Press the Up Arrow key to select an upload operation.

**DRIVE ← PC
UP, DOWN, or ENT**

Press the Down Arrow key to select a download operation.

**DRIVE → PC
UP, DOWN, or ENT**

- Press the ENT key to accept the Upload or Download selection. A message will appear that will state the actions that may be performed.

**PARAMETER xfer
UP, DOWN, or ENT**

- At this point, the ESC key, the Up Arrow key, or the Down Arrow key may be pressed.

Press the ESC key to return to the function entry mode without performing any data transfers.

**UPLOAD/DOWNLOAD
(press ENT) T992**

Press the Up Arrow key to select transfer of the program.

**PROGRAM xfer
UP, DOWN, or ENT**

Press the Down Arrow key to select transfer of the parameters.

**PARAMETER xfer
UP, DOWN, or ENT**



- ❑ Press the ENT key to accept the given selection. A message will appear that will state the actions that may be performed.

**Select BAUD rate
19200 UP,DWN,ENT**

- ❑ Press the Up or Down Arrow keys to select the desired baud rate. Pressing the Up arrow will increase the baud rate and pressing the Down arrow key will decrease the baud rate (19,200 is the maximum baud rate).
- ❑ Press the ENT key to accept the displayed baud rate. The VCD 723 will begin the selected file transfer.

CAUTION

When the program transfer begins it must be completed because the existing program is erased.

- ❑ Initiate a Y Modem Batch file transfer from the PC (i.e., for ProComm users press the <PgUp> key for an upload or press the <PgDn> key for a download, and select the YMODEM Batch mode).
- ❑ Depending on the direction and type of file transfer, one of several sequences will occur.

For a Program Upload:

- A message will appear explaining that permanent storage memory is being erased.

**Erasing the
FLASH ROMs**

- A message will appear explaining that the VCD 723 is attempting to start the program transfer.

**Start UPLOAD
of Program**

- At this time, the VCD 723 is waiting to communicate with the PC. When the transfer begins, a message will appear showing how much of the transfer has already taken place. For a baud rate of 19200, the transfer will take approximately five minutes. The completion percent number counts up as more data is transferred.

**Completion:
23%**

In addition, the lights on the LCDU will appear to bubble up showing that the transfer is taking place.

- When the transfer is complete, non-volatile memory needs to be initialized. A message will appear explaining what to do.

**BAD NVRAM CRC
ENT FOR DEFAULTS**

- Press the ENT key. This will load the programmed default values into the active parameter area and into the non-volatile memory area and begin execution of the PAC program.

**Powered Up
and Ready**

- For a Program Download:

- A message appears explaining that the VCD 723 is attempting to start the program transfer.

**Start DOWNLOAD
of Program**

- At this time, the VCD 723 is waiting to communicate with the PC. When the transfer begins, a message will appear showing how much of the transfer has already taken place. For a baud rate of 19200, the transfer will take approximately ten minutes. The completion percent number counts up as more data is transferred.

**Completion:
23%**



In addition, the lights on the LCDU will appear to bubble up showing that the transfer is taking place.

Downloads generally take longer than uploads because the download transfers all memory locations while an upload only transmits the active portion of memory.

- When the transfer is complete, the function entry mode will return.

**UPLOAD/DOWNLOAD
(press ENT) T992**

- For a Parameter Upload:

- A message appears explaining that the VCD 723 is attempting to start the parameter transfer.

**Start UPLOAD
of Parameters**

- At this time, the VCD 723 is waiting to communicate with the PC. When the transfer begins, a message will appear showing how much of the transfer has already taken place. For a baud rate of 19200, the transfer will take approximately 30 seconds. The completion percent number counts up as more data is transferred.

**Completion:
23%**

In addition, the lights on the LCDU will appear to bubble up showing that the transfer is taking place.

- When the transfer is complete, the function entry mode will return.

**UPLOAD/DOWNLOAD
(press ENT) T992**

❑ For a Parameter Download:

- A message appears explaining that the VCD 723 is attempting to start the parameter transfer.

**Start DOWNLOAD
of Parameters**

- At this time, the VCD 723 is waiting to communicate with the PC. When the transfer begins, a message will appear showing how much of the transfer has already taken place. For a baud rate of 19200, the transfer will take approximately 30 seconds. The completion percent number counts up as more data is transferred.

**Completion:
23%**

In addition, the lights on the LCDU will appear to bubble up showing that the transfer is taking place.

- When the transfer is complete, the function entry mode will return.

**UPLOAD/DOWNLOAD
(press ENT) T992**

**Hex Monitor
(T999)**

Function number 999 is used to directly view memory values. A memory map is required, and as such, it is reserved for use by MagneTek personnel.

**DCU HEX MONITOR
(press ENT) T999**



Fault and Error Conditions

An error or fault condition is an indication of abnormal behavior. Table 8 lists all of the standard type errors and faults that might arise, and suggestions on what actions need to be performed to correct the problem. In addition to the errors and faults listed, the PAC program may contain more application specific errors and faults; refer to the order documentation for a list of these errors and faults. Use the procedures in Section 3 to view the errors and faults that may be present. Once action has been performed to remove the cause of the fault, use the procedures listed in section 3 to clear the faults.

Table 8. Standard Error and Fault Descriptions

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
17, DIVIDE BY ZERO	A division by the number zero has occurred.	Check the PAC diagram for any denominators that may be zero. The fault display will show which PAC block was executing at the time of the fault.
21, WATCHDOG TRIP 22, RSRVD INTERRUPT 30, MEMORY ACCESS 31, SEVERE CODE FLT 32, CODE FAULT 33, HARDWARE FAULT	A problem with either hardware or software has occurred on the MicroTrac circuit card.	Refer to troubleshooting chart 13.
96, WEB BREAK	The continuous web has broken.	
97, OVERSPEED	Command value is too high.	Verify all speed parameter settings (i.e. pulses per revolution, motor rated speed, etc.). Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ① Correct the setting. ② Use function 994 to transfer the data from RAM to NVRAM. ③ Turn power off. ④ When the charge light is off, then turn power on.
98, TACH LOSS	<ol style="list-style-type: none"> ① Broken tach wires. ② Loose connector. ③ Tach failure - belt loss? 	Verify wiring to the tachometer.
99, REVERSE TACH	Tach connected backwards.	Reverse tachometer A signals with tachometer B signals. For example, switch wire labeled A+ with wire labeled B+, then switch wire labeled A- with wire labeled B-.
100, NOT-A-NUMBER 101, MATH OVERFLOW 102, MATH UNDERFLOW 103, F.P. DIVIDE BY ZERO 104, SIGN ERROR	A mathematical error has occurred.	Check the PAC diagram for the possible cause. The fault display will show which PAC block was executing at the time of the fault.



Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
113, MISSING PCU	The MicroTrac is running but not communicating with the processor on the Power Conversion Unit circuit card.	Refer to troubleshooting chart 13.
121, DP RAM ERROR	The cable between the MicroTrac card and the inverter is bad. The Dual Port RAM on the MicroTrac card is bad.	Replace the cable between the MicroTrac card and the drive. Replace MicroTrac circuit card.
260, ITERATION T/O	Upload/Download protocol detected, too many retries.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
261, OUT OF SEQUENCE	Upload/Download protocol block sequence is not contiguous.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
262, BYTE TIMEOUT	Upload/Download protocol more than one second has elapsed between block byte transmission or reception.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
263, WRONG FILE TYPE	Upload/Download protocol unrecognized file extension.	Use one of the proper file extensions when using Upload or Download (i.e., .PAC or .PRG).
264, NULL BLK EXPECTD	Upload/Download protocol partial null block was sent.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
265, USER CANCELLED	Upload/Download protocol user abort.	The Y Modem transfer was cancelled by the user. This occurs when the ESC key is pressed on the LCDU or when the user cancels it through use of the communications software executing on the PC.
266, UNEXPECTD NL BLK	Upload/Download protocol, a null block was not expected.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
267, WRONG S-REC TYPE	Upload/Download protocol only S2 and S8 records are OK.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
268, BAD S-REC CHECK	Upload/Download protocol S record did not verify.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.
269, BAD, S-REC ENDREC	Upload/Download protocol END record did not verify.	<ol style="list-style-type: none"> ① Check serial port cable wiring and connections. ② Check software executing on PC.

Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
270, FILE TOO LARGE	Upload/Download protocol filesize is greater than one gigabyte.	None of the files used will ever be this size, so check the validity of the file under question.
271, WRONG FILENAME	Upload/Download protocol given parameter .PAR filename does not match the PAC program .PRG filename.	Check for the proper filenames.
272, NO MEMORY HERE	Upload/Download protocol memory check did not pass after an S-record write.	<ol style="list-style-type: none"> ❶ Verify S-record writes to available memory. ❷ The FLASH ROM IC's may need to be replaced. ❸ The MicroTrac card may need to be replaced.
274, MOTOR RUNNING	Upload/Download was attempted while the Motor is in the RUN mode.	Stop the motor before attempting an Upload or a Download.
275, NOT PARAM FILE	Upload/Download parameter .PAR file had an invalid (no sync) S0 record.	<ol style="list-style-type: none"> ❶ Check serial port cable wiring and connections. ❷ Check software executing on PC.
276, FLASH PRG 00 ERR	Can't program a byte in the FLASH ROM to all logic 0.	<ol style="list-style-type: none"> ❶ The FLASH ROM IC's may need to be replaced. ❷ The MicroTrac card may need to be replaced.
277, FLASH PRG FF ERR	Can't program a byte in the FLASH ROM to all logic 1.	<ol style="list-style-type: none"> ❶ The FLASH ROM IC's may need to be replaced. ❷ The MicroTrac card may need to be replaced.
278, FLASH VERIFY ERR	A byte in the FLASH ROM did not program correctly.	<ol style="list-style-type: none"> ❶ The FLASH ROM IC's may need to be replaced. ❷ The MicroTrac card may need to be replaced.
700, I MAIN P U VLT	Drive declared a main power under voltage. This occurs two seconds after detection of low voltage.	Check incoming power.
701, I CTRL P U VLT	Drive declared the control circuit power to be under the acceptable voltage level during operation.	Control power supply may be bad.
702, MC CONTACTOR OFF	Drive declared that the main circuit magnetic contactor does not operate correctly.	Check connections to main circuit contactor.



Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
703, BRAKE TRANSISTOR	Drive declared that the braking transistor is malfunctioning.	Replace braking transistor or gate drive board.
704, BRAKE RESIST HOT	Drive declared that the brake resistor unit overheated.	Wait for resistor to cool. Check application requirements for braking capacity.
706, THERMISTOR OPEN	Drive declared that the connection to the motor thermistor is disconnected.	Verify proper wiring to the thermistor. If properly wired, then use the spare thermistor.
707, TRANSMIT ERROR	Drive declared that the transmission between the VCD 723 and the remote operator was not established within 5 seconds after the power supply was turned on.	Verify that the correct version of EPROM's are installed in the VCD 723. This error indicates that the inverter portion of the drive is programmed as a VCD 703.
712, EXT FLT T INPUT	Drive declared that a transmission error occurred 2 seconds after transmission was established between the VCD 723 and the remote operator.	Verify that the correct version of EPROM's are installed in the VCD 723. This error indicates that the inverter portion of the drive is programmed as a VCD 703.
720, OPEN INV TACH	Drive detected that its pulse generator input is open.	Verify wiring to PG-X circuit card CA-1 connector.
721, INV OVERSPEED	Drive declared an overspeed.	Verify all speed parameter settings (i.e. pulses per revolution, motor rated speed). Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ① Correct the setting. ② Use function 994 to transfer the data from RAM to NVRAM. ③ Turn power off. ④ When the charge light is off, then turn power on.
722, INV SPEED ERROR	Drive detected a probable speed error.	
741, BASE BLOCK CKT	Drive detected a control circuit failure.	Replace the inverter control circuit card.
742, SHADOW RAM FLT	Drive detected that its NVRAM is bad.	Replace the inverter control circuit card.
743, NVRAM CHKSUM ERR	Drive detected that the constants in its non-volatile memory are not valid.	Confirm that all parameters are within allowable ranges. If they are, then replace the inverter control circuit card.
744, INV MCU Q/D FLT	Drive detected that its CPU A/D converter has failed.	Replace the inverter control circuit card.

Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
745, OPTION CARD CONN	Drive detected that its optional card connector has failed.	Replace the inverter control circuit card or the connecting cable.
751, DSP P CKT FLT	Drive detected that its Digital Signal Processor (DSP) peripheral circuitry has failed.	Replace the inverter control circuit card.
752, OPTION A/D FLT	Drive declared that the A/D converter on its High Accuracy Torque Control option card has failed.	Replace the inverter control circuit card.
753, MISSING DCU	Drive has not received a software handshake from the MicroTrac circuit card.	<ol style="list-style-type: none"> ❶ Cycle power off and on. ❷ Replace the cable between the MicroTrac card and the drive. ❸ Replace MicroTrac circuit card.
754, INV MODEL ERROR	Drive declared that the model number is wrong.	Replace the inverter control circuit card.
760, DPRAM CHECKSUM	Drive declared that the checksum validating the constants in the Dual Port RAM (between the MicroTrac card and the inverter) is incorrect.	Verify all of the constant settings. Replace the MicroTrac circuit card. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
761, DPRAM CONST. ERR	Drive declared that a constant in the Dual Port RAM (between the MicroTrac card and the inverter) is out of range.	Verify all of the lettered constant settings. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.



Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
762, KVA SETTING ERR	Drive declared that the KVA setting is out of range.	Verify the KVA setting constant SN01. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
763, SETTING ERROR	Drive declared that a constant in the Dual Port RAM (between the MicroTrac card and the inverter) is out of range.	Verify all of the lettered constant settings. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
764, SN15-18 SET ERR	Drive declared that one or more of the constants SN15, SN16, SN17, SN18, are invalid.	<ol style="list-style-type: none"> ❶ Verify the settings of the constants SN15, SN16, SN17, SN18. ❷ Verify data relationship (SN15, SN16, SN17, SN18). Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
765, TRQ SELECT ERR	Drive declared the Torque control mode selection is in error.	Verify the settings of the constants that affect the Torque control. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.

Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
766, INV NV RAM ERR	Drive has declared an error in writing to its non-volatile RAM.	Replace the inverter control circuit card. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
767, OUT OF RANGE	Drive declared a value is out of range.	Verify all of the lettered constant settings. Whenever changing parameter settings the following procedure must be followed: <ol style="list-style-type: none"> ❶ Correct the setting. ❷ Use function 994 to transfer the data from RAM to NVRAM. ❸ Turn power off. ❹ When the charge light is off, then turn power on.
768, OVERCURRENT	Drive has detected that the output current exceeds 200% of the transistor rated current.	Refer to troubleshooting chart 7.
769, BUS OVERVOLTAGE	Drive has detected that the DC bus voltage is high. The detection level is approximately 400V for a 230V rated unit; 800V for a 460V rated unit.	Refer to troubleshooting chart 5.
770, INV. OVERLOAD	Drive detected that the Drive overload protection has tripped.	Refer to troubleshooting chart 8.
771, INVERTER HOT	Drive detected that the fin temperature has exceeded 90 degrees C (194 degrees F) +/-5 degrees.	Refer to troubleshooting chart 10.
772, BLOWN FUSE	DC Bus fuse has cleared.	Check for a short circuit in the output.
773, OPEN LOAD PHASE	Drive detected an opening in the wiring from the inverter to the motor.	Check for problems in the drive to motor wiring.
774, INV HARDWARE FLT	Drive detected a fault in its control circuit hardware.	Replace the inverter control circuit card.
775, MOTOR OVERLOAD	Drive detected that the motor overload protection has tripped.	Refer to troubleshooting chart 8.



Table 8. Standard Error and Fault Descriptions - Continued

ERROR/FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
776, MOTOR HOT	Drive detected that the motor overheat temperature has been exceeded.	<ol style="list-style-type: none"> ❶ Verify constant CN14 and CN15 settings. ❷ Refer to troubleshooting chart 10.
777, TRANSIENT P LOSS	Drive detected low voltage, but momentary power loss ride-thru is enabled, and momentary power loss ride-thru time (constant CN19) has not been exceeded yet.	Verify incoming power.
778, SPEED DEVIATION	Drive detected excessive speed deviation.	Verify speed related constants.
779, INVERTER FAN	Drive detected that its cooling fan has failed.	<ol style="list-style-type: none"> ❶ Look for cooling fan obstructions. ❷ Replace cooling fan.
800, LAN HARDWARE ERR	The Local Area Network (LAN) hardware is not operating properly.	Check BNC "T" Connector. Check 95Ω termination resistors. Replace the MicroTrac circuit card.
801, MAX. LAN RETRIES	A directed LAN message was not received by the given network node number after trying several times.	Verify that the given node number is connected to the same coaxial cable (the MicroTrac LAN) as the VCD 723, and that it is operational.
802, ILLEGAL MSG TYPE	A directed LAN message was received by the VCD 723 from the given node, and the message content is not one of the supported message data types.	<ol style="list-style-type: none"> ❶ Verify that the given node number is operating properly. ❷ Verify that the LAN is operating properly.
803, BROADCAST MISSED	A broadcast message from the given node was not received by the VCD 723 within the allotted time, and one was expected.	Verify that the given node number is connected to the same coaxial cable (the MicroTrac LAN) as the VCD 723, and that it is operational.
804, DIRECTED MISSED	A directed message from the given node was not received by the VCD 723 within the allotted time, and one was expected.	Verify that the given node number is connected to the same coaxial cable (the MicroTrac LAN) as the VCD 723, and that it is operational.
805, LAN - NO TX ROOM	Not enough memory is allocated in the MicroTrac memory to store all of the LAN messages that need to be transmitted.	Contact MagneTek. The software on the MicroTrac circuit card needs to be changed.
806, LAN - NO RX ROOM	Not enough memory is allocated in the MicroTrac memory to store and process all of the LAN messages that have been received.	Contact MagneTek. The software on the MicroTrac circuit card needs to be changed.

**Troubleshooting
Flowcharts**

If the VCD 723 malfunctions, locate the cause and take corrective action by following the flowcharts in this section.

A. TROUBLESHOOTING MOTOR SYMPTOMS

Motor Does Not Rotate	Chart 1
Motor Stalls During Operation	Chart 2
Motor Does Not Rotate at Set Speed	Chart 3
Motor Hunting	Chart 4

B. TROUBLESHOOTING FOR FAULT CONDITIONS

Overvoltage	Chart 5
Blown Fuse	Chart 6
Overcurrent	Chart 7
Overload	Chart 8
Underload	Chart 9
Inverter Overheated	Chart 10
Control Function Error	Chart 11
External Fault	Chart 12
Power Supply Verification	Chart 13

WARNING

Oscilloscope chassis may be at voltages potentially hazardous to life if not properly grounded. If oscilloscope is used to measure high voltage waveforms, use only a dual channel oscilloscope in the differential mode with X100 probes. Always connect oscilloscope chassis to earth ground.

WARNING

Voltages dangerous to life exist when equipment is open and energized. Do not work alone.

CAUTION

To prevent equipment damage always remove incoming three-phase power before test equipment is connected or removed. Never disconnect or connect the wiring while the power is applied.



Chart 1. Motor Does Not Rotate




Chart 2. Motor Stalls During Operation






Chart 3. Motor Does Not Rotate At Set Speed




Chart 4. **Motor Hunting**






Chart 5. Overvoltage (ou) Fault Indication





Chart 6. Blown Fuse (FU) Fault Indication



WARNING
DO NOT REPLACE DC BUS FUSE WITHOUT FIRST CHECKING OUTPUT TRANSISTORS.



Chart 7. Overcurrent (oC) Fault Indication




Chart 8. Overload (oL) Fault Indication






Chart 9. Underload (uU) Fault Indication




Chart 10. Inverter Overheated (oH) Fault Indication






Chart 11. Control Function Error (CPF_ _) Fault Indication




Chart 12. External Fault (EF_) Indication






Chart 13. Power Supply Verification




Table 9. AC MicroTrac Circuit Card Test Points


TP1 - TP13	For use by MagneTek Engineering
TP14	Analog Input 0 (+/-10 VDC)
TP15	Analog Input 1 (+/-10 VDC)
TP16	Analog Output 0 (+/-10 VDC)
TP17	Analog Output 1 (+/-10 VDC)
TP18	+10VREF
TP19	-10VREF
TP20	-15 VDC Supply
TP21	+5 VDC Supply
TP22	+15 VDC Supply
TP23	+24 VDC Supply
TP24	Power Supply Common
TP25	Power Supply Common

Diode and Transistor Module Resistance Test

Diode Module

Measure the resistance across the module terminals with a volt-ohm meter. Set the meter at the X1 range. The measured resistance should be within the values listed in Table 10.

RESISTANCE TEST FOR 3Ø CONVERTER MODULES (BRIDGE RECT)



VOM RESISTANCE SCALE R x 1
 + IS THE POSITIVE POLARITY LEAD*
 - IS THE NEGATIVE POLARITY LEAD

*THE VOM RED LEAD IS NOT NECESSARILY THE POSITIVE POTENTIAL IN THE RESISTANCE MODE. FOR THESE TESTS THE + LEAD REFERS TO THE POSITIVE POTENTIAL. MAKE SURE YOU KNOW WHICH POLARITY YOU HAVE ON YOUR VOM.


Table 10. Diode Module Resistances

+	-	NORMAL READING (OHMS)	ABNORMAL READING (OHMS)	+	-	NORMAL READING (OHMS)	ABNORMAL READING (OHMS)
ON	ON			ON	ON		
L1	P	10 to 50	0 or INFINITE	L1	N	INFINITE	LESS THAN 1M
L2	P			L2	N		
L3	P			L3	N		
N	L1			P	L1		
N	L2			P	L2		
N	L3			P	L3		
				P	N	MAGNITUDE OF CAP CHARGE TO INFINITE	0 or INFINITE



Transistor Module Measure the resistance across the module terminals with a volt-ohm meter. Set the meter to the X1 range. The measured resistance should be within the values listed in Table 11.

RESISTANCE TEST FOR 3Ø TRANSISTOR MODULES



VOM RESISTANCE SCALE R x 1
 + IS THE POSITIVE POLARITY LEAD*
 - IS THE NEGATIVE POLARITY LEAD

*THE VOM RED LEAD IS NOT NECESSARILY THE POSITIVE POTENTIAL IN THE RESISTANCE MODE. FOR THESE TESTS THE + LEAD REFERS TO THE POSITIVE POTENTIAL. MAKE SURE YOU KNOW WHICH POLARITY YOU HAVE ON YOUR VOM.

**OR 0.3 TO 0.7 ON DIGITAL METER SET TO DIODE DROP SCALE.

Table 11. Transistor Module Resistances

+	-	NORMAL READING (OHMS)	ABNORMAL READING (OHMS)	+	-	NORMAL READING (OHMS)	ABNORMAL READING (OHMS)
ON	ON			ON	ON		
P+	T1	INFINITE	0	G1A	T1	INFINITE	LESS THAN 1M
P+	T2			G1B	T2		
P+	T3			G1C	T3		
T1	N-			G2A	N-		
T2	N-			G2B	N-		
T3	N-			G2C	N-		
T1	P+	5** to 50	0 or INFINITE	T1	G1A	INFINITE	LESS THAN 1M
T2	P+			T2	G1B		
T3	P+			T3	G1C		
N-	T1			N-	G2A		
N-	T2			N-	G2B		
N-	T3			N-	G2C		



Spare Parts List

Table 12. Spare Parts List - 230 Volt Drives

Description	Qty/Drive	Part Number
Transistor Module		
3HP	1	50207804
5HP	1	50207805
7.5HP	3	50207806
10HP	3	50207807
15HP	3	50207808
20HP	3	50207809
30HP	6	50207810
Diode Module		
3HP and 5HP	1	50207822
7.5HP	1	50207823
10HP	1	50207824
15HP	1	50173962
20HP and 30HP	3	50184816
Control Board		
3HP thru 30HP	1	50207937
50HP	1	50207918
Gate Driver Board		
3HP	1	50207943
5HP	1	50207944
7.5HP	1	50207945
10HP	1	50207946
15HP and 20HP	1	50207947
30HP	1	50207948
Power Supply Board		
3HP thru 10HP	1	50207964
Cooling Fan		
3HP thru 7.5HP	1	50207966
10HP thru 30HP	1	50207919
50HP	2	50207919
Fuse, DC Bus		
3HP	1	50184828
5HP	1	50184829
7.5HP and 10HP	1	50184830
15HP	1	50184831
Fuse		
20HP	1	50207974
Fuse, DC Bus		
30HP	1	50184859
50HP	1	50184890
AC MicroTrac Board		
3HP thru 50HP	1	46S03034-0010
AC MicroTrac Local Display		
3HP thru 50HP	1	46S03035-0010



Table 13. Spare Parts List - 460 Volt Drives

Description	Qty/Drive	Part Number
Transistor Module		
3HP	1	50207812
5HP	3	50207813
10HP	3	50207814
15HP	3	50207815
20HP	3	50207816
30HP	3	50207817
40HP and 60HP	6	50207818
75HP and 100HP	6	50207907
150HP	12	50207908
200HP	12	50207909
Diode Module		
3HP	1	50207825
5HP and 10HP	1	50207826
15HP	1	50184817
20HP	1	50207827
30HP	1	50184818
40HP and 60HP	3	50207828
75HP and 100HP	6	50207914
150HP	9	50207914
Main Diode Circuit		
200HP	6	50207915
Control Board		
3HP thru 40HP	1	50207937
60HP thru 200HP	1	50207918
Gate Driver Board		
3HP	1	50207952
5HP	1	50207953
10HP	1	50207954
15HP and 20HP	1	50207955
30HP	1	50207956
40HP	1	50207957
60HP	1	50207958
75HP	1	50207960
100HP	1	50207961
150HP	1	50207962
200HP	1	50207963
Power Supply Board		
3HP thru 10HP	1	50207965
Control Board		
300HP and 400HP	1	50207918



Table 13. Spare Parts List - 460 Volt Drives - Continued

Description	Qty/Drive	Part Number
Main Drive Board		
300HP	1	50207917
400HP	1	50207916
Sub Drive Board		
300HP	3	50207925
400HP	3	50207926
Main Diode Circuit		
300HP	6	50207915
400HP	9	50207915
Cooling Fan		
3HP thru 10HP	1	50207966
15HP and 20HP	1	50207967
30HP	1	50207919
40HP thru 200HP	2	50207919
Fan Unit		
300HP and 400HP	3	50207929
Fuse, DC Bus		
3HP	1	50207850
5HP and 10HP	1	50207851
Fuse		
15HP and 20HP	1	50207968
30HP and 40HP	1	50207969
60HP	1	50207970
75HP	1	50207971
100HP	1	50207972
150HP	1	50173998
200HP	1	50207973
AC MicroTrac Board		
3HP thru 400HP	1	46S03034-0010
AC MicroTrac Local Display		
3HP thru 400HP	1	46S03035-0010




VCM Motor/PG Connection

The vector control motor (VCM) windings must be connected to the VCD 723 as shown in the following table and illustration.

Table 14. Connection of VCM

CONNECTION	T1	T2	T3	CONNECT ALL TOGETHER
Parallel Star	T1 & T7	T2 & T8	T3 & T9	T4 - T5 - T6 - T10 - T11 - T12



The VCM contains two thermistors. Connect only one thermistor (VCM leads M1 & M11) to the VCD 723. The other thermistor (leads M2 & M22) is a spare.

Pulse Generator connections are shown in the following tables.

Table 15. TB1 - PG Connection

FUNCTION	TB1 TERMINAL	EPC MODEL 755A (1)	BEI MODEL E25
+12V (200mA)	1	White	Red
0V	2	Black	Black
A+	3	Red	Yellow
A-	4	Green	Wht/Yel
B+	5	Brown	Blue
B-	6	Yellow	Wht/Blue
SHIELD	7	Shield	Green

(1) For PG, EPC Model 755A (provided as standard), Orange and Blue wires are not used.


Table 16. Connectors on PG Card

CONNECTOR NO.	FUNCTION	TERMINAL ARRANGEMENT (2)	WIRE SIZE
CA1	For Pulse Generator		18 GA (0.75 mm ²)
CA2	For Pulse Monitor		18 GA (0.75 mm ²)

(2) Top view (from pin connections).



For VCM frame sizes 180 & 210, the blower motor should be connected as shown in the following illustration.



* Tied off (if shown paired) and insulated.



Motor Parameters

Parameter Calculation

This procedure must be performed if the motor to be used with the VCD 723 Drive is NOT a MagneTek VCM induction AC vector motor. This calculation is to be used for SPEED CONTROL MODE ONLY with tachometer feedback (PG). When the application requires torque control, motor parameters should be set and adjusted by using the tuning procedure.

Required Motor Data For Calculation

This information is usually located on the motor nameplate, except for the no-load current. If the motor manufacturer is unable to supply this information, use 30% for the dn-07 data value.

Motor Output (HP) :	HP
Motor Voltage (V) :	V_m
Motor Rated Speed (RPM):	N_R
Motor Base Speed (RPM):	N_S
No. of Poles:	pp
Full Load Amps (FLA):	I_{FLA}
No-Load Amps (NLA):	I_{NLA}

Calculation Method

dn-XX Calculation:

- (1) dn-01 Base Speed
dn-01 = See Table A
- (2) dn-02 Top Speed
 - (a) For constant torque applications
dn-02 = dn-01
 - (b) For constant HP applications
dn-02 = Top Speed (dn-02 \leq 2 • dn-01)
- (3) dn-03 No. of Poles
dn-03 = pp (See Table A)
- (4) dn-04 No-Load Voltage: V_{NL}
dn-04 = V_{NL} (See Table B)
- (5) dn-05 Torque producing current: IT
dn-05 = $\sqrt{(I_{FLA})^2 - (I_{NLA})^2}$



(6) dn-06 Slip Frequency: SF

$$dn-06 = \left(\frac{V_M}{V_{NL}} \right)^2 \left[\frac{N_S - N_R}{N_S} \right] \times 60$$

(7) dn-07 Magnetizing Current: IM

$$dn-07 = \frac{I_{NLA}}{dn-05} \times 100\%$$

(IM = 30% if no-load current not available)

(8) dn-08 thru dn-18 = Factory default values acceptable

(9) Cn-09 (PG Constant) = PPR of Tachometer (Pulses Per Revolutions)

Table A. Base Speed

fl	Poles	dn-01
60	4	1750 RPM
50	4	1450 RPM
60	6	1150 RPM
60	8	850 RPM

Table B. No-Load Voltage (V)

V _m	V _{NL}
230V	210V
460V	420V

(10) Optional Adjustments

On-02: 0110

Disable thermistor and rotor heat model

On-03: 1010

Disable overvoltage protection when Dynamic Braking Option is installed.



Sample Calculation

Motor Data

Motor Output:	HP = 15
Motor Voltage:	$V_M = 230V$
Motor Rated Speed:	$N_R = 1763 \text{ RPM}$
Motor Base Speed:	$N_S = 1800 \text{ RPM}$
No. of Poles:	$pp = 4$
Full Load Amps:	$I_{FLA} = 39.4 \text{ A}$
No-Load Amps:	$I_{NLA} = 12.0 \text{ A}$

Calculate dn-XX's

dn-01	$(N_R) = 1750$
dn-02	$(N_S) = 1750$
dn-03	$(pp) = 4$
dn-04	$(V_{NL}) = 210$

$$\begin{aligned} \text{dn-05} &= 38 & \text{dn-05} &= \sqrt{(I_{FLA})^2 - (I_{NLA})^2} \\ \text{dn-05} & & \text{dn-05} &= \sqrt{(39.4)^2 - (12)^2} \\ \text{dn-05} & & \text{dn-05} &= 37.5 \approx 38 \end{aligned}$$

$$\begin{aligned} \text{dn-06} &= 1.5 & \text{dn-06} &= \left(\frac{V_M}{V_{NL}}\right)^2 \left[\frac{N_S - N_R}{N_S} \times 60\right] \\ \text{dn-06} & & \text{dn-06} &= \left(\frac{230}{210}\right)^2 \left[\frac{1800 - 1763}{1800} \times 60\right] \\ \text{dn-06} & & \text{dn-06} &= 1.48 \approx 1.5 \end{aligned}$$

$$\begin{aligned} \text{dn-07} &= 31.6 & \text{dn-07} &= \frac{I_{NLA}}{\text{dn-05}} \times 100\% \\ \text{dn-07} & & \text{dn-07} &= \frac{12}{38} \times 100\% \\ \text{dn-07} & & \text{dn-07} &= 31.6\% \end{aligned}$$



Node, Channel and Subchannel Assignments

Every device in a MicroTrac system is identified with a Node number, a Channel number, and a Subchannel number, regardless of whether the device uses the Local Area Network or not. These identifiers have different significance for each device and some devices may not need all three fields to provide a unique identification. This appendix lists each device type relating to the VCD 723, and describes the significance of each field for that device.

VCD 723 Constants

CN-09 Settings

CN-09 sets the digital tach pulses per revolution. This is normally set for either 1024 or 2500 PPR depending upon the type of tach used on the motor.

DN-01 thru DN-18 Settings

DN-01 thru DN-18 set the motor constants per the following tables:

CONSTANT	DESCRIPTION	INITIAL VALUE	UNITS
Dn-01	MOTOR BASE SPEED	1750	RPM
Dn-02	MOTOR MAXIMUM SPEED	1750	RPM
Dn-03	NUMBER OF MOTOR POLES	4	~
Dn-04	MOTOR NO LOAD VOLTAGE	PER TABLE	VAC
Dn-05	MOTOR RATED PRIMARY CURRENT	PER TABLE	AAC
Dn-06	RATED SLIP FREQUENCY	PER TABLE	HZ
Dn-07	EXCITATION CURRENT REFERENCE	PER TABLE	%
Dn-08	PRIMARY RESISTANCE, USED WITH OPT TRQ BOARD	PER TABLE	%
Dn-09	LEAKAGE COEFFICIENT, USED WITH OPT TRQ BOARD	PER TABLE	%
Dn-10	MOTOR IRON LOSS	PER TABLE	%
Dn-11	MOTOR MACHINERY LOSS	PER TABLE	%
Dn-12	SECONDARY CIRCUIT TIME CONSTANT	PER TABLE	MSEC
Dn-13	LEAKAGE SAT COEF, USED WITH OPT TRQ BOARD	1.20	~
Dn-14	ROTOR HEAT GAIN	0.00	~
Dn-15	ROTOR HEAT TIME CONSTANT	30	MIN
Dn-16	IRON CORE SATURATION COMP COEFFICIENT 1	0.5	~
Dn-17	IRON CORE SATURATION COMP COEFFICIENT 2	0.75	~
Dn-18	MOTOR OVERHEAT TEMPERATURE	155	°C



DN-01 Thru DN-18 Motor Setting Constants

RTD MTR VAC	VCM MODEL NO.	HP	Dn-04	Dn-05	Dn-06	Dn-07	Dn-08	Dn-09	Dn-10	Dn-11	Dn-12	
190	VMA003	3	175	8.03	1.57	51.6	5.1	8.77	6.7	0.4	138	
	VMA005	5	175	13.34	1.37	56.1	4.0	8.39	6.6	0.3	140	
	VMA7P5	7.5	175	19.94	1.83	37.4	3.3	8.05	3.4	0.6	143	
	VMA010	10	175	26.24	1.67	33.5	2.7	6.62	3.2	0.7	171	
	VMA015	15	175	39.07	1.33	28.4	3.3	5.84	1.4	1.0	212	
	VMA020	20	175	52.11	1.17	24.7	2.9	5.86	1.4	0.8	268	
	VMA025	25	180	63.32	1.03	29.1	2.1	5.84	1.5	1.0	264	
	VMA030	30	180	75.61	1.13	27.2	1.9	5.32	1.3	0.8	255	
	VMA040	40	175	108.0	0.67	34.6	1.5	9.68	1.3	1.0	154	
VMA050	50	175	133.7	0.67	30.9	1.4	8.63	1.2	0.8	165		
230	VMA003	3	210	6.80	1.37	61.0	4.7	9.86	7.4	0.4	116	
	VMA005	5	215	11.00	1.23	71.2	3.6	9.86	7.6	0.3	118	
	VMA7P5	7.5	215	16.26	1.67	44.2	3.0	8.21	3.9	0.6	135	
	VMA010	10	215	21.45	1.20	39.8	2.4	7.05	3.7	0.7	162	
	VMA015	15	215	31.92	1.20	34.1	2.9	6.23	1.6	1.0	176	
	VMA020	20	215	42.55	1.07	29.3	2.5	6.20	1.5	0.8	247	
	VMA025	25	215	53.16	0.93	33.1	1.9	6.21	1.6	1.0	240	
	VMA030	30	215	63.54	1.00	30.5	1.8	5.73	1.4	0.8	263	
	VMA040	40	215	85.36	0.60	28.1	1.3	6.52	1.6	1.0	230	
VMA050	50	215	109.04	0.60	36.7	1.2	8.90	1.4	0.8	163		
380	VMB003	3	350	4.02	1.57	51.6	5.1	8.77	6.7	0.4	139	
	VMB005	5	355	6.58	1.37	57.7	3.9	8.39	6.7	0.3	140	
	VMB7P5	7.5	350	9.97	1.83	37.4	3.3	8.05	3.4	0.6	143	
	VMB010	10	355	12.94	1.67	34.5	2.7	6.62	3.3	0.7	171	
	VMB015	15	350	19.54	1.33	28.4	3.3	5.84	1.4	1.0	212	
	VMB020	20	355	25.69	1.17	25.4	2.8	5.86	1.4	0.8	268	
	VMB025	25	360	31.66	1.03	29.1	2.1	5.84	1.5	1.0	264	
	VMB030	30	360	37.80	1.13	27.2	1.9	5.32	1.3	0.8	255	
	VMB040	40	355	53.23	0.67	35.6	1.4	9.68	1.3	1.0	154	
	VMB050	50	355	65.90	0.67	31.8	1.3	8.63	1.3	0.8	165	
	VMB060	60	360	75.16	0.80	26.0	1.3	4.70	1.2	1.2	309	
	VMB075	75	Consult MagneTek									
	VMB100	100										
	VMB150	150										
VMB200	200											
VMB300	300											
VMB400	400											
460	VMB003	3	425	3.34	1.37	62.5	4.6	9.86	7.6	0.4	116	
	VMB005	5	430	5.50	1.23	71.2	3.6	9.86	7.6	0.3	118	
	VMB7P5	7.5	425	8.25	1.67	43.1	3.0	8.49	3.8	0.6	135	
	VMB010	10	430	10.72	1.20	40.0	2.4	7.05	3.7	0.7	162	
	VMB015	15	425	16.15	1.20	33.3	3.0	6.23	1.6	1.0	176	
	VMB020	20	430	21.28	1.07	29.3	2.5	6.20	1.5	0.8	247	
	VMB025	25	435	26.29	0.93	33.9	1.9	6.21	1.7	1.0	240	
	VMB030	30	435	31.41	1.00	31.2	1.7	5.73	1.5	0.8	263	
	VMB040	40	435	42.19	0.60	28.8	1.2	6.52	1.6	1.0	230	
	VMB050	50	435	53.89	0.60	37.6	1.2	8.86	1.4	0.8	163	
	VMB060	60	440	61.60	0.73	30.2	1.2	4.88	1.3	1.2	271	
	VMB075	75	Consult MagneTek									
	VMB100	100										
	VMB150	150										
VMB200	200											
VMB300	300											
VMB400	400											



ON-01 Setting

ON-01 is factory set for 0000 and should not be changed. This enables the inverter fault circuit which detects tach connection.

ON-02 Setting

ON-02 is factory set for 0010. This determines whether the inverter utilizes the motor thermistor or not:

- 0000 = Control with thermistor
- 0010 = Control without thermistor

SN-01 Settings

SN-01 sets the capacity of the VCD 723 per the following table. SN-01 can be set either by using a numo block to write the decimal value to [260-101-0] or by using the geth block to write the hex value to [723-101-~]. If SN-09 is set for low noise operation, the values shown for continuous current must be reduced by 20%. SN-01 automatically determines the setting of CN-19.

RATED INPUT VAC	VCD MODEL NO.	HP	Sn-01 HEX	Sn-01 DEC	CONTINUOUS RATED CURRENT	POWER LOSS RIDE THRU TIME (CN-19)
230	VCD 723-A003	3	03	03	9.6	1.00
	VCD 723-A005	5	04	04	16	2.00
	VCD 723-A7P5	7.5	05	05	24	2.00
	VCD 723-A010	10	06	06	32	2.00
	VCD 723-A015	15	07	07	48	2.00
	VCD 723-A020	20	08	08	64	2.00
	VCD 723-A030	30	0A	10	96	2.00
	VCD 723-A050	50	0C	12	160	2.00
460	VCD 723-B003	3	23	35	4.8	1.00
	VCD 723-B005	5	24	36	8	2.00
	VCD 723-B010	10	26	38	16	2.00
	VCD 723-B015	15	27	39	24	2.00
	VCD 723-B020	20	28	40	32	2.00
	VCD 723-B030	30	2A	42	48	2.00
	VCD 723-B040	40	2B	43	64	2.00
	VCD 723-B060	60	2D	45	76.8	2.00
	VCD 723-B075	75	2E	46	128	2.00
	VCD 723-B100	100	2F	47	165	2.00
	VCD 723-B150	150	31	49	224	2.00
	VCD 723-B200	200	33	51	300	2.00
	VCD 723-B300	300	35	53	450	2.00
	VCD 723-B400	400	36	54	600	2.00

SN-02 Setting

SN-02 is factory set for “FFF” hex (4095 DEC) and should not be changed. This determines that the DN-XX constants are used to define the motor rather than the VCD 723 factory preset values.

SN-09 Settings

SN-09 is set to match the input voltage and the inverter carrier frequency as follows:

SN-09	230/460 VAC	200/400 VAC	LOW CARRIER FREQUENCY	HIGH CARRIER FREQUENCY
0000	X		X	
0001		X	X	
1000	X			X
1001		X		X

If set for high carrier frequency (low noise operation), the continuous current rating of the VCD 723 is reduced by 20%. The VCD 723 overload curve is automatically changed.

SN-12 Settings

SN-12 determines the reaction of the drive to the status of the contact connected to terminal 3 of the VCD 723. Terminal 3 is always the external fault input and normally would be used as an E-stop input. In the following table, “N.O.” means the contact closes on a fault:

SN-12	N.O. CONTACT	N.C. CONTACT
0100	X	
0101		X

SN-15, 16, 17 & 18 Settings

SN-15 thru SN-18 are set to 15 decimal (of hex). This determines that the logic input terminals 5 thru 8 are read by the DCU only. In other words, they have no direct effect on the inverter.

SN-20, 21, 22, 23 & 24 Settings

SN-20 thru SN-24 are set to 15 decimal (of hex). This configures the normally open relay contact (terminals 9 & 10) and the four open collector outputs (terminals 25, 26, 28 & 29) for control by the DCU.

SN-30 Settings

SN-30 is set for 0100 and should not be changed. This configures the VCD 723 for the torque control mode rather than the speed control mode.



Node 260 (Dual Port Ram) Assignments

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
0	~	NUMO	TORQUE REFERENCE. RANGE IS 0 TO +/- 1.0
1	0	LOGO	RUN
1	1	LOGO	REVERSE
1	2	LOGO	BASEBLOCK ON
1	3	LOGO	NOT USED
1	4	LOGO	EXTERNAL ERROR (CONTROLLED BY SN-31)
1	5	LOGO	RESET FAULTS
1	6	LOGO	USE ACCEL/DECEL TIME 2
1	7	LOGO	ACCEL/DECEL PROHIBITED (SPEED HOLD)
2	0	LOGO	APPLY INITIAL CURRENT TO MOTOR
2	1	LOGO	RESET INTEGRAL CHANNEL OF AUTOMATIC SPEED REGULATOR (ASR)
2	2	LOGO	NOT USED
2	3	LOGO	ACCEL/DECEL CONTROL INACTIVE (ALLOW STEP CHANGES)
2	4	LOGO	CONTROLS RELAY CONTACT LOGIC OUTPUT (TERM 9&10)
2	5	LOGO	CONTROLS OPEN COLLECTOR LOGIC OUTPUT (TERM 25)
2	6	LOGO	CONTROLS OPEN COLLECTOR LOGIC OUTPUT (TERM 26)
2	7	LOGO	CONTROLS OPEN COLLECTOR LOGIC OUTPUT (TERM 28)
3	~	NUMO	SPEED REFERENCE TO ASR (RANGE IS 0 TO +/- 1.0922)
4	~	NUMO	TORQUE COMPENSATION TO BE ADDED TO THE OUTPUT OF THE ASR
5	~	NUMO	EXTERNAL MAGNETIC FLUX REFERENCE
6	~	NUMO	ASR PROPORTIONAL GAIN. USED ONLY IF BIT 1 OF SN-30 IS SET TO 1
7	~	NUMO	REGENERATIVE TORQUE LIMIT. ACCEPTABLE RANGE IS 0 TO 3.0
8	0	LOGO	SELECTS MICROTRAC TO CONTROL ANALOG OUTPUT (TERM 21 & 22)
8	1	LOGO	SELECTS MICROTRAC TO CONTROL AO-08 OPTIONAL CH-1 OUTPUT
8	2	LOGO	SELECTS MICROTRAC TO CONTROL AO-08 OPTIONAL CH-2 OUTPUT
8	3	LOGO	SELECTS MICROTRAC TO CONTROL AO-12 OPTIONAL CH-1 OUTPUT
8	4	LOGO	SELECTS MICROTRAC TO CONTROL AO-12 OPTIONAL CH-2 OUTPUT
8	5	LOGO	SELECTS MICROTRAC TO CONTROL DO-08 OPTIONAL DIGITAL OUTPUTS
8	6	LOGO	NOT USED
8	7	LOGO	NOT USED
9	0	LOGO	NOT USED
9	1	LOGO	NOT USED
9	2	LOGO	NOT USED
9	3	LOGO	NOT USED
9	4	LOGO	NOT USED
9	5	LOGO	NOT USED
9	6	LOGO	NOT USED
9	7	LOGO	CONTROLS OPEN COLLECTOR LOGIC OUTPUT (TERM 29)
10	~	NUMO	CONTROLS ANALOG OUTPUT (TERM 21&22). 1 = +11.0 VDC, -1 = -11.0 VDC



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
11	0	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 0
11	1	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 1
11	2	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 2
11	3	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 3
11	4	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 4
11	5	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 5
11	6	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 6
11	7	LOGO	CONTROLS DO-08 LOGIC OUTPUT BIT 7
12	~	NUMO	CONTROLS AO-08 ANALOG OUTPUT CH 1. +1 = +11 VDC
13	~	NUMO	CONTROLS AO-08 ANALOG OUTPUT CH 2. +1 = +11 VDC
14	~	NUMO	CONTROLS AO-12 ANALOG OUTPUT CH 1. +1 = +11 VDC, -1 = -11 VDC
15	~	NUMO	CONTROLS AO-12 ANALOG OUTPUT CH 2. +1 = +11 VDC, -1 = -11 VDC
50	0	LOGI	DRIVE RUNNING
50	1	LOGI	AT ZERO SPEED
50	2	LOGI	REVERSE OPERATION
50	3	LOGI	FAULT RESET HAS BEEN INPUTTED
50	4	LOGI	SPEED COINCIDENCE AS SET BY Cn-02 AND Cn-03 DETECTED
50	5	LOGI	INVERTER READY
50	6	LOGI	A MINOR FAULT HAS OCCURRED
50	7	LOGI	A MAJOR FAULT HAS OCCURRED
51	0	LOGI	SPEED REF FROM DCU NOT WITHIN ACCEPTABLE RANGE
51	1	LOGI	LAST POWER LOSS/MOMENTARY STOP NOT WITHIN RIDE THROUGH RANGE
51	2	LOGI	REMOTE OPERATION (INVERTER RECOGNIZES THAT MICROTRAC IS IN CONTROL)
51	3	LOGI	NOT USED
51	4	LOGI	NOT USED
51	5	LOGI	NOT USED
51	6	LOGI	NOT USED
51	7	LOGI	NOT USED
52	0	LOGI	OVERCURRENT (OR GROUNDING) DETECTED ALARM
52	1	LOGI	DC BUS OVERVOLTAGE TRIP ALARM
52	2	LOGI	INVERTER OVERLOADED ALARM
52	3	LOGI	INVERTER OR BRAKING RESISTOR OVERHEATED OR BRAKING TRANSISTOR FAULT
52	4	LOGI	OVERSPEED FAULT DETECTED ALARM
52	5	LOGI	BLOWN FUSE ALARM
52	6	LOGI	LOAD OPEN PHASE ALARM
52	7	LOGI	EXTERNAL ERROR ALARM



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
53	0	LOGI	HARDWARE ERROR DETECTED (RAM CHECK OR BASEBLOCK CHECK) ALARM
53	1	LOGI	MOTOR OVERLOAD ALARM
53	2	LOGI	MOTOR OVERTEMPERATURE ALARM
53	3	LOGI	IN MOMENTARY STOP (MOMENTARY STOP IS A POWER LOSS OF LESS THAN 2 SEC) ALARM
53	4	LOGI	POWER FAILURE DETECTED (EITHER MAIN OR CONTROL POWER OR MC CONT. OFF) ALARM
53	5	LOGI	OVERSPEED DEVIATION (INCLUDING STARTING STALL) ALARM
53	6	LOGI	TACH OR THERMISTOR CABLE DISCONNECTED ALARM
53	7	LOGI	COOLING FAN FAULT ALARM
54	~	NUMI	SPEED REFERENCE (RANGE IS 0 TO +/- 1.0922)
55	~	NUMI	PRIMARY FREQUENCY REFERENCE (RANGE IS 0 TO +/- 1.0922)
56	~	NUMI	SPEED FEEDBACK (RANGE IS 0 TO +/- 1.0922). FILTERING SET BY Sn-34.
57	~	NUMI	TORQUE REFERENCE (RANGE IS 0 TO +/- 1.0)
58	~	NUMI	OUTPUT CURRENT (RANGE IS 0 TO +3.276)
59	~	NUMI	OUTPUT VOLTAGE REFERENCE (RANGE IS 0 TO +3.276)
60	~	NUMI	ANALOG INPUT (PIN 13 OR 14). +10 VDC OR 20 MA = 1
61	~	NUMI	ANALOG INPUT (PIN 16). +10 VDC = 1
62	0	LOGI	INVERTER MAIN BOARD TERMINAL 1
62	1	LOGI	INVERTER MAIN BOARD TERMINAL 2
62	2	LOGI	INVERTER MAIN BOARD TERMINAL 3 (DEDICATED TO THE FUNCTION OF EXTERNAL FAULT). Sn-12 DETERMINES WHETHER INPUT IS NORMALLY OPEN OR CLOSED.
62	3	LOGI	INVERTER MAIN BOARD TERMINAL 4
62	4	LOGI	INVERTER MAIN BOARD TERMINAL 5
62	5	LOGI	INVERTER MAIN BOARD TERMINAL 6
62	6	LOGI	INVERTER MAIN BOARD TERMINAL 7
62	7	LOGI	INVERTER MAIN BOARD TERMINAL 8
63	~	NUMI	KVA CONSTANT (CONFIRMATION OF SN-01 SETTING)
64	0	LOGI	INVERTER OPTIONAL CARD A CONNECTED (SPEED FEEDBACK OPTION)
64	1	LOGI	INVERTER OPTIONAL CARD B CONNECTED (EXCLUSIVE USE OPTION)
64	2	LOGI	INVERTER OPTIONAL CARD C CONNECTED (REFERENCE, TRANSMISSION OPTIONS)
64	3	LOGI	INVERTER OPTIONAL CARD D CONNECTED (MONITOR OPTION)
64	4	LOGI	PERSONAL COMPUTER CONNECTED
64	5	LOGI	1=575 VOLT SYSTEM. 0=230/460 VOLT SYSTEM
64	6	LOGI	1=460 VOLT SYSTEM. 0=230 VOLT SYSTEM
64	7	LOGI	1=BI-POLAR TRANSISTOR DEVICES. 0=IGBT DEVICES
65	~	NUMI	OPTION A MODEL CODE



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
66	~	NUMI	OPTION B MODEL CODE
67	~	NUMI	OPTION C MODEL CODE
68	~	NUMI	OPTION D MODEL CODE
69	~	NUMI	DC BUS VOLTAGE (FOR A 460 VAC SYSTEM, 1 PU = 800 VOLTS)
70	~	NUMI	MOMENTARY LOWERING VOLTAGE DEPTH VALUE
71	0	LOGI	MAIN POWER UNDERVOLTAGE FAULT
71	1	LOGI	CONTROL POWER UNDERVOLTAGE FAULT
71	2	LOGI	MC CONTACTOR OFF
71	3	LOGI	BRAKING TRANSISTOR FAULT
71	4	LOGI	BRAKING RESISTOR OVERHEAT FAULT
71	5	LOGI	NOT USED
71	6	LOGI	THERMISTOR OPEN FAULT
71	7	LOGI	CP-213 TRANSMISSION ERROR FAULT
72	0	LOGI	NOT USED
72	1	LOGI	NOT USED
72	2	LOGI	EXTERNAL FAULT (TRANSMISSION INPUT)
72	3	LOGI	EXTERNAL FAULT (TERMINAL #3)
72	4	LOGI	EXTERNAL FAULT (TERMINAL #5)
72	5	LOGI	EXTERNAL FAULT (TERMINAL #6)
72	6	LOGI	EXTERNAL FAULT (TERMINAL #7)
72	7	LOGI	EXTERNAL FAULT (TERMINAL #8)
73	0	LOGI	PULSE GENERATOR LEADS OPEN FAULT
73	1	LOGI	OVERSPEED FAULT
73	2	LOGI	ESTIMATED SPEED ERROR FAULT
73	3	LOGI	NOT USED
73	4	LOGI	NOT USED
73	5	LOGI	NOT USED
73	6	LOGI	NOT USED
73	7	LOGI	NOT USED
75	0	LOGI	NOT USED
75	1	LOGI	BASE BLOCK CIRCUIT FAULT
75	2	LOGI	NVRAM OR SRAM FAULT
75	3	LOGI	NVRAM BCC ERROR FAULT
75	4	LOGI	MCU A/D CONVERTER FAULT
75	5	LOGI	FAULTY CONNECTION OF OPTION CONNECTOR
75	6	LOGI	NOT USED
75	7	LOGI	NOT USED
76	0	LOGI	NOT USED
76	1	LOGI	DSP PERIPHERAL FAULT



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
76	2	LOGI	OPTION CARD A/D CONVERTER FAULT
76	3	LOGI	TRANSMISSION OPTIONAL CARD FAULT
76	4	LOGI	INVERTER MODEL CODE ERROR
76	5	LOGI	MCU MUTUAL DIAGNOSIS FAULT
76	6	LOGI	TORQUE CONTROL CARD A/D ERROR
76	7	LOGI	NOT USED
78	0	LOGI	UNDERVOLTAGE DETECTION ALARM
78	1	LOGI	OVERVOLTAGE DURING STOPPING ALARM
78	2	LOGI	MOTOR OVERLOAD ALARM
78	3	LOGI	INVERTER OVERLOAD ALARM
78	4	LOGI	NOT USED
78	5	LOGI	COOLING FAN FAULT ALARM
78	6	LOGI	INVERTER OVERHEAT PREDICTION ALARM
78	7	LOGI	LOAD CIRCUIT FAULT ALARM
79	0	LOGI	NOT USED
79	1	LOGI	OPERATION SEQUENCE INPUT ALARM (2-WIRE)
79	2	LOGI	EXTERNAL FAULT (TRANSMISSION OPTION)
79	3	LOGI	EXTERNAL FAULT (TERMINAL 3)
79	4	LOGI	EXTERNAL FAULT (TERMINAL 5)
79	5	LOGI	EXTERNAL FAULT (TERMINAL 6)
79	6	LOGI	EXTERNAL FAULT (TERMINAL 7)
79	7	LOGI	EXTERNAL FAULT (TERMINAL 8)
80	0	LOGI	BUS TRANSMISSION FAULT (CP-213)
80	1	LOGI	NOT USED
80	2	LOGI	NOT USED
80	3	LOGI	EXCESSIVE SPEED DEVIATION
80	4	LOGI	NOT USED
80	5	LOGI	NOT USED
80	6	LOGI	NOT USED
80	7	LOGI	NOT USED
81	~	NUMI	INVERTER ROM NUMBER
82	~	NUMI	OPTIONAL ROM NUMBER
83	~	NUMI	TORQUE FEEDBACK
84	~	NUMI	SPEED DETECTION COUNTER VALUE
85	~	NUMI	TRACE SAMPLING TIME



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION	INITIAL VALUE
101	~	NUMO	S _n -01 KVA SELECT	
102	~	NUMO	S _n -02 (SELECTS PRE PROGRAMMED PATTERNS OF C _n CONSTANTS)	
103	00-03	LOGO	BITS 0-3 SET S _n -03	0000
103	04-07	LOGO	BITS 4-7 SET S _n -04	0011
105	00-03	LOGO	BITS 0-3 SET S _n -05	0001
105	04-07	LOGO	BITS 4-7 SET S _n -06	0000
107	00-03	LOGO	BITS 0-3 SET S _n -07	0000
107	04-07	LOGO	BITS 4-7 SET S _n -08	0000
109	00-03	LOGO	BITS 0-3 SET S _n -09	0000
109	04-07	LOGO	BITS 4-7 SET S _n -10	0111
111	00-03	LOGO	BITS 0-3 SET S _n -11	0000
111	04-07	LOGO	BITS 4-7 SET S _n -12	0100
113	00-03	LOGO	BITS 0-3 SET S _n -13	0101
113	04-07	LOGO	BITS 4-7 SET S _n -14	1101
115	~	NUMO	S _n -15 (SELECTS FUNCTION TO BE PERFORMED BY INPUT NO. 5)	03
116	~	NUMO	S _n -16 (SELECTS FUNCTION TO BE PERFORMED BY INPUT NO. 6)	04
117	~	NUMO	S _n -17 (SELECTS FUNCTION TO BE PERFORMED BY INPUT NO. 7)	06
118	~	NUMO	S _n -18 (SELECTS FUNCTION TO BE PERFORMED BY INPUT NO. 8)	08
119	~	NUMO	S _n -19 (SELECTS FUNCTION FOR ANALOG INPUT TERMINAL 16)	00
120	~	NUMO	S _n -20 (SELECTS FUNCTION FOR OUTPUT NO. 1)	00
121	~	NUMO	S _n -21 (SELECTS FUNCTION FOR OUTPUT NO. 2)	01
122	~	NUMO	S _n -22 (SELECTS FUNCTION FOR OUTPUT NO. 3)	02
123	~	NUMO	S _n -23 (SELECTS FUNCTION FOR OUTPUT NO. 4)	06
124	~	NUMO	S _n -24 (SELECTS FUNCTION FOR OUTPUT NO. 5)	0D
127	00-03	LOGO	BITS 0-3 SET S _n -27	0000
127	04-07	LOGO	BITS 4-7 SET S _n -28	0000
130	00-03	LOGO	BITS 0-3 SET S _n -30	0000
130	04-07	LOGO	BITS 4-7 SET S _n -31	0100
132	00-03	LOGO	BITS 0-3 SET S _n -32	0001
132	04-07	LOGO	BITS 4-7 SET S _n -33 WHICH IS NOT USED WITH MICROTRAC	0000
134	00-03	LOGO	BITS 0-3 SET S _n -34	0001
134	04-07	LOGO	BITS 4-7 SET S _n -35 WHICH IS NOT USED WITH MICROTRAC	0000



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION	INITIAL VALUE	UNITS
201	~	NUMO	Cn-01 (ZERO SPEED LEVEL)	2.00	%
202	~	NUMO	Cn-02 (SPEED COINCIDENCE LEVEL)	100	%
203	~	NUMO	Cn-03 (SPEED COINCIDENCE DEADBAND)	2.00	%
204	~	NUMO	Cn-04 (SPEED DEVIATION)	10.00	%
205	~	NUMO	Cn-05 (SPEED REFERENCE INPUT LIMIT)	109.00	%
206	~	NUMO	Cn-06 (MINIMUM SPEED LIMIT)	2.00	%
207	~	NUMO	Cn-07 (ASR FILTER #1)	4	MSEC
208	~	NUMO	Cn-08 (EXCITATION TIMER?)	0.0	SEC
209	~	NUMO	Cn-09 (PULSE GENERATOR CONSTANT)	600	PPR
210	~	NUMO	Cn-10 (SPEED LIMIT BIAS)	20.00 ◆	%
211	~	NUMO	Cn-11 (EMERGENCY TORQUE COMPENSATION?)	0.0	%
212	~	NUMO	Cn-12 (NOT USED)		
213	~	NUMO	Cn-13 (FEEDER RESISTANCE, i.e. LINE IMPEDANCE)	0.0	%
214	~	NUMO	Cn-14 (MOTOR OVERLOAD DETECTION STARTING CURRENT)	110	%
215	~	NUMO	Cn-15 (MOTOR OVERLOAD OPERATION TIME)	60	SEC
216	~	NUMO	Cn-16 (OVERSPEED DETECTION LEVEL)	120	%
217	~	NUMO	Cn-17 (PUV DETECTION LEVEL)	210/430	VAC
218	~	NUMO	Cn-18 (DISCONNECTED TACH CABLE DETECTION TIME)	1.00	SEC
219	~	NUMO	Cn-19 (MOMENTARY POWER LOSS RIDE THROUGH TIME)	1.00 ■	SEC
220	~	NUMO	Cn-20 (NUMBER OF AUTO RESTART ATTEMPTS)	0	~
221	~	NUMO	Cn-21 (STOP TIMER)	0.0	SEC
222	~	NUMO	Cn-22 (ASR PROPORTIONAL GAIN 2)	20	~
223	~	NUMO	Cn-23 (ASR PROPORTIONAL GAIN SELECTION LEVEL)	0.00	%
224	~	NUMO	Cn-24 (ZERO SERVO GAIN)	5	~
225	~	NUMO	Cn-25 (ZERO SERVO COMPLETION WIDTH)	10	PULSE
226	~	NUMO	Cn-26 (S-CURVE TIME 2)	0.0	SEC
227	~	NUMO	Cn-27 (TORQUE REFERENCE FILTER)	0	MSEC
228	~	NUMO	Cn-28 (MOTOR TEMP RISE DETECTION LEVEL)	80	°C
229	~	NUMO	Cn-29 (MOTOR TEMPERATURE?)	0	~
233	~	NUMO	Cn-33 (TORQUE DETECTION LEVEL 1)	100	%
234	~	NUMO	Cn-34 (TORQUE DETECTION LEVEL 2)	100	%

◆ -Initial value dependent on setting of Sn-02. Value shown is for Sn-02 setting of 0F hex.

■ -Initial value dependent on setting of Sn-01.



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION	INITIAL VALUE	UNITS
301	00-03	LOGO	BITS 0-3 SET On-01	0000	
301	04-07	LOGO	BITS 4-7 SET On-02	0000	
303	00-03	LOGO	BITS 0-3 SET On-03	1010	
303	04-07	LOGO	BITS 4-7 SET On-04	0000	
305	~	NUMO	On-05 (INVERTER LOW FREQUENCY OL GAIN)	■	
306	~	NUMO	On-06 (INVERTER LOW FREQUENCY OL FREQUENCY)	■	
307	~	NUMO	On-07 (REGEN TORQUE LIMIT AT LOW FREQUENCY)	50.00	%
308	~	NUMO	On-08 (CURRENT AMPLIFIER CHARACTERISTIC NO. 1)	020	~
309	~	NUMO	On-09 (ASR OUTPUT FILTER NO. 2)	0	MSEC
310	~	NUMO	On-10 (CEMF COMPENSATION)	1.000	NONE
311	~	NUMO	On-11 (A-phi-R TIME CONSTANT, USED WITH TRQ OPTION PCB)	◆	MSEC
312	~	NUMO	On-12 (AFR GAIN)	1.00	NONE
313	~	NUMO	On-13 (AFR TIME CONSTANT)	120	MSEC
314	~	NUMO	On-14 (FLUX FDBK GAIN, USED WITH TRQ OPTION BOARD)	1.000	NONE
315	~	NUMO	On-15 (CURRENT FDBK GAIN, USED WITH TRQ OPTION PCB)	1.000	NONE
316	~	NUMO	On-16 (NVRAM SOFT NUMBER)		NONE
317	~	NUMO	On-17 (DSP A/D CONVERTER U PHASE GAIN)		NONE
318	~	NUMO	On-18 (DSP A/D CONVERTER U PHASE OFFSET)		NONE
319	~	NUMO	On-19 (DSP A/D CONVERTER W PHASE GAIN)		NONE
320	~	NUMO	On-20 (DSP A/D CONVERTER W PHASE OFFSET)		NONE
321	~	NUMO	On-21 (ON DELAY COMPENSATED GAIN)	1.00	NONE
322	~	NUMO	On-22 (A/D OFFSET ADJUST)	0.000	VLTS
401	~	NUMO	An-01 (SPEED REFERENCE 1, MAIN SPEED REFERENCE)	0.00	%
402	~	NUMO	An-02 (SPEED REFERENCE 2, MULTI-STEP SPEED)	0.00	%
403	~	NUMO	An-03 (SPEED REFERENCE 3, MULTI-STEP SPEED)	0.00	%
404	~	NUMO	An-04 (SPEED REFERENCE 4, MULTI-STEP SPEED)	0.00	%
405	~	NUMO	An-05 (SPEED REFERENCE 5, MULTI-STEP SPEED)	0.00	%
406	~	NUMO	An-06 (SPEED REFERENCE 6, MULTI-STEP SPEED)	0.00	%
407	~	NUMO	An-07 (SPEED REFERENCE 7, MULTI-STEP SPEED)	0.00	%
408	~	NUMO	An-08 (SPEED REFERENCE 8, MULTI-STEP SPEED)	0.00	%
409	~	NUMO	An-09 (JOGGING SPEED REFERENCE)	10.00	%

◆ -Initial value dependent on setting of Sn-02. Value shown is for Sn-02 setting of 0F hex.

■ -Initial value dependent on setting of Sn-01.



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION	INITIAL VALUE	UNITS
501	~	NUMO	Bn-01 (ACCELERATION TIME 1)	10.0	SEC
502	~	NUMO	Bn-02 (DECELERATION TIME 1)	10.0	SEC
503	~	NUMO	Bn-03 (ACCELERATION TIME 2)	10.0	SEC
504	~	NUMO	Bn-04 (DECELERATION TIME 2)	10.0	SEC
505	~	NUMO	Bn-05 (ASR PROPORTIONAL GAIN)	20	~
506	~	NUMO	Bn-06 (ASR INTEGRAL TIME)	1000	MSEC
507	~	NUMO	Bn-07 (FORWARD TORQUE LIMIT)	150.00	%
508	~	NUMO	Bn-08 (REVERSE TORQUE LIMIT)	150.00	%
509	~	NUMO	Bn-09 (REGENERATIVE TORQUE LIMIT)	150.00	%
510	~	NUMO	Bn-10 (RATED SPEED ADJUSTMENT)	1.0000	~
511	~	NUMO	Bn-11 (TRACE SAMPLING TIME)	0.060	SEC
512	~	NUMO	Bn-12 (EMERGENCY STOP TIME)	10.0	SEC
513	~	NUMO	Bn-13 (MONITOR NUMBER AFTER TURNING ON PWR SUPPLY)	1	~
514	~	NUMO	Bn-14 (PULSE GENERATOR DIVISION RATIO)	1	~
515	~	NUMO	Bn-15 (SPEED 0 ADJUSTMENT)	0.00	%
516	~	NUMO	Bn-16 (VOLTAGE ADJUSTMENT)	1.000	~
517	~	NUMO	Bn-17 (MULTI FUNCTION MOTOR OUTPUT SELECT)	23	~
518	~	NUMO	Bn-18 (MULTI FUNCTION MOTOR OUTPUT GAIN)	100	%
519	~	NUMO	Bn-19 (S CURVE TIME)	0	SEC
522	~	NUMO	Bn-22 (AO OPTIONAL CH1 OUTPUT SELECT)	22	~
523	~	NUMO	Bn-23 (AO OPTIONAL CH1 OUTPUT GAIN)	100.0	~
524	~	NUMO	Bn-24 (AO OPTIONAL CH2 OUTPUT SELECT)	23	~
525	~	NUMO	Bn-25 (AO OPTIONAL CH2 OUTPUT GAIN)	100.0	~



Node 260 (Dual Port Ram) Assignments - Continued

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION	INITIAL VALUE	UNITS
601	~	NUMO	Dn-01 (MOTOR BASE SPEED)	1750	RPM
602	~	NUMO	Dn-02 (MOTOR MAXIMUM SPEED)	1750	RPM
603	~	NUMO	Dn-03 (NUMBER OF MOTOR POLES)	4	~
604	~	NUMO	Dn-04 (MOTOR NO LOAD VOLTAGE)	170/340	VAC
605	~	NUMO	Dn-05 (MOTOR RATED PRIMARY CURRENT)		AAC
606	~	NUMO	Dn-06 (RATED SLIP FREQUENCY)	1.00	HZ
607	~	NUMO	Dn-07 (EXCITATION CURRENT REFERENCE)	30.0	%
608	~	NUMO	Dn-08 (PRIMARY RESISTANCE, USED WITH OPT TRQ BOARD)	2.0	%
609	~	NUMO	Dn-09 (LEAKAGE COEFFICIENT, USED WITH OPT TRQ BOARD)	20.00	%
610	~	NUMO	Dn-10 (MOTOR IRON LOSS)	2.0	%
611	~	NUMO	Dn-11 (MOTOR MACHINERY LOSS)	0.5	%
612	~	NUMO	Dn-12 (SECONDARY CIRCUIT TIME CONSTANT)	100	MSEC
613	~	NUMO	Dn-13 (LEAKAGE SAT COEF, USED WITH OPT TRQ BOARD)	1.20	~
614	~	NUMO	Dn-14 (ROTOR HEAT GAIN)	0.00	~
615	~	NUMO	Dn-15 (ROTOR HEAT TIME CONSTANT)	30	MIN
616	~	NUMO	Dn-16 (IRON CORE SATURATION COMP COEFFICIENT 1)	0.5	~
617	~	NUMO	Dn-17 (IRON CORE SATURATION COMP COEFFICIENT 2)	0.75	~
618	~	NUMO	Dn-18 (MOTOR OVERHEAT TEMPERATURE)	120 ◆	°C

◆ -Initial value dependent on setting of Sn-02. Value shown is for Sn-02 setting of FFF hex.



Node 703 (Accessible by PCDU) Assignments

CHAN	SUB CHAN	PAC BLOCK TYPE	CONST	DESCRIPTION
101	~	GETH	Sn-01	KVA SELECT
102	~	GETH	Sn-02	MOTOR SELECTION (SELECTS PRE PROGRAMMED MOTOR PARAMETERS)
103	0	GETP	Sn-03	DETERMINES READ/WRITE STATUS OF CONSTANTS IN THE DRIVE MODE
103	4	GETP	Sn-04	SETS INVERTER CONFIGURATION
105	0	GETP	Sn-05	SETS INVERTER CONFIGURATION
105	4	GETP	Sn-06	SETS INVERTER CONFIGURATION
107	0	GETP	Sn-07	SETS INVERTER CONFIGURATION
107	4	GETP	Sn-08	SETS INVERTER CONFIGURATION
109	0	GETP	Sn-09	SETS INVERTER CONFIGURATION
109	4	GETP	Sn-10	SETS INVERTER CONFIGURATION
111	0	GETP	Sn-11	SETS INVERTER CONFIGURATION
111	4	GETP	Sn-12	SETS INVERTER CONFIGURATION
113	0	GETP	Sn-13	SETS INVERTER CONFIGURATION
113	4	GETP	Sn-14	SETS INVERTER CONFIGURATION
115	~	GETH	Sn-15	SELECTS FUNCTION TO BE PERFORMED BY LOGIC INPUT NO. 5
116	~	GETH	Sn-16	SELECTS FUNCTION TO BE PERFORMED BY LOGIC INPUT NO. 6
117	~	GETH	Sn-17	SELECTS FUNCTION TO BE PERFORMED BY LOGIC INPUT NO. 7
118	~	GETH	Sn-18	SELECTS FUNCTION TO BE PERFORMED BY LOGIC INPUT NO. 8
119	~	GETH	Sn-19	SELECTS FUNCTION FOR ANALOG INPUT TERMINAL 16
120	~	GETH	Sn-20	SELECTS FUNCTION FOR LOGIC OUTPUT NO. 1
121	~	GETH	Sn-21	SELECTS FUNCTION FOR LOGIC OUTPUT NO. 2
122	~	GETH	Sn-22	SELECTS FUNCTION FOR LOGIC OUTPUT NO. 3
123	~	GETH	Sn-23	SELECTS FUNCTION FOR LOGIC OUTPUT NO. 4
124	~	GETH	Sn-24	SELECTS FUNCTION FOR LOGIC OUTPUT NO. 5
127	0	GETP	Sn-27	SETS INVERTER CONFIGURATION
127	4	GETP	Sn-28	SETS INVERTER CONFIGURATION
130	0	GETP	Sn-30	SETS INVERTER CONFIGURATION
130	4	GETP	Sn-31	SETS INVERTER CONFIGURATION
132	0	GETP	Sn-32	SETS INVERTER CONFIGURATION
132	4	GETP	Sn-33	NOT USED WITH MICROTRAC
134	0	GETP	Sn-34	SETS INVERTER CONFIGURATION
134	4	GETP	Sn-35	NOT USED WITH MICROTRAC
301	0	GETP	On-01	SETS INVERTER CONFIGURATION
301	1	GETP	On-02	SETS INVERTER CONFIGURATION
303	0	GETP	On-03	SETS INVERTER CONFIGURATION
303	1	GETP	On-04	SETS INVERTER CONFIGURATION

**Node 247 (MicroTrac Card) Assignments**

CHAN	SUB CHAN	PAC BLOCK TYPE	DESCRIPTION
0	0	LOGO	LCDU READY LED
0	1	LOGO	LCDU RUN LED
0	2	LOGO	LCDU TORQUE LIMIT LED
0	3	LOGO	LCDU OVERLOAD LED
7	0	LOGO	REQUEST FAULT RESET
8	0	LOGI	FAULT EXISTS IN FAULT LIST
8	4	LOGI	LCDU FAULT RESET BUTTON PRESSED
16	~	NUMI	FX=0
17	~	NUMI	FX=1
18	~	NUMI	FP=0
19	~	NUMI	FP=1
20	0	LOGI	FALSE
20	1	LOGI	TRUE
21	0	LOGO	LOGIC DATA DUMP
21	~	NUMO	NUMERIC DATA DUMP
30	~	TACH	DIGITAL FEEDBACK TACH
31	~	TACH	DIGITAL REFERENCE TACH
32	0	NUMI	MAIN BOARD ANALOG INPUT
32	1	NUMI	MAIN BOARD ANALOG INPUT
33	0	NUMO	MAIN BOARD ANALOG OUTPUT
33	1	NUMO	MAIN BOARD ANALOG OUTPUT
40	~	NUMI	TRACE BUFFER 0
41	~	NUMI	TRACE BUFFER 1



VCD 723 Error Codes

ERROR CODE	PCDU DISPLAY	DESCRIPTION
700	M PWR U VLT	INVERTER DECLARED MAIN POWER UNDERVOLTAGE
701	C PWR U VLT	INVERTER DECLARED CONTROL POWER UNDERVOLTAGE
702	MC CONTACT OFF	INVERTER DECLARED MC CONTACTOR OFF
703	BRAKE TRANS FLT	INVERTER DECLARED BRAKING TRANSISTOR FAULT
704	BRAKE R HOT	INVERTER DECLARED BRAKING RESISTOR OVERTEMP
706	THERMISTOR OPEN	INVERTER DECLARED THERMISTOR OPEN
707	TRANSMIT ERROR	INVERTER DECLARED TRANSMISSION ERROR
712	EXT FLT T INPUT	EXTERNAL FAULT DECLARED VIA INVERTER TRANSMISSION INPUT
713	EXT FLT TERM 3	EXTERNAL FAULT DECLARED VIA INVERTER TERMINAL 3
714	EXT FLT TERM 5	EXTERNAL FAULT DECLARED VIA INVERTER TERMINAL 5
715	EXT FLT TERM 6	EXTERNAL FAULT DECLARED VIA INVERTER TERMINAL 6
716	EXT FLT TERM 7	EXTERNAL FAULT DECLARED VIA INVERTER TERMINAL 7
717	EXT FLT TERM 8	EXTERNAL FAULT DECLARED VIA INVERTER TERMINAL 8
720	INV PG OPEN	INVERTER DETECTED THAT ITS PULSE GENERATOR IS OPEN
721	INV OVERSPD	INVERTER DECLARED OVERSPEED FAULT
722	INV SPD ERROR	INVERTER HAS DETECTED A PROBABLE SPEED ERROR
741	BASE BLK FLT	INVERTER HAS DETECTED A BASE BLOCK CIRCUIT FAULT
742	S RAM FLT	INVERTER HAS DETECTED A SHADOW RAM FAULT
743	NVRAM CHK ERR	INVERTER HAS DETECTED A NVRAM CHECKSUM ERROR
744	MCU A D FLT	INVERTER HAS DETECTED A MAIN MCU A/D CONVERTER FAULT
745	OP CRD CONNECT	INVERTER HAS DETECTED A POOR OPTION CARD CONNECTION
751	DSP P FLT	INVERTER HAS DETECTED A DSP PERIPHERAL CIRCUIT FAULT
752	OPT A D FLT	INVERTER HAS DECLARED AN OPTION CARD A/D FAULT
753	MISSING DCU	INVERTER HAS NOT SEEN THE DCU HANDSHAKE
754	INV MODEL ERR	INVERTER MODEL CODE NUMBER IS WRONG
760	DPRAM CHK ERR	AN ERROR IN THE DPRAM CHECKSUM HAS BEEN DETECTED
761	DPRAM CNST	INVERTER DETECTED ERROR IN SETTING ONE OF THE LETTERED CONSTANTS
762	KVA SET ERR	INVERTER DECLARED KVA SETTING ERROR
763	SET ERR	INVERTER DETECTED ERROR IN SETTING ONE OF THE LETTERED CONSTANTS
764	SN ERR	SN-15 THROUGH SN-18 SETTING ERROR
765	TQ ERR	TORQUE CONTROL MODE SELECTION ERROR
766	NVRAM ERR	INVERTER HAS AN NVRAM WRITE ERROR
767	RANGE ERROR	UPPER/LOWER LIMIT EXCEEDED IN SETTING
768	INV OVC	INVERTER OVERCURRENT
769	INV OVV	INVERTER BUS OVERVOLTAGE



VCD 723 Error Codes - Continued

ERROR CODE	PCDU DISPLAY	DESCRIPTION
770	INV OVL	INVERTER OVERLOAD
771	INV OVT	INVERTER OVERTEMPERATURE
772	INV FUSE	INVERTER FUSE BLOWN
773	INV PHASE	INVERTER OPEN LOAD PHASE
774	INV HWD	GENERAL INVERTER HARDWARE FAILURE
775	INV MOVL	INVERTER SENSED MOTOR OVERLOAD
776	INV MOVT	INVERTER SENSED MOTOR OVERTEMP
777	INV PL	INVERTER MOMENTARY POWER LOSS
778	INV SPDD	OVERSPEED DEVIATION
779	INV FAN	INVERTER COOLING FAN FAULT



Glossary **A/D** – Analog to Digital converter.

Active Hub – A central component in LAN star networks that ensures data integrity over distances of up to 2000 feet by regenerating the network signal.

Active menu item – The menu item for an RDU that will be used to get the source of the information to be displayed. When a menu item number is selected, the Control/Display Unit (CDU) menu item data will be used; if there is no data in the CDU menu item for the selected menu item number, then the default menu item data is used.

Active Link – A device that interconnects two LAN bus networks.

ANI/O – Remote Analog I/O [Input/Output] PCB.

Broadcast message – A type of LAN message which is capable of being received by all nodes on the LAN. The message contains the source of the message, but the destination is all nodes that have been enabled to receive broadcast messages.

CDU – Control/Display Unit. There are two CDUs supported for the MicroTrac DSD drive: the Standard CDU (see *SCDU* definition) and the Portable CDU (see *PCDU* definition).

CDU menu item – A menu item of an RDU that was built by using the PCDU.

Channel – The second level address used to further define the location of information external to the the PAC environment (the first level of addressing being the Node number - see *NODE* definition). To access information external to the PAC environment requires reference to that information by an address which includes all levels of addressing defined for that particular information. That is, to use a Channel number also requires the associated Node number such as Node 50, Channel 21. The system will support a maximum of 256 (0 through 255) Channel numbers.

Complex PAC task – Any of the more complicated PAC functions (as opposed to the simpler elemental functions), which consists of two (or more) interrelated PAC tasks. These interrelated tasks are referred to as segments. Each segment is a self-contained module which executes sequentially, although each segment executes separately. The interrelated segments exchange information between each other which has predefined significance. The various segments need not be programmed in a common scan (see *SCAN* definition).

An example of a complex task would be SPDR, the speed regulator task, which consists of two related segments. One segment executes in the fast scan, and consists of the actual function of regulating the speed by comparing the speed reference to the feedback and generating a torque command based on the

difference and the required gains of the regulator. The other segment consists of the code used to calculate the gains required for the speed regulation function in the format required by that segment. In other words, it translates from the engineering terms used to describe regulator performance (such as load inertia and desired crossover frequency) to the integral and proportional gains required by the regulator segment. Since these defining parameters are rarely changed, this segment needs to execute only rarely, thus saving processor time for other functions which do require frequent execution.

Conditional scan – Conditional scan tasks define sub-programs (i.e. sub-programs consisting of unique interconnections of PAC tasks) which execute only when certain logic conditions related to the conditional scan task are satisfied. When the conditional scan executes, the program defined for the conditional scan executes at the scan level at which the conditional scan task is programmed (see *SCAN* definition). The use of conditional scans allows greater utilization of the limited processor time.

Custom fault – A fault (or error) defined via the PAC task “FLTD”. These faults have significance only to a particular PAC design. (See *Fault* or *Error* definition).

D/A – Digital to Analog converter.

DCU – Drive Control Unit. The drive control unit refers to the hardware and software used to control the drive as opposed to the hardware and software used to control the power conversion process. Specifically, it refers to the hardware and software associated with the DCU microprocessor. The DCU software includes the variable software generated as a result of the PAC program and the fixed software (see *Kernel* definition) used to control execution of the PAC program.

Default menu – A menu for an RDU that contains the default menu items as received through the LAN from the drives. Each drive connected to the LAN can have default menu items that are to be displayed on specific RDUs. The default menu items and the order of the menu items are determined by the PAC programmer.

Directed message – A type of LAN message which can be received only by one LAN Node. This type of message contains both the source and destination Node numbers.

Elemental PAC task – The simpler PAC language functions where everything associated with that function is contained in one sequentially executed module.

EPROM – Erasable Programmable Read Only Memory. An integrated circuit that is usually used to hold the instructions for a microprocessor’s program.

Error – An abnormal condition considered less serious than a fault (see *FAULT* definition). The difference between the two is that an error is recorded in the NVRAM, but not announced on the CDUs. The declaration of a fault will cause immediate display of the fault code number on the SCDU and the lighting of the **FAULT LED**. Any abnormal condition, standard or custom (also see *STANDARD FAULT* and *CUSTOM FAULT* definitions) may be declared as an error, a fault or both. Each abnormal condition is given an initial default classification as either an error, a fault, or both an error AND a fault. A special CDU function is provided to override that initial default classification.

The declaration of an error places the error number assigned to that error at the end of the Last Error List. This error list is of fixed length (16) and allows display via the CDU of the latest errors (note this differs from the First Fault List, which displays the oldest faults). In addition to the display of the error code number, this error list also allows the display of the task number of the PAC task generating the error (if the error was not generated by a PAC task, then task number zero [0] is displayed) and a time stamp of when the error occurred.

Fault – An abnormal condition generally requiring corrective action. A fault is considered to be a condition more serious than an error (see *ERROR* definition). The difference between the two is that an error is recorded in the NVRAM, but not announced on the CDUs. The declaration of a fault will cause immediate display of the fault code number on the SCDU and the lighting of the Fault LED. If multiple faults occur, the last declared fault is the fault displayed on the CDU.

A fixed number of faults (16) are recorded in order of declaration. This Fault List may be reviewed by order of fault declaration via a special CDU function. Once the Fault List is full, declaration of additional faults will not appear on the Fault List until space on the list is made available. The same CDU function used to display the Fault List may be used to clear from the list either all the faults or individual faults. The **FAULT LED** will remain lit until all the faults have been cleared from the Fault List.

Faults can be classified into two categories: “Standard” (see *STANDARD FAULT* definition) and “Custom” (see *CUSTOM FAULT* definition).

In most cases, no action is taken when a fault is declared. In these cases, the corrective action is the responsibility of the PAC program. In some cases, however, the abnormal condition is so severe that corrective action must be taken without regard to the PAC program (see *SEVERE FAULT* definition).

All defined abnormal conditions may be categorized as a fault or not a fault via a special CDU function. Each of these conditions is given an initial default (i.e. it is either categorized as a fault or not). The special CDU function allows overriding of that initial definition.

Fixed point number – A number system used internally in the computer which is encoded in a specific manner. Fixed point numbers have a limited range of values which they can represent. In the case of the fixed point numbering system used for the PAC language, the maximum value which can be represented is +/- 32,767.99998 and the smallest non-zero value is +/- 0.000015.

The advantage of fixed point numbers is that some of the arithmetic operations such as addition, subtraction, and comparison execute much faster than a value represented in floating point.

Floating point number – A number system used internally in the computer which is encoded in a specific manner. In this case the encoding method (i.e. format) is a widely used format developed by the IEEE organization. The encoding scheme is similar to scientific notation of numbers which make use of number field and exponent. For example, $1.2 \times E-2$ is a scientific notation of the number 0.012 (1.2 times ten to the minus 2 power). The advantage of floating point numbers is that they can represent a very large range of values from the very small to the very large.

HIT – High Impedance Transceiver. A type of transceiver circuitry on a LAN Node that electrically connects to the coaxial cable. HIT Nodes may be interconnected in star or bus networks. MicroTrac DSD uses this type of transceiver.

Kernel – This is the fixed (i.e. non-changeable) code for the DCU microprocessor which forms the operating system of the microprocessor. As such, it controls the generation of the various scans, the order of execution of the PAC tasks, the information passed to and from the PAC tasks and the execution of other standard code not directly associated with the PAC tasks such as the control of the CDU or LAN handler.

LAN – Local Area Network. A high speed serial communication network which allows two-way communications between multiple devices (referred to as Nodes) all connected to the same communications cable. The specific LAN used is “ARCNET”.

LAND – LAN Driver transceiver. A type of transceiver circuitry on a LAN Node that electrically connects to the coaxial cable. LAND Nodes may be interconnected in a star network only.

LAN Node – A point in a network where service is provided, service is used, or communications channels are interconnected.

LCD – Liquid crystal display.

LED – Light emitting diode.

Local I/O – The class of Input and Output hardware located on the MicroTrac DSD chassis. All connections between the Main CPU Control PCB and these I/O boards are made via ribbon cables. All connections between the actual I/O devices (i.e. push buttons, thumbwheel switches, lights etc.) are made with individual wires between the I/O device and the drive.

Local RDU – When referring to a keyboard, the local RDU is the RDU that the keyboard is connected to.

Locked RDU – An RDU whose display may not be modified by a keyboard or push button connected to another RDU.

LOGI/O – Remote Logic I/O [Input/Output] PCB.

Menu – A list of items for an RDU, any one of which may be selected to be displayed on that RDU.

Menu item – A source definition of where the information to be displayed on an RDU, when selected, is to come from. The source definition includes the Drive Node number, the Channel number, and the Subchannel number. The decimal point location is also defined.

Node – Originally a term used to identify the base address of devices connected to the LAN. For MicroTrac DSD this term has been expanded to refer to the base address of anything outside the PAC program environment. Thus, the PCU and Local I/O PCBs are each assigned a Node number, even though the DCU does not communicate with those devices over the LAN. The system will support Node numbers 1 thru 258.

Node numbers assigned to devices on the LAN are unique, and refer to only one device on the LAN. Node numbers other than those on the LAN are predefined and not changeable. (Also see *LAN Node* definition.)

NVRAM – Non-Volatile Random Access Memory. Memory that can be written to as well as read from. In addition, this memory is protected from losing data when the power is lost. Usually this is accomplished with a battery that is good for at least 10 years.

PAC – Programmable Application Control. The graphically oriented task-based language used to customize the DCU (i.e. customize the drive for a specific application).

PAC Diagram – A drawing, resembling a schematic diagram, which shows the various PAC tasks and the unique interconnection of those PAC tasks.

PAC task – The smallest unit which can be programmed in the PAC language. Numerous types of PAC tasks are provided, each performing a specific, well defined function. Each type of PAC task may be used numerous times in a PAC design. Each PAC task is represented by a block on the PAC Diagram.

PAC task number – A unique number assigned by the PAC programmer to each PAC task on the PAC Diagram. These numbers may be assigned in any order and serve only as a means of identifying unique sources of information in the PAC program. The system will support up to 32,767 PAC tasks with the allowable task numbers being 1 to 32767.

Passive Hub – A central component in LAN star networks that splits the network signal. Data integrity is ensured over a distance of 100 feet for a 4-port Passive Hub.

PCB – Printed Circuit Board.

PCDU – Portable Control/Display Unit. A device which can plug into a drive or an RDC, via a cable with a modular connector (similar to a telephone cord), that has two lines of 16 character alphanumeric display and a 30 key keyboard. It allows the viewing and setting of variables.

PCU – Power Conversion Unit. The power conversion unit refers to the hardware and software associated with the power conversion from the AC lines to the motor. Specifically, it refers to the hardware and software associated with the PCU microprocessor as well as the power related components. The PCU is responsible only for the power conversion process, not determination of how much power should be converted (which is a function of the DCU).

Per-unit value – A per-unit value is a method of representing a quantity where the value 1.0 represents the “Rated” value for that quantity. Whereas the “Rated” value is generally a dimensioned value, the Per-Unit value is a dimensionless quantity.

Power cube – The MicroTrac DSD chassis and all components mounted on or inside it. A power cube alone cannot operate a motor; auxiliary items such as isolation transformer, input circuit breaker, control power transformer and motor loop contactor are needed to make up a complete MicroTrac DSD drive.

Queue – A list consisting of values where each new value is entered at the end of the list and values read from the list are taken from the beginning of the list. In other words, a first-in first-out [FIFO] buffer.

“RAM” – Random Access Memory. Memory that can be written to as well as read from. The data in this memory is lost when the power is lost.

RDC – Remote Display Controller LAN Node PCB. A board that includes the LAN Node circuitry and the software to control what is displayed on each of up to 31 RDUs. This device also communicates with the drives over the LAN.

RDU – Remote Display Unit. A device that has a 16 character alphanumeric display and a 5-1/2 digit plus sign numeric display. This device is controlled by an RDC.

RDU message – The data that is displayed on both displays of the RDU. The source of the message is defined in the RDC by a Menu Item number, Drive number, Channel number, Subchannel number, decimal position, a flag stating what type of message it is (whether the message is modifiable or not), and - if it is modifiable - the minimum and maximum allowable limits of an entered value.

RI/O – Remote I/O [Input/Output] Controller LAN Node PCB. A board that includes the LAN Node circuitry and the software to control outputs to and monitor inputs from Remote (Logic or Analog) I/O boards. This device also communicates with the drives over the LAN.

Scan – This term refers to the frequency at which a particular PAC task will execute. All PAC tasks programmed in a particular scan will execute in the same time frame. MicroTrac DSD is provided with four timed scans and one background scan. Each PAC task programmed in a timed scan will execute once in that time frame. The background scan executes each PAC task once in whatever time is left over from the timed scans and then starts over executing each task again.

SCDU – Standard Control/Display Unit. The 4-1/2 digit numeric display, 4 push buttons (keypad) and multi-color LED on the drive. It allows viewing and setting of variables.

Selected menu item – The menu item number in the RDU's menu that is being displayed.

Severe fault – An abnormal condition whose severity requires immediate action by the microprocessor sensing the error. An example of a severe error is an IST condition sensed by the PCU. In this case, the PCU disconnects the load; it does not wait for the PAC program to command load disconnect. (Also see *FAULT* definition.)

Speed Command – The desired speed setpoint prior to local PAC task modification such as linear accel/decel control, draw modification, trim modification, etc. (Also see *SPEED REFERENCE* definition.)

Speed Reference – The speed reference signal after all PAC task modification such as linear accel/decel control, draw modification, trim modification, etc. That is, the instantaneous value of the reference which is applied to the speed regulator. (Also see *SPEED COMMAND* definition.)

Standard fault – A fault (or error) which is independent of a particular PAC design. These conditions are associated with the operation of the DCU microprocessor or the PCU or the LAN handler. (See *FAULT* or *ERROR* definition.)

Subchannel – The PAC language defines a particular input or output by use of a Node, a Channel, and a Subchannel. The Subchannel refers to a specific input or output of a given Node and Channel.

The third level of addressing which further defines the location of information external to the PAC program environment; the first level is the Node number (see *NODE* definition) and the second level is the Channel number (see *CHANNEL* definition). To access information requires specifying all levels of addressing defined for that piece of information. For example, Node 251, Channel 4, Subchannel 0 refers to the Local Digital I/O PCB connected to connector J1 (assigned Node 251), Thumbwheel switch inputs (assigned as Channel 4 of the Digital I/O PCB), and specifically the set of thumbwheel switches designated as Bank 0 (i.e. Subchannel 0).

Token – A term used with the LAN to describe a special LAN message. This message is passed from one LAN Node to another. When a LAN Node receives this message (i.e. the token), it is allowed to transmit a message it has generated while waiting to receive permission to transmit. Once it has completed its transmission, it must pass the token to the next node (in numerical sequence). Nodes which do not have the token may receive messages but may not transmit a message until the token is received. If the node receiving the token does not have any messages to transmit, it simply passes the token to the next node.

TWI/O – Remote Thumbwheel I/O [Input/Output] PCB.

Unlocked RDU – An RDU whose display may be modified by a keyboard or push button connected to another RDU. This is the default RDU lock state.

Please send information concerning scheduled dates of Training Seminar(s) for the VCD 723.

Send Information to: Magnetek
Attn: Training Coordinator
16555 West Ryerson Road
New Berlin, WI 53151
(800) 541-0939
(414) 782-0200 Ext. 317

Applicant Name _____

Position/Title _____

Company _____

Address _____

City _____ State _____ ZIP _____

Telephone () - _____


Expected Number of Attendees _____

FAX (414) 782-2884

07/01/97



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL
FIRST CLASS MAIL PERMIT NO. 2562 NEW BERLIN, WI 53151

Postage will be paid by addressee



16555 West Ryerson Road
New Berlin, WI 53151-3671

ATTN: Training Coordinator

VCD 723 Product Literature Request Form

Mail or Fax to:
 MagneTek
 ATTN: Ken Gniot
 16555 West Ryerson Road
 New Berlin, WI 53151
 Telephone #414/782-0200
 Fax #414/782-1283

✓	Catalog Number	Quantity Required	Description
VCD 723			
	BL 6723		VCD 723 Product Bulletin
	TM 6723		VCD 723 Product Guide
	TM 6723-10		VCD 723 Maintenance Guide
	TM 6723-20		PCDU Guide
	TM 6723-30		MicroTrac LAN Network Guide

Show Complete Shipping Address
 Do Not Use P.O. Box

Ship To:

Requisitioner *(Print Name)*

Street Address

City/State Zip

Phone Number _____ Drive S/N _____

Fax Number _____ Drive Purchased From _____

Allow one (1) week for delivery.

Date of Order _____

VCD 723

Data subject to change without notice. MicroTrac, DSD, PAC, and VCD are trademarks of MagneTek, Inc.

MagneTek
16555 West Ryerson Road
New Berlin, WI 53151
(800) 541-0939, (414) 782-0200, FAX (414) 782-1283

