



TOE-S616-40.2

TRANSISTOR INVERTER

# Varispeed™ - 616HII

200 TO 230 V · 11 TO 45 kW (15 TO 60 HP) · 15 TO 60 kVA

## INSTRUCTION MANUAL


Before initial operation  
read these instructions  
thoroughly and retain  
for future reference

When properly installed, operated and maintained, this equipment will provide a lifetime of service. It is mandatory that the person who operates, inspects, or maintains this equipment thoroughly read and understand this manual, before proceeding.

This manual applies to VS-616HII Model CIMR-11 B, -15 B, -18.5 B, -22 B, -30 B, and -45 B.

The VS-616HII Drive is an AC variable speed drive system for high-precision variable speed applications. It basically consists of a three-phase squirrel-cage induction motor, a VS-616HII controller (VS-616HII), an operator control station, and optional control units. This manual primarily describes VS-616HII, but contains basic information for operator control station as well. For details of the operation of individual units, refer to their respective manuals.

685-285



VS-616HII Inverter  
with Digital Operator (Optional)

## CONTENTS

<p><b>1. RECEIVING</b> 5</p> <p><b>2. VS-616 HII FUNCTIONAL DESCRIPTION</b> 6</p> <p>2.1 VS-616 HII Functional Block Diagram and Major Control Component Layout 6</p> <p>2.2 Circuit Operational Description 8</p> <p>2.2.1 Main Circuit 8</p> <p>2.2.2 Control Circuit 8</p> <p>2.2.3 Protective Circuits 9</p> <p><b>3. INSTALLATION</b> 9</p> <p>3.1 Location 9</p> <p>3.2 Positioning 10</p> <p>3.3 Mounting Dimensions 10</p> <p><b>4. WIRING</b> 11</p> <p>4.1 Interconnections 11</p> <p>4.2 Molded-Case Circuit Breaker (MCCB) and Power Supply Magnetic Contactor (MC) 12</p> <p>4.3 Surge Absorber 12</p> <p>4.4 Wire Size 12</p> <p>4.5 Wiring Instructions 13</p> <p>4.5.1 Control Circuit 13</p> <p>4.5.2 Main Circuit Input/Output 13</p> <p>4.5.3 Grounding 14</p> <p><b>5. TEST RUN</b> 15</p> <p>5.1 Checks Before Test Run 15</p> <p>5.2 Presetting and Adjustment Before Test Run 15</p> <p>5.3 Trial Operation/Test Run 21</p> <p>5.3.1 Use of Analog Operator Model JVOP-72 (optional) 22</p> <p>5.3.2 Use of Digital Operator Model JVOP-71 (optional) 23</p> <p>5.3.3 Use of VS Operator Model JVOP-65 (optional) 24</p>	<p>5.4 Frequency Meter Calibration 25</p> <p><b>6. OPERATION AT LOAD</b> 25</p> <p><b>7. MAINTENANCE</b> 26</p> <p><b>8. FAILURE INDICATION AND DETAILS</b> 27</p> <p><b>9. TROUBLESHOOTING</b> 28</p> <p>9.1 Measuring Point and Instrument 28</p> <p>9.2 Troubleshooting for Motor Symptom 29</p> <p>9.3 Troubleshooting for Failure Indications 31</p> <p><b>APPENDIX 1 VS-616 HII RATINGS AND SPECIFICATIONS</b> 36</p> <p><b>APPENDIX 2 TERMINAL FUNCTIONS</b> 37</p> <p><b>APPENDIX 3 INTERNAL CIRCUIT AND INTERCONNECTION DIAGRAMS</b> 38</p> <p>A3-1 VS-616 HII Internal Circuit 38</p> <p>A3-2 Interconnection Diagrams for VS-616 HII Applications 39</p> <p><b>APPENDIX 4 VS-616 HII OPTIONAL AND AUXILIARY UNITS</b> 47</p> <p>A4-1 VS-616 HII Optional Units 47</p> <p>A4-2 VS-616 HII Auxiliary Units 48</p> <p><b>APPENDIX 5 CHECKING OF DIODE AND TRANSISTOR MODULES</b> 49</p> <p>A5-1 Diode Module 49</p> <p>A5-2 Transistor Module 49</p> <p><b>APPENDIX 6 PARTS REPLACEMENT</b> 50</p> <p>A6-1 Replacement of Control PC Board 50</p> <p>A6-2 Replacement of Base Drive PC Board 50</p> <p>A6-3 Replacement of Diode Module and Transistor Module 51</p> <p>A6-4 Main Circuit Fuse Removal 52</p> <p>A6-5 Replacement of Cooling Fan 52</p> <p><b>APPENDIX 7 SPARE PARTS</b> 53</p>
---	---

## INDEX

Subject	Chapter	Section	Page
<b>A</b> ANALOG OPERATOR MODEL JVOP-72 (OPTIONAL), USE OF . . . . .	5	5.3.1	22
Auxiliary Units, VS-616 HII . . . . .	APPENDIX 4	A4-2	48
<b>B</b> Before Test Run, Checks . . . . .	5	5.1	15
BLOCK AND INTERCONNECTION DIAGRAMS. . . . .	APPENDIX 3		38
<b>C</b> Circuit Operational Description . . . . .	2	2.2	8
CONTROL CIRCUIT . . . . .	2	2.2.2	8
Control PC Board, Replacement of. . . . .	APPENDIX 6	A6-1	50

## INDEX (Cont'd)

Subject	Chapter	Section	Page
<b>D</b> Digital Operator Model JVOP-71 (Optional) (Fig. 15), Use of . . . . .	5	5.3.2	23
Diode Module . . . . .	APPENDIX 5	A5-1	49
Diode Module and Transistor Module, Replacement of . . . . .	APPENDIX 6	A6-3	51
<b>F</b> FAILURE INDICATION AND DETAILS . . . . .	8		27
Frequency Meter Calibration . . . . .	5	5.4	25
Functional Block Diagram and Major Control Component Layout, VS-616 HII . . . . .	2	2.1	6
FUNCTIONAL DESCRIPTION, VS-616 HII . . . . .	2		6
<b>I</b> INSTALLATION . . . . .	3		9
Internal Circuit, VS-616 HII . . . . .	APPENDIX 3	A3-1	38
Interconnection Diagrams for VS-616 HII Applications . . . . .	APPENDIX 3	A3-2	39
Interconnections . . . . .	4	4.1	11
<b>L</b> Location . . . . .	3	3.1	9
<b>M</b> Main Circuit . . . . .	2	2.2.1	8
MAINTENANCE . . . . .	7		26
Measuring Point and Instrument . . . . .	9	9.1	28
Molded-Case Circuit Breaker (MCCB) and Power Supply Magnetic Contactor (MC) . . . . .	4	4.2	12
Mounting Dimensions . . . . .	3	3.3	10
<b>O</b> OPERATION AT LOAD . . . . .	6		25
OPTIONAL UNITS, AND AUXILIARY UNITS, VS-616 HII . . . . .	APPENDIX 4		47
Optional Units, VS-616 HII . . . . .	APPENDIX 4	A4-1	47
<b>P</b> PARTS REPLACEMENT . . . . .	APPENDIX 6		50
Positioning . . . . .	3	3.2	10
Protective Circuit . . . . .	2	2.2.3	9
<b>R</b> Ratings and Specifications, VS-616 HII . . . . .	APPENDIX 1		36
RECEIVING . . . . .	1		5
SPARE PARTS . . . . .	APPENDIX 7		53
<b>S</b> Surge Absorber . . . . .	4	4.3	12
<b>T</b> TEST RUN . . . . .	5		15
Test Run, Presetting and Adjustment before . . . . .	5	5.2	15
Transistor Module . . . . .	APPENDIX 5	A5-2	49
Trial Operation/Test Run . . . . .	5	5.3	21
TROUBLESHOOTING . . . . .	9		28
Troubleshooting for Motor Symptom . . . . .	9	9.2	29
Troubleshooting for Failure Indications . . . . .	9	9.3	31
<b>V</b> VS OPERATOR MODEL JVOP-65- (OPTIONAL) (Fig. 16), USE OF . . . . .	5	5.3.3	24
<b>W</b> WIRE SIZE . . . . .	4	4.4	12
WIRING . . . . .	4		11
WIRING INSTRUCTIONS . . . . .	4	4.5	13

## INDEX OF FIGURES

Fig. 1 VS-616 HII Functional Block Diagram	6
Fig. 2 Major Control Component Layout of VS-616 HII Model CIMR-18.5B	7
Fig. 3 Accel/Decel Time Setting	8
Fig. 4 Example of V/f Setting	8
Fig. 5 VS-616 HII Clearance Requirements for Proper Cooling and Maintenance	10
Fig. 6 Cabinet Mounting Dimensions	10
Fig. 7 Example of VS-616 HII Interconnections	11
Fig. 8 Shielded Lead Termination	13
Fig. 9 Grounding of Three VS-616 HII Units	14
Fig. 10 Connections for Megger Testing	14
Fig. 11 ON/OFF Switches of 6S (1 to 8)	20
Fig. 12 Master Frequency Reference Signal Selection	20
Fig. 13 Auxiliary Frequency Reference Signal Selection	20
Fig. 14 Run and Stop Time Chart	21
Fig. 15 Analog Operator (Optional)	22
Fig. 16 Digital Operator (Optional)	23
Fig. 17 VS Operator (Optional)	24
Fig. 18 Points for Measurement	29
Fig. 19 Output Voltage Measurement	29
Fig. 20 VS-616 HII Internal Circuit	38
Fig. 21 With Analog Operator	39
Fig. 22 With Digital Operator	39
Fig. 23 With VS Operator	40
Fig. 24 With User-Arranged Operation Circuit	41
Fig. 25 With Magnetic Contactor for Start/Stop Operation	42
Fig. 26 With VS Operator and Analog Operator	43
Fig. 27 With VS Operator and Digital Operator	44
Fig. 28 With Braking Module and Braking Resistor Unit	45
Fig. 29 With Transistor (Open-Collector) for Start/Stop Operation	46
Fig. 30 Control PC Board	50
Fig. 31 Base Drive PC Board	50
Fig. 32 Removing Diode Module and Transister Module	51
Fig. 33 Removing Transistor Module	51
Fig. 34 Removing Main Circuit Fuse	52
Fig. 35 Cooling Fan Assembly	52

## INDEX OF TABLES

Table 1 VS-616 HII Model Name Ratings	5
Table 2 Molded-Case Circuit Breakers and Magnetic Contactors	12
Table 3 Surge Absorbers	12
Table 4 Wire Size for Main and Control Circuits	12
Table 5 Round Pressure Terminals	12
Table 6 List of Setting Switches	15
Table 7 V/f Pattern Selection	16
Table 8 Accel/Decel Time Range Setting	17
Table 9 Notch Selection of Electronic Thermal Setting Switch (Use of Standard Motor)	18
Table 10 Notch Selection of Electronic Thermal Setting Switch (Use of VS-616 HII Motor)	18
Table 11 Inverter Capacity Selection	18
Table 12 Selection of Operation Modes	19
Table 13 Periodical Inspection	26
Table 14 Failure Indication of Analog and Digital Operators	27
Table 15 Failure Indication of VS-616 HII	27
Table 16 Measuring Points and Instruments	28
Table 17 VS-616 HII Ratings and Specifications	36
Table 18 Terminal Functions and Voltages of Main Circuit	37
Table 19 Terminal Functions and Signals of Control Circuit	37
Table 20 VS-616 HII Operational Units	47
Table 21 VS-616 HII Auxiliary Units	48
Table 22 Devices of VS Operator Model JVOP-65	48
Table 23 Diode Module Resistances	49
Table 24 Transistor Module Resistances of Model CIMR-11B	49
Table 25 Transistor Module Resistances of Model CIMR-15B, and -45B	49
Table 26 Spare Parts	53

## DANGER

- Do not touch circuit components until "CHARGE" lamp is extinguished after turning off the AC main circuit power supply. The capacitors are still charged and can be quite dangerous.
- Before changing switch settings (1S to 6S), turn off the power and make sure that CHARGE lamp is off.
- Do not connect or disconnect wires and connectors while power is applied to the circuit.
- Do not check signals during operation.

## IMPORTANT

- Be sure to ground VS-616HII using the ground terminal (E). See para 4.5.3 on page 14.
- Never connect main circuit output terminals (U)(T1), (V)(T2), (W)(T3) to AC main circuit power supply.
- All the potentiometers of VS-616HII have been adjusted at the factory. Do not change their settings unnecessarily.
- Do not make withstand voltage test on any part of the VS-616HII unit, because it is electronic equipment using semi-conductors and vulnerable to high voltage.
- To make the insulation resistance test with a megger, special precautions must be taken. Before test, see Insulation Resistance Test on page 14.
- Control PC board employs CMOS IC which is easily damaged by static electricity. Take care not to touch the CMOS elements inadvertently.

## 1. RECEIVING

This VS-616HII has been put through severe tests at the factory before shipped. After unpacking, however, check and see the following.

- Nameplate ratings meet your requirements. See Table 1.
- Leads and connectors are not disengaged.
- No damage while in transit.
- Bolts and screws are not loose.

If any part of VS-616HII is damaged or lost, immediately notify us giving full details and nameplate data.

Table 1 VS-616HII Model Name and Ratings

VS-616HII Model CIMR-	11 B	15 B	18.5 B	22 B	30 B	37 B	45 B
Max Motor Output kW(Hp)	11 (15)	15 (20)	18.5 (25)	22 (30)	30 (40)	37 (50)	45 (60)
Inverter Capacity kVA	15	20	25	30	40	50	60

## 2. VS-616 H II FUNCTIONAL DESCRIPTION

### 2.1 VS-616 H II FUNCTIONAL BLOCK DIAGRAM AND MAJOR CONTROL COMPONENT LAYOUT

VS-616HII functional block diagram is shown in Fig. 1 and major control component layout, in Fig. 2.




Fig. 1 VS-616 H II Functional Block Diagram





Fig. 2 Major Control Component Layout of VS-616 H II Model CIMR-18.5B

## 2.2 CIRCUIT OPERATIONAL DESCRIPTION

### 2.2.1 MAIN CIRCUIT

- (1) Rectifying circuit: Converts three-phase AC inputs through diodes to DC voltage.
- (2) Smoothing circuit: Smooths ripples in DC voltage by means of a capacitor.
- (3) Inverter circuit: Converts DC voltage to AC voltage of a preset frequency by switching six transistors. The output voltage level is controlled by changing the pulse width ratio, thus generating pseudo-sine waves.

### 2.2.2 CONTROL CIRCUIT

- (1) Base drive circuit: Drives the transistors in the inverter circuit.
- (2) Sine wave PWM control circuit: Calculates the pulse width every time a reference signal is received from the V/f control circuit, and outputs a PWM signal approximating a sine wave.
- (3) V/f selector circuit: Selects V/f pattern from 15 types of built-in voltage/frequency (V/f) patterns (Fig. 3).
- (4) Acceleration and deceleration time setting circuit: Smoothly changes the output frequency upon a rapid change of the frequency reference signal. Acceleration and deceleration times can be independently set by the acceleration (ACC) and deceleration (DEC) time setting potentiometers (Fig. 4).
- (5) Stall prevention circuit
  - During acceleration - Stops acceleration in the event of overcurrent condition and prevent the motor from stopping due to overcurrent. When the current returns to the rated value, acceleration is resumed.
  - During deceleration - Stops deceleration in the event of overvoltage condition and prevents the motor from stopping due to overvoltage. When the voltage returns to the rated value, deceleration is resumed.
  - In constant-speed operation - Reduces motor speed in the event of overload condition so as to prevent the motor from stopping due to overload. When overload condition is alleviated, motor resumes running at normal speed.




Fig. 3 Example of V/f Pattern




Fig. 4 Accel/Decel Time Setting



(6) Operation mode selector circuit: Selects one of eight operation modes individually to tailor the inverter to a specific application.

(7) Sequence mode selector circuit: Selects the optimum function from ten modes, according to the application.

### 2.2.3 PROTECTIVE CIRCUITS

See 8. Failure Indication and Details on page 26 when protective circuits function.

(1) Undervoltage protective circuit: If the supply voltage drops below a set level or any one of phases is open, the undervoltage protective circuit shuts off the power transistors in the main circuit, and outputs a fault signal (UV operation). With the appropriate operation mode selected, operation can continue if the power is resumed in approximately 2 seconds (operation after momentary power failure).

(2) Overvoltage protective circuit: If the main circuit DC voltage becomes higher than the set level, the overvoltage protective circuit shuts off the power transistors in the main circuit, and outputs a fault signal (OV operation).

(3) Overcurrent protective circuit: If more than 200% of the rated current flow is detected, the overcurrent protective circuit immediately shuts off the power transistors in the main circuit, and outputs a fault signal (OC operation).

(4) Overload protective circuit: When inverter of motor overload is detected by increased motor current, the overload protective circuit shuts off the power transistors in the main circuit after a specified time, and outputs a fault signal (OL operation).

(5) Electronic thermal overload protective circuit: Automatically adjusts protective characteristics to current and time to maximize operating capability.

## 3. INSTALLATION

### 3.1 LOCATION

Location of the equipment is important to achieve proper performance and normal operating life. The VS-616HII units should be installed in areas where the following conditions exist.

- Ambient temperature: -10 to +40°C
- Protected from rain or moisture.
- Protected from direct sunlight.
- Protected from corrosive gases or liquids.
- Free from airborne dust or metallic particles.
- Free from vibration.

#### CAUTION

Never move, lift or handle the VS-616HII cabinet by the front cover.

### 3.2 POSITIONING

For cooling and maintenance purposes, make sure that there is sufficient clearance around the equipment, as shown in Fig. 5.

To keep effective cooling conditions, it must be installed vertically to the ground using the four mounting screws.




Fig 5 VS-616HII Clearance Requirements for Proper Cooling and Maintenance

### 3.3 MOUNTING DIMENSIONS

The mounting dimensions for the VS-616HII are given in Fig. 6.





Fig. 6 Cabinet Mounting Dimensions

## 4. WIRING


### 4.1 INTERCONNECTIONS

Fig. 7 shows the connection diagram for combination of VS-616HII with VS operator. Remove the front cover before wiring. Connections should be made correctly, referring to Fig. 7.



Note:

1. indicates shielded leads and , twisted-pair shielded leads.
2. External terminal ⑳ of +15V has maximum output current capacity of 20 mA. It accommodates a single VS operator, if used.
3. When VS operator is used, remove external terminal connections between ① and ③.
4. External terminals ① and ② are short-circuited. To improve the power factor of power supply, remove the connections, and connect a reactor to ① and ②.
5. Terminal symbol ① shows main circuit, and ②, control circuit.



#### NOTE

Be sure to connect a surge absorber to the coils of relays, magnetic contactors, magnetic valves, or magnetic brakes.

Fig. 7 Example of VS-616HII Interconnections

## 4.2 MOLDED-CASE CIRCUIT BREAKER (MCCB) AND POWER SUPPLY MAGNETIC CONTACTOR (MC)

Be sure to connect MCCBs between power supply and VS-616HII input terminals  $\text{R}(\text{L}1)$ ,  $\text{S}(\text{L}2)$ ,  $\text{T}(\text{L}3)$ . Recommended MCCBs are listed in Table 2.

When a ground fault interrupter is used to prevent malfunction, setting current should be 200 mA or over and operating time, 0.2 sec or over.

Table 2 Molded-Case Circuit Breakers and Magnetic Contactors

VS-616 H II	Model CIMR-	11 B	15 B	18.5 B	22 B	30 B	37 B	45 B
	Capacity kVA	15	20	25	30	40	50	60
	Rated Output Current A	45	60	75	90	120	150	180
Molded-Case Circuit Breaker	Rated Current*	100 A	100 A	100 A	150 A	225 A	225 A	300 A
Yaskawa Magnetic Contactors Model		HI-50 E	HI-50 E	HI-80 E	HI-100 E	HI-100 E	HI-200 E	HI-200 E

\*Comply with NEMA AB1.

## 4.3 SURGE ABSORBER

For the surge absorbers to be connected to the coils of relays, magnetic contactors, magnetic valves or magnetic relays. Select models from the ones listed in Table 3.

Table 3 Surge Absorbers

Coils of Magnetic Contactor and Control Relay		Surge Absorber*		
		Model	Specifications	Code No.
200 V To 230 V	Large-size Magnetic Contactors	DCR2-50A22E	250 VAC 0.5 $\mu$ F+200 $\Omega$	C002417
	Control Relay LY-2,-3(OMRON) HH-22,-23(Fuji) MM-2,-4(OMRON)	DCR2-10A25C	250 VAC 0.1 $\mu$ F+100 $\Omega$	C002482

\*Made by MARCON Electronics.

## 4.4 WIRE SIZE

Wire sizes for main and control circuits are listed in Table 4, and Table 5 gives the selection of round pressure terminals according to wire size.

Table 4 Wire Size for Main and Control Circuits

Circuit	VS616HII Model CIMR-	Inverter Capacity kVA	Terminal Symbols	Terminal Screw	Wire Size*		Lead Type
					mm <sup>2</sup>	AWG	
Main	11 B	15	$\text{R}(\text{L}1)$ , $\text{S}(\text{L}2)$ , $\text{T}(\text{L}3)$ $\text{U}(\text{T}1)$ , $\text{V}(\text{T}2)$ , $\text{W}(\text{T}3)$ $\text{N}$ $\text{P}1$ , $\text{P}2$ , $\text{P}3$	M6	8-14	8-6	Power Cable: 600 V vinyl-sheathed lead or equivalent
	15 B	20					
	18.5 B	25		M6 (M8 for $\text{P}3$ )	8-14	8-6	
	22 B	30		M8	22-38	4-1	
	30 B	40		M10	30-100	2-4/0	
	37 B	50		M10	50-100	1/0-4/0	
	45 B	60		M10	50-100	1/0-4/0	
Control	11 B to 45 B		$\text{E}$	M4	2-5.5	14-10	Twisted shielded lead† for instrumentation
			$\text{r}(\text{L}1)$ , $\text{s}(\text{L}2)$	M4	0.5-2	20-14	

\*Lead size should be determined considering voltage drop of leads.

† Polyethylene-insulated vinyl-sheathed, with shielding.

Table 5 Round Pressure Terminals

Wire Size		Terminal Screw	Round Pressure Terminal
mm <sup>2</sup>	AWG		
0.5	20	M4	1.25-4
0.75	18		
1.25	16		
2	14	M4	2-4
3.5	12	M4	5.5-4
5.5	10		
8	8	M5	8-5
8	8		
14	6	M6	14-6
22	4		
38	1	M8	22-8
38	1		
60	2/0	M10	38-10
80	3/0		
100	4/0		
100	4/0		

## 4.5 WIRING INSTRUCTIONS

### 4.5.1 CONTROL CIRCUIT

#### (1) Separation of control circuit leads and main circuit leads

Signal leads ① through ② must be separated from main circuit leads  $\text{R}(\text{L1})$ ,  $\text{S}(\text{L2})$ ,  $\text{T}(\text{L3})$ ,  $\text{N}$ ,  $\text{P}_1$ ,  $\text{P}_2$ ,  $\text{P}_3$ ,  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ ,  $\text{W}(\text{T3})$ ,  $\text{r}(\text{l1})$ ,  $\text{s}(\text{l2})$ , to prevent erroneous operation caused by noise interference. If signal leads ⑫ to ⑯ (contact output) are connected to another power supply, separate them from ① to ⑪ and ⑰ to ⑳.

#### (2) Control circuit leads

Use the twisted shielded or twisted-pair shielded lead for the control circuit line and connect the shield sheath to the any of the inverter terminals ④, ⑪, or ⑱. See Fig. 8.




Fig. 8 Shielded Lead Termination

#### (3) Wiring distance

It is recommended that the wiring distance of the signal leads (①—⑳) be 50 meters (164 feet) or below.

### 4.5.2 MAIN CIRCUIT INPUT/OUTPUT

#### (1) Direction of phase rotation of power

- Phase rotation of power is available to each direction, clockwise and counterclockwise.
- When inverter output terminals  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ , and  $\text{W}(\text{T3})$  are connected to motor terminals  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ , and  $\text{W}(\text{T3})$ , respectively, motor rotates counterclockwise, viewed from opposite drive end, upon forward operation command. To reverse the rotation interchange any two of motor leads.

(2) Never connect power supply to output terminals  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ , and  $\text{W}(\text{T3})$ .

(3) Care should be taken to prevent contact of wiring leads with VS-616HII cabinet, for short-circuit may result.

(4) To feed DC power supply from terminals  $\text{P}_2$  and  $\text{N}$ , remove the leads across  $\text{R}(\text{L1})$ , and  $\text{r}(\text{l1})$ , and  $\text{S}(\text{L2})$  and  $\text{s}(\text{l2})$ . Connect cooling fan and magnetic contactor power supply (200/230V, 50/60Hz; 220/230V, 60Hz) across terminals  $\text{r}(\text{l1})$  and  $\text{s}(\text{l2})$ .

(5) Never connect power factor correction capacitor, noise filter to VS-616HII output.

(6) After completing VS-616HII interconnections, be sure to check that connections are correct. Never use control circuit buzzer check.

### 4.5.3 GROUNDING

Make a positive grounding using ground terminal (E) on the casing of VS-616HII.

- (1) Ground resistance should be  $100\Omega$  or less.
- (2) Never ground VS-616HII in common with welding machines, motors, and other large-current electrical equipment, or ground pole. Run the ground lead in a separate conduit from leads for large-current electrical equipment.
- (3) Use ground lead listed in Table 3 and make the length as short as possible.
- (4) Even when VS-616HII is grounded through its mounting such as channel base or steel plate, be sure to ground VS-616HII using the ground terminal (E).
- (5) Where several VS-616HII units are used side by side, all the units should preferably be grounded directly to the ground poles. However, connecting all the ground terminals of VS-616HII in parallel, and ground only one of VS-616HII to the ground pole is also permissible (Fig. 9). However, do not form a loop with the ground leads.




Fig. 9 Grounding of Three VS-616HII Units

### INSULATION RESISTANCE TEST

For megger-testing the main circuit, measure the insulation resistance with a 500V megger.

Connect the AC input, output terminals (r)(L1), (s)(L2), (R)(L1), (S)(L2), (T)(L3), (N), (P<sub>1</sub>, P<sub>2</sub>, P<sub>3</sub>), (U)(T1), (V)(T2), and (W)(T3), by a common wire, and connect the control terminals ① - ②② (excluding ④, ⑪, ⑲) by a common wire as shown in Fig. 10. After that, measure the insulation resistance between the common wire of input/output terminals and ground with a megger. Never measure the insulation resistance of circuit other than main circuit (power line). For both the input and output terminals, a reading above  $1M\Omega$  is considered satisfactory.




Fig. 10 Connections for Megger Testing

## 5. TEST RUN

### 5.1 CHECKS BEFORE TEST RUN

After completing mounting and connection of units, check for:

- Correct connections
- No short-circuit conditions
- No loose screw terminals (Check especially for loose wire clippings.)
- Proper load condition

### 5.2 PRESETTING AND ADJUSTMENT BEFORE TEST RUN










Before setting, be sure to shut off the AC main circuit power and make sure that the CHARGE lamp goes out. If any setting except for accel/decel time is performed with the power on, the following failure indicators will blink:

- FAULT lamp on the inverter
- CPF lamp, if the Analog or Digital operator is used

If any setting is changed during operation, the operation will continue with the setting made before the change. If the VS-616HII is turned off and then on again, it operates with the changed settings.

- The VS operator provides no failure indication for setting with power ON.

Table 6 List of Setting Switches

Switch Name	Symbol	Function	Factory-setting
V/f Pattern Selector Switch	1S 	Selects one of 15V/f patterns to match specific applications.	Notch ①
Accel/Decel Time Setting	Switch 2S 	Selects accel/decel time range (0.2 to 1800 seconds)	Notch ①
	Potentiometer ACC DEC 	Accel/decel times independently adjustable between the time range selected by 2S.	Scale 5
Sequence Mode Selector Switch	3S 	Selects one of 15 types of sequences according to application requirements.  ----- <b>CAUTION</b> Do not tamper with this switch. Any changes or adjustments must be made by the factory.	Notch ②
Electronic Thermal Setting Switch	4S 	Protects motor and inverter from overcurrent conditions if motor capacity is different from inverter capacity.	(See Tables 9 and 10.)
Inverter Capacity Selector Switch	5S 	Set according to inverter capacity. <b>CAUTION</b> Same as for 3S.	(See Table 11.)
Operation Mode Selector Switch	6S 	Selects the operation mode according to specific applications.	OFF
Master Frequency Reference Signal Selector Shunt	 C V	Selects either a current signal (4-20 mA) or a voltage signal (0-10 V) to feed frequency reference signal at terminal ⑨.	V (Voltage signal)
Auxiliary Frequency Reference Signal Selector Shunt	R  L	Set to input frequency reference at external terminal ⑩. When the Analog operator is used for frequency setting, set the shunt on "L" because signals from external terminal ⑩ are not accepted.	R

## 5.2 PRESETTING AND ADJUSTMENT BEFORE TEST RUN (Cont'd)

### (1) Setting of V/f pattern selector switch (1S)

The V/f pattern selector switch (1S) has been factory-set at the notch ① for most applications. For specific applications such as fans and pumps, high-starting torques, or machine tools, select the optimum V/f pattern for motor running, according to the load characteristics. (See Table 7.)

Table 7 V/f Pattern Selection (Input Supply Voltage: 200 V)

Application	Specification	1S Notch	V/f Pattern	Application	Specification	1S Notch	V/f Pattern		
General Purpose	50Hz	①		High Starting Torque	50Hz	Starting Torque Low	⑧		
						Starting Torque High	⑨		
	60Hz	60Hz Saturation	①			60Hz	Starting Torque Low	A	
		50Hz Saturation	②				Starting Torque High	B	
	72Hz	③			90Hz	C			
Variable Output (Fans and Pumps)	50Hz	Variable Torque 2	④	Constant Output (Machine Tools)	120Hz	D			
		Variable Torque 1						⑤	
	60Hz	Variable Torque 2	⑥		180Hz	E			
		Variable Torque 1						⑦	

Note: 1. Take account of the following conditions and others when selecting V/f pattern:

- Pattern matching the voltage-frequency characteristic of the motor.
- According to the maximum motor speed.

2. V/f pattern for high starting torque should be selected for:

- Long wiring distance.
- Large voltage drop at start.
- AC reactor connected to input or output of the inverter.
- Use of motor of the rating below the max.

For details, contact Yaskawa representative.



(2) Setting of acceleration and deceleration times (2S, ACC, DEC)

Set the acceleration and deceleration times using acceleration time range selector switch (2S), and the acceleration (ACC) and deceleration (DEC) time setting potentiometers (Table 8).

2S has been factory-set to notch ①, and the ACC and DEC potentiometers have been individually set to scale 5 (approximately 10 seconds).




Table 8 Accel/Decel Time Range Setting

2S Notch	Accel/Decel Time Setting Range (sec)
①	0.2-6
① (Factory setting)	1.8-18
②	6-60
③	18-180
④	60-600
⑤-⑥	180-1800
⑦	Soft start/stop function not provided.
⑧	For calibrating freq meter See para 5.4. on page 24.

(3) Selection of sequence mode (3S)

The standard sequence mode selector switch (3S) is paint-locked to notch ①.

Notches ① to ⑧ provide sequences for special applications. For details, contact Yaskawa representative.

(4) Setting of electronic thermal setting switch (4S)

When a motor has a capacity different from the maximum applicable capacity of the inverter, the VS-616HII setting must be changed to suit the motor capacity to protect the motor positively. Table 9 on page 18 shows the selections of Yaskawa standard motors (4 poles). The switch has been factory-set to the notch marked off by shading.

When VS-616HII motors are used, set the switch (4S) according to Table 10 on page 18. (Notch F inactivates the motor protection by the electronic thermal function.)

## 5.2 PRESETTING AND ADJUSTMENT BEFORE TEST RUN (Cont'd)

Table 9 Notch Selection of Electronic Thermal Overload Protective Switch  
(Use of Standard Motor)

VS-616 H II Model CIMR-	kVA	Max Motor Output kW (Hp)						
		11(15)	15(20)	18.5(25)	22(30)	30(40)	37(50)	45(60)
11 B	15	⑥	—	—	—	—	—	—
15 B	20	③	⑥	—	—	—	—	—
18.5 B	25	①	③	⑥	—	—	—	—
22 B	30	—	①	③	—	—	—	—
30 B	40	—	—	①	③	—	—	—
37 B	50	—	—	—	①	③	—	—
45 B	60	—	—	—	—	①	③	—

 Shaded areas show factory-set notches.

Table 10 Notch Selection of Electronic Thermal Overload Protective Switch  
(Use of VS-616 H II Motor)

VS-616 H II Model CIMR-	kVA	Max Motor Output kW (Hp)						
		11(15)	15(20)	18.5(25)	22(30)	30(40)	37(50)	45(60)
11 B	15	⑨	—	—	—	—	—	—
15 B	20	③	⑨	—	—	—	—	—
18.5 B	25	⑤	③	⑨	—	—	—	—
22 B	30	—	⑤	③	⑨	—	—	—
30 B	40	—	—	⑤	③	⑨	—	—
37 B	50	—	—	—	⑤	③	⑨	—
45 B	60	—	—	—	—	⑤	③	⑨

### (5) Selection of inverter capacity (5S)

The switch 5S has been factory-set to agree with the inverter capacity as shown in Table 11.

Table 11 Inverter Capacity  
Selection

VS-616 H II Model CIMR-	kVA	5 S Notch
11 B	15	④
15 B	20	⑤
18.5 B	25	
22 B	30	⑥
30 B	40	⑦
37 B	50	
45 B	60	⑧

## (6) Selection of operation modes (6S)

Select the operation modes from Table 12 according to the application, and set the switch (6S) as appropriate. All notches have been factory-set to OFF (OFF).

Table 12 Selection of Operation Modes


6S Notch	Function	ON/OFF Setting	Description of Operation Mode
①	Dynamic Braking (DB)	OFF	The motor is decelerated until it reaches 1/40 rated speed with the frequency reduced, and DB operation is performed at the speeds less than 1/40 rating.
		ON	The motor is decelerated until it reaches 1/40 rated speed with the frequency reduced, and is coasting to a stop.
②	Stopping	OFF	The motor stops in the mode set by notch ① of 6S when a STOP command is input.
		ON	The motor is coasting to a stop when a STOP command is input ignoring 6S setting of notch ①.
③	Stall Prevention during Deceleration	OFF	Too high load $GD^2$ during deceleration activates stall prevention function and extends the set decel time.
		ON	Stall prevention function during deceleration not provided.
④	Stopping Free-run Motor	OFF	DB operation is not applied at the start.
		ON	Motor starts after DB operation is applied. (DB operation within 1/5 decel time)
⑤	Operation Continuation at Momentary Power Failure	OFF	Motor coasts to a stop at momentary power failure.
		ON	Motor resumes running after momentary power failure of approximately 2 seconds or less; it coasts to a stop more than 2 seconds of momentary power failure.
⑥	Operation Continuation after Momentary Power Failure* (When notch ⑤ of 6S is ON)	OFF	Restarts operation after motor residual voltage is reduced upon recovery from momentary power failure.
		ON	Immediately restarts operation upon recovery from momentary power failure†.
⑦	Jogging	OFF	Full-voltage operation is performed at 1/10 rated speed when jog command is input.
		ON	Frequency acceleration and deceleration is performed at 1/10 rated speed when jog command is input.
⑧	Main Circuit Magnetic Contactor† Interlock	OFF	For inverters rated 200 to 230 V.
		ON	For inverters rated 380 to 460 V.

\*Speed search function starts when motor speed is decreased due to momentary power failure and load current.

† OC (overvoltage) protective circuit may be activated according to power recovery timing and load conditions. AC reactor should be connected or an inverter one size larger than specified should be selected.

## 5.2 PRESETTING AND ADJUSTMENT BEFORE TEST RUN (Cont'd)


Fig. 11 ON/OFF Switches of 6S (1 to 8)



### (7) Selection of master frequency reference signal

When the frequency reference signal is input from input terminal ⑨, select either a current signal (4 to 20mA) or a voltage signal (0 to 10V) (Fig. 12). The voltage reference signal (V) is factory-selected.

Fig. 12 Master Frequency Reference Signal Selection




### (8) Selection of auxiliary frequency reference signal

When the Analog operator (optional) is not used, input terminal ⑳ can be used for frequency setting. The auxiliary frequency reference signal selector shunt must be set as illustrated in Fig. 13.

The shunt is factory-set to (L) for use with Analog operator, and to (R) for other applications.


Fig. 13 Auxiliary Frequency Reference Signal Selection



(9) Radio noise reducing filter selection

Radio noise reducing filter is incorporated. If ground fault breaker trips, remove the short-circuit lead across terminals (E<sub>N</sub>) and (E).

Ground circuit is disconnected and erroneous operation is prevented.



5.3 TRIAL OPERATION/TEST RUN

Whenever possible, uncouple the motor from the driven machine. If the motor must be rotated with the driven machine connected, make sure that all dangerous conditions have been eliminated.

Fig. 14 shows the run-stop time chart when notches ① and ② of operation mode setting switch 6S are set to OFF.

Test run procedure is given in three ways (use of Analog operator, Digital operator, and VS operator). If any fault occurs, isolate the trouble spot, referring to par. 9 Troubleshooting.




Fig. 14 Run and Stop Time Chart

### 5.3.1 USE OF ANALOG OPERATOR MODEL JVOP-72 (Optional)

1. Set the AUTO/MAN switch to MAN, move the FWD/REV switch to FWD, and turn the FREQ SET potentiometer fully counterclockwise to LOW.
2. Turn on the VS-616HII AC main circuit power (circuit breaker). The STOP lamp (orange) lights.
3. Move the RUN/STOP switch to RUN with the FREQ SET potentiometer at LOW. It causes the RUN lamp (green) to light.
4. Slowly turning the FREQ SET potentiometer clockwise starts running the motor, with the frequency meter reading the output frequency. Make sure that the motor is running forward. If shaft rotation is incorrect, turn off AC main circuit power, and reverse any two of motor leads (U(T1), V(T2), W(T3)).
5. By turning the FREQ SET potentiometer slowly clockwise or counterclockwise, the motor accelerates or decelerates smoothly. Set the maximum motor speed by turning the FREQ SET potentiometer fully clockwise to HIGH and check the motor for normal running. After this check, return the FREQ SET potentiometer fully counterclockwise to LOW.
6. To stop the motor, set the RUN/STOP switch to STOP, and the STOP lamp comes on.

#### PRESET START

To make the preset start (a "one-touch" operation at a preset frequency), use steps 1 to 2 mentioned above and then proceed as follows.

(a) Set the frequency using frequency setting potentiometer. Move the RUN/STOP switch to RUN, and the motor accelerates within the time set in para. 5.2 (2) on page 17, then keeps on running at the preset frequency. If the motor does not run smoothly during acceleration (with the acceleration stall prevention function working), or if any FAULT lamp comes on, the acceleration time is assumed to have been set too short for the load level; extend the acceleration time.

(b) Set the RUN/STOP switch to STOP to stop the motor.

The motor decelerates in the time set in para. 5.2 (2) on page 17, then stops. If the motor does not run smoothly during deceleration function working), or if any failure indicator comes on, the deceleration time is assumed to have been set too short for the load level; increase the deceleration time.




Fig. 15 Analog Operator (Optional)

### 5.3.2 USE OF DIGITAL OPERATOR MODEL JVOP-71 (Optional) (Fig. 16)

1. Turn on the VS-616HII AC main circuit power (circuit breaker). Then "AUTO," "MONI," "0.0Hz," "STOP," and "FWD" are shown on the Digital operator display.
2. Display "MAN" by pressing 

AUTO
MAN

 key.
3. Make sure that "FWD" is displayed.  
If "REV" is displayed, press 

FWD
REV

 key to display "FWD."
4. Confirm that the motor runs forward slowly while 

JOG
-----

 key is being pressed. If shaft rotation is incorrect, turn off AC main circuit power, and reverse any two of motor leads. (The jog operation mode outlined in para. 5.2 (6) on page 19 is selected.)
5. Display "REV" by pressing 

FWD
REV

 key again, and make sure that the motor runs in reverse direction with JOG key pressed.
6. Pressing 

DISP
------

 key changes "MONI" to "SET," placing the operator in the setting mode. Select a digit to be set by operating 

◀
---

 or 

▶
---

 key. It is indicated by blinking. Pressing 

◀
---

 key moves blinking one space to the left, and 

▶
---

 key one space to the right. Set the required frequency by operating 

▲
---

 or 

▼
---

 . Pressing 

▲
---

 key increases the blinking value by one, and 

▼
---

 key decreases by one. After finishing the setting, press 

ENTER
-------

 key.
7. Pressing 

RUN
-----

 key displays "RUN." The motor then accelerates within the preset acceleration time and keeps on running at the frequency set in step 6.
8. To display the output frequency, press 

DISP
------

 key again. "SET" changes to "MONI," and the output frequency appears.
9. Pressing 

STOP
------

 key switches "RUN" to "STOP." The motor then decelerates within the preset deceleration time and stops.




Fig 16 Digital Operator (Optional)

### 5.3.3 USE OF VS OPERATOR MODEL JVOP-65· (Optional) (Fig. 17)

Complete the connection of units according to example in Fig. 7, on page 11 and perform the test run using the following procedures.

1. Set the MASTER/AUX switch to MASTER, move the FWD/REV switch to FWD, and turn the FREQ SET potentiometer fully counterclockwise to LOW.
2. Turn on the VS-616HII AC main circuit power (circuit breaker), and the SOURCE lamp (green) will light.
3. Change the RUN/STOP switch to RUN with the FREQ SET potentiometer at LOW, and RUN lamp (green) will light.
4. Slowly turning the FREQ SET potentiometer clockwise causes the motor to start running and the frequency meter to indicate the output frequency. Make sure that the motor is running forward. If shaft rotation is incorrect, turn off AC main circuit power, and reverse any two of motor leads  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ ,  $\text{W}(\text{T3})$ .
5. By turning the FREQ SET potentiometer clockwise or counterclockwise, the motor accelerates or decelerates smoothly. Also, set the maximum speed of the motor by turning the FREQ SET potentiometer fully clockwise to HIGH, and check the motor for normal running. After this check, return the FREQ SET potentiometer fully counterclockwise to LOW.
6. To stop the motor, set the RUN/STOP switch to STOP, and the RUN lamp goes out after the motor stops.

#### PRESET START

To make the preset start (a "one-touch" operation at a preset frequency), apply steps 1 to 2 mentioned above and then proceed as follows.

(a) Set the frequency using frequency setting potentiometer. Set the RUN/STOP switch to RUN, and the motor accelerates within the time set in para. 5.2 (2) on page 17, then keeps on running at the preset frequency. If the motor does not run smoothly during acceleration (with the acceleration stall prevention function working), or if a FAULT lamp comes on, the acceleration time is assumed to have been set too short for the load level; increase the acceleration time.

(b) To stop the motor, change the RUN/STOP switch to STOP. The motor decelerates within time set in para. 5.2 (2) on page 17, then stops. If the motor does not run smoothly during deceleration (with the deceleration stall prevention function working), or if a FAULT lamp comes on, the deceleration time is assumed to have been set too short for the load level; increase the deceleration time.




Fig. 17 VS Operator (Optional)



## 5.4 FREQUENCY METER CALIBRATION

When the Analog or VS operator is used, the frequency meter must be calibrated. The motor need not be run during calibration. Perform the following procedures:

1. Shut off the AC main circuit power.
2. Record the position (notch number) of setting switch 2S on the control PC board.
3. Set 2S to notch ⑥.
4. Turning on the main circuit power causes the meter to indicate approximately the rated frequency.
5. Adjust MTR CAL potentiometer of the Analog operator (or MTR ADJ potentiometer of the VS operator) so that the meter reads the rated frequency.
6. After the adjustment, turn off AC main circuit power again, then return setting switch 2S to the recorded position.

## 6. OPERATION AT LOAD

After the no-load operation, turn off the AC main circuit power, and connect the driven machine to the motor. Make sure that the driven machine is in running condition, and there is no danger around VS-616HI system, and run the motor under load in exactly the same way as for test run.

### PRECAUTION

- (1) Start the motor after making sure that the motor is stopped. If the operation is started during motor coasting, overvoltage (OV) or overcurrent (OC) protective circuit may be operated.
- (2) The motor can be operated by an operation signal from either the inverter-mounted operator or external terminal ②. This selection can be made only when the inverter is standby.
- (3) The motor can be stopped unconditionally by a STOP signal from either the inverter-mounted operator or external terminal ③. Either stop command takes priority over any other command in operation.
- (4) When a standard motor is driven with the inverter, there is a little increase in motor temperature, noise, and vibration as compared to the operation from the commercial power supply.
- (5) The motor cooling effect lowers during low-speed running. The torque needs to be reduced in accordance with the frequency. (For the reduction ratio, refer to the catalog or technical sheet.)
- (6) Even with small load, never use a motor whose current exceeds the inverter rating. When two or more motors are operated, check to be sure that the total motor current is not larger than inverter rating.
- (7) When starting and stopping the motor, be sure to use the operation signals (RUN and STOP), not the magnetic contactor on the power supply side. Exception: If the magnetic contactor is to be used to start and stop a motor, see A3-2, (5) on page 41. Care should be taken not to start and stop the motor frequently.

## 7. MAINTENANCE

VS-616HI requires almost no routine checks. It will function efficiently and longer if it is kept clean, cool and dry, observing precautions listed in 3.1 Location, on page 9. Especially check for tightness of electrical connections, discoloration or other signs of overheating. Use Table 13 as the inspection guide. Before servicing inspection, turn off AC main circuit power and be sure that CHARGE lamp is off.

Table 13 Periodical Inspection

Component	Check	Corrective Action
External terminals, unit mounting bolts, connectors, etc.	Loosened screws	Tighten
	Loosened connectors	Tighten
Cooling fins	Build-up of dust and dirt	Blow with a dry compressed air of 4 to 6 kg·cm <sup>2</sup> (57 to 85 lbs. in <sup>2</sup> ) pressure.
Printed circuit board	Accumulation of conductive dust and oil mist.	Clean the board. If dust and oil cannot be removed, replace the board.
	Discoloration to brown	Replace the board.
Cooling fan	For abnormal noise and vibration. Whether the cumulative operation time exceeds 20,000 hours or not.	Replace the cooling fan.
Power elements	Accumulation of dust and dirt	Blow with a dry compressed air of 4 to 6 kg·cm <sup>2</sup> (57 to 85 lbs. in <sup>2</sup> ) pressure.
Smoothing capacitor	Discoloration or odor	Replace the capacitor or inverter unit.

## 8. FAILURE INDICATION AND DETAILS

A failure, if it is detected, can shut off the output power transistor and output FAULT contact signals across control circuit terminals ⑭, ⑮, and ⑯.

When Analog or Digital operator is used, failure indications listed in Table 14 will function. When neither of them is used, failure conditions are shown by FAULT lamps F1 and F2 on the VS-616HII.

Table 14 Failure Indication

Indication	Symptom	VS 616 HII Operation
FU (Fuse Blown)	Main circuit fuse blown	Inverter stops output momentarily. (Motor is coasting)
OC (Overcurrent)	More than 200 percent of rated current flow in inverter output side. (Instantaneous operation)	
OL (Overload)	Overload of motor and inverter detected by electronic thermal.	
OV or OU <sup>††</sup> (Overvoltage)	Main circuit DC voltage higher than approx 395 V	
UV* or UU* <sup>†</sup> (Undervoltage)	Main circuit DC voltage lower than approx 210 V	
OH (Heat Sink Overheat)	Thermoswitch operated by overheat of heat sink of main circuit semiconductor	
EB or Eb <sup>†</sup> (External Failure)	Fault signal is input from external terminal ⑦	#
CPF	Steady (Major Control Function Error)	
	Blinks (Setting error)	Any one of setting switches (1 S to 6 S) changed with power ON

\*In operation continuation after a momentary power failure mode (⑤ notch of 6 S ON), UV lamp is flashing for approx two seconds

†For Digital operator display

††FAULT will be displayed with OU on the screen of Digital operator.

# Inverter continues operation. When the setting is returned to the state before change, the display replaces the normal operation status.

Table 15 Failure Indication of VS-616 HII

Indication		Cause	VS 616 HII Operation
F 1	F 2		
□	■ ■ ■	FU (Fuse Blown): Main circuit fuse blown	Inverter stops output momentarily (Motor is coasting.)
□	■ ■ ■	OC (Overcurrent). More than 200 percent of rated current flow in inverter output side	
□	■ ■ ■	OL (Overload): Overload of motor and inverter detected by electronic thermal overload protective circuit.	
■ ■ ■	■ ■ ■	OV (Overvoltage). DC bus voltage higher than 395V.	
■ ■ ■	■ ■ ■	UV 1 (Undervoltage) DC bus voltage lower than approx 210V. with 6S-⑤ set to ON (F1 blinking for 2 seconds UV 1 indication changed to UV 2)	
■ ■ ■	■ ■ ■	UV 2 (Undervoltage). DC bus voltage lower than 210V.	
■ ■ ■	□	OH (Heat Sink Overheat): Thermoswitch operated by overheat of heat sink of main circuit semiconductor.	
■ ■ ■	□	EB (External Failure). Fault signal is input from external terminal ⑦.	#
■ ■ ■	□	CPF (Control Function Error): Detection of the failure of CPU and main control function by self-diagnostic function	
■ ■ ■	■ ■ ■	CPF · SEL (Selection Error) Any one of setting switches (1 S to 6 S) changed with power ON.	

Note: Indication status is as follows

□ : Light OFF

■ ■ ■ : Blinking at equal intervals

■ ■ ■ : Blinking at short-long intervals.

■ ■ ■ : Light ON

# Inverter continues operation. When the setting is returned to the state before change, the display replaces the normal operation status

## 9. TROUBLESHOOTING

If the VS-616HII malfunctions, find the cause and take the corrective action by following the flowcharts given in this section.














If the cause cannot still be located by the flowcharts, the inverter or some parts are damaged, or any other problem occurs, contact Yaskawa representative.

### 9.1 MEASURING POINT AND INSTRUMENT

Since the VS-616HII transistor inverters utilize the PWM control mode, unless specified instruments are used, correct measurement cannot be made.

The measuring points and the measuring instruments are shown in Fig. 18 on page 29 and Table 16.

Table 16 Measuring Points and Instruments

Item	Points	Instrument	Note
Supply Voltage $V_1$	Across R-S(L1-L2), S-T(L2-L3) T-R(L3-L1)  ( $V_{L1-L2}$ , $V_{L2-L3}$ , $V_{L3-L1}$ )	 Moving-iron type, or rectifier type voltmeter	—
Power Supply Current $I_1$	Line current R, S, T(L1, L2, L3)  ( $A_{L1}$ , $A_{L2}$ , $A_{L3}$ )	 Moving-iron type	—
Power Supply Power* $P_1$	R, S, T(L1, L2, L3) and across R-S(L1-L2), S-T(L2-L3) T-R(L3-L1)  ( $W_{L1}$ , $W_{L2}$ , $W_{L3}$ )	 Electrodynamometer type; Use 3 identical single-phase meters.	$F_1 = W_R + W_S + W_T$
Power Supply Power Factor $Pf_1$	Calculate from measured supply voltage, supply current, and supply power. $Pf_1 = \frac{P_1}{\sqrt{3}V_1I_1} \times 100(\%)$		
Output Voltage $V_2$	Across U-V(T1-T2), V-W(T2-T3), W-U(T3-T1)  ( $V_{T1-T2}$ , $V_{T2-T3}$ , $V_{T3-T1}$ )	 Rectifier type (YOKOGAWA 2017 or equivalent) Moving-iron type can not be used.	1000 V full scale for 400 V circuit.
Output Current $I_2$	Line current at U, V, W(T1, T2, T3)  ( $A_{T1}$ , $A_{T2}$ , $A_{T3}$ )	 Moving-iron type	—
Output Current $P_2$	U, V, W(T1, T2, T3) and across U-V(T1-T2), V-W(T2-T3), W-U(T3-T1)  ( $W_{T1}$ , $W_{T2}$ , $W_{T3}$ )	 Electrodynamometer type, Three identical rating single-phase meters are used.	$P_2 = W_u + W_v + W_w$
Output Power Factor $Pf_2$	Calculated same as power factor on supply side. $Pf_2 = \frac{P_2}{\sqrt{3}V_2I_2} \times 100(\%)$		
Frequency Setting Signal	Across ①-⑩ Across ⑪-⑫	 Moving-coil type (Multimeter is OK) (Internal resistance: 50 kΩ max)	0 to 10 V DC
Frequency Monitor	Across ⑬-⑭		10 VDC at max frequency (Without frequency meter)

\*To measure the power, use the power meter incorporating a hall generator:  
HIOKI TYPE 3161 Power meter (made by HIOKI Electric, Japan).

The output voltage  $\text{U}(\text{T1})$ ,  $\text{V}(\text{T2})$ ,  $\text{W}(\text{T3})$  has been measured with a YOKOGAWA 2017 (rectifier type) voltmeter before shipping.

Fig. 19 on page 29 shows an example of actually measured output voltage. The rectifier type instruments give different readings, depending on type.




Fig. 18 Points for Measurement






Fig. 19 Output Voltage Measurement

## 9. 2 TROUBLESHOOTING FOR MOTOR SYMPTOM

### (1) Motor will not run.


For operation from external command through external terminals (Digital or Analog operator not used)




Continued to A on page 30

## 9.2 TROUBLESHOOTING FOR MOTOR SYMPTOM (Cont'd)

Continued from (A) on page 29



### (2) Motor stalls during acceleration




### 9.3 TROUBLESHOOTING FOR FAILURE INDICATIONS

When the inverter protective function works, the malfunctions are detected by failure indicators. The predictable symptoms are as follows:

- (1) Fuse blown
- (2) Overvoltage of the main circuit DC bus.
- (3) Overcurrents in load.
- (4) Overloaded operation.
- (5) Undervoltage of the main circuit DC bus.
- (6) The inverter overheated.
- (7) The control function went down.
- (8) A fault signal input.


(1) Fuse blow (FU) is turned on:

When the fuse blows, be sure to check the power transistor, even when the cause is on the load side.




### 9.3 TROUBLESHOOTING FOR FAILURE INDICATIONS (Cont'd)

#### (2) Overvoltage (OV) indication




#### (3) Overcurrent (OC) indication







#### (4) Overload (OL) indication




## (5) Undervoltage (UV) indication




## (6) Inverter overheat (OH) indication



(7) CPF indication



(8) EB Indication




# APPENDIX 1 VS-616 H II RATINGS AND SPECIFICATIONS

Table 17 VS-616 H II Ratings and Specifications


Inverter Model CIMR-		11 B	15 B	18.5 B	22 B	30 B	37 B	45 B
Output Characteristics	Max Applicable Motor Output* kW(HP)	11 (15)	15 (20)	18.5 (25)	22 (30)	30 (40)	37 (50)	45 (60)
	Inverter Capacity kVA	15	20	25	30	40	50	60
	Rated Output Current A	45	60	75	90	120	150	180
	Max Continuous Output Current A	50	66	83	100	130	165	200
	Variable Torque Rated Output Current A	50	69	86.3	104	138	173	207
	Rated Output Voltage	3-Phase, 200/208/220/230 VAC						
	Rated Output Frequency	50, 60, 72, 90, 120, 180 Hz (240, 360 Hz available as an option)						
Power Supply	Rated Input Voltage and Frequency	3-Phase, 200/208/220 V, 50 Hz, 200/208/220/230 V, 60 Hz						
	Allowable Voltage Fluctuation	Within $\pm 10\%$						
	Allowable Frequency Fluctuation	Within $\pm 5\%$						
Control Characteristics	Control Method	Sine wave PWM						
	Frequency Control Range	40:1						
	Frequency Accuracy	Digital command: 0.01%(-10 to 40°C), Analog command: 0.2%(25°C $\pm$ 10°C)						
	Frequency Resolution	Digital reference, with Digital operator, 0.1 Hz, with Precision controller, 0.004 Hz/60 Hz Analog reference, with Analog operator, 0.06 Hz/60 Hz, with High-precision AD converter, 0.004 Hz/60 Hz						
	Overload Capacity	150% for one minute						
	Frequency Setting Signal	0 to 10 VDC, 4-20 mA(500 $\Omega$ )						
	Accel/Decel Time	0.1 to 1800 sec, 6 ranges selectable, Accel/Decel time set independently						
	Efficiency	Approx 95%						
	Braking Torque	Approx. 20% (100%, provided with braking unit and braking resistor unit: 10% duty cycle)						
	No. of V/f Patterns	15 in total. 4: For general purpose; 4: For high starting torque; 4: For fans and pumps; 3: For machine tools.						
Protective Functions	Motor Overload Protection	Electronic thermal relay (4)						
	Instantaneous Overcurrent	Base blocked at approx 200% rated current						
	Overload	Base blocked at 150% load for 1 minute						
	Overvoltage	Base blocked if converter output voltage exceeds 395 V						
	Undervoltage	Base blocked if converter output voltage drops to 210 V or below						
	Momentary Power Failure	Immediately stop by momentary power failure detection. (Continues system operation during power failure less than 2 sec by setting on notch ⑤ of 6 S switch.)						
	Fin Overheat	Thermostat (trips at fin temperature of approx 90°C)						
	Stall Prevention	Stall prevention at acceleration/deceleration and constant-speed operation						
	Ground Fault	Electronic circuit						
	Power Charge Indication	Charge lamp keeps ON until converter output voltage drops below 50 V.						
Environmental Condition	Location	Indoor (protected from corrosive gases and dust)						
	Ambient Temperature	-10 to 40°C (not frozen) (5)						
	Storage Temperature	-20 to 60°C (6)						
	Humidity	90% RH (no condensation)						
	Vibration	1G less than 20 Hz, up to 0.2G at 20 to 50 Hz						
Approx Weight kg(lbs.)		20 (44.09)	30 (66.14)	60 (132.28)				
Dimensions mm (in.)	Width	250 (9.84)	325 (12.80)	475 (18.70)				
	Height	500 (19.69)	550 (21.65)	800 (31.45)				
	Depth	255 (10.04)	255 (10.04)	280 (11.02)				

- (1) For standard motors rated 4 poles at 60 Hz
- (2) Parenthesized values indicate max continuous output capacity
- (3) Parenthesized values indicate max continuous output current
- (4) Protects motors having the torque characteristics shown below

- (5) Up to 50°C when built-in a panel, with front cover removed
- (6) Temperature during shipping. Storing in this temperature for a long period may deteriorate main circuit capacitor, contact your Yaskawa representative



General-purpose Motors



Inverter Motors

## APPENDIX 2 TERMINAL FUNCTIONS

Table 18 Terminal Functions and Voltages of Main Circuit

Terminals	Functions	Levels
R(L1) S(L2) T(L3)	Main circuit input power supply	Three-phase 200/208/220 VAC, 50 Hz; 200/208/220/230 VAC, 60 Hz (Voltage fluctuation $\pm 10\%$ )
r(l1) s(l2)	Cooling fan input power supply	
U(T1) V(T2) W(T3)	VS-616 H II output	Three-phase 200/208/220/230 VAC (corresponding to input voltage)
P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub> N	Main circuit DC power supply	Approx 300 VDC (across the terminals (P <sub>1</sub> ), (P <sub>2</sub> ), (P <sub>3</sub> )-(N))
E	Ground terminal	—

Table 19 Terminal Functions and Signals of Control Circuit

Terminals	Functions	Levels
1	Sequence control input common terminal	Sequence control input 0V
2	Run signal	Run at closed*
3	Stop signal	Stop at open†
4	Connection to shield sheath of signal lead	—
5	Forward / Reverse operation selector.	Forward at open†, Reverse at closed*
6	Master / Aux frequency reference selector	Master speed at open†, Aux at closed
7	External fault input	Fault at closed†
8	Fault reset input (external)	Fault reset at closed*
9	Master speed frequency reference input	0 to +10 V or 4–20mA(500 $\Omega$ )
10		0 V
11	Connection to shield sheath of signal lead	—
12	Run contact output‡ (1NC)	Open† during run
13		Common
14		Closed* at fault
15	Fault contact output (1NONC)	Open† at fault
16		Common
17	Frequency meter input	Approx +10V/100%, output impedance 3k $\Omega$
18		0
19	Connection to shield sheath of signal lead	—
20	Aux frequency input	+15V (VS-616HII internal power supply)
21		+10V/100%
22		0 V

\* Short-circuited with terminal ①


† Opening terminal

‡ Used as a zero-interlock contact. With notches ① and ② of operation mode selector switch 6S set OFF, RUN contact is on at RUN command and off after DB operation at STOP command.

# APPENDIX 3 INTERNAL CIRCUIT AND INTERCONNECTION DIAGRAMS

VS-616HII used in the internal circuit and interconnection diagrams is of Model CIMR-45B, 200-230V, 60kVA.

## A3-1 VS-616 HII INTERNAL CIRCUIT



## A3-2 INTERCONNECTION DIAGRAMS FOR VS-616 H II APPLICATIONS

### (1) WITH ANALOG OPERATOR




Fig. 21 With Analog Operator

### (2) WITH DIGITAL OPERATOR





Fig. 22 With Digital Operator

# A3-2 INTERCONNECTION DIAGRAMS FOR VS-616 HII APPLICATIONS (Cont'd)

## (3) WITH VS OPERATOR



Note:


1. To give frequency reference from VS operator, set the VS operator MASTER/AUX switch to MASTER.
2. Remove the short-circuit leads across ① and ③.

Fig. 23 With VS Operator



(4) WITH USER-ARRANGED OPERATION CIRCUIT


POWER SUPPLY, 3-PHASE  
200/208/220 VAC, 50 Hz  
200/208/220/230 VAC, 60Hz



- Note:
1. Remove the short-circuit lead across external terminals ① and ③.
  2. Use RUN terminal ② to stop or start the motor.

Fig. 24 With User-Arranged Operation Circuit


\*Start and Stop commanded by a Single Contact.



### A3-2 INTERCONNECTION DIAGRAMS FOR VS-616 H II APPLICATIONS (Cont'd)

#### (5) WITH MAGNETIC CONTACTOR FOR START/STOP OPERATION

Before turning on power, never fail to be sure the motor is at rest. For frequent start/stop operations, this drive circuit is not recommended.



Note: Remove the short-circuit lead across external terminals ① and ③.

Fig. 25 With Magnetic Contactor for Start/Stop Operation

(6) WITH VS OPERATOR AND ANALOG OPERATOR




Fig. 26 With VS Operator and Analog Operator

Note:

1. To give the frequency reference from VS operator, change the Analog operator AUTO/MAN switch to AUTO, and VS operator MASTER/AUX switch to MASTER.
2. To give the frequency reference from Analog operator, set the AUTO/MAN switch to MAN.
3. Use of Analog operator does not permit the use of auxiliary frequency reference terminal ②.
4. Stop operation can be made by either VS operator or Analog operator. Stop command Either stop command takes priority over any command.
5. Disconnect the short-circuited terminals ① and ③.

# A3-2 INTERCONNECTION DIAGRAMS FOR VS-616 H II APPLICATIONS (Cont'd)

## (7) WITH VS OPERATOR AND DIGITAL OPERATOR




Fig. 27 With VS Operator and Digital Operator

(8) WITH BRAKING MODULES AND BRAKING RESISTOR UNIT




Fig. 28 With Braking Module and Braking Resistor Unit

### A3-2 INTERCONNECTION DIAGRAMS FOR VS-616 H II APPLICATIONS (Cont'd)

#### (9) WITH TRANSISTOR (OPEN-COLLECTOR) FOR START/STOP OPERATION

To input start/stop signals by relay contacts or transistor (open collector), use the following elements:

- Relay contact:  
Contact capacity — 30 VDC or above  
Rated current — 100 mA or above
- Transistor (open collector):  
Withstand voltage — 35 VDC or above  
Rated current — 100 mA or above




Fig. 29 With Transistor (Open-Collector) for Start/Stop Operation

# APPENDIX 4 VS-616 HII OPTIONAL AND AUXILIARY UNITS

## A4-1 VS-616 HII OPTIONAL UNITS

Table 20 VS-616 HII Optional Units

Name	Model	Code No.	Functions
Digital Operator	JVOP-71	73041-0701 X	Mounted on the inverter. Issues operation commands, sets the frequency by the digital signal, and displays the preset or current frequency in digital form. Also, displays the type of fault in characters when a failure occurs.
Analog Operator	JVOP-72· *	73041-0702 X- *	Mounted on the inverter. Gives operation commands, sets the frequency by the analog signal, and indicates the current frequency on the frequency meter.
VS Operator	JVOP-65· *	73041-0703 X- *	Used for remote operation. Outputs operation commands, sets the frequency by analog commands, and indicates the current frequency on the frequency meter.
Braking Unit	CDBR-15 H	EUJ 00648 X	If the main circuit DC voltage exceeds a specified level during motor regeneration, causes the braking resistor to absorb regeneration energy.
	CDBR-22 H	EUJ 00649 X	
Braking Resistor Unit	LKEB-4.8 B	EUX 00191 X	Absorbs regeneration energy of the motor, enhancing the inverter braking capability.
	LKEB-9 B	EUX 00192 X	

\*Code No. and model name suffixes indicate the type of frequency meter as shown below.

### ·Analog Operator

Model JVOP-72·      Code No. 73041-0702X-

Frequency Meter Max Scale (Double Scale)	60/120 Hz	1	01
	72 Hz	4	04
	90/180 Hz	5	05
	240 Hz	8	08
	360 Hz	9	09

### ·VS Operator

Model JVOP-65·      Code No. 73041-0703X-

Frequency Meter Max Scale	75Hz	1	01
	150Hz	2	02
	220Hz	3	03

## A4-2 VS-616 HII AUXILIARY UNITS

Table 21 VS-616 HII Auxiliary Units

Name	Function
Main Circuit Magnetic Contactor Model HI-	Switches on and off the main circuit, and interlocks the circuit if a failure occurs.
Molded-case Circuit Breaker (MCCB)	Protects the main circuit wiring and inverter from damage caused by short-circuit current.
AC Reactor	Improves the high-frequency content of the power or prevents mutual interference due to voltage waveform distortion when connected to the power side. Beters the current waveform, lowers noise, and increases the motor torque when connected to the output of the inverter.
Noise Filter Model LF-	<ul style="list-style-type: none"> <li>• Suppresses transmission of high-frequency noise produced by the inverter to the power side (input noise filter).</li> <li>• Suppresses transmission of high-frequency noise produced by the inverter to the motor (output noise filter).</li> </ul>
Thermal Overload Relay	Protects the motors from burning when two or more motors are operated by one inverter.
Ground Fault Interrupter	Detects degradation in main circuit insulation, and shuts off the main circuit. (Set the Setting to 200 mA, and the operating time to 0.2 sec or more.)
Surge Absorber	Prevents problems due to noise when connected coils of relays, magnetic contactors, magnetic valves, or magnetic brakes, and so on (DCR2-50 A 22 E or DCR2-10 A 25 C). (If power waveform distortion is serious, contact YASKAWA representative.)
Frequency Setting Potentiometer	Variable resistor used to set the analog frequency. (2 k $\Omega$ , 0.5W or more).
Frequency Meter Calibration Potentiometer	Calibrates the maximum indication value of the frequency meter. (10 k $\Omega$ , 0.25 W or more).
Frequency Meter	Indicates the output frequency of the inverter. (3V, 1mA at full scale).

Table 22 Devices of VS Operator Model JVOP-65-□

Device	Model	Specifications	Part Code	
Frequency Meter	DCF-6	3V, 1mA	75 Hz at full scale	FM 000067
			150 Hz at full scale	FM 000069
			220 Hz at full scale	FM 000072
Frequency Setting Potentiometer	RV30YN 20S-HV	2 k $\Omega$ , 1W	RH 000649	





# APPENDIX 5 CHECKING OF DIODE AND TRANSISTOR MODULES

## A5-1 DIODE MODULE

Measure the resistance across the module terminals with a volt-ohm meter. Use the meter by setting at  $\times 1\Omega$  range. The measured resistance should be within the reference value listed in Table 23.

Table 23 Diode Module Resistances

Diode Module Terminals	Volt-ohm Meter Terminals		Reference Resistances	Abnormal Resistances
	$\ominus$	$\oplus$		
Model CIMR-11 B 	$\ominus$	$\ominus$	$\infty$	Approx several 10 ohms
	$\oplus$	$\ominus$		
	$\ominus$	$\ominus$	Approx several 10 ohms	$\infty$ or $0\Omega$
	$\ominus$	$\oplus$		
Model CIMR-15 B, to -45 B 	$\ominus$	$\ominus$	$\infty$	Approx several 10 ohms
	$\oplus$	$\ominus$		
	$\ominus$	$\ominus$	Approx several 10 ohms	$\infty$ or $0\Omega$
	$\ominus$	$\oplus$		

## A5-2 TRANSISTOR MODULE

Measure the resistance across the module terminals with a volt-ohm meter. Use the meter by setting at  $\times 1\Omega$  range. The measured resistance should be within the reference value listed in Tables 24 and 25.

Table 24 Transistor Module Resistances of Model CIMR-11 B



Transistor Module Terminals		Reference Resistances	Abnormal Resistances	Transistor Module Terminals
VOM Terminal $\ominus$	VOM Terminal $\oplus$			
$E_1$ $C_2$	$C_1$	Approx several 10 ohms	$0\Omega$ or $\infty$	
$C_1$	$E_1$ $C_2$	Approx several 100 kilohms	$0\Omega$	
$B_1$	$E_1$ $C_2$	Approx several 10 ohms	Approx several 10 kilohms or above	
$E_1$ $C_2$	$B_1$	Approx several 100 ohms to several kilohms	$0\Omega$ or $\infty$	
$E_2$	$E_1$ $C_2$	Approx several 10 ohms	$0\Omega$ or $\infty$	
$E_1$ $C_2$	$E_2$	Approx several 100 kilohms	$0\Omega$	
$B_2$	$E_2$	Approx several 10 ohms	Approx several 10 kilohms or above	
$E_2$	$B_2$	Approx several 100 ohms to several kilohms	$0\Omega$ or $\infty$	

Table 25 Transistor Module Resistances of Model CIMR-15 and -45 B

Transistor Module Terminals		Reference Resistances	Abnormal Resistances	Transistor Module Terminals
VOM Terminal $\ominus$	VOM Terminal $\oplus$			
E	C	Several 10 ohms max	$0\Omega$ or $\infty$	
C	E	Several 100 kilohms min	$0\Omega$	
B ( $B_1$ )	E	Several 10 ohms	Several kilohms	
E	B ( $B_1$ )	Several 10 ohms	$0\Omega$ or $\infty$	

## APPENDIX 6 PARTS REPLACEMENT

For checking or replacing parts, observe the following.

- Tag leads to insure correct reconnection before disconnecting the leads without marks.
- Tighten the parts mounting screws or lead terminal screws firmly. Even one loose screw may cause malfunction.

### A6-1 REPLACEMENT OF CONTROL PC BOARD

1. Remove the connectors 1CN, 5CN, 6CN, and 7CN by the lead lock. To remove the lead lock, press the top of the locking clip to release from the header and pull out.
2. Remove the connector 3CN. Open the lock lever, and the connector is released.




Fig. 30 Control PC Board

3. Remove 4 screws (a) and a ground lead screw (b) to remove the control PC board.
4. Take off the control printed PC board.

### A6-2 REPLACEMENT OF BASE DRIVE PC BOARD

1. Pull out the connectors 1CN to 5CN and 7CN to 15CN.
2. Remove six mounting screws (a) and a ground lead screw (b).
3. Remove the base drive PC board with shield plate.




Fig. 31 Base Drive PC Board


## A6-3 REPLACEMENT OF DIODE MODULE AND TRANSISTOR MODULE

### CAUTION

When remounting transistor or diode modules, apply thermal compound "JOINTAL Z" (Nippon Light Metal Co., Ltd.), or equivalent compound to the mounting surface, to assure good contact and heat conduction between the module and the mounting surface for cooling.

### DIODE MODULE REMOVAL


1. Remove the bus bar mounting screws.
2. Remove diode module lead terminal screws.
3. Remove diode module mounting screws.
4. Remove the modules.



685-209 Fig. 32 Removing Diode Module

### TRANSISTOR MODULE REMOVAL

1. Remove the bus bar mounting screws.
2. Remove transistor module mounting screws.
3. Remove the modules.



685-209 Fig 33 Removing Transistor Module of Model CIMR-18.5, 200 V, 25 kVA

#### A6-4 MAIN CIRCUIT FUSE REMOVAL

Remove main circuit fuse mounting screws and replace the blown fuse.




Fig. 34 Removing Main Circuit Fuse of Model CIMR-37 B, 200 V, 50 kVA

#### A6-5 REPLACEMENT OF COOLING FAN

Replace the fan after approximately 20,000 hours of cumulative operation.

1. After removing the control PC and base drive PC boards as outlined in para. A6-1 and A6-2, remove two fan power leads.
2. Loosen four fan mounting screws and take off the fan unit.




Fig. 35 Cooling Fan Assembly of Model CIMR-18.5B, 200 V, 25 kVA

## APPENDIX 7 SPARE PARTS

As insurance against costly downtime, it is strongly recommended that spare parts to be kept on hand in accordance with the table below. When ordering spare parts, please specify to Yaskawa Electric office or representative; Parts Name, Parts Code No. and Quantity.

Table 26 Spare Parts

Parts Name		Main Circuit Transistor†	Main Circuit Diode	Main Circuit Fuse	Base Drive PC Board	Control PC Board*†	Cooling Fan	
VS-616 H II Model CIMR	-11 B	Model	MG150H2CL1	100 L 6P 41	CR 2 L-75	JPAC-C 247	4715 PS-22T -B30-B00	
		Code	STR000216	SID 000291	FU 000747	ETC 00776 X	ETC00760 X -S XX	FAN000130
		Q' ty	3	1	1	1	1	1
	-15 B	Model	MG200H1AL2	RM 60 DZ-H	CR 2 L-100	JPAC-C 250	JPAC-C 231	4715 PS-22T -B30-B00
		Code	STR000159	SID 000303	FU 000748	ETC 00779 X	ETC00760 X -S XX	FAN000130
		Q' ty	6	3	1	1	1	1
	-18.5 B	Model	QM 300 HA-H	RM 60 DZ-H	CR 2 L-125	JPAC-C 250	JPAC-C 231	5915 PC-22T -B30-B00
		Code	STR000173	SID 000303	FU 000749	ETC 00779 X	ETC00760 X -S XX	FAN000131
		Q' ty	6	3	1	1	1	1
	-22 B	Model	QM 300 HA-H	RM 60 DZ-H	CR 2 L-150	JPAC-C 250	JPAC-C 231	5915 PC-22T -B30-B00
		Code	STR000173	SID 000303	FU 000750	ETC 00779 X	ETC00760 X -S XX	FAN000131
		Q' ty	6	3	1	1	1	1
	-30 B	Model	MG200H1FL1	RM 100 DZ-H	CR 2 L-200	JPAC-C 253	JPAC-C 231	5915 PC-22T -B30-B00
		Code	STR000156	SID 000332	FU 000751	ETC 00782 X	ETC00760 X -S XX	FAN000131
		Q' ty	12	3	1	1	1	2
	-37 B	Model	QM 300 HA-H	RM 100 DZ-H	CR 2 L-260	JPAC-C 253	JPAC-C 231	5915 PC-22T -B30-B00
		Code	STR000157	SID 000332	FU 000752	ETC 00782 X	ETC00760 X -S XX	FAN000131
		Q' ty	12	6	1	1	1	2
	-45 B	Model	QM 300 HA-H	RM 100 DZ-H	CR 2 L-300	JPAC-C 253	JPAC-C 231	5915 PC-22T -B30-B00
		Code	STR000157	SID 000332	FU 000753	ETC 00782 X	ETC00760 X -S XX	FAN000131
		Q' ty	12	6	1	1	1	2

\* of the control PC board model name shows the type of function.

† Spare board should have the same model name suffix as that of the board in use.

†XX of Code No. for the control PC board indicates the revision number of the control PC board.

New board should have the same code suffix number or larger than that of the board being replaced.


A pair of spare transistor modules should have the same number or letter of characteristics rank which is stamped on the module surface.

† Transistor modules of Models CIMR-30 B to -45 B are connected in parallel, in pairs.

Characteristics of each pair of modules are controlled by block of 1 and 11 TRM, 2 and 12 TRM, 3 and 13 TRM, 4 and 14 TRM, 5 and 15 TRM, and 6 and 16 TRM.

Model	Characteristics Rank
CIMR-30 B	1, 2, 3
CIMR-37 B, CIMR-45 B	C, D, E

CHARACTERISTICS  
RANK



(QM 300 HA-H)

CHARACTERISTICS  
RANK



(MG 200 H1 FL.1)

Transistor Modules.

TRANSISTOR INVERTER

**Varispeed™ 616H II**

200 TO 230V 11 TO 45kW (15 TO 60HP) 15 TO 60kVA



*A Better Tomorrow for Industry through Automation*

**YASKAWA Electric Mfg. Co., Ltd.**

**TOKYO OFFICE** Ohtemachi Bldg., 1-6-1 Ohtemachi, Chiyoda-ku, Tokyo, 100 Japan  
Phone (03) 3284-9111, -9145 Telex YASKAWA J33530 Fax (03) 3284-9034

**SEOUL OFFICE** Seoul Center Bldg., 91-1, So Kong-Dong, Chung-Ku, Seoul, Korea  
Phone (02) 776-7844 Fax (02) 753-2639

**SINGAPORE OFFICE** CPF Bldg., 79 Robinson Road No. 24-03, Singapore 0106  
Phone 2217530 Telex (87) 24890 YASKAWA RS Fax (65) 224-5854

**TAIPEI OFFICE** Union Commercial Bldg., 137, Nanking East Road, Sec. 2, Taipei, Taiwan  
Phone (02) 507-7065, -7732 Fax (02) 506-3837

**YASKAWA ELECTRIC AMERICA, INC.: SUBSIDIARY**

**Chicago Office (Head Office)** 3160 MacArthur Blvd., Northbrook, Illinois 60062-1917, U.S.A.  
Phone (708) 291-2340, 291-2348 Telex (230) 270197 YSKW YSNC NBRK Fax (708) 498-2430, 480-9731

**Los Angeles Office** 7341 Lincoln Way, Garden Grove, California 92641, U.S.A.  
Phone (714) 894-5911 Telex (230) 678396 YASKAWAUS TSTN Fax (714) 894-3258

**New Jersey Office** 30 Two Bridges Road, Fairfield, New Jersey 07006, U.S.A.  
Phone (201) 575-5940 Fax (201) 575-5947

**YASKAWA ELECTRIC EUROPE GmbH: SUBSIDIARY**

Niederh ochst adter Stra e 71-73, W 6242 Kronberg-Oberh ochstadt, Germany  
Phone (06173) 640071, 640072, 640073 Telex 415660 YASE D Fax (06173) 68421

**YASKAWA EL TRICO DO BRASIL COM RCIO LTDA.: SUBSIDIARY**

Av. Brig. Faria Lima, 1664-cj 721/724, Pinheiros, S o Paulo-SP, Brasil CEP-01452  
Phone (011) 813-3933, 813-3694 Telex (011) 82688 YSKW BR Fax (011) 815-8795

