

VARISPEED-676H5

INSTRUCTION MANUAL

INVERTER FOR SYSTEM DRIVES (VS-676H5)

MODEL: CIMR-H5[...]

200V CLASS 0.4 to 75kW (1.0 to 100kVA)

400V CLASS 0.4 to 300kW (1.0 to 400kVA)

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

REFERENCE

VARISPEED-676H5 DESCRIPTIVE MANUAL FOR CONSTANTS (TOEZ-S676-7.1)



YASKAWA

MANUAL NO. TOE-S676-7B



PREFACE

YASKAWA's VS-676H5 is an inverter for system drives provided with both V/f control and vector control for standard models. This instruction manual describes installation, maintenance and inspection, troubleshooting, and specifications of the VS-676H5. Read this instruction manual thoroughly before operation.

YASKAWA ELECTRIC CORPORATION

General Precautions

- Some drawings in this manual are shown with the protective cover or shields removed, in order to describe detail with more clarity. Make sure all covers and shields are replaced before operating this product.
- This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications.
Such modifications are denoted by a revised manual No.
- To order a copy of this manual, if your copy has been damaged or lost, contact your YASKAWA representative.
- YASKAWA is not responsible for any modification of the product made by the user, since that will void your guarantee.

NOTES FOR SAFE OPERATION

Read this instruction manual thoroughly before installation, operation, maintenance or inspection of the VS-676H5. In this manual, NOTES FOR SAFE OPERATION are classified as "WARNING" or "CAUTION".

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to personnel and damage to equipment.

It may also be used to alert against unsafe practices.

Even items described in  **CAUTION** may result in a vital accident in some situations. In either case, follow these important notes.

NOTE

: These are steps to be taken to insure proper operation.

RECEIVING

CAUTION

(Ref. page)

- Do not install or operate any inverter which is damaged or has missing parts.

Failure to observe this caution may result in personal injury or equipment damage.

12

INSTALLATION

CAUTION

(Ref. page)

- Lift the cabinet by the base. When moving the unit, never lift by the front cover.
Otherwise, the main unit may be dropped causing damage to the unit. 14
- Mount the inverter on nonflammable material (i.e. metal).
Failure to observe this caution can result in a fire. 14
- When mounting units in an enclosure, install a fan or other cooling device to keep the intake air temperature below 45°C.
Overheating may cause a fire or damage to the unit. 14

WIRING

WARNING

(Ref. page)

- Only commence wiring after verifying that the power supply is turned OFF.
Failure to observe this warning can result in an electrical shock or a fire. 23
- Wiring should be performed only by qualified personnel.
Failure to observe this warning can result in an electrical shock or a fire. 23
- When wiring the emergency stop circuit, check the wiring thoroughly before operation.
Failure to observe this warning can result in personal injury. 23
- Make sure to ground the ground terminal .
- (Ground resistance
200V class: 100Ω or less, 400V class: 10Ω or less)
Failure to observe this warning can result in an electrical shock or a fire. 32



CAUTION

(Ref. page)

- Verify that the inverter rated voltage coincides with the AC power supply voltage.
Failure to observe this caution can result in personal injury or a fire. 22
- Do not perform a withstand voltage test of the inverter.
It may cause semi-conductor elements to be damaged. 22
- To connect a braking resistor, braking resistor unit or braking unit, follow the procedures described in APPENDIX.3.
Improper connection may cause a fire. 22
- Tighten terminal screws to the specified tightening torque.
Failure to observe this caution can result in a fire. 22
- Never connect the AC main circuit power supply to output terminals U, V and W.
The inverter will be damaged and invalidate the guarantee. 32

PREPARATION FOR OPERATION



CAUTION

(Ref. page)

- Before starting test run, disconnect the coupling that directly connects the motor to the machine, belt or others to allow the motor to be run independently. If the inverter should be operated for the test with the motor connected to the machine, do so only after ensuring the safety.
Failure to observe this caution can result in personal injury. 49

OPERATION



WARNING

(Ref. page)

- Only turn ON the input power supply after replacing the front cover. Do not remove the cover while current is flowing.
Failure to observe this warning can result in an electrical shock. 69
- When the retry function is selected, do not approach the inverter or the load, since it may restart suddenly after being stopped.
(Construct machine system, so as to assure safety for personnel, even if the inverter should restart.) Failure to observe this warning can result in personal injury. 69
- Since the stop button can be disabled by a function setting, install a separate emergency stop switch.
Failure to observe this warning can result in personal injury. 69
- If an alarm is reset with the operation signal ON, the inverter restarts automatically. Only reset the alarm after verifying that the operation signal is OFF.
Failure to observe this warning can result in personal injury. 69



CAUTION

(Ref. page)

- Never touch the heatsink or discharging resistor since the temperature is very high.
Failure to observe this caution can result in harmful burns to the body. 69
- Since it is easy to change operation speed from low to high speed, verify the safe working range of the motor and machine before operation.
Failure to observe this caution can result in personal injury and machine damage. 69
- Install a holding brake separately if necessary.
Failure to observe this caution can result in personal injury. 69
- Do not check signals during operation.
The machine or the inverter may be damaged. 69
- All the constants of the inverter have been preset at the factory. Do not change the settings unnecessarily.
The inverter may be damaged. For supply voltage, follow Para. 4.2. 69

MAINTENANCE AND INSPECTION



WARNING

(Ref. page)

- Never touch high-voltage terminals in the inverter.
Failure to observe this warning can result in an electrical shock. 78
- Replace all protective covers before powering up the inverter. To remove the cover, make sure to shut OFF the molded-case circuit breaker.
Failure to observe this warning can result in an electrical shock. 78
- Perform maintenance or inspection only after verifying that the CHARGE LED goes OFF, after the main circuit power supply is turned OFF.
The capacitors are still charged and can be dangerous. 78
- Only authorized personnel should be permitted to perform maintenance, inspections or parts replacement.
[Remove all metal objects (watches, bracelets, etc.) before operation.]
(Use tools which are insulated against electrical shock.)
Failure to observe this warning can result in an electrical shock. 78



CAUTION

(Ref. page)

- The control PC board employs CMOS ICs. Do not touch the CMOS elements.
They are easily damaged by static electricity. 78
- Do not connect or disconnect wires or connectors while power is applied to the circuit.
Failure to observe this caution can result in personal injury. 78

OTHERS




WARNING

- Never modify the product.
Failure to observe this warning can result in an electrical shock or personal injury and will invalidate the guarantee.

WARNING LABEL


A warning label is displayed on the front cover of the inverter, as shown below. Follow these instructions when handling the inverter.



Book type: Model CIMR-H5D27P5

Cubic type: Model CIMR-H5D2030

Warning Label



CONTENTS

NOTES FOR SAFE OPERATION	4
1 RECEIVING	12
1.1 INSPECTION CHECKPOINTS	12
1.2 IDENTIFYING THE PARTS	13
2 INSTALLATION	14
2.1 REMOVING AND REPLACING THE FRONT COVER	14
2.2 MOUNTING OPTION CARDS	16
2.3 CHOOSING A LOCATION TO MOUNT THE INVERTER	19
2.4 CLEARANCES	20
3 WIRING	22
3.1 CONNECTION DIAGRAMS	23
3.2 WIRING THE MAIN CIRCUIT	32
3.3 WIRING THE CONTROL CIRCUIT	47
3.4 WIRING INSPECTION	48
4 PREPARATION FOR OPERATION	49
4.1 INSPECTION BEFORE TURNING THE POWER ON	49
4.2 SETTING THE LINE VOLTAGE USING JUMPER	50
4.3 TURNING ON THE MAIN CIRCUIT POWER	51
4.4 CHECKING THE ROTATION DETECTION DIRECTION OF PG	52
4.5 SETTING THE CARRIER FREQUENCY	53
4.6 SETTING THE RATED SPEED	53
4.7 SETTING FOR THERMISTOR	54
4.8 SELECTION OF OPERATION MODE	54
4.9 AUTO-TUNING	55
5 SETTING OPERATION CONDITIONS	60
5.1 DIGITAL OPERATOR KEY DESCRIPTION	60
5.2 DIGITAL OPERATOR MODE SELECTION	61
5.3 DRIVE MODE	62
5.4 SETTING THE INVERTER OPERATION ENVIRONMENT	64
5.5 SETTING AND READING CONSTANTS (PROGRAM MODE)	66
6 OPERATION	69
6.1 TEST RUN	70
7 MAINTENANCE AND INSPECTION	77
7.1 PERIODIC INSPECTION	78
7.2 PARTS REPLACEMENT SCHEDULE (GUIDELINES)	78
8 TROUBLESHOOTING	79
8.1 FAULT DIAGNOSIS AND CORRECTIVE ACTIONS	79
8.2 MOTOR FAULTS AND CORRECTIVE ACTIONS	84
8.3 DISPLAY SEQUENCE OF FAULT CODES	85
8.4 MONITOR CONSTANTS RELATED WITH FAULTS	86

APPENDIX 1 SPECIFICATIONS	87
APPENDIX 2 DIMENSIONS (mm)	90
APPENDIX 3 TYPICAL CONNECTION DIAGRAMS	93
3.1 USING DC INPUT UNIT WITH BUILT-IN INRUSH CURRENT SUPPRESSING CIRCUIT	93
3.2 USING DC INPUT UNIT WITHOUT BUILT-IN INRUSH CURRENT SUPPRESSING CIRCUIT	94
3.3 USING AC INPUT UNIT	95
APPENDIX 4 FUNCTION BLOCK DIAGRAMS	96
4.1 FLUX VECTOR CONTROL	96
4.2 OPEN LOOP VECTOR CONTROL	98
4.3 V/f CONTROL	100
4.4 EMS CONTROL	102
APPENDIX 5 TABLE OF COMMUNICATION DATA	106
APPENDIX 6 TABLE OF CONSTANTS	109

1 RECEIVING

CAUTION

- Do not install or operate any inverter which is damaged or has missing parts.
Failure to observe this caution may result in personal injury or equipment damage.

This chapter describes how to verify the inverter after delivery to the user.

1.1 INSPECTION CHECKPOINTS

(1) Receiving Checkpoints

Table 1 Checkpoints

Checkpoints	Description
Does the inverter model number correspond with the purchase order?	Check the model number on the nameplate on the side of the VS-676H5 (Refer to page 13)
Are any parts damaged?	Visually check the exterior and verify that there was no damage during transport
Is hardware properly seated and securely tightened?	Remove inverter front cover Check all visible hardware with appropriate tools

If any of the above checkpoints are not satisfactory, contact your YASKAWA representative.

(2) Checking the Nameplate Data

(a) Nameplate Data

Example of model CIMR-H5D20P4




Fig. 1 Nameplate Data

(b) Model Designation




Fig. 2 Model Designation

(c) Specification Designation





Fig. 3 Specification Designation

1.2 IDENTIFYING THE PARTS



Book type: Model CIMR-H5D27P5 (200 V, 7.5 kW)

Cubic type: Model CIMR-H5D2030 (200 V, 30 kW)

Fig. 4 Configuration of VS-676H5

2 INSTALLATION

⚠ CAUTION

- Lift the cabinet by the base. When moving the unit, never lift by the front cover. Otherwise, the main unit may be dropped causing damage to the unit.
- Mount the inverter on nonflammable material (i.e. metal). Failure to observe this caution can result in a fire.
- When mounting units in an enclosure, install a fan or other cooling device to keep the intake air temperature below 45°C. Overheating may cause a fire or damage to the unit.

This chapter describes the configuration, location and space when mounting the VS-676HS.

2.1 REMOVING AND REPLACING THE FRONT COVER

(1) Book Type (200V 0.4 to 15kW, 400V 0.4 to 18.5kW)

To remove the front cover from the inverter, pull it out in the direction shown by arrow ② while lifting it in the direction shown by arrow ①. After pulling it a little, disconnect the wires from the control card to the base driver card. Follow the procedure in the reverse order when mounting it to the inverter.




Fig. 5 Removing and Replacing the Front Cover
(Book Type : 200V 0.4 to 15 kW, 400V 0.4 to 18.5kW)

(2) Book Type (200V 8.5 to 22kW, 400V 22 to 45kW)

To remove the front cover from the inverter, pull it out in the direction shown by arrow ② while lifting it in the direction shown by arrow ①.




Fig. 6 Removing and Replacing the Front Cover
(Book Type : 200V 8.5 to 22 kW, 400V 22 to 45kW)

(3) Cubic Type

To remove the front cover from the inverter, pull it in the direction shown by arrow ② while lifting it in the direction shown by arrow ①. Follow the procedure in the reverse order when mounting it to the inverter.

The control card and the option cards are accessible by opening the sub cover at the front.




Fig. 7 Removing and Replacing the Front Cover (Cubic Type)

2.2 MOUNTING OPTION CARDS

- (1) Insert the option card that fits to connector 2CN, 3CN, or 4CN.
- (2) Fit the option card onto the support spacer at (S).
- (3) For the option card that fits onto connector 2CN, attach screw (N).
- (4) To remove option cards, follow steps (1) to (3) in the reverse order.




Fig. 8 Mounting Option Cards

NOTE

-
1. When mounting option cards A and D, make sure that part (S) of support spacer is correctly fitted (support tongues are opened) after mounting the board.
 2. When mounting option card C, make sure that screws (N) are securely tightened after mounting the board.
 3. Note that some of the connectors are of the same type. Therefore, make sure to mount option cards to the correct connectors each of which is identified by device symbol.
-

Table 2 Table of Option Cards

Type	Name	Code No.	Function	Position	Remarks
Built-in type (mounted to connector)	Feedback detection option card	PG speed control card PG-A2/H	<ul style="list-style-type: none"> - A-phase pulse (single pulse) input - PG frequency range 50 to 32767 Hz - Pulse monitor output +12V, 20 mA (Max) 	Mounted to 4CN on the control card (note)	See TOE-C736-40 12
	PG speed control card PG-B2/H	73600-A018X	<ul style="list-style-type: none"> - For complementary output PG - A- and B-phase pulses for vector control (2-phase pulse) Input - PG frequency range 50 to 32767 Hz - Pulse monitor output: +24 V, 30 mA (Max) (open collector output) 		See TOE-C736-40 13
	Synchronous input, control card SP-A2/H (exclusive for EMS)	73600-A019X	Applicable frequency 0 to approx 100 Hz		See TOE-C736-40 14
Monitor option card	Analog monitor card AO-12/H	73600-D008X	<ul style="list-style-type: none"> - Outputs analog signals that are used to monitor the operation status (output speed, torque, etc) - Output resolution 11 bits + sign (1/2048) - Output voltage: -10 to +10 V (non-insulated) - Output channels: 2-channels 	Mounted to 3CN on the control card (note)	See TOE-C736-40 10
	Digital output card DO-08/H	73600-D009X	<ul style="list-style-type: none"> - Outputs the inverter's operation status and fault contents (multi-function output). - Photocoupler output 8 channels (with same common terminal) 		See TOE-C736-40 11
Communication control option card	Inverter kit controller CP-916A	87916-1100X-s0100Y	<ul style="list-style-type: none"> - Board-type controller directly mounted to the inverters. - Program steps: 1k steps - Communication CP-215 (1 port) 	Mounted to 2CN on the control card (note)	See SIE-C873-16 4 SIE-C879-16 1
	CP-216 communication interface card CP-216IF/INV	87216-1100X-s0100Y	Used to connect to the CP-216 transmission line		See SIE-C873-16 1 SIE-C873-16 4

NOTE

1. Only one card can be connected to each connector.
2. The numbers represented by X and Y are changed according to the modifications and version upgrading of the hardware and software.
 X: The number representing modifications made to the hardware
 Y: The number representing modifications made to the software

2.3 CHOOSING A LOCATION TO MOUNT THE INVERTER

To ensure proper performance and long operating life, follow the recommendations below when choosing a location for installing the VS-676H5. Make sure the inverter is protected from the following conditions.

- Direct sunlight. (Avoid using outdoors.)
- Corrosive gases or liquids.
- Oil sprays, splashes
- Salt spray.
- Rain, moisture
- Dust metallic particles in the air.
- Physical shock, vibration.
- High humidity
- Extreme cold and heat. Allowable ambient temperature range: -10 to +40°C
- Magnetic noise. (Example: Welding machines, power devices, etc.)
- Radioactive materials.
- Combustibles

2.4 CLEARANCES

Install the VS-676H5 vertically and allow sufficient clearances for effective cooling as shown in Fig. 9 and 10.




Fig. 9 Clearances (Type of 200 V 22 kW/400 V 45 kW or Less)




Fig. 10 Clearances (Type of 200 V 30 kW/400 V 55 kW or Larger)

NOTE

1. For the external dimensions and mounting dimensions, refer to APPENDIX 2 "DIMENSIONS".
2. Allowable intake air temperature to the inverter.
Open chassis type: -10 to +45°C
3. For the types of 200 V, 22 kW or less and those of 400 V, 45 kW or less, cooling air indicated below must be secured since these types do not have a built-in cooling fan.

Table 3 Required Cooling Air

Model Name of VS-676H5 CIMR- █	Wind Velocity of Cooling Air at Heat Sink m/s
HSD20P4	
HSD20P7	
HSD21P5	1.5
HSD22P2	
HSD23P7	
HSD25P5	
HSD27P5	2.0
HSD2011	
HSD2015	2.5
HSD2018	
HSD2022	3.5

Model Name of VS-676H5 CIMR- █	Wind Velocity of Cooling Air at Heat Sink m/s
HSD40P4	
HSD40P7	
HSD41P5	1.5
HSD42P2	
HSD43P7	
HSD45P5	
HSD47P5	2.0
HSD4011	
HSD4015	2.5
HSD4018	
HSD4022	
HSD4030	
HSD4037	3.5
HSD4045	

3 WIRING



WARNING

- Only commence wiring after verifying that the power supply is turned OFF.
Failure to observe this warning can result in an electrical shock or a fire.
- Wiring should be performed only by qualified personnel.
Failure to observe this warning can result in an electrical shock or a fire.
- When wiring the emergency stop circuit, check the wiring thoroughly before operation.
Failure to observe this warning can result in personal injury.



CAUTION

- Verify that the inverter rated voltage coincides with the AC power supply voltage.
Failure to observe this caution can result in personal injury or a fire.
- Do not perform a withstand voltage test of the inverter.
It may cause semi-conductor elements to be damaged.
- To connect a braking resistor, braking resistor unit or braking unit, follow the procedures described in APPENDIX 3.
Improper connection may cause a fire.
- Tighten terminal screws to the specified tightening torque.
Failure to observe this caution can result in a fire.

This chapter describes the main circuit wiring and the control circuit wiring of the VS-676H5.

3.1 CONNECTION DIAGRAMS

The following are connection diagrams including those of option cards.

(1) Connection diagram of standard inverter




Fig. 11 Connection Diagram of Standard Inverter
(Model CIMR-H5D2030, 200 V 30 kW)

NOTE

-
1. Control circuit terminal (connector 9CN-1, 10) of +15V/-15V has a maximum output current capacity of 20 mA.
 2. Multi-function analog output should be used for monitoring meters such as a frequency meter and an ammeter and should not be used for feedback control system. It is recommended to use analog monitor card (Model DO-08/H or AO-12/H) for the control system.
-

(2) Connection Diagram of PG Card Option





Fig. 12 Connection Diagram of PG-A2/H (Single-Pulse Input)



Note: Terminal symbols of PG are examples assuming Yaskawa's motor is used
 PG model: LMA-□□B-S185Y (Complementary output)

Fig. 13 Connection Diagram of PG-B2/H (Double-Pulse Input)

NOTE

Cautions on Wiring

1. Isolate the control signal wires (terminals TA1 and TA2) of the PG speed control cards PG-A2/H and PG-B2/H from the main circuit wires and power cables.
2. For connection with a PG, use shielded wires to prevent malfunctions due to noise. The allowable maximum wiring distance varies depending on the type of cables used for connection.

KPEV-S (0.75 mm², three-pair wire): Max. 50 m

KPEV-S (1.25 mm², three-pair wire): Max. 300 m

(junction terminal must be used.)

(3) Connection Diagram of Synchronous Control Option




Fig. 14 Connection Diagram of SP-A2/H (Exclusive for EMS Control)

Cautions on Wiring

NOTE

1. Isolate the control signal wires (terminals TA1 and TA2) of the synchronous control card SP-A2/H from the main circuit wires and power cables.
2. For connection within a specified area, use shielded wires to prevent malfunctions due to noise. The wiring distance should be less than 50 m.

(4) Connection Diagram of Analog Output Option

The following diagram shows an example of connection of the inverter, analog monitor card AO-12/H, and a peripheral: outputs of AO-12/H are connected to a frequency meter and an ammeter.




Fig. 15 Connection Diagram of AO-12/H

Cautions on Wiring

NOTE

1. Isolate the control signal wires (terminals TD1 to TD3) of the analog monitor card AO-12/H from the main circuit wires and power cables.
2. For the connection of control signals, use shielded wires and treat the termination of wires in the manner shown below to prevent malfunctions due to noise. The wiring distance should be less than 50 m.




Fig. 16 Termination Treatment of Shielded Wires

(5) Connection Diagram of Digital Output Option

The following diagram shows an example of connection of the inverter, digital output card DO-08/H, and a peripheral: outputs of DO-08/H are connected to DC relays.




Fig. 17 Connection Diagram of DO-08/H

Cautions on Wiring

NOTE

1. Isolate the wiring connected to terminals TD from the main circuit wires and power cables.
2. For the wiring connected to terminals TD, use shielded wires to prevent malfunctions due to noise. The wiring distance should be less than 50 m.

(6) Connection Diagram of Inverter Kit Controller Option




Fig. 18 Connection Diagram of CP-916A

(7) Connection Diagram of Communication Option




Fig. 19 Connection Diagram of CP-216 IF/INV

NOTE

Isolation of Power Cables in the Panel

The low-voltage line must be isolated from the main line by separating them at least 200 mm from each other. In addition, use the shielded wires for the low-voltage line to protect it from influence of the operation line and other lines run in parallel to it.




Fig. 20 Isolation of Cables in the Panel and the Minimum Isolating Distance

Connection of Shielded Sheath

Connect the shield wire in the power cable to the earth terminal Es.

For details, refer to "FDS System Installation Manual" (SIE-C873-16.4).

3.2 WIRING THE MAIN CIRCUIT



WARNING

- Make sure to ground the ground terminal .
(Ground resistance 200 V class: 100 Ω or less, 400 V class: 10Ω or less)
Failure to observe this warning can result in an electrical shock or a fire.



CAUTION

- Never connect the AC main circuit power supply to output terminals U, V and W.
The inverter will be damaged and invalidate the guarantee.

(1) Wiring Precautions for Main Circuit Input

< AC Input >

(a) Installation of Ground Fault Interrupter

When connecting a ground fault interrupter to input terminals R, S, and T, select one that is not affected by high frequency.

Examples: NV series by Mitsubishi Electric Co., Ltd.
(manufactured in or after 1988)
EG, SG series by Fuji Electric Co., Ltd.
(manufactured in or after 1984)

(b) Installation of Magnetic Contactor

When using a braking resistor unit, install a magnetic contactor at the primary side of the inverter to protect the braking resistor unit, and program the sequence to turn off the magnetic contactor upon actuation of the overload relay trip contact. If the inverter malfunctions, the braking resistor unit could be burned out.

(c) Terminal Block Connection Sequence

Input power supply phases can be connected to any terminal regardless of the order of R, S, and T on the terminal block.

(d) Installation of Surge Suppressor

For inductive loads (magnetic contactors, magnetic relays, solenoid valves, solenoids, magnetic brake, etc.) connected near the inverter, connect a surge suppressor at the same time.

(e) Prohibition of Installation of Phase Advancing Capacitor

For the improvement of the power factor, use an AC reactor on the input power supply side. If a phase advancing capacitor or surge suppressor is connected in order to improve the power factor, it may become overheated and damaged by high harmonic components of the inverter. Also, the inverter may malfunction because of overcurrent.

< DC Input >

(a) Installation of DC Power ON/OFF Switch (SW)

With the following types of inverters, inrush current suppressing function is not built into the inverter.

Book type: 200 V, 11 kW to 22 kW
400 V, 11 kW to 45 kW

Therefore, it is necessary to prepare the inrush current suppressing circuit at the output side of the SW if one is installed.




Fig. 21 Example of Installation of Inrush Current Suppressing Circuit

(2) Wiring Precautions for Main Circuit Output

(a) Connection of Terminal Block and Load

Connect output terminals U, V and W to motor lead wires U, V and W. Verify that the motor rotates in the forward-direction (CCW: counterclockwise when viewed from the motor load side) with the forward run command. If the motor rotation is incorrect, exchange any two of output terminals U, V or W.

For the vector control with PG, wiring of the PG must also be changed. Refer to 4.4 "CHECKING THE ROTATION DETECTION DIRECTION OF PG".

(b) Strict Prohibition of Connection of Input Power Supply to Output Terminals

Never connect the input power supply to output terminals U, V and W.

(c) Strict Prohibition of Short Circuiting or Grounding of Output Circuit

Never touch the output circuit directly or put the output line in contact with the inverter case. Otherwise, it may cause an electrical shock or grounding. In addition, never short circuit the output line.

(d) Prohibition of Connection of Phase Advancing Capacitor or LC/RC Noise Filter

Never connect a phase advancing capacitor or LC/RC noise filter to the output circuit.

(e) Installation of Magnetic Starter or Contactor

When a magnetic starter or magnetic contactor is connected to the output circuit, the inverter overcurrent protective circuit could operate due to inrush current if the magnetic starter or contactor is opened while the inverter is running.

The sequence must be designed so that the magnetic starter or contactor is opened only during base block state.

(f) Installation of Thermal Overload Relay

An electronic overload protective function is incorporated into the inverter. It is necessary, however, to connect a thermal overload relay when driving several motors with one inverter or when using a multi-pole motor. If a thermal overload relay is used, its setting must be as indicated below.

- At 50 Hz The same rated current value as that described on the motor nameplate.
- At 60 Hz 1.1 times larger than the rated current value described on the motor nameplate.

(3) Grounding

- Ground resistance
200 V class: 100Ω or less, 400 V class: 10Ω or less.
- Never ground VS-676H5 in common with welding machines, motors, or other large-current electrical equipment. Run all the ground wires in a conduit separate from wires for large-current electrical equipment.
- Use the ground wires described in Tables 7, 8, or 9 and keep the length as short as possible.
- When using several inverter units side by side, ground the units as shown in Fig. 22, (a) or (b). Do not loop the ground wires as shown in (c).




Fig. 22 Grounding of Three Inverter Units

(4) Functions of Main Circuit Terminals

The following table outlines the functions of the main circuit terminals.
Wire according to each terminal function.

Table 4 200V Class DC Input Terminal Functions

Model CIMR-H5D □	20P4 to 2022	2030 to 2075
Max Applicable Motor Output	0.4 to 22 kW	30 to 75 kW
⊖	DC input power supply	
⊕ 1		
U		
V	Inverter output	
W		
▲		
r		
①	Ground terminal (Grounding resistance: 100 Ω or less)	

Table 5 400V Class DC Input Terminal Functions


Model CIMR-H5D □	40P4 to 47P5	4011 to 4015	4018 to 4045	4055 to 4160		
Max Applicable Motor Output	0.4 to 7.5 kW	11 to 15 kW	18.5 to 45 kW	55 to 160 kW		
⊖	DC input power supply					
⊕ 1						
U						
V	Inverter output					
W						
r			Cooling fan power supply (Control power supply) r - ▲200 200 to 230V AC input r - ▲400 380 to 460V AC input			
▲ 200						
▲ 400						
①	Ground terminal (Grounding resistance: 10Ω or less)					

Table 6 200/400 V Class AC Input Terminal Functions

Voltage	200 V Class	400 V Class				
Model CIMR-H5A □	2030 to 2075	4055 to 4160	4185 to 4300			
Max Applicable Motor Output	30 to 75 kW	55 to 160 kW	185 to 300 kW			
R		Main circuit input power supply				
S						
T						
⊖		Braking unit (⊕3 - ⊖) (⊕1 terminal is not provided)	DC power supply (⊕1 - ⊖) Braking unit (⊕3 - ⊖)			
⊕ 1						
⊕ 3						
U		Inverter output				
V						
W						
▲	Cooling fan power supply	—				
Γ		Cooling fan power supply (Control power supply) Γ - ▲200 : 200 to 230V AC input Γ - ▲400 : 380 to 460V AC input				
▲ 200	—					
▲ 400	—					
⊕	Ground terminal (Grounding resistance 200V class: 100 Ω or less, 400 V class 10 Ω or less)					

(5) Main Circuit Configuration

(a) Configuration A (DC input)




- 200 V Class:
CIMR-H5D20P4 - 27P5
0.4 to 7.5 kW

- 400 V Class:
CIMR-H5D40P4 - 47P5
0.4 to 7.5 kW

Note: C: [Inverter capacity] \times 50%

(b) Configuration B (DC input)




- 200 V Class:
CIMR-H5D2011 - 2015
11 to 15 kW

- 400 V Class:
CIMR-H5D4011 - 4015
11 to 15 kW

Note: C: [Inverter capacity] \times 50%

(c) Configuration C (DC input)



- 200 V Class:

CIMR-H5D2018 - 2022

18.5 to 22 kW


- 400 V Class:

CIMR-H5D4018 - 4045

18.5 to 45 kW

Note: C: [Inverter capacity] × .60%

(d) Configuration D (DC input)




- 200 V Class:

CIMR-H5D2030 - 2075

30 to 75 kW


(e) Configuration E (DC input)



- 400 V Class:
CIMR-H5D4055 - 4160
55 to 160 kW

Note: C: [Inverter capacity] \times 60%

(f) Configuration F (AC/DC input)




- 400 V Class:
CIMR-H5A4185 - 4300
185 to 300 kW

Note: C: [Inverter capacity] \times 100%

*When using DC input power supply (terminals $\oplus 1$ and \ominus), remove the wiring between both terminals R and r, S and s 400


(g) Configuration g (AC input)



- 200 V Class:
CIMR-H5A2030 - 2075
30 to 75 kW

Note: C: [Inverter capacity] × 100%

(h) Configuration h (AC input)



- 400 V Class:
CIMR-H5A4055 - 4160
55 to 160 kW

Note: C: [Inverter capacity] × 100%

(6) Parts Required for Wiring

Select wires and solderless terminals to be used for wiring from Tables 7, 8, and 9.

Table 7 Wire Size for 200V Class (DC Input)

Circuit	Model CIMR- 	Terminal Symbol	Terminal Screw	Wire Size ^{*1} mm ²	Wire Type
Main	H5D20P4	Θ, Θ1 U, V, W	M4	2 - 55	Power cable. 600V fire-retardant polyflex cable
		⊕			
	H5D20P7	Θ, Θ1 U, V, W	M4	2 - 55	
		⊕			
	H5D21P5	Θ, Θ1 U, V, W	M4	2 - 55	
		⊕			
	H5D22P2	Θ, Θ1 U, V, W	M4	2 - 55	
		⊕			
	H5D23P7	Θ, Θ1 U, V, W	M4	2 - 55	
		⊕			
	H5D25P5	Θ, Θ1 U, V, W	M6	5.5 - 22	
		⊕	M5	5.5 - 14	
	H5D27P5	Θ, Θ1 U, V, W	M6	5.5 - 22	
		⊕	M5	5.5 - 14	
	H5D2011	Θ, Θ1 U, V, W	M8	14 - 38	
		⊕		8	
	H5D2015	Θ, Θ1 U, V, W	M8	14 - 38	
		⊕		8	
	H5D2018	Θ, Θ1 U, V, W	M8	30 - 60	
		⊕		14	
	H5D2022	Θ, Θ1 U, V, W	M8	30 - 60	
		⊕		14	
	H5D2030	Θ, Θ1 U, V, W	M10	100	Twisted shielded wire
		⊕	M8	22	
		r, s	M4	0.5 - 5.5	
	H5D2037	Θ, Θ1 U, V, W	M10	100	Twisted shielded wire
		⊕	M8	22	
		r, s	M4	0.5 - 5.5	
	H5D2045	Θ, Θ1 U, V, W	M10	60 × 2P	Twisted shielded wire
		⊕	M8	22	
		r, s	M4	0.5 - 5.5	
	H5D2055	Θ, Θ1 U, V, W	M10	60 × 2P	Twisted shielded wire
		⊕	M8	30	
		r, s	M4	0.5 - 5.5	
	H5D2075	Θ, Θ1 U, V, W	M12	100 × 2P	Twisted shielded wire
		⊕	M8	50	
		r, s	M4	0.5 - 5.5	
Control	Common to all models	TB1 to TB3, 1CN, 9CN to 11CN	-	*2	Twisted shielded wire

*1 Wire size is determined using 110°C temperature-rated copper wire

*2 Specifications of the control card terminals are indicated in page 45

Table 8 Wire Size for 400V Class (DC Input)

Circuit	Model CIMR- █	Terminal Symbol	Terminal Screw	Wire Size ^{*1} mm ²	Wire Type
Main	H5D40P4	⊖, + I U, V, W	M4	2 - 5.5	Power cable: 600V fire-retardant polyflex cable
	H5D40P7	⊖, + I U, V, W	M4	2 - 5.5	
	H5D41P5	⊖, + I U, V, W	M4	2 - 5.5	
	H5D42P2	⊖, + I U, V, W	M4	2 - 5.5	
	H5D43P7	⊖, + I U, V, W	M4	2 - 5.5	
	H5D45P5	⊖, + I U, V, W	M4	2 - 5.5	
	H5D47P5	⊖, + I U, V, W	M4	2 - 5.5	
	H5D4011	⊖, + I U, V, W	M5	5.5 - 14 8	
	H5D4015	⊖, + I U, V, W	M5	5.5 - 14 8	
	H5D4018	⊖, + I U, V, W	M6	14 - 22 8	
	H5D4022	⊖, + I U, V, W	M6	14 - 22 8	
	H5D4030	⊖, + I U, V, W	M8	38 - 60 8	
	H5D4037	⊖, + I U, V, W	M8	38 - 60 14	
	H5D4045	⊖, + I U, V, W	M8	38 - 60 14	
	H5D4055	⊖, + I U, V, W	M10	100	
	H5D4075	⊖, + I U, V, W r, △ 200, △ 400	M8	22	
M4			0.5 - 5.5		
H5D4110	⊖, + I U, V, W r, △ 200△ 400	M10	100		
		M8	22		
H5D4160	⊖, + I U, V, W r, △ 200△ 400	M4	0.5 - 5.5		
		M10	60 × 2P		
H5D4185	R, S, T, ⊖, + I, + 3 U, V, W r, △ 200△ 400	M8	50		
		M16	325 × 2P		
H5D4220	R, S, T, ⊖, + I, + 3 U, V, W r, △ 200△ 400	M8	50		
		M4	0.5 - 5.5		
H5D4300	R, S, T, ⊖, + I, + 3 U, V, W r, △ 200△ 400	M16	325 × 2P		
		M8	60		
Control	Common to all models	TB1 to TB3, 1CN to 11CN	—	*2	Twisted shielded wire

*1 Wire size is determined using 110°C temperature-rated copper wire

*2 Specifications of the control card terminals are indicated in page 45

Table 9 Wire Size for 200/400V Class (AC Input)

Circuit	Model CIMR-■■■	Terminal Symbol	Terminal Screw	Wire Size*1 mm ²	Wire Type
Main	H5A2030	R, S, T, U, V, W	M10	100	Power cable 600V fire-retardant polyflex cable
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ	M4	0.5 - 5.5	
	H5A2037	R, S, T, U, V, W	M10	60 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ	M4	0.5 - 5.5	
	H5A2045	R, S, T, U, V, W	M10	60 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ	M4	0.5 - 5.5	
	H5A2055	R, S, T, U, V, W	M10	60 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	30	
		Γ, Δ	M4	0.5 - 5.5	
	H5A2075	R, S, T, U, V, W	M12	100 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	50	
		Γ, Δ	M4	0.5 - 5.5	
	H5A4055	R, S, T, U, V, W	M10	100	
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
	H5A4075	R, S, T, U, V, W	M10	100	
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
	H5A4110	R, S, T, U, V, W	M10	60 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	22	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
	H5A4160	R, S, T, U, V, W	M12	100 × 2P	
		⊖, ⊕3	M8	—	
		⊕	M8	50	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
	H5A4185	R, S, T, ⊖, ⊕1, ⊕3 U, V, W	M16	325 × 2P	
		⊕	M8	50	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
		R, S, T, ⊖, ⊕1, ⊕3 U, V, W	M16	325 × 2P	
	H5A4220	⊕	M8	60	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
		R, S, T, ⊖, ⊕1, ⊕3 U, V, W	M16	325 × 2P	
		⊕	M8	60	
	H5A4300	Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
		R, S, T, ⊖, ⊕1, ⊕3 U, V, W	M16	325 × 2P	
		⊕	M8	60	
		Γ, Δ 200, Δ 400	M4	0.5 - 5.5	
Control	Common to all models	TB1 to TB3, 1CN, 9CN to 11CN	—	*2	Twisted shielded wire

*1 Wire size is determined using 110°C temperature-rated copper wire. When connecting a braking unit, select wire size referring to the instructions of braking unit (manual No TOE-C726-2).

*2 Specifications of the control card terminals are indicated in page 45.

NOTE




When determining wire size, consider voltage drop. Select a wire size so that voltage drop will be less than 2% of the rated voltage. Voltage drop is calculated by the following equation:










Line voltage drop (V)

$$= \sqrt{3} \times \text{wire resistance } (\Omega/\text{km}) \times \text{wiring distance } (\text{m}) \times \text{current } (\text{A}) \times 10^{-3}$$

(7) Control Circuit Terminals

Table 10 Control-Circuit Terminals

	Connector No.	Function	Connector Type		Connector Pin Nos.	Applicable Max. Wire Size	Connector Manufacturer	
			Inverter Side	Wiring Side				
Control Card	TB1	Inrush current suppression circuit	MC1 5/4G-3.81	MC1 5/4ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co	
	TB3	Motor thermistor	MC1.5/2G-3.81	MC1 5/2ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co.	
	1CN	Digital operator	10214-52A2JL	10114-3000VE 10314-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd.	
	9CN	Control signals	10226-52A2JL	10126-3000VE 10326-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd	
	10CN	Control signals	10220-52A2JL	10120-3000VE 10320-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd	
	TB2	Inverter dry contact	MSTB2 5/5-GF	MSTBT2 5/5-ST		2.5 mm²	Phoenix Contact GmbH & Co	
Option Cards	PG-A2/H	TA1	Control signals	10220-52A2JL	10120-3000VE 10320-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd
		TA2	Control signals	MC1 5/2G-3.81	MC1.5/2ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co

	Connector No.	Function	Connector Type		Connector Pin Nos.	Applicable Max. Wire Size	Connector Manufacturer	
			Inverter Side	Wiring Side				
Option Cards	PG-B2/H	TA1	Control signals	10220-52A2JL	10120-3000VE 10320-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd
		TA2	Control signals	MC1.5/4G-3.81	MC1.5/4ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co
	SP-A2/H	TA1	Control signals	10220-52A2JL	10120-3000VE 10320-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd
		TA2	Control signals	MC1.5/4G-3.81	MC1.5/4ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co
Option Cards	AO-12/H	TD	Control signals	MC1.5/3G-3.81	MC1.5/3-ST-3.81		1.5 mm²	Phoenix Contact GmbH & Co
	DO-08/H	TD	Control signals	10214-52A2JL	10114-3000VE 10314-52A0-008 (case)		0.2 mm²	Sumitomo 3M Ltd
	CP-916A	CN1	CP-215 transmission	MR-8RFA4 (G)	MR-8M (G) MR-8L (case)		IPEV-S (Cu) 1.25 mm² × 1P	Honda Tsushin Kogyo Co., Ltd
		CN2	PP/digital operator	17LE-13090-27 (D8B) (with case)	17JE-23090-02 (D8B) (with case)		Use a special cable. Code No: DUD005010	Daiichi Denshi Kogyo Co., Ltd
	2161F/INV	CN2	CP-216 transmission	MR-8RMA4 (G)	MR-8F (G) MR-8L (case)		IPEV-S (Cu) 1.25 mm² × 1P	Honda Tsushin Kogyo Co., Ltd

NOTE

Some of the connectors attached with control cards and option cards are of the same type. Therefore, make sure to mount the cards to the correct connectors each of which is identified by device symbol. If connection is wrong, it may cause damage to the inverter.

3.3 WIRING THE CONTROL CIRCUIT

The following table outlines the functions of the control circuit terminals.
Wire correctly according to the purpose.

(1) Functions of Control Circuit Terminals

Table 11 Control Circuit Terminals

Terminal Symbol	Signal Name	Terminal Function		Signal Level	
9CN	17	Forward run/stop	Forward run when closed, stop when open	Photocoupler insulation Input 24 VDC 8 mA	
	18	Reverse run/stop	Reverse run when closed, stop when open		
	19	Input signal 1	-		
	20	Input signal 2	-		
	21	Input signal 3	-		
	22	Input signal 4	-		
	23	Input signal 5	-		
	24	Input signal 6	-		
	25	DI-COM	-		
	1	+15 power supply output	+15 V power supply for analog commands	+15 V (Allowable current: 20 mA max)	
TB2	10	-15 power supply output	-15 V power supply for analog commands	-15 V (Allowable current: 20 mA max)	
	4	Analog input 1	0 to 10 V/-10 to 10 V	Valid if B1-01 = 1 Through mode in other cases	
	6	Analog input 2	0 to 10 V/-10 to 10 V		
			4 to 20 mA		
	8	Analog input 3	0 to 10 V/-10 to 10 V		
10CN	2	Output signal 1 (fault contact input)	Outputs an error signal if the inverter hardware is defective (TB-1 to TB-3: Closed)	Multi-function contact output (H2-06)	
	3				
	1				
	4	Output signal 6		Multi-function contact output (H2-01)	
	5				
TB3	2	Analog output 1	-	Multi-function analog monitor (H4-01 to H4-07)	
	4	Analog output 2	-		
	10	Output signal 2	-	Multi-function PHC output (H2-02 to H2-05)	
	12	Output signal 3	-		
	14	Output signal 4	-		
	16	Output signal 5	-		
	17	PHC-COM	-		
TB1	1	Motor thermistor	Detects motor temperature		
	2		-		
	1	Interface to the inrush current suppressing circuit installed externally	Closed Inrush current suppressing circuit contactor ON command	24VDC 100 mA	
	2		Closed Inrush current suppressing circuit contactor ON answer	24VDC 7 mA	

(2) Precautions on Control Circuit Wiring

- Isolate the control circuit wires (connectors: 9CN, 10CN, TB1 to TB3) from the main circuit wires (terminals: R, S, T, U, V, W, \ominus , $\oplus 1$, $\oplus 3$) and other power cables to prevent malfunctions of the inverter due to noises.
- Isolate the wire connected to the control circuit terminal (TB2: contact output) from the wires connected to 9CN, 10CN, TB1, and TB3.
- Use twisted shielded or twisted-pair shielded wires for the control circuit line to prevent malfunctions of the inverter due to noise. The ending of the wires should be insulated as shown below. Wiring distance should be less than 50 m.




Fig. 23 Shielded Wire Termination

3.4 WIRING INSPECTION

After completing installation and wiring, check the following items. In this check, never test the buzzer in the control circuit.

- Wiring is proper.
- Wire clippings or screws are not left in the unit.
- Screws are securely tightened.
- Bare wire in the terminal does not in contact with other terminals.

4 PREPARATION FOR OPERATION

⚠ CAUTION

- Before starting test run, disconnect the coupling that directly connects the motor to the machine, belt or others to allow the motor to be run independently.
If the inverter should be operated for the test with the motor connected to the machine, do so only after ensuring the safety.
Failure to observe this caution can result in personal injury.

4.1 INSPECTION BEFORE TURNING THE POWER ON

Check the following items after completing installation and wiring.

- (1) Wiring is proper.
- (2) Wire clippings or screws are not left in the unit that could cause short-circuit.
- (3) Screws are securely tightened.
- (4) Connected loads are proper.

4.2 SETTING THE LINE VOLTAGE USING JUMPER

This setting is necessary only for the inverters of 55 kW or larger types of 400 V class.

Set the line voltage jumper according to the main circuit power supply as shown in Fig. 24. Insert the jumper at the appropriate location corresponding to the input voltage.

It has been preset at the factory to 440 V.




Fig. 24 Line Voltage Jumper

4.3 TURNING ON THE MAIN CIRCUIT POWER

After turning on the main circuit power, verify that there are no abnormalities.

When the power is turned on, the CHARGE indicating lamp lights and then the display unit in the digital operator lights (when a digital operator is connected.).




Fig. 25 Digital Operator

NOTE

If an exclusive-use thermistor is not provided with the motor, **ГИП** (thermistor open circuit) is displayed.

In this case, set "0" (without thermistor) for **L 9-01** and perform fault reset. This recovers correct display.

When No. 2 motor is selected, set "0" for **L 9-04** and perform fault reset.

4.4 CHECKING THE ROTATION DETECTION DIRECTION OF PG

Select motor speed display on the display unit in the digital operator and turn the motor shaft. Make sure that display of motor rotation direction and polarity is correct and also that the motor speed is displayed correctly.

Forward direction: Counterclockwise as viewed from the load side (standard setting). See Fig. 26.




Fig. 26 Motor Rotation Direction

This inspection can be carried out only after making sure that the STOP LED on the digital operator is lit.

Procedure:

- ① Press the display selection key [DSPL] on the digital operator to change the display mode to motor speed display.

P 0.00 (%) → 0.00
(command display) (feedback display)

- ② Turn the motor counterclockwise as viewed from the load side.

Make sure that the displayed rotation direction is forward and that the displayed motor speed corresponds to the present rotating speed.

Example: **3.00 (%)**

- ③ Turn the motor clockwise as viewed from the load side.

Make sure that the displayed rotation direction is reverse and that the displayed motor speed corresponds to the present rotating speed.

Example: **-3.00(%)**

- ④ If the display unit does not show the motor rotation direction and motor speed correctly, check the wiring by referring to Para. 3.2 (2) "Connection Diagram of PG Card Option".

4.5 SETTING THE CARRIER FREQUENCY

If magnetic noise of a motor poses problems, it is possible to lower noise level by changing the setting for the upper limit of the carrier frequency at C6-01. Note that this is not possible for all types of inverters. Table 12 shows whether or not noise reduction is possible by changing the setting for the carrier frequency upper limit for the individual inverter types.

Carrier frequency is set at 2 kHz at the factory. The setting range of the carrier frequency upper limit is indicated in Table 12.

Table 12 Setting the Carrier Frequency Upper Limit

Type CIMR-H5	Noise Reduction	Setting Range of Carrier Frequency
D20P4 - D2018	Possible	0.4 to 15.0 kHz*
D2022 - D2075, A2030 - A2075	Possible	0.4 to 10.0 kHz*
D40P4 - D4030, D4037 - D4160, A4055 - A4160		
A4185 - A4300	Not possible	0.4 to 2.5 kHz*

*Carrier frequency lower limit is 2.0 kHz during vector control

NOTE

When changing the carrier frequency, contact your Yaskawa representative. The continuous rated current can be output when carrier frequency is set at 2 kHz. To reduce noise level by increasing the carrier frequency, it will be necessary to lower the rated current.

4.6 SETTING THE RATED SPEED

The inverter is set at the factory so that the motor rotates at the rated speed when the speed reference of "100%" is input.

To change the rated speed meeting the machine specifications, set the required speed for constant C9-01 (rated speed adjustment).

Motor speed at 100% speed reference

$$= \text{Max. speed (E1-04)} \times \text{Rated speed adjustment (C9-01)}$$

Note: The value of "max. speed × rated speed adjustment" must not exceed 1.2 times the rated motor speed

Example: Adjustment for rotating the motor (rated speed: 1750 r/min) at 2100 r/min by inputting speed reference of 100%.

Rated speed adjustment (C9-01): 1.0000 → 1.2000

With No. 2 motor, "E4-01" is used instead of "E1-04".

4.7 SETTING FOR THERMISTOR

Standard motors for inverter have specific thermistor as standard.

If the motor to be used is a general-purpose motor which does not have a thermistor, set "0" for "L9-01 (No. 2 motor: L9-04)".

4.8 SELECTION OF OPERATION MODE

With VS-676H5, two operation modes of LOCAL and REMOTE are provided. Selection of the operation mode is possible by using the [LOCAL/REMOVE] key on the digital operator while the inverter is stopped. The presently selected operation mode can be visually confirmed by the SEQ and REF LEDs on the digital operator.

The operation mode is set to "REMOTE" in the factory, in which the inverter operates by the speed reference set by the option and the run command given by the option. The multi-function inputs of 9CN-19 to 9CN-24 are valid, regardless of the selected operation mode.

- LOCAL: The digital operator is used to set both the speed reference and run command. In the LOCAL mode, neither the SEQ nor the REF LEDs are not lit.
- REMOTE: The speed reference and run command are selected by the constants as indicated in Table 13.

Table 13 Command Selection by Constants in the REMOTE Mode

Constant No.	Name	Description
B1-01	Speed reference selection	<p>0 : Master speed reference from the digital operator (D1-01) (REF LED on the digital operator: OFF)</p> <p>1 : Master speed reference from control circuit terminals 9CN-4 and 9CN-6 (REF LED on the digital operator: ON)</p> <p>2 : Master speed reference set by MEMOBUS (REF LED on the digital operator: Blinking)</p> <p>3 : Master speed reference set by the MEMOBUS option (REF LED on the digital operator: Blinking)</p>
B1-02	Run command selection	<p>0 : The motor starts running in response to the run command of the digital operator (SEQ LED on the digital operator: OFF)</p> <p>1 : The motor starts running in response to the run command input from the control circuit terminal 9CN-17. (SEQ LED on the digital operator: ON)</p> <p>2 : The motor starts running in response to the run command input by MEMOBUS. (SEQ LED on the digital operator: Blinking)</p> <p>3 : The motor starts running in response to the run command input from the MEMOBUS option (SEQ LED on the digital operator: Blinking)</p>

4.9 AUTO-TUNING

NOTE

1. Since the motor starts running automatically during auto-tuning, disconnect the motor from the machine so that starting the motor does not create hazardous conditions.
2. In the auto-tuning mode, signals input to the control circuit terminals are all disregarded.
3. At the start of tuning, input the RUN command only after making sure that the motor has been stopped.

(1) Operation Procedure

(a) Confirm the safety.

Confirm the following:

- The motor is disconnected from the machine.
- The lock key is removed from the motor shaft.
- There are no persons or objects near the motor shaft.
- The brake has been released (for the motor with the braking unit).
- Inspection and setting have been made according to the instructions stated in Paras. 4.1 and 4.2.

(b) Turn the power to the inverter ON.

Confirm the following:

- There are no abnormalities.
- Rotation direction of the PG (for the inverter with the PG).

(c) Select the program mode.

Select the program mode by the [DRIVE/PRGM] key. When the program mode is selected, the DRIVE LED is turned off.

(d) Input the values indicated on the nameplate or motor constants.

- Auto-tuning by inputting the values indicated on the nameplate
Input the nameplate values to the T2 constants.

Constant No.	Input Data	Setting Range	Description
T2-01	Motor base voltage	0.0 to 255.0 V	Input the value indicated on the nameplate
T2-02	Motor rated current	0.00 to 2000.0 A	Input the value indicated on the nameplate Input the base side value 7.5 kW or smaller types: 0.01 A units
T2-03	Motor base frequency	0.00 to 400.00 Hz	Input the value indicated on the nameplate
T2-04	Motor base speed	0 to 24000 r/min	Input the value indicated on the nameplate
T2-05	Number of poles	2 to 48	Input the value indicated on the nameplate
T2-06	Motor insulation class	0 to 4	Input the number corresponding to the value indicated on the nameplate Insulation class A (100°C) 0 E (120°C) 1 B (130°C) 2 F (155°C) 3 H (180°C) 4
T2-07	PG constants	0 to 10000	

- Auto-tuning by inputting the motor constants to the E constants
Input the data directly to the E constants.

(e) Input the motor selection and tuning mode selection.

- Input the data to the T1 constants

Constant No.	Input Data	Setting Range	Description
T1-01	Motor selection	1/2	1: No 1 motor 2: No 2 motor
T1-02	Tuning mode	0 to 4	0: Normal operation mode 1: Tuning by inputting nameplate value (digital operator) 2: Tuning by inputting motor constants (digital operator) 3: Tuning by inputting nameplate value (master controller) 4: Tuning by inputting motor constants (master controller)

Notes

1 No 2 motor setting is valid for PROM No 1030 and after. With previous model inverters, selection of No 2 motor is not permitted. With No 2 motor, auto-tuning is possible only in the "open loop vector control" if the PG card is not installed. (PROM No can be monitored by U1-14.)

2 Auto-tuning is disabled if a fault occurs. (Return to 0.)

(f) Select the drive mode.

Select the drive mode by pressing the [DRIVE/PRGM] key. When the drive mode is selected, the DRIVE LED is turned ON.

The following is displayed.

CAL

: Selected motor No.

: Tuning mode

(g) Execute the auto-tuning.

Press the [RUN] key.

The following begins flashing and tuning starts.

CAL

(h) End of tuning

Ending normally: **End** is displayed.

Ending abnormally: **Er -XX** is displayed (see Table 14).

Warning: If the load exceeds 20% during tuning, warning message of "**End20**" is displayed.

(2) Error Processing in Auto-tuning

- Fault (major, minor) which could occur during normal operation is detected during auto-tuning.
- If a fault occurs including minor fault, the motor stops after coasting (base block) and auto-tuning is interrupted regardless of the fault stop mode.
- During auto-tuning, errors indicated in Table 14 are also detected in addition to the faults which could occur in normal operation.
- The motor stops after coasting (base block) and auto-tuning is interrupted if any of these errors is detected. The error messages are not logged in the fault history.
- It is possible to forcibly interrupt auto-tuning by pressing the [STOP] key. When the [STOP] key is pressed, the motor stops after coasting (base block).
The stop command given from the master controller has the same effect as the input of the [STOP] key.
- When the auto-tuning is interrupted, the value set for T1-02 is automatically returned to "0" and the setting for all constants (including T□-0□) is automatically returned to the setting made before the start of auto-tuning.
- If an error has occurred during coasting and regaining speed or during deceleration to stop at the end of tuning, error display is given in the display unit of the digital operator. In this case, the auto-tuning is not interrupted and the results of tuning are valid.

Table 14 Auto-tuning Error Messages

Error Message	Contents	Description
Er-01	Motor data error (only in the nameplate value input mode)	The initial values calculated by the input data are outside the setting range
Er-02	Acceleration error	The set speed is not reached within the time of "acceleration time + 10 seconds"
Er-03	Motor rotation direction error (only in the control with PG)	During acceleration, torque reference is 100% or larger and the signs of speed reference and detected speed value do not agree with each other = Incorrect connection of PG (A- and B-phase) or inverter output (U-, V-, and W-phase)
Er-04	Motor speed error	With PG During acceleration, torque reference is 100% or larger and the signs of speed reference and detected speed value agree with each other = Motor overload, setting error of number of PG pulses Without PG During acceleration, torque reference is 100% or larger = Motor overload
Er-05	Line resistance error	<ul style="list-style-type: none"> Voltage command exceeds 100% Feedback current is less than 1% of motor rated current even when the voltage reference exceeds 50% Result of tuning is negative (Feeder resistance value is excessive) Tuning has not been completed within 5 minutes
Er-06	No-load current error	These errors are detected according to the setting for the constants.
Er-07	Iron-core saturation coefficient 1 error	<ul style="list-style-type: none"> The result of tuning is outside the setting range of a constant In the case of upper limit over of iron-core saturation coefficient 1 and 2, it is processed as limit over and it does not cause an error
Er-08	Iron-core saturation coefficient 2 error	
Er-09	Rated slip error	<ul style="list-style-type: none"> Tuning has not been completed within 1 minute for the individual tuning and constants
Er-10	Stop command input	The stop command is input by the pressing of the [STOP] key, etc

(3) Processing after the Completion of Tuning


- According to the selection of No. 1/No. 2 motor, the results of tuning are entered into the constants. The constants other than the tuning results such as accel./decel. time and ASR gain are automatically returned to the previously set values.
- After the completion of entire processing of auto-tuning, the setting for T1-02 is returned to "0" and "**End**" display is given for 3 seconds.
- If load exceeds 20% during tuning, the warning message indicated in Table 14 is given.

Table 15 Auto-tuning Warning Messages

Warning Message	Contents	Description
End20	Overload during tuning	During tuning, torque reference has exceeded 20%

5 SETTING OPERATION CONDITIONS

5.1 DIGITAL OPERATOR KEY DESCRIPTION



Mode Indicator LEDs

All LEDs blink if an error occurs in the drive mode

Drive Mode Display

Lights when the drive mode is selected - OFF when the program mode is selected

Rotating Direction Display

FWD Lights when forward run command is input
REV Lights when reverse run command is input

Remote Mode

Operation mode using the signals input from the control circuit terminals or option cards

SEQ Lights when the remote mode is selected for the run command

REF Lights when the remote mode is selected for the speed reference

Display

Displays set values of each function or monitoring values such as speed and output current (5 characters)

Mode Selection Key

Selects the drive mode and the program mode alternately. Selection of a mode is possible even during operation. When the drive mode is selected, the DRIVE LED lights

Display Selection Key

Selects the data to be displayed in predetermined sequence. Display sequence is explained in Para 5.3 "DRIVE MODE".

Read/Write Key

Displays the set values of the constants. Pressing this key again after setting a value enters it.

Numeric Value Change Keys

Changes set values or constant numbers

^ : Increment key

v : Decrement key

Digit Selection Key

Selects the digit of a set value to be changed. The selected digit blinks. This key is also used as the reset key if a fault is displayed.

Operation Command Keys

Used to operate the inverter by the digital operator. They are valid only in the drive mode.

* STOP : Red LED lights when STOP is pressed

* RUN : Red LED lights when RUN is pressed


FWD/REV : Selects forward or reverse run

JOG : Jog run is possible while JOG key is held pressed

Operation Mode Selection Key

Selects the REMOTE and LOCAL (digital operator) mode alternately

* RUN or STOP LED changes in accordance with the following operations.



Note : The RUN and STOP LED light, blink, and go OFF according to the run status.

Fig. 27 Digital Operator Key Description

5.2 DIGITAL OPERATOR MODE SELECTION

The digital operator of the VS-676H5 has the two operation modes, drive mode and program mode.

Mode selection is made by the mode selection key. Even during operation, it is possible to change the mode. The inverter keeps operating even if the mode is changed to the program mode during running to set or display the constant values. There are constants for which setting is not allowed during running. For these constants, refer to Appendix 6, "TABLE OF CONSTANTS".

When the run command is input while the inverter is at a stop with the program mode selected, the inverter does not start operating.

Drive mode: Inverter operation is possible. Displays monitor values, fault trace or fault log.

Program mode: Sets/reads constants.

5.3 DRIVE MODE

The inverter can operate in this mode. Run data display and fault display are possible.

Each time the display selection key is pressed, the item to be monitored is changed. At an occurrence of a fault, the digital operator enters the fault display mode automatically. The display mode returns to the one selected previously by pressing the [RESET] key.

Table 16 Typical Operation in Drive Mode

Description	Key Operation	Digital Operator Display
Power ON*1	DSPL	P00.00
Speed Reference*2	DSPL	0.00
Motor Speed	DSPL	0.00R
Output Current	DSPL	0.0J
Output Voltage*3	DSPL	
U Constants*4	DSPL	U1-01 ^{*5}

*1 The first item to be displayed after power ON can be selected from speed reference, motor speed, output current, and output voltage by setting an appropriate value for O1-02.

*2 A speed reference can be set by using the numerical value change keys and digit selection key.

*3 Instead of the output voltage, required U1 constant can be displayed by setting the appropriate value corresponding to the U constant to be displayed for O1-01.

*4 Select the U constant to be displayed by using the numerical value change keys and digit selection key

*5 : The U constant selected previously is displayed

(1) Changing the Speed Reference Value

(Operation Example)

Changing the speed reference value from 0.00% to 100.00% in the LOCAL and drive modes.

Table 17 Changing the Speed Reference Value

Description	Key Operation	Digital Operator Display	Remarks
▪ To display the speed reference value	DSPL	P 00.00	
▪ To change the value to "100.00%"	▼ ▲ > RESET	P 10.00	The value to be set blinks
▪ To write the set value	DATA ENTER	P 100.0	Display stops blinking for 2 seconds
		P 100.0	Display starts blinking again

(2) Monitor Display

(Operation Example)

Monitoring DC bus voltage (U1-07) during speed reference display.

Table 18 Typical Monitor Display Operation

Description	Key Operation	Digital Operator Display	Remarks
▪ During the display of speed reference		P 100.0	
▪ To display the U constant	DSPL	U 1-01	
▪ To select U1-07	▼ ▲ > RESET	U 1-07	The U constant selected previously is displayed
▪ To display monitored value	DATA ENTER	Pn3 10	
▪ To return to U1-07 display	DSPL	U 1-07	
▪ To return to speed reference display	DSPL	P 100.0	

5.4 SETTING THE INVERTER OPERATION ENVIRONMENT

Access level to set/read constants and control mode (V/f control, vector control) can be set as indicated below. Make sure to set the environment setting constants before using the VS-676H5.

The following table shows the major environment setting constants.

Table 19. Environment Setting Constants

Constant No.	Name	Description
A1-01	Access level (can be changed during run)	0 For monitoring (To set/read A1-01 and read U constants for quick-start level) 2 QUICK-START (To set/read the constants necessary for simplified operation) 3 BASIC (To set/read the basic constants) 4 ADVANCED (To set/read the application constants)
A1-02	Control mode selection	0 V/f control 1 V/f control with PG feedback 2 Open loop vector 3 Flux vector 4 EMS control
A1-03	Initialization	2220 Constants initialization
A1-04	Password 1 (for inputting)	Input password 1
A1-05	Password 2 (for setting)	Input password 2 (set/read is possible only in the MEMOBUS)

NOTE


If password 1 ≠ password 2, setting is disabled for A1-01 to A1-03. For these constants, only reading is permitted and the environment setting constants are locked.

(1) Changing the Control Mode

(Operation Example)

Changing the operation mode from the open loop vector to the V/f control


Table 20 Typical Control Mode Change Operation

Description	Key Operation	Digital Operator Display	Remarks
<ul style="list-style-type: none"> ▪ During the display of speed reference ▪ To change the mode to the program mode ▪ To select A1-02 ▪ To display the set value ▪ To change the control mode ▪ To write the set value ▪ To return to the display of constant number ▪ To return the mode to the drive mode 			<p>The constant number selected previously is displayed</p> <p>Display for 0.5 sec</p> <p>Returns to the display before writing</p>

5.5 SETTING AND READING CONSTANTS (PROGRAM MODE)

The constants of the VS-676H5 are composed of group symbol, function number and serial umber of each function. Use numeric value change keys to change the group and function display and select one by the [DATA/ENTER] key. For details of the constants, refer to Appendix 6, "TABLE OF CONSTANTS".

Constant No.



Group symbol

U: Monitor constants
(only reading is enabled.)

A: Environment setting constants

B: Application-related constants

C: Adjustment constants

D: Speed reference related constants

E: Motor related constants

F: Option related constants

H: Control circuit terminal related constants

L: Protection related constants



O: Digital operator related constants

T: Auto-tuning related constants
(not stored)

(Operation Example 1)

Changing the deceleration time (C1-02) from 10.0 seconds to 20.0 seconds during the display of speed reference when QUICK-START is selected (A1-01 = 2).

Table 21 Typical Constant Data Change Operation (QUICK-START Selected)

Description	Key Operation	Digital Operator Display	Remarks
<ul style="list-style-type: none"> ▪ During the display of speed reference ▪ To change the mode to the program mode ▪ To select C1-02 ▪ To display the present setting ▪ To change the set value ▪ To write the set value ▪ To return to the display of constant number ▪ To return the mode to the drive mode 			<p>The constant number selected previously is displayed</p> <p>Display for 0.5 sec</p> <p>Returns to the display before writing</p>

NOTE

When the QUICK-START is selected, to select the constant number of U constants, use the [RESET] key to select the digit to be changed and select the constant number by pressing the numeric value change keys.

(Operation Example 2)

Changing the deceleration time (C1-02) from 10.0 seconds to 20.0 seconds during the display of speed reference when BASIC or ADVANCED is selected.

Table 22 Typical Constant Data Change Operation (BASIC or ADVANCED Selected)

Description	Key Operation	Digital Operator Display	Remarks
<ul style="list-style-type: none"> During the display of speed reference To change the mode to the program mode To select C1-02 To display the present setting To change the set value To write the set value To return to the display of constant number To return the mode to the drive mode 			<p>The constant number selected previously is displayed</p> <p>Display for 0.5 sec</p> <p>Returns to the display before writing</p>

6 OPERATION



WARNING

- Only turn ON the input power supply after replacing the front cover. Do not remove the cover while current is flowing.
Failure to observe this warning can result in an electrical shock.
- When the retry function (L5-02) is selected, do not approach the inverter or the load, since it may restart suddenly after being stopped.
(Construct machine system, so as to assure safety for personnel, even if the inverter should restart.)
Failure to observe this warning can result in personal injury.
- Since the stop button can be disabled by a function setting, install a separate emergency stop switch.
Failure to observe this warning can result in personal injury.
- If an alarm is reset with the operation signal ON, the inverter restarts automatically. Only reset the alarm after verifying that the operation signal is OFF.
Failure to observe this warning can result in personal injury.



CAUTION

- Never touch the heatsink or discharging resistor since the temperature is very high.
Failure to observe this caution can result in harmful burns to the body.
- Since it is easy to change operation speed from low to high speed, verify the safe working range of the motor and machine before operation.
Failure to observe this caution can result in personal injury and machine damage.
- Install a holding brake separately if necessary.
Failure to observe this caution can result in personal injury.
- Do not change signals during operation.
The machine or the inverter may be damaged.
- All the constants of the inverter have been preset at the factory. Do not change the settings unnecessarily.
The inverter may be damaged. For supply voltage, follow Para. 4.3.

This chapter describes the basic operation procedures of the VS-676H5.

6.1 TEST RUN

(1) Digital Operator Display at Power-up

When the system is ready for operation, turn ON the power supply. Verify that the inverter powers up properly. If any problems are found, turn OFF the power supply immediately. The digital operator display illuminates as shown below when turning the power supply ON.




Fig. 28 Digital Operator Display at Power-up

(2) Operation Check Points

Check the following items during operation.

- Motor rotates smoothly.
- Motor rotates in the correct direction.
- Motor does not have abnormal vibration or noise.
- Acceleration and deceleration are smooth.
- The current matching the load flows.
- Status indicator LEDs and digital operator display are correct.

(3) Example of Basic Operation

(a) Operation by Digital Operator

The diagram below shows a typical operation pattern using the digital operator.




Fig. 29 Operation Sequence by Digital Operator

Table 23 Typical Operation by Digital Operator

Description	Key Sequence	Digital Operator Display
<p>① Power ON • Displays speed reference value.</p> <p>Operation Condition Setting • Select LOCAL mode.</p>		 REMOTE LED OFF (SEQ, REF) FWD LED lights.
<p>② Forward Jog Run (10%) • JOG run procedure (Runs while depressing JOG key.)</p>		
<p>③ Speed Setting • Change reference value.</p> <p>• Write-in set value.</p> <p>• Select motor speed monitor display.</p>	 	 Digit to be changed blinks. (Stops blinking for 2 sec.) RUN LED lights.
<p>④ Forward Run • Forward run (25%)</p>		

Table 23 Typical Operation by Digital Operator (Cont'd)

Description	Key Sequence	Digital Operator Display
⑤ Speed Reference Value Change (25% → 100%) • Select frequency reference value display.	DSPL	P 25.00
• Change set value.	Change the value by pressing RESET	P 100.0 Digit to be changed blinks.
• Write-in set value.	DATA ENTER	P 100.0 (Stops blinking for 2 sec.)
• Select motor speed monitor display.	DSPL	25.00 ↓ 100.0
⑥ Reverse Run • Switch to reverse run.	FWD REV	- 100.0 REV LED lights.
⑦ Stop • Decelerates to a stop.	STOP	0.00 STOP LED lights. (RUN LED blinks during deceleration.) STOP

(b) Operation by Control Circuit Terminal Signal

The diagram below shows a typical operation pattern using the control circuit terminal signals.




Fig. 30 Operation Sequence by Control Circuit Terminal Signal

Table 24 Typical Operation by Control Circuit Terminal Signal

Description	Key Sequence	Digital Operator Display
① Power ON		
Program mode selection	DRIVE PRGM	
Setting speed reference from the control circuit terminal Setting "B1-01 = 1"	▼▲ DATA ENTER	b 1-01 03 01
	▼▲> DATA ENTER	End 01
	DSPL	b 1-01 02
Setting run command from the control circuit terminal Setting "B1-02 = 1"	▼▲ DATA ENTER	b 1-02 03 01
	▼▲> DATA ENTER	End 01
	DSPL	b 1-02 P 0.00
Drive mode selection	DRIVE PRGM	Displays speed reference value.

Table 24 Typical Operation by Control Circuit Terminal Signal (Cont'd)

Description	Key Sequence	Digital Operator Display
② Speed Setting • Input speed reference voltage from control circuit terminal 9CN-4 and verify the input value by the digital operator.		 P 100.0 Reference voltage. 10 V
Changing to motor speed display	DSPL.	 0.00
③ Forward Run • Close the control circuit terminals 9CN-17 to 9CN-25 to perform forward run.		 100.00 RUN LED lights. FWD LED lights.
④ Stop • Open the control circuit terminals 9CN-17 to 9CN-25 to stop operation.		 0.00 STOP LED lights. (RUN LED blinks during deceleration.)

7 MAINTENANCE AND INSPECTION



WARNING

- Never touch high-voltage terminals in the inverter.
Failure to observe this warning can result in an electrical shock.
- Replace all protective covers before powering up the inverter. To remove the cover, make sure to shut OFF the molded-case circuit breaker.
Failure to observe this warning can result in an electrical shock.
- Perform maintenance or inspection only after verifying that the CHARGE LED goes OFF, after the main circuit power supply is turned OFF.
The capacitors are still charged and can be dangerous.
- Only authorized personnel should be permitted to perform maintenance, inspections or parts replacement.
[Remove all metal objects (watches, bracelets, etc.) before operation.]
(Use tools which are insulated against electrical shock.)
Failure to observe this warning can result in an electrical shock.



CAUTION

- The control PC board employs CMOS ICs. Do not touch the CMOS elements.
They are easily damaged by static electricity.
- Do not connect or disconnect wires or connectors while power is applied to the circuit.
Failure to observe this caution can result in personal injury.

This chapter describes basic maintenance and inspection procedures for the VS-676H5.

7.1 PERIODIC INSPECTION

Perform the inspection as indicated below to ensure reliable operation of VS-676H5 for a prolonged time by preventing faults.

Before servicing, turn OFF the main circuit power and be sure that the CHARGED LED is OFF.

Table 25 Periodic Inspection

Component	Check	Corrective Action
External Terminals, Unit Mounting Bolts, Connectors, etc.	Loose screws	Tighten
	Loose connectors	Tighten.
Heatsink	Build-up of dust and dirt	Blow with dry compressed air of 39.2×10^4 to 58.8×10^4 Pa (4 to 6kg/cm ²) pressure.
Printed Circuit Board	Accumulation of conductive dust or oil	Blow with dry compressed air of 39.2×10^4 to 58.8×10^4 Pa (4 to 6kg·cm ²) pressure If dust and oil cannot be removed, replace the board
Cooling Fan	For abnormal noise and vibration Whether the cumulative operation time exceeds 20,000 hours or not	Replace the cooling fan
Power Elements	Accumulation of dust and dirt	Blow with dry compressed air of 39.2×10^4 to 58.8×10^4 Pa (4 to 6kg·cm ²) pressure
Smoothing Capacitor	Discoloration or odor	Replace the capacitor or inverter unit

7.2 PARTS REPLACEMENT SCHEDULE (GUIDELINES)

Replace the following parts periodically, for a long, safe, trouble free working life of VS-676H5.

Table 26 Parts Replacement Schedule

Parts	Interval (Approx.)	Remarks
Cooling Fan	2 to 3 years	Replace with new one.
Smoothing Capacitor	5 years	Replace with new one. (Decided after inspection.)
Breakers or Relays	—	Decided after inspection.
Fuse	10 years	Replace with new one.
Aluminum Electrolytic Capacitor on PC Board	5 years	Replace with new one. (Decided after inspection.)

NOTE

Operating conditions are as follows:

Ambient temperature : 30°C yearly average

Load factor : 80% or below

Operation rate : 20 hours or below /day

8 TROUBLESHOOTING

This chapter describes the inverter fault display and the fault contents caused by motor/machine malfunctions and the corrective actions to be taken.

8.1 FAULT DIAGNOSIS AND CORRECTIVE ACTIONS

- (1) When the VS-676H5 detects a fault, it activates the fault contact output to turn ON or blink the LEDs on the control card as indicated in Table 27. Details of faults can be checked by connecting the digital operator to 1CN. Check the cause in the tables in the following pages and take the corrective actions by referring to Table 28, "Fault Diagnosis and Corrective Actions".
- (2) If the inspections or corrective actions described cannot solve the problem, contact your YASKAWA representative immediately.
- (3) To restart, turn ON the reset input signal or depress [>RESET] key or shut OFF the main circuit power supply once, to reset the stop status.

Table 27 Status Indication by LEDs

Green	Red	Description
OFF	OFF	Base block status (excluding major fault)
ON	--	Running
Blinking	--	The motor does not run although the run command is input Speed reference < E1-09 (V/f control without PG, V/f control with PG, vector control without PG) External base block signal is input
--	Blinking	Minor fault
--	ON	Major fault
ON	ON	Flash write-in mode
During one blinking cycle (Note)	Blinks 1 time	Watchdog error (Control card error)
	Blinks 2 time	RAM check error (Control card error)
	Blinks 3 time	Sum check error (Control card error)
	Blinks 4 time	Illegal command (Control card error)
	Blinks 5 time	Slot illegal command (Control card error)
	Blinks 6 time	CPU bus error (Control card error)
	Blinks 7 time	DMA bus error (Control card error)

(Note) Example Sum check error




Table 28 Fault Diagnosis and Corrective Actions

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
Uu1	Main circuit undervoltage (PUV)	Undervoltage in the direct current main circuit during running Detection level 200 V class Approx 190 V or less 400 V class Approx 380 V or less		A
Uu2	Control circuit undervoltage (CUV)	Undervoltage in the control circuit during running	Check the power supply wiring Correct the line voltage	A
Uu3	Pre-charge contactor open	The pre-charge contactor opened during running		A
Uu4	Power unit control supply undervoltage	Undervoltage in the power unit control supply during running		A
Uu	Momentary power loss	The main circuit direct current voltage fell below the PUV level The pre-charge contactor opened The control power source fell below the CUV level		B
GF	Ground fault (GF) (Earth fault)	Inverter output grounding current exceeded 50% of inverter rated current	Check that motor insulation has not deteriorated Check that connection between inverter and motor is not damaged	A
OC	Overcurrent (OC)	The inverter output current exceeded the OC level	Check the motor coil resistance Extend the accel/decel time Check the motor insulation Multi-meter check	A
OU	Overvoltage (OV)	The main circuit direct current voltage exceeded the OV level Detection level 200 V class Approx 400 V 400 V class Approx 800 V	Extend the deceleration time, add braking circuit	A
OS	Overspeed (OS)	The motor speed exceeded the overspeed level	Check the load	A
dEo	Speed deviation (DEV)	The deviation of the speed reference and speed feedback exceeded the regulation level	Check the load	A
PGo	PG open circuit (PGO)	The PG line is broken	Check the PG line Check the condition of the motor lock or the load	A
T HA	Thermistor open circuit	Motor temperature detection thermistor wiring is broken	Check the thermistor	A
PF	Excessive ripple in DC bus bar voltage	Inverter input power supply has open-phase Large unbalance in input voltage	Check the line voltage Re-tighten the input terminal screws	A
LF	Output open-phase	Inverter output has open-phase	Check the output wiring Check the motor impedance Re-tighten the output terminal screws	A

Table 28 Fault Diagnosis and Corrective Actions (Cont'd)

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
SC	Load short-circuit (SC)	Inverter output (load) is short-circuited	Check the motor coil resistance Check the motor insulation	A
UnbC	Current unbalance	Output current of individual power units became unbalanced (Detects models of 600kW or larger)	Check the wiring	A
oH4	Converter overheat	Converter fin temperature exceeds 105°C (Detects models of 600kW or larger)	Check the fan and the ambient temperature	A
PUF	Fuse blown (FU)	The output transistors were damaged The direct current circuit fuse is blown	Check for damaged transistor, load side short circuit, grounding, etc	A
oH	Heatsink overheat warning	The transistor heatsink temperature exceeded the allowable value	Check the heatsink and ambient temperature	B
oH1	Heatsink overheat	The transistor heatsink temperature exceeded the allowable value	Check the filter and fan	A
oH3	Motor overheat	The motor temperature exceeded the allowable value	Reduce the load Check the ambient temperature.	A
oL1	Motor overload	Inverter output exceeded the motor overload level	Reduce the load	A
oL2	Inverter overload	Inverter output exceeded the inverter overload level	Reduce the load Extend the acceleration/deceleration time	A
oL3	Overtorque 1	Torque exceeded the overtorque detection level	Check the load	A/B
oL4	Overtorque 2	Torque exceeded the overtorque detection level 2		A/B
rr	Braking transistor failure	The braking transistor has failed.	Replace the inverter.	A
rH	Braking resistor unit overheat	The braking resistor unit temperature has exceeded the allowable value. (Protects only inverter built-in type)	Reduce the regenerative load	A
EFO	External fault by master controller	External fault was input from the master controller	External fault, defined by user specification, was input from the master controller. Find the external fault items from the I/O list and correct it.	A/B
EF3	External fault at terminal 3 (9CN-19)	Fault occurred in the external control circuit	Check the condition of the input terminal If the LED lights when terminal is not connected, replace the inverter	A
EF4	External fault at terminal 4 (9CN-20)			A
EF5	External fault at terminal 5 (9CN-21)			A
EF6	External fault at terminal 6 (9CN-22)			A

Table 28 Fault Diagnosis and Corrective Actions (Cont'd)

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
EF7	External fault at terminal 7 (9CN-23)	Fault occurred in the external control circuit	Check the condition of the input terminal	A
EF8	External fault at terminal 8 (9CN-24)		If the LED lights when terminal is not connected, replace the inverter	A
SE 10	Motor change error	Motor was changed in program mode, EMS control mode, or during motor running	Make sure that the digital operator is in the drive mode Make sure that the control mode is not EMS control Make sure that the motor is not running	B
CPF00	Control circuit fault 1	Transmission between the inverter and digital operator cannot be established until 5 seconds after supplying power MPU peripheral element check faulty (at power-up)	Insert the digital operator connector again Check the control circuit wiring Replace the control card	A/B
CPF01	Control circuit fault 2	Transmission between the inverter and digital operator is established once after supplying power, but later transmission faults continue three times for a duration of more than 2 seconds each time MPU peripheral element check fault (at power-up)	Insert the digital operator connector again Check the control circuit wiring Replace the control card	A/B
CPF02	Baseblock circuit fault (CPF02)	Inverter control unit fault	Replace the control card	A
CPF03	EEPROM fault (CPF03)			A
CPF04	CPU internal A/D converter fault			A
CPF05	CPU external A/D converter fault			A
CPF06	Option card connection fault	The option card is not installed correctly	Install the option card again	A
CPF07	PWM timer fault	Inverter control-unit fault (Detects models of 600kW or larger)	Replace the control card	A
CPF08	Common RAM BCC error			A
CPF09	Cross-diagnose fault between common RAMs			A
CPF10	Common RAM initial check fault			A
CPF21	Transmission control card hardware fault	Transmission control card hardware check error (at power-up)	Replace the control card	A
CPF22	Transmission control card code No error	Transmission control card which is not applicable for the inverter is connected	Replace the control card with applicable one	A
CPF23	Cross-diagnose fault between master controller and control card	Diagnosis data has not been updated for more than 0.2 seconds between the transmission control card and the control card	Replace the transmission control card	A

Table 28 Fault Diagnosis and Corrective Actions (Cont'd)

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
Err	EEPROM writing fault (ERR)	EEPROM internal data did not match when initializing the constant	Replace the control card	B
bus	CP-216 Transmission error	CP-216 Transmission error continued for 25 seconds	Check transmission devices and transmission signals	A/B
base	Base test mode fault	During the test, main circuit DC power supply voltage exceeded 20 V	Lower the main circuit DC voltage	C
oPE01	kVA selection fault	Inverter capacity selection fault	Check and set the constant data	C
oPE02	Constant setting range fault	Constant data is out of range	Check the constant data settings	C
oPE03	Multi-function contact input selection fault	In H1-01 to H1-06 settings Not set in the ascending order The same values are set except for F and FF	Check the function selection	C
oPE05	Option reference selection fault (OPE05)	C-option is not connected although speed reference from C-option is selected C-option is not connected although run command from C-option is selected	Check and set the constant data. Connect the C-option	B
oPE06	Control mode selection fault	PG card is not connected during flux vector control or V/f with PG feedback	Connect PG card	B
oPE10	V/f data setting fault (E1-04 to E1-10)	When the settings of E1-04 to E1-10 do not satisfy the following conditions: $E1-04 \geq E1-11 \geq E1-06 > E1-07 \geq E1-09$	Check the constants.	C
oPE11	Carrier frequency constant setting fault	Any of the following constant setting is not correct Carrier frequency upper limit (C6-01) > 5 Hz Carrier frequency lower limit (C6-02) ≤ 5 kHz Carrier frequency proportional gain (C6-03) > 6 (C6-01) $<$ (C6-02)	Check and set the constant data	C
opr	Digital operator fault	In the digital operator run command mode, the digital operator circuit is open (Detected only when O2-06 is set to 1)	Check the wiring and connectors Replace the control card	A

* The ranks are classified as follows:

Rank A : Major fault (Motor coasts to stop, digital operator indication lights, and fault contact is output.)

Rank B : Fault [Operation continues, digital operator indication blinks, no fault contact is output, and minor fault contact is output (when multi-function output is selected).]

Rank C : Warning (Operation cannot be performed, digital operator indication lights, no fault contact is output, no minor fault contact is output.)

8.2 MOTOR FAULTS AND CORRECTIVE ACTIONS

- (1) If any of the faults shown in 29 occurs in the motor, check the cause and provide the relevant corrective action.
- (2) If these inspections and corrective actions cannot solve the problem, contact your YASKAWA representative immediately.

Table 29 Motor Faults and Corrective Actions


Fault	Check Point	Corrective Action
Motor does not rotate	Power supply voltage applied to power supply terminals R, S, T? Is CHARGE LED ON?	<ul style="list-style-type: none"> • Turn ON power supply • Turn OFF power supply, and then ON again • Check power supply voltage • Make sure terminal screws are tight
	Use rectifier type voltmeter to test Voltage output to output terminals U, V, W correct?	Turn OFF power supply, then turn ON again
	Motor locks due to excessive load?	Reduce the load and release the lock
	Fault displayed in operator display?	Check troubleshooting table
	FWD or REV run command entered?	Check the wiring
	Frequency setting voltage entered?	<ul style="list-style-type: none"> • Correct the wiring • Check frequency setting voltage
Motor rotation reverses	Reference selection (b1-01), operation method selection(b1-02) correct?	Input the correct set value
	Wiring of terminals U, V, W correct?	Match wiring to the phase order of the motor leads U, V, W
	FWD and REV wiring run signals entered?	Correct the wiring
Motor rotates, but variable speed not available	Wiring of frequency setting circuit correct?	Correct the wiring
	Reference selection (b1-01), operation method selection(b1-02) correct?	With the digital operator, check the reference selection or operation mode selection
	Load excessively large?	Reduce the load
Motor r/min too high or too low	Motor ratings (number of poles, voltage) correct?	Check motor nameplate specifications
	Accel/decel speed change ratio for gears, etc correct?	Check speed changer (gears, etc)
	Maximum frequency set value correct?	Check the maximum frequency set value
	Use rectifier voltmeter Voltage between motor terminals not excessively reduced?	Check V/f characteristics values
Motor r/min not stable during operation	Load excessively large?	Reduce the load
	Load variation excessively large?	<ul style="list-style-type: none"> • Reduce the load variation • Increase inverter motor capacity
	Open phase?	<ul style="list-style-type: none"> • Check the wiring if power supply is open phase

8.3 DISPLAY SEQUENCE OF FAULT CODES

If more than one fault occurs, up to four faults are logged in the order of occurrence (excluding CPF00 and CPF01). They are displayed in order by pressing the  and  keys in the drive mode by connecting the digital operator.

The record of major fault is cleared when the fault is cleared by the fault reset operation.

Example of display:



① First display



② Pressing 




③ Pressing 



④ Pressing 



⑤ Pressing 



Returns to ②

8.4 MONITOR CONSTANTS RELATED WITH FAULTS

By using the U2 constants, it is possible to check the controlled status of the inverter at the occurrence of major faults only.

With the U3 constants, it is possible to check the contents of previous major faults only and the cumulative operation time until the occurrence of that fault (U1-13). The data are displayed for up to four faults from the latest fault. Since U2 and U3 constants are stored to the EEPROM, the stored data are retained even after the power is turned OFF.

NOTE

1. Concerning the contents of faults stored to U3-01 to U3-04, only lower three digits can be displayed since "F" is displayed in the first two digits.
Example: CPF05 is displayed as "**F F05**".
2. By initialization processing called by A1-03, U2 and U3 constants are cleared.

APPENDIX 1 SPECIFICATIONS

Table A-1 200 V Class Specifications (DC Input)

Inverter Model CIMR-H5D	20P4	20P7	21P5	22P2	23P7	25P5	27P5	2011	2015	2018	2022	2030	2037	2045	2055	2075
Max Applicable Motor Output (*1) kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Inverter Capacity kVA	1	1.5	2	3	5	7.5	10	15	20	25	30	40	50	60	70	100
Rated Output Current A	3.2	6	8	11	17.5	25	33	49	64	80	96	130	160	183	224	300
Max Output Voltage	3-phase, 190 V (*2)															
Output Frequency	Up to 400 Hz available by programming															
Power Supply	DC 270 to 330 V															
Allowable Voltage Fluctuation	+10%, -15%															
Control Characteristics																
Control Method	Sine wave PWM															
Starting Torque	150% / 0 r/min (150% / 1 Hz without PG)															
Speed Control Range	1 1000 (100 without PG)															
Speed Control Accuracy	±0.01% (±0.2% without PG)															
Speed Response	30 Hz (5 Hz without PG) (*3)															
Torque Limit	Available (Parameter setting, 4 quadrants can be changed)															
Torque Accuracy	±3% (*4)															
Torque Response	150 Hz (20 Hz without PG) (*5)															
Speed Control Range	0 to 24000 r/min (2-pole motor)															
Speed Reference Setting Resolution	Digital reference 30000/100% Analog reference 1000/100%															
Torque Reference Setting Resolution (Calculation Resolution)	Digital reference 10000/100% Analog reference 1000/100%															
Overload Capacity	150% of rated output current for 1 minute															
Accel/Decel Time	0.01 to 6000.0 sec (Accel/decel time setting independently, 2 steps available)															
Braking Torque	Approx 20%															
Protective Functions																
Motor Overload Protection	Protected by thermistor (*6) or electronic thermal overload relay															
Instantaneous Overcurrent	Motor coasts to a stop at approx 200% of inverter rated current															
DC Bus Line Protection	Motor coasts to a stop by blown-fuse															
Overload	150% of rated output current															
Oversupply	Motor coasts to a stop if converter output voltage exceeds 410 V															
Undervoltage	Motor coasts to a stop if converter output voltage drops to 190 V or below															
Momentary Power Loss	Immediately stop by 15 ms and above momentary power loss (Factory setting) Continuous operation during power loss less than 2 sec can be selected by operation mode															
Heatsink Overheat	Protected by thermistor															
Stall Prevention	Stall prevention during accel/decel and constant speed operation															
Ground Fault	Protected by electronic circuit (Overcurrent level)															
Power Charge Indication	Charge LED stays ON until bus voltage drops below 50 V															
Ambient Temperature	-10°C to +45°C (Enclosed wall-mounted type)															
Humidity	90% RH or less (Non-condensing)															
Storage Temperature	-20°C to +60°C (Not frozen)															
Location	Indoor (protected from corrosive gases and dust)															
Elevation	1000 m or less															
Vibration	9.8 m/s ² (1G) at 10 to less than 20 Hz, up to 2 m/s ² (0.2G) at 20 to 50 Hz															

*1 Based on a YASKAWA standard 4-pole motor for max applicable motor output

*2 Output voltage in the vector control mode (300 V DC input)

*3 Response when ratio of inertia between motor and load is 1 : 1

*4 To achieve this value tests are required by actually connecting to a motor

*5 Electric torque response

*6 Valid for the motor with built-in thermistor




Fig. A-1 Main Circuit Configuration (200 V Class DC Input)

Table A-2 400 V Class Specifications (DC Input)

Inverter Model CIMR-H5D	40P4	40P7	41P5	42P2	43P7	45P5	47P5	4011	4015	4018	4022	4030	4037	4045	4055	4075	4110	4160	4185 (*7)	4220 (*7)	4300 (*7)
Max Applicable Motor Output (*1) kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	110	160	185	220	300
Inverter Capacity kVA	1	1.5	2	3	5	7.5	10	15	20	25	30	40	50	60	80	100	140	200	250	300	400
Rated Output Current A	1.8	3.4	4.8	6.2	8	14	18	27	34	41	48	65	80	96	128	165	224	302	340	450	605
Rated Output Voltage	3-phase, 380 V (*2)																				
Rated Output Frequency	Up to 400 Hz available by programming																				
Power Supply	Rated Input Voltage and Frequency DC 540 to 660 V																				
Control Characteristics	Allowable Voltage Fluctuation +10%, -15%																				
	Control Method Sine wave PWM																				
	Starting Torque 150% / 0 r/min (150% / 1 Hz without PG)																				
	Speed Control Range 1 1000 (1 100 without PG)																				
	Speed Control Accuracy ±0.01% (±0.2% without PG)																				
	Speed Response 30 Hz (5 Hz without PG) (*3)																				
	Torque Limit Available (Parameter setting, 4 quadrants can be changed)																				
	Torque Accuracy ±3% (*4)																				
	Torque Response 150 Hz (20 Hz without PG) (*5)																				
	Speed Control Range 0 to 24000 r/min (2-pole motor)																				
Protective Functions	Speed Reference Digital reference 30000/100%																				
	Setting Resolution Analog reference 1000/100%																				
	Torque Reference Setting Resolution (Calculation Resolution) Digital reference 10000/100%																				
	Analog reference 1000/100%																				
	Overload Capacity 150% of rated output current for 1 minute																				
	Accel/Decel Time 0.01 to 6000.0 sec (Accel/decel time setting independently, 2 steps available)																				
	Braking Torque Approx 20%																				
	Motor Overload Protection Protected by thermistor (*6) or electronic thermal overload relay																				
	Instantaneous Over-current Motor coasts to a stop at approx 200% of inverter rated current																				
Environment	DC Bus Line Protection Motor coasts to a stop by blown-fuse																				
	Overload 150% of rated output current																				
	Overvoltage Motor coasts to a stop if converter output voltage exceeds 820 V																				
	Undervoltage Motor coasts to a stop if converter output voltage drops to 380 V or below																				
	Momentary Power Loss Immediately stop by 15 ms and above momentary power loss (Factory setting) Continuous operation during power loss less than 2 sec can be selected by operation mode																				
	Heatsink Overheat Protected by thermistor																				
	Stall Prevention Stall prevention during accel and constant speed operation																				
	Ground Fault Protected by electronic circuit (Overcurrent level)																				
	Power Charge Indication Charge LED stays ON until bus voltage drops below 50 V																				
Environment	Ambient Temperature -10°C to +45°C (Enclosed wall-mounted type)																				
	Humidity 90% RH or less (Non-condensing)																				
	Storage Temperature -20°C to +60°C (Not frozen)																				
	Location Indoor (protected from corrosive gases and dust)																				
	Elevation 1000 m or less																				
	Vibration 9.8 m/s ² (1G) at 10 to less than 20 Hz, up to 2 m/s ² (0.2G) at 20 to 50 Hz																				

*1 Based on a YASKAWA standard 4-pole motor for max applicable motor output

*2 Output voltage in the vector control mode (600 V DC input)

*3 Response when ratio of inertia between motor and load is 1 : 1

*4 To achieve this value tests are required by actually connecting to a motor

*5 Electric torque response

*6 Valid for the motor with built-in thermistor

*7 For 185 to 300 kW, model name is CIMR-H5A [] since an AC input and a unit are in common




Table A-3 200/400 V Class Specifications (AC Input)

Inverter Model CIMR-H5A	2030	2037	2045	2055	2075	4055	4075	4110	4160	4185	4220	4300																				
Max Applicable Motor Output (*1) kW	30	37	45	55	75	55	75	110	160	185	220	300																				
Inverter Capacity kVA	40	50	60	70	100	80	100	140	200	250	300	400																				
Rated Output Current A	130	160	183	224	300	128	165	224	302	340	450	605																				
Max Output Voltage	3-phase, 190 V (*2)				3-phase, 380 V (*2)																											
Output Characteristics	Rated Output Frequency Up to 400 Hz available by programming																															
Power Supply	Rated Input Voltage and Frequency 3-phase 200/208/220 V 50 Hz 200/208/220/230 V 60 Hz				3-phase 380/400/415/440/460 V 50/60 Hz																											
Allowable Voltage Fluctuation	+10%, -15%																															
	Allowable Frequency Fluctuation ±5%																															
Control Characteristics	Control Method Sine wave PWM																															
	Starting Torque 150% / 0 r/min (150% / 1 Hz without PG)																															
	Speed Control Range 1 1000 (1 100 without PG)																															
	Speed Control Accuracy ±0.01% (±0.2% without PG)																															
	Speed Response 30 Hz (5 Hz without PG) (*3)																															
	Torque Limit Available (Parameter setting, 4 quadrants can be changed)																															
	Torque Accuracy ±3% (*4)																															
	Torque Response 150 Hz (20 Hz without PG) (*5)																															
	Speed Control Range 0 to 24000 r/min (2-pole motor)																															
	Speed Reference Setting Resolution Digital reference 30000/100% Analog reference 1000/100%																															
	Torque Reference Setting Resolution (Calculation Resolution) Digital reference 10000/100% Analog reference 1000/100%																															
	Overload Capacity 150% of rated output current for 1 minute																															
	Accel/Decel Time 0.01 to 6000.0 sec (Accel/decel time setting independently, 2 steps available)																															
	Braking Torque Approx 20%																															
Protective Functions	Motor Overload Protection Protected by thermistor (*6) or electronic thermal overload relay																															
	Instantaneous Overcurrent Motor coasts to a stop at approx 200% of inverter rated current																															
	DC Bus Line Protection Motor coasts to a stop by blown-fuse																															
	Overload Motor coasts to a stop after 1 minute at 150% of rated output current																															
	Overvoltage Motor coasts to a stop if converter output voltage exceeds 410 V																															
	Undervoltage Motor coasts to a stop if converter output voltage drops to 190 V or below																															
	Momentary Power Loss Immediately stop by 15 ms and above momentary power loss (Factory setting) Continuous operation during power loss less than 2 sec can be selected by operation mode																															
	Heatsink Overheat Protected by thermistor																															
Environment	Stall Prevention Stall prevention during accel/decel and constant speed operation																															
	Ground Fault Protected by electronic circuit (Overcurrent level)																															
	Power Charge Indication Charge LED stays ON until bus voltage drops below 50 V																															
	Ambient Temperature -10°C to +45°C (Enclosed wall-mounted type)																															
	Humidity 90% RH or less (Non-condensing)																															
Storage Temperature -20°C to +60°C (Not frozen)																																
Location Indoor (protected from corrosive gases and dust)																																
Elevation 1000 m or less																																
Vibration 9.8 m/s² (1G) at 10 to less than 20 Hz, up to 2 m/s² (0.2G) at 20 to 50 Hz																																

*1 Based on a YASKAWA standard 4-pole motor for max applicable motor output

*2 Output voltage in the vector control mode (220/440V AC input)

*3 Response when ratio of inertia between motor and load is 1 : 1

*4 To achieve this value tests are required by actually connecting to a motor

*5 Electric torque response

*6 Valid for the motor with built-in thermistor






Fig. A-3 Main Circuit Configuration (200/400 V Class AC Input)

APPENDIX 2 DIMENSIONS (mm)

The figures below show 200V 7.5 kW model and 30 kW model.



(a) Book Type (CIMR-H5D27P5)



(b) Cubic Type (CIMR-H5D2030)


Fig. A-4 Dimensions of VS-676H5

Table A-4 Dimensions (mm) and Approx. Mass (kg) of VS-676H5

Voltage	Motor Capacity kW	Enclosed Wall-mounted Type										d	Type	
		W	H	D	W1	H1	H2	D1	D2	Mass (kg)				
										DC input	AC input			
200V Class	0.4	100	350	350	75	335	75	220	130	7	-	M5	Book type	
	0.75													
	1.5													
	2.2													
	3.7													
	5.5	125	350	350	100	335	75	220	130	8	-	M5	Book type	
	7.5													
	11	150	350	350	125	335	75	220	130	10	-	M5	Book type	
	15													
	18.5	200	350	350	150	335	75	220	130	15	-	M5	Book type	
	22													
	30	425	675	355	320	650	125	-	-	48	61	M10	Cubic type	
	37										62			
	45	475	800	355	370	775	125	-	-	65	80	M10		
	55													
	75	575	925	405	445	895	15	-	-	110	135	M12		
400V Class	0.4	100	350	350	75	335	75	220	130	7.5	-	M5	Book type	
	0.75													
	1.5													
	2.2													
	3.7													
	5.5	125	350	350	100	335	75	220	130	9.5	-	M5	Book type	
	7.5													
	11	150	350	345	125	335	75	215	130	9.5	-	M5	Book type	
	15													
	18.5	200	350	350	150	335	75	220	130	15	-	M5	Book type	
	22													
	30	250	350	350	200	335	75	220	130	19.5	-	M5	Book type	
	37													
	45	455	820	355	350	795	125	-	-	62	79	M10	Cubic type	
	55										80			
	75	575	925	380	445	895	15	-	-	112	135	M12	Cubic type	
	110													
	160													
	185 (*2)	950	1450	435	(*1)	1400	25	-	-	-	360	M12	Cubic type	
	220 (*2)													
	300 (*2)	960	1600	455	(*1)	1550	25	-	-	-	420	M12		

*1 Mounting dimensions of 400V 185 kW to 300 kW models are indicated on next page

*2 400 V 185 kW to 300 kW models are AC input models



Applicable Motor Capacity kW	W1	W2	W3	W4	W5	W6
185, 220	750	440	310	850	285	565
300	750	440	310	873	298	575

APPENDIX 3 TYPICAL CONNECTION DIAGRAMS


3.1 USING DC INPUT UNIT WITH BUILT-IN INRUSH CURRENT SUPPRESSING CIRCUIT

For Models CIMR-H5D20P4 to H5D27P5 (200 V Class 0.4 to 7.5 kW),

Models CIMR-H5D40P4 to H5D47P5 (400 V Class 0.4 to 7.5 kW)

For Models CIMR-H5D2030 to H5D2075 (200 V Class 30 to 75 kW),


Models CIMR-H5D4055 to H5D4160 (400 V Class 55 to 160 kW)



3.2 USING DC INPUT UNIT WITHOUT BUILT-IN INRUSH CURRENT SUPPRESSING CIRCUIT

For models CIMR-H5D2011 to H5D2022 (200 V Class 11 - 22 kW)

For models CIMR-H5D4011 to H5D4045 (400 V Class 11 - 45 kW)



9CN DI-COM: 25, 26


9CN SG: 3, 5, 7, 9, 12, 13

10CN SG: 1, 3, 5

10CN PHC-COM: 17, 18, 19, 20


3.3 USING AC INPUT UNIT

For models CIMR-H5A2030 to H5A2075 (200 V Class 30 to 75 kW)
 For models CIMR-H5A4055 to H5A4300 (400 V Class 55 to 300 kW)




APPENDIX 4 FUNCTION BLOCK DIAGRAMS


4.1 FLUX VECTOR CONTROL




(cont'd)




4.2 OPEN LOOP VECTOR CONTROL




(cont'd)




4.3 V/f CONTROL



(cont'd)




4.4 EMS CONTROL



*Available when B1-01 = 3 and F9-14 = 1
†Available when B1-01 = 3 and F9-15 = 1

*Available when B1-01 = 3 and F9-14 = 1
†Available when B1-01 = 3 and F9-15 = 1

(cont'd)



APPENDIX 5 TABLE OF COMMUNICATION DATA

Table A-5 Control Commands (Master Controller to VS-676H5)

No.	V/f Control		V/f with PG Feedback		Open Loop Vector		Flux Vector		EMS Control	
	Item	Specification								
1	Operation signal	Operation signal	Operation signal	0 to 32767 30000/100%	-32768 to 32767 30000/100%	Speed reference	-32768 to 32767 30000/100%	Operation signal	0 to 32767 30000/100%	Operation signal
2	Speed reference	0 to 32767 30000/100%	Speed reference	0 to 32767 30000/100%	-30000 to 30000 10000/100%	Torque reference	-30000 to 30000 10000/100%	Speed reference	0 to 32767 30000/100%	Frequency reference
3	-	-	-	-	-	-	-	Torque reference	0 to 20000 10000/100%	Current reference
4	-	-	-	-	-	-	-	Torque compensation	-30000 to 30000 10000/100%	-
5	-	-	-	-	-	-	-	External magnetic-flux reference	-2000 to 12000 10000/100%	-
6	Inverter AO CH1 output	-10 to 10 V/0 to 1320	Inverter AO CH1 output	-10 to 10 V/0 to 1320	Inverter AO CH1 output	-10 to 10 V/0 to 1320	Inverter AO CH1 output	-10 to 10 V/0 to 1320	Inverter AO CH1 output	-10 to 10 V/0 to 1320
7	Inverter AO CH2 output	-10 to 10 V/0 to 1320	Inverter AO CH2 output	-10 to 10 V/0 to 1320	Inverter AO CH2 output	-10 to 10 V/0 to 1320	Inverter AO CH2 output	-10 to 10 V/0 to 1320	Inverter AO CH2 output	-10 to 10 V/0 to 1320
8	Bits 0 to 5 are used Inverter DO output	0 to FFFFFH (7 bits or more are disregarded)	Bits 0 to 5 are used Inverter DO output	0 to FFFFFH (7 bits or more are disregarded)	Bits 0 to 5 are used Inverter DO output	0 to FFFFFH (7 bits or more are disregarded)	Bits 0 to 5 are used Inverter DO output	0 to FFFFFH (7 bits or more are disregarded)	Bits 0 to 5 are used Inverter DO output	0 to FFFFFH (7 bits or more are disregarded)
9	AO-12 CH1 output	-11 to 11 V/0 to 4095	AO-12 CH1 output	-11 to 11 V/0 to 4095	AO-12 CH1 output	-11 to 11 V/0 to 4095	AO-12 CH1 output	-11 to 11 V/0 to 4095	AO-12 CH1 output	-11 to 11 V/0 to 4095
10	AO-12 CH2 output	-11 to 11 V/0 to 4095	AO-12 CH2 output	-11 to 11 V/0 to 4095	AO-12 CH2 output	-11 to 11 V/0 to 4095	AO-12 CH2 output	-11 to 11 V/0 to 4095	AO-12 CH2 output	-11 to 11 V/0 to 4095
11	DO-08/H output	Bits 0 to 7 are used 0 to FFH	DO-08/H output	Bits 0 to 7 are used 0 to FFH	DO-08/H output	Bits 0 to 7 are used 0 to FFH	DO-08/H output	Bits 0 to 7 are used 0 to FFH	DO-08/H output	Bits 0 to 7 are used 0 to FFH
12	Not used	-								
13	Not used	-								
14	Not used	-								
15	Empty	-								
16	Empty	-								

Notes 1 Notes 1 to No. 4 are accessed in a scan cycle (1 to 2 msec)

2 For Nos. 3, 4, 15, and 16, data items can be changed by the setting for a parameter In addition to the parameter items indicated above, the following parameters are added

- ASR proportional gain (No. 17) 0 to 30000 (100/V)

- Regeneration torque limit (No. 18) 0 to 30000 (10000/100%)

3 The data of Nos. 6 and 11 are disregarded at the inverter unless the communication mode is the "through mode"

4 If the same data is set in the selection permitted area and the selection not permitted area, only the high-speed data are accessed The data at the low-speed communication side are disregarded

Table A-6 Control Response (VS-676H5 to Master Controller)

No.	Item	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control
No.	Item	Specification	Item	Specification	Item	Specification
1	Status signal	Status signal	—	Status signal	—	Status signal
2	—	Speed feedback	—	Speed feedback*1	—	Speed feedback
3	—	—	—	Torque reference	-30000 to 30000 10000/100%	Torque reference -30000 to 30000 10000/100%
4	—	Speed detection PG count value	0 to 32767	—	—	Speed detection PG count value
5	Speed reference	0 to 32767 30000/100%	Speed reference	0 to 32767 30000/100%	-32768 to 32767 30000/100%	Speed reference
6	Primary frequency reference	0 to 32767 30000/100%	Primary frequency reference	0 to 32767 30000/100%	0 to 32767 30000/100%	Primary frequency reference
7	Output current	0 to 20000 10000/100%	Output current	0 to 20000 10000/100%	0 to 20000 10000/100%	Output current
8	Output voltage reference	0 to 10000/100%	Output voltage reference	0 to 10000/100%	Output voltage reference	Output voltage reference
9	Main circuit DC voltage	0 to 12500 (200 V class: 400 [V]) 10000/100% (400 V class: 800 [V])	Main circuit DC voltage	0 to 12500 (200 V class: 400 [V]) 10000/100% (400 V class: 800 [V])	0 to 12500 (200 V class: 400 [V]) Main circuit DC voltage	0 to 12500 (200 V class: 400 [V]) Main circuit DC voltage
10	—	—	—	Torque feedback	-30000 to 30000 10000/100%	Torque feedback -30000 to 30000 10000/100%
11	Fault alarm signal 1	Fault alarm signal 1	Fault alarm signal 1	Fault alarm signal 1	—	Fault alarm signal 1
12	Fault alarm signal 2	Fault alarm signal 2	Fault alarm signal 2	Fault alarm signal 2	—	Fault alarm signal 2
13	Inverter AI CH3 input	-10V to +10V/ 0 to 4095	Inverter AI CH3 input	-10V to +10V/ 0 to 4095	Inverter AI CH3 input	-10V to +10V/ 0 to 4095
14	Inverter DI input	—	Inverter DI input	—	Inverter DI input	—
15	Inverter AI CH1 input	-10V to +10V/ 0 to 4095	Inverter AI CH1 input	-10V to +10V/ 0 to 4095	Inverter AI CH1 input	-10V to +10V/ 0 to 4095
16	Momentary power loss drop amount	-32768 to 32767 30000/100%	Momentary power loss drop amount	-32768 to 32767 30000/100%	Momentary power loss drop amount	-32768 to 32767 30000/100%

Notes 1 Nos 1 to 4 are output in ASR scan (1 to 2 msec)

2 For Nos 3, 4, 15, and 16, data items can be changed by the setting for a parameter

By setting the selection permitted parameter, data items can be changed. Send the data to a master controller in the internal access cycle

3 With Nos 13 to 15 (inverter input signals), the contents of the signals are sent to the master controller even when the communication mode is not the through mode

4. (*1) The assumed speed is output

Table A-7 Operation Signals (Master Controller to VS-676H5)

Bit No.	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control
0 Run/stop	Run/stop	Run/stop	Run/stop	Run/stop	Run/stop
1 Reverse run	Reverse run				
2 Base block/release	Base block/release				
3 Trace start/stop	Trace start/stop				
4 External fault	External fault				
5 Fault reset	Fault reset				
6 Changing acceleration/deceleration time	Changing acceleration/deceleration time				
7 Accel./decel. prohibit (speed hold) / release	Accel./decel. prohibit (speed hold) / release				
8 DB command	DB command	Initial excitation	Initial excitation	Initial excitation	Not used
9	Integration reset (ASR)	Integration reset (ASR)	Integration reset (ASR)	Integration reset (ACR)	Integration reset (ACR)
A	Integration hold (ASR)	Integration hold (ASR)	Integration hold (ASR)	Integration hold (ACR)	Integration hold (ACR)
B	Soft starter cancel				
C	Trace reset (after occurrence of fault)				
D	Energy saving control ON/OFF	Energy saving control ON/OFF	Servo ON	Synchronous control ON/OFF	Synchronous control ON/OFF
E	Empty	Empty	Torque/speed control selection	Not used	Not used
F	Motor selection (No. 2/No. 1)	Not used			

Table A-8 Status Signals (VS-676H5 to Master Controller)

Bit No.	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control
0 Run/stop	Run/stop	Run/stop	Run/stop	Run/stop	Run/stop
1 Zero speed	-				
2 Reverse run	-				
3 Reset signal input	Reset signal input				
4 Speed agree	Current agree/not agree				
5 Inverter ready/not ready	Inverter ready/not ready				
6 Minor fault	Minor fault				
7 Major fault	Major fault				
8 Command error (control data 16W)	Command error (control data 16W)				
9 Recovery from power loss/momentary power loss	Recovery from power loss/momentary power loss				
A Remote/Local	Remote/Local	Remote/Local	Remote/Local	Remote/Local	Remote/Local
B Regeneration/Current	Regeneration/Current	Regeneration/Current	Regeneration/Current	Regeneration/Current	Regeneration/Current
C Current (torque) limit	Current (torque) limit				
D Speed limited (ASR limit)	-	-	-	Speed limited (ASR limit)	-
E Motor selection (No. 2/No 1)	Synchronous control				
F -	-	-	-	Zero servo complete	-

Table A-9 Fault and Alarm Signals (VS-676H5 to Master Controller)

Bit No.	V/f, Vector	Signal 1		Fault Rank
		EMS	EMS	
0	Overspeed (OS)	Overspeed (OS)	Overspeed (OS)	A
1	Ground fault (GF)	Ground fault (GF)	Ground fault (GF)	A
2	Over voltage (OV)	Over voltage (OV)	Over voltage (OV)	A
3	Main circuit low voltage (UV1)	Main circuit low voltage (UV1)	Main circuit low voltage (UV1)	B
4	Control power supply low voltage (UV2)	Control power supply low voltage (UV2)	Control power supply low voltage (UV2)	A
5	Inrush current resistor short MC fault (UV3)	Inrush current resistor short MC fault (UV3)	Inrush current resistor short MC fault (UV3)	A
6	Fuse blown (FU)	Fuse blown (FU)	Fuse blown (FU)	A
7	-	-	-	A
8	Inverter overheat alarm (OH)	Inverter overheat alarm (OH)	Inverter overheat alarm (OH)	B
9	Inverter overheat (OH1)	Inverter overheat (OH1)	Inverter overheat (OH1)	A
A	Inverter overload (OL2)	Inverter overload (OL2)	Inverter overload (OL2)	A
B	Over torque 1 (OL3)	-	-	A
C	Over torque 2 (OL4)	-	-	A
D	Motor overload (OL1)	-	-	B
E	Motor overheat (OH3)*1	-	-	A
F	Thermistor open circuit (THM)*1	-	-	A
Signal 2				
0	Braking transistor fault (RR)*1	-	-	A
1	Braking resistor overheat (RH)*1	-	-	A
2	External fault (EF1 to EF8)	External fault (EF1 to EF8)	External fault (EF1 to EF8)	B
3	Over speed (OS)*1	-	-	A
4	Speed deviation (DEV)*1	Excessive current deviation (DEV)*1	Excessive current deviation (DEV)*1	B
5	PG open circuit (PGO)*1	-	-	A
6	Excessive ripple in DC bus bar voltage (PF)	Excessive ripple in DC bus bar voltage (PF)	Excessive ripple in DC bus bar voltage (PF)	A
7	Output open-phase (LF)	Output open-phase (LF)	Output open-phase (LF)	A
8	Load short circuit (SC)	Load short circuit (SC)	Load short circuit (SC)	A
9	-	-	-	A
A	Digital operator fault (OPR)	Digital operator fault (OPR)	Digital operator fault (OPR)	A
B	CP-216 transmission error (CE)	CP-216 transmission error (CE)	CP-216 transmission error (CE)	A
C	Hardware fault (CPF**)	Hardware fault (CPF**)	Hardware fault (CPF**)	A
D	-	Synchronous control error	Synchronous control error	A
E	-	-	-	
F	-	-	-	

Note(*1) Error or fault is detected only when the corresponding hardware is installed

APPENDIX 6 TABLE OF CONSTANTS

Table A-10 Table of Monitor Constants

Constant No.	MEMOBUS Address	Constant Name	Unit	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
U1-01	20H	Speed reference	0.01%	Q	Q	Q	Q	Q	The unit varies depending on the setting of O1-03
U1-02	21H	Output frequency	0.01 Hz	Q	Q	Q	Q	Q	
U1-03	22H	Output current	0.1 A	Q	Q	Q	Q	Q	For 7.5 kW model or smaller, minimum unit is 0.01 A
U1-04	23H	Control method	-	Q	Q	Q	Q	Q	0 V/f control 1 V/f with PG feedback 2: Open loop vector 3: Flux vector 4: EMS control
U1-05	24H	Motor speed	0.01%	Q	Q	Q	Q	Q	The unit varies depending on the setting of O1-03
U1-06	25H	Output voltage	0.1 V	Q	Q	Q	Q	Q	
U1-07	26H	DC bus voltage	1 V	Q	Q	Q	Q	Q	
U1-08	27H	Output power	0.1 kW	Q	Q	Q	Q	Q	
U1-09	28H	Torque reference (internal)	0.1%	-	-	Q	-	-	
U1-10	29H	Input terminal status	-	Q	Q	Q	Q	Q	
U1-11	2AH	Output terminal status	-	Q	Q	Q	Q	Q	
U1-12	2BH	Operation status	-	Q	Q	Q	Q	Q	
U1-13	2CH	Cumulative operation time	1H	Q	Q	Q	Q	Q	
U1-14	2DH	PROM No. (at FLASH side)	-	Q	Q	Q	Q	Q	
U1-15	2EH	Input voltage at 9CN-4 (AI-1) terminal	0.1%	B	B	B	B	B	
U1-16	2FH	Input voltage at 9CN-6 (AI-2) terminal	0.1%	B	B	B	B	B	
U1-17	30H	Input voltage at 9CN-8 (AI-3) terminal	0.1%	B	B	B	B	B	
U1-18	31H	Motor secondary current (Iq)	0.1%	B	B	B	B	B	
U1-19	32H	Motor exciting current (Id)	0.1%	-	-	B	B	-	
U1-20	33H	Soft starter output	0.01%	A	A	A	A	A	The unit varies depending on the setting of O1-03.
U1-21	34H	ASR input (speed deviation)	0.01%	-	A	-	A	-	
U1-22	35H	ASR output	0.01%	-	A	-	A	-	

Constant No.	MEMOBUS Address	Constant Name	Unit	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
U1-23	36H	Current reference soft starter input	0.01%	-	-	-	-	Q	
U1-24	37H	Current reference soft starter output	0.01%	-	-	-	-	Q	
U1-25	38H	Current control deviation	0.01%	-	-	-	-	A	
U1-26	39H	Output voltage reference (Vq)	0.1V	-	-	A	A	-	
U1-27	3AH	Output voltage reference (Vd)	0.1V	-	-	A	A	-	
U1-28	3BH	PROM No (at CPU ROM side)	-	A	A	A	A	A	
U1-29	3CH	LED check (diagnosis)	-	A	A	A	A	A	
U1-30	3DH	Operation status 2	-	Q	Q	Q	Q	Q	
U1-31	3EH	Master controller command 1	-	Q	Q	Q	Q	Q	
U1-32	3FH	Master controller command 2	-	Q	Q	Q	Q	Q	
U1-33	40H	External torque reference	0.01%	-	-	A	A	-	
U1-34	41H	Torque compensation	0.01%	-	-	-	A	-	
U1-35	42H	Slip frequency reference	0.01%	-	-	A	A	-	
U1-36	43H	Magnetic flux reference	0.01%	A	A	A	A	-	
U1-37	44H	DO-08/H output status	-	Q	Q	Q	Q	Q	
U1-38	45H	Momentary power loss drop amount	0.01%	B	B	B	B	-	The unit varies depending on the setting of Q1-03
U1-39	46H	Motor temperature	1°C	B	B	B	B	-	Valid when thermistor provided is selected
U1-40	47H	Speed detection PG counter value	Pulse	-	A	-	A	-	
U1-41	48H	Acceleration torque monitor (observer)	0.1%	-	-	A	-	-	
U1-42	49H	Acceleration torque reference (observer)	0.1%	-	-	A	-	-	
U1-43	4AH	Torque observer control PI output	0.1%	-	-	A	-	-	
U1-44	4BH	Torque observer control output	0.1%	-	-	A	-	-	
U1-45	4CH	Synchronous phase difference	0.1 deg	-	-	-	A	-	
U1-46	4DH	Output voltage phase	0.1 deg	-	-	-	A	-	
U1-47	4EH	Zero-servo move,pulse	Pulse	-	-	A	-	-	
U1-48	4FH	ACRq output	0.1%	-	-	A	A	-	
U1-49	50H	ACRd output	0.1%	-	-	A	A	-	
U1-50	51H	Not used	-	-	-	-	-	-	

Constant No.	MEMOBUS Address	Constant Name	Unit	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
U2-01	70H	Current fault	-	Q	Q	Q	Q	Q	
U2-02	71H	Last fault	-	Q	Q	Q	Q	Q	
U2-03	72H	Speed reference (U1-01) at fault	0.01%	Q	Q	Q	Q	Q	The unit varies depending on the setting of O1-03
U2-04	73H	Output frequency (U1-02) at fault	0.01 Hz	Q	Q	Q	Q	Q	
U2-05	74H	Inverter output current (U1-03) at fault	0.1 A	Q	Q	Q	Q	Q	For 7.5 kW model or smaller, minimum unit is 0.01 A
U2-06	75H	Motor speed (U1-05) at fault	0.01%	Q	Q	Q	Q	Q	The unit varies depending on the setting of O1-03
U2-07	76H	Output voltage reference (U1-06) at fault	0.1 V	Q	Q	Q	Q	Q	
U2-08	77H	DC bus voltage (U1-07) at fault	1 V	Q	Q	Q	Q	Q	
U2-09	78H	Output power (U1-08) at fault	0.1 kW	Q	Q	Q	Q	Q	
U2-10	79H	Torque reference (U1-09) at fault	0.1%	-	-	Q	Q	-	
U2-11	7AH	Input terminal status (U1-10) at fault	-	Q	Q	Q	Q	Q	
U2-12	7BH	Output terminal status (U1-11) at fault	-	Q	Q	Q	Q	Q	
U2-13	7CH	Operation status (U1-12) at fault	-	Q	Q	Q	Q	Q	
U2-14	7DH	Cumulative operation time (U1-13) at fault	1H	Q	Q	Q	Q	Q	
U2-15	7EH	Speed controller (ASR) output (U1-22) at fault	0.01%	-	A	-	A	-	
U2-16	7FH	Current control deviation (U1-25) at fault	0.01%	-	-	-	-	A	
U2-17	80H	Operation status 2 (U1-30) at fault	-	Q	Q	Q	Q	Q	
U2-18	81H	Master controller command 1 (U1-31) at fault	-	Q	Q	Q	Q	Q	
U2-19	82H	Master controller command 2 (U1-32) at fault	-	Q	Q	Q	Q	Q	
U2-20	83H	External torque reference (U1-33) at fault	0.01%	-	-	A	A	-	
U2-21	84H	Torque compensation (U1-34) at fault	0.01%	-	-	-	A	-	
U2-22	85H	Magnetic flux reference (U1-36) at fault	0.01%	A	A	A	A	-	

Constant No.	MEMOBUS Address	Constant Name	Unit	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
U2-23	86H	Observer control output (U1-44) at Fault	0.1%	-	-	-	A	-	
U2-24	87H	Output voltage phase (U1-46) at fault	0.1 deg	-	-	-	-	A	
U3-01	90H	Most recent fault	-	Q	Q	Q	Q	Q	
U3-02	91H	Second most recent fault	-	Q	Q	Q	Q	Q	
U3-03	92H	Third most recent fault	-	Q	Q	Q	Q	Q	
U3-04	93H	Fourth/oldest fault	-	Q	Q	Q	Q	Q	
U3-05	94H	Cumulative operation time at fault	IH	Q	Q	Q	Q	Q	
U3-06	95H	Accumulated operation time of second fault	IH	Q	Q	Q	Q	Q	
U3-07	96H	Accumulated operation time of third fault	IH	Q	Q	Q	Q	Q	
U3-08	97H	Accumulated operation time of fourth/oldest fault	IH	Q	Q	Q	Q	Q	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
A1-00	100H	Not used	-	-	-	-	-	-	-	-	
A1-01	101H	Access level	2	0 to 9999	O	Q	Q	Q	Q	Q	0. For monitoring 1. Quick-start (Q) 2. Basic (B) 3. Advanced (A)
A1-02	102H	Control method selection	3	0 to 4		Q	Q	Q	Q	Q	0. V/f control 1. V/f with PG feedback 2. Open loop vector 3. Flux vector 4. EMS control
A1-03	103H	Initialize	0000	0000 to 9999		Q	Q	Q	Q	Q	0000, 1110, 3330 2220. Constants initialization
A1-04	104H	Password 1 (for inputting)	0	0000 to 9999		Q	Q	Q	Q	Q	
A1-05	105H	Password 2 (for setting)	0	0000 to 9999		-	-	-	-	-	
A2-01 to 32	106H to 125H	Not used	-	-	-	-	-	-	-	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
B1-01	180H	Reference selection	3	0 to 3		Q	Q	Q	Q	Q	0 Digital operator 1. Control circuit terminal 2. Transmission 3. Option
B1-02	181H	Operation method selection	3	0 to 3		Q	Q	Q	Q	Q	0 Digital operator 1. Control circuit terminal 2. Transmission 3. Option
B1-03	182H	Stopping method selection (for stop command)	0	0 to 3		Q	Q	Q	Q	Q	0 Deceleration to stop 1. Coast to stop 2. DC injection braking to stop 3. Timer controlled coast to stop Note: For flux vector control, selection is possible only from 0 and 1.
B1-04	183H	Reverse run prohibition selection	0	0/1		B	B	B	B	-	0. Reverse run enabled 1. Reverse run prohibited
B1-05	184H	Operation selection at a speed lower than the minimum r/min (E1-09)	0	0 to 3		-	-	-	A	-	0. Normal operation 1. Stop 2. Run at E1-09 3. Zero-speed run
B1-06	185H	Read sequence input, twice	1	0/1		A	A	A	A	A	0. 1 ms - 2 scans 1. 5 ms - 2 scans
B2-01	186H	Zero-speed level (DC injection braking starting speed)	0.50	0.00 to 10.00%		B	B	B	B	-	The unit varies depending on the setting of O1-03
B2-02	187H	DC injection braking current	50	0 to 100%		B	B	B	B	-	
B2-03	188H	Initial excitation (DC injection braking) time at start	0.00	0.00 to 10.00 sec		B	B	B	B	-	
B2-04	189H	DC injection braking time at stop	0.00	0.00 to 10.00 sec		B	B	B	B	-	
B2-05	18AH	Not used	-	-		-	-	-	-	-	
B2-06	18BH	Not used	-	-		-	-	-	-	-	
B2-07	18CH	Not used	-	-		-	-	-	-	-	
B3-01	18DH	Speed search selection at start	1	0/1		A	A	A	A	-	For V/f control and open loop vector control, initial value is 0 0 Disabled 1 Enabled
B3-02	18EH	Speed search operating current at start	150	0 to 200%		A	-	-	-	-	
B3-03	18FH	Speed search deceleration time	20	0 to 10.0 sec		A	-	-	-	-	
B3-04	190H	Not used	-	-		-	-	-	-	-	
B4-01	191H	Not used	-	-		-	-	-	-	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
B4-02	192H	Not used	-	-	-	-	-	-	-	-	
B5-01	193H	Not used	-	-	-	-	-	-	-	-	
B5-02	194H	EMS current control proportional gain	0.10	0.00 to 10.00	O	-	-	-	-	A	
B5-03	195H	EMS current control integral time	0.10	0.00 to 360.00 sec	O	-	-	-	-	A	
B5-04	196H	EMS current control integral limit	115.0	0.0 to 200.0%	O	-	-	-	-	A	
B5-05	197H	Not used	-	-	-	-	-	-	-	-	
B5-06	198H	P1 limit	115.0	0.0 to 200.0%	O	-	-	-	-	A	
B5-07	199H	Not used	-	-	-	-	-	-	-	-	
B5-08	19AH	Not used	-	-	-	-	-	-	-	-	
B6-01	19BH	Not used	-	-	-	-	-	-	-	-	
B6-02	19CH	Not used	-	-	-	-	-	-	-	-	
B6-03	19DH	Not used	-	-	-	-	-	-	-	-	
B6-04	19EH	Not used	-	-	-	-	-	-	-	-	
B7-01	19FH	Droop amount	0.0	0.0 to 100.0%	O	-	-	A	A	-	
B7-02	1A0H	Not used	-	-	-	-	-	-	-	-	
B8-01	1A1H	Not used	-	-	-	-	-	-	-	-	
B8-02	1A2H	Not used	-	-	-	-	-	-	-	-	
B9-01	1A3H	Zero-servo gain	5	0 to 100	O	-	-	A	A	-	
B9-02	1A4H	Zero-servo completion width	10	0 to 16383 pulse	-	-	-	A	A	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
C1-01	200H	Acceleration time 1	10.0		O	Q	Q	Q	Q	Q	
C1-02	201H	Deceleration time 1	10.0		O	Q	Q	Q	Q	Q	
C1-03	202H	Acceleration time 2	10.0		O	B	B	B	B	B	
C1-04	203H	Deceleration time 2	10.0	0.0 to 6000 sec (C1-10=1) 0.00 to 600.00 sec (C1-10=0)	O	B	B	B	B	B	
C1-05	204H	Current reference positive start time (EMS)	10.0		-	-	-	-	-	Q	
C1-06	205H	Current reference negative start time (EMS)	10.0		-	-	-	-	-	Q	
C1-07	206H	Not used	-		-	-	-	-	-	-	
C1-08	207H	Not used	-		-	-	-	-	-	-	
C1-09	208H	Emergency stop time	10.0		B	B	B	B	B	-	
C1-10	209H	Accel./decel. time setting unit	1	0.01	A	A	A	A	A	0.001 sec 1.01 sec	
C1-11	20AH	Not used	-		-	-	-	-	-	-	
C2-01	20BH	Not used	-		-	-	-	-	-	-	
C2-02	20CH	Not used	-		-	-	-	-	-	-	
C2-03	20DH	Not used	-		-	-	-	-	-	-	
C2-04	20EH	Not used	-		-	-	-	-	-	-	
C3-01	20FH	Sip compensation gain	0.0	0.0 to 2.5	O	A	A	A	A	-	For open loop vector control, initial value 1s.10
C3-02	210H	Sip compensation primary delay time	200	0 to 10000 msec	A	-	A	-	-	-	For V/f control, initial value is 2000
C3-03	211H	Sip compensation limit	200	0 to 250%.	A	-	A	-	-	-	
C3-04	212H	Sip compensation selection during regeneration	0	0/1	A	-	A	-	-	-	0-Disabled 1-Enabled
C4-01	213H	Torque compensation gain	1.00	0.00 to 2.50	O	B	B	B	B	-	
C4-02	214H	Torque compensation time constant	20	0 to 10000 msec	A	A	A	A	-	-	
C5-01	215H	ASR proportional (P) gain 1	20.00	0.00 to 300.00	O	-	B	-	B	-	For V/f with PG feedback, initial value is 0.20
C5-02	216H	ASR integral (I) time 1	0.500	0.000 to 10.000 sec	O	-	B	-	B	-	For flux vector control, lower limit is 1.00
C5-03	217H	ASR proportional (P) gain 2	20.00	0.00 to 300.00	O	-	B	-	B	-	For V/f with PG feedback, initial value is 0.02
											For flux vector control, lower limit is 1.00

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
C5-04	218H	ASR integral (I) time 2	0.500	0.000 to 10.000 sec	O	-	B	-	B	-	For V/f with PG feedback, initial value is 0.050
C5-05	219H	ASR limit	5.0	0.0 to 20.0%	-	A	-	-	-	-	
C5-06	21AH	ASR primary delay time	0.000	0.000 to 0.500 sec	O	-	-	-	A	-	
C5-07	21BH	ASR switching speed	0.00	0.00 to 100.00%	-	-	-	-	A	-	The unit varies depending on the setting of O1-03.
C6-01	21CH	Carrier frequency upper limit	2.0	0.4 to 15.0 kHz	-	A	A	A	A	A	For vector control, lower limit is 2.0 Upper limit changes depending on the inverter capacity (Refer to para 4.5)
C6-02	21DH	Carrier frequency lower limit	2.0	0.4 to 15.0 kHz	-	A	A	-	-	-	For vector control, lower limit is 2.0 Upper limit changes depending on the inverter capacity (Refer to para 4.5)
C6-03	21EH	Carrier frequency proportional gain	00	00 to 99	-	A	A	-	-	-	
C7-01	21FH	Hunting prevention selection	1	0/1	-	A	A	-	-	-	0. Disabled 1. Enabled
C7-02	220H	Hunting prevention gain	1.00	0.00 to 2.50	-	A	A	-	-	-	
C7-03	221H	Not used	-	-	-	-	-	-	-	-	
C7-04	222H	Not used	-	-	-	-	-	-	-	-	
C8-01	223H	Not used	-	-	-	-	-	-	-	-	
C8-02	224H	Not used	-	-	-	-	-	-	-	-	
C8-03	225H	Not used	-	-	-	-	-	-	-	-	
C8-04	226H	Not used	-	-	-	-	-	-	-	-	
C8-05	227H	Not used	-	-	-	-	-	-	-	-	
C8-06	228H	Not used	-	-	-	-	-	-	-	-	
C8-07	229H	Not used	-	-	-	-	-	-	-	-	
C8-08	22AH	AFR gain	2.00	0.00 to 10.00	-	-	-	-	A	-	
C8-09	22BH	Not used	-	-	-	-	-	-	-	-	
C8-10	22CH	Not used	-	-	-	-	-	-	-	-	
C8-11	22DH	Not used	-	-	-	-	-	-	-	-	
C8-12	22EH	Not used	-	-	-	-	-	-	-	-	
C8-13	22FH	Not used	-	-	-	-	-	-	-	-	
C8-14	230H	Not used	-	-	-	-	-	-	-	-	
C8-15	231H	Not used	-	-	-	-	-	-	-	-	
C8-16	232H	Not used	-	-	-	-	-	-	-	-	
C8-17	233H	Not used	-	-	-	-	-	-	-	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
C8-18	234H	Not used	-	-	-	-	-	-	-	-	
C8-19	235H	Not used	-	-	-	-	-	-	-	-	
C8-20	236H	Test (simulation) mode	0	0 to 3	A	A	A	A	A	A	0 Normal operation 1 Simulation mode 2 Base test mode (only when individual control power supplies are used) 3 V/f test mode
C8-21	237H	Not used	-	-	-	-	-	-	-	-	
C8-22	238H	Not used	-	-	-	-	-	-	-	-	
C8-23	239H	Not used	-	-	-	-	-	-	-	-	
C8-24	23AH	Not used	-	-	-	-	-	-	-	-	
C8-25	23BH	Not used	-	-	-	-	-	-	-	-	
C8-26	23CH	Not used	-	-	-	-	-	-	-	-	
C8-27	23DH	Not used	-	-	-	-	-	-	-	-	
C8-28	23EH	Not used	-	-	-	-	-	-	-	-	
C8-29	23FH	Not used	-	-	-	-	-	-	-	-	
C8-30	240H	Not used	-	-	-	-	-	-	-	-	
C8-31	241H	Not used	-	-	-	-	-	-	-	-	
C8-32	242H	Not used	-	-	-	-	-	-	-	-	
C8-33	243H	Not used	-	-	-	-	-	-	-	-	
C8-34	244H	Not used	-	-	-	-	-	-	-	-	
C8-35	245H	Not used	-	-	-	-	-	-	-	-	
C9-01	246H	Rated speed adjustment	1.0000	0.5000 to 1.3000	B	B	B	B	B	B	
C9-02	247H	Energy-saving control selection	0	0/1	A	A	A	A	A	A	0 Normal mode 1 Energy-saving mode
C9-03	248H	Energy-saving control coefficient K2	0.00	0.00 to 655.00	A	A	A	A	A	A	
C9-04	249H	Energy-saving voltage upper limit (60 Hz)	120	0 to 120%	A	A	A	A	A	A	
C9-05	24AH	Energy-saving voltage upper limit (6 Hz)	16	0 to 25%	A	A	A	A	A	A	
C9-06	24BH	Energy-saving voltage lower limit (60 Hz)	50	0 to 120%	A	A	A	A	A	A	
C9-07	24CH	Energy-saving voltage lower limit (6 Hz)	12	0 to 25%	A	A	A	A	A	A	
C9-08	24DH	Power average time	1'00	0.01 to 50 sec	A	A	A	A	A	A	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
C9-09	24EH	Probing operation voltage limit	0	0 to 100%		A	A	-	-	-	
C9-10	24FH	Probing operation voltage step (at Vout 100%)	0.5	0.1 to 10.0%		A	A	-	-	-	
C9-11	250H	Probing operation voltage step (at Vout 5%)	0.2	0.1 to 10.0%		A	A	-	-	-	
C9-12	251H	Power detection filter time constant	0.140	0.000 to 2.000 sec		A	A	-	-	-	
C9-13	252H	Power detection filter switching width	10	1 to 100%		A	A	-	-	-	
C9-14	253H	Torque observer selection	0	0/1		-	-	-	A	-	0 Control OFF 1 Control ON
C9-15	254H	Speed/torque control switching	0	0/1		-	-	-	A	-	0 Speed control 1 Torque control Valid only when C9-14=1
C9-16	255H	Droop control selection	0	0/1		-	-	-	A	-	0 Speed control 1 Droop speed control Valid only when C9-14=1
C9-17	256H	Motor mechanical time constant	0.000	0.000 to 5.000 sec		-	-	-	A	-	
C9-18	257H	Torque observer proportional gain	0.000	0.000 to 2.000	O	-	-	-	A	-	
C9-19	258H	Torque observer integral time	0.000	0.000 to 500 sec	O	-	-	-	A	-	
C9-20	259H	Torque observer secondary filter time constant 1	0.000	0.000 to 1.000 sec	O	-	-	-	A	-	
C9-21	25AH	Torque observer secondary filter time constant 2	0.000	0.000 to 5.000 sec	O	-	-	-	A	-	
C9-22	25BH	Torque observer output leading time	0.000	0.000 to 0.050 sec	O	-	-	-	A	-	
C9-23	25CH	Filter time constant for torque observer acceleration torque monitor	0.000	0.000 to 500 sec	-	-	-	-	A	-	
C9-24	25DH	Torque observer control integral hold	0.00	0.00 to 100.00%	-	-	-	-	A	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
D1-01	280H	Speed reference	0 00	0 00 to 100.00%	O	Q	Q	Q	Q	Q	The unit varies depending on the setting of O1-03.
D1-02	281H	Current reference (EMS)	0 0	0 0 to 100.0%	O	-	-	-	-	Q	
D1-03	282H	Not used	-	-	-	-	-	-	-	-	
D1-04	283H	Not used	-	-	-	-	-	-	-	-	
D1-05	284H	Not used	-	-	-	-	-	-	-	-	
D1-06	285H	Not used	-	-	-	-	-	-	-	-	
D1-07	286H	Not used	-	-	-	-	-	-	-	-	
D1-08	287H	Not used	-	-	-	-	-	-	-	-	
D1-09	288H	Jog speed reference	10 00	0 00 to 100.00%	O	Q	Q	Q	Q	-	The unit varies depending on the setting of O1-03
D2-01	289H	Not used	-	-	-	-	-	-	-	-	
D2-02	28AH	Not used	-	-	-	-	-	-	-	-	
D3-01	28BH	Not used	-	-	-	-	-	-	-	-	
D3-02	28CH	Not used	-	-	-	-	-	-	-	-	
D3-03	28DH	Not used	-	-	-	-	-	-	-	-	
D3-04	28EH	Not used	-	-	-	-	-	-	-	-	
D4-01	28FH	Not used	-	-	-	-	-	-	-	-	
D4-02	290H	Not used	-	-	-	-	-	-	-	-	
D5-01	291H	Not used	-	-	-	-	-	-	-	-	
D5-02	292H	Torque reference delay time	0	0 to 1000 msec					A	-	1 Speed reference 2 D5-04
D5-03	293H	Speed limit selection	1	1/2					A	-	
D5-04	294H	Speed limit	0	-120 to 120%				-	A	-	
D5-05	295H	Speed limit bias	5	0 to 120%				-	A	-	
D5-06	296H	Speed/torque control switching timer	50	0 to 1000 msec				-	A	-	
D5-07	297H	Torque reference function selection	0	0/1				-	A	-	0 Torque reference 1 Torque limit
D6-01	298H	External magnetic flux reference selection	0	0/1					A	-	0 Magnetic flux reference input from master controller is invalid 1 Magnetic flux reference input from master controller is valid


Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
E1-01	300H	Input voltage setting	200	180 to 230 V		Q	Q	Q	Q	Q	For 400 V class, the value to be set is twice as that of 200 V class
E1-02	301H	Motor selection (V/f or vector)	2	0 to 2		Q	Q	Q	Q	-	0 General-purpose motor 1 V/f control motor 2 Vector control motor
E1-03	302H	V/f pattern selection	0F	00 to 0F		Q	Q	-	-	-	00 - 0E: Preset V/f pattern (15 kinds) 0F: Custom V/f pattern In vector control mode, fixed to 0F
E1-04	303H	Rated r/min	1750	0 to 24000 r/min		Q	Q	Q	Q	-	The unit varies depending on the setting of O1-04. With V/f control and V/f with PG feedback, initial value is 1800
E1-05	304H	Rated voltage	1800	0 to 2550 V		Q	Q	Q	Q	-	For 400 V class, the value to be set is twice as that of 200 V class.
E1-06	305H	Base r/min	1750	0 to 24000 r/min		Q	Q	Q	Q	-	The unit varies depending on the setting of O1-04. With V/f control and V/f with PG feedback, initial value is 1800
E1-07	306H	Middle r/min	90	0 to 24000 r/min		Q	Q	A	-	-	The unit varies depending on the setting of O1-04.
E1-08	307H	Middle voltage	0.0	0.0 to 255.0 V		Q	Q	A	-	-	Initial values 11.0 Open loop vector 15.0 V/f control, 0.4 to 1.5 kW 14.0 V/f control, 2.2 to 45 kW 12.0 V/f control, 55 kW or more For 400 V class, the value to be set is twice as that of 200 V class
E1-09	308H	Minimum r/min	100	0 to 24000 r/min		Q	Q	Q	B	-	Initial values 15. Open loop vector 45 V/f control The unit varies depending on the setting of O1-04.
E1-10	309H	Minimum voltage	0.0	0.0 to 255.0 V		Q	Q	A	-	-	Initial values 2.0 Open loop vector 9.0 V/f control, 0.4 to 1.5 kW 7.0 V/f control, 2.2 to 45 kW 6.0 V/f control, 55 kW or more For 400 V class, the value to be set is twice as that of 200 V class
E1-11	30AH	Middle r/min 2	0	0 to 24000 r/min		B	B	B	B	-	The unit varies depending on the setting of O1-04.
E1-12	30BH	Middle voltage 2	0.0	0.0 to 255.0 V		B	B	B	B	-	For 400 V class, the value to be set is twice as that of 200 V class.

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
E1-13	30CH	Base voltage	1800	0.0 to 255.0 V		Q	Q	Q	Q	-	With V/f control and V/f with PG feedback, initial value is 0.0. For 400 V class, the value to be set is twice as that of 200 V class
E2-00	30DH	Motor rated output (not used)	*	00 to FF		Q	Q	Q	Q	-	Same setting as the inverter output
E2-01	30EH	Motor rated current	*	0.01 to 2000.0 A**		Q	Q	Q	Q	Q	*: Initial values vary depending on the kVA setting and motor selection **: For 7.5 kW model or smaller, minimum unit is 0.01 A
E2-02	30FH	Motor rated slip	*	0.00 to 20.00 Hz	O	A	A	Q	Q	-	
E2-03	310H	Motor no-load current	*	0.01 to 1500.0 A**	O	A	A	Q	Q	-	
E2-04	311H	Number of motor poles	4	2 to 48		Q	Q	Q	Q	-	
E2-05	312H	Motor line-to-line resistance	*	0.000 to 65.000 ohm	O	A	A	A	A	-	
E2-06	313H	Motor leak inductance	*	0.0 to 30.0%	O	-	-	A	A	-	
E2-07	314H	Motor iron-core saturation coefficient 1	0.50	0.00 to 1.00	O	-	-	A	A	-	
E2-08	315H	Motor iron-core saturation coefficient 2	0.75	0.00 to 1.00	O	-	-	A	A	-	
E2-09	316H	Motor mechanical loss	0.0	0.0 to 10.0%	O	-	-	A	A	-	
E2-10	317H	Motor overheat temperature	120	50 to 200°C		Q	Q	Q	Q	-	
E2-11	318H	Motor feeder resistance	1.0	0.0 to 10.0%	O	A	A	A	A	-	
E3-01	319H	Motor 2 control method selection	2	0 to 3		A	A	A	A	-	0: V/f control 1: V/f with PG feedback 2: Open loop vector 3: Flux vector
E3-02	31AH	Motor 2 rated output (not used)	*	00 to FF		A	A	A	A	-	Same setting as the inverter capacity
E3-03	31BH	Motor 2 PG constant	600	0 to 10000	-	A	A	-	A	-	
E4-01	31CH	Motor 2 rated r/min	1750	0 to 24000 r/min		A	A	A	A	-	The unit varies depending on the setting of O1-04 With V/f control and V/f with PG feedback, initial value is 1800
E4-02	31DH	Motor 2 rated voltage	180.0	0.0 to 255.0 V		A	A	A	A	-	For 400 V class, the value to be set is twice as that of 200 V class
E4-03	31EH	Motor 2 base r/min	1750	0 to 24000 r/min		A	A	A	A	-	The unit varies depending on the setting of O1-04 With V/f control and V/f with PG feedback, initial value is 1800
E4-04	31FH	Motor 2 mid. r/min	90	0 to 24000 r/min		A	A	A	A	-	The unit varies depending on the setting of O1-04.

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
E4-05	320H	Motor 2 mid. voltage	0.0	0.0 to 255.0 V		A	A	A	-	-	Initial values: 11.0 Open loop vector 15.0 V/f control, 0.4 to 1.5 kW 14.0 V/f control, 2.2 to 45 kW 12.0 V/f control, 55 kW or more For 400 V class, the value to be set is twice as that of 200 V class.
E4-06	321H	Motor 2 minimum r/min	100	0 to 24000 r/min		A	A	A	A	-	Initial values. 15.0 Open loop vector 45.0 V/f control The unit varies depending on the setting of OI-04
E4-07	322H	Motor 2 maximum voltage	0.0	0.0 to 255.0 V		A	A	A	-	-	Initial values: 2.0 Open loop vector 9.0 V/f control, 0.4 to 1.5 kW 7.0 V/f control, 2.2 to 45 kW 6.0 V/f control, 55 kW or more For 400 V class, the value to be set is twice as that of 200 V class
E4-08	323H	Motor 2 input voltage selection	200	180 to 230 V		A	A	A	A	-	For 400 V class, the value to be set is twice as that of 200 V class
E4-09	324H	Motor 2 motor selection (V/f or vector)	0	0 to 2		A	A	A	A	-	0 General-purpose motor 1 V/f control motor 2 Vector control motor
E4-10	325H	Motor 2 rated current	0F	00 to 0F		A	A	A	A	-	00 - 0E Preset V/f pattern (15 kinds) 0F Custom V/f pattern In vector control mode, fixed to 0F
E4-11	326H	Motor 2 rated slip	0	0 to 24000 r/min		A	A	A	A	-	The unit varies depending on the setting of OI-04
E4-12	327H	Motor 2 no-load current	0.0	0.0 to 255.0 V		A	A	A	A	-	For 400 V class, the value to be set is twice as that of 200 V class
E4-13	328H	Motor 2 base voltage	180.0	0.0 to 255.0 V		A	A	A	A	-	With V/f control and V/f with PG feedback, initial value is 0.0 For 400 V class, the value to be set is twice as that of 200 V class
E5-01	329H	Motor 2 rated current	*	0.00 to 2000.0 A**		A	A	A	A	-	* Initial values vary depending on the kVA setting and motor selection.
E5-02	32AH	Motor 2 rated slip	*	0.00 to 20.00 Hz		O	A	A	A	-	** For 7.5 kW model or smaller, minimum unit is 0.01A
E5-03	32BH	Motor 2 no-load current	*	0.00 to 1500.0 A**		O	A	A	A	-	
E5-04	32CH	Motor 2 number of poles	4	2 to 48		A	A	A	A	-	
E5-05	32DH	Motor 2 line-to-line resistance	*	0.000 to 65.000 ohm		O	A	A	A	-	
E5-06	32EH	Motor 2 leak inductance	*	0.0 to 30.0%		O	-	-	A	-	
E5-07	32FH	Motor 2 iron-core saturation coefficient 1	0.50	0.00 to 1.00		O	-	-	A	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
E5-08	330H	Motor 2 iron-core saturation coefficient 2	0.75	0.00 to 1.00	O	-	-	A	A	-	
E5-09	331H	Motor 2 mechanical loss	0.0	0.0 to 10.0%	O	-	-	-	A	-	
E5-10	332H	Motor 2 overheat temperature	120	50 to 200°C		A	A	A	A	-	
E5-11	333H	Motor 2 feeder resistance	1.0	0.0 to 10.0%	O	A	A	A	A	-	
E6-01	334H	Maximum output frequency (EMS)	60.0	0.0 to 400.0 Hz		-	-	-	-	Q	
E6-02	335H	Minimum output frequency (EMS)	1.5	0.0 to 400.0 Hz		-	-	-	-	Q	

[V/f Pattern Setting]



Set r/min to be $E1-09 \leq E1-07 < E1-06 \leq E1-11 \leq E1-04$

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
F1-01	380H	PG constant	600	0 to 10000	-	Q	-	Q	-	-	
F1-02	381H	Operation selection at PG open circuit	1	0 to 3	-	B	-	B	-	-	For flux vector control, selection is possible only from 1 and 3 0 Ramp to stop 1 Coast to stop 2 Emergency stop 3 Operation continue
F1-03	382H	Operation selection at overspeed detection	1	0 to 3	-	B	-	B	-	-	0 Ramp to stop 1 Coast to stop 2 Emergency stop 3 Operation continue
F1-04	383H	Operation selection at excessive speed deviation detection	3	0 to 3	-	B	-	B	-	-	0 Ramp to stop 1 Coast to stop 2 Emergency stop 3 Operation continue
F1-05	384H	PG rotation	0	0/1	-	B	-	B	-	-	0 Ramp to stop 1 Coast to stop 2 Emergency stop 3 Operation continue
F1-06	385H	PG division rate (PG pulse monitor output)	1	1 to 132	-	B	-	B	-	-	0 Forward direction 1 Reverse direction
F1-07	386H	Integral value during accel/decel enable/disable	0	0/1	-	B	-	B	-	-	0 Disabled 1 Enabled
F1-08	387H	Overspeed detection level	115	0 to 120%	-	A	-	A	-	-	
F1-09	388H	Overspeed detection delay time	0	0 to 20 sec	-	A	-	A	-	-	For V/f with PG feedback, initial value is 10
F1-10	389H	Excessive speed deviation detection level	10	0 to 50%	-	A	-	A	-	-	
F1-11	38AH	Excessive speed deviation detection delay time	0.5	0 to 100 sec	-	A	-	A	-	-	
F1-12	38BH	Number of PG gear teeth 1	0	0 to 1000	-	A	-	A	-	-	
F1-13	38CH	Number of PG gear teeth 2	0	0 to 1000	-	A	-	A	-	-	
F2-01	38DH	Not used	-	-	-	-	-	-	-	-	
F2-01	38EH	Not used	-	-	-	-	-	-	-	-	
F4-01	38FH	AO-12/H channel 1 monitor selection	0	0 to 50	○	B	○	B	B	B	0 Through mode
F4-02	390H	AO-12/H channel 1 gain	1.00	-300.00 to 300.00	○	B	○	B	B	B	Digital operator setting range -99.99 ~ +99.99
F4-03	391H	AO-12/H channel 2 monitor selection	0	0 to 50	○	B	○	B	B	B	0 Through mode
F4-04	392H	AO-12/H channel 2 gain	1.00	-300.00 to 300.00	○	B	○	B	B	B	Digital operator setting range -99.99 ~ +99.99
F4-05	393H	AO-12/H channel 1 bias	0	-32768 to 32767	○	B	○	B	B	B	30000/10V

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
F4-06	394H	AO-12/H channel 2 bias	0	-32768 to 32767	○	B	B	B	B	B	30000/10V
F5-01	395H	Not used	-	-	-	-	-	-	-	-	-
F5-02	396H	Not used	-	-	-	-	-	-	-	-	-
F6-01	397H	DO-08/H output mode selection	2	0 to 2		B	B	B	B	B	0' Individual outputs at 8 channels 1. Code output 2. General-purpose individual outputs
F7-01	398H	Not used	-	-	-	-	-	-	-	-	-
F8-01	399H	Division rate setting (EMS)	1	1 to 10		-	-	-	-	-	A
F8-02	39AH	Not used	-	-	-	-	-	-	-	-	-
F8-03	39BH	Not used	-	-	-	-	-	-	-	-	-
F8-04	39CH	Not used	-	-	-	-	-	-	-	-	-
F8-05	39DH	Not used	-	-	-	-	-	-	-	-	-
F8-06	39EH	Synchronous control ON/OFF selection (EMS)	0	0/1		-	-	-	-	-	0' OFF 1. ON
F9-01	39FH	External fault bit selection	0	0/1		A	A	A	A	A	0' Fault at "1" 1' Fault at "0"
F9-02	3A0H	External fault detection mode	0	0/1		A	A	A	A	A	0' Detected, always 1. Detected during run
F9-03	3A1H	Operation selection at external fault detection	1	0 to 3		A	A	A	A	A	0' Ramp to stop 1 Emergency stop 2 Coast to stop 3 Operation continue
F9-04	3A2H	Operation selection at bus error	1	0 to 3		A	A	A	A	A	0' Ramp to stop 1 Emergency stop 2 Coast to stop 3 Operation continue
F9-05	3A3H	Control data item selection, at high-speed side 1	3	1 to 18		A	A	A	A	A	Third control data
F9-06	3A4H	Control data item selection, at high-speed side 2	4	1 to 18		A	A	A	A	A	Fourth control data
F9-07	3A5H	Control data item selection, at low-speed side 1	15	1 to 18		A	A	A	A	A	15th control data
F9-08	3A6H	Control data item selection, at low-speed side 2	16	1 to 18		A	A	A	A	A	16th control data
F9-09	3A7H	Monitor data item selection, at high-speed side 1	9	1 to 50		A	A	A	A	A	Third monitor data
F9-10	3A8H	Monitor data item selection, at high-speed side 2	40	1 to 50		A	A	A	A	A	Fourth monitor data
F9-11	3A9H	Monitor data item selection, at low-speed side 1	15	1 to 50		A	A	A	A	A	15th monitor data

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
F9-12	3AAH	Monitor data item selection, at low-speed side 2	38	1 to 50		A	A	A	A	A	16th monitor data
F9-13	3ABH	Trace sampling cycle	0	0 to 60000 scan		A	A	A	A	A	0 Every scan
F9-14	3ACH	Transmission ASR proportional gain selection	0	0/1		—	A	—	A	—	0 The gain set by the constant is used 1 The gain sent from the master controller is used
F9-15	3ADH	Transmission regeneration side torque limit selection	0	0/1		—	—	A	A	—	0 The regeneration side torque limit set by the constant is used. 1 The regeneration side torque limit sent from the master controller is used
F9-16	3AEH	Not used	—	—		—	—	—	—	—	
F9-17	3AFH	Not used	—	—		—	—	—	—	—	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
H1-01	400H	Multi-function input (terminal 9CN-19)	0F	00 to FF		B	B	B	B	OF	Through mode
H1-02	401H	Multi-function input (terminal 9CN-20)	0F	00 to FF		B	B	B	B	OF	Through mode
H1-03	402H	Multi-function input (terminal 9CN-21)	0F	00 to FF		B	B	B	B	OF	Through mode
H1-04	403H	Multi-function input (terminal 9CN-22)	0F	00 to FF		B	B	B	B	OF	Through mode
H1-05	404H	Multi-function input (terminal 9CN-23)	0F	00 to FF		B	B	B	B	OF	Through mode
H1-06	405H	Multi-function input (terminal 9CN-24)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-01	406H	Multi-function output (terminal TB2-4, 5)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-02	407H	Multi-function output (terminal 10CN-10)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-03	408H	Multi-function output (terminal 10CN-12)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-04	409H	Multi-function output (terminal 10CN-14)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-05	40AH	Multi-function output (terminal 10CN-16)	0F	00 to FF		B	B	B	B	OF	Through mode
H2-06	40BH	Multi-function output (terminal TB2-1, 2, 3)	0E	00 to FF		B	B	B	B	OE	Error
H3-01	40CH	Signal level selection (terminal 9CN-4)	0	0/1		B	B	B	B	0 to 10 V	
H3-02	40DH	Gain (terminal 9CN-4)	100.0	0.0 to 1000.0%	0	B	B	B	B	1 -10 V to +10V	
H3-03	40EH	Bias (terminal 9CN-4)	0.0	-100.0 to 100.0%	0	B	B	B	B		
H3-04	40FH	Signal level selection (terminal 9CN-8)	0	0/1		B	B	B	B	0 to 10 V	
H3-05	410H	Not used	-	-	-	-	-	-	-		
- H3-06	411H	Gain (terminal 9CN-8)	100.0	0.0 to 1000.0%	0	B	B	B	B		
H3-07	412H	Bias (terminal 9CN-8)	0.0	-100.0 to 100.0%	0	A	A	A	A	0 to 10 V	
H3-08	413H	Signal level selection (terminal 9CN-6)	2	0 to 2		A	A	A	A	1 -10 V to +10V	
H3-09	414H	Not used	-	-	-	-	-	-	-		
H3-10	415H	Gain (terminal 9CN-6)	100.0	0.0 to 1000.0%	0	A	A	A	A		
H3-11	416H	Bias (terminal 9CN-6)	0.0	-100.0 to 100.0%	0	A	A	A	A	2.4 to 20 mA	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
H3-12	417H	Analog input filter time constant	0.00	0.00 to 2.00 sec		A	A	A	A	A	
H4-01	418H	Multi-function AO (terminal 10CN-2)	0	0 to 50	○	B	B	B	B	B	0. Through mode
H4-02	419H	Gain (terminal 10CN-2)	1.00	-300.00 to 300.00	○	B	B	B	B	B	Digital operator setting range -99.99 ~ +99.99
H4-03	41AH	Bias (terminal 10CN-2)	0	-32768 to 32767	○	B	B	B	B	B	30000/10V
H4-04	41BH	Multi-function AO (terminal 10CN-4)	0	0 to 50	○	B	B	B	B	B	0 Through mode
H4-05	41CH	Gain (terminal 10CN-4)	1.00	-300.00 to 300.00	○	B	B	B	B	B	Digital operator setting range -99.99 ~ +99.99
H4-06	41DH	Bias (terminal 10CN-4)	0	-32768 to 32767	○	B	B	B	B	B	30000/10V
H4-07	41EH	Analog output signal polarity selection	1	0/1		B	B	B	B	B	Also used for signal characteristics of AO-12/H 0' Unsigned 1. Signed
H5-01	41FH	Not used	-	-	-	-	-	-	-	-	
H5-02	420H	Not used	-	-	-	-	-	-	-	-	
H5-03	421H	Not used	-	-	-	-	-	-	-	-	
H5-04	422H	Not used	-	-	-	-	-	-	-	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
L4-01	493H	Desired speed agree detection level	0 00	0 00 to 100 00%		B	B	B	B	B	The unit varies depending on the setting of O1-03 EMS Desired current detection level should be set Minimum setting unit is fixed at 0 01%
L4-02	494H	Speed detection width	2.00	0 00 to 100 00%		B	B	B	B	B	The unit varies depending on the setting of O1-03 For V/f control and V/f with PG feedback, initial value is 1 20 Hz EMS Current detection width should be set Minimum setting unit is fixed at 0 01%
L4-03	495H	Not used	-	-	-	-	-	-	-	-	
L4-04	496H	Not used	-	-	-	-	-	-	-	-	
L4-05	497H	Not used	-	-	-	-	-	-	-	-	
L5-01	498H	Number of auto restart attempts	0	0 to 10		B	B	B	B	-	
L5-02	499H	Auto restart operation selection	0	0/1		B	B	B	B	-	0 No fault retry 1 Fault retry active
L5-03	49AH	Not used									
L6-01	49BH	Torque detection selection	0	0 to 4		B	B	B	B	-	0 Disabled 1 Detects during constant-speed run (operation continue) 2 Detects during run (operation continue) 3 Detects during constant-speed run (operation stopped) 4 Detects during running (operation stopped)
L6-02	49CH	Torque detection level	150	0 to 300%		B	B	B	B	-	
L6-03	49DH	Torque detection time	0.1	0.0 to 10.0 sec		B	B	B	B	-	0 Disabled 1 Detects during constant-speed run (operation continue) 2 Detects during run (operation continue) 3 Detects during constant-speed run (operation stopped) 4 Detects during running (operation stopped)
L6-04	49EH	Torque detection selection 2	0	0 to 4		A	A	A	A	-	
L6-05	49FH	Torque detection level 2	150	0 to 300%		A	A	A	A	-	
L6-06	4AOH	Torque detection time 2	0.1	0.0 to 10.0 sec		A	A	A	A	-	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
L7-01	4A1H	Forward torque limit	160	0 to 300%	-	-	B	B	B	-	
L7-02	4A2H	Reverse torque limit	160	0 to 300%	-	-	B	B	B	-	
L7-03	4A3H	Forward regenerative torque limit	160	0 to 300%	-	-	B	B	B	-	
L7-04	4A4H	Reverse regenerative torque limit	160	0 to 300%	-	-	B	B	B	-	
L7-05	4A5H	Not used	-	-	-	-	-	-	-	-	
L7-06	4A6H	Not used	-	-	-	-	-	-	-	-	
L8-01	4A7H	Braking circuit protection selection	2	0 to 2			B	B	B	-	0 Braking transistor provided, braking resistor not provided 1. Braking transistor provided, braking resistor not provided 2. Braking transistor not provided
L8-02	4A8H	Inverter overheat pre-alarm level	100	50 to 110 deg		A	A	A	A	A	
L8-03	4A9H	Operation selection after inverter overheat pre-alarm	3	0 to 3		A	A	A	A	A	
L8-04	4AAH	Not used	-	-	-	-	-	-	-	-	
L8-05	4ABH	Input open-phase protection selection	0	0/1		A	A	A	A	A	0. Input open-phase protection not provided 1. Input open-phase protection provided
L8-06	4ACH	Not used	-	-	-	-	-	-	-	-	
L8-07	4ADH	Output open-phase protection selection	1	0/1		A	A	A	A	A	0 Output open-phase protection not provided 1 Output open-phase protection provided
L8-08	4AEH	Not used	-	-	-	-	-	-	-	-	
L8-09	4AFH	Not used	-	-	-	-	-	-	-	-	
L8-10	4B0H	Not used	-	-	-	-	-	-	-	-	
L8-11	4B1H	Not used	-	-	-	-	-	-	-	-	
L8-12	4B2H	Not used	-	-	-	-	-	-	-	-	
L8-13	4B3H	Not used	-	-	-	-	-	-	-	-	
L9-01	4B4H	Thermistor provided/not provided selection	1	0/1		B	B	B	B	B	For V/f control and V/f with PG feedback, initial value is 0 0. Not provided 1. Provided
L9-02	4B5H	Operation selection at thermistor open circuit	3	0 to 3		B	B	B	B	B	

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remarks
L9-03	4B6H	Operation selection at motor overheat (OH3)	1	0 to 3		B	B	B	B	-	
L9-04	4B7H	Motor 2 thermistor provided/not provided selection	1	0/1		A	A	A	A	-	For V/f control and V/f with PG feedback, initial value is 0.

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remark
01-01	500H	Monitor selection	6	4 to 50	O	B	B	B	B	B	
01-02	501H	Monitor selection after power up	1	1 to 4	O	B	B	B	B	B	1. Speed reference 2. Motor speed (equivalent to U1-05) 3. Output current 4. Monitor items set by O1-01
01-03	502H	Setting/display unit of speed reference/monitor	1	0 to 39999	B	B	B	B	B	B	For V/f control and V/f with PG feedback, initial value is 0. EMS Fixed to 0
01-04	503H	Setting unit of V/f patterns	1	0/1	B	B	B	B	B	B	
01-05	504H	Not used	-	-	-	-	-	-	-	-	
02-01	505H	LOCAL/REMOTE key enable/disable	1	0/1	B	B	B	B	B	B	0 Hz 1. r/min
02-02	506H	STOP key enable/disable during remote operation	0	0/1	B	B	B	B	B	B	
02-03	507H	Not used	-	-	-	-	-	-	-	-	
02-04	508H	kVA selection	*	00 to FF	B	B	B	B	B	B	Depends on inverter capacity
02-05	509H	Speed reference setting method selection	0	0/1	A	A	A	A	A	A	0 ENTER key operation is necessary 1 ENTER key operation is not necessary
02-06	50AH	Digital operator disconnection detection enable/disable selection	0	0/1	A	A	A	A	A	A	0 Operation continues even when digital operator is disconnected 1. Inverter fault when digital operator is disconnected
02-07	50BH	Cumulative operation time setting	-	0 to 65535H	A	A	A	A	A	A	
02-08	50CH	Cumulative operation time selection	0	0/1	A	A	A	A	A	A	0 Power ON time 1. Running time

Constant No.	MEMOBUS Address	Constant Name	Initial Value	Setting Range	Change during Operation	V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS Control	Remark
T1-01	F0H	Motor selection	1*	1/2	-	-	B	B	-	-	1. No 1 motor 2. No 2 motor
T1-02	F1H	Tuning mode	0*	0 to 4	-	-	B	B	-	-	0 Normal operation mode 1 Tuning by inputting nameplate value (digital operator) 2. Tuning by inputting motor constant (digital operator) 3 Tuning by inputting nameplate value (master controller) 4 Tuning by inputting motor constant (master controller)
T2-01	F2H	Motor base voltage	E1-13† (E4-13)‡	0.0 to 255.0 V	-	-	B	B	-	-	Motor nameplate value should be input
T2-02	F3H	Motor rated current	E2-01† (E5-01)‡	0.00 to 2000.0 A	-	-	B	B	-	-	Motor nameplate value should be input Input the base side value For 7.5 kW model or smaller, minimum unit is 0.01 A
T2-03	F4H	Motor base frequency	*†	0.00 to 400.00 Hz	-	-	B	B	-	-	Motor nameplate value should be input No 1 motor (E1-06) × (E2-04)/120 No 2 motor (E4-03) × (E5-04)/120
T2-04	F5H	Motor base r/min	E1-06† (E4-03)	0 to 24000 r/min	-	-	B	B	-	-	Motor nameplate value should be input.
T2-05	F6H	Number of motor poles	E2-04 (E5-04)‡	2 to 48	-	-	B	B	-	-	Motor nameplate value should be input
T2-06	F7H	Motor insulation class	0	0 to 4	-	-	B	B	-	-	Motor nameplate value should be input Insulation class A (100°C) 0 E (120°C) 1 B (130°C) 2 F (155°C) 3 H (180°C) 4
T2-07	F8H	PG constant	F1-01† (E3-03)‡	0 to 10000	-	-	B	B	-	-	

*When setting up, return to the initial value

†When setting up, or changing T1-01 setting, return to the initial value.
‡For No. 2 motor (T1-01 = 2)

Table A-11 Table of Multi-function Input/Output Terminal Setting

Setting Value	Multi-function Input Terminal Functions (H1-01, 02, 03, 04, 05, 06)
02	Option/inverter selection
08	External base block (NO contact)
09	External base block (NC contact)
0F	Through mode
14	Fault reset
15	Emergency stop
20	
21 - 2F	External fault

Setting Value	Multi-function Output Terminal Functions (H2-01, 02, 03, 04, 05, 06)
00	During run
01	Zero speed
02	Frequency agree 1
03	Desired frequency agree 1
06	Inverter ready
07	Low voltage detected
08	Base block
0E	Fault
0F	Through mode
11	Fault reset
1A	During reverse run

The following constants are changed when the set value of A1-02 is changed.

Table A-12 Constants for Which Factory-set Values Vary Depending on Control Mode

Constant No.	Constant Name	Factory-set Values				
		V/f Control	V/f with PG Feedback	Open Loop Vector	Flux Vector	EMS
B3-01	Speed search selection at start	0	1	0	1	-
C3-01	Slip compensation gain	0.0	-	1.0	0.0	-
C3-02	Slip compensation primary delay time	2000	-	200	-	-
C4-02	Torque compensation time constant	200	200	20	-	-
C5-01	ASR proportional (P) gain 1	-	0.20	-	20.00	-
C5-02	ASR integral (I) time 1	-	0.200	-	0.500	-
C5-03	ASR proportional (P) gain 2	-	0.02	-	20.00	-
C5-04	ASR integral (I) time 2	-	0.050	-	0.500	-
C5-05	ASR limit	-	5.0	-	-	-
C5-06	ASR primary delay time	-	-	-	0.000	-
E1-04 E4-01	Rated r/min	1800		1750		-
E1-06 E4-03	Base speed	1800		1750		-
E1-08 E4-05	Middle voltage	(① 15.0 * ② 14.0 ③ 12.0)		11.0	-	-
E1-09 E4-06	Minimum speed	45		15	0	-
E1-10 E4-07	Minimum voltage	(① 9.0 * ② 7.0 ③ 6.0)		2.0	-	-
E1-13 E4-13	Base voltage	0.0		180.0		-
F1-09	Overspeed detection delay time	-	1.0	-	0.0	-
L2-04	Voltage recovery time	0.300	0.300	0.300	0.100	-
L3-03	Stall prevention limit during acceleration	50	50	100	-	-
L4-02	Speed detection width	1.20 Hz	1.20 Hz	2.00%	2.00%	2.00%
L9-01	Thermistor provided/not provided selection	0	0	1	1	-
L9-04	Motor 2 thermistor provided/not provided selection	0	0	1	1	-
O1-03	Setting/display unit of speed reference/monitor	0	0	1	1	-

*Constants that vary depending on kVA selection

- ① 0.4 to 1.5 kW
- ② 2.2 to 45 kW
- ③ 55 kW or larger

The following constants are changed when the set value of O2-04 is changed.

Table A-13 Constants for Which Factory-set Values Vary Depending on Inverter Output (O2-04)
200 V Class

Constant No.	Constant Name	Unit	Factory-set Values									
—	Inverter capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5
O2-04	kVA selection	1	0	1	2	3	4	5	6	7	8	9
C6-01	Carrier frequency upper limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
—	Upper limit range of carrier frequency	kHz	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.0
C6-02	Carrier frequency lower limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
C6-03	Carrier frequency proportional gain	1	0	0	0	0	0	0	0	0	0	0
—	Inverter rated current	A	3.2	6.0	8.0	11.0	17.5	25.0	33.0	49.0	64.0	80.0
E2-01	Motor rated current	A	1.90	3.30	6.20	8.50	14.00	19.60	26.60	39.7	53.0	65.8
E2-02	Motor rated slip	Hz	2.90	2.50	2.60	2.90	2.73	1.50	1.30	1.70	1.60	1.67
E2-03	Motor no-load current	A	1.20	1.80	2.80	3.00	4.50	5.10	8.00	11.2	15.2	15.7
E2-05	Motor line-to-line resistance	Ω	9.842	5.156	1.997	1.601	0.771	0.399	0.288	0.230	0.138	0.101
E2-06	Motor leak inductance	%	18.2	13.8	18.5	18.4	19.6	18.2	15.5	19.5	17.2	20.1
L2-02	Momentary power loss ridethru time	sec	1.0	1.0	-1.0	-1.0	1.0	1.0	1.0	1.0	1.0	1.0
L2-03	Minimum base block time	sec	0.5	0.5	0.5	0.5	0.5	0.7	0.7	0.7	0.7	1.0

200 V Class

Constant No.	Constant Name	Unit	Factory-set Values					
—	Inverter capacity	kW	22	30	37	45	55	75
O2-04	kVA capacity selection	1	A	B	C	D	E	F
C6-01	Carrier frequency upper limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0
—	Upper limit range of carrier frequency	kHz	10.0	10.0	10.0	10.0	10.0	10.0
C6-02	Carrier frequency lower limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0
C6-03	Carrier frequency proportional gain	1	0	0	0	0	0	0
—	Inverter rated current	A	96.0	130.0	160.0	183.0	224.0	300.0
E2-01	Motor rated current	A	77.2	105.0	131.0	160.0	190.0	260.0
E2-02	Motor rated slip	Hz	1.70	1.80	1.33	1.60	1.43	1.39
E2-03	Motor no-load current	A	18.5	21.9	38.2	44.0	45.6	72.0
E2-05	Motor line-to-line resistance	Ω	0.079	0.064	0.039	0.030	0.022	0.023
E2-06	Motor leak inductance	%	19.5	20.8	18.8	20.2	20.5	20.0
L2-02	Momentary power loss ridethru time	sec	1.0	1.0	1.0	1.0	1.0	1.0
L2-03	Minimum base block time	sec	1.0	1.0	1.0	1.0	1.0	1.0

The following constants are changed when the set value of O2-04 is changed.

Table A-14 Constants for Which Factory-set Values Vary Depending on Inverter Output (O2-04)
400 V Class

Constant No.	Constant Name	Unit	Factory-set Values										
-	Inverter capacity	kW	0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11	15	18.5
O2-04	kVA selection	1	20	21	22	23	24	25	26	27	28	29	2A
C6-01	Carrier frequency upper limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
-	Upper limit range of carrier frequency	kHz	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
C6-02	Carrier frequency lower limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
C6-03	Carrier frequency proportional gain	1	0	0	0	0	0	0	0	0	0	0	0
-	Inverter rated current	A	1.8	3.4	4.8	6.2	8.0	11.0	14.0	18.0	27.0	34.0	41.0
E2-01	Motor rated current	A	1.00	1.60	3.10	4.20	7.00	7.00	9.80	13.30	19.9	26.5	32.9
E2-02	Motor rated slip	Hz	2.90	2.60	2.50	3.00	2.70	2.70	1.50	1.30	1.70	1.60	1.67
E2-03	Motor no-load current	A	0.60	0.80	1.40	1.50	2.30	2.30	2.60	4.00	5.6	7.6	7.8
E2-05	Motor line-to-line resistance	Ω	38.198	22.459	10.100	6.495	3.333	3.333	1.595	1.152	0.922	0.550	0.403
E2-06	Motor leak inductance	%	18.2	14.3	18.3	18.7	19.3	19.3	18.2	15.5	19.6	17.2	20.1
L2-02	Momentary power loss ridethru time	sec	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
L2-03	Minimum base block time	sec	0.5	0.5	0.5	0.5	0.5	0.7	0.7	0.7	0.7	0.7	1.0

400 V Class

Constant No.	Constant Name	Unit	Factory-set Values										
-	Inverter capacity	kW	2.2	3.0	3.7	4.5	5.5	7.5	11.0	16.0	18.5	22.0	30.0
O2-04	kVA selection	1	2B	2C	2D	2E	2F	30	32	34	35	36	37
C6-01	Carrier frequency upper limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
-	Upper limit range of carrier frequency	kHz	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	2.5	2.5	2.5
C6-02	Carrier frequency lower limit	kHz	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
C6-03	Carrier frequency proportional gain	1	0	0	0	0	0	0	0	0	0	0	0
-	Inverter rated current	A	48.0	65.0	80.0	96.0	128.0	165.0	224.0	302.0	340.0	450.0	605.0
E2-01	Motor rated current	A	38.6	52.3	65.6	79.7	95.0	130.0	190.0	270.0	310.0	370.0	500.0
E2-02	Motor rated slip	Hz	1.70	1.80	1.33	1.60	1.46	1.39	1.40	1.35	1.30	1.30	1.25
E2-03	Motor no-load current	A	9.2	10.9	19.1	22.0	24.0	36.0	49.0	70.0	81.0	96.0	130.0
E2-05	Motor line-to-line resistance	Ω	0.316	0.269	0.155	0.122	0.088	0.092	0.046	0.029	0.025	0.020	0.014
E2-06	Motor leak inductance	%	23.5	20.7	18.8	19.9	20.0	20.0	20.0	20.0	20.0	20.0	20.0
L2-02	Momentary power loss ridethru time	sec	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
L2-03	Minimum base block time	sec	1.0	1.0	1.0	1.0	1.0	1.0	4.0	4.0	4.0	4.0	4.0

Table A-15 Monitor Unit

Constant No.	Constant Name	Digital Operator	MEMOBUS	Master Controller Control Response Level	Analog Output Level (At Gain=1.0)	Value at 100%
U1-01	Speed reference	*1	0~1Hz	30000/100%	10V/100%	E1-04 *4
U1-02	Output frequency	0~1Hz	0~1Hz	30000/100%	10V/100%	E1-04 *4
U1-03	Output current	0~1A *2	8192/100%	10000/100%	10V/100%	Inverter rated current
U1-04	Control method	No	No	No	0	-
U1-05	Motor speed	*1	0~1Hz	30000/100%	10V/100%	(E1-04) × (C9-01) *4
U1-06	Output voltage	0~1V	0~1V	10000/100%	10V/100%	Voltage class *7
U1-07	DC bus voltage	1V	1V	10000/100%	10V/100%	Voltage class × 2 *7
U1-08	Output power	0~1kW	0~1kW	0~1kW	10V/100%	Motor rated output
U1-09	Torque reference (internal)	0~1%	0~1%	10000/100%	10V/100%	Motor rated torque
U1-10	Input terminal status	bit	bit	bit	0	-
U1-11	Output terminal status	bit	bit	bit	0	-
U1-12	Operation status	bit	bit	bit	0	-
U1-13	Cumulative operation time	1H	1H	1H	0	-
U1-14	PROM No (at FLASH side)	No	No	0	0	-
U1-15	Input voltage at 9CN-4 (AI-1) terminal	0~1%	0~1%	0~4095/10~10V	10V/100%	10V
U1-16	Input voltage at 9CN-6 (AI-2) terminal	0~1%	0~1%	2048~4095/ 4~20mA *5	10V/100%	20mA
U1-17	Input voltage at 9CN-8 (AI-3) terminal	0~1%	0~1%	0~4095/10~10V	10V/100%	10V
U1-18	Motor secondary current (Iq)	0~1%	0~1%	10000/100%	10V/100%	E2-01
U1-19	Motor exciting current (Id)	0~1%	0~1%	10000/100%	10V/100%	E2-01
U1-20	Soft starter output	*1	0~1Hz	30000/100%	10V/100%	E1-04 *4
U1-21	ASR input (speed deviation)	*1	0~0.1%	10000/100%	10V/100%	(E1-04) × (C9-01) *4
U1-22	ASR output	0~0.1%	0~0.1%	10000/100%	10V/100%	*4 *6
U1-23	Current reference soft starter input	0~0.1%	0~0.1%	10000/100%	10V/100%	E2-01
U1-24	Current reference soft starter output	0~0.1%	0~0.1%	10000/100%	10V/100%	E2-01
U1-25	Current control deviation	0~0.1%	0~0.1%	10000/100%	10V/100%	E2-01
U1-26	Output voltage reference (Vq)	0~1V	0~1V	10000/100%	10V/100%	Voltage class *7
U1-27	Output voltage reference (Vd)	0~1V	0~1V	10000/100%	10V/100%	Voltage class *7
U1-28	PROM No (at CPU ROM side)	No	No	0	0	-
U1-29	LED check (diagnosis)	-	0	0	0	-
U1-30	Operation status 2	bit	bit	bit	0	-
U1-31	Master controller command 1	bit	bit	bit	0	-
U1-32	Master controller command 2	bit	bit	bit	0	-
U1-33	External torque reference	0~0.1%	0~0.1%	10000/100%	10V/100%	Motor rated torque
U1-34	Torque compensation	0~0.1%	0~0.1%	10000/100%	10V/100%	Motor rated torque
U1-35	Slip frequency reference	0~0.1%	0~0.1%	10000/100%	10V/100%	E1-04 *4
U1-36	Magnetic flux reference	0~0.1%	0~0.1%	10000/100%	10V/100%	-
U1-37	DO-08/H output status	bit	bit	bit	0	-
U1-38	Momentary power loss drop amount	*1	0~1Hz	30000/100%	10V/100%	(E1-04) × (C9-01) *4
U1-39	Motor temperature	1°C	1°C	1°C	10V/100%	200°C
U1-40	Speed detection PG counter value	Pulse	Pulse	Pulse	10V/100%	32768

Table A-15 Monitor Unit (Cont'd)

Constant No.	Constant Name	Digital Operator	MEMOBUS	Master Controller Control Response Level	Analog Output Level (At Gain=1.0)	Value at 100%
U1-41	Acceleration torque monitor (observer)	0 1%	0 1%	10000/100%	10V/100%	Motor rated torque
U1-42	Acceleration torque reference (observer)	0 1%	0 1%	10000/100%	10V/100%	Motor rated torque
U1-43	Torque observer control PI output	0 1%	0 1%	10000/100%	10V/100%	Motor rated torque
U1-44	Torque observer control output	0 1%	0 1%	10000/100%	10V/100%	Motor rated torque
U1-45	Synchronous phase difference	0 1deg	0 1deg	0 1deg	10V/100%	360deg
U1-46	Output voltage phase	0 1deg	0 1deg	0 1deg	10V/100%	360deg
U1-47	Zero-servo move pulse	Pulse	Pulse	Pulse	10V/100%	32768
U1-48	ACR (q) output	0 1%	0 1%	10000/100%	10V/100%	Voltage class *7
U1-49	ACRd output	0 1%	0 1%	10000/100%	10V/100%	Voltage class *7
U1-50	Setting Fault Data Address	*3	ADDRESS	0	0	-

Table A-15 Monitor Unit (Cont'd)

Constant No.	Constant Name	Digital Operator	MEMOBUS	Value at 100%
U2-01	Current fault	-	-	-
U2-02	Last fault	-	-	-
U2-03	Speed reference (U1-01) at fault	*1	0 1Hz	-
U2-04	Output frequency (U1-02) at fault	0 01Hz	0 1Hz	-
U2-05	Inverter output current (U1-03) at fault	0 1A *2	8192/100%	Motor rated current
U2-06	Motor speed (U1-05) at fault	*1	0 1Hz	-
U2-07	Output voltage reference (U1-06) at fault	0 1V	0 1V	-
U2-08	DC bus voltage (U1-07) at fault	1V	1V	-
U2-09	Output power (U1-08) at fault	0 1kW	0 1kW	-
U2-10	Torque reference (U1-09) at fault	0 1%	0 1%	Motor rated torque
U2-11	Input terminal status (U1-10) at fault	bit	bit	-
U2-12	Output terminal status (U1-11) at fault	bit	bit	-
U2-13	Operation status (U1-12) at fault	bit	bit	-
U2-14	Cumulative operation time (U1-13) at fault	1H	1H	-
U2-15	Speed controller (ASR) output (U1-22) at fault	0 01%	0 01%	*4 *6
U2-16	Current control deviation (U1-25) at fault	0 01%	0 01%	E2-01
U2-17	Operation status 2 (U1-30) at fault	bit	bit	-
U2-18	Master controller command 1 (U1-31) at fault	bit	bit	-
U2-19	Master controller command 2 (U1-32) at fault	bit	bit	-
U2-20	External torque reference (U1-33) at fault	0 01%	0 01%	Motor rated torque
U2-21	Torque compensation (U1-34) at fault	0 01%	0 01%	Motor rated torque
U2-22	Magnetic flux reference (U1-36) at fault	0 01%	0 01%	-
U2-23	Observer control output (U1-44) at fault	0 1%	0 1%	Motor rated torque
U2-24	Output voltage phase (U1-46) at fault	0 1deg	0 1deg	-

*1 The unit varies depending on the setting of O1-03

*2 For 7.5kW model or smaller, minimum unit is 0 01A

*3 The constant No. at setting fault is displayed

*4 E1-04 changes into E4-01 when selecting the No 2 motor

*5 0 to 4095/-10V to 10V when H3-08=0

*6 For V/f control (E1-04) × (C9-01), For Vector control: $\sqrt{[(E2-01)^2 - (E2-03)^2]}$

*7 Voltage class: 200V or 400V

INDEX

A

- accel /decel: time setting unit 116
accel/decel time 87, 88, 89
acceleration time 116
acceleration torque monitor 110
acceleration torque reference 110
ADVANCED 64
ADVANCED 68
allowable frequency fluctuation 89
allowable voltage fluctuation 87, 88, 89
ambient temperature 78, 87, 88, 89
analog output option 28
approx. mass 91
auto-tuning 55

B

- base r/min 121
base test-mode fault 83
base voltage 122
baseblock circuit fault 82
BASIC 64, 68
blown fuse protection 87, 88, 89
book type 13, 90
braking circuit protection selection 132
braking resistor unit overheat 81
braking torque 87, 88, 89
braking transistor failure 81
built-in inrush current supressing circuit 93

C

- carrier frequency 53, 117
carrier frequency constant setting fault 83
common RAM BCC error 82
common RAM initial check fault 82
communication-data 104
communication option 31
connection diagram of analog output option 28
connection diagram of communication option 31
connection diagram of digital output option 29
connection diagram of inverter kit controller option 30
connection diagram of PG card option 25
connection diagram of synchronous control option 27
connection diagrams 23, 93
constant setting range fault 83
control characteristics 87, 88, 89
control circuit 47
control circuit fault 82
control circuit terminal 74
control circuit terminal signal 74
control circuit terminals 47
control circuit undervoltage 80

- control circuit wiring 48
control commands 104
control data item selection 126
control method 87, 88, 89, 109
control method selection 113
control mode 65
control mode selection fault 83
control PC board 8, 77
control response 105
converter overheat 81
cooling air 21
cooling fan 78
CP-216 Transmission error 83
CPU external A/D converter fault 82
CPU internal A/D converter fault 82
cross diagnose fault 82
cubic type 13, 90
cumulative operation time 109, 134
current control deviation 110
current reference 120
current reference negative start time 116
current reference positive start time 116
current unbalance 81

D

- DC bus voltage 109
DC injection braking current 114
DC injection braking time at stop 114
DC power ON/OFF switch (SW) 33
deceleration time 116
desired speed agree detection level 131
digital operator 60, 70
digital operator fault 83
digital output option 29
dimentions 90
division rate setting 126
drive mode 60, 61, 62
droop amount 115
droop control 119

E

- EEPROM fault 82
EEPROM writing fault 83
electronic thermal overload relay 87, 88, 89
elevation 87, 88, 89
emergency stop circuit 5, 22
emergency stop time 116
EMS-control 102
EMS current control 115
enclosed wall-mounted type 87, 88, 89

enclosure	13
energy-saving control	118
environment	87, 88, 89
external fault	81, 82, 126
external magnetic flux reference	120

F

fault and alarm signals	108
fault diagnosis	79
feeder resistance	122
filter time constant	129
flux vector control	96
frequency accuracy	87, 88, 89
frequency control range	87, 88, 89
frequency resolution	87, 88, 89
front cover	14
function block diagrams	96
fuse blown	81

G

ground fault	87, 88, 89
ground fault interrupter	32
ground resistance	35
ground terminal	5, 32
grounding	34, 35, 80

H

heatsink	78
heatsink overheat	81, 87, 88, 89
humidity	87, 88, 89
hunting prevention	117

I

initialize	113
input open-phase	80
input open-phase	132
input terminal	36
input terminal status	109
input voltage	121
inrush current suppressing circuit	33
instantaneous overcurrent	87, 88, 89
insulation class	135
integral value	125
inverter capacity	87, 88, 89
inverter kit controller option	30
inverter overload	81
iron-core saturation coefficient	59, 122

K

kVA selection	134
---------------------	-----

kVA selection fault	83
---------------------------	----

L

leak inductance	122
LEDs	79
line resistance	59
line voltage using jumper	50
line-to-line resistance	122
load	34
load factor	78
load short-circuit	81
LOCAL	54
location	87, 88, 89

M

magnetic contactor	32
magnetic contactor	34
magnetic flux reference	110
magnetic starter or contactor	34
main circuit	32
main circuit configuration	38
main circuit power supply	6, 8, 77
main circuit terminal	36
main circuit terminals	36
main circuit undervoltage	80
master controller command	110
max. applicable motor output	13, 87, 88, 89
max. output voltage	87, 88, 89
maximum output frequency	124
mechanical loss	122
middle r/min	121
middle voltage	121
minimum base block time	130
minimum output frequency	124
minimum r/min	121
minimum voltage	121
mode selection	61
molded-case circuit breaker	77
momentary power loss	80, 87, 88, 89
momentary power loss drop amount	110
momentary power loss ridethru time	130
monitor constants	86, 109
monitor data item selection	126
motor change error	82
motor exciting current	109
motor mechanical time constant	119
motor overheat	81
motor overload	81
motor overload protection	87, 88, 89
motor secondary current	109
motor selection	121, 135
motor speed	109

motor temperature	110
multi-function contact input selection fault	83

N

nameplate	12
nameplate data	12
no-load current	59, 122
number of auto restart attempts	131
number of motor poles	122

O

open chassis type	13
open loop vector control	98
open phase	84
operation method selection	114
operation mode	54, 60
operation signals	106
operation status	109
option card	16
option card connection fault	82
option reference selection fault	83
output characteristics	87, 88, 89
output current	109
output frequency	109
output mode selection	126
output open-phase	80
output open-phase	132
output power	109
output terminal	34
output terminal status	109
output terminals	34
output voltage	109
output voltage phase	110
output voltage reference	110
overcurrent	80
overload	87, 88, 89
overload capacity	87, 88, 89
overspeed	80
overspeed detection	125
overtorque	81
overvoltage	80, 87, 88, 89

P

password	113
periodic inspection	78
PG card option	25
PG constant	125, 135
PG open circuit	80
phase advancing capacitor	33, 34
PI limit	115
power average time	118

power charge indication	87, 88, 89
power detection filter	119
power elements	78
power supply	87, 88, 89
pre-chARGE contactor open	80
printed circuit board	78
probing operation	119
program mode	61, 66
PROM no.	109
protective functions	87, 88, 89
PWM timer fault	82

Q

QUICK-START	64
QUICK-START	67

R

rated input voltage and frequency	87, 88, 89
rated output current	87, 88, 89
rated output frequency	87, 88, 89
rated r/min	121
rated slip	59, 122
rated speed adjustment	118
rated voltage	121
reference selection	114
REMOTE	54
reverse run prohibition selection	114

S

shielded wire	48
short circuiting	34
shortcircuit	34
sine wave PWM	87, 88, 89
slip compensation	116
slip frequency reference	110
smoothing capacitor	78
soft starter output	109
specifications	87
speed control accuracy	87, 88, 89
speed control range	87, 88, 89
speed detection PG counter value	110
Speed detection width	131
speed deviation	80
speed deviation detection	125
speed limit	120
speed reference	109, 120
speed response	87, 88, 89
speed search	114
stall prevention	87, 88, 89, 130
starting torque	87, 88, 89
status signals	107

stopping method selection	114
storage temperature	87, 88, 89
surge suppressor	32
synchronous control option	27
synchronous phase difference	110

T

terminal screw	42,43,44
test mode	118
test run	70
thermal overload relay	35
thermistor	54, 87, 88, 89, 132
thermistor open circuit	80, 132
torque accuracy	87, 88, 89
torque compensation	110, 116
torque detection	131
torque limit	87, 88, 89, 132
torque observer	110, 119
torque reference	109, 120
torque response	87, 88, 89
trace sampling cycle	127
transmission control card hardware fault	82
transmission control card code no. error	82
tuning mode	135
twisted shielded wire	2,43,44
twisted-pair shielded wires	48

U

undervoltage	87, 88, 89
undervoltage detection level	130

V


V/f control	100
V/f data setting fault	83
V/f pattern selection	121
vibration	87, 88, 89
voltage	13
voltage recovery time	130

W

warning label	9
wire size	42,43,44,45
wiring the control circuit	47
withstand voltage test	6,22

Z

zero-servo completion width	115
zero-servo gain	115
zero-servo move pulse	110





VARISPEED-676H5

INSTRUCTION MANUAL

TOKYO OFFICE New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minato-ku, Tokyo 105 Japan
Phone 81-3-5402-4511 Fax 81-3-5402-4580

YASKAWA ELECTRIC AMERICA, INC.

Chicago-Corporate Headquarters 2942 MacArthur Blvd Northbrook, IL 60062-2028, U S A

Phone 1-847-291-2340 Fax 1-847-498-2430

Chicago-Technical Center 3160 MacArthur Blvd Northbrook, IL 60062-1917, U S A

Phone 1-847-291-0411 Fax 1-847-291-1018

MOTOMAN INC.

805 Liberty Lane West Carrollton, OH 45449, U S A

Phone 1-937-847-6200 Fax 1-937-847-6277

YASKAWA ELÉTRICO DO BRASIL COMÉRCIO LTDA.

Avenida Brigadeiro Faria Lima 1664-5° CJ 504/511, São Paulo, Brazil

Phone 55-11-815-7723 Fax 55-11-870-3849

YASKAWA ELECTRIC EUROPE GmbH

Am Kronberger Hang 2, 65824 Schwalbach, Germany

Phone 49-6196-569-300 Fax 49-6196-888-301

Motoman Robotec AB

Box 504 S38525 Torsås, Sweden

Phone 46-486-48800 Fax 46-486-41410

Motoman Robotec GmbH

Kammerfeldstraße 1, 85391 Allershausen, Germany

Phone 49-8166-900 Fax 49-8166-9039

YASKAWA ELECTRIC UK LTD.

Unit2 Centunion Court Brick Close, Kilk Farm, Milton Keynes MK11 3JA, United Kingdom

Phone 44-1908-565874 Fax 44-1908-565891

YASKAWA ELECTRIC KOREA CORPORATION

Pak Nam Bldg 901 188-3, 1-Ga Euljiro, Joong-Gu Seoul, Korea

Phone 82-2-776-7844 Fax 82-2-753-2639

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.

151 Lorong Chuan, #04-01, New Tech Park Singapore 556741, Singapore

Phone 65-282-3003 Fax 65-289-3003

YATEC ENGINEERING CORPORATION

Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan

Phone 886-2-563-0010 Fax 886-2-567-4677

BEIJING OFFICE Room No 301 Office Building of Beijing International Club, 21

Jiangwumenwa Avenue, Beijing 100020, China

Phone 86-10-532-1850 Fax 86-10-532-1851

SHANGHAI OFFICE 27 Hui He Road Shanghai 200437 China

Phone 86-21-6553-6080 Fax 86-21-6553-6060

YASKAWA JASON (HK) COMPANY LIMITED

Rm 2909-10, Hong Kong Plaza, 186-191 Connaught Road West, Hong Kong

Phone 852-2803-2385 Fax 852-2547-5773

TAIPEI OFFICE Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan

Phone 886-2-563-0010 Fax 886-2-567-4677



YASKAWA ELECTRIC CORPORATION

YASKAWA