

# VARISPEED-686SS5

# DESCRIPTIVE MANUAL FOR CONSTANTS

SUPER-ENERGY SAVING VARIABLE SPEED DRIVE (VS-686SS5)

MODEL: CIMR-SSA [ ]

200V CLASS 0.4 to 75kW (1.2 to 110kVA)

400V CLASS 0.4 to 300kW (1.4 to 460kVA)

---

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

---

## REFERENCE

VARISPEED-686SS5 INSTRUCTION MANUAL (TOE-S686-15)





# CONTENTS

1.	OPERATION MODE SELECTION .....	2
1.1	CONTROL METHOD SETTING .....	2
1.2	FEATURES OF TWO CONTROL METHODS .....	4
1.3	CONTROL METHOD CHANGING PROCEDURE .....	5
1.4	INITIALIZE MODE .....	6
1.4.1	CONSTANT ACCESS LEVEL .....	6
1.4.2	CONSTANT INITIALIZATION .....	8
2.	CONSTANT LIST .....	9
2.1	CONSTANT ARRAY OF DIGITAL OPERATOR (JVOP-132) DISPLAY FUNCTIONS .....	9
2.2	VS-686SS5 CONSTANT LIST .....	10
2.3	MONITOR CONSTANT LIST .....	23
2.4	MULTI-FUNCTION I/O TERMINAL SETTING LIST .....	27
2.5	CONSTANTS THAT CAN BE CHANGED BY SETTING CONTROL METHOD (A1-02) .....	28
2.6	CONSTANTS THAT CAN BE CHANGED BY SETTING INVERTER CAPACITY (o2-04) .....	29
2.7	CONSTANTS THAT CAN BE CHANGED BY SETTING MOTOR CAPACITY SELECTION (VARIABLE TORQUE) .....	30
2.8	CONSTANTS THAT CAN BE CHANGED BY SETTING MOTOR CAPACITY SELECTION (CONSTANT TORQUE) .....	33
3.	CONSTANT DESCRIPTION .....	38
b	APPLICATION-RELATED CONSTANTS .....	38
C	CONSTANTS FOR ADJUSTMENT .....	44
d	SPEED REFERENCE-RELATED CONSTANTS .....	48
E	MOTOR-RELATED CONSTANTS .....	53
F	OPTION-RELATED CONSTANTS .....	54
H	CONTROL CIRCUIT TERMINAL-RELATED CONSTANTS .....	59
L	PROTECTION-RELATED CONSTANTS .....	72
o	DIGITAL OPERATOR-RELATED CONSTANTS .....	79
T	AUTO-TUNING CONSTANTS .....	82

# 1 OPERATION MODE SELECTION

## 1.1 CONTROL METHOD SETTING

When setting up the VS-686SS5, make sure to follow the procedures below. Mistakes in setup order may cause values to be written over resulting in poor operation.

STEP 1 Control method selection (Page 40 of the INSTRUCTION MANUAL)


STEP 2 Constant torque/variable torque motor setting (Pages 41 to 43 of the INSTRUCTION MANUAL)

STEP 3 Motor capacity selection (Pages 41 to 43 of the INSTRUCTION MANUAL)

STEP 4 Nameplate value setting (Pages 41 to 43 of the INSTRUCTION MANUAL)

The VS-686SS5 is equipped with two current vector control methods (with or without PG). Either method can be easily selected by using the digital operator to meet user application needs. Open loop vector control is set at the factory prior to shipment. In the following cases, observe the following procedures to set and verify the control method and motor related constants.

- When conducting initial operation of the VS-686SS5.
- When replacing either motor or inverter
- When replacing PG



## 1.2 FEATURES OF TWO CONTROL METHODS

Table 1 shows the features of open loop vector control and flux vector control.

**Table 1 Features of Two Control Methods**

Control Method	Open Loop Vector	Flux Vector
Basic control	Current vector control without PG	Current vector control with PG
Speed detector	Not needed	Needed (pulse generator)
Speed detection option	Not needed	PG-X2
Speed control range	1 10	1 500
Starting torque	50%/0 Hz	150%/0Hz
Speed control accuracy	± 0.2%	± 0.02%
Torque accuracy	± 10%	± 5%
Torque limit	Possible	Possible
Torque control	Not possible	Possible
Momentary overcurrent	Higher than approx 200% of inverter rated output current	Higher than approx 200% of inverter rated output current
Motor protection	Protection by electronics overload thermal relay	Protection by electronics overload thermal relay
Momentary power loss ride-through	Possible	Possible
Stall prevention	Overvoltage prevention	Overvoltage prevention
Application	Fans, blowers (Root variable torque characteristics)	General variable speed (constant torque characteristics)

### 1.3 CONTROL METHOD CHANGING PROCEDURE

The following procedure shows how to select or change the control method.

Step	Description	Key Sequence	Digital Operator Display
①	Power ON • Displays speed reference value		 REMOTE LEDs (SEQ,REF) ON
②	Control method selection • Move to program mode		
③	• Move to control method selection (A1-02)		
④	• Verify the set value		 (Initial setting: open loop vector)
⑤	• Change to flux vector		
⑥	• Write-in the value		 Displays for 0.5 seconds.  Setting completed.
⑦	Return to drive mode		

## 1.4 INITIALIZE MODE

As described below, the access level to set/read constants and control method can be selected. Set initialize mode constants before use of the VS-686SS5.

The following table shows the constants for initialize mode.

Constant No	Name	Description
A1-01	Access level (change enable during run)	0 Exclusive for monitoring A1-01 can be set/read and U constants in QUICK-START level can be read 2 QUICK-START Constants required for quick-start operation can be set/read 3 BASIC Constants required for basic operation can be set/read 4 ADVANCED Constants required for advanced operation can be set/read
A1-02	Control method	5 Open loop vector 6 Flux vector
A1-03	Initialize	Constant initialization 2220 2-wire sequence (Returns to the value set at the factory prior to shipment) 3330 3-wire sequence
A1-04	Password (for input)	For future use (Do not set because of special function)

### 1.4.1 CONSTANT ACCESS LEVEL

Constants to be set/read by digital operator can be selected by setting constant A1-01 as shown below. A1-01=2 (QUICK-START) is preset at the factory.

A1-01	Name	Description
0	Exclusive for monitoring	Operation mode and initialize mode are enabled Constants cannot be set/read by digital operator in programming mode or modified constants mode
2	QUICK-START	Constants required for quick-start operation are set/read For details, refer to the VS-686SS5 access level list in Table 2
3	BASIC	Basic constants are set/read For details, refer to the VS-686SS5 access level list in Table 2
4	ADVANCED	Advanced constants are set/read For details, refer to the VS-686SS5 access level list in Table 2



**Table 2 VS-686SS5 Access Level List**

Group No	Group	Function No.	Function Name	Access Level		
				Q	B	A
b	Application	b1	Operation mode selection	○	○	○
		b2	Zero-speed level	○	○	
		b3	Initial magnetic pole pull-in			○
		b4	Timer function			○
		b5	PID control			○
		b6	DWELL function			○
		b7	DROOP function			○
C	Tuning	C1	Accel/decel time	○	○	○
		C2	Phase compensation			○
		C3	Energy-saving control selection			○
		C5	ASR		○	○
		C6	Carrier frequency			○
d	Reference	d1	Speed reference value	○	○	○
		d2	Limits		○	○
		d3	Jump speed		○	○
		d4	Sequence			○
		d5	Torque reference			○
E	Motor	E1	Motor constants	○	○	○
F	Options	F1	PG speed control card	○	○	○
		F2	Analog reference card		○	○
		F3	Digital input card		○	○
		F4	Analog output card		○	○
		F5	Digital output card		○	○
		F6	Digital output card		○	○
H	Control circuit terminal function	H1	Sequence input		○	○
		H2	Sequence output		○	○
		H3	Analog input		○	○
		H4	Analog output		○	○
L	Protection	L1	Motor protection		○	○
		L2	Momentary power loss ride-through			○
		L3	Overvoltage prevention		○	○
		L4	Speed detection			○
		L5	Fault retry		○	○
		L6	Overtorque detection		○	○
		L7	Torque limit		○	○
		L8	Hardware protection			○
		L9	Step-out protection			○
o	Operator	o1	Selection of display		○	○
		o2	Operation (key function)			○
T	Auto-tuning	T1	Auto-tuning	○	○	○

Following letters indicate each access level

Q: QUICK-START (A1-01=2) B: BASIC (A1-01=3) A: ADVANCED (A1-01=4)

## 1.4.2 CONSTANT INITIALIZATION
















To return the inverter constants to the factory setting or to replace the control circuit boards, initialize the constants after control method selection (A1-02) and kVA selection (o2-04).

All the constants are returned to initial setting by initialization. Several constants such as motor constants cannot be initialized. For details, refer to 2.2 CONSTANT LIST.

The contents of initialization differ as shown below, depending on the set values.


A1-01	Name	Description
2220	2-wire initialize	Terminal 1 becomes FWD run command and terminal 2 becomes REV run command.
3330	3-wire initialize	Terminal 1 becomes run command, terminal 2 becomes stop command and terminal 3 becomes FWD/REV run selection

The following shows an example of constant initialization.

Step	Description	Key Sequence	Digital Operator Display	Remarks
	Displaying speed reference			
①	Move to program mode		Constant No. display	Displays the constant No selected formerly
②	Select A1-03			
③	Display the set value			
④	Input 2220			
⑤	Write-in-the value		 	Displays for 0.5 seconds Displays return to 0
⑥	Return to constant No display			
⑦	Return to drive mode			Speed reference return to 0

## 2 CONSTANT LIST

### 2.1 CONSTANTS ARRAY OF DIGITAL OPERATOR (JVOP-132) DISPLAY FUNCTIONS



\*1: Constant Access Level  
Setting or reading possible when Q: QUICK-START (A1-01=2), B: BASIC (A1-01=3) or A: ADVANCED (A1-01=4).

\*2: Verified Constants  
Verified Constants can be read in the operation mode.  
The mode can be changed by pressing the RESET key and DRIVE/PRGM key of operator JVOP-132 at the same time.

## 2.2 VS-686SS5 CONSTANT LIST (1)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Initialize	Initialize	A1-01	Constant access level	0 to 4	1	2	0 Exclusive for monitor 2 Quick-start( Q) 3 Basic (B) 4 Advanced (A) (Refer to page 6)	○	Q	Q
		A1-02	Control method selection	5, 6	1	5	5 Open loop vector 6 Flux vector (Refer to page 4)	×	Q	Q
		A1-03	Initialize	0000 to 9999	1	0000	2220 2-wire Initialize 3330 3-wire Initialize (Refer to page 8)	×	Q	Q
		A1-04	Password 1 (for input)	0000 to 9999	1	0000	(Refer to page 6)	×	Q	Q
Application	Sequence	b1-01	Speed reference selection	0 to 3	1	1	0 Digital operator 1. Control circuit terminal 2. — 3. Option card (CP-916B/G, 216I/F) 4. Personal computer (CP-717) (Refer to page 38)	×	Q	Q
		b1-02	Operation method selection	0 to 3	1	1	0 Digital operator 1. Control circuit terminal 2. — 3. Option card (CP-916B/G, 216I/F) 4. Personal computer (CP-717) (Refer to page 38)	×	Q	Q
		b1-03	Stopping method selection	0 to 3	1	0	0 Ramp to stop 1: Coast to a stop 2. — 3 Coast to a stop with timer (Refer to page 38)	×	Q	Q
		b1-04	Prohibition of reverse operation	0, 1	1	0	0. Reverse enabled 1: Reverse disabled (Refer to page 39)	×	B	B
		b1-05	Operation selection for setting of E1-08 or less	0 to 3 *1	1	1	* Factory setting differs depending on the control method (A1-02) (Refer to pages 28 and 39.)	×	A	A
		b1-06	Operation selection after switching to remote mode	0, 1	1	0	0 Does not operate even if run command is ON when switching LOCAL to REMOTE 1: Operates if run command is ON when switching LOCAL to REMOTE	×	A	A
	Zero-speed Level	b2-01	Zero speed level	0 00 to 10 00	0 01%	1.00*	* Changing the control method (A1-02) changes the set value automatically (Refer to pages 28 and 40)	×	B	B

\*1 Setting range is only 1 and 2 when the control method is set to flux vector control

## CONSTANT LIST (2)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○: Enabled x: Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Application	Initial Magnetic Pole Lead-in	b3-02	Magnetic-pole lead-in current	0 to 150	1%	80	(Refer to page 40.)	x	A	A
		b3-04	Current rising time start	0.0 to 5.0	0.1sec	0.2	(Refer to page 40.)	x	A	A
		b3-05	Magnetic-pole lead-in time	0.0 to 5.0	0.1sec	0.0	(Refer to page 40.)	x	A	A
	Delay Timers	b4-01	Timer function ON-delay time (Delay-ON Timer)	0.0 to 300.0	0.1sec	0.0	(Refer to page 41.)	x	A	A
		b4-02	Timer function OFF-delay time (Delay-OFF Timer)	0.0 to 300.0	0.1sec	0.0	(Refer to page 41.)	x	A	A
	PID Control	b5-01	PID control mode selection	0, 1, 2	1	0	0: Disabled 1: Enabled 2: Enabled (D=Feed-Forward) (Refer to page 41.)	x	A	A
		b5-02	Proportional gain (P)	0.00 to 25.00	0.01	1.00	(Refer to page 42.)	○	A	A
		b5-03	Integral time (I)	0.0 to 360.0	0.1sec	1.0	(Refer to page 42.)	○	A	A
		b5-04	Integral limit	0.0 to 100.0	0.1%	100.0	(Refer to page 42.)	○	A	A
		b5-05	Differential time (D)	0.00 to 10.00	0.01sec	0.00	(Refer to page 42.)	○	A	A
		b5-06	PID limit	0.0 to 100.0	0.1%	100.0	(Refer to page 42.)	○	A	A
		b5-07	PID offset adjustment	-100.0 to 100.0	0.1%	0.0	(Refer to page 42.)	○	A	A
		b5-08	PID primary delay time constant	0.00 to 10.00	0.01sec	0.00	(Refer to page 42.)	○	A	A
	DWEELL Function	b6-01	Dwell speed at start	0.00 to 100.00	0.01%	0.00	Setting unit differs depending on o1-03 setting	x	A	A
		b6-02	Dwell time at start	0.0 to 10.0	0.1sec	0.0	(Refer to page 43.)	x	A	A
		b6-03	Dwell speed at stop	0.00 to 100.00	0.01%	0.00	Setting unit differs depending on o1-03 setting.	x	A	A
		b6-04	Dwell time at stop	0.0 to 10.0	0.1sec	0.0	(Refer to page 43.)	x	A	A
	Droop Function	b7-01	Droop value	0.0 to 100.0	0.01%	0.0	(Refer to page 43.)	○	—	A
		b7-02	Droop delay time	0.00 to 1.00	0.01sec	0.10	(Refer to page 43.)	○	—	A

### CONSTANT LIST (3)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled x Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Tuning	Accel / Decel	C1-01	Acceleration time 1	0 00 to 600 00 (at C1-10=1) 0 0 to 6000 0 (at C1-10=0)	0 1 sec or 0 01 sec	10 0	(Refer to page 44.)	○	Q	Q
		C1-02	Deceleration time 1			10 0	(Refer to page 44.)	○	Q	Q
		C1-03	Acceleration time 2			10 0	(Refer to page 44 )	○	B	B
		C1-04	Deceleration time 2			10 0	(Refer to page 44.)	○	B	B
		C1-05	Acceleration time 3			10 0	(Refer to page 44 )	x	A	A
		C1-06	Deceleration time 3			10.0	(Refer to page 44.)	x	A	A
		C1-07	Acceleration time 4			10.0	(Refer to page 44.)	x	A	A
		C1-08	Deceleration time 4			10 0	(Refer to page 44 )	x	A	A
		C1-09	Emergency stop time			10 0	(Refer to page 44.)	x	B	B
		C1-10	Accel / decel time setting unit	0, 1	1	1	0 0 01 seconds 1. 0.1 seconds (Refer to page 44.)	x	A	A
	C1-11	Accel / decel time switching speed	0 00 to 100 00	0 01%	0 00	(Refer to page 44 )	x	A	A	
	Phase Compensation	C2-12	Leading phase compensation amount	-180 to +180.0	0 1 deg	-5 6	Not initialized by Initialize. (Refer to page 45 )	x	Q	-
		C2-13	PG zero-pulse compensation amount	-180 to +180 0	0 1 deg	0.0	Not initialized by Initialize. (Refer to page 45 )	x	-	A
	Energy-saving Control Selection	C3-01	Energy-saving control selection	0, 1	1	1	0 Disabled 1 Enabled (Refer to page 45.)	x	A	A
		C3-05	Voltage limit control selection	0, 1	1	1	0 Disabled 1. Enabled (Refer to page 45.)	x	A	A
	ASR	C5-01	ASR proportional (P) gain 1	0 00 to 300 00	0 01	15 00*	* Changing the control method (A1-02) changes the set value automatically. (Refer to pages 28, 45 and 46 )	○	B	B
		C5-02	ASR integral (I) time 1	0 000 to 10.000	0.001 sec	0.500	(Refer to pages 45 and 46 )	○	B	B
		C5-03	ASR proportional (P) gain 2	0 00 to 300 00	0 01	15 00*	* Changing the control method (A1-02) changes the set value automatically (Refer to pages 28, 45 and 46 )	○	B	B
		C5-04	ASR integral (I) time 2	0 000 to 10.000	0 001 sec	0.500	(Refer to pages 45 and 46.)	○	B	B
		C5-05	ASR primary delay time	0.000 to 0 500	0.001 sec	0.004	(Refer to pages 45 and 46.)	○	A	A
		C5-06	ASR switching speed	0 00 to 100 00	0.01%	0.00	(Refer to pages 45 and 46.)	x	A	A
C5-07		ASR Proportional (P) gain at start	0 00 to 300 00	0 01	20.00	(Refer to pages 45 and 46 )	x	A	A	

## CONSTANT LIST (4)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (O. Enabled x. Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Tuning	Carrier Frequency	C6-02	Carrier frequency selection	2, 4, 8, 12	2 kHz	2 **	Input effective value (Refer to page 47)	x	A	A
		C6-07	$\gamma$ -axis voltage offset	-100 0 to +100 0	0 1%	-1.0	Not initialized (Refer to page 47.)	x	A	A
		C6-11	Adaptive control selection	0, 1	1	0	0: Disabled 1. Enabled (Refer to page 47)	x	A	A
		C6-12	Adaptive control compensation gain	0 70 to 1.30	0 01	0.95 **	** Factory setting differs depending on kVA capacity (o2-04) (Refer to pages 29 and 47)	x	A	A
Reference	Preset Reference	d1-01	Speed reference 1	0.00 to 100.00	0.01%	0 00	Changing o1-03 setting changes the setting unit automatically. (Refer to page 48)	O	Q	Q
		d1-02	Speed reference 2	0 00 to 100 00	0 01%	0 00	Changing o1-03 setting changes the setting unit automatically (Refer to page 48)	O	Q	Q
		d1-03	Speed reference 3	0 00 to 100 00	0 01%	0.00	Changing o1-03 setting changes the setting unit automatically. (Refer to page 48)	O	Q	Q
		d1-04	Speed reference 4	0 00 to 100.00	0 01%	0.00	Changing o1-03 setting changes the setting unit automatically (Refer to page 48)	O	Q	Q
		d1-05	Speed reference 5	0 00 to 100 00	0 01%	0 00	Changing o1-03 setting changes the setting unit automatically. (Refer to page 48)	O	B	B
		d1-06	Speed reference 6	0.00 to 100.00	0 01%	0 00	Changing o1-03 setting changes the setting unit automatically. (Refer to page 48.)	O	B	B
		d1-07	Speed reference 7	0 00 to 100.00	0 01%	0 00	Changing o1-03 setting changes the setting unit automatically (Refer to page 48)	O	B	B
		d1-08	Speed reference 8	0.00 to 100 00	0.01%	0 00	Changing o1-03 setting changes the setting unit automatically. (Refer to page 48)	O	B	B
		d1-09	Jog speed reference	0 00 to 100.00	0.01%	10 00	Changing o1-03 setting changes the setting unit automatically (Refer to page 48)	O	Q	Q
	Reference Limit	d2-01	Speed reference upper limit	0.0 to 110.0	0 1%	100.0	(Refer to page 49)	x	B	B
		d2-02	Speed reference lower limit	0 0 to 100 0	0.1%	0 0	(Refer to page 49)	x	B	B

# CONSTANT LIST (5)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Reference	Jump Speed	d3-01	Jump speed 1	0 0 to 100 0	0 1%	0.0	(Refer to page 49 )	×	B	B
		d3-02	Jump speed 2	0.0 to 100.0	0 1%	0 0	(Refer to page 49.)	×	B	B
		d3-03	Jump speed 3	0.0 to 100 0	0 1%	0 0	(Refer to page 49 )	×	B	B
		d3-04	Jump speed width	0 0 to 100.0	0 1%	1 0	(Refer to page 49 )	×	B	B
	Sequence	d4-01	Speed reference hold function selection	0, 1	1	0	0: Disabled 1: Enabled (Refer to pages 49, 51 and 52 )	×	A	A
	Torque Control	d5-01	Torque control selection	0, 1	1	0	0: Speed control 1: Torque control (Refer to pages 49, 51 and 52 )	—	—	A
		d5-02	Torque reference delay time	0 to 1000	1 msec	0	(Refer to pages 49, 51 and 52 )	—	—	A
		d5-03	Speed limit selection	1, 2	1	1	1. Speed reference value set by b1-01 2. d5-04 set value (Refer to pages 50, 51 and 52 )	—	—	A
		d5-04	Speed limit	-120 to +120	1%	0	(Refer to pages 50, 51 and 52 )	—	—	A
		d5-05	Speed limit bias	0 to 120	1%	10	(Refer to pages 50, 51 and 52 )	—	—	A
		d5-06	Speed/torque control switching timer	0 to 1000	1 msec	0	(Refer to pages 50, 51 and 52 )	—	—	A
	Motor	E1-01	Input voltage setting	18 to 230	1 V	200	For 400V class, the value is twice as that of 200V class. Not initialized by initialize (Refer to page 53 )	×	Q	Q
		E1-02	Motor capacity selection	000 to 2FF	—	****	0xx Rated 1750 (r/min) 1xx Rated 1450 (r/min) 2xx Not initialized at rated 1150 (r/min) **** Factory setting differs depending on inverter capacity selection (o2-04) and the value of rated 1750 (r/min)	×	Q	Q
E1-03		Motor rated voltage	0 0 to 255 0	0 1 V	***	For 400 V class, the value is twice that of 200 V class. *** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53 ) Not initialized by initialize	×	A	A	
E1-04		Motor rated current	0 0 to 200.0*	0 1 A	***	Least setting unit 0 01 for 7 5 kW or less. *** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53 ) Not initialized by initialize	×	Q	Q	
E1-05		Number of motor poles	2, 4, 6, 8 poles	2 poles	6	Four types 2, 4, 6 and 8 Not initialized by initialize. (Refer to pages 30 to 37 and 53 )	×	A	A	

\*: Set value for 200 V class For 400V class, the value is twice as that of 200 V class



# CONSTANT LIST (6)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level	
								Open Loop Vector	Flux Vector
Motor	E1-06	Motor max r/min	0 to 1.5 × (E1-07)	1 r/min	***	*** Factory setting differs depending on motor selection (E1-02). (Refer to pages 30 to 37 and 53.) Not initialized by initialize	×	A	A
	E1-07	Motor base r/min	1000 to 3600	1 r/min	***	*** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53 ) Not initialized by initialize	×	A	A
	E1-08	Motor min. r/min	0 to 3600	1 r/min	*	Initial value without PG: 175 r/min Initial value with PG 30 r/min * Factory setting differs depending on control method selection (A1-02). (Refer to pages 28 and 53 ) Not initialized by initialize	×	A	A
	E1-09	Motor armature resistance	0 000 to 65 000	0 001 Ω	***	Resistance value for armature winding one phase *** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53 ) Not initialized initialize	×	Q	Q
	E1-10	Motor d-axis inductance	0.00 to 300 00	0 01 mH	***	*** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53 ) Not initialized by initialize	×	Q	Q
	E1-11	Motor q-axis inductance	0 00 to 600 00	0 01 mH	***	*** Factory setting differs depending on motor selection (E1-02). (Refer to pages 30 to 37 and 53.) Not initialized by initialize	×	Q	Q
	E1-13	Induced voltage	100 0 to 2000 0	0 1 mV·sec/rad	***	Phase voltage wave height value (electrical angle). *** Factory setting differs depending on motor selection (E1-02) (Refer to pages 30 to 37 and 53.) Not initialized by initialize	×	Q	Q
	E1-14	Variable torque/constant torque selection	0, 1	1	0	0. Motor for variable torque 1. Motor for constant torque Not initialized by initialize (Refer to page 53.)	×	A	A
	E1-15	Motor mechanical loss	0 0 to 10.0	0 1%	0.0	Not initialized (Refer to page 53 )	×	A	A
	E1-16	Motor wiring resistance	0.0 to 10.0	0.1%	1.0	Not initialized by initialize (Refer to page 53 )	×	A	A

# CONSTANT LIST (7)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○: Enabled x: Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Options	PG Option Setup	F1-01	PG constants	0 to 10000	1	1024	(Refer to page 54.)	x	—	Q
		F1-02	Operation selection at PG open-circuit (PGO) detection	0 to 3	1	1	0 Ramp to stop 1 Coast to stop 2 Fast-stop 3 Continues operation (Refer to pages 54 and 55)	x	—	B
		F1-03	Operation selection at overspeed (OS) detection	0 to 3	1	1	0 Ramp to stop 1 Coast to stop 2 Fast-stop 3 Continues operation (Refer to page 54.)	x	B	B
		F1-04	Operation selection at deviation (DEV) detection	0 to 3	1	3	0 Ramp to stop 1 Coast to stop 2 Fast-stop 3 Continues operation (Refer to pages 54 and 55.)	x	B	B
		F1-05	PG rotation detection	0, 1	1	1*	0 Motor forward run with phase A leading 1 Motor reverse run with phase A leading (Refer to page 54.)	x	—	B
		F1-08	Overspeed (OS) detection level	0 to 120	1%	115	(Refer to page 55.)	x	A	A
		F1-09	Overspeed (OS) detection delay time	0 0 to 2 0	0.1 sec	0 0	(Refer to page 55.)	x	A	A
		F1-10	Speed deviation (DEV) detection level	0 to 50	1%	10	(Refer to page 55.)	x	A	A
		F1-11	Speed deviation (DEV) delay time	0 0 to 10 0	0.1 sec	0 5	(Refer to page 55)	x	A	A
		F1-13	PG open-circuit (PGO) detection delay time	0 0 to 10.0	0.1 sec	3 0	(Refer to page 55)	x	—	A
	Analog Reference Card	F2-01	AI-14B input function selection	0, 1	1	0	0 3-channel individual 1 3-channel addition (Refer to page 56)	x	B	B
	Digital Input Card	F3-01	DI-08, DI-16H2 speed reference setting selection	0 to 7	1	0	0 BCD 1% 1 BCD 0.1% 2 BCD 0.01% 7 Binary (Displays set value in decimal) (Refer to page 56)	x	B	B
	Analog Output Card	F4-01	AO-08, 12CH1 output item selection	0 to 60	1	5	(Refer to page 56)	○	B	B
		F4-02	AO-08, 12CH1 output gain	-300 0 to +300 0	0.1	1 0	(Refer to page 56)	○	B	B
		F4-03	AO-08, 12CH1 output bias	-109 2 to +109 2	0.1%	0 0	(Refer to page 56)	○	B	B
		F4-04	AO-08, 12CH2 output item selection	0 to 60	1	3	(Refer to page 56)	○	B	B
		F4-05	AO-08, 12CH2 output gain	-300 0 to +300 0	0.1	1.0	(Refer to page 56)	○	B	B
		F4-06	AO-08, 12CH2 output bias	-109 2 to +109 2	0.1%	0 0	(Refer to page 56)	○	B	B

\* The initial value is "0" with the software numbers (at flash side) (U1-14) up to 1031: it is "1" with those after 1031.

## CONSTANT LIST (8)

Function	Constant No.	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Options	Digital Output Card	F5-01	DO-02 CH1 output selection	00 to FFH	—	0	Refer to H2-xx for setting. (Refer to page 55.)	×	B	B
		F5-02	DO-02 CH2 output selection	00 to FFH	—	1	Refer to H2-xx for setting. (Refer to page 55.)	×	B	B
		F6-01	DO-08 output mode selection	0 to 2	1	0	0: 8-channel individual output 1: Code output 2: General-purpose individual output (Refer to page 57)	×	B	B
	Transmission Option Card	F9-01	Input level of external fault from transmission option	0, 1	1	0	(Refer to page 58.)	×	B	B
		F9-02	External fault from transmission option	0, 1	1	0	(Refer to page 58.)	×	B	B
		F9-03	Operation at external fault input from transmission option	0 to 3	1	1	(Refer to page 58.)	×	B	B
		F9-04	Trace sampling cycle of transmission option	0 to 6000	1	0	(Refer to page 58.)	×	B	B
		F9-05	Torque reference selection of transmission option	0, 1	1	1	(Refer to page 58.)	×	B	B
		F9-06	Operation selection at BUS error detection	0 to 3	1	1	(Refer to page 58.)	×	B	B

# CONSTANT LIST (9)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Terminal	Sequence Inputs	H1-01	Multi-function input (terminal 3-11)	00 to FFH		24	(Refer to pages 59 to 64 )	×	B	B
		H1-02	Multi-function input (terminal 4-11)	00 to FFH		14	(Refer to pages 59 to 64.)	×	B	B
		H1-03	Multi-function input (terminal 5-11)	00 to FFH		3 (0) *1	(Refer to pages 59 to 64 )	×	B	B
		H1-04	Multi-function input (terminal 6-11)	00 to FFH		4 (3) *1	(Refer to pages 59 to 64.)	×	B	B
		H1-05	Multi-function input (terminal 7-11)	00 to FFH		6 (4) *1	(Refer to pages 59 to 64.)	×	B	B
		H1-06	Multi-function input (terminal 8-11)	00 to FFH		8 (6) *1	(Refer to pages 59 to 64.)	×	B	B
	Sequence Outputs	H2-01	Multi-function output (terminal 9-10)	00 to FFH		0	(Refer to pages 65 to 68 )	×	B	B
		H2-02	Multi-function output (terminal 25-27)	00 to FFH		1	(Refer to pages 65 to 68 )	×	B	B
		H2-03	Multi-function output (terminal 26-27)	00 to FFH		2	(Refer to pages 65 to 68 )	×	B	B
	Analog Inputs	H3-01	Signal level selection (terminal 13)	0, 1	1	0	0: 0 to 10 VDC 1: -10 to +10 VDC (Refer to page 69 )	×	B	B
		H3-02	Gain (terminal 13)	0 0 to 1000 0	0 1%	100 0	(Refer to page 69 )	○	B	B
		H3-03	Bias (terminal 13)	-100 0 to +100 0	0 1%	0 0	(Refer to page 69 )	○	B	B
		H3-04	Signal level selection (terminal 16)	0,1	1	0	0 0 to 10 VDC 1: -10 to +10 VDC (Refer to pages 69 to 71 )	×	B	B
		H3-05	Multi-function analog input (terminal 16)	0 to 1F	—	00	(Refer to pages 70 to 71 )	×	B	B
		H3-06	Gain (terminal 16)	0 0 to 1000.0	0 1%	100.0	(Refer to pages 70 to 71 )	○	B	B
		H3-07	Bias (terminal 16)	-100 0 to +100 0	0 1%	0 0	(Refer to pages 70 to 71 )	○	B	B
		H3-08	Signal level selection (terminal 14)	0, 1, 2	1	2	0 0 to 10 VDC 1: -10 to +10 VDC 2: 4 to 20 mA (Refer to pages 69 to 71 )	×	A	A
		H3-09	Multi-function analog input (terminal 14)	00 to 1F	—	1F	(Refer to pages 69 to 71 )	×	A	A
		H3-10	Gain (terminal 14)	0 0 to 1000 0	0 1%	100 0	(Refer to pages 69 to 71.)	○	A	A
		H3-11	Bias (terminal 14)	-100 0 to +100 0	0 1%	0 0	(Refer to pages 69 to 71 )	○	A	A
		H3-12	Analog input filter time constant	0 00 to 2 00	0 01 sec	0 00	(Refer to pages 69 to 71 )	×	A	A
Analog Outputs	H4-01	Monitor selection (Multi-function AO) (terminal 21-22)	0 to 60	1	5	(Refer to page 71 )	○	B	B	
	H4-02	Gain (terminal 21-22)	-300 0 to +300 0	0 1	1.0	(Refer to page 71.)	○	B	B	
	H4-03	Bias (terminal 21-22)	-109.2 to +109.2	0 1%	0.0	(Refer to page 71.)	○	B	B	

\*1 Factory settings in the parentheses are values obtained at 3-wire initialization.

# CONSTANT LIST (10)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled x: Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Terminal	Analog Outputs	H4-04	Monitor selection (terminal 23-22)	0 to 60	1	3	(Refer to page 71.)	○	B	B
		H4-05	Gain (terminal 23-22)	-300 0 to +300 0	0.1	1.0	(Refer to page 71.)	○	B	B
		H4-06	Bias (terminal 23-22)	-109 2 to +109 2	0.1 %	0 0	(Refer to page 71.)	○	B	B
		H4-07	Analog output signal level selection (Multifunction AO)	0, 1	1	1	AO-12 signal characteristics used in common. 0 without sign 1 with sign (Refer to page 71)	○	B	B
Protection	Motor Protection	L1-01	Motor protection selection	0, 1	1	1	0 Disabled 1: Enabled (Refer to page 72)	x	B	B
		L1-02	Motor protection time	0.1 to 300 0	0.1 sec	60 0	(Refer to page 72)	x	B	B
	Power Loss Rid	L2-01	Momentary power loss detection	0, 1	1	0	0: Disabled 1: Power loss ride (Refer to page 72)	x	B	B
		L2-02	Momentary power loss ridethru time	0 0 to 2 0	0.1 sec	**	** Factory setting differs depending on inverter capacity. (Refer to pages 23, 24 and 72)	x	B	B
		L2-03	Deceleration time at momentary power loss	0.1 to 100 0	0.1 sec	30 0	(Refer to page 73.)	x	B	B
		L2-05	Undervoltage detection level	150 to 210	1 V	190	Set value for 200V class For 400V class, the value is twice as that of 200V class (Refer to page 73)	○	A	A
	Over Voltage Prevention	L3-01	Overvoltage prevention selection	0, 1	1	1	0: Disabled 1 Enabled (Refer to page 73)	x	B	B

# CONSTANT LIST (11)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled x . Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Protection	Speed Detection	L4-01	Speed detection level	0 0 to 100 0	0 1%	0.0	(Refer to pages 73 and 74.)	x	B	B
		L4-02	Speed detection width	0 0 to 100 0	0 1%	2.0	(Refer to pages 73 and 74 )	x	B	B
		L4-03	Speed detection level (+/-)	0 0 to ±100 0	0 1%	0.0	(Refer to pages 73 and 74.)	x	A	A
		L4-04	Speed detection width(+/-)	0.0 to 100 0	0 1%	2 0	(Refer to pages 73 and 74 )	x	A	A
		L4-05	Operation when speed reference is missing	0, 1	1	0	0 Disabled 1: Enabled (Refer to page 75.)	x	A	A
	Fault Restart	L5-01	Number of auto restart attempts	0 to 10	1 time	0	(Refer to page 76 )	x	—	B
		L5-02	Auto restart operation selection	0, 1	-1	0	0: Disabled 1: Enabled (Refer to page 76 )	x	—	B
	Torque Detection	L6-01	Torque detection selection 1	0 to 4	1	0	0 Disabled 1 Detected during speed agree, and operation continues after detection 2: Detected during running, and operation continues after detection 3: Detected during speed agree, and inverter output is shut OFF 4. Detected during running, and inverter output is shut OFF (Refer to page 76 )	x	B	B
		L6-02	Torque detection level 1	0 to 300	1%	150	(Refer to page 76 )	x	B	B
		L6-03	Torque detection time 1	0 0 to 10 0	0 1 sec	0 1	(Refer to page 76.)	x	B	B
		L6-04	Torque detection selection 2	0 to 4	1	0	0. Disabled 1: Detected during speed agree, and operation continues after detection 2: Detected during running, and operation continues after detection 3: Detected during speed agree, and inverter output is shut OFF 4: Detected during running, and inverter output is shut OFF (Refer to page 76.)	x	A	A
		L6-05	Torque detection level 2	0 to 300	1%	150	(Refer to page 76 )	x	A	A
		L6-06	Torque detection time 2	0.0 to 10 0	0 1 sec	0 1	(Refer to page 76 )	x	A	A

## CONSTANT LIST (12)

Function	Constant No	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (O: Enabled x: Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Protection	Torque Limit	L7-01	Forward torque limit	0 to 300	1%	160	(Refer to pages 76 and 77.)	x	B	B
		L7-02	Reverse torque limit	0 to 300	1%	160	(Refer to pages 76 and 77.)	x	B	B
		L7-03	Forward regenerative torque limit	0 to 300	1%	160	(Refer to pages 76 and 77.)	x	B	B
		L7-04	Reverse regenerative torque limit	0 to 300	1%	160	(Refer to pages 76 and 77.)	x	B	B
	Hardware Protection	L8-01	Protect selection for internal DB resistor	0, 1	1	0	0 Disabled 1 Enabled (Refer to page 77.)	x	B	B
		L8-02	Inverter pre-alarm level	50 to 110	1 deg	95		x	A	A
Protection	Hardware Protection	L8-03	Operation selection after OH pre-alarm	0 to 3	1	3	0: Ramp to stop 1: Coast to stop 2: Fast-stop 3: Alarm only (Refer to page 77.)	x	A	A
		L8-05	Input open-phase protection selection	0, 1	1	0	0: Disabled 1 Enabled (Refer to page 78.)	x	A	A
		L8-07	Output open-phase protection selection	0, 1	1	0	0: Disabled 1. Enabled (Refer to page 78.)	x	A	A
		L8-10	Ground fault protection selection	0, 1	1	1	0: Disabled 1. Enabled (Refer to page 78.)	x	A	A
	Step-Out Protection	L9-01	Step-out Protection selection	0, 1	1	1	0 Disabled 1: Enabled (Refer to page 78.)	x	A	-




# CONSTANT LIST (13)

Function	Constant No.	Name	Setting Range	Setting Unit	Factory Setting	Remarks	Change During Operation (○ Enabled × Disabled)	Constant Access Level		
								Open Loop Vector	Flux Vector	
Operator	Monitor Select	o1-01	Monitor selection	4 to 54	1	6	(Refer to page 79 )	×	B	B
		o1-02	Monitor selection after power up	1 to 4	1	1	1: Speed reference 2: Motor speed (U1-05 or equivalent) 3 Output current 4 Monitor selected by o1-01 (Refer to page 79 )	×	B	B
		o1-03	Speed units of reference setting and monitor	0 to 39999	1	0	(Refer to page 79.)	×	B	B
	Key Select	o2-01	LOCAL/REMOTE key enable/disable	0, 1	1	1	0 Disabled 1: Enabled	×	B	B
		o2-02	STOP key during control circuit terminal operation	0, 1	1	0	0 Disabled 1: Enabled	×	B	B
		o2-04	kVA selection	0 to FF	1	*	* Not initialized Factory setting differs depending on the inverter capacity (Refer to pages 29 and 80.)	×	B	B
		o2-05	Speed reference setting method selection	0, 1	1	0	0 Disabled 1 Enabled (Refer to page 80 )	×	A	A
		o2-06	Operation selection when digital operator is disconnected	0, 1	1	0	0. Disabled 1 Enabled (Refer to page 81 )	×	A	A
		o2-07	Cumulative operation time setting	0 to 65535	1 hour	—	(Refer to page 81 )	×	A	A
		o2-08	Cumulative operation time selection	0, 1	1	0	0. Power-on time 1: Running time (Refer to page 81.)	×	A	A
		Auto-tuning	T1-02	Auto-tuning mode	0, 2 only	1	0	0 Normal mode 2 Tuning mode (Refer to page 82 )	×	Q
	T1-03		Auto-tuning item selection	0, 1	1	1	0: All auto-tuning executed 1. Auto-tuning executed only for PG origin pulse compensated value (Refer to page 82 )	×	—	Q





## 2.3 MONITOR CONSTANT LIST (1)

\* Analog monitor output selection is disabled.

Function	Constant No	Name	Setting Unit	Remarks	Analog Monitor Output Level	Constant Access Level	
						Open Loop Vector	Flux Vector
Monitor	U1-01	Speed reference (Frequency Ref)	0.01%	Setting unit differs depending on setting of o1-03.	10 V/max. r/min	Q	Q
	U1-02	Output frequency	0.01 Hz	Refer to u1-05 for motor rotation	10 V/max output frequency	Q	Q
	U1-03	Output current	0.1 A	Setting unit is 0.01 A for 7.5 kW or less	10 V/inverter rated current	Q	Q
	U1-04	Control method *	—	5. Open loop vector 6. Flux vector	—	Q	Q
	U1-05	Motor speed	0.01%	Setting unit differs depending on setting of o1-03.	10 V/max r/min	Q	Q
	U1-06	Output voltage	0.1 V		10 V/200 V or 400 V	Q	Q
	U1-07	DC bus voltage	1 V		10 V/400 V or 800 V	Q	Q
	U1-08	Output power	0.1 kW		10 V/inverter capacity (kW)	Q	Q
	U1-09	Torque reference (internal)	0.1%		10 V/motor rated torque	Q	Q
	U1-10	Input terminal status *	—	 <ul style="list-style-type: none"> <li>Control circuit terminal 1 "Closed"</li> <li>Control circuit terminal 2 "Closed"</li> <li>Control circuit terminal 3 "Closed"</li> <li>Control circuit terminal 4 "Closed"</li> <li>Control circuit terminal 5 "Closed"</li> <li>Control circuit terminal 6 "Closed"</li> <li>Control circuit terminal 7 "Closed"</li> <li>Control circuit terminal 8 "Closed"</li> </ul>	—	Q	Q
	U1-11	Output terminal status *	—	 <ul style="list-style-type: none"> <li>Control circuit terminal 9-10 "Closed"</li> <li>Control circuit terminal 25 "Closed"</li> <li>Control circuit terminal 26 "Closed"</li> <li>Not used</li> <li>Not used</li> <li>Not used</li> <li>Not used</li> <li>Fault contact output operates</li> </ul>	—	Q	Q
	U1-12	Operation status *	—	 <ul style="list-style-type: none"> <li>During run</li> <li>During zero-speed</li> <li>During reverse run</li> <li>During reset signal inputting</li> <li>During speed agree</li> <li>Inverter operation ready</li> <li>Minor fault</li> <li>Major fault</li> </ul>	—	Q	Q
	U1-13	Cumulative operation time *	1 hour		—	Q	Q
	U1-14	Software No. (at flash side) *	—		—	Q	Q
	U1-15	Control circuit terminal 13 input voltage	0.1%		10 V/100 %	B	B
	U1-16	Control circuit terminal 14 input current/voltage	0.1%		10 (V), 4 (mA) to 20 (mA) /100 %	B	B
	U1-17	Control circuit terminal 16 input (Term 16 Level)	0.1%		10 V/100 %	B	B
	U1-18	Motor q-axis current (Iq)	0.1%		10 V/motor rated current	A	B
	U1-19	Motor d-axis current (Id)	0.1%		10 V/motor rated current	A	B
	U1-20	Output frequency after soft-start	0.01%	Setting unit differs depending on setting of o1-03.	10 V/max. r/min	A	A
	U1-21	ASR input	0.01%		10 V/max r/min	A	A

## MONITOR CONSTANT LIST (2)

Function	Constant No.	Name	Setting Unit	Remarks	Analog Monitor Output Level	Constant Access Level	
						Open Loop Vector	Flux Vector
Monitor	U1-22	ASR output	0.01%	Analog monitor output level becomes 10 V/max output frequency with V/f control	10 V/motor rated primary current	A	A
	U1-27	q-axis current reference	0.1%		10 V/motor rated current	A	A
	U1-28	d-axis current reference	0.1%		10 V/motor rated current	A	A
	U1-29	Voltage limit control output	0.1%		10 V/motor rated current	A	A
	U1-30	q-axis current control output	0.1%	200 for 200-V class, 400 for 400 V class	10 V/200 V or 400 V	A	A
	U1-31	d-axis current control output	0.1%	200 for 200 V class, 400 for 400 V class	10 V/200 V or 400 V	A	A
	U1-32	Output voltage reference Vq	0.1 V	V $\delta$ without PG 200 for 200 V class, 400 for 400 V class.	10 V/200 V or 400 V	A	A
	U1-33	Output voltage reference Vd	0.1 V	V $\gamma$ without PG 200 for 200 V class, 400 for 400 V class	10 V/200 V or 400 V	A	A
	U1-36	Output voltage phase	0.1 deg		10 V/360 deg	A	A
	U1-37	Magnetic pole position detection value (with PG)	0.1 deg		10 V/360 deg	—	A
	U1-38	Magnetic pole position detection estimated value (without PG)	0.1 deg		10 V/360 deg	A	—
	U1-41	LED check (diagnosis)	—		Analog output disabled	A	A
	U1-42	Operation status 2	—	 <ul style="list-style-type: none"> <li>1 During reference error input</li> <li>1 Recovery from power loss (0 recovery from momentary power loss)</li> <li>1 Priority given to controller</li> <li>1 During regenerating (0 motoring)</li> <li>1 During current/torque limit</li> <li>1 During speed limit</li> <li>0 Not used</li> <li>0 Not used</li> </ul>	Analog output disabled	A	A
	U1-43	Command 1 from transmission option	—	Cleared by initialization	—	Q	Q
	U1-44	Command 2 from transmission option	—	Cleared by initialization.	—	Q	Q
	U1-45	External torque reference	0.01%		10 V/motor rated torque	A	A
	U1-46	Torque compensation	0.01%		10 V/motor rated torque	—	A
	U1-47	DO-08/H output status	—	 <ul style="list-style-type: none"> <li>1 TD5 ON</li> <li>1 TD6 ON</li> <li>1 TD7 ON</li> <li>1 TD8 ON</li> <li>1 TD9 ON</li> <li>1 TD10 ON</li> <li>1 TD1 ON</li> <li>1 TD3 ON</li> </ul>	Analog output disabled	A	A
	U1-48	Momentary power loss drop amount	0.01%	Setting unit differs depending on o1-03 setting	10 V/max. r/min	A	A
	U1-49	Software No. (at CPU side)	—		Analog output disabled	A	A
	U1-50	Speed detection PG counter value	Pulse		10 V/65536	—	A
	U1-51	Output current phase	0.1 deg		10 V/360 deg	A	A
U1-53	PID feedback amount	0.01%	Setting unit differs depending on o1-03 setting	10 V/max r/min	A	A	
U1-54	DI-16H input status	—	Displays input value according to F3-01 setting. (Example) When lower 8 bits are ON: Binary selection: 256 BCD selection: 99	Analog output disabled	A	A	

### MONITOR CONSTANT LIST (3)

Function	Constant No	Name	Setting Unit	Remarks	Analog Monitor Output Level	Constant Access Level	
						Open Loop Vector	Flux Vector
Fault Trace	U2-01	Current fault	-	Cleared by fault reset	—	Q	Q
	U2-02	Last fault	-	Cleared by initialization	—	Q	Q
	U2-03	Speed reference at fault (U1-01)	0 01%	Cleared by initialization.	—	Q	Q
	U2-04	Output frequency at fault (U1-02)	0 01Hz	Cleared by initialization.	—	Q	Q
	U2-05	Output current at fault (U1-03)	0.1 A	Cleared by initialization	—	Q	Q
	U2-06	Motor speed at fault (U1-05)	0.01%	Cleared by initialization.	—	Q	Q
	U2-07	Output voltage reference at fault (U1-06)	0.1 V	Cleared by initialization	—	Q	Q
	U2-08	DC bus voltage at fault (U1-07)	1 V	Cleared by initialization	—	Q	Q
	U2-09	Output power at fault (U1-08)	0 1 kW	Cleared by initialization.	—	Q	Q
	U2-10	Torque reference at fault (U1-09)	0 1%	Cleared by initialization	—	Q	Q
	U2-11	Input terminal status at fault (U1-10)	—	Displays the same status at that of U1-10. Cleared by initialization.	—	Q	Q
	U2-12	Output terminal status at fault (U1-11)	—	Displays the same status at that of U1-11. Cleared by initialization.	—	Q	Q
	U2-13	Operation status at fault (U1-12)	—	Displays the same status at that of U1-12. Cleared by initialization	—	Q	Q
	U2-14	Cumulative operation time at fault (U1-13)	1 hour	Cleared by initialization.	—	Q	Q
	U2-15	Motor q-axis current at fault (U1-18)	0 1%	Cleared by initialization.	—	A	B
	U2-16	Motor d-axis current at fault (U1-19)	0.1%	Cleared by initialization	—	A	B
	U2-17	Operation status 2 at fault (U1-42)	—	Displayed in the same format as U1-42. Cleared by initialization.	—	A	A
	U2-18	Command 1 from transmission option at fault (U1-43)	—	Cleared by initialization	—	Q	Q
	U2-19	Command 2 from transmission option at fault (U1-44)	—	Cleared by initialization.	—	Q	Q
	U2-20	External torque reference at fault (U1-45)	0 01%	Cleared by initialization	—	A	A
	U2-21	Torque compensation at fault (U1-46)	0 01%	Cleared by initialization	—	—	A
	U2-22	ASR output at fault (U1-22)	0.01%	Cleared by initialization.	—	A	A
	U2-23	Output voltage phase at fault (U1-36)	0.1 deg	Cleared by initialization	—	A	A
	U2-24	Magnetic-pole position detection value at fault (U1-37)	0 1 deg	Cleared by initialization	—	—	A
	U2-25	Magnetic-pole position detection estimated value at fault (U1-38)	0.1 deg	Cleared by initialization	—	A	—

## MONITOR CONSTANT LIST (4)

Function	Constant No	Name	Setting Unit	Remarks	Analog Monitor Output Level	Constant Access Level	
						Open Loop Vector	Flux Vector
Fault History	U3-01	Most recent fault	—	Cleared by initialization	—	Q	Q
	U3-02	Second most recent fault	—	Cleared by initialization	—	Q	Q
	U3-03	Third most recent fault	—	Cleared by initialization.	—	Q	Q
	U3-04	Fourth/oldest fault	—	Cleared by initialization.	—	Q	Q
	U3-05	Cumulative operation time at fault	1 hour	Cleared by initialization	—	Q	Q
	U3-06	Accumulated time of second fault	1 hour	Cleared by initialization	—	Q	Q
	U3-07	Accumulated time of third fault	1 hour	Cleared by initialization.	—	Q	Q
	U3-08	Accumulated time of fourth/oldest fault	1 hour	Cleared by initialization	—	Q	Q

## 2.4 MULTI-FUNCTION I/O TERMINAL SETTING LIST

Set Value	Multi-function Input Terminal Function (H1-01, 02, 03, 04, 05, 06)	Multi-function Output Terminal Function (H2-01, 02, 03)	Multi-function Analog Input Terminal Function (H3-05)
00	3-Wire sequence (FWD/REV run selection)	During run	Auxiliary speed reference
01	Local/remote selection	Zero-speed	FGAIN
02	Option/inverter selection	Frequency agree 1	FBIAS
03	Multi-step speed reference 1	Desired speed agree 1	Not used
04	Multi-step speed reference 2	Speed detection 1	
05	Multi-step speed reference 3	Speed detection 2	
06	Jog reference selection	Inverter operation ready	
07	Accel/decel time selection 1	During undervoltage detection	Overtorque detection level
08	External baseblock (NO contact)	During baseblock (No contact)	Not used
09	External baseblock (NC contact)	Operation reference mode	Speed reference lower limit level
0A	Accel/decel prohibit (hold)	Speed reference mode	Setting prohibit speed
0B	Inverter overheat alarm (OH2)	During overtorque detection 1 (NO contact output)	PID feedback
0C	Multi-function analog input enable/disable	Speed reference missing	Not used
0D	Not used	Braking resistor fault	
0E	Speed control integral reset	Fault	
0F	Not used	For transmission option	
10	UP command	Alarm	FWD torque limit
11	DOWN command	During fault reset	REV torque limit
12	FJOG command	Timer output	Regeneration side torque limit
13	RJOG command	Speed agree 2	Torque reference (at torque control), limit (at speed control)
14	Fault reset	Desired speed agree 2	Torque compensation
15	Emergency stop	Speed detection 3	FWD/REV torque limits
16	Not used	Speed detection 4	Not used
17		During overtorque detection 1 (NC contact)	
18	ON-/OFF-delay timer input	During overtorque detection 2 (NO contact)	
19	PID control cancel	During overtorque detection 2 (NC contact)	
1A	Accel/decel time selection 2	During reverse run	
1B	Constant write-in prohibit	During baseblock 2 (NC contact)	
1C	Not used	Not used	
1D		Motoring/regenerating mode	
1E	Analog speed reference sample/hold	During retry	
1F	Analog input terminal (13/14) selection	OL1 pre-alarm	
20	External fault	OH pre-alarm	
21-2F		Not used	
30	PID control integral reset	During current/torque limiting	
31	Not used	During speed limit	
32		Not used	
33			
37		During run 2	
34-5F		Not used	
60			
61			
62			
63		Not used	
64, 65, 66			
67-70			
71	Speed/torque control selection		
72	Not used		
73-76			
77	Speed control proportional gain selection		
78-FF	Not used		

Note: Values which can be set depends on the control method (A1-02).

## 2.5 CONSTANTS THAT CAN BE CHANGED BY SETTING CONTROL METHOD (A1-02)

Constant No	Name	Setting Range	Setting Unit	Factory Setting	
				Open Loop Vector A1-02 = 05	Flux Vector A1-02 = 06
b1-05	Operation selection for setting of E1-08 or less	0 to 3	1	1	0
b2-01	Zero-speed level	0.00 to 10 00	0 01%	1.00*	0 50*
C5-01	ASR proportional gain 1	0 00 to 300.00	0 01	15 00	20 00
C5-03	ASR proportional gain 2	0 00 to 300.00	0 01	15.00	20 00
E1-08	Motor minimum r/min	0 to 3600	1 r/min	10% of base r/min (E1-07)*	30*

\* Setting unit depends on the o1-03 setting

## 2.6 CONSTANTS THAT CAN BE CHANGED BY SETTING INVERTER CAPACITY (o2-04)

### 200 V Class

Constant	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
—	Inverter capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
o2-04	Inverter capacity selection	—	0	1	2	3	4	5	6	7	8
C6-12	Adaptive control compensation gain	—	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95
L2-02	Momentary power loss ride time	sec	0.7	1.0	1.0	1.0	2.0	2.0	2.0	2.0	2.0

Constant	Name	Unit	Factory Setting						
			18.5	22	30	37	45	55	75
—	Inverter capacity	kW	18.5	22	30	37	45	55	75
o2-04	Inverter capacity selection	—	9	A	B	C	D	E	F
C6-12	Adaptive control compensation gain	—	0.95	0.95	0.95	0.95	0.95	0.95	0.95
L2-02	Momentary power loss ride time	sec	2.0	2.0	2.0	2.0	2.0	2.0	2.0

\*: Not initialized by Initialize (A1-03).

### 400 V Class

Constant	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
—	Inverter capacity	kW	0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
o2-04	Inverter capacity selection	—	20	21	22	23	24	25	26	27	28
C6-12	Adaptive control compensation gain	—	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95
L2-02	Momentary power loss ride time	sec	1.0	1.0	1.0	1.0	2.0	2.0	2.0	2.0	2.0

Constant	Name	Unit	Factory Setting								
			15	18.5	22	30	37	45	55	75	110
—	Inverter capacity	kW	15	18.5	22	30	37	45	55	75	110
o2-04	Inverter capacity selection	—	29	2A	2B	2C	2D	2E	2F	30	32
C6-12	Adaptive control compensation gain	—	0.95	0.95	0.95	0.95	100	0.95	0.95	0.95	0.95
L2-02	Momentary power loss ride time	sec	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0

Constant	Name	Unit	Factory Setting			
			160	185	220	300
—	Inverter capacity	kW	160	185	220	300
o2-04	Inverter capacity selection	—	34	35	36	37
C6-12	Adaptive control compensation gain	—	0.95	0.95	0.95	0.95
L2-02	Momentary power loss ride time	sec	2.0	2.0	2.0	2.0

\* Not initialized by Initialize (A1-03)

## 2.7 CONSTANTS THAT CAN BE CHANGED BY SETTING MOTOR CAPACITY SELECTION (VARIABLE TORQUE)

### (1) 200V Class, 1750 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0 4	0.75	1.5	2.2	3 7	5 5	7 5	11	15
—	Motor capacity	kW	0 4	0.75	1.5	2.2	3 7	5 5	7 5	11	15
E1-02	Motor capacity selection	—	000	001	002	003	004	005	006	007	008
E1-03	Motor rated voltage	V	200	200	200	200	200	200	200	200	200
E1-04	Motor rated current	A	1 72	3 19	5.66	8 55	14	20 5	26.2	39 4	53 2
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	Ω	10 58	3.006	1.996	1 07	0 645	0.332	0.266	0.112	0.0862
E1-10	Motor d-axis inductance	mH	41 66	19 06	15 12	9 803	7 839	5 034	4.431	3 014	2 403
E1-11	Motor q-axis inductance	mH	65 26	29 85	23.69	13 48	10 77	7 187	6 326	4 404	3 652
E1-13	Induced voltage	mV·sec/rad	223 7	222 21	245 57	239 04	243 63	247 73	265 77	254.12	253 85

Constant No	Name	Unit	Factory Setting							
			18 5	22	30	37	45	55	75	
—	Motor capacity	kW	18 5	22	30	37	45	55	75	
E1-02	Motor capacity selection	—	009	00A	00B	00C	00D	00E	00F	
E1-03	Motor rated voltage	V	200	200	200	200	200	200	200	
E1-04	Motor rated current	A	64.4	77.3	99 7	126 6	152 8	176 3	242 5	
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750	
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	
E1-09	Motor armature resistance	Ω	0 0664	0.0493	0 0412	0 0272	0.0188	0 0169	0 0096	
E1-10	Motor d-axis inductance	mH	1 994	1.602	1 383	0 973	0 788	0.778	0 515	
E1-11	Motor q-axis inductance	mH	3 031	2 435	2 188	1 538	1 229	1.214	0 804	
E1-13	Induced voltage	mV·sec/rad	259 92	256 05	277 07	265 59	264.33	294 84	285 08	

### (2) 200V Class, 1450 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0 4	0.75	1.5	2.2	3 7	5 5	7 5	11	15
—	Motor capacity	kW	0 4	0.75	1.5	2.2	3 7	5 5	7 5	11	15
E1-02	Motor capacity selection	—	100	101	102	103	104	105	106	107	108
E1-03	Motor rated voltage	V	200 0	200 0	200 0	200 0	200.0	200 0	200 0	200.0	200 0
E1-04	Motor rated current	A	1.78	3.12	5 88	8.55	14 1	20	25 7	38 6	51.6
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	4.405	2 425	1.647	0 936	0 462	0 341	0 247	0.13	0 0986
E1-10	Motor d-axis inductance	mH	26 62	19 14	14 53	11 29	7 098	5 899	6 414	3.589	3 004
E1-11	Motor q-axis inductance	mH	41 7	29 98	19.98	15 5	10 14	8.423	9 026	5.456	4.565
E1-13	Induced voltage	mV·sec/rad	262 62	276.26	291.02	292 37	294 26	306.63	333	310 28	318 96

Constant No	Name	Unit	Factory Setting					
			18 5	22	30	37	45	55
—	Motor capacity	kW	18 5	22	30	37	45	55
E1-02	Motor capacity selection	—	109	10A	10B	10C	10D	10E
E1-03	Motor rated voltage	V	200 0	200 0	200 0	200 0	200.0	200 0
E1-04	Motor rated current	A	64.3	74	101.7	124 4	148.6	172 7
E1-05	Number of motor poles	Pole	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	0 0747	0 0567	0 0407	0 0284	0 0214	0 0164
E1-10	Motor d-axis inductance	mH	2 393	1.883	1 453	1.177	0 985	0 834
E1-11	Motor q-axis inductance	mH	3.637	2 978	2 298	1.837	1.537	1.302
E1-13	Induced voltage	mV·sec/rad	312 98	323.33	318.78	323.1	331.74	362.84



(3) 200V Class, 1150 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0 4	0 75	1.5	2 2	3 7	5 5	7 5	11	15
—	Motor capacity	kW	0 4	0 75	1.5	2 2	3 7	5 5	7 5	11	15
E1-02	Motor capacity selection	—	200	201	202	203	204	205	206	207	208
E1-03	Motor rated voltage	V	200.0	200.0	200 0	200.0	200 0	200.0	200.0	200 0	200.0
E1-04	Motor rated current	A	1.74	3 17	5 9	8.84	14 2	18.6	25.8	38 6	53 1
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	Ω	6 763	3.66	1 48	0 696	0 502	0 414	0 262	0 149	0.111
E1-10	Motor d-axis inductance	mH	42.88	28 59	17 64	10 4	8 495	10 6	7.529	4 487	3 604
E1-11	Motor q-axis inductance	mH	67 17	44 78	24.23	14.85	12 13	14.92	10 97	6.82	5 479
E1-13	Induced voltage	mV·sec/rad	333 32	337 68	365 45	356.18	368.01	428.18	410	389 84	384.12

Constant No	Name	Unit	Factory Setting				
			18 5	22	30	37	45
—	Motor capacity	kW	18 5	22	30	37	45
E1-02	Motor capacity selection	—	209	20A	20B	20C	20D
E1-03	Motor rated voltage	V	200 0	200.0	200 0	200 0	200 0
E1-04	Motor rated current	A	63 8	74.1	100.6	124.7	148 9
E1-05	Number of motor poles	Pole	6	6	6	6	6
E1-06	Motor max r/min	r/min	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	Ω	0 083	0 0653	0.0461	0 0324	0.0214
E1-10	Motor d-axis inductance	mH	2 776	2 354	1.907	1.472	1.09
E1-11	Motor q-axis inductance	mH	4.391	3 722	2 975	2.296	1 7
E1-13	Induced voltage	mV·sec/rad	392.58	405 72	411.21	405 5	414.72

(4) 200V Class, 1750 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0 4	0 75	1.5	2.2	3 7	5.5	7 5	11	15
—	Motor capacity	kW	0 4	0 75	1.5	2.2	3 7	5.5	7 5	11	15
E1-02	Motor capacity selection	—	020	021	022	023	024	026	027	028	029
E1-03	Motor rated voltage	V	400	400	400	400	400	400	400	400	400
E1-04	Motor rated current	A	0 86	1.6	2 83	4.28	6 99	10.3	13 1	19 7	26 6
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	Ω	42 32	12 02	7.984	4 28	2 578	1 328	1.065	0.4995	0.345
E1-10	Motor d-axis inductance	mH	166.6	76.24	60.48	39.21	31.36	20 14	17.72	12 06	9.611
E1-11	Motor q-axis inductance	mH	261	119.4	94.76	53 92	43 07	28 75	25 3	17.62	14 61
E1-13	Induced voltage	mV·sec/rad	447 44	444 47	491.18	478 04	487 35	495 5	531.41	508.41	507 92

Constant No	Name	Unit	Factory Setting							
			18 5	22	30	37	45	55	75	
—	Motor capacity	kW	18 5	22	30	37	45	55	75	
E1-02	Motor capacity selection	—	02A	02B	02C	02D	02E	02F	030	
E1-03	Motor rated voltage	V	400	400	400	400	400	400	400	
E1-04	Motor rated current	A	32 2	38.6	49.9	63 3	76.4	88 2	121.2	
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750	
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	
E1-09	Motor armature resistance	Ω	0.266	0 197	0.165	0.1088	0 0751	0.0674	0 0385	
E1-10	Motor d-axis inductance	mH	7 976	6.407	5.533	3 89	3 153	3.114	2.06	
E1-11	Motor q-axis inductance	mH	12 12	9 739	8 751	6.153	4.917	4.856	3.214	
E1-13	Induced voltage	mV·sec/rad	519 89	512 24	554.36	521.82	528.53	589 77	570.15	

(5) 400V Class, 1450 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
E1-02	Motor capacity selection	—	120	121	122	123	124	126	127	128	129
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	0.89	1.56	2.94	4.28	7.07	10	12.9	19.3	25.8
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	$\Omega$	17.62	9.7	6.588	3.743	1.848	1.366	0.987	0.52	0.394
E1-10	Motor d-axis inductance	mH	106.5	76.56	58.12	45.16	28.39	23.6	25.66	14.36	12.01
E1-11	Motor q-axis inductance	mH	166.8	119.9	79.91	62.02	40.54	33.69	36.1	21.82	18.26
E1-13	Induced voltage	mV·sec/rad	525.15	552.47	582.12	584.51	588.33	613.26	665.91	620.42	638.15

Constant No	Name	Unit	Factory Setting					
			18.5	22	30	37	45	55
—	Motor capacity	kW	18.5	22	30	37	45	55
E1-02	Motor capacity selection	—	12A	12B	12C	12D	12E	12F
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	32.2	37	50.9	62.2	74.3	86.4
E1-05	Number of motor poles	Pole	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	$\Omega$	0.299	0.227	0.163	0.113	0.0856	0.0654
E1-10	Motor d-axis inductance	mH	9.572	7.53	5.812	4.709	3.941	3.338
E1-11	Motor q-axis inductance	mH	14.55	11.91	9.192	7.346	6.147	5.206
E1-13	Induced voltage	mV·sec/rad	626.18	646.74	637.65	646.29	663.53	725.76

(6) 400V Class, 1150 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
E1-02	Motor capacity selection	—	220	221	222	223	224	226	227	228	229
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	0.87	1.59	2.95	4.42	7.1	9.31	12.9	19.3	26.6
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	$\Omega$	27.05	14.64	5.921	2.783	2.006	1.657	1.049	0.595	0.444
E1-10	Motor d-axis inductance	mH	171.5	114.4	70.56	41.61	33.98	42.41	30.12	17.95	14.42
E1-11	Motor q-axis inductance	mH	268.7	179.1	96.9	59.41	48.52	59.68	43.88	27.28	21.91
E1-13	Induced voltage	mV·sec/rad	666.86	675.5	731.03	712.35	735.8	856.44	820.04	779.85	768.33

Constant No	Name	Unit	Factory Setting				
			18.5	22	30	37	45
—	Motor capacity	kW	18.5	22	30	37	45
E1-02	Motor capacity selection	—	22A	22B	22C	22D	22E
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	31.9	37	50.3	62.3	74.4
E1-05	Number of motor poles	Pole	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	$\Omega$	0.332	0.261	0.185	0.129	0.0857
E1-10	Motor d-axis inductance	mH	11.1	9.414	7.629	5.887	4.359
E1-11	Motor q-axis inductance	mH	17.56	14.89	11.9	9.182	6.799
E1-13	Induced voltage	mV·sec/rad	785.12	811.44	822.47	810.95	829.62

## 2.8 CONSTANTS THAT CAN BE CHANGED BY SETTING MOTOR CAPACITY SELECTION (CONSTANT TORQUE)

### (1) 200V Class, 1750 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0 4	0 75	1.5	2.2	3.7	5.5	7.5	11	15
—	Motor capacity	kW	0 4	0 75	1.5	2.2	3.7	5.5	7.5	11	15
E1-02	Motor capacity selection	—	000	001	002	003	004	005	006	007	008
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	1.8	3.5	6.5	8.9	14.6	20.0	29.3	37.9	53.2
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	Ω	3.006	1.474	1.048	0.645	0.331	0.370	0.223	0.153	0.095
E1-10	Motor d-axis inductance	mH	18.16	11.03	6.96	7.03	4.78	5.39	3.58	3.46	2.46
E1-11	Motor q-axis inductance	mH	27.10	16.46	10.58	9.71	6.52	7.36	4.89	4.96	3.70
E1-13	Induced voltage	mV·sec/rad	214.61	207.54	220.82	235.31	239.31	254.25	236.97	269.96	254.25

Constant No	Name	Unit	Factory Setting						
			18.5	22	30	37	45	55	75
—	Motor capacity	kW	18.5	22	30	37	45	55	75
E1-02	Motor capacity selection	—	009	00A	00B	00C	00D	00E	00F
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	65.0	76.4	103.5	133.1	149.4	181.6	241.0
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	Ω	0.069	0.054	0.041	0.027	0.022	0.016	0.011
E1-10	Motor d-axis inductance	mH	1.99	1.70	1.29	0.91	0.90	0.72	0.57
E1-11	Motor q-axis inductance	mH	2.99	2.55	2.00	1.41	1.39	1.11	0.88
E1-13	Induced voltage	mV·sec/rad	256.73	261.05	260.37	245.07	275.99	277.07	292.23

### (2) 200V Class, 1450 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
E1-02	Motor capacity selection	—	100	101	102	103	104	105	106	107	108
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	1.8	3.2	6.1	9.4	13.9	19.5	26.0	39.2	52.9
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	4.669	2.425	0.966	0.429	0.514	0.338	0.247	0.155	0.099
E1-10	Motor d-axis inductance	mH	27.36	18.24	10.60	6.05	7.47	6.37	6.04	4.34	2.86
E1-11	Motor q-axis inductance	mH	40.82	27.21	13.99	8.25	10.19	8.69	8.86	6.31	4.30
E1-13	Induced voltage	mV·sec/rad	263.39	266.81	282.33	269.24	299.12	315.95	321.66	309.92	308.12

Constant No	Name	Unit	Factory Setting						
			18.5	22	30	37	45	55	75
—	Motor capacity	kW	18.5	22	30	37	45	55	75
E1-02	Motor capacity selection	—	109	10A	10B	10C	10D	10E	10F
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	65.0	74.0	101.1	123.3	146.3	178.2	246.8
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	0.078	0.065	0.048	0.033	0.025	0.016	0.009
E1-10	Motor d-axis inductance	mH	2.39	2.01	1.61	1.29	1.12	0.77	0.55
E1-11	Motor q-axis inductance	mH	3.58	3.13	2.50	2.00	1.74	1.19	0.91
E1-13	Induced voltage	mV·sec/rad	309.15	325.49	326.75	331.2	346.37	340.97	325.67

(3) 200V Class, 1150 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
E1-02	Motor capacity selection	—	200	201	202	203	204	205	206	207	208
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	1.8	3.4	6.1	8.8	14.8	18.8	27.8	39.3	54.6
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	$\Omega$	3.660	2.100	1.480	0.747	0.502	0.414	0.262	0.177	0.111
E1-10	Motor d-axis inductance	mH	27.25	14.72	15.82	10.75	8.06	9.98	7.09	5.43	3.43
E1-11	Motor q-axis inductance	mH	40.66	22.38	21.85	14.67	11.00	14.64	10.29	7.88	5.16
E1-13	Induced voltage	mV·sec/rad	326.16	321.21	352.98	358.97	355.46	413.55	369.86	389.39	371.03

Constant No	Name	Unit	Factory Setting						
			18.5	22	30	37	45	55	75
—	Motor capacity	kW	18.5	22	30	37	45	55	75
E1-02	Motor capacity selection	—	209	20A	20B	20C	20D	20E	20F
E1-03	Motor rated voltage	V	200.0	200.0	200.0	200.0	200.0	200.0	200.0
E1-04	Motor rated current	A	64.3	74.3	100.7	123.5	144.7	175.1	248.4
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	$\Omega$	0.093	0.075	0.049	0.036	0.025	0.017	0.011
E1-10	Motor d-axis inductance	mH	2.89	2.51	2.02	1.62	1.27	0.97	0.72
E1-11	Motor q-axis inductance	mH	4.50	3.91	3.12	2.50	1.97	1.62	1.11
E1-13	Induced voltage	mV·sec/rad	390.6	408.47	413.96	415.58	438.35	434.21	412.7

(4) 400V Class, 1750 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
E1-02	Motor capacity selection	—	020	021	022	023	024	025	026	027	028
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	0.9	1.8	3.3	4.5	7.3	8.6	10.0	14.6	19.0
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	$\Omega$	12.020	5.894	4.192	2.658	1.329	1.819	1.479	0.892	0.613
E1-10	Motor d-axis inductance	mH	72.66	44.12	27.83	28.12	19.11	19.18	21.58	14.33	13.84
E1-11	Motor q-axis inductance	mH	108.4	65.84	42.32	38.85	26.08	32.35	29.44	19.56	19.83
E1-13	Induced voltage	mV·sec/rad	429.21	415.04	441.68	470.57	478.62	556.8	508.41	473.85	540

Constant No	Name	Unit	Factory Setting								
			15	18.5	22	30	37	45	55	75	90
—	Motor capacity	kW	15	18.5	22	30	37	45	55	75	90
E1-02	Motor capacity selection	—	029	02A	02B	02C	02D	02E	02F	030	031
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	26.6	32.5	38.2	51.8	66.6	74.7	90.8	120.5	147.7
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	$\Omega$	0.378	0.276	0.217	0.165	0.107	0.087	0.064	0.045	0.025
E1-10	Motor d-axis inductance	mH	9.85	7.95	6.80	5.15	3.62	3.59	2.87	2.26	1.52
E1-11	Motor q-axis inductance	mH	14.79	11.94	10.22	8.00	5.63	5.55	4.44	3.50	2.53
E1-13	Induced voltage	mV·sec/rad	508.41	513.68	522.27	520.83	490.23	551.97	554.36	584.51	542.88

Constant No	Name	Unit	Factory Setting					
			110	132	160	200	250	300
—	Motor capacity	kW	110	132	160	200	250	300
E1-02	Motor capacity selection	—	032	033	034	035	036	037
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	174.2	212.8	242.9	311.5	382.8	453.2
E1-05	Number of motor poles	Pole	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1750	1750	1750	1750	1750	1750
E1-07	Motor base r/min	r/min	1750	1750	1750	1750	1750	1750
E1-09	Motor armature resistance	$\Omega$	0.022	0.016	0.011	0.009	0.006	0.005
E1-10	Motor d-axis inductance	mH	1.46	1.12	0.95	0.67	0.57	0.49
E1-11	Motor q-axis inductance	mH	2.27	1.74	1.48	1.04	0.98	0.84
E1-13	Induced voltage	mV·sec/rad	589.77	567.27	627.62	590.27	596.97	617.54

(5) 400V Class, 1450 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
E1-02	Motor capacity selection	—	120	121	122	123	124	125	126	127	128
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	0.9	1.7	3.1	4.4	7.4	6.2	9.4	13.9	19.7
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	14.640	8.400	5.921	2.987	2.006	2.546	1.657	1.049	0.708
E1-10	Motor d-axis inductance	mH	109.00	58.88	63.28	43.00	32.24	29.22	39.94	28.35	21.70
E1-11	Motor q-axis inductance	mH	162.60	89.52	87.40	58.68	44.00	52.83	58.56	41.18	31.52
E1-13	Induced voltage	mV·sec/rad	652.5	642.47	706.1	718.07	710.91	612.7	827.24	739.62	778.91

Constant No	Name	Unit	Factory Setting								
			15	18.5	22	30	37	45	55	75	90
—	Motor capacity	kW	15	18.5	22	30	37	45	55	75	90
E1-02	Motor capacity selection	—	129	12A	12B	12C	12D	12E	12F	130	131
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	27.3	32.2	37.1	50.3	61.8	72.3	87.6	124.2	146.3
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	0.444	0.371	0.300	0.196	0.144	0.102	0.067	0.045	0.036
E1-10	Motor d-axis inductance	mH	13.74	11.58	10.05	8.08	6.47	5.09	3.89	2.87	2.53
E1-11	Motor q-axis inductance	mH	20.63	18.00	15.63	12.49	9.99	7.87	6.46	4.45	3.92
E1-13	Induced voltage	mV·sec/rad	742.01	781.29	816.71	827.73	831.06	876.56	868.41	825.3	850.68

Constant No	Name	Unit	Factory Setting				
			110	132	160	200	250
—	Motor capacity	kW	110	132	160	200	250
E1-02	Motor capacity selection	—	132	133	134	135	136
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	175.9	207.6	247.0	314.4	400.0
E1-05	Number of motor poles	Pole	6	6	6	6	6
E1-06	Motor max. r/min	r/min	1450	1450	1450	1450	1450
E1-07	Motor base r/min	r/min	1450	1450	1450	1450	1450
E1-09	Motor armature resistance	Ω	0.020	0.016	0.013	0.009	0.004
E1-10	Motor d-axis inductance	mH	1.79	1.50	1.27	0.95	0.50
E1-11	Motor q-axis inductance	mH	2.80	2.35	2.20	1.65	0.80
E1-13	Induced voltage	mV·sec/rad	863.15	885.65	895.68	864.59	652.7

(6) 400V Class, 1150 r/min Rating

Constant No	Name	Unit	Factory Setting								
			0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
—	Motor capacity	kW	0.4	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11
E1-02	Motor capacity selection	—	220	221	222	223	224	225	226	227	228
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	0.9	1.6	3.1	4.7	7.0	6.2	9.7	13.0	19.6
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	Ω	18.680	9.700	3.862	1.715	2.057	2.753	1.554	0.987	0.619
E1-10	Motor d-axis inductance	mH	109.40	72.96	42.40	24.19	29.86	35.49	25.48	24.16	17.36
E1-11	Motor q-axis inductance	mH	163.30	108.80	55.96	33.00	40.76	64.19	34.77	35.42	25.22
E1-13	Induced voltage	mV·sec/rad	526.59	533.79	564.89	538.56	598.41	779.7	631.94	643.41	619.97

Constant No	Name	Unit	Factory Setting								
			15	18.5	22	30	37	45	55	75	90
—	Motor capacity	kW	15	18.5	22	30	37	45	55	75	90
E1-02	Motor capacity selection	—	229	22A	22B	22C	22D	22E	22F	230	231
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	26.4	32.5	37.0	50.6	61.6	73.1	89.1	123.4	142.7
E1-05	Number of motor poles	Pole	6	6	6	6	6	6	6	6	6
E1-06	Motor max r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150	1150	1150	1150	1150	1150
E1-09	Motor armature resistance	Ω	0.394	0.311	0.260	0.190	0.131	0.099	0.065	0.037	0.032
E1-10	Motor d-axis inductance	mH	11.45	9.54	8.04	6.43	5.17	4.49	3.08	2.19	2.10
E1-11	Motor q-axis inductance	mH	17.19	14.33	12.50	10.00	8.00	6.94	4.76	3.64	3.28
E1-13	Induced voltage	mV·sec/rad	616.1	618.53	651.06	653.45	662.54	692.73	681.71	651.56	707.54

Constant No	Name	Unit	Factory Setting			
			110	132	160	200
—	Motor capacity	kW	110	132	160	200
E1-02	Motor capacity selection	—	232	233	234	235
E1-03	Motor rated voltage	V	400.0	400.0	400.0	400.0
E1-04	Motor rated current	A	174.4	207.3	254.6	311.4
E1-05	Number of motor poles	Pole	6	6	6	6
E1-06	Motor max r/min	r/min	1150	1150	1150	1150
E1-07	Motor base r/min	r/min	1150	1150	1150	1150
E1-09	Motor armature resistance	Ω	0.025	0.014	0.009	0.008
E1-10	Motor d-axis inductance	mH	1.76	1.20	0.91	0.77
E1-11	Motor q-axis inductance	mH	2.72	1.88	1.42	1.33
E1-13	Induced voltage	mV·sec/rad	708.98	706.1	688.91	696.56

### 3. CONSTANT DESCRIPTION

#### b APPLICATION-RELATED CONSTANTS

Constant No.	Name	Description	Remarks												
b1-01  b1-02	Speed reference selection  Operation method selection	<p>Frequency reference and run command can be set independently in the REMOTE mode as shown below</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Run by digital operator reference</td> </tr> <tr> <td>1</td> <td>Run by control circuit terminal reference</td> </tr> <tr> <td>2</td> <td>—</td> </tr> <tr> <td>3</td> <td>Run by option card (CP-916 B/G or 216 I/F reference)</td> </tr> <tr> <td>4</td> <td>Run by personal computer (CP-717)</td> </tr> </tbody> </table> <p>By using the digital operator LOCAL/REMOTE key, operation mode can be selected during stop as shown below</p> <p><b>LOCAL</b> Run by frequency reference and run command from digital operator</p> <p><b>REMOTE</b> Run by frequency reference and run command set by b1-01 and b1-02, respectively</p> <p>Note REMOTE is set when the power supply is turned ON</p>	Set Value	Description	0	Run by digital operator reference	1	Run by control circuit terminal reference	2	—	3	Run by option card (CP-916 B/G or 216 I/F reference)	4	Run by personal computer (CP-717)	When b1-01 is selected, frequency reference is a sum of terminals 13 and 14 (When terminal 14 is selected as a multi-function input, only terminal 13 is input)
Set Value	Description														
0	Run by digital operator reference														
1	Run by control circuit terminal reference														
2	—														
3	Run by option card (CP-916 B/G or 216 I/F reference)														
4	Run by personal computer (CP-717)														
b1-03	Stopping method selection	<p>The stopping method can be set as shown below.</p> <p>① b1-03 = 0 Deceleration to stop      ② b1-03 = 1 Coast to stop</p> <p>③ B1-03 = 3 Coasting to a stop (with timer function)</p> <p>ONCE STOP COMMAND IS INPUT, RUN COMMAND IS DISREGARDED FOR T1 TIME AFTER ELAPSE OF T1 TIME, INVERTER DOES NOT RESTART UNLESS RUN COMMAND IS INPUT AGAIN</p> <p>T1 TIME IS SPECIFIED ACCORDING TO MOTOR SPEED AT STOP COMMAND INPUT</p>	Deceleration time is selected among C1-02, C1-04, C1-06 and C1-08												




Constant No.	Name	Description	Remarks										
b1-04	Prohibition of reverse operation	<table border="1"> <thead> <tr> <th>Selection</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>REV run enabled</td> </tr> <tr> <td>1</td> <td>REV run prohibited (REV run command and minus speed reference are not accepted)</td> </tr> </tbody> </table>	Selection	Description	0	REV run enabled	1	REV run prohibited (REV run command and minus speed reference are not accepted)					
Selection	Description												
0	REV run enabled												
1	REV run prohibited (REV run command and minus speed reference are not accepted)												
b1-05	Operation selection for setting of E1-08 or less	<p>When flux vector control is set select operation mode for speed reference less than E1-08.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Run according to speed reference (E1-08 invalid)</td> </tr> <tr> <td>1</td> <td>Baseblock</td> </tr> <tr> <td>2</td> <td>Run with min speed reference (E1-08)</td> </tr> <tr> <td>3</td> <td>Zero-speed operation (Internal speed reference is set to zero.)</td> </tr> </tbody> </table> <p>Time Chart of Inverter internal speed reference</p>	Selection	Description	0	Run according to speed reference (E1-08 invalid)	1	Baseblock	2	Run with min speed reference (E1-08)	3	Zero-speed operation (Internal speed reference is set to zero.)	<ul style="list-style-type: none"> <li>This setting is disabled when E1-08=0 (INITIAL VALUE)</li> <li>When A1-02 = 05 (open loop vector control), only 1 and 2 can be selected at less than the minimum r/min (E1-08) since the rotor position is not defined</li> </ul>
Selection	Description												
0	Run according to speed reference (E1-08 invalid)												
1	Baseblock												
2	Run with min speed reference (E1-08)												
3	Zero-speed operation (Internal speed reference is set to zero.)												

Constant No	Name	Description	Remarks												
b1-06	Operation selection after switching to remote mode	<table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Does not operate even if REMOTE run command is ON when switching LOCAL to REMOTE</td> </tr> <tr> <td>1</td> <td>Operates if REMOTE run command is ON when switching LOCAL to REMOTE</td> </tr> </tbody> </table>	Set Value	Description	0	Does not operate even if REMOTE run command is ON when switching LOCAL to REMOTE	1	Operates if REMOTE run command is ON when switching LOCAL to REMOTE	When the set value is 0, turn OFF the run command once and then turn it ON to start the operation						
Set Value	Description														
0	Does not operate even if REMOTE run command is ON when switching LOCAL to REMOTE														
1	Operates if REMOTE run command is ON when switching LOCAL to REMOTE														
b2-01	Zero-speed level (BB starting speed)	Set speed which starts baseblock in units of 0.01%, when deceleration to stop is selected	The initial values are 1.00% at A1-02=5 (open loop vector control) and 0.50% at A1-02=6 (flux vector control). The setting unit can be changed by a1-03.												
b3-02	Magnetic-pole lead-in current	Sets current at initial magnetic-pole lead-in (Unit 1%) Motor rated current (E1-04) becomes 100% To increase starting torque, increase this value													
b3-04	Current rising time	Sets current rising time at initial magnetic-pole lead-in (Unit: 0.1 sec).													
b3-05	Magnetic-pole lead-in time	<p>Sets the waiting time for lead-in after current positive start at initial magnetic-pole lead-in (Unit 0.1 sec).</p> <p>Current variation at initial magnetic-pole lead-in is as shown below.</p> <p>The following outlines the adjustment for reduction of starting time or increase of starting torque at startup in open loop vector control method</p> <table border="1"> <thead> <tr> <th>Operation Status</th> <th>b3-02 Adjustment</th> <th>b3-04 Adjustment</th> <th>b3-05 Adjustment</th> </tr> </thead> <tbody> <tr> <td>Startup is slow.</td> <td>—</td> <td>Decrease set value</td> <td>Decrease set value.</td> </tr> <tr> <td>Starting torque is short and "STO" is output</td> <td>Increase set value.</td> <td>—</td> <td>—</td> </tr> </tbody> </table>	Operation Status	b3-02 Adjustment	b3-04 Adjustment	b3-05 Adjustment	Startup is slow.	—	Decrease set value	Decrease set value.	Starting torque is short and "STO" is output	Increase set value.	—	—	<p>Control operation by b3-02 to b3-05 differs depending on the control method (A1-02)</p> <p>Flux vector control (A1-02=06) Operates only at origin pulse tuning Does not operate under normal operation</p> <p>Open loop vector control (A1-02=05) Performs magnetic-pole lead-in operation at every startup</p>
Operation Status	b3-02 Adjustment	b3-04 Adjustment	b3-05 Adjustment												
Startup is slow.	—	Decrease set value	Decrease set value.												
Starting torque is short and "STO" is output	Increase set value.	—	—												

Constant No	Name	Description	Remarks								
b4-01 b4-02	Timer function ON-delay time Timer function OFF-delay time	<p>By combining multi-function input terminal timer input (set value=18) and multi-function output terminal timer output (set value=12), a timer to be mounted on the outside of the inverter can be enclosed in the inverter</p> <p>Sets ON-delay time in units of 0.1 second</p> <p>Sets OFF-delay time in units of 0.1 second.</p> <p>Sequence</p> <ol style="list-style-type: none"> <li>① When timer input "CLOSED" time is shorter than b4-01, timer output remains "OPEN."</li> <li>② When timer input is "CLOSED," time output becomes "CLOSED" after the time set to b4-01 elapses.</li> <li>③ When timer input "OPEN" time is shorter than b4-02, timer output remains "CLOSED"</li> <li>④ When timer input is "OPEN," time output becomes "OPEN" after the time set to b4-02 elapses</li> </ol>	For selection of multi-function input terminal function, refer to H1-01 to H1-06								
b5-01	PID control method selection	<ul style="list-style-type: none"> <li>• PID process control is enabled in the inverter</li> </ul> <table border="1"> <thead> <tr> <th>b5-01</th> <th>PID Control Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PID control disabled</td> </tr> <tr> <td>1</td> <td>PID control enabled (Deviation is D-controlled )</td> </tr> <tr> <td>2</td> <td>PID control enabled (Feedback value is D-controlled.)</td> </tr> </tbody> </table> <p>The following shows the PID control block diagram.</p> <ul style="list-style-type: none"> <li>• Set this constant to 1 or 2 for PID control. Normally, use measured value differential type PID control of set value 2</li> <li>• When "PID control enabled" is selected, the aimed value input is determined by b1-01 (speed reference selection)</li> <li>• Input the feedback value from multi-function analog input terminal or speed reference (current) terminal. Set PID feedback (set value B) either to multi-function analog input terminal 16 function selection (H3-05) or speed reference (current) terminal 14 function selection (H3-09). Set gain and bias of the analog input to be used for adjustment of feedback amount. Proportional gain (P), integral time (I), differential time (D): b5-02, b5-03, b5-05</li> <li>• Adjust the response of PID control using proportional gain (P), integral time (I) and differential time (D).</li> </ul>	b5-01	PID Control Function	0	PID control disabled	1	PID control enabled (Deviation is D-controlled )	2	PID control enabled (Feedback value is D-controlled.)	
b5-01	PID Control Function										
0	PID control disabled										
1	PID control enabled (Deviation is D-controlled )										
2	PID control enabled (Feedback value is D-controlled.)										



Constant No	Name	Description	Remarks
b5-02	Proportional gain (P)	Sets P-control proportional gain. Setting to 0.0 does not perform P-control	For multi-function analog input terminal function, refer to H3-04 to H3-12.
b5-03	Integral (I) time	Sets I-control integral time. Setting to 0.0 does not perform I-control.	
b5-04	Integral (I) limit	Sets integral limit in the ratio for motor r/min max (E1-06).	
b5-05	Differential (D) time	Sets D-control differential time Setting to 0.0 does not perform D-control	
b5-06	PID limit	Sets PID limit control limiter in the ratio for motor max. r/min (E1-06).	
b5-07	PID offset adjustment	Sets offset for output after PID control in the ratio for motor max. r/min(E1-06)	
b5-08	PID primary delay time	Sets primary delay time constant for frequency reference after PID control	

(When variation is of step form)



• Value I is reset to 0 in the following cases




- ① Stop command is input or operation held
  - ② For selection of multi-function input PID control, terminal is set to CLOSED and PID control is set to DISABLED
  - ③ For selection of multi-function input PID control integral reset, terminal is set to CLOSED and integration is reset.
- The upper limit of value I can be set by b5-04.  
To increase control capability by integration, increase the value of b5-04. If the control system vibrates and it cannot be resolved by adjusting integral time or primary time constant, decrease the value of b5-04
- By selecting multi-function input PID DISABLED/ENABLED and closing the contact during run, PID control is canceled and the aimed value signal is used as frequency reference without being changed.

Constant No.	Name	Description	Remarks
b6-01 b6-02 b6-03 b6-04	Dwell speed at start Dwell time at start Dwell speed at stop Dwell time at stop	<p>Dwell (temporary stop) function is used to stop motor speed or speed reference temporarily and hold it when driving a motor with a heavy starting load.</p> <p>Sets speed reference to hold motor speed during acceleration in units of 0.01% with motor max r/min (E1-06) as 100%.</p> <p>Sets time to hold motor speed during acceleration in units of 0.1sec</p> <p>Sets speed reference to hold motor speed during deceleration in units of 0.01% with motor max r/min (E1-06) as 100%</p> <p>Sets time to hold motor speed during deceleration in units of 0.1sec</p> 	<p>The unit of b6-01 and b6-03 can be changed by o1-03 setting.</p> <p>Dwell function at startup becomes invalid when b6-01 <math>\leq</math> E1-08 (motor min r/min).</p> <p>Dwell function at stopping becomes invalid when b6-03 <math>\leq</math> E1-08</p>
b7-01 b7-02	Droop control gain Droop control delay time	<p>Drooping is a function to provide speed drooping characteristics in proportion to load torque</p> <p>Sets b7-01 to speed reduction amount in the rated (100%) load status in the ratio (%) for motor max r/min (E1-06)</p> $\text{Speed drop amount (\%)} = \frac{(b7-01)}{100} \times 100\% \text{ (rated torque)}$ <p>Sets the drooping response time to b7-02</p> <p>By decreasing b7-02, drooping response quicker, however, the motor would hunt more easily</p> <p>The following shows the speed drooping characteristics when a step load is applied</p> 	<p>Function only for A1-02 = 6 (flux vector control)</p>

## C CONSTANTS FOR ADJUSTMENT

Constant No	Name	Description	Remarks																				
C1-01 C1-02 C1-03 C1-04 C1-05 C1-06 C1-07 C1-08	Acceleration time 1 Deceleration time 1 Acceleration time 2 Deceleration time 2 Acceleration time 3 Deceleration time 3 Acceleration time 4 Deceleration time 4	<p>Sets acceleration time to accelerate from 0(r/min) to the max r/min (E1-06), and deceleration time to decelerate from the max. r/min to 0(r/min).</p> <p>By accel/decel time selection commands 1 and 2 of multi-function inputs, accel/decel time can be changed up to 4 steps. (Changeable even during run )</p> <table border="1"> <thead> <tr> <th>Accel/decel Time Selection 2 Multi-function Input Set Value =1A</th> <th>Accel/decel Time Selection 1 Multi-function Input Set Value =07</th> <th>Accel Time</th> <th>Decel Time</th> </tr> </thead> <tbody> <tr> <td>Open or not set</td> <td>Open or not set</td> <td>C1-01</td> <td>C1-02</td> </tr> <tr> <td>Open or not set</td> <td>Closed</td> <td>C1-03</td> <td>C1-04</td> </tr> <tr> <td>Closed</td> <td>Open or not set</td> <td>C1-05</td> <td>C1-06</td> </tr> <tr> <td>Closed</td> <td>Closed</td> <td>C1-07</td> <td>C1-08</td> </tr> </tbody> </table>	Accel/decel Time Selection 2 Multi-function Input Set Value =1A	Accel/decel Time Selection 1 Multi-function Input Set Value =07	Accel Time	Decel Time	Open or not set	Open or not set	C1-01	C1-02	Open or not set	Closed	C1-03	C1-04	Closed	Open or not set	C1-05	C1-06	Closed	Closed	C1-07	C1-08	For multi-function input terminal function selection, refer to H1-01 to H1-06
Accel/decel Time Selection 2 Multi-function Input Set Value =1A	Accel/decel Time Selection 1 Multi-function Input Set Value =07	Accel Time	Decel Time																				
Open or not set	Open or not set	C1-01	C1-02																				
Open or not set	Closed	C1-03	C1-04																				
Closed	Open or not set	C1-05	C1-06																				
Closed	Closed	C1-07	C1-08																				
C1-09	Emergency stop time	<p>Emergency stop time becomes valid in the following cases</p> <ul style="list-style-type: none"> <li>Multi-function input emergency stop command ( set value = 15) is closed</li> <li>Selection at fault detection is set to emergency stop</li> </ul>	Turn OFF operation signal and emergency stop signal at reactivation after emergency stop																				
C1-10	Accel/decel time setting unit	<p>Accel/decel Time Setting Unit</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Accel/decel time (C1-01 to 09) setting range is in units of 0.01 second Setting range 0.00 to 600.00 seconds</td> </tr> <tr> <td>1</td> <td>Accel/decel time (C1-01 to 09) setting range is in units of 0.1 second Setting range 0.0 to 6000.0 seconds</td> </tr> </tbody> </table> <p>When C1-10 is changed, the setting unit of accel/decel time (C1-01 to 09) stored in the inverter is changed automatically as follows</p> <p>When C1-10 is changed from 1 to 0 at C1-01 = 12.4 seconds, 12.40 seconds is automatically set to C1-01.</p> <p>If either of C1-01 to 09 is set to 600.1 seconds or more, C1-10 cannot be changed from 1 to 0</p>	Set Value	Description	0	Accel/decel time (C1-01 to 09) setting range is in units of 0.01 second Setting range 0.00 to 600.00 seconds	1	Accel/decel time (C1-01 to 09) setting range is in units of 0.1 second Setting range 0.0 to 6000.0 seconds															
Set Value	Description																						
0	Accel/decel time (C1-01 to 09) setting range is in units of 0.01 second Setting range 0.00 to 600.00 seconds																						
1	Accel/decel time (C1-01 to 09) setting range is in units of 0.1 second Setting range 0.0 to 6000.0 seconds																						
C1-11	Accel/decel time switching speed	<p>By using C1-11, accel/decel time can be changed automatically.</p> <p>Run at C1-01 and 02 accel/decel time at motor speed <math>\geq</math> C1-11. Run at C1-07 and 08 accel/decel time at motor speed <math>&lt;</math> C1-11.</p> <p>Multi-function input accel/decel time selection has priority over automatic change of accel/decel</p>																					

Constant No	Name	Description	Remarks						
C2-12	Leading phase compensation amount	Compensates for difference between estimated magnetic-pole position (control axis) and actual magnetic-pole position in units of 0.1 degree (electrical angle). Set automatically by auto-tuning of open loop vector control. Do not change it unnecessarily after setting.	Not initialized						
C2-13	PG zero-pulse compensation amount	Sets the gap between magnetic pole and Z-phase pulse (Zero-pulse) in units of 0.1 degree (electrical angle) Set automatically by auto-tuning of flux vector control Do not change it unnecessarily after setting	Not initialized						
C3-01	Energy saving control selection	Sets energy-saving control selection. <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Controls d-axis current as 0 in a constant torque area. Applies d-axis current required to limit output voltage by C3-05 setting in a constant output area</td> </tr> <tr> <td>1</td> <td>Controls d-axis current and q-axis current so that motor efficiency will be the maximum according to torque reference Energy-saving operation is not enabled since output voltage limit has a priority in a constant output area</td> </tr> </tbody> </table>	Set Value	Description	0	Controls d-axis current as 0 in a constant torque area. Applies d-axis current required to limit output voltage by C3-05 setting in a constant output area	1	Controls d-axis current and q-axis current so that motor efficiency will be the maximum according to torque reference Energy-saving operation is not enabled since output voltage limit has a priority in a constant output area	Normally, set the value to "1".
Set Value	Description								
0	Controls d-axis current as 0 in a constant torque area. Applies d-axis current required to limit output voltage by C3-05 setting in a constant output area								
1	Controls d-axis current and q-axis current so that motor efficiency will be the maximum according to torque reference Energy-saving operation is not enabled since output voltage limit has a priority in a constant output area								
C3-05	Voltage limit control selection	Sets voltage limit control selection. <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Enabled Applies d-axis current to control voltage so that the voltage limit control set value (peculiar to motor) will not be exceeded when output voltage is increased.</td> </tr> </tbody> </table>	Set Value	Description	0	Disabled	1	Enabled Applies d-axis current to control voltage so that the voltage limit control set value (peculiar to motor) will not be exceeded when output voltage is increased.	Normally, set the value to "1"
Set Value	Description								
0	Disabled								
1	Enabled Applies d-axis current to control voltage so that the voltage limit control set value (peculiar to motor) will not be exceeded when output voltage is increased.								
C5-01	ASR proportional gain 1	Sets ASR proportional gain in units of 0.01.	Refer to the block diagram on page 46						
C5-02	ASR integral time 1	Sets ASR integral time 1 in units of 1 msec							
C5-03	ASR proportional gain 2	Sets ASR proportional gain in 2 in units of 0 01.							
C5-04	ASR integral time 2	Sets ASR integral time 2 in units of 1 msec							
C5-05	ASR primary delay time	Sets the primary delay time (Unit 1 msec).							
C5-06	ASR switching speed	Sets the speed to switch ASR proportional gain and integral time in units of 0 01%.	·Refer to the block diagram on page 46 ·The setting unit can be changed by o1-03						
C5-07	ASR proportional gain at start	ASR proportional gain used at magnetic-pole lead-in or startup (Setting unit: 0 01).							

Constant No	Description
	<p data-bbox="337 267 539 289">ASR of vector control</p> <p data-bbox="337 338 704 360">The following shows the block diagram</p>  <p data-bbox="337 714 1360 765">Note: ASR P-gain in flux vector control is based on motor max r/min (E1-06). Proportional gain and integral time are approximated in a straight line by motor speed as shown below</p>  <ul data-bbox="540 1092 992 1114" style="list-style-type: none"> <li>• When C5-06 0, Fixed to P = C5-01, I = C5-02</li> </ul> <p data-bbox="337 1249 1105 1271">If 77 is selected to multi-function input terminal, proportional gain can be changed.</p>  <ul data-bbox="540 1599 854 1661" style="list-style-type: none"> <li>• Changed at time set by C5-02.</li> <li>• Integral time is not changed</li> </ul>



Constant No.	Name	Description	Remarks						
C6-02	Carrier frequency selection	Sets carrier frequency. Set value must be either 2, 4, 8 or 12 kHz To reduce carrier noise, set to 12 kHz To reduce noise, set to 2 kHz	2 kHz is set prior to shipment.						
C6-07	$\gamma$ -axis voltage offset	Compensates for offset between voltage reference and actual voltage. Set in unit of 0.1% with voltage class as 100%. Set automatically by auto-tuning Do not change it unnecessarily after setting	Not initialized						
C6-11	Adaptive control selection	A function to compensate for torque accuracy according to motor parameter variation caused by heat generation at operation. <table border="1" data-bbox="565 541 873 690"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Enabled</td> </tr> </tbody> </table>	Set Value	Description	0	Disabled	1	Enabled	
Set Value	Description								
0	Disabled								
1	Enabled								
C6-12	Adaptive control compensation gain	Sets the gain for power estimated value The smaller the set value is, the greater the torque compensation that can be obtained							

## d SPEED REFERENCE-RELATED CONSTANTS

Constant No.	Name	Description	Remarks																				
d1-01	Speed reference 1	Sets speed reference	Setting unit of speed can be changed according to speed reference/monitor display unit (o1-03).																				
d1-02	Speed reference 2	[Example of multi-step speed operation]																					
d1-03	Speed reference 3	By combining multi-function input multi-step speed references 1 to 3 and jog speed reference selections, up to 9 steps can be selected																					
d1-04	Speed reference 4																						
d1-05	Speed reference 5																						
d1-06	Speed reference 6																						
d1-07	Speed reference 7																						
d1-08	Speed reference 8																						
d1-09	Jog speed reference																						
		<table border="1"> <thead> <tr> <th>Terminal Constant No</th> <th>Factory Setting</th> <th>Set Value</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>⑤ H1-03</td> <td>3 (Multi-step speed reference 1)</td> <td>3</td> <td>Multi-step speed reference 1</td> </tr> <tr> <td>⑥ H1-04</td> <td>4 (Multi-step speed reference 2)</td> <td>4</td> <td>Multi-step speed reference 2</td> </tr> <tr> <td>⑦ H1-05</td> <td>6 (Jog speed reference selection)</td> <td>5</td> <td>Multi-step speed reference 3</td> </tr> <tr> <td>⑧ H1-06</td> <td>8 (External baseblock NO)</td> <td>6</td> <td>Jog reference selection</td> </tr> </tbody> </table>	Terminal Constant No	Factory Setting	Set Value	Name	⑤ H1-03	3 (Multi-step speed reference 1)	3	Multi-step speed reference 1	⑥ H1-04	4 (Multi-step speed reference 2)	4	Multi-step speed reference 2	⑦ H1-05	6 (Jog speed reference selection)	5	Multi-step speed reference 3	⑧ H1-06	8 (External baseblock NO)	6	Jog reference selection	
Terminal Constant No	Factory Setting	Set Value	Name																				
⑤ H1-03	3 (Multi-step speed reference 1)	3	Multi-step speed reference 1																				
⑥ H1-04	4 (Multi-step speed reference 2)	4	Multi-step speed reference 2																				
⑦ H1-05	6 (Jog speed reference selection)	5	Multi-step speed reference 3																				
⑧ H1-06	8 (External baseblock NO)	6	Jog reference selection																				
		<p>The diagram shows a speed reference signal that steps up through levels 1 to 8. Each step is triggered by a specific terminal signal: FWD RUN COMMAND (terminal 1) for the start, MULTI-SPEED REF 1 (terminal 5) for step 1, MULTI-SPEED REF 2 (terminal 6) for step 2, MULTI-SPEED REF 3 (terminal 7) for step 3, and JOG REF SELECTION (terminal 8) for step 8. The signal then ramps down and returns to zero.</p>																					
		<p>*1 Master speed reference becomes constant set value (d1-01) when B1-01 = 0, and analog reference set by control terminal 13 or 14 when b1-01 = 01</p> <p>*2 Auxiliary speed reference becomes analog frequency reference input from terminal 16 when H3-05 = 00 and the constant set value (d1-02) at any setting other than H3-05 = 00 Set H3-05 to 1F when multi-function analog input (terminal 16) is not used [H3-05 constant access level A1-01 is "3" (BASIC) or "4" (ADVANCED) ]</p>																					
		<p>[Example of 3-step speed operation]</p> <p>The following shows an example of 3-step speed operation at the speed set by a constant in the inverter</p>																					
		<p>This diagram illustrates a 3-step speed operation. The speed reference signal steps up through levels d1-01, d1-02, and d1-03. Each step is initiated by a RUN/REV RUN COMMAND (terminal 1 or 2) and a corresponding MULTI-SPEED SPEED REF signal (terminal 5 for step 1, terminal 6 for step 2). The speed reference signal then ramps down and returns to zero.</p>																					

Constant No	Name	Description	Remarks						
d2-01 d2-02	Speed reference upper limit Speed reference lower limit	<ul style="list-style-type: none"> <li>Sets the upper/lower limit values of motor speed in the ratio (%) for motor max r/min (E1-06).</li> <li>When speed reference is zero and a run command is input, the motor accelerates from the min speed to the speed reference lower limit and maintains operation at the speed reference lower limit</li> </ul>							
d3-01 d3-02 d3-03 d3-04	Jump speed 1 Jump speed 2 Jump speed 3 Jump speed width	<p>Sets the jump speed width by combining d3-01 to 04. By setting jump speed to 0 (%), this function is disabled.</p> <p>d3-01 to 03—d3-04 ≤ Sets the jump speed width ≤ d3-01 to 03+d3-04</p> <p>Note Constant speed operation is prohibited in jump speed However, output speed does not jump during accel/decel and smooth accel/decel is available</p>	<ul style="list-style-type: none"> <li>When some jump speed width set by d3-01 to 04 are overlapped, be sure to set <math>d3-03 \leq d3-02 \leq d3-01</math></li> </ul>						
d4-01	Reference speed hold function selection	<p>Sets whether speed at HOLD is stored when the power supply is turned OFF or a stop command is input during HOLD by multi-function input terminal UP/DOWN commands or accel/decel stop command</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Does not store speed during HOLD (but it becomes 0)</td> </tr> <tr> <td>1</td> <td>Stores speed during HOLD and runs at stored speed at restart of operation</td> </tr> </tbody> </table>	Set Value	Description	0	Does not store speed during HOLD (but it becomes 0)	1	Stores speed during HOLD and runs at stored speed at restart of operation	
Set Value	Description								
0	Does not store speed during HOLD (but it becomes 0)								
1	Stores speed during HOLD and runs at stored speed at restart of operation								
d5-01	Torque control selection	<p>Selects speed/torque control</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Speed control method</td> </tr> <tr> <td>1</td> <td>Torque control method</td> </tr> </tbody> </table>	Set Value	Description	0	Speed control method	1	Torque control method	Torque control is enabled only when A1-02 = 06 (flux vector control)
Set Value	Description								
0	Speed control method								
1	Torque control method								
d5-02	Torque reference delay time	Sets primary delay time constant for torque reference input in torque control method in units of 1 ms							

Constant No	Name	Description	Remarks						
d5-03	Speed limit selection	<p>Selects speed limit value in the torque control method</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Speed limit becomes speed reference set by the setting of speed reference selection (b1-01).</td> </tr> <tr> <td>2</td> <td>Speed limit value becomes the set value of d5-04</td> </tr> </tbody> </table>	Set Value	Description	1	Speed limit becomes speed reference set by the setting of speed reference selection (b1-01).	2	Speed limit value becomes the set value of d5-04	
Set Value	Description								
1	Speed limit becomes speed reference set by the setting of speed reference selection (b1-01).								
2	Speed limit value becomes the set value of d5-04								
d5-04	Speed limit	Sets speed limit value in the torque control method in the ratio (%) for motor max r/min (E1-06) when d5-03 = 02							
d5-05	Speed limit bias	Sets bias value for speed limit input in the torque control mode in the ratio (%) for motor max r/min (E1-06)							
d5-06	Speed/torque control switching timer	Sets time when speed/torque control select command is input until the control method is actually changed in the units of 1 ms	Speed/torque control select is executed by multi-function input function (set value 71).						

Function	Description																																					
Torque Control Operation	<ul style="list-style-type: none"> <li>When A1-02 = 06 (flux control), torque control is enabled.</li> <li>To select torque control, set torque selection (d5-01) to 1 or close multi-function input terminal speed/torque control selection and set terminal 16 function selection to "torque reference" (H3-05 = 13)</li> </ul>																																					
	<p>[Block Diagram]</p>																																					
<p>*1 At speed limit selection (d5-03) = 01, constant set value (d5-04) becomes the speed limit when the speed reference selected by speed reference selection (b1-01) is d5-03 = 02 To input the speed limit to terminal 14, set H3-09 to "IF" (Refer to the description of H3-08 to 11)</p> <p>*2 When terminal 14 function selection is set to torque compensation (H3-09 = 14), terminal 14 input value can be used as torque compensated value (Refer to the description of H3-08 to 11)</p>																																						
<p>[Sequence]</p> <p>When torque reference &gt; 0 and speed limit &gt; 0 (winder sequence), the following sequence is performed</p> <ul style="list-style-type: none"> <li>When <math>-1 \times \text{speed limit bias (d5-05)} &lt; \text{motor speed} &lt; \text{"speed limit + d5-05"}</math> torque control is performed with the set torque reference</li> <li>When motor speed &gt; "speed limit + d5-05", the speed limiting circuit outputs minus torque reference to prevent motor speed from increasing.</li> <li>When motor speed &lt; <math>-1 \times \text{d5-05}</math>, the speed limiting circuit outputs plus torque reference to prevent motor speed from increasing to the reverse run side</li> </ul> <p>Therefore, when torque reference &gt; 0 and speed limit &gt; 0, the possible torque control range is, <math>-1 \times \text{d5-05} &lt; \text{motor speed} &lt; \text{"speed limit + d5-05"}</math></p> <p>For the detailed relation of torque reference, speed limit and motor speed, refer to the table shown below</p>																																						
<table border="1"> <thead> <tr> <th colspan="2"></th> <th colspan="2">Winding</th> <th colspan="2">Rewinding</th> </tr> </thead> <tbody> <tr> <td colspan="2">Configuration</td> <td colspan="2"> </td> <td colspan="2"> </td> </tr> <tr> <td colspan="2">Rotating Direction</td> <td>FWD run</td> <td>REV run</td> <td>FWD run</td> <td>REV run</td> </tr> <tr> <td rowspan="2">Reference Polarity</td> <td>Torque Reference (TREF)</td> <td>+</td> <td>-</td> <td>-</td> <td>+</td> </tr> <tr> <td>Speed Limit (NLIM)</td> <td>+</td> <td>-</td> <td>+</td> <td>-</td> </tr> <tr> <td colspan="2">Generated Torque*</td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>						Winding		Rewinding		Configuration						Rotating Direction		FWD run	REV run	FWD run	REV run	Reference Polarity	Torque Reference (TREF)	+	-	-	+	Speed Limit (NLIM)	+	-	+	-	Generated Torque*					
		Winding		Rewinding																																		
Configuration																																						
Rotating Direction		FWD run	REV run	FWD run	REV run																																	
Reference Polarity	Torque Reference (TREF)	+	-	-	+																																	
	Speed Limit (NLIM)	+	-	+	-																																	
Generated Torque*																																						

Function	Description																				
	<p>Note: The speed limit (NLIM) polarity of generating torque is specified according to the speed limit input polarity selected by d5-03 (speed limit selection and run command (FWD/REV)).</p> <table border="1" data-bbox="342 311 1019 482"> <thead> <tr> <th data-bbox="342 311 792 356">Speed Limit Input Polarity</th> <th data-bbox="792 311 906 356">+</th> <th data-bbox="906 311 1019 356">-</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 356 792 389">Run Command</td> <td data-bbox="792 356 906 389">+</td> <td data-bbox="906 356 1019 389">-</td> </tr> <tr> <td data-bbox="342 389 792 422">Forward run</td> <td data-bbox="792 389 906 422">+</td> <td data-bbox="906 389 1019 422">-</td> </tr> <tr> <td data-bbox="342 422 792 482">Reverse run</td> <td data-bbox="792 422 906 482">-</td> <td data-bbox="906 422 1019 482">+</td> </tr> </tbody> </table>	Speed Limit Input Polarity	+	-	Run Command	+	-	Forward run	+	-	Reverse run	-	+								
Speed Limit Input Polarity	+	-																			
Run Command	+	-																			
Forward run	+	-																			
Reverse run	-	+																			
Speed / Torque Control Switching	<p>When A1-02 = 06 (flux control). Speed control or torque control can be selected during run by using the multi-function input speed/torque control select command (set value = 71). The following shows an example of selection</p> <p>[Constant Setting]</p> <table border="1" data-bbox="342 632 1414 880"> <thead> <tr> <th data-bbox="342 632 456 710">Terminal No</th> <th data-bbox="456 632 602 710">Constant No</th> <th data-bbox="602 632 773 710">Factory Setting</th> <th data-bbox="773 632 919 710">Set Value</th> <th data-bbox="919 632 1414 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 710 456 765">8</td> <td data-bbox="456 710 602 765">H1-06</td> <td data-bbox="602 710 773 765">8</td> <td data-bbox="773 710 919 765">71</td> <td data-bbox="919 710 1414 765">Speed/torque control select</td> </tr> <tr> <td data-bbox="342 765 456 831">13</td> <td data-bbox="456 765 602 831">b1-01 d5-03</td> <td data-bbox="602 765 773 831">1 1</td> <td data-bbox="773 765 919 831">1 1</td> <td data-bbox="919 765 1414 831">Speed reference selection (terminals 13, 14) Speed limit selection (terminals 13, 14)</td> </tr> <tr> <td data-bbox="342 831 456 880">16</td> <td data-bbox="456 831 602 880">H3-05</td> <td data-bbox="602 831 773 880">1</td> <td data-bbox="773 831 919 880">13</td> <td data-bbox="919 831 1414 880">Torque reference/speed limit</td> </tr> </tbody> </table> <p>[Time Chart]</p> <p>[Sequence]</p> <ol style="list-style-type: none"> <li>① When torque/speed control select command is "OPEN", speed control is performed       <ul style="list-style-type: none"> <li>• Speed reference at speed control depends on speed reference selection (b1-01) setting. To change terminal 13 or 14 master speed reference to speed reference, set b1-01 to 01</li> <li>• Torque limit at speed control is the smaller absolute value of terminal 16 torque limit or constant set values (L7-01 to 04)</li> <li>• When a stop command is input during speed control, speed control is maintained and the smaller absolute value of terminal 16 torque limit or constant set values (L7-01 to 04), is used as torque limit. Then the motor decelerates to a stop</li> </ul> </li> <li>② When torque/speed control select command is "CLOSED", torque control is performed       <ul style="list-style-type: none"> <li>• Speed limit under torque control uses terminal 13 or 14 master speed reference as frequency reference when speed limit selection (d5-03) = 01 and as constant set value (d5-04) when d5-03 = 02, disregarding speed reference selection (b1-01) setting</li> <li>• During torque control, terminal 16 analog input value becomes torque reference</li> </ul> </li> <li>③ By inputting a stop command during torque control, it is changed to speed control automatically, and the motor decelerates to a stop. Torque limit during deceleration to a stop becomes constant set value (L7-01 to 04).</li> </ol> <p>Note: Actual control mode is changed after the torque /speed control select command is changed and the speed/torque select timer (d5-06) elapses. Terminal 13 speed reference/speed limit and terminal 16 torque limit/torque reference are held in the inverter until the time set to d5-06 elapses</p>	Terminal No	Constant No	Factory Setting	Set Value	Description	8	H1-06	8	71	Speed/torque control select	13	b1-01 d5-03	1 1	1 1	Speed reference selection (terminals 13, 14) Speed limit selection (terminals 13, 14)	16	H3-05	1	13	Torque reference/speed limit
Terminal No	Constant No	Factory Setting	Set Value	Description																	
8	H1-06	8	71	Speed/torque control select																	
13	b1-01 d5-03	1 1	1 1	Speed reference selection (terminals 13, 14) Speed limit selection (terminals 13, 14)																	
16	H3-05	1	13	Torque reference/speed limit																	

## E MOTOR-RELATED CONSTANTS

Constant No	Name	Description	Remarks
E1-01	Input voltage setting	Sets inverter input voltage in units of 1V	The value for 400 V class will be twice as large as that for 200 V class
E1-02	Motor capacity selection	Sets motor capacity. Motor constants are set automatically by this constant setting Do not change it unnecessarily after setting Motor constants will be initialized.	Refer to Par 2.7.
E1-03	Motor rated voltage	Sets motor rated voltage in units of 0.1 V	
E1-04	Motor rated current	Sets motor rated current in units of 0.01A for motor capacity of 7.5 kW or less or in units of 0.1 A for 11 kW or more	
E1-05	Number of motor poles	Sets the number of motor poles	2, 4, 6 or 8 poles can be selected
E1-06	Motor max. r/min	Sets the motor maximum r/min in units of 1 (r/min)	100% reference of speed
E1-07	Motor base r/min	Sets the motor base r/min in units of 1 (r/min)	
E1-08	Motor min. r/min	Sets operable motor minimum r/min in units of 1 (r/min)	
E1-09	Motor armature resistance	Sets resistance per motor phase in units of 0.001 Ω Set automatically by auto-tuning Do not change unnecessarily after setting	
E1-10	Motor d-axis inductance	Sets motor d-axis inductance in units of 0.01 mH Set automatically by auto-tuning Do not change unnecessarily after setting	
E1-11	Motor q-axis inductance	Sets q-axis inductance at motor rated load in units of 0.01 mH	
E1-13	Induced voltage	Sets wave height value of induced voltage per motor phase in units of 0.1 mV/(rad/s) [electrical angle] Set automatically by auto-tuning Do not change unnecessarily after setting	
E1-14	Variable torque/constant torque selection	Selects whether variable torque motor or constant torque motor is to be used This constant matches the motor overload protective characteristics to the motor overload resistance	
E1-15	Motor mechanical loss	Sets motor mechanical loss in units of 0.1% Motor rated output is 100%	
E1-16	Motor wiring resistance	Sets wiring resistance between the inverter and the motor according to percent of inverter rated voltage. $R_{feed}\% = \frac{R_f \times I_m}{\frac{V_b}{\sqrt{3}}} \times 100$ R <sub>f</sub> : feeder resistance (Ω) I <sub>m</sub> : Rated current (E1-04) (A) V <sub>d</sub> : Rated voltage (E1-03) (V)	

Note. E constants cannot be initialized.

## F OPTION-RELATED CONSTANTS

Constant No	Name	Description	Remarks										
F1-01	PG constants	Sets the number of pulses of PG (pulse generator) to be used. The set value is the number of pulses per motor revolution (pulses/rev)											
F1-02	Operation selection at PG open-circuit (PGO) detection	<p>Sets the stopping method at PG disconnected detection.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Deceleration to stop (deceleration time C1-02)</td> </tr> <tr> <td>1</td> <td>Coasting to stop</td> </tr> <tr> <td>2</td> <td>Emergency stop (deceleration time C1-09)</td> </tr> <tr> <td>3</td> <td>Continuous operation (displayed only)</td> </tr> </tbody> </table>	Set Value	Description	0	Deceleration to stop (deceleration time C1-02)	1	Coasting to stop	2	Emergency stop (deceleration time C1-09)	3	Continuous operation (displayed only)	
Set Value	Description												
0	Deceleration to stop (deceleration time C1-02)												
1	Coasting to stop												
2	Emergency stop (deceleration time C1-09)												
3	Continuous operation (displayed only)												
F1-03	Operation selection at overspeed (OS) detection	<p>Sets the stopping method at overspeed detection</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Deceleration to stop (deceleration time C1-02)</td> </tr> <tr> <td>1</td> <td>Coasting to stop</td> </tr> <tr> <td>2</td> <td>Emergency stop (deceleration time C1-09)</td> </tr> <tr> <td>3</td> <td>Continuous operation (displayed only)</td> </tr> </tbody> </table>	Set Value	Description	0	Deceleration to stop (deceleration time C1-02)	1	Coasting to stop	2	Emergency stop (deceleration time C1-09)	3	Continuous operation (displayed only)	
Set Value	Description												
0	Deceleration to stop (deceleration time C1-02)												
1	Coasting to stop												
2	Emergency stop (deceleration time C1-09)												
3	Continuous operation (displayed only)												
F1-04	Operation selection at deviation (DEV) detection	<p>Sets the stopping method at excessive speed deviation detected</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Deceleration to stop (deceleration time C1-02)</td> </tr> <tr> <td>1</td> <td>Coasting to stop</td> </tr> <tr> <td>2</td> <td>Emergency stop (deceleration time C1-09)</td> </tr> <tr> <td>3</td> <td>Continuous operation (displayed only)</td> </tr> </tbody> </table>	Set Value	Description	0	Deceleration to stop (deceleration time C1-02)	1	Coasting to stop	2	Emergency stop (deceleration time C1-09)	3	Continuous operation (displayed only)	
Set Value	Description												
0	Deceleration to stop (deceleration time C1-02)												
1	Coasting to stop												
2	Emergency stop (deceleration time C1-09)												
3	Continuous operation (displayed only)												
F1-05	PG rotation detection	<p>Sets the relation between the motor rotating direction and PG polarity</p> <p>0: Phase A advanced in motor FWD rotation            1: Phase A advanced in motor REV rotation</p>	<ul style="list-style-type: none"> <li>Motor FWD rotation is in the counterclockwise (CCW) direction viewed from the load side</li> </ul>										



Constant No	Name	Description	Remarks
F1-08	Overspeed (OS) detection level	Sets the motor overspeed detection level in the ratio (%) for E1-06 (motor max r/min).	<ul style="list-style-type: none"> <li>Stopping method at overspeed detection depends on the setting of F1-03.</li> </ul>
F1-09	Overspeed (OS) detection delay time	<p>Sets the time from when overspeed is detected to when it is regarded as a fault</p> <p>A fault signal is output to stop operation after the absolute value of motor speed exceeds the set value of F1-08 and the time set to F1-09 elapses</p>	
F1-10	Speed deviation (DEV) detection level	Sets the excessive speed deviation detection level in the ratio (%) for E1-06 (motor max. r/min)	<ul style="list-style-type: none"> <li>Stopping method at excessive speed deviation detection depends on the setting of F1-04</li> <li>This is not detected during accel/decel or torque control</li> </ul>
F1-11	Speed deviation (DEV) detection delay time	<p>Sets the time from when excessive speed deviation is detected to when it is regarded as a fault.</p> <p>A fault signal is output to stop operation after deviation between speed reference and motor speed exceeds the set value of F1-10 and the time set to F1-11 elapses.</p>	
F1-13	PG open-circuit (PGO) detection delay time	Sets the time from when PG open-circuit is detected to when it is regarded as a fault.	<ul style="list-style-type: none"> <li>Stopping method at detection of PG open-circuit depends on F1-03 setting.</li> </ul>



Constant No.	Name	Description	Remarks															
F2-01	AI-14B input function selection	<p>Selects CH1 to 3 input functions when AI-14B (optional) is connected</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Function</th> <th>CH1 (TC1-TC4)</th> <th>CH2 (TC2-TC4)</th> <th>CH3 (TC3-TC4)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3CH individual input</td> <td>Substitute for terminals 13-17</td> <td>Substitute for terminals 14-17</td> <td>Substitute for terminals 16-17</td> </tr> <tr> <td>1</td> <td>3CH addition input</td> <td colspan="3">Sum of CH1 to 3 input values is regarded as a speed reference value</td> </tr> </tbody> </table> <p>Sets b1-01 to 01 (speed reference from control circuit terminal) when 3CH individual input is used</p>	Set Value	Function	CH1 (TC1-TC4)	CH2 (TC2-TC4)	CH3 (TC3-TC4)	0	3CH individual input	Substitute for terminals 13-17	Substitute for terminals 14-17	Substitute for terminals 16-17	1	3CH addition input	Sum of CH1 to 3 input values is regarded as a speed reference value			The function of multi-function input (option/inverter reference selection) (set value 02) is disabled
Set Value	Function	CH1 (TC1-TC4)	CH2 (TC2-TC4)	CH3 (TC3-TC4)														
0	3CH individual input	Substitute for terminals 13-17	Substitute for terminals 14-17	Substitute for terminals 16-17														
1	3CH addition input	Sum of CH1 to 3 input values is regarded as a speed reference value																
F3-01	DI-08, DI-16H2 speed reference setting selection	<p>Selects the setting mode of frequency reference input from DI-08 (optional) or DI-16H2 (optional).</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Speed Reference Setting Mode</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>BCD 1% unit *</td> </tr> <tr> <td>1</td> <td>BCD 0.1% unit *</td> </tr> <tr> <td>2</td> <td>BCD 0.01% unit *</td> </tr> <tr> <td>3 to 6</td> <td>Not used</td> </tr> <tr> <td>7</td> <td>Binary DI-08 255/100% DI-16H2, 12-bit selection 4096/100% DI-16H2, 16-bit selection. 30000/100%</td> </tr> </tbody> </table>	Set Value	Speed Reference Setting Mode	0	BCD 1% unit *	1	BCD 0.1% unit *	2	BCD 0.01% unit *	3 to 6	Not used	7	Binary DI-08 255/100% DI-16H2, 12-bit selection 4096/100% DI-16H2, 16-bit selection. 30000/100%	*: When o1-03 is set to 2 or more, the BCD setting unit becomes the o1-03 setting unit			
Set Value	Speed Reference Setting Mode																	
0	BCD 1% unit *																	
1	BCD 0.1% unit *																	
2	BCD 0.01% unit *																	
3 to 6	Not used																	
7	Binary DI-08 255/100% DI-16H2, 12-bit selection 4096/100% DI-16H2, 16-bit selection. 30000/100%																	
F4-01	AO-08, 12 CH1 output item selection	<p>Selects item to be output to AO-08 (optional) and AO-12 (optional) and sets output gain and output bias</p> <p>Set the monitor number (U1-XX) to be output</p> <p>For calculation of output level and output bias, convert the monitor item output level into 30000/100%, and subtract the output bias set value from the converted value and multiply it with output gain This calculated value is output to AO-08 or AO-12 channel as 10 V/30000</p> <p>The following diagram shows this calculation</p> <p>(Constants in parentheses indicate channel 2)</p>																
F4-02	CH1 output gain																	
F4-03	CH1 output bias																	
F4-04	CH2 output item selection																	
F4-05	CH2 output gain																	
F4-06	CH2 output bias																	
F5-01	DO-02C CH1 output selection	<p>Sets multi-function output items to be output to DO-02C (optional)</p> <p>For the selecting method of output items, refer to H2-01 to H2-03</p>																
F5-02	CH2 output selection																	


Constant No.	Name	Description	Remarks																																																																																		
F6-01	DO-08 Output mode selection	<p>The following table outlines items to be output from DO-08 (optional) according to F6-01 setting</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th colspan="2">Output Contents</th> </tr> </thead> <tbody> <tr> <td rowspan="9">0</td> <td>Terminal No.</td> <td>Output Contents</td> </tr> <tr> <td>TD5-TD11</td> <td>Overcurrent (SC, OC, GF)</td> </tr> <tr> <td>TD6-TD11</td> <td>Overvoltage (OV)</td> </tr> <tr> <td>TD7-TD11</td> <td>Inverter overload (OL2)</td> </tr> <tr> <td>TD8-TD11</td> <td>Fuse blown (PUF)</td> </tr> <tr> <td>TD9-TD11</td> <td>Overspeed (OS)</td> </tr> <tr> <td>TD10-TD11</td> <td>Inverter overheat (OH1) or motor overlord (OL1)</td> </tr> <tr> <td>TD1-TD2</td> <td>During zero-speed detection</td> </tr> <tr> <td>TD3-TD4</td> <td>During speed agree</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Terminal No</th> <th colspan="2">Output Contents</th> </tr> </thead> <tbody> <tr> <td>TD5-TD11</td> <td>bit0</td> <td rowspan="4">Sign output (See the table below)</td> </tr> <tr> <td>TD6-TD11</td> <td>bit1</td> </tr> <tr> <td>TD7-TD11</td> <td>bit2</td> </tr> <tr> <td>TD8-TD11</td> <td>bit3</td> </tr> <tr> <td>TD9-TD11</td> <td colspan="2">During zero-speed detection</td> </tr> <tr> <td>TD10-TD11</td> <td colspan="2">During speed agree</td> </tr> <tr> <td>TD1-TD2</td> <td colspan="2">During run</td> </tr> <tr> <td>TD3-TD4</td> <td colspan="2">Minor fault</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>bit 3210</th> <th>Output Contents</th> <th>bit 3210</th> <th>Output Contents</th> </tr> </thead> <tbody> <tr> <td>0000</td> <td>No fault</td> <td>1000</td> <td>External fault (EFxx)</td> </tr> <tr> <td>0001</td> <td>Overcurrent (SC, OC, GF)</td> <td>1001</td> <td>Controller fault (CPUxx)</td> </tr> <tr> <td>0010</td> <td>Overvoltage (OV)</td> <td>1010</td> <td>Motor overload (OL1)</td> </tr> <tr> <td>0011</td> <td>Inverter overlord (OL2)</td> <td>1011</td> <td>Hunting (STO)</td> </tr> <tr> <td>0100</td> <td>Inverter overheat (OH, OH1)</td> <td>1100</td> <td>Power loss (UV1, UV2, UV3)</td> </tr> <tr> <td>0101</td> <td>Overspeed (OS)</td> <td>1101</td> <td>Speed deviation (DEV), Z-phase pulse error (ZDEV)</td> </tr> <tr> <td>0110</td> <td>Fuse blown (PUF)</td> <td>1110</td> <td>PG open-circuit (PGO)</td> </tr> <tr> <td>0111</td> <td>Braking resistor unit overheat (RH), braking transistor error (RR)</td> <td>1111</td> <td>Not used</td> </tr> </tbody> </table>	Set Value	Output Contents		0	Terminal No.	Output Contents	TD5-TD11	Overcurrent (SC, OC, GF)	TD6-TD11	Overvoltage (OV)	TD7-TD11	Inverter overload (OL2)	TD8-TD11	Fuse blown (PUF)	TD9-TD11	Overspeed (OS)	TD10-TD11	Inverter overheat (OH1) or motor overlord (OL1)	TD1-TD2	During zero-speed detection	TD3-TD4	During speed agree	Terminal No	Output Contents		TD5-TD11	bit0	Sign output (See the table below)	TD6-TD11	bit1	TD7-TD11	bit2	TD8-TD11	bit3	TD9-TD11	During zero-speed detection		TD10-TD11	During speed agree		TD1-TD2	During run		TD3-TD4	Minor fault		bit 3210	Output Contents	bit 3210	Output Contents	0000	No fault	1000	External fault (EFxx)	0001	Overcurrent (SC, OC, GF)	1001	Controller fault (CPUxx)	0010	Overvoltage (OV)	1010	Motor overload (OL1)	0011	Inverter overlord (OL2)	1011	Hunting (STO)	0100	Inverter overheat (OH, OH1)	1100	Power loss (UV1, UV2, UV3)	0101	Overspeed (OS)	1101	Speed deviation (DEV), Z-phase pulse error (ZDEV)	0110	Fuse blown (PUF)	1110	PG open-circuit (PGO)	0111	Braking resistor unit overheat (RH), braking transistor error (RR)	1111	Not used	
Set Value	Output Contents																																																																																				
0	Terminal No.	Output Contents																																																																																			
	TD5-TD11	Overcurrent (SC, OC, GF)																																																																																			
	TD6-TD11	Overvoltage (OV)																																																																																			
	TD7-TD11	Inverter overload (OL2)																																																																																			
	TD8-TD11	Fuse blown (PUF)																																																																																			
	TD9-TD11	Overspeed (OS)																																																																																			
	TD10-TD11	Inverter overheat (OH1) or motor overlord (OL1)																																																																																			
	TD1-TD2	During zero-speed detection																																																																																			
	TD3-TD4	During speed agree																																																																																			
Terminal No	Output Contents																																																																																				
TD5-TD11	bit0	Sign output (See the table below)																																																																																			
TD6-TD11	bit1																																																																																				
TD7-TD11	bit2																																																																																				
TD8-TD11	bit3																																																																																				
TD9-TD11	During zero-speed detection																																																																																				
TD10-TD11	During speed agree																																																																																				
TD1-TD2	During run																																																																																				
TD3-TD4	Minor fault																																																																																				
bit 3210	Output Contents	bit 3210	Output Contents																																																																																		
0000	No fault	1000	External fault (EFxx)																																																																																		
0001	Overcurrent (SC, OC, GF)	1001	Controller fault (CPUxx)																																																																																		
0010	Overvoltage (OV)	1010	Motor overload (OL1)																																																																																		
0011	Inverter overlord (OL2)	1011	Hunting (STO)																																																																																		
0100	Inverter overheat (OH, OH1)	1100	Power loss (UV1, UV2, UV3)																																																																																		
0101	Overspeed (OS)	1101	Speed deviation (DEV), Z-phase pulse error (ZDEV)																																																																																		
0110	Fuse blown (PUF)	1110	PG open-circuit (PGO)																																																																																		
0111	Braking resistor unit overheat (RH), braking transistor error (RR)	1111	Not used																																																																																		


Constant No	Name	Description	Remarks										
F9-01	Input level of external fault from transmission option	<p>Sets the level to detect an external fault from a transmission option</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Detected by NO contact</td> </tr> <tr> <td>1</td> <td>Detected by NC contact</td> </tr> </tbody> </table>	Set Value	Description	0	Detected by NO contact	1	Detected by NC contact					
Set Value	Description												
0	Detected by NO contact												
1	Detected by NC contact												
F9-02	External fault from transmission option	<p>Specifies the detection timing of an external fault from a transmission option.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Always detected</td> </tr> <tr> <td>1</td> <td>Detected during running</td> </tr> </tbody> </table>	Set Value	Description	0	Always detected	1	Detected during running					
Set Value	Description												
0	Always detected												
1	Detected during running												
F9-03	Operation at external fault input from transmission option	<p>Sets the stopping method at external fault input from a transmission option</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ramp to stop</td> </tr> <tr> <td>1</td> <td>Coast to a stop</td> </tr> <tr> <td>2</td> <td>Emergency stop</td> </tr> <tr> <td>3</td> <td>Continue operation</td> </tr> </tbody> </table>	Set Value	Description	0	Ramp to stop	1	Coast to a stop	2	Emergency stop	3	Continue operation	
Set Value	Description												
0	Ramp to stop												
1	Coast to a stop												
2	Emergency stop												
3	Continue operation												
F9-04	Trace sampling-time of transmission option	<p>Sets the sampling cycle of the inverter trace function - Setting it to 0 executes trace at every scan (processing basic cycle of transmission option) Setting it to N executes trace once at N scan.</p>											
F9-05	Torque reference selection of transmission option	<p>Selects whether torque reference (torque limit at speed control) from a transmission option is to be enabled or disabled</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Torque reference (limit) from transmission option disabled Inverter torque reference (limit) enabled.</td> </tr> <tr> <td>1</td> <td>Torque reference (limit) from transmission option enabled Set control reference item No. 3 to the reference value.</td> </tr> </tbody> </table>	Set Value	Description	0	Torque reference (limit) from transmission option disabled Inverter torque reference (limit) enabled.	1	Torque reference (limit) from transmission option enabled Set control reference item No. 3 to the reference value.					
Set Value	Description												
0	Torque reference (limit) from transmission option disabled Inverter torque reference (limit) enabled.												
1	Torque reference (limit) from transmission option enabled Set control reference item No. 3 to the reference value.												
F9-06	Operation selection at BUS error detection	<p>Sets the stopping method at BUS error detection from a transmission option</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ramp to stop</td> </tr> <tr> <td>1</td> <td>Coast to a stop</td> </tr> <tr> <td>2</td> <td>Emergency stop</td> </tr> <tr> <td>3</td> <td>Continue operation</td> </tr> </tbody> </table>	Set Value	Description	0	Ramp to stop	1	Coast to a stop	2	Emergency stop	3	Continue operation	
Set Value	Description												
0	Ramp to stop												
1	Coast to a stop												
2	Emergency stop												
3	Continue operation												

## H CONTROL CIRCUIT TERMINAL-RELATED CONSTANTS

Constant No	Name	Description																																																																																																																																																																																																																																		
	Multi-function input terminal function selection	Selects the function of a signal input form control circuit terminals 3 to 8																																																																																																																																																																																																																																		
H1-01	Multi-function input (terminal 3-11)																																																																																																																																																																																																																																			
H1-02	Multi-function input (terminal 4-11)																																																																																																																																																																																																																																			
H1-03	Multi-function input (terminal 5-11)																																																																																																																																																																																																																																			
H1-04	Multi-function input (terminal 6-11)																																																																																																																																																																																																																																			
H1-05	Multi-function input (terminal 7-11)																																																																																																																																																																																																																																			
H1-06	Multi-function input (terminal 8-11)																																																																																																																																																																																																																																			
			<table border="1"> <thead> <tr> <th>Set Value</th> <th>Function</th> <th>Open Loop Vector</th> <th>Flux Vector</th> <th>Reference Page</th> </tr> </thead> <tbody> <tr><td>00</td><td>3-wire sequence FWD/REV run selection</td><td>○</td><td>○</td><td>60</td></tr> <tr><td>01</td><td>LOCAL/REMOTE selection</td><td>○</td><td>○</td><td>60</td></tr> <tr><td>02</td><td>Option/Inverter selection</td><td>○</td><td>○</td><td>60</td></tr> <tr><td>03</td><td>Multi-step speed reference 1</td><td>○</td><td>○</td><td>48</td></tr> <tr><td>04</td><td>Multi-step speed reference 2</td><td>○</td><td>○</td><td>48</td></tr> <tr><td>05</td><td>Multi-step speed reference 3</td><td>○</td><td>○</td><td>48</td></tr> <tr><td>06</td><td>Jog speed reference</td><td>○</td><td>○</td><td>48</td></tr> <tr><td>07</td><td>Accel/decel time selection 1</td><td>○</td><td>○</td><td>44</td></tr> <tr><td>08</td><td>External baseblock/NO contact</td><td>○</td><td>○</td><td>60</td></tr> <tr><td>09</td><td>External baseblock/NC contact</td><td>○</td><td>○</td><td>61</td></tr> <tr><td>0A</td><td>Accel/decel stop</td><td>○</td><td>○</td><td>61</td></tr> <tr><td>0B</td><td>Inverter overheat prediction (OH2)</td><td>○</td><td>○</td><td>61</td></tr> <tr><td>0C</td><td>Multi-function analog input enable/disable</td><td>○</td><td>○</td><td>61</td></tr> <tr><td>0D</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>0E</td><td>Speed control integral reset</td><td>○</td><td>○</td><td>61</td></tr> <tr><td>0F</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>10</td><td>UP command</td><td>○</td><td>○</td><td>62</td></tr> <tr><td>11</td><td>DOWN command</td><td>○</td><td>○</td><td>62</td></tr> <tr><td>12</td><td>FJOG command (FWD jog run)</td><td>○</td><td>○</td><td>63</td></tr> <tr><td>13</td><td>RJOG command (REV jog run)</td><td>○</td><td>○</td><td>63</td></tr> <tr><td>14</td><td>Fault reset</td><td>○</td><td>○</td><td>63</td></tr> <tr><td>15</td><td>Emergency stop</td><td>○</td><td>○</td><td>44</td></tr> <tr><td>16</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>17</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>18</td><td>ON-delay, OFF-delay timer input</td><td>○</td><td>○</td><td>41</td></tr> <tr><td>19</td><td>PID control cancel</td><td>○</td><td>○</td><td>41</td></tr> <tr><td>1A</td><td>Accel/decel time selection 2</td><td>○</td><td>○</td><td>44</td></tr> <tr><td>1B</td><td>Constant write-in prohibition</td><td>○</td><td>○</td><td>63</td></tr> <tr><td>1C</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>1D</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>1E</td><td>Analog speed reference sample/hold</td><td>○</td><td>○</td><td>—</td></tr> <tr><td>1F</td><td>Terminal 13/14 selection</td><td>○</td><td>○</td><td>63</td></tr> <tr><td>20 to 2F</td><td>External fault</td><td>○</td><td>○</td><td>64</td></tr> <tr><td>30</td><td>PID control integral reset</td><td>○</td><td>○</td><td>64</td></tr> <tr><td>60</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>61</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>62</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>63</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>64</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>65</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>66</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>71</td><td>Speed/torque control selection</td><td>×</td><td>○</td><td>52</td></tr> <tr><td>72</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>77</td><td>Speed control proportional gain selection</td><td>○</td><td>○</td><td>47</td></tr> </tbody> </table>	Set Value	Function	Open Loop Vector	Flux Vector	Reference Page	00	3-wire sequence FWD/REV run selection	○	○	60	01	LOCAL/REMOTE selection	○	○	60	02	Option/Inverter selection	○	○	60	03	Multi-step speed reference 1	○	○	48	04	Multi-step speed reference 2	○	○	48	05	Multi-step speed reference 3	○	○	48	06	Jog speed reference	○	○	48	07	Accel/decel time selection 1	○	○	44	08	External baseblock/NO contact	○	○	60	09	External baseblock/NC contact	○	○	61	0A	Accel/decel stop	○	○	61	0B	Inverter overheat prediction (OH2)	○	○	61	0C	Multi-function analog input enable/disable	○	○	61	0D	Not used	—	—	—	0E	Speed control integral reset	○	○	61	0F	Not used	—	—	—	10	UP command	○	○	62	11	DOWN command	○	○	62	12	FJOG command (FWD jog run)	○	○	63	13	RJOG command (REV jog run)	○	○	63	14	Fault reset	○	○	63	15	Emergency stop	○	○	44	16	Not used	—	—	—	17	Not used	—	—	—	18	ON-delay, OFF-delay timer input	○	○	41	19	PID control cancel	○	○	41	1A	Accel/decel time selection 2	○	○	44	1B	Constant write-in prohibition	○	○	63	1C	Not used	—	—	—	1D	Not used	—	—	—	1E	Analog speed reference sample/hold	○	○	—	1F	Terminal 13/14 selection	○	○	63	20 to 2F	External fault	○	○	64	30	PID control integral reset	○	○	64	60	Not used	—	—	—	61	Not used	—	—	—	62	Not used	—	—	—	63	Not used	—	—	—	64	Not used	—	—	—	65	Not used	—	—	—	66	Not used	—	—	—	71	Speed/torque control selection	×	○	52	72	Not used	—	—	—	77	Speed control proportional gain selection	○	○	47
Set Value	Function		Open Loop Vector	Flux Vector	Reference Page																																																																																																																																																																																																																															
00	3-wire sequence FWD/REV run selection		○	○	60																																																																																																																																																																																																																															
01	LOCAL/REMOTE selection		○	○	60																																																																																																																																																																																																																															
02	Option/Inverter selection		○	○	60																																																																																																																																																																																																																															
03	Multi-step speed reference 1		○	○	48																																																																																																																																																																																																																															
04	Multi-step speed reference 2		○	○	48																																																																																																																																																																																																																															
05	Multi-step speed reference 3		○	○	48																																																																																																																																																																																																																															
06	Jog speed reference		○	○	48																																																																																																																																																																																																																															
07	Accel/decel time selection 1		○	○	44																																																																																																																																																																																																																															
08	External baseblock/NO contact		○	○	60																																																																																																																																																																																																																															
09	External baseblock/NC contact		○	○	61																																																																																																																																																																																																																															
0A	Accel/decel stop		○	○	61																																																																																																																																																																																																																															
0B	Inverter overheat prediction (OH2)		○	○	61																																																																																																																																																																																																																															
0C	Multi-function analog input enable/disable		○	○	61																																																																																																																																																																																																																															
0D	Not used		—	—	—																																																																																																																																																																																																																															
0E	Speed control integral reset		○	○	61																																																																																																																																																																																																																															
0F	Not used		—	—	—																																																																																																																																																																																																																															
10	UP command		○	○	62																																																																																																																																																																																																																															
11	DOWN command		○	○	62																																																																																																																																																																																																																															
12	FJOG command (FWD jog run)	○	○	63																																																																																																																																																																																																																																
13	RJOG command (REV jog run)	○	○	63																																																																																																																																																																																																																																
14	Fault reset	○	○	63																																																																																																																																																																																																																																
15	Emergency stop	○	○	44																																																																																																																																																																																																																																
16	Not used	—	—	—																																																																																																																																																																																																																																
17	Not used	—	—	—																																																																																																																																																																																																																																
18	ON-delay, OFF-delay timer input	○	○	41																																																																																																																																																																																																																																
19	PID control cancel	○	○	41																																																																																																																																																																																																																																
1A	Accel/decel time selection 2	○	○	44																																																																																																																																																																																																																																
1B	Constant write-in prohibition	○	○	63																																																																																																																																																																																																																																
1C	Not used	—	—	—																																																																																																																																																																																																																																
1D	Not used	—	—	—																																																																																																																																																																																																																																
1E	Analog speed reference sample/hold	○	○	—																																																																																																																																																																																																																																
1F	Terminal 13/14 selection	○	○	63																																																																																																																																																																																																																																
20 to 2F	External fault	○	○	64																																																																																																																																																																																																																																
30	PID control integral reset	○	○	64																																																																																																																																																																																																																																
60	Not used	—	—	—																																																																																																																																																																																																																																
61	Not used	—	—	—																																																																																																																																																																																																																																
62	Not used	—	—	—																																																																																																																																																																																																																																
63	Not used	—	—	—																																																																																																																																																																																																																																
64	Not used	—	—	—																																																																																																																																																																																																																																
65	Not used	—	—	—																																																																																																																																																																																																																																
66	Not used	—	—	—																																																																																																																																																																																																																																
71	Speed/torque control selection	×	○	52																																																																																																																																																																																																																																
72	Not used	—	—	—																																																																																																																																																																																																																																
77	Speed control proportional gain selection	○	○	47																																																																																																																																																																																																																																

Set Value	Description
00	<p>• 3-wire sequence</p> <p>When 00 is set to HI-01 to 06, 3-wire sequence is entered</p> <p>The terminal having set value of 00 becomes a FWD/REV run command</p> <p>(Typical Setting)</p> <p>H1-03=00</p>  <p>The following shows the time chart</p> 
01	<p>• LOCAL/REMOTE selection</p> <p>Operation signal selection is effective only during stop</p> <p>Open Runs according to the setting of b1-01 or b1-02 in the remote mode</p> <p>Closed Runs by digital operator speed reference or run command in the local mode</p> <p>Note When local/remote selection is set by multi-function input terminal, digital operator local/remote selection becomes invalid</p>
02	<p>• Option/Inverter selection</p> <p>Selects whether operation is performed with option card reference or inverter reference Option/inverter selection is effective only during stop</p> <p>Open: Runs by speed reference and run command from inverter control circuit terminal or digital operator.</p> <p>Closed. Runs by speed reference and run command from option card.</p>
08	<p>• External baseblock</p> <p>Baseblock operation is performed at "closed" External baseblock operation differs as described below, depending on the run-command input status</p> <p>When an external baseblock signal is input during run, bb blinks on the digital operator to shut OFF inverter output</p> <p>When the external baseblock signal is removed, operation restarts with the speed reference obtained before baseblock</p> <p>When a stop signal is input and an external baseblock signal is input while the inverter is decelerating, bb blinks on the digital operator and the inverter output is shut OFF to stop the operation</p> <p>At open loop vector control, releasing bb during coasting drives may cause OC (overcurrent) or OV (overvoltage).</p> <p>In this case, do not release bb until the motor stops</p>

Set Value	Description
09	<ul style="list-style-type: none"> <li>External baseblock</li> </ul> <p>Baseblock is performed at "open" The other sequence is the same as that of set value 08</p>
0A	<ul style="list-style-type: none"> <li>Accel/decel stop (HOLD) command</li> </ul> <p>Accel/decel is stopped while an accel/decel stop command is input, and the current motor speed is held. When a stop command is input, the accel/decel stop status is released to stop operation The following shows the time chart</p>  <p>Note · When d4-01 is set to 1 and accel/decel stop command is input, by inputting a run command again after a stop command is input, the held motor speed is stored unless the accel/decel stop command is released. Therefore, operation is performed at the stored motor speed</p> <p>When the power supply is turned OFF in the status where the accel/decel stop command is input, the held motor speed is still stored</p> <p>When d4-01 is set to 0, the held motor speed is not stored</p>
0B	<ul style="list-style-type: none"> <li>Inverter overheat prediction (OH2)</li> </ul> <p>While the inverter overheat prediction signal is input, only OH2 is displayed, blinking, on the digital operator Used for monitoring inverter ambient temperature</p>
0C	<ul style="list-style-type: none"> <li>Multi-function analog input enable/disable</li> </ul> <p>When this function is selected for multi-function terminal, the functions set to multi-function analog input have the following limitation</p> <p>Open. Multi-function analog input is not accepted.</p> <p>Closed. Multi-function analog input is accepted</p>
0E	<ul style="list-style-type: none"> <li>Speed control integral value reset</li> </ul> <p>Speed control integral value reset is enabled even during running</p> <p>Open. PI-control (Speed control integral values are added.)</p> <p>Closed. P-control (Speed control integral values are reset by integral time constant )</p>


Set Value	Description															
10,11	<p>• UP/DOWN commands</p> <p>By inputting UP and DOWN signals, accel/decel can be performed for operation at an aimed speed without changing speed reference while a FWD(REV) run command is input</p> <p>Set value = 10 UP signal</p> <p>Set value = 11 DOWN signal</p> <table border="1" data-bbox="440 422 1089 570"> <tr> <td>UP Command</td> <td>Closed</td> <td>Open</td> <td>Open</td> <td>Closed</td> </tr> <tr> <td>DOWN Command</td> <td>Open</td> <td>Closed</td> <td>Open</td> <td>Closed</td> </tr> <tr> <td>Status</td> <td>Accel</td> <td>Decel</td> <td>HOLD</td> <td>HOLD</td> </tr> </table> <p>The following shows the time chart where UP/DOWN commands are used</p>  <p>U = UP (acceleration) status  D = DOWN (deceleration) status  H = HOLD (constant speed) status  U1 = During clamping at upper limit speed in UP status  D1 = During clamping at lower limit speed in DOWN status</p> <p>Notes</p> <ol style="list-style-type: none"> <li>To use UP/DOWN commands, be sure to set 1 to b1-01 setting (speed reference selection)  Set value = 1 UP/DOWN commands enabled  Set value ≠ 1 UP/DOWN commands disabled</li> <li>Upper limit speed  = motor max r/min (E1-06) × speed reference upper limit (d2-01)</li> <li>Lower limit value is either speed reference over limit (d2-01) or master speed reference from control circuit terminal 13 or 14</li> <li>When d4-01=01, even if the power supply is turned OFF in the status where accel/decel stop (HOLD) command is input, the held motor speed is stored  When d4-01=0, the held output frequency is stored</li> <li>If a jog speed reference is input during run by UP/DOWN commands, the jog reference has priority</li> <li>When UP and DOWN commands are set together, a setting error (OPE03) occurs</li> <li>When multi-function input accel/decel stop (HOLD) command is set simultaneously, a setting error (OPE03) occurs</li> </ol>	UP Command	Closed	Open	Open	Closed	DOWN Command	Open	Closed	Open	Closed	Status	Accel	Decel	HOLD	HOLD
UP Command	Closed	Open	Open	Closed												
DOWN Command	Open	Closed	Open	Closed												
Status	Accel	Decel	HOLD	HOLD												




Set Value	Description
12,13	<ul style="list-style-type: none"> <li>FJOG command, RJOG command</li> </ul> <p>FWD and REV run jog speed operations are enabled</p> <p>Set value = 12 FJOG command closed. FWD run at jog speed reference (d1-09)</p> <p>Set value = 13 RJOG command closed. REV run at jog speed reference (d1-09).</p> <p>Notes</p> <ol style="list-style-type: none"> <li>When FJOG command is input during run, FJOG command and RJOG command have priority.</li> <li>When both FJOG command and RJOG command are closed more than 500 ms, inverter stops according to the stopping method selection (b1-03)</li> <li>FJOG command or RJOG command can be set independently.</li> </ol>
14	<ul style="list-style-type: none"> <li>Fault reset</li> </ul> <p>Closed: Resets a fault</p>
1B	<ul style="list-style-type: none"> <li>Constant write-in prohibition</li> </ul> <p>Open: To write in constants is prohibited</p> <p>Closed: To write in constants is permitted.</p>
1E	<ul style="list-style-type: none"> <li>Analog speed reference sample/hold</li> </ul> <p>Analog input value 100 msec after setting to "closed" is to be the speed reference.</p> <div data-bbox="365 968 950 1167" style="text-align: center;"> </div> <p>Notes</p> <ol style="list-style-type: none"> <li>Analog speed reference sample/hold is enabled only for analog inputs from terminals 13, 14, 16 or AI-14U, B-option</li> <li>An error (OPE03) will occur if more than one of accel/decel stop (0A), UP/DOWN commands (10, 11) and analog speed reference sample/hold (1E) are set simultaneously</li> </ol>
1F	<ul style="list-style-type: none"> <li>Terminal 13/14 selection</li> </ul> <p>Open Terminal 13 is regarded as the master speed reference</p> <p>Closed Terminal 14 is regarded as the master speed reference</p> <p>When "1F" (terminal 13/14 selection) is not set to multi-function input terminal function selection (H1-01 to H1-06) and when of terminal 14 (H3-09) is "1F" (master speed reference), the master speed reference becomes the sum of terminals 13 and 14.</p> <p>When the set value of H3-09 is other than 1F and multi-function input terminal 13/14 selection (set value 1F) is set, a setting error (OPE03) occurs</p>

Set Value	Description											
20 to 2F	<ul style="list-style-type: none"> <li>External fault</li> </ul> <p>Used to stop the inverter or send an alarm to external devices at fault of peripheral devices, etc</p>											
	Set Value (HEX input) (Same date cannot be set)		Selection Mode									
			Contact Mode		Detection Mode		Stopping Method					
	2nd Digit	3rd Digit	NO contact input	NC contact input	Always detected	Detected during run	Decel to stop (major fault)	Coasting to stop (major fault)	Emergency stop (major fault)	Continuous operation (major fault)		
	2	0	○		○		○					
		1		○	○		○					
		2	○		△	○	○					
		3		○	△	○	○					
		4	○		○			○				
		5		○	○			○				
		6	○		△	○		○				
		7		○	△	○		○				
		8	○		○					○		
		9		○	○					○		
		A	○		△	○				○		
B			○	△	○				○			
C		○		○						○		
D			○	○						○		
E	○				○				○			
F		○			○				○			
<p>(Example) When "24" is set to HI-06 (terminals 8-11 function selection)</p> <ul style="list-style-type: none"> <li>An external fault occurs when it is closed between terminals 8 and 11 (NO contact)</li> <li>An external fault is always detected</li> <li>An external fault is regarded as a major fault and the motor coasts to stop</li> </ul> <p>Note: Setting "closed" during stop causes a minor fault when the detection mode is set to "Detected during run" and the stopping method is set to major fault (set value = 22, 23, 26, 27, 2A, 2B) (in the sections marked with △).</p>												
30	<ul style="list-style-type: none"> <li>Integral reset</li> </ul> <p>Reset at stop command input or during stop at PID control.</p>											

Constant No	Name	Description																																																																																																																																																																																																													
	Multi-function output terminal function selection	Selects the function of signals output from control circuit terminals 9, 25 and 26. <table border="1"> <thead> <tr> <th>Set Value</th> <th>Function</th> <th>Open Loop Vector</th> <th>Flux Vector</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>00</td><td>During run</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>01</td><td>Zero-speed</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>02</td><td>Speed agree 1</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>03</td><td>Desired speed agree 1</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>04</td><td>Speed detection 1</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>05</td><td>Speed detection 2</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>06</td><td>Inverter operation ready</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>07</td><td>During undervoltage detection</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>08</td><td>During baseblock (NO contact output)</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>09</td><td>Speed reference mode</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>0A</td><td>Run command mode</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>0B</td><td>Overtorque detection 1 (NO contact output)</td><td>○</td><td>○</td><td>66</td></tr> <tr><td>0C</td><td>Speed reference missing</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>0D</td><td>Braking resistor fault</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>0E</td><td>Fault</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>0F</td><td>For transmission option</td><td>—</td><td>—</td><td>67</td></tr> <tr><td>10</td><td>Minor fault</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>11</td><td>During fault reset</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>12</td><td>Timer output</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>13</td><td>Speed agree 2</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>14</td><td>Desired speed agree 2</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>15</td><td>Speed detection 3</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>16</td><td>Speed detection 4</td><td>○</td><td>○</td><td>67</td></tr> <tr><td>17</td><td>Overtorque detection 1 (NC contact output)</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>18</td><td>Overtorque detection 2 (NO contact output)</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>19</td><td>Overtorque detection 2 (NC contact output)</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>1A</td><td>During REV run</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>1B</td><td>During baseblock 2 (NC contact output)</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>1C</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>1D</td><td>Motoring retry</td><td>×</td><td>○</td><td>68</td></tr> <tr><td>1E</td><td>During retry</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>1F</td><td>OL1 pre-alarm</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>20</td><td>OH pre-alarm</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>21 to 2F</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>30</td><td>During torque limit</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>31</td><td>During speed limit</td><td>×</td><td>○</td><td>68</td></tr> <tr><td>32</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>33</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> <tr><td>37</td><td>During run 2</td><td>○</td><td>○</td><td>68</td></tr> <tr><td>34 to 3F</td><td>Not used</td><td>—</td><td>—</td><td>—</td></tr> </tbody> </table>	Set Value	Function	Open Loop Vector	Flux Vector	Reference	00	During run	○	○	66	01	Zero-speed	○	○	66	02	Speed agree 1	○	○	66	03	Desired speed agree 1	○	○	66	04	Speed detection 1	○	○	66	05	Speed detection 2	○	○	66	06	Inverter operation ready	○	○	66	07	During undervoltage detection	○	○	66	08	During baseblock (NO contact output)	○	○	66	09	Speed reference mode	○	○	66	0A	Run command mode	○	○	66	0B	Overtorque detection 1 (NO contact output)	○	○	66	0C	Speed reference missing	○	○	67	0D	Braking resistor fault	○	○	67	0E	Fault	○	○	67	0F	For transmission option	—	—	67	10	Minor fault	○	○	67	11	During fault reset	○	○	67	12	Timer output	○	○	67	13	Speed agree 2	○	○	67	14	Desired speed agree 2	○	○	67	15	Speed detection 3	○	○	67	16	Speed detection 4	○	○	67	17	Overtorque detection 1 (NC contact output)	○	○	68	18	Overtorque detection 2 (NO contact output)	○	○	68	19	Overtorque detection 2 (NC contact output)	○	○	68	1A	During REV run	○	○	68	1B	During baseblock 2 (NC contact output)	○	○	68	1C	Not used	—	—	—	1D	Motoring retry	×	○	68	1E	During retry	○	○	68	1F	OL1 pre-alarm	○	○	68	20	OH pre-alarm	○	○	68	21 to 2F	Not used	—	—	—	30	During torque limit	○	○	68	31	During speed limit	×	○	68	32	Not used	—	—	—	33	Not used	—	—	—	37	During run 2	○	○	68	34 to 3F	Not used	—	—	—
Set Value	Function		Open Loop Vector	Flux Vector	Reference																																																																																																																																																																																																										
00	During run		○	○	66																																																																																																																																																																																																										
01	Zero-speed		○	○	66																																																																																																																																																																																																										
02	Speed agree 1		○	○	66																																																																																																																																																																																																										
03	Desired speed agree 1		○	○	66																																																																																																																																																																																																										
04	Speed detection 1		○	○	66																																																																																																																																																																																																										
05	Speed detection 2		○	○	66																																																																																																																																																																																																										
06	Inverter operation ready		○	○	66																																																																																																																																																																																																										
07	During undervoltage detection		○	○	66																																																																																																																																																																																																										
08	During baseblock (NO contact output)		○	○	66																																																																																																																																																																																																										
09	Speed reference mode		○	○	66																																																																																																																																																																																																										
0A	Run command mode		○	○	66																																																																																																																																																																																																										
0B	Overtorque detection 1 (NO contact output)		○	○	66																																																																																																																																																																																																										
0C	Speed reference missing		○	○	67																																																																																																																																																																																																										
0D	Braking resistor fault		○	○	67																																																																																																																																																																																																										
0E	Fault		○	○	67																																																																																																																																																																																																										
0F	For transmission option		—	—	67																																																																																																																																																																																																										
10	Minor fault		○	○	67																																																																																																																																																																																																										
11	During fault reset		○	○	67																																																																																																																																																																																																										
12	Timer output		○	○	67																																																																																																																																																																																																										
13	Speed agree 2		○	○	67																																																																																																																																																																																																										
14	Desired speed agree 2		○	○	67																																																																																																																																																																																																										
15	Speed detection 3		○	○	67																																																																																																																																																																																																										
16	Speed detection 4		○	○	67																																																																																																																																																																																																										
17	Overtorque detection 1 (NC contact output)		○	○	68																																																																																																																																																																																																										
18	Overtorque detection 2 (NO contact output)		○	○	68																																																																																																																																																																																																										
19	Overtorque detection 2 (NC contact output)		○	○	68																																																																																																																																																																																																										
1A	During REV run		○	○	68																																																																																																																																																																																																										
1B	During baseblock 2 (NC contact output)		○	○	68																																																																																																																																																																																																										
1C	Not used		—	—	—																																																																																																																																																																																																										
1D	Motoring retry		×	○	68																																																																																																																																																																																																										
1E	During retry		○	○	68																																																																																																																																																																																																										
1F	OL1 pre-alarm		○	○	68																																																																																																																																																																																																										
20	OH pre-alarm		○	○	68																																																																																																																																																																																																										
21 to 2F	Not used		—	—	—																																																																																																																																																																																																										
30	During torque limit		○	○	68																																																																																																																																																																																																										
31	During speed limit		×	○	68																																																																																																																																																																																																										
32	Not used		—	—	—																																																																																																																																																																																																										
33	Not used		—	—	—																																																																																																																																																																																																										
37	During run 2	○	○	68																																																																																																																																																																																																											
34 to 3F	Not used	—	—	—																																																																																																																																																																																																											
H2-01	Multi-function output (terminal 9-10)																																																																																																																																																																																																														
H2-02	Multi-function output (terminal 25-27)																																																																																																																																																																																																														
H2-03	Multi-function output (terminal 26-27)																																																																																																																																																																																																														

Set Value	Description
00	<ul style="list-style-type: none"> <li>• During run</li> </ul> Closed when the inverter outputs voltage or when run command is input
01	<ul style="list-style-type: none"> <li>• During zero-speed</li> </ul> Closed when the motor speed is less than the zero-speed level (b2-01) in flux vector control  
02	<ul style="list-style-type: none"> <li>• Speed agree 1</li> </ul> Closed when output speed is $\text{Speed reference} - L4-02 \leq \text{SFS output} \leq \text{Speed reference} + L4-02$
03	<ul style="list-style-type: none"> <li>• Desired speed agree 1</li> </ul> Closed when the set value = 02 (speed agree status) and motor speed is within the detection range shown below $L4-01 - L4-02 \leq \text{SFS output (without a sign)} \leq L4-01 + L4-02$
04	<ul style="list-style-type: none"> <li>• Speed detection 1</li> </ul> Closed when output frequency is less than the detection level shown below. $\text{SFS output (without a sign)} \leq L4-01 + L4-02$
05	<ul style="list-style-type: none"> <li>• Speed detection 2</li> </ul> Closed when motor speed is less than the detection level shown below $\text{SFS output (without a sign)} \geq L4-01$
06	<ul style="list-style-type: none"> <li>• Inverter operation ready</li> </ul> Closed when inverter operation is ready
07	<ul style="list-style-type: none"> <li>• During undervoltage detection</li> </ul> Closed when the main circuit or control circuit power supply is reduced or main circuit MC is turned OFF.
08	<ul style="list-style-type: none"> <li>• During baseblock</li> </ul> Closed during inverter output baseblock (NO contact output)
09	<ul style="list-style-type: none"> <li>• Speed reference mode</li> </ul> Open during run with speed reference given by control circuit terminal or option. Closed during run with speed reference from the digital operator
0A	<ul style="list-style-type: none"> <li>• Run command mode</li> </ul> Open during run by run command given by control circuit terminal or option    Closed during run by run command from the digital operator
0B	<ul style="list-style-type: none"> <li>• Overtorque detection 1</li> </ul> Closed while overtorque detection 1 is being detected (Refer to L6-01 to 03 )

Set Value	Description
0C	<ul style="list-style-type: none"> <li>During speed reference is missing</li> </ul> <p>Closed when speed reference is missing.</p> <p>(Example)</p> <p>By setting this constant to ENABLED (L4-05), operation is continued at 80% of the frequency reference as shown below</p> <p>By setting L4-05 = 1, master frequency reference obtained 0.4 second before is always compared with the current reference, when the current reference is reduced to 10% or less of the reference obtained 0.4 second before, operation continues at 80% of the master speed reference obtained 0.4 second before. At this time, during speed reference missing signal is closed.</p>  <p>The diagram shows four signals over time:     <ul style="list-style-type: none"> <li><b>FWD RUN COMMAND:</b> A high-level pulse that starts and ends.</li> <li><b>MASTER SPEED REFERENCE:</b> A signal that starts at 80%, drops to 10% for a duration, then returns to 80%.</li> <li><b>MOTOR SPEED:</b> A signal that follows the master speed reference but with a 0.4-second delay. When the reference drops to 10%, the motor speed drops to 80%.</li> <li><b>DURING SPEED REFERENCE MISSING:</b> A signal that goes from high to low (labeled 'CLOSED') when the master speed reference drops to 10%.</li> </ul> </p>
0D	<ul style="list-style-type: none"> <li>Braking resistor fault</li> </ul> <p>Closed during braking resistor overheating or a braking transistor fault</p>
0E	<ul style="list-style-type: none"> <li>Fault</li> </ul> <p>Closed during a fault excluding CPF00 and CPF01.</p>
0F	<ul style="list-style-type: none"> <li>For transmission option</li> </ul> <p>Reserved for transmission option. Do not use unnecessarily</p>
10	<ul style="list-style-type: none"> <li>Minor fault</li> </ul> <p>Closed while an alarm is displayed</p>
11	<ul style="list-style-type: none"> <li>During fault reset</li> </ul> <p>Closed while fault is being reset</p>
12	<ul style="list-style-type: none"> <li>Timer output</li> </ul> <p>Closed while a timer input is being output</p>
13	<ul style="list-style-type: none"> <li>Speed agree 2</li> </ul> <p>Closed when motor speed is within the detection range shown below.  <math>\text{Speed reference} - L4-04 \leq \text{SFS output} \leq \text{speed reference} + L4-04</math>          Same as speed agree 1 (set value = 02) except that the detection width is L4-04.</p>
14	<ul style="list-style-type: none"> <li>Desired speed agree 2</li> </ul> <p>Closed when the set value is 13 (speed agree status) and it is within detection range shown below.  <math>L4-03 - L4-04 \leq \text{SFS output (with a sign)} \leq L4-03 + L4-04</math></p>
15	<ul style="list-style-type: none"> <li>Speed detection 3</li> </ul> <p>Closed when motor speed is less than the detection level shown below.  <math>\text{SFS output (with a sign)} \leq L4-03</math></p>
16	<ul style="list-style-type: none"> <li>Speed detection 4</li> </ul> <p>Closed when motor speed is less than the detection level shown below.  <math>\text{SFS output (with a sign)} \geq L4-03</math></p>


Set Value	Description
17	<ul style="list-style-type: none"> <li>• Overtorque detection 1</li> </ul> Open while overtorque detection 1 is being detected (NC contact output) (Refer to L6-01 to 03 )
18	<ul style="list-style-type: none"> <li>• Overtorque detection 2</li> </ul> Closed while overtorque detection 2 is being detected (NO contact output). (Refer to L6-04 to 06 )
19	<ul style="list-style-type: none"> <li>• Overtorque detection 2</li> </ul> Open while overtorque detection 2 is being detected (NC contact output). (Refer to L6-04 to 06 )
1A	<ul style="list-style-type: none"> <li>• During REV run</li> </ul> Closed during REV run
1B	<ul style="list-style-type: none"> <li>• During baseblock</li> </ul> Open during inverter output baseblock (NC contact output)
1D	<ul style="list-style-type: none"> <li>• Motoring retry</li> </ul> Closed in the regenerating mode in flux vector control.
1E	<ul style="list-style-type: none"> <li>• During retry</li> </ul> Closed during retry operation at fault retry Valid only at A1-02 = 06 (flux vector control).
1F	<ul style="list-style-type: none"> <li>• OL1 pre-alarm</li> </ul> Closed when electronic thermal overload relay integrated value becomes 90% of the fault detection level (Refer to L8-02, 03.)
20	<ul style="list-style-type: none"> <li>• OH pre-alarm</li> </ul> Closed when the cooling fin temperature exceeds the cooling fin overheat temperature. (Refer to L8-02, 03.)
30	<ul style="list-style-type: none"> <li>• During torque limit</li> </ul> Closed during torque limit
31	<ul style="list-style-type: none"> <li>• During speed limit</li> </ul> Closed when either of the following constants limits the speed reference <ul style="list-style-type: none"> <li>(1) Speed reference upper limit (d2-01)</li> <li>(2) Speed reference lower limit [d2-02, multi-function analog input (set value = 09)]</li> <li>(3) Motor min, r/min (E1-08)</li> </ul>
37	<ul style="list-style-type: none"> <li>• During run 2</li> </ul> Closed, except during baseblock (bb), or initial magnetic-pole lead-in, or during initial status estimation

Constant No.	Name	Description	Remarks						
H3-01	Signal level selection (terminal 13)	<table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0 to 10 V input</td> </tr> <tr> <td>1</td> <td>-10 to +10 V input</td> </tr> </tbody> </table>	Set Value	Description	0	0 to 10 V input	1	-10 to +10 V input	<ul style="list-style-type: none"> <li>Resolution [11-bit + sign input]</li> </ul>
Set Value	Description								
0	0 to 10 V input								
1	-10 to +10 V input								
H3-02	Gain (terminal 13)	Sets the speed reference when speed reference voltage is 10 V.							
H3-03	Bias (terminal 13)	Sets the speed reference when speed reference voltage is 0 V							

H3-04	Signal level selection (terminal 16)	<table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0 to 10 V input</td> </tr> <tr> <td>1</td> <td>-10 to +10 V input</td> </tr> </tbody> </table> <p>Set terminal 16 to multi-function analog reference The following table shows the set values</p>	Set Value	Description	0	0 to 10 V input	1	-10 to +10 V input	<ul style="list-style-type: none"> <li>Resolution [11-bit + sign input]</li> </ul>
Set Value	Description								
0	0 to 10 V input								
1	-10 to +10 V input								
H3-05	Multi-function analog input (terminal 16)								

Set Value	Function	Open Loop Vector	Flux Vector	Input Level	Remarks
00	Auxiliary speed reference	○	○	±100% / ±10 V	100% Motor max r/min (E1-06)
01	FGAIN	○	○	100% / 10 V	
02	FBIAS	○	○	±100% / ±10 V	100%. Motor max r/min (E1-06)
04	Not used	—	—	100% / 10 V	
05	Not used	—	—	100% / 1 V	
06	Not used	—	—	100% / 10 V	
07	Overtorque detection level	○	○	100% / 10 V	100% Motor rated torque
08	Not used	—	—	100% / 10 V	
09	Speed reference lower limit level	○	○	100% / 10 V	100% Motor max r/min (E1-06)
0A	Jump speed	○	○	100% / 10 V	100% Motor max r/min (E1-06)
0B	PID feedback	○	○	±100% / ±10 V	100%: Motor max. r/min (E1-06)
0C to 0F	Not used	—	—	—	
10	FWD side torque limit	○	○	100% / ±10 V	100% Motor rated torque
11	REV side torque limit	○	○	100% / ±10 V	100% Motor rated torque
12	Regeneration side torque limit	○	○	100% / ±10 V	100% Motor rated torque
13	Torque reference (at torque control) Torque limit (at speed control)	×	○	±100% / ±10 V	100% Motor rated torque
14	Torque compensation (bias)	×	○	±100% / ±10 V	100%: Motor rated torque
15	FWD/REV side torque limit	○	○	±100% / 10 V	100% Motor rated torque
16 to 1F	Not used	—	—	—	Set H3-05 to 1F when speed reference 2 (d1-02) is used



[ Description of torque limits ]



Note For torque limit, smaller value between constants (L7-01 to 04) and analog reference has the priority

Constant No	Name	Description	Remarks								
H3-06 H3-07	Gain (terminal 16) Bias (terminal 16)	<ul style="list-style-type: none"> <li>Auxiliary speed reference (set value = 00)</li> <li>FBIAS (set value = 02)</li> <li>PID feedback (set value = 0B)</li> </ul> <p>(100% = fmax)</p> <ul style="list-style-type: none"> <li>Torque reference (set value = 13)</li> <li>Torque compensation (set value = 14)</li> </ul> <ul style="list-style-type: none"> <li>Torque limit (set value = 10, 11, 12)</li> <li>Torque limit (set value = 15)</li> </ul> <p>Sets the input gain (level) when terminal 16 is 10 V</p> <p>Sets the input bias (level) when terminal 16 is 0 V</p>									
H3-08	Signal level selection (terminal 14)	<table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0 to -10 V input</td> </tr> <tr> <td>1</td> <td>-10 to +10 V input</td> </tr> <tr> <td>2</td> <td>4 to 20 mA input</td> </tr> </tbody> </table> <p>Note. To change the analog reference level from current input (4 to 20 mA) to voltage input (0 to 10 V, etc), it is necessary to cut a Jumper-wire (J1) on the control board</p>	Set Value	Description	0	0 to -10 V input	1	-10 to +10 V input	2	4 to 20 mA input	<ul style="list-style-type: none"> <li>Resolution [10-bit input]</li> </ul>
Set Value	Description										
0	0 to -10 V input										
1	-10 to +10 V input										
2	4 to 20 mA input										
H3-09	Multi-function analog input (terminal 14)	<p>Inputs the set value of multi-function analog reference (Refer to H3-05)</p> <p>However, set values "00" and "1F" have functions different from those of H3-05 as described below</p> <p>00 Not used</p> <p>1F Master speed reference</p> <p>When "1F" (terminal 13/14 selection) is not set to multi-function input terminal function selection (H1-01 to H1-06) and when terminal 14 (H3-09) is set to "1F" (master speed reference), master speed reference is the sum of terminals 13 and 14</p> <p>When any value other than "1F" (master speed reference) is set to terminal 14 (H3-09) and when "1F" (terminal 13/14 selection) is set to multi-function input terminal function selection (H1-01 to H1-06), setting error (OPE 03) occurs</p>									



Constant No.	Name	Description	Remarks						
H3-10 H3-11	Gain (terminal 14) Bias (terminal 14)	<p>Sets the input gain (level) when terminal 14 is 20 mA (10 V).</p> <p>Sets the input bias (level) when terminal 14 is 4 mA (0 V).</p> <p>Note: When master speed reference is the sum of terminals 13 and 14 (when H3-09 is set to "IF" and H1-01 to 06 is not set to "IF"), H3-10 [Gain (terminal 14)] and H3-11 [Bias (terminal 14)] become invalid in this case. H3-02 and H3-03 set gain and bias for the master speed reference that is the sum of terminals 13 and 14</p>							
H3-12	Analog input filter time constant	Sets terminals 13, 14 and 16 to primary delay filter time constant							
H4-01 H4-02 H4-03	Monitor selection (terminal 21-22) Gain (terminal 21-22) Bias (terminal 21-22)	<p>Selects item to be output to terminals 21-22 and 23-22 (multi-function analog monitor) function selection and sets output gain and output bias.</p> <p>For output item, set the monitor number (U1-XX) to be output</p> <p>For calculation of output level and output bias, convert the monitor item output level into 30000/100%, and subtract the output bias set value from the converted value and multiply it by output gain. This calculated value is output to multi-function analog monitor channel as 10 V/30000.</p> <p>The following diagram shows this calculation</p>	<p>• Resolution [9-bit + sign output]</p> <p>Set value 0 is a special function for transmission option. Do not set to 0</p>						
H4-04 H4-05 H4-06	Monitor selection (terminal 23-22) Gain (terminal 23-22) Bias (terminal 23-22)	 <p>(Constants in parentheses indicate terminals 23-22)</p>	<p>• Resolution [9-bit + sign output]</p> <p>Set value 0 is a special function for transmission option. Do not set to 0.</p>						
H4-07	Analog output signal level selection	<table border="1" data-bbox="581 1139 998 1294"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0 to 10 V input</td> </tr> <tr> <td>1</td> <td>-10 to +10 V input</td> </tr> </tbody> </table>	Set Value	Description	0	0 to 10 V input	1	-10 to +10 V input	
Set Value	Description								
0	0 to 10 V input								
1	-10 to +10 V input								


# L PROTECTION-RELATED CONSTANTS

Constant No	Name	Description	Remarks						
L1-01	Motor protection selection	<p>Selects whether motor overload protection is provided at electronic thermal overload relay</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Enabled</td> </tr> </tbody> </table> <p>If the inverter power supply is turned OFF, the assumed value of the motor temperature is cleared to 0. Therefore, in some applications where the inverter power supply is turned OFF, protection may not be effective</p>	Set Value	Description	0	Disabled	1	Enabled	
Set Value	Description								
0	Disabled								
1	Enabled								
L1-02	Motor protection time constant	<p>Sets the electronic thermal overload relay protection time when 150% of overload is applied (hot-start) after the motor is operated continuously at rated current. The factory setting is one minute. Set the value according to the overload resistance of motors to be used.</p> <p style="text-align: center;">MOTOR CURRENT (%) E2-04 BECOMES 100%</p>							
L2-01	Momentary power loss detection	<p>Selects whether the inverter stops at momentary power loss detection or operation restarts after recovery if momentary power loss occurs</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Operation does not restart after recovery. When PN voltage reaches the undervoltage detection level (L2-05), a fault occurs immediately resulting in baseblock.</td> </tr> <tr> <td>1</td> <td>Operation restarts after recovery.                      ① Operation restarts if PN voltage is held by regenerative energy using L2-03 and the power supply is recovered within the L2-05 set time.                      ② Operation restarts if the power supply is recovered within the L2-02 set time even after elapse of the C2-05 set time.</td> </tr> </tbody> </table>	Set Value	Description	0	Operation does not restart after recovery. When PN voltage reaches the undervoltage detection level (L2-05), a fault occurs immediately resulting in baseblock.	1	Operation restarts after recovery. ① Operation restarts if PN voltage is held by regenerative energy using L2-03 and the power supply is recovered within the L2-05 set time. ② Operation restarts if the power supply is recovered within the L2-02 set time even after elapse of the C2-05 set time.	
Set Value	Description								
0	Operation does not restart after recovery. When PN voltage reaches the undervoltage detection level (L2-05), a fault occurs immediately resulting in baseblock.								
1	Operation restarts after recovery. ① Operation restarts if PN voltage is held by regenerative energy using L2-03 and the power supply is recovered within the L2-05 set time. ② Operation restarts if the power supply is recovered within the L2-02 set time even after elapse of the C2-05 set time.								
L2-02	Momentary power loss ride time	<p>Sets the allowable value of power supply recovery time when restart of operation after recovery of the power supply (L2-01=1) is selected for a process at momentary power loss occurrence. Setting unit 0.1sec</p>	Valid only at L2-01=1						

Constant No.	Name	Description	Remarks						
L2-03	Deceleration time at momentary power loss	<p>Sets deceleration time at momentary power loss occurrence Deceleration time is set in order that motor regenerative energy followed by deceleration is returned to the DC bus bar to maintain the controller power supply and control. Reduction of deceleration time can maintain the controller power supply longer.</p> <table border="1"> <thead> <tr> <th>Contents</th> <th>C2-03 Adjustment</th> </tr> </thead> <tbody> <tr> <td>Overvoltage (OV) display</td> <td>Increase by 5 seconds</td> </tr> <tr> <td>Momentary power loss (UV) display</td> <td>Decrease by 5 seconds</td> </tr> </tbody> </table>	Contents	C2-03 Adjustment	Overvoltage (OV) display	Increase by 5 seconds	Momentary power loss (UV) display	Decrease by 5 seconds	Valid only at L2-01=01.
Contents	C2-03 Adjustment								
Overvoltage (OV) display	Increase by 5 seconds								
Momentary power loss (UV) display	Decrease by 5 seconds								
L2-05	Undervoltage detection level	<p>Sets inverter main circuit DC bus bar voltage value to detect undervoltage To set this value less than the standard set value (200V class 190 VDC, 400 V class 380 VDC), it may be necessary to insert at the input side</p>							
L3-01	Overvoltage prevention function selection	<p>Sets a function to prevent the inverter DC bus bar from overvoltage.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled Inverter does not maintain DC bus bar voltage When overvoltage (OV) is detected, the inverter outputs a fault contact and stops</td> </tr> <tr> <td>1</td> <td>Enabled. Regenerative side torque limit is decreased automatically to prevent overvoltage (OV), monitoring DC bus bar voltage status. For automatic adjustment of deceleration rate, the deceleration time may be longer than the set value</td> </tr> </tbody> </table> <p>Set the value to 0 when decelerating using braking unit/braking resistor unit.</p>	Set Value	Description	0	Disabled Inverter does not maintain DC bus bar voltage When overvoltage (OV) is detected, the inverter outputs a fault contact and stops	1	Enabled. Regenerative side torque limit is decreased automatically to prevent overvoltage (OV), monitoring DC bus bar voltage status. For automatic adjustment of deceleration rate, the deceleration time may be longer than the set value	
Set Value	Description								
0	Disabled Inverter does not maintain DC bus bar voltage When overvoltage (OV) is detected, the inverter outputs a fault contact and stops								
1	Enabled. Regenerative side torque limit is decreased automatically to prevent overvoltage (OV), monitoring DC bus bar voltage status. For automatic adjustment of deceleration rate, the deceleration time may be longer than the set value								
L4-01	Speed detection level	<p>This constant is used to detect speed agree, etc. Motor speed to be detected is set. This detection is performed both for FWD and REV run.</p>	Refer to page 74						
L4-02	Speed detection width	Set detection width at L4-01 frequency detection	Refer to page 74.						
L4-03	Speed detection level (+/-)	<p>This constant is used to detect speed agree, etc. Motor speed to be detected is set. This detection is enabled either for FWD or REV run (Motor speed polarity is provided at detection)</p>	Refer to page 74.						
L4-04	Speed detection width (+/-)	Sets detection width at L4-03 speed agree detection	Refer to page 74						

# DESCRIPTION OF SPREED DETECTION ON OPERATION

Related Constants	L4-01 (Speed Detection Level) L4-02 (Speed Detection Width)	L4-03 (Speed Detection Level) L4-04 (Speed Detection Width)
Speed Agree	<p style="text-align: center;"><b>Speed Agree 1</b></p> <p style="text-align: center;">SPEED AGREE 1 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=02)</p>	<p style="text-align: center;"><b>Speed Agree 2</b></p> <p style="text-align: center;">SPEED AGREE 2 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=13)</p>
	<p style="text-align: center;"><b>Desired Speed Agree 1</b></p> <p style="text-align: center;">SPEED AGREE 1 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=03)</p>	<p style="text-align: center;"><b>Desired Speed Agree 2</b></p> <p style="text-align: center;">SPEED AGREE 2 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=14)</p>
Speed Detection	<p style="text-align: center;"><b>Speed Detection 1</b></p> <p style="text-align: center;">SPEED DETECTION 1 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=04)</p>	<p style="text-align: center;"><b>Speed Detection 3</b></p> <p style="text-align: center;">SPEED DETECTION 3 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=15)</p>
	<p style="text-align: center;"><b>Speed Detection 2</b></p> <p style="text-align: center;">SPEED DETECTION 2 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=05)</p>	<p style="text-align: center;"><b>Speed Detection 4</b></p> <p style="text-align: center;">SPEED DETECTION 4 (MULTI-FUNCTION CONTACT OUTPUT SET VALUE=16)</p>

Constant No	Name	Description	Remarks						
L4-05	Operation when speed reference is missing	<p>Selects when speed reference from the control circuit terminal is quickly reduced.</p> <table border="1" data-bbox="578 316 1224 533"> <thead> <tr> <th>Set Value</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Normal operation (Following variation of reference)</td> </tr> <tr> <td>1</td> <td>When speed reference from control circuit terminal is reduced by 90% within 400 ms, operation continues at 80% of speed reference obtained before reduction.</td> </tr> </tbody> </table>	Set Value	Contents	0	Normal operation (Following variation of reference)	1	When speed reference from control circuit terminal is reduced by 90% within 400 ms, operation continues at 80% of speed reference obtained before reduction.	
Set Value	Contents								
0	Normal operation (Following variation of reference)								
1	When speed reference from control circuit terminal is reduced by 90% within 400 ms, operation continues at 80% of speed reference obtained before reduction.								
L5-01	Number of auto restart attempts	<p>Fault retry is function to reset the fault in the inverter and restart automatically to continue operation if a fault occurs. This constant sets the number of fault retry times. By setting 0, fault retry operation is not performed.</p> <p style="text-align: center;"><b>Fault retry operation</b></p> <ol style="list-style-type: none"> <li>① When a fault is detected, the inverter output is shut OFF resulting in baseblock. The digital operator displays the fault while the inverter output is shut OFF.</li> <li>② The fault is reset automatically to continue operation.</li> <li>③ When the total number of faults exceeds the number of fault retry times (L5-01), the faults are not reset automatically and the inverter output remains OFF. At this time, a fault contact output is activated.</li> </ol> <div style="text-align: center;">  </div> <p style="text-align: center;"><b>Clearing the number of retry times</b></p> <p>The number of retry times is cleared to 0 in the following cases:</p> <ol style="list-style-type: none"> <li>① A fault does not occur for more than 10 minutes.</li> <li>② A fault reset signal is input from the control circuit terminal or digital operator.</li> <li>③ The power supply is shut OFF and the control power supply has dissipated, and then the power supply is turned ON again.</li> </ol> <p>Fault retry is disabled for the following faults.</p> <ul style="list-style-type: none"> <li>UV3 (MC answer fault)</li> <li>SC (Load short-circuit)</li> <li>OH (Heatsink overheat)</li> <li>EF (Run command fault)</li> <li>OS (Over speed)</li> <li>DEV (Excessive speed deviation)</li> <li>ZDEV (Z-phase error)</li> <li>PGO (PG disconnection)</li> <li>OPR (Constant setting error)</li> <li>CE (Transmission error)</li> <li>EF3 to 8 (External fault)</li> <li>STO (Hunting prevention)</li> <li>ERR (EEPROM write-in error)</li> <li>UV1 (Main circuit under voltage) · Only when L2-01=00</li> </ul>							

Constant No	Name	Description	Remarks												
L5-02	Auto restart operation selection	<p>Sets whether a fault contact output is activated during fault retry.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>A fault contact output is not activated during fault retry.</td> </tr> <tr> <td>1</td> <td>A fault contact output is activated during fault retry</td> </tr> </tbody> </table>	Set Value	Description	0	A fault contact output is not activated during fault retry.	1	A fault contact output is activated during fault retry							
Set Value	Description														
0	A fault contact output is not activated during fault retry.														
1	A fault contact output is activated during fault retry														
L6-01	Torque detection selection 1	<p>Sets a function to detect overtorque. Overtorque is detected using the inverter internal torque reference</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Overtorque detection disabled (factory setting)</td> </tr> <tr> <td>1</td> <td>Overtorque detection enabled Overtorque detection is performed only during speed agree and "OL3" is displayed, blinking, to continue operation after detection</td> </tr> <tr> <td>2</td> <td>Overtorque detection enabled Overtorque detection is performed during run and "OL3" is displayed, blinking, to continue operation after detection</td> </tr> <tr> <td>3</td> <td>Overtorque detection enabled Overtorque detection is performed only during speed agree "OL3" is displayed, lighting at overtorque detection, and a fault contact is output to shut OFF inverter output</td> </tr> <tr> <td>4</td> <td>Overtorque detection enabled Overtorque detection is performed during run "OL3" is displayed, lighting at overtorque detection, and a fault contact output is activated to shut OFF inverter output.</td> </tr> </tbody> </table>	Set Value	Description	0	Overtorque detection disabled (factory setting)	1	Overtorque detection enabled Overtorque detection is performed only during speed agree and "OL3" is displayed, blinking, to continue operation after detection	2	Overtorque detection enabled Overtorque detection is performed during run and "OL3" is displayed, blinking, to continue operation after detection	3	Overtorque detection enabled Overtorque detection is performed only during speed agree "OL3" is displayed, lighting at overtorque detection, and a fault contact is output to shut OFF inverter output	4	Overtorque detection enabled Overtorque detection is performed during run "OL3" is displayed, lighting at overtorque detection, and a fault contact output is activated to shut OFF inverter output.	
Set Value	Description														
0	Overtorque detection disabled (factory setting)														
1	Overtorque detection enabled Overtorque detection is performed only during speed agree and "OL3" is displayed, blinking, to continue operation after detection														
2	Overtorque detection enabled Overtorque detection is performed during run and "OL3" is displayed, blinking, to continue operation after detection														
3	Overtorque detection enabled Overtorque detection is performed only during speed agree "OL3" is displayed, lighting at overtorque detection, and a fault contact is output to shut OFF inverter output														
4	Overtorque detection enabled Overtorque detection is performed during run "OL3" is displayed, lighting at overtorque detection, and a fault contact output is activated to shut OFF inverter output.														
L6-02	Torque detection level 1	Sets the overtorque detection level. Motor rated torque becomes 100%													
L6-03	Torque detection time 1	Overtorque is detected if the time when motor current or torque exceeds the value set to L6-02 is longer than the time set by this constant Digital operator displays "OL3"													
L6-04	Torque detection selection 2	The functions are the same as those described for constants L6-01 to L6-03 Used when two types of overtorque detection are output to multi-function outputs Digital operator displays "OL4"													
L6-05	Torque detection level 2														
L6-06	Torque detection time 2														
L7-01	Forward torque limit	Sets motoring side torque limit value during FWD run Torque limit value decreases automatically in reverse proportion to speed in a constant output area [base r/min (E1-07) or more].													
L7-02	Reverse torque limit	Sets motoring side torque limit value during REV run Torque limit value decreases automatically in reverse proportion to speed in a constant output area [base r/min (E1-07) or more]													
L7-03	Forward regenerative torque limit	Sets regenerating side torque limit value during FWD run Torque limit value decreases automatically in reverse proportion to speed in a constant output area [base r/min (E1-07) or more]													

Constant No.	Name	Description	Remarks										
L7-04	Reverse regenerative torque limit	<p>Sets regenerating side torque limit value during REV run. Torque limit value decreases automatically in reverse prorortion to speed in a constant output area [base r/min (E1-07) or more].</p> <p style="text-align: center;">TORQUE REFERENCE</p> <p style="text-align: center;">TORQUE LIMIT VALUE</p>											
L8-01	Protect selection for internal DB resistor	<p>When a braking resistor that can be built in the inverter is used, overheat protection is enabled by using this function. (Overheat is detected at operating duty 3% of braking resistor)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Braking resistor overheat protection disabled</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Braking resistor overheat protection enabled</td> </tr> </tbody> </table>	Set Value	Description	0	Braking resistor overheat protection disabled	1	Braking resistor overheat protection enabled					
Set Value	Description												
0	Braking resistor overheat protection disabled												
1	Braking resistor overheat protection enabled												
L8-02	OH pre-alarm level	Sets the heatsink temperature to predict heatsink overheat											
L8-03	Operation selection after OH pre-alarm	<p>Selects the operation mode when the inverter detects heatsink overheat prediction.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Deceleration to stop at either C1-02, 04, 06, or 08, set value whichever is selected at detection of overheat prediction</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Inverter output OFF (Coasting to stop)</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Deceleration to stop at value set to C1-09 (Quick deceleration to stop)</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Continuous operation (Displayed only)</td> </tr> </tbody> </table>	Set Value	Description	0	Deceleration to stop at either C1-02, 04, 06, or 08, set value whichever is selected at detection of overheat prediction	1	Inverter output OFF (Coasting to stop)	2	Deceleration to stop at value set to C1-09 (Quick deceleration to stop)	3	Continuous operation (Displayed only)	
Set Value	Description												
0	Deceleration to stop at either C1-02, 04, 06, or 08, set value whichever is selected at detection of overheat prediction												
1	Inverter output OFF (Coasting to stop)												
2	Deceleration to stop at value set to C1-09 (Quick deceleration to stop)												
3	Continuous operation (Displayed only)												

Constant No	Name	Description	Remarks						
L8-05	Input open-phase protection selection	<p>If power supply open-phase, excessive power supply voltage imbalance or main circuit electrolytic capacitor deterioration occurs, excessive inverter DC bus bar ripple voltage is detected to stop the inverter.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Excessive ripple detection disabled</td> </tr> <tr> <td>1</td> <td>Excessive ripple detection enabled</td> </tr> </tbody> </table>	Set Value	Description	0	Excessive ripple detection disabled	1	Excessive ripple detection enabled	
Set Value	Description								
0	Excessive ripple detection disabled								
1	Excessive ripple detection enabled								
L8-07	Output open-phase protection selection	<p>A function to detect inverter output open-phase</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Inverter output open-phase detection disabled</td> </tr> <tr> <td>1</td> <td>Inverter output open-phase detection enabled</td> </tr> </tbody> </table> <p>Output open-phase may be detected inadvertently when applied motor capacity is small for inverter capacity, etc</p>	Set Value	Description	0	Inverter output open-phase detection disabled	1	Inverter output open-phase detection enabled	
Set Value	Description								
0	Inverter output open-phase detection disabled								
1	Inverter output open-phase detection enabled								
L8-10	Ground fault protection selection	<p>A function to detect grounding fault</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ground fault protection disabled</td> </tr> <tr> <td>1</td> <td>Ground fault protection enabled</td> </tr> </tbody> </table>	Set Value	Description	0	Ground fault protection disabled	1	Ground fault protection enabled	
Set Value	Description								
0	Ground fault protection disabled								
1	Ground fault protection enabled								
L9-01	Step-out protection selection	<p>A function to select operation when step-out is detected at open loop vector control</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Step-out protection disabled</td> </tr> <tr> <td>1</td> <td>Step-out protection enabled</td> </tr> </tbody> </table>	Set Value	Description	0	Step-out protection disabled	1	Step-out protection enabled	
Set Value	Description								
0	Step-out protection disabled								
1	Step-out protection enabled								



o DIGITAL OPREATOR-RELATED CONSTANTS

Constant No	Name	Description	Remarks										
o1-01	Monitor selection	Four items can be monitored in drive mode. This constant can select an item to be monitored instead of output voltage. Set o1-01 to □□ in monitor constant U1-□□											
o1-02	Monitor selection after power up	<p>Set an item to be monitored immediately after the power supply is turned ON. Digital operator displays the item set by this constant after the power supply is turned ON</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Displays speed reference</td> </tr> <tr> <td>2</td> <td>Displays motor speed</td> </tr> <tr> <td>3</td> <td>Displays output current</td> </tr> <tr> <td>4</td> <td>Displays a monitor item selected by o1-01</td> </tr> </tbody> </table>	Set Value	Description	1	Displays speed reference	2	Displays motor speed	3	Displays output current	4	Displays a monitor item selected by o1-01	
Set Value	Description												
1	Displays speed reference												
2	Displays motor speed												
3	Displays output current												
4	Displays a monitor item selected by o1-01												
o1-03	Speed units of reference setting and monitor	<p>Units for speed related reference or monitor can be selected as shown below.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Unit 0.01% Speed reference indicated as P□□ □□</td> </tr> <tr> <td>2 to 39</td> <td> <ul style="list-style-type: none"> <li>Unit r/min</li> <li>r/min = 120 × speed reference (Hz) / (E1-05)</li> <li>Speed reference indicated as n□□□□.</li> </ul> </td> </tr> <tr> <td>40 to 3999</td> <td> <p>Decimal point position set with 5th digit value of o1-03.</p> <p>5th digit value = 0. Displayed as v□□□□                      5th digit value = 1. Displayed as v□□□ □                      5th digit value = 2. Displayed as v□□ □□                      5th digit value = 3. Displayed as v□ □□□</p> <p>o1-03 1st to 4th digits determine the set value of 100% speed.</p> <p>(Example 1)                      Assuming that 100% speed set value is 200.0 set o1-03 = 12000                      When o1-03 = 12000 is set, 100% frequency is displayed as 200.0 and 60% speed is displayed as 120.0</p> <p>(Example 2)                      Assuming that 100% speed set value is 65.00, set o1-03 = 26500                      When o1-03 = 26500 is set, 60% speed is displayed as 39.00</p> </td> </tr> </tbody> </table>	Set Value	Description	1	Unit 0.01% Speed reference indicated as P□□ □□	2 to 39	<ul style="list-style-type: none"> <li>Unit r/min</li> <li>r/min = 120 × speed reference (Hz) / (E1-05)</li> <li>Speed reference indicated as n□□□□.</li> </ul>	40 to 3999	<p>Decimal point position set with 5th digit value of o1-03.</p> <p>5th digit value = 0. Displayed as v□□□□                      5th digit value = 1. Displayed as v□□□ □                      5th digit value = 2. Displayed as v□□ □□                      5th digit value = 3. Displayed as v□ □□□</p> <p>o1-03 1st to 4th digits determine the set value of 100% speed.</p> <p>(Example 1)                      Assuming that 100% speed set value is 200.0 set o1-03 = 12000                      When o1-03 = 12000 is set, 100% frequency is displayed as 200.0 and 60% speed is displayed as 120.0</p> <p>(Example 2)                      Assuming that 100% speed set value is 65.00, set o1-03 = 26500                      When o1-03 = 26500 is set, 60% speed is displayed as 39.00</p>			
Set Value	Description												
1	Unit 0.01% Speed reference indicated as P□□ □□												
2 to 39	<ul style="list-style-type: none"> <li>Unit r/min</li> <li>r/min = 120 × speed reference (Hz) / (E1-05)</li> <li>Speed reference indicated as n□□□□.</li> </ul>												
40 to 3999	<p>Decimal point position set with 5th digit value of o1-03.</p> <p>5th digit value = 0. Displayed as v□□□□                      5th digit value = 1. Displayed as v□□□ □                      5th digit value = 2. Displayed as v□□ □□                      5th digit value = 3. Displayed as v□ □□□</p> <p>o1-03 1st to 4th digits determine the set value of 100% speed.</p> <p>(Example 1)                      Assuming that 100% speed set value is 200.0 set o1-03 = 12000                      When o1-03 = 12000 is set, 100% frequency is displayed as 200.0 and 60% speed is displayed as 120.0</p> <p>(Example 2)                      Assuming that 100% speed set value is 65.00, set o1-03 = 26500                      When o1-03 = 26500 is set, 60% speed is displayed as 39.00</p>												
o2-01	LOCAL/REMOTE key enable/disable	<p>Sets digital operator LOCAL/REMOTE key enabled/disabled.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Digital operator REMOTE/LOCAL key disabled</td> </tr> <tr> <td>1</td> <td>Digital operator REMOTE/LOCAL key enabled. Priority of speed reference and run command is alternated with priority set by digital operator and b1-01/02.</td> </tr> </tbody> </table>	Set Value	Description	0	Digital operator REMOTE/LOCAL key disabled	1	Digital operator REMOTE/LOCAL key enabled. Priority of speed reference and run command is alternated with priority set by digital operator and b1-01/02.					
Set Value	Description												
0	Digital operator REMOTE/LOCAL key disabled												
1	Digital operator REMOTE/LOCAL key enabled. Priority of speed reference and run command is alternated with priority set by digital operator and b1-01/02.												

Constant No.	Name	Description	Remarks						
o2-02	STOP key during control circuit terminal operation	<p>Sets digital operator STOP key enabled/disabled in operation mode</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Digital operator STOP key disabled Digital operator STOP key is disabled during run by run command other than that given from the digital operator</td> </tr> <tr> <td>1</td> <td>Digital operator STOP key enabled Digital operator STOP key is enabled even during run by run command other than that given from the digital operator.</td> </tr> </tbody> </table> <p>When the set value is "1 (factory setting)" and operation is stopped by a STOP command other than that given from the digital operator, it is necessary to turn OFF the RUN command once</p>	Set Value	Description	0	Digital operator STOP key disabled Digital operator STOP key is disabled during run by run command other than that given from the digital operator	1	Digital operator STOP key enabled Digital operator STOP key is enabled even during run by run command other than that given from the digital operator.	
Set Value	Description								
0	Digital operator STOP key disabled Digital operator STOP key is disabled during run by run command other than that given from the digital operator								
1	Digital operator STOP key enabled Digital operator STOP key is enabled even during run by run command other than that given from the digital operator.								
o2-03	User constant initial value	<p>Constants set by user can be stored in the inverter as user initial values</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User constant initial value setting Each constant obtained when o2-03 = 1 is set, is stored as a constant initial value. Even if each constant setting is changed after setting this constant, it can be returned to the user constant initial value by setting A1-03 = 1110 (initialization to user initial value)</td> </tr> <tr> <td>1</td> <td>Clearing user constant initial value Clears the user constant initial values that are set as above</td> </tr> </tbody> </table> <p>After setting the value, the indication on the digital operator shows "Entry accepted" then resets to "0"</p>	Set Value	Description	0	User constant initial value setting Each constant obtained when o2-03 = 1 is set, is stored as a constant initial value. Even if each constant setting is changed after setting this constant, it can be returned to the user constant initial value by setting A1-03 = 1110 (initialization to user initial value)	1	Clearing user constant initial value Clears the user constant initial values that are set as above	
Set Value	Description								
0	User constant initial value setting Each constant obtained when o2-03 = 1 is set, is stored as a constant initial value. Even if each constant setting is changed after setting this constant, it can be returned to the user constant initial value by setting A1-03 = 1110 (initialization to user initial value)								
1	Clearing user constant initial value Clears the user constant initial values that are set as above								
o2-04	kVA selection	<p>Sets inverter capacity. By this constant setting, control constants peculiar to the inverter can be set automatically.</p>	<ul style="list-style-type: none"> <li>Refer to Par 2 6 of this manual.</li> <li>Do not change it unnecessarily Not initialized (A1-03 setting)</li> </ul>						
o2-05	Speed reference setting method selection	<p>Whether ENTER key operation is needed can be set when speed reference is set by digital operator</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Digital operator ENTER key needed To set speed reference by digital operator, the inverter accepts speed reference at the time when the digital operator ENTER key is depressed</td> </tr> <tr> <td>1</td> <td>Digital operator ENTER key not needed Inverter accepts speed reference displayed on the digital operator speed reference without ENTER key operation</td> </tr> </tbody> </table>	Set Value	Description	0	Digital operator ENTER key needed To set speed reference by digital operator, the inverter accepts speed reference at the time when the digital operator ENTER key is depressed	1	Digital operator ENTER key not needed Inverter accepts speed reference displayed on the digital operator speed reference without ENTER key operation	
Set Value	Description								
0	Digital operator ENTER key needed To set speed reference by digital operator, the inverter accepts speed reference at the time when the digital operator ENTER key is depressed								
1	Digital operator ENTER key not needed Inverter accepts speed reference displayed on the digital operator speed reference without ENTER key operation								

Constant No	Name	Description	Remarks						
o2-06	Operation selection when digital operator is disconnected	<p>When running by digital operator, inverter operation selection at communication fault occurrence between the digital operator and the inverter (cable disconnection, removal of digital operator, etc ) is set</p> <table border="1" data-bbox="570 334 1219 504"> <thead> <tr> <th data-bbox="570 334 695 384">Set Value</th> <th data-bbox="695 334 1219 384">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="570 384 695 435">0</td> <td data-bbox="695 384 1219 435">Operation continues</td> </tr> <tr> <td data-bbox="570 435 695 504">1</td> <td data-bbox="695 435 1219 504">Coasting to a stop and an error message "OPR" is indicated on a digital operator.</td> </tr> </tbody> </table>	Set Value	Description	0	Operation continues	1	Coasting to a stop and an error message "OPR" is indicated on a digital operator.	
Set Value	Description								
0	Operation continues								
1	Coasting to a stop and an error message "OPR" is indicated on a digital operator.								
o2-07	Cumulative operation time setting	<p>Sets an initial value of cumulative operation time Accumulation of operation time starts from this set value The operator display returns to "0" for o2-07 set value after setting.</p>							
o2-08	Cumulative operation time selection	<p>Defines the operation time.</p> <table border="1" data-bbox="570 687 1219 871"> <thead> <tr> <th data-bbox="570 687 695 738">Set Value</th> <th data-bbox="695 687 1219 738">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="570 738 695 805">0</td> <td data-bbox="695 738 1219 805">All time while the inverter power supply is turned ON is accumulated as operation time.</td> </tr> <tr> <td data-bbox="570 805 695 871">1</td> <td data-bbox="695 805 1219 871">Only the time while the inverter is running is accumulated as operation time.</td> </tr> </tbody> </table>	Set Value	Description	0	All time while the inverter power supply is turned ON is accumulated as operation time.	1	Only the time while the inverter is running is accumulated as operation time.	
Set Value	Description								
0	All time while the inverter power supply is turned ON is accumulated as operation time.								
1	Only the time while the inverter is running is accumulated as operation time.								

# T AUTO-TUNING CONSTANTS

Constant No	Name	Description	Remaks						
T1-02	Auto-tuning mode	<p>Sets the auto-tuning mode Pressing the [RUN] key of the digital operator in the drive mode after setting "2" executes auto-tuning.</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Normal operation mode</td> </tr> <tr> <td>2</td> <td>Auto-tuning mode</td> </tr> </tbody> </table> <p>Returns to "0" automatically after completion of auto-tuning</p>	Set Value	Description	0	Normal operation mode	2	Auto-tuning mode	For auto-tuning, refer to APPENDIX 5 of the instruction manual
Set Value	Description								
0	Normal operation mode								
2	Auto-tuning mode								
T1-03	Auto-tuning item selection	<p>Selects auto-tuning items in the flux vector control mode</p> <table border="1"> <thead> <tr> <th>Set Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Executes all auto-tuning items.</td> </tr> <tr> <td>1</td> <td>Executes only PG origin pulse adjustment</td> </tr> </tbody> </table>	Set Value	Description	0	Executes all auto-tuning items.	1	Executes only PG origin pulse adjustment	
Set Value	Description								
0	Executes all auto-tuning items.								
1	Executes only PG origin pulse adjustment								



# VARISPEED-686SS5

## DESCRIPTIVE MANUAL FOR CONSTANTS

### TOKYO OFFICE

New Pier Takeshiba South Tower, 1-16-1, Kagan, Minatoku, Tokyo 105-0022 Japan  
Phone 81-3-5402-4511 Fax 81-3-5402-4580

### YASKAWA ELECTRIC AMERICA, INC.

**Chicago-Corporate Headquarters**  
2942 MacArthur Blvd Northbrook, IL 60062-2028, U S A  
Phone 1-847-291-2340 Fax 1-847-498-2430

**Chicago-Technical Center**  
3160 MacArthur Blvd Northbrook, IL 60062-1917, U S A  
Phone 1-847-291-0411 Fax 1-847-291-1018

### MOTOMAN INC. HEADQUARTERS

805 Liberty Lane West Carrollton, OH 45449, U S A  
Phone 1-937-847-6200 Fax 1-937-847-6277

### YASKAWA ELÉTRICO DO BRASIL COMÉRCIO LTDA.

Avenida Fagundes Filho, 620 Bairro Saude-Sao Paulo-SP, Brazil CEP 04304-000  
Phone 55-11-5071-2552 Fax 55-11-5581-8795

### YASKAWA ELECTRIC EUROPE GmbH

Am Kronberger Hang 2, 65824 Schwalbach, Germany  
Phone 49-6196-569-300 Fax 49-6196-888-301

### Motoman Robotics AB

Box 504 S38525 Torsås, Sweden  
Phone 46-486-48800 Fax 46-486-41410

### Motoman Robotec GmbH

Kammerfeldstraße 1, 85391 Allershausen, Germany  
Phone 49-8166-900 Fax 49-8166-9039

### YASKAWA ELECTRIC UK LTD.

1 Hunt Hill Orchardton Woods Cumbernauld, G68 9LF, United Kingdom  
Phone 44-1236-735000 Fax 44-1236-458182

### YASKAWA ELECTRIC KOREA CORPORATION

Kipa Bldg #1201, 35-4 Youido-dong, Yeongdungpo-Ku, Seoul 150-010, Korea  
Phone 82-2-784-7844 Fax 82-2-784-8495

### YASKAWA ELECTRIC (SINGAPORE) PTE. LTD

151 Lorong Chuan, #04-01, New Tech Park Singapore 556741, Singapore  
Phone 65-282-3003 Fax 65-289-3003

### YATEC ENGINEERING CORPORATION

Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan  
Phone 886-2-2563-0010 Fax 886-2-2567-4677

### BEIJING OFFICE

Room No 301 Office Building of Beijing International Club, 21  
Jianguomenwai Avenue, Beijing 100020, China  
Phone 86-10-6532-1850 Fax 86-10-6532-1851

### SHANGHAI OFFICE

27 Hui He Road Shanghai 200437 China  
Phone 86-21-6553-6600 Fax 86-21-6531-4242

### YASKAWA JASON (HK) COMPANY LIMITED

Rm 2909-10, Hong Kong Plaza, 186-191 Connaught Road West, Hong Kong  
Phone 852-2803-2385 Fax 852-2547-5773

### TAIPEI OFFICE

Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan  
Phone 886-2-2563-0010 Fax 886-2-2567-4677

### SHANGHAI YASKAWA-TONGJI M & E CO., LTD.

27 Hui He Road Shanghai China 200437  
Phone 86-21-6531-4242 Fax 86-21-6553-6060

### BEIJING YASKAWA BEIKE AUTOMATION ENGINEERING CO., LTD.

30 Xue Yuan Road, Haidian, Beijing P R China Post Code 100083  
Phone 86-10-6233-2782 Fax 86-10-6232-1536

### SHOUGANG MOTOMAN ROBOT CO., LTD.

7, Yongchang-North Street, Beijing Economic Technological Investment & Development Area,  
Beijing 100076, P R China  
Phone 86-10-6788-0551 Fax 86-10-6788-2878



YASKAWA

YASKAWA ELECTRIC CORPORATION