


# AC SERVO DRIVES HR SERIES DESCRIPTIVE MANUAL

FOR MULTI-FUNCTIONS/POSITIONING CONTROL


SERVOMOTOR M,F,G,D,S,R,P SERIES  
SERVOPACK CACR-HR  BAB(RACK-MOUNTED TYPE)  
CACR-HR  BB (BASE-MOUNTED TYPE)



Yaskawa AC Servos have been developed for the most advanced FA and FMS. The extensive servo manufacturing technology accumulated through half a century of servo drive applications has created this series.

AC Servopack CACR-HR is a general-purpose multi-function position controller which applies YASKAWA's long-term positioning control technologies to software.

In addition to realization of high-accuracy and quick response control even under adverse conditions, easy and flexible operation is available with excellent maintainability due to various display functions and protective functions.



### General Precautions

- Some drawings in this manual are shown with the protective cover or shields removed, in order to describe the detail with more clarity. Make sure all covers and shields are replaced before operating this product.
- Some drawings in this manual are shown as typical example and may differ from the shipped product.
- This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications.  
Such modification is made as a revision by renewing the manual No.
- To order a copy of this manual, if your copy has been damaged or lost, contact your YASKAWA representative listed on the last page stating the manual No. on the front cover.
- YASKAWA is not responsible for accidents or damages due to any modification of the product made by the user since that will void our guarantee.

## NOTES FOR SAFE OPERATION


Read this manual thoroughly before installation, operation, maintenance or inspection of the AC Servo Drives. In this manual, the NOTES FOR SAFE OPERATION are classified as "WARNING" or "CAUTION."

### WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious personal injury.

### CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate personal injury and/or damage to the equipment.

In some instances, items described in  CAUTION may also result in a serious accident. In either case, follow these important items.

### WARNING

#### (WIRING)

- Grounding must be in accordance with the national code and consistent with sound local practices.  
Failure to observe this warning may lead to electric shock or fire.

#### (OPERATION)

- Never touch any rotating motor parts during operation.  
Failure to observe this warning may result in personal injury.

#### (INSPECTION AND MAINTENANCE)

- Never open the panel cover while power is ON, and never turn ON power when the panel cover is open.  
Otherwise, electric shock may result.
- After turning OFF power, wait at least five minutes before servicing the product.  
Otherwise, residual electric charges may result in electric shock.

 **CAUTION**

**(RECEIVING)**

- Use the specified combination of **SERVOMOTOR** and **SERVOPACK**.  
Failure to observe this caution may lead to fire or failure.

**(INSTALLATION)**

- Never use the equipment where it may be exposed to splashes of water, corrosive or flammable gases, or near flammable materials.  
Failure to observe this caution may lead to electric shock or fire.

**(WIRING)**

- Do not connect three-phase power supply to output terminals **U**, **V** and **W**.  
Failure to observe this caution may lead to personal injury or fire.
- Securely tighten screws on the power supply and motor output terminals.  
Failure to observe this caution can result in a fire.

**(OPERATION)**

- To avoid inadvertent accidents, run the **SERVOMOTOR** only in test run (without load).  
Failure to observe this caution may result in personal injury.
- Before starting operation with a load connected, make sure emergency-stop procedures are in place.  
Failure to observe this caution may result in personal injury.
- During operation, do not touch the heat sink, regenerative resistance, **SERVOMOTOR** and other peripheral devices.  
Failure to observe this caution may result in burns.
- When Servo Alarm goes off, determine cause and confirm safety before resetting alarm and resuming operation.  
Failure to observe this caution may result in personal injury.

**(INSPECTION AND MAINTENANCE)**

- Do not disassemble the **SERVOMOTOR**.  
Failure to observe this caution may result in electric shock or personal injury.
- Never change wiring while power is **ON**.  
Failure to observe this caution may result in electric shock or personal injury.



<b>1</b>	<b>OUTLINE</b>	<b>9</b>
<b>2</b>	<b>TYPE DESIGNATION AND CONFIGURATION</b>	<b>12</b>
<b>3</b>	<b>RATINGS AND SPECIFICATIONS OF AC SERVOMOTOR</b>	<b>18</b>
<b>4</b>	<b>RATINGS AND SPECIFICATIONS OF AC SERVOPACK</b>	<b>44</b>
<b>5</b>	<b>CONNECTION</b>	<b>55</b>
<b>6</b>	<b>I/O SIGNAL OPERATION AND FUNCTIONS</b>	<b>95</b>
<b>7</b>	<b>SERIAL COMMUNICATION</b>	<b>121</b>
<b>8</b>	<b>PARAMETERS</b>	<b>145</b>
<b>9</b>	<b>DISPLAY/SETTING/MONITOR FUNCTIONS</b>	<b>182</b>
<b>10</b>	<b>INSTALLATION AND WIRING</b>	<b>197</b>
<b>11</b>	<b>TEST RUN, MAINTENANCE, AND INSPECTION</b>	<b>201</b>
<b>12</b>	<b>PERIPHERAL DEVICES</b>	<b>223</b>
<b>13</b>	<b>DIMENSIONS</b>	<b>250</b>
<b>14</b>	<b>APPENDIX PARAMETER SETTING</b>	<b>278</b>

# CONTENTS

	Page		Page
1. OUTLINE .....	9	5.1.1 Basic Connection .....	55
2. TYPE DESIGNATION AND CONFIGURATION .....	12	5.1.2 Typical Connection at Positioning by Station No. ....	56
2.1 TYPE DESIGNATION .....	12	5.1.3 Typical Connection at Positioning by DG-SW Data .....	57
2.2 COMBINATION OF AC SERVOPACK AND SERVOMOTOR .....	14	5.1.4 Typical Connection at Positioning by Serial Communication .....	59
2.3 CONFIGURATION WITH PERIPHERAL DEVICES .....	17	5.1.5 Typical Connection at Positioning by Command Table .....	60
3. RATINGS AND SPECIFICATIONS OF AC SERVOMOTOR .....	18	5.2 MAIN CIRCUIT TERMINAL NAMES AND OUTLINE .....	61
3.1 RATINGS AND SPECIFICATIONS .....	18	5.3 CONNECTOR TERMINAL (2CN) FOR I/O SIGNAL .....	61
3.1.1 M Series .....	18	5.3.1 Applicable Receptacle Specifications .....	61
3.1.2 F Series .....	20	5.3.2 Connector 2CN Layout and Connection .....	62
3.1.3 G Series .....	22	5.3.3 Description and Usage of I/O Signals of Connector 2CN .....	64
3.1.4 D Series .....	24	5.4 CONNECTOR TERMINAL (3CN) FOR ENCODER .....	65
3.1.5 S Series .....	26	5.4.1 Applicable Receptacle and Cable Specifications .....	65
3.1.6 R Series (For 200V) .....	28	5.4.2 Connector 3CN Layout and Connection .....	67
3.1.7 R Series (For 100V) .....	30	5.5 CONNECTOR TERMINAL (4CN) FOR I/O SIGNAL .....	70
3.1.8 P Series .....	32	5.5.1 Applicable Receptacle .....	70
3.2 MECHANICAL CHARACTERISTICS .....	34	5.5.2 Connector 4CN Layout and Connection .....	70
3.2.1 Mechanical Strength .....	34	5.5.3 Description and Usage of I/O Signals of Connector 4CN .....	72
3.2.2 Allowable Radial Load and Thrust Load .....	34	5.6 CONNECTOR TERMINAL (5CN) FOR I/O SIGNAL .....	73
3.2.3 Mechanical Specifications .....	35	5.6.1 Applicable Receptacle Specifications .....	73
3.2.4 Rotating Direction .....	35	5.6.2 Connector 5CN Layout and Connection .....	73
3.2.5 Shock Resistance .....	35	5.6.3 Description and Usage of I/O Signals of Connector 5CN .....	80
3.2.6 Vibration Resistance .....	35	5.7 POWER SUPPLY CONNECTION .....	86
3.2.7 Vibration Class .....	35	5.7.1 Power Supply ON/OFF .....	86
3.3 RECEPTACLES .....	36	5.7.2 Power Supply Line Protection .....	88
3.3.1 Connector Specifications .....	36	5.8 RATED CURRENT AND TYPICAL APPLICABLE CABLE SIZE .....	89
3.3.2 List of Standard Combination .....	40	5.9 NOISE CONTROL .....	91
4. RATINGS AND SPECIFICATIONS OF AC SERVOPACK .....	44	6. I/O SIGNAL OPERATION AND FUNCTIONS .....	95
4.1 RATINGS AND SPECIFICATIONS .....	44	6.1 OPERATION AND FUNCTIONS OF 2CN INPUT SIGNAL .....	95
4.2 INTERNAL BLOCK DIAGRAM .....	46	6.1.1 Signal Timing .....	95
4.3 PROTECTIVE CIRCUIT .....	49	6.1.2 Input Circuit (Refer to Fig. 5.7 for Connection.) .....	95
4.4 PRECAUTIONS FOR APPLICATION .....	52	6.1.3 Signal Operation and Functions .....	96
4.4.1 Overhanging Load .....	52		
4.4.2 Load Inertia ( $J_L$ ) .....	52		
4.4.3 Allowable Cyclic Operating Frequency .....	52		
4.4.4 High Voltage Line .....	53		
4.5 POWER LOSS .....	54		
5. CONNECTION .....	55		
5.1 TYPICAL CONNECTION .....	55		

# CONTENTS

	Page		Page
6.2 OPERATION AND FUNCTIONS OF 5CN INPUT SIGNAL .....	101	10.2 INSTALLATION .....	197
6.2.1 Signal Timing .....	101	10.2.1 Servomotor .....	197
6.2.2 Input Circuit (Refer to Figs. 5.14, 5.15 and 5.16 for Typical Connection.) .....	101	10.2.2 Servopack .....	199
6.2.3 Signal Operation and Functions .....	102	10.3 WIRING PRECAUTIONS .....	200
6.3 OPERATION AND FUNCTIONS OF 2CN/5CN OUTPUT SIGNAL .....	114	11. TEST RUN, MAINTENANCE, AND INSPECTION .....	201
6.3.1 Output Circuit (Refer to Figs. 5.7, 5.14 and 5.15.) .....	114	11.1 CHECK ITEMS BEFORE TEST RUN .....	201
6.3.2 Signal Operation and Functions .....	114	11.1.1 Servomotor .....	201
7. SERIAL COMMUNICATION .....	121	11.1.2 Servopack .....	201
7.1 SPECIFICATIONS .....	121	11.2 TEST RUN PROCEDURES .....	202
7.2 CONTROL CONFIGURATION .....	121	11.2.1 Test-run Preparations .....	202
7.3 COMMAND TRANSMISSION (MASTER CONTROLLER → SERVOPACK) .....	122	11.2.2 Operation Check .....	209
7.3.1 Transmission Method .....	122	11.3 SERVO PERFORMANCE ADJUSTMENT .....	213
7.3.2 How to Use Axis Address .....	123	11.3.1 Parameter Setting .....	213
7.4 TRANSMISSION DATA (SERVOPACK → HOST CONTROLLER) .....	124	11.3.2 Adjusting Method-Kp, Kv' Optimum Setting .....	214
7.5 SERIAL COMMUNICATION AND TYPICAL SERVOPACK RESPONSE .....	125	11.4 INSPECTION AND MAINTENANCE .....	215
7.6 SERIAL COMMUNICATION CONTROL CODE .....	125	11.4.1 AC Servomotor .....	215
7.7 AUTOMATIC TRANSMISSION DATA FROM SERVOPACK .....	126	11.4.2 Servopack .....	215
7.8 SERIAL COMMAND .....	129	11.4.3 Battery Replacement .....	216
7.8.1 Serial Command List .....	129	11.5 TROUBLESHOOTING GUIDE .....	217
7.8.2 Command Functions .....	130	11.5.1 AC Servomotor .....	217
8. PARAMETERS .....	145	11.5.2 Servopack .....	218
8.1 GENERAL PROCEDURE FOR DEFINING PARAMETERS .....	145	12. PERIPHERAL DEVICES .....	223
8.2 PARAMETER LIST .....	149	12.1 COMBINATION OF PERIPHERAL DEVICES .....	223
8.3 PARAMETER FUNCTION DETAILS .....	157	12.2 BRAKE POWER SUPPLY .....	227
9. DISPLAY/SETTING/MONITOR FUNCTIONS .....	182	12.3 BRAKING RESISTOR UNIT (TYPE JUSP-RA03) .....	229
9.1 DISPLAY AND SETTING FUNCTIONS .....	182	12.4 EXTERNAL POSITION INDICATOR (TYPE MCIF-L8[ ]) .....	230
9.1.1 Display .....	182	12.5 DIGITAL SWITCH UNIT (TYPE MCIF-D[ ]) .....	232
9.1.2 Display and Setting Functions for Servopack Type CACR-HR[ ]BAB[ ] .....	184	12.6 CONTACT INPUT UNIT (TYPE MCIF-R86) .....	234
9.1.3 Display and Setting Functions for Servopack Type CACR-HR[ ]BB .....	190	12.7 MANUAL PULSE GENERATOR (TYPE PREH-2C3T/100-M1) .....	236
9.2 MONITOR FUNCTION .....	195	12.8 CONNECTING CABLE .....	238
9.2.1 Servopack Type CACR-HR[ ]BAB[ ] .....	195	12.9 PARAMETER SETTER (PF803) .....	239
9.2.2 Servopack Type CACR-HR[ ]BB .....	196	12.9.1 Specifications .....	239
10. INSTALLATION AND WIRING .....	197	12.9.2 External View .....	242
10.1 RECEIVING .....	197	12.9.3 How to Use .....	243
		13. DIMENSIONS .....	250
		13.1 AC SERVMOTOR WITH ABSOLUTE ENCODER .....	250
		13.2 AC SERVMOTOR WITH INCREMENTAL ENCODER .....	266
		13.3 SERVOPACK .....	276

# CONTENTS (cont'd)

	Page		Page
13.3.1 Rack-mounted Type CACR-HR[ ]BAB[ ]	276	14.7 PARAMETER CHECK LIST	284
13.3.2 Base-mounted Type CACR-HR[ ]BB	277	14.7.1 Parameters Related to Motor Used	284
14. APPENDIX PARAMETER SETTING	278	14.7.2 Parameters Related to Machine Specifications	285
14.1 APPLICATIONS	278	14.7.3 Parameters Related to Position Reference Method	287
14.2 ORDER ELECTRICAL DEVICES	278	14.7.4 Speed Reference Method	287
14.3 MACHINE CONFIGURATION	279	14.7.5 Parameters Related to Position Control	288
14.4 SPECIFICATIONS	279	14.7.6 Selection Function	288
14.5 SPEED DIAGRAM	280		
14.6 PARAMETER SETTING TABLE	281		

## INDEX

	Section NO.	Page		Section No.	Page
<b>A</b>					
AC Servomotor	11.4.1	215	COMBINATION OF PERIPHERAL DEVICES	12.1	223
AC Servomotor	11.5.1	217	Command Functions	7.8.2	130
AC SERVMOTOR WITH ABSOLUTE ENCODER	13.1	250	COMMAND TRANSMISSION (MASTER CONTROLLER → SERVOPACK) 7.3		122
AC SERVMOTOR WITH INCREMENTAL ENCODER	13.2	266	CONFIGURATION WITH PERIPHERAL DEVICES	2.3	17
Adjusting Method-Kp, Kv' Optimum Setting	11.3.2	214	CONNECTING CABLE	12.8	238
Allowable Cyclic Operating Frequency	4.4.3	52	CONNECTION	5	55
Allowable Radial Load and Thrust Load	3.2.2	34	Connector 2CN Layout and Connection	5.3.2	62
APPENDIX PARAMETER SETTING	14	278	Connector 3CN Layout and Connection	5.4.2	67
Applicable Receptacle Specifications	5.3.1	61	Connector 4CN Layout and Connection	5.5.2	70
Applicable Receptacle and Cable Specifications	5.4.1	65	Connector 5CN Layout and Connection	5.6.2	73
Applicable Receptacle	5.5.1	70	Connector Specifications	3.3.1	36
Applicable Receptacle Specifications	5.6.1	73	CONNECTOR TERMINAL (2CN) FOR I/O SIGNAL	5.3	61
APPLICATIONS	14.1	278	CONNECTOR TERMINAL (3CN) FOR ENCODER	5.4	65
AUTOMATIC TRANSMISSION DATA FROM SERVOPACK	7.7	126	CONNECTOR TERMINAL (4CN) FOR I/O SIGNAL	5.5	70
			CONNECTOR TERMINAL (5CN) FOR I/O SIGNAL	5.6	73
<b>B</b>			CONTACT INPUT UNIT (TYPE MCIF-R86)	12.6	234
Base-mounted Type CACR-HR[ ]BB	13.3.2	277	CONTROL CONFIGURATION	7.2	121
Basic Connection	5.1.1	55			
Battery Replacement	11.4.3	216	<b>D</b>		
BRAKE POWER SUPPLY	12.2	227	Description and Usage of I/O Signals of Connector 2CN	5.3.3	64
BRAKING RESISTOR UNIT (TYPE JUSP-RA03)	12.3	229	Description and Usage of I/O Signals of Connector 4CN	5.5.3	72
			Description and Usage of I/O Signals of Connector 5CN	5.6.3	80
<b>C</b>			DIGITAL SWITCH UNIT (TYPE MCIF-D[ ])	12.5	232
CHECK ITEMS BEFORE TEST RUN	11.1	201			
COMBINATION OF AC SERVOPACK AND SERVMOTOR	2.2	14			

# INDEX

	Section NO.	Page
DIMENSIONS .....	13	250
Display .....	9.1.1	182
DISPLAY AND SETTING FUNCTIONS .....	9.1	182
Display and Setting Functions for Servopack		
Type CACR-HR{ }BAB{ } .....	9.1.2	184
Display and Setting Functions for Servopack		
Type CACR-HR{ }BB .....	9.1.3	190
DISPLAY/SETTING/MONITOR FUNCTIONS .....	9	182
D Series .....	3.1.4	24
<b>E</b>		
External View .....	12.9.2	242
EXTERNAL POSITION INDICATOR (TYPE MCIF-L8{ }) .....	12.4	230
<b>F</b>		
F Series .....	3.1.2	20
<b>G</b>		
GENERAL PROCEDURE FOR DEFINING PARAMETERS .....	8.1	145
G Series .....	3.1.3	22
<b>H</b>		
High Voltage Line .....	4.4.4	53
How to Use .....	12.9.3	243
How to Use Axis Address .....	7.3.2	123
<b>I</b>		
I/O SIGNAL OPERATION AND FUNCTIONS .....	6	95
Input Circuit (Refer to Fig. 5.7 for Connection.) .....	6.1.2	95
Input Circuit (Refer to Figs. 5.14, 5.15 and 5.16 for Typical Connection.) .....	6.2.2	101
INSPECTION AND MAINTENANCE .....	11.4	215
INSTALLATION .....	10.2	197
INSTALLATION AND WIRING .....	10	197
INTERNAL BLOCK DIAGRAM .....	4.2	46
<b>L</b>		
List of Standard Combination .....	3.3.2	40
Load Inertia (J <sub>L</sub> ) .....	4.4.2	52

## M

MACHINE CONFIGURATION .....	14.3	279
MAIN CIRCUIT TERMINAL NAMES AND OUTLINE .....	5.2	61
MANUAL PULSE GENERATOR (TYPE PREH-2C3T/100-M1) .....	12.7	236
MECHANICAL CHARACTERISTICS .....	3.2	34
Mechanical Specifications .....	3.2.3	35
Mechanical Strength .....	3.2.1	34
MONITOR FUNCTION .....	9.2	195
M Series .....	3.1.1	18

## N

NOISE CONTROL .....	5.9	91
---------------------	-----	----

## O

OPERATION AND FUNCTIONS OF 2CN INPUT SIGNAL .....	6.1	95
OPERATION AND FUNCTIONS OF 5CN INPUT SIGNAL .....	6.2	101
OPERATION AND FUNCTIONS OF 2CN/5CN OUTPUT SIGNAL .....	6.3	114
Operation Check .....	11.2.2	209
ORDER ELECTRICAL DEVICES .....	14.2	278
OUTLINE .....	1	9
Output Circuit (Refer to Figs. 5.7, 5.14 and 5.15.) .....	6.3.1	114
Overhanging Load .....	4.4.1	52

## P

PARAMETER CHECK LIST .....	14.7	284
PARAMETER FUNCTION DETAILS .....	8.3	157
PARAMETER LIST .....	8.2	149
Parameters Related to Motor Used .....	14.7.1	284
Parameters Related to Position Reference Method .....	14.7.3	287
Parameters Related to Position Control .....	14.7.5	288
PARAMETERS .....	8	145
Parameters Related to Machine Specifications .....	14.7.2	285
PARAMETER SETTER (PF803) .....	12.9	239
Parameter Setting .....	11.3.1	213

## INDEX (cont'd)

	Section NO.	Page		Section No.	Page
PARAMETER SETTING TABLE .....	14.6	281	SERVOPACK .....	13.3	276
PERIPHERAL DEVICES .....	12	223	Servopack Type CACR-HR[ ]BAB[ ] .....	9.2.1	195
POWER LOSS .....	4.5	54	Servopack Type CACR-HR[ ]BB .....	9.2.2	196
POWER SUPPLY CONNECTION .....	5.7	86	SERVO PERFORMANCE ADJUSTMENT .....	11.3	213
Power Supply Line Protection .....	5.7.2	88	Shock Resistance .....	3.2.5	35
Power Supply ON/OFF .....	5.7.1	86	Signal Operation and Functions .....	6.1.3	96
PRECAUTIONS FOR APPLICATION .....	4.4	52	Signal Operation and Functions .....	6.2.3	102
PROTECTIVE CIRCUIT .....	4.3	49	Signal Operation and Functions .....	6.3.2	114
P Series .....	3.1.8	32	Signal Timing .....	6.1.1	95
<b>R</b>			Signal Timing .....	6.2.1	101
Rack-mounted Type			SPECIFICATIONS .....	7.1	121
CACR-HR[ ]BAB[ ] .....	13.3.1	276	SPECIFICATIONS .....	14.4	279
RATED CURRENT AND TYPICAL			Specifications .....	12.9.1	239
APPLICABLE CABLE SIZE .....	5.8	89	SPEED DIAGRAM .....	14.5	280
RATINGS AND SPECIFICATIONS OF			Speed Reference Method .....	14.7.4	287
AC SERVOMOTOR .....	3	18	S Series .....	3.1.5	26
RATINGS AND SPECIFICATIONS .....	3.1	18	<b>T</b>		
RATINGS AND SPECIFICATIONS OF			TEST RUN, MAINTENANCE,		
AC SERVOPACK .....	4	44	AND INSPECTION .....	11	201
RATINGS AND SPECIFICATIONS .....	4.1	44	Test-run Preparations .....	11.2.1	203
RECEIVING .....	10.1	197	TEST RUN PROCEDURES .....	11.2	202
RECEPTACLES .....	3.3	36	TRANSMISSION DATA		
Rotating Direction .....	3.2.4	35	(SERVOPACK → HOST CONTROLLER) .....	7.4	124
R Series (For 100V) .....	3.1.7	30	Transmission Method .....	7.3.1	122
R Series (For 200V) .....	3.1.6	28	TROUBLESHOOTING GUIDE .....	11.5	217
<b>S</b>			TYPICAL CONNECTION .....	5.1	55
Selection Function .....	14.7.6	288	Typical Connection at Positioning		
SERIAL COMMAND .....	7.8	129	by Station No. ....	5.1.2	56
Serial Command List .....	7.8.1	129	TYPE DESIGNATION AND CONFIGURATION .....	2	12
SERIAL COMMUNICATION .....	7	121	TYPE DESIGNATION .....	2.1	12
SERIAL COMMUNICATION AND			Typical Connection at Positioning		
TYPICAL SERVOPACK RESPONSE .....	7.5	125	by DG-SW Data .....	5.1.3	57
SERIAL COMMUNICATION			Typical Connection at Positioning		
CONTROL CODE .....	7.6	125	by Serial Communication .....	5.1.4	59
Servomotor .....	10.2.1	197	Typical Connection at Positioning by Command Table .....	5.1.5	60
Servomotor .....	11.1.1	201	<b>V</b>		
Servopack .....	10.2.2	199	Vibration Class .....	3.2.7	35
Servopack .....	11.1.2	201	Vibration Resistance .....	3.2.6	35
Servopack .....	11.4.2	215	<b>W</b>		
Servopack .....	11.5.2	218	WIRING PRECAUTIONS .....	10.3	200

# 1 OUTLINE

Servopack types CACR-HR [ ] [ ] [ ] BAB and -HR [ ] [ ] [ ] BB are single axis position controller and servo amplifier for AC Servomotor.

Input method of positioning data (speed, position) can be selected from Table 1.1 by setting parameters. Each input method has four operation modes described in Table 1.2. All servo constants are set by parameters. Therefore, adjustment can be performed properly without dispersion.

This manual describes functions and use of Servopack types CACR-HR [ ] [ ] [ ] BAB and -HR [ ] [ ] [ ] BB and to realize their full performance. Read this manual to customize the use of this drive and improve performance for the machines.

Table 1.1 Input Method

Input Method	Description
Serial Communication Input	Positioning data are input by serial commands. Commands can be sent to 16 Servopacks with one master controller by connecting with multi-drop method.
Station No. Input	Indexing positioning is performed. Numbers provided to indexing points (station numbers) are input as position data. Speed data are selected from four types of speed set in the Servopack by parameters, by speed selection signals. Both "one-way rotation" and "short-cut rotation" are possible. <ul style="list-style-type: none"> <li>• Range of station numbers <ul style="list-style-type: none"> <li>Binary coded decimal(BCD): 0 to 999</li> <li>Binary: 0 to 4095</li> </ul> </li> </ul>
Digital Switch(DG-SW) (Thumbwheel switch) Input	Positioning data are input by contacts from digital switches, relays or sequencers. <ul style="list-style-type: none"> <li>• Range of positioning data <ul style="list-style-type: none"> <li>Speed: Up to 6 digits</li> <li>Position: Sign + up to 8 digits</li> </ul> </li> </ul> <p>Note: According to strobe signal, HR drive reads DG-SW input data in time divisions of 2 digits. Therefore, YASKAWA's exclusive digital switch is recommended. When another digital switch or relay is used, use "contact input unit". When data are directly input from the PLC, it is necessary to set scan time of HR drive (24 to 2000 ms, variable) to match sequencer scan time.</p>
Command Table Input	Positioning data are selected from the command table set in the Servopack by using the positioning data selection signals. Positioning data are selected in the form of position and speed as a pair : Up to 64 patterns can be selected.

Table 1.2 Operation Modes

Operation Mode	Contents
Automatic Mode	After positioning data are input, positioning is performed based on the data by turning on start signal.
Manual Mode	While manual operation signal is turned on, operation is performed at constant speed.
Pulse Mode	Positioning is performed by pulse train command given by an external pulse generator.  <ul style="list-style-type: none"> <li>• Pulse method: Line driver/line receiver method</li> <li>• Pulse form: 90° phase difference 2-phase pulse train                (up to 1.6 Mpps)                Sign + pulse train (up to 400 kpps)                CW + CCW pulse train (up to 400 kpps)</li> <li>• Pulse multiplication: ×1, ×10, ×100</li> </ul>
Zero-point Return (Homing) Mode	Used for zero-point return (homing) when incremental encoder is used. Two types of methods can be selected. (1) Decel limit switch and encoder Cφ-pulse signal are used. (2) Only stop limit switch is used.

**Software Revised Version**

Some functions of the CACR-HR type have been added with the revised software. Concerning the additional functions in Table 1.3, check the software version before use.

Table 1.3 Software Version Adjustable for Additional Functions

Function	Software Version	
	HRG003BAB	HRG003BB
Command table method and zone signal	3 and upper	HRG006 and upper
Positioning completion signal change		
Positioning command error detection		
Extension of station No. output	4 and upper	HRG008 and upper
Addition of Servopack response axis addresses		



Software Version Indication Position

Figs.1.1 and 1.2 show the software version indications.




Fig. 1.1 Software Version Indication of HR [ ] [ ] BAB





Fig. 1.2 Software Version Indication of HR [ ] [ ] BB

# 2


## TYPE DESIGNATION AND CONFIGURATION

### 2.1 TYPE DESIGNATION

#### (1) Servomotor



#### (2) Servopack



\*1

Encoder Specification	Series	Type
Absolute 8192P/R	M	USAMED-03BS to -60BS
	F	USAFED-02CS to -44CS
	G	USAGED-02AS to -44AS
	D	USADED-05ES to -37ES
	S	USASEM-02AS to -30AS
	R	USAREM-A5CS(200V) to -07CS USAREM-A5DS(100V) to -05DS
Absolute 1024P/R	M	USAMED-03BW to -60BW
	F	USAFED-02CW to -44CW
	G	USAGED-02AW to -44AW
	D	USADED-05EW to -37EW
	S	USASEM-02AW to -30AW
	P	USAPEM-01CW to -07CW

Encoder Specification	Series	Type
Incremental 2048P/R	M	USAMED-03C3 -06C3 -09B3 to -60B3
	F	USAFED-02D3 to -09D3 -13C3 to -44C3
	G	USAGED-02C3 to -09C3 -13A3 to -44A3
	D	USADED-05E3 to -37E3
	S	USASEM-02A3 to -30A3
	Incremental 8192P/R	M
F		USAFED-02D2 -03D2 -05C2 to -44C2
G		USAGED-02C2 -03C2 -05A2 to -44A2
Incremental 2500P/R	D	USADED-05E2 to -37E2
	S	USASEM-02A4 to -30A4

2

## 2.2 COMBINATION OF AC SERVOPACK AND SERVOMOTOR

Table 2.1 Rack-mounted Type Servopack (200 VAC)

Configuration, Main Circuit Voltage		Rack-mounted Type, Single-phase 200VAC					Rack-mounted Type, 3-phase 200VAC			
Type CACR-HR		A5BAB12	O1BAB12	O2BAB12	O3BAB12	O5BAB12	10BAB		15BAB	
M Series	Applicable Servomotor	Type USAMED-	—	—	—	O3 [ ] 1	—	O6 [ ] 1	O9B [ ] 1	12B [ ] 1
		Output kW HP	—	—	—	0.3 0.4	—	0.6 0.8	0.9 1.2	1.2 1.6
		Speed r/min	—	—	—	Rating 1000/Max. 2000		Rating 1000/Max. 2000		
	Continuous Output Current Arms	—	—	—	3.0		—	5.8	7.6	11.7
	Max Output Current Arms	—	—	—	7.3		—	13.9	16.6	28.0
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	—	67.5 60		—	121.5 107.5	183.5 162.5	290 256
F Series	Applicable Servomotor	Type USAFED-	—	—	—	O2 [ ] 1	O3 [ ] 1	O5 [ ] 1	O9 [ ] 1	13C [ ] 2
		Output kW HP	—	—	—	0.15 0.2	0.3 0.4	0.45 0.6	0.85 1.1	1.3 1.7
		Speed r/min	—	—	—	Rating 1500/Max. 2500			Rating 1500/Max. 2500	
	Continuous Output Current Arms	—	—	—	3.0	3.0	3.8	6.2		9.7
	Max Output Current Arms	—	—	—	8.5	8.5	11.0	17.0		27.6
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	—	6.5 5.75	10.3 9	67.5 60	121.5 107.5	183.5 162.5	
G Series	Applicable Servomotor	Type USAGED-	—	—	—	O2 [ ] 1	O3 [ ] 1	O5 [ ] 1	O9 [ ] 1	13A [ ] 2
		Output kW HP	—	—	—	0.15 0.2	0.3 0.4	0.45 0.6	0.85 1.1	1.3 1.7
		Speed r/min	—	—	—	Rating 1500/Max. 3000			Rating 1500/Max. 3000	
	Continuous Output Current Arms	—	—	—	3.0	3.0	3.8	7.6		11.7
	Max Output Current Arms	—	—	—	8.5	8.5	11.0	17.0		28.0
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	—	6.5 5.75	10.3 9	67.5 60	121.5 107.5	183.5 162.5	
D Series	Applicable Servomotor	Type USADED-	—	—	—	—	O5E [ ]	—	—	10E [ ]
		Output kW HP	—	—	—	—	0.5 0.67	—	—	1.0 1.3
		Speed r/min	—	—	—	—	Rating 2000 Max. 2500		—	Rating 2000 Max. 2500
	Continuous Output Current Arms	—	—	—	—	3.5		—	7.9	
	Max Output Current Arms	—	—	—	—	10.6		—	25.2	
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	—	—	105 91		—	180 143	
S Series	Applicable Servomotor	Type USASEM-	—	—	O2A [ ] 2	O3A [ ] 2	O5A [ ] 2	O8A [ ] 2	15A [ ] 2	
		Output kW HP	—	—	0.154 0.2	0.308 0.4	0.462 0.6	0.771 1.0	1.54 2.1	
		Speed r/min	—	—	Rating 3000/Max. 4000			Rating 3000/Max. 4000		
	Continuous Output Current Arms	—	—	2.1	3.0	4.2	5.3		10.4	
	Max Output Current Arms	—	—	6.0	8.5	11.0	15.6		28.0	
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	0.65 0.55	2.55 2.25	3.75 3.35	14.25 12.65		16.5 14.4	

Table 2.1 Rack-mounted Type Servopack (200 VAC) (Cont'd)

Configuration, Main Circuit Voltage		Rack-mounted Type, Single-phase 200VAC					Rack-mounted Type, 3-phase 200VAC			
Type CACR-HR		A5BAB12	01BAB12	02BAB12	03BAB12	05BAB12	10BAB	15BAB		
R Series	Applicable Servomotor	Type USAPEM-	A5CS	01CS	02CS	03CS	05CS	07CS	—	
		Output W HP	50 0.07	100 0.13	200 0.27	300 0.40	500 0.67	700 0.94	—	
		Speed r/min	Rating 3000/Max. 4500					Rating 3000/Max. 4500		—
	Continuous Output Current Arms	0.71	1.0	2.0	2.7	3.6	5.7	—		
	Max Output Current Arms	2.1	2.8	5.7	7.8	10.6	16.3	—		
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $oz \cdot in \cdot S^2 \times 10^{-3}$	0.775 10.8	1.25 17.8	5.075 71.8	7.65 109	27.2 386	37.2 528	—		
P Series	Applicable Servomotor	Type USAPEM-	—	01CW	02CW	03CW	05CW	07CW	—	
		Output W HP	—	100 0.13	200 0.27	300 0.40	500 0.67	700 0.94	—	
		Speed r/min	—	Rating 3000/Max. 4500					Rating 3000/Max. 4500	
	Continuous Output Current Arms	—	1.0	2.0	2.7	3.6	5.7	—		
	Max Output Current Arms	—	2.8	5.7	7.8	10.6	16.3	—		
	Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $oz \cdot in \cdot S^2 \times 10^{-3}$	—	1.95 27.75	3.2 45.15	4.9 69.5	23.9 339	32.85 465	—		

Table 2.2 Rack-mounted Type Servopack (Single-phase 100VAC)

Configuration, Main Circuit Voltage		Rack-mounted Type, Single-phase 100VAC					
Type CACR-HR		A5BAB11	01BAB11	02BAB11	03BAB11	05BAB11	
R Series	Applicable Servomotor	Type USAPEM-	A5DS	01DS	02DS	03DS	05DS
		Output W HP	50 0.07	100 0.13	200 0.27	300 0.40	500 0.67
		Speed r/min	Rating 3000/Max. 4000				
	Continuous Output Current Arms	1.2	1.7	2.9	3.6	5.5	
Max Output Current Arms	3.6	5.0	8.5	10.6	16.3		
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $oz \cdot in \cdot S^2 \times 10^{-3}$	0.775 10.8	1.25 17.8	5.075 71.8	7.65 109	27.2 386		

Note: Combination of Servomotor and encoder is as shown below:

Servomotor	No. of Pulses	Incremental Encoder			Absolute Encoder	
		2048	2500	8192	1024	8192
M Series	○	—	◎	○	◎	
F Series	○	—	◎	○	◎	
G Series	○	—	◎	○	◎	
D Series	◎	—	○	◎	○	
S Series	◎	○	—	○	◎	
R Series	—	—	—	—	◎	
P Series	—	—	—	◎	—	


◎ Standard  
○ Semi-standard

Table 2.3 Base-mounted Type Servopack (3-phase 200VAC)


Configuration, Main Circuit Voltage		Base-mounted Type, 3-phase 200VAC									
Type CACR-HR		03BB	05BB	10BB		15BB	20BB	30BB	44BB	60BB	
M Series	Type USAMED-	03B [ ] 1	—	06B [ ] 1	09B [ ] 2	12B [ ] 2	20B [ ] 2	30B [ ] 2	44B [ ] 2	USAMKD -60B [ ] 2	
	Output kW HP	0.3 0.4	—	0.6 0.8	0.9 1.2	1.2 1.6	2.0 2.7	3.0 4.0	4.4 5.9	6.0 8.0	
	Speed r/min	Rating 1000/ Max. 2000	—	Rating 1000/Max. 2000					Rating 1000/Max. 1500		
	Continuous Output Current Arms	3.0	—	5.8	7.6	11.7	18.8	26.0	33.0	45.0	
	Max Output Current Arms	7.3	—	13.9	16.6	28.0	42.0	56.5	70.0	80.6	
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	67.5 60	—	121.5 107.5	183.5 162.5	290 256	550 486	715 633.5	1200 1063	1200 1063		
F Series	Type USAFED-	02 [ ] 1	03 [ ] 1	05 [ ] 1	09 [ ] 1	13C [ ] 2	20C [ ] 2	30C [ ] 2	44C [ ] 2	—	
	Output kW HP	0.15 0.2	0.3 0.4	0.45 0.6	0.85 1.1	1.3 1.7	1.8 2.4	2.9 3.9	4.4 5.9	—	
	Speed r/min	Rating 1500/Max. 2500									
	Continuous Output Current Arms	3.0	3.0	3.8	6.2	9.7	15.0	20.0	30.0	—	
	Max Output Current Arms	8.5	8.5	11.0	17.0	27.6	42.0	56.5	77.0	—	
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	6.5 5.75	10.3 9	67.5 60	121.5 107.5	183.5 162.5	290 256	550 486	715 633.5	—		
C Series	Type USAGED-	02 [ ] 1	03 [ ] 1	05 [ ] 1	09 [ ] 1	13A [ ] 2	20A [ ] 2	30A [ ] 2	44A [ ] 2	—	
	Output kW HP	0.15 0.2	0.3 0.4	0.45 0.6	0.85 1.1	1.3 1.7	1.8 2.4	2.9 3.9	4.4 5.9	—	
	Speed r/min	Rating 1500/Max. 3000									
	Continuous Output Current Arms	3.0	3.0	3.8	7.6	11.7	19.0	26.0	33.0	—	
	Max Output Current Arms	8.5	8.5	11.0	17.0	28.0	42.0	56.5	70.0	—	
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	6.5 5.75	10.3 9	67.5 60	121.5 107.5	183.5 162.5	290 256	550 486	715 633.5	—		
D Series	Type USADED-	—	—	05E [ ]	—	10E [ ]	15E [ ]	22E [ ]	37E [ ]	—	
	Output kW HP	—	—	0.5 0.67	—	1.0 1.3	1.5 2.0	2.2 2.9	3.7 5.0	—	
	Speed r/min	—	—	Rating 2000 Max. 2500	—	Rating 2000/Max. 2500				—	
	Continuous Output Current Arms	—	—	3.5	—	7.9	12.6	16.6	23.3	—	
	Max Output Current Arms	—	—	10.6	—	25.2	40.6	54.0	76.7	—	
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $lb \cdot in \cdot S^2 \times 10^{-3}$	—	—	105 91	—	160 143	310 274.5	415 367.5	740 655	—		
S Series	Type USASEM-	02A [ ] 2	03A [ ] 2	05A [ ] 2	08A [ ] 2	15A [ ] 2	—	30A [ ] 2	—	—	
	Output kW HP	0.154 0.2	0.308 0.4	0.462 0.6	0.771 1.0	1.54 2.1	—	3.08 4.1	—	—	
	Speed r/min	Rating 3000/Max. 4000					—	Rating 3000 Max. 4000	—	—	
	Continuous Output Current Arms	2.1	3.0	4.2	5.3	10.4	—	19.9	—	—	
	Max Output Current Arms	6.0	8.5	11.0	15.6	28.0	—	56.5	—	—	
Allowable Load Inertia $kg \cdot cm^2$ $J_L (=GD^2_L/4)$ $oz \cdot in \cdot S^2 \times 10^{-3}$	0.65 0.55	2.55 2.25	3.75 3.35	14.25 12.65	16.5 14.4	—	28.7 25.45	—	—		

## 2.3 CONFIGURATION WITH PERIPHERAL DEVICES


Option



(See Par. 12. 1.)




Option




(See Par. 3. 3.)




Main Body




Attachment



(See Pars. 5. 3. to 5. 6.)





Option



(See par. 12. 8.)

Option



(See Yaskawa Controls Co., Ltd. Catalog HSE-CO-16)

# 3

## RATINGS AND SPECIFICATIONS OF AC SERVOMOTOR

### 3.1 RATINGS AND SPECIFICATIONS

#### 3.1.1 M Series

##### (1) Ratings

Time Rating: Continuous

Insulation: Class F

Isolation Voltage: 1500 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled for 03 to 44 and externally fan-cooled for 60; IP65 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Ambient Humidity: 20% to 80% (non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

##### (2) Combination with encoder

###### • Standard

USAM000 - 0000 BS 00 : With absolute encoder (8192 pulses/rev)

USAM000 - 0000 B2 00 : With incremental encoder (8192 pulses/rev)

###### • Semi-Standard

USAM000 - 0000 BW 00 : With absolute encoder (1024 pulses/rev)

USAM000 - 0000 B3 00 : With incremental encoder (2048 pulses/rev) (09 to 60)

USAMED - 0000 C3 00 : With incremental encoder (2048 pulses/rev) (03, 06)

Table 3.1 Ratings and Specifications of M Series AC Servomotors

Item	Motor Type USAMED-	USAMKD-							
		03 000 1	06 000 1	09B 00 2	12B 00 2	20B 00 2	30B 00 2	44B 00 2	60B 00 2
Rated Output*	kW (HP)	0.3 (0.4)	0.6 (0.8)	0.9 (1.2)	1.2 (1.6)	2.0 (2.7)	3.0 (4.0)	4.4 (5.9)	6.0 (8.0)
Rated Torque*	N·m (lb·in)	2.84 (25)	5.68 (50)	8.62 (76)	11.5 (102)	19.1 (169)	28.4 (252)	41.9 (372)	57.2 (507)
Continuous Max. Torque*	N·m (lb·in)	2.94 (26)	5.88 (52)	8.82 (78)	11.8 (104)	21.6 (191)	32.3 (286)	46.1 (408)	62.9 (557)
Instantaneous Peak Torque*	N·m (lb·in)	7.17 (63)	14.1 (125)	19.3 (171)	28.0 (248)	44.0 (390)	63.7 (564)	91.1 (807)	106 (938)
Rated Current*	A	3.0	5.8	7.6	11.7	18.8	26	33	45
Rated Speed*	r/min	1000							
Instantaneous Max. Speed*	r/min	2000						1500	
Torque Constant	N·m/A (lb·in/A)	1.01 (8.9)	1.04 (9.2)	1.21 (10.7)	1.02 (9.0)	1.07 (9.5)	1.16 (10.2)	1.33 (11.8)	1.33 (11.8)
Moment of Motor Inertia $J_w (=GD^2_w/4)$	Kg·m <sup>2</sup> ×10 <sup>-4</sup> (lb·in·s <sup>2</sup> ×10 <sup>-3</sup> )	13.5 (12.0)	24.3 (21.5)	36.7 (32.5)	58 (51.2)	110 (97.2)	143 (126.7)	240 (212.6)	240 (212.6)
Power Rate*	kW/s	6.0	13.3	20.3	22.7	33.2	57.0	74.0	138
Inertia Time Constant	ms	12.8	6.3	4.4	6.0	5.2	3.5	3.6	3.6
Inductive Time Constant	ms	2.7	5.1	6.5	10.4	12.9	15.3	16.2	16.2

\* Typical value at armature winding temperature of 20°C, in combination with Servopack.




### (3) Speed-torque characteristics

Typical at 20°C (Armature Winding Temp.)


**A**: Continuous Duty Zone

**B**: Intermittent Duty Zone


**USAMED-03**




**USAMED-06**




**USAMED-09B**




**USAMED-12B**




**USAMED-20B**




**USAMED-30B**



**USAMED-44B**



**USAMKD-60B**



### 3.1.2 F Series

#### (1) Ratings

Time Rating: Continuous

Insulation: Class F

Isolation Voltage: 1500 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;  
IP65 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

#### (2) Combination with encoder

##### • Standard

USAFED- [ ] CS [ ] : With absolute encoder (8192 pulses/rev)

USAFED- [ ] C2 [ ] : With incremental encoder (8192 pulses/rev) (05 to 44)

USAFED- [ ] D2 [ ] : With incremental encoder (8192 pulses/rev) (02, 03)

##### • Semi-Standard

USAFED- [ ] CW [ ] : With absolute encoder (1024 pulses/rev)

USAFED- [ ] C3 [ ] : With incremental encoder (2048 pulses/rev) (13 to 44)

USAFED- [ ] D3 [ ] : With incremental encoder (2048 pulses/rev) (02 to 09)

Table 3.2 Ratings and Specifications of F Series AC Servomotors

Item	Motor Type USAFED-	02 [ ] 1	03 [ ] 1	05 [ ] 1	09 [ ] 1	13C [ ] 2	20C [ ] 2	30C [ ] 2	44C [ ] 2
Rated Output*	kW (HP)	0.15 (0.2)	0.3 (0.4)	0.45 (0.6)	0.85 (1.1)	1.3 (1.7)	1.8 (2.4)	2.9 (3.9)	4.4 (5.9)
Rated Torque*	N·m (lb·in)	0.98 (8.7)	1.96 (17)	2.84 (25)	5.39 (48)	8.34 (74)	11.5 (102)	18.6 (165)	28.4 (252)
Continuous Max. Torque*	N·m (lb·in)	1.08 (10)	2.16 (19)	2.94 (26)	5.88 (52)	8.83 (78)	11.8 (104)	22.6 (200)	37.3 (330)
Instantaneous Peak Torque*	N·m (lb·in)	2.91 (26)	5.82 (52)	8.92 (79)	15.2 (135)	24.7 (219)	34.0 (301)	54.1 (479)	76.2 (675)
Rated Current*	A	3.0	3.0	3.8	6.2	9.7	15	20	30
Rated Speed*	r/min	1500							
Instantaneous Max. Speed*	r/min	2500							
Torque Constant	N·m/A (lb·in/A)	0.36 (3.2)	0.72 (6.3)	0.8 (7.1)	0.92 (8.2)	0.92 (8.2)	0.82 (7.3)	0.98 (8.7)	1.02 (9.0)
Moment of Motor Inertia $J_w (=GD^2_w/4)$	Kg·m <sup>2</sup> × 10 <sup>-4</sup> (lb·in·S <sup>2</sup> × 10 <sup>-3</sup> )	1.30 (1.2)	2.06 (1.8)	13.5 (12.0)	24.3 (21.5)	36.7 (32.5)	58 (51.2)	110 (97.2)	143 (126.7)
Power Rate*	kW/s	7.4	18.3	6.0	12	18.9	22.7	31.5	57.0
Inertia Time Constant	ms	3.9	2.5	10.9	6.0	4.4	5.9	5.2	3.7
Inductive Time Constant	ms	3.4	4.3	3.2	5.2	6.1	10.4	13.0	15.2

\* Typical value at armature winding temperature of 20°C, in combination with Servopack.

(3) Speed-torque characteristics


Series 3000

Typical at 20°C (Armature, Winding Temp.)


**A** Continuous Duty Zone

**B** Intermittent Duty Zone


USAFED-02




USAFED-03




USAFED-05




USAFED-09




USAFED-13C




USAFED-20C



USAFED-30C



USAFED-44C



3

### 3.1.3 G Series

#### (1) Ratings

Time Rating: Continuous

Insulation: Class F

Isolation Voltage: 1500 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;  
IP65 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

#### (2) Combination with encoder

##### . Standard

USAGED-~~0000~~A S ~~00~~ With absolute encoder (8192 pulses/rev)

USAGED-~~0000~~A 2 ~~00~~ With incremental encoder (8192 pulses/rev) (05 to 44)

USAGED-~~0000~~C 2 ~~00~~ With incremental encoder (8192 pulses/rev) (02, 03)

##### . Semi-Standard

USAGED-~~0000~~AW ~~00~~ : With absolute encoder (1024 pulses/rev)

USAGED-~~0000~~A 3 ~~00~~ With incremental encoder (2048 pulses/rev) (13 to 44)

USAGED-~~0000~~ C3 ~~00~~ : With incremental encoder (2048 pulses/rev) (02 to 09)

Table 3.3 Ratings and Specifications of G Series AC Servomotors

Item	Motor Type USAGED-	Motor Type USAGED-							
		02 <del>0000</del> 1	03 <del>0000</del> 1	05 <del>0000</del> 1	09 <del>0000</del> 1	13A <del>00</del> 2	20A <del>00</del> 2	30A <del>00</del> 2	44A <del>00</del> 2
Rated Output*	kW (HP)	0.15 (0.2)	0.3 (0.4)	0.45 (0.6)	0.85 (1.1)	1.3 (1.7)	1.8 (2.4)	2.9 (3.9)	4.4 (5.9)
Rated Torque*	N·m (lb·in)	0.98 (8.7)	1.96 (17)	2.84 (25)	5.39 (48)	8.34 (74)	11.5 (102)	18.6 (165)	28.4 (252)
Continuous Max. Torque*	N·m (lb·in)	1.08 (10)	2.16 (19)	2.94 (26)	5.88 (52)	8.83 (78)	11.8 (104)	22.6 (200)	37.3 (330)
Instantaneous Peak Torque*	N·m (lb·in)	2.91 (26)	5.83 (52)	8.92 (79)	13.3 (118)	23.3 (207)	28.0 (248)	45.1 (400)	66.2 (587)
Rated Current*	A	3.0	3.0	3.8	7.6	11.7	19.0	26.0	33.0
Rated Speed'	r/min	1500							
Max. Speed*	r/min	3000							
Torque Constant	N·m/A (lb·in/A)	0.36 (3.2)	0.72 (6.3)	0.80 (7.1)	0.80 (7.1)	0.83 (7.4)	0.67 (5.9)	0.80 (7.1)	0.95 (8.4)
Moment of Inertia J <sub>m</sub> (=GD <sub>m</sub> <sup>2</sup> /4)	kg·m <sup>2</sup> × 10 <sup>-4</sup> (lb·in·s <sup>2</sup> × 10 <sup>-3</sup> )	1.3 (1.2)	2.06 (1.8)	13.5 (12.0)	24.3 (21.5)	36.7 (32.5)	57.9 (51.2)	110 (97.2)	143 (126.7)
Power Rate'	kW/s	7.4	18.3	6.0	12.0	18.9	22.7	36.5	57.0
Inertia Time Constant	ms	4.5	2.5	10.9	6.1	4.3	5.8	5.2	3.4
Inductive Time Constant	ms	3.4	4.3	3.2	5.2	6.7	10.4	13.2	15.9


\* Typical value at armature winding temperature of 20°C. in combination with Servopack.

### (3) Speed-torque characteristics


Typical at 20°C (Armature Winding Temp.)

 : Continuous Duty Zone  
 : Intermittent Duty Zone


USAG ED-02




USAGED-03




USAGED-05




USAGED-09




USAGED-13A




USAGED-20A



USAGED-30A



USAGED-44A



### 3.1.4 D Series

#### (1) Ratings

Time Rating: Continuous

Vibration: 15 $\mu$ m or below

Insulation: Class F

Finish in Munsell Notation: N1.5

Isolation Voltage: 1500 VAC, one minute

Excitation: Permanent magnet

Insulation Resistance: 500 VDC, 10M $\Omega$  or more

Mounting: Flange mounted

Enclosure: Totally-enclosed, self-cooled;  
IP65 (exclusive of shaft opening)

Drive Method: Direct drive

Holding Brake Provided

Ambient Temperature: 0 to + 40°C

Ambient Humidity: 20% to 80%(non-condensing)

#### (2) Combination with encoder

##### • Standard

USADED- [ ] EW : With absolute encoder (1024 pulses/rev)

USADED- [ ] E3 : With incremental encoder (2048 pulses/rev)

##### • Semi-Standard

USADED- [ ] ES : With absolute encoder (8192 pulses/rev)

USADED- [ ] E2 : With incremental encoder (8192 pulses/rev)

Table 3.4 Ratings and Specifications of D Series AC Servomotors

Item	Motor Type USADED-	05E [ ]	10E [ ]	15E [ ]	22E [ ]	37E [ ]
Rated Output*	kW (HP)	0.5 (0.67)	1.0 (1.3)	1.5 (2.0)	2.2 (2.9)	3.7 (5.0)
Rated Torque*	N·m (lb·in)	2.35 (21)	4.81 (43)	7.16 (63)	10.5 (93)	17.7 (156)
Continuous Max. Torque*	N·m (lb·in)	3.43 (30)	6.37 (56)	8.83 (78)	13.7 (122)	21.6 (191)
Instantaneous Peak Torque*	N·m (lb·in)	8.24 (73)	16.9 (149)	25.1 (222)	36.8 (326)	61.8 (547)
Rated Current*	A	3.5	7.9	12.6	16.6	23.3
Rated Speed*	r/min	2000				
Instantaneous Peak Speed*	r/min	2500				
Torque Constant	N·m/A (lb·in/A)	0.83 (7.38)	0.69 (6.07)	0.64 (5.64)	0.71 (6.25)	0.82 (7.29)
Moment of Motor Inertia $J_M (=GD^2_M/4)$	kg·m <sup>2</sup> ×10 <sup>-4</sup> (lb·in·s <sup>2</sup> ×10 <sup>-3</sup> )	21.13 <sup>†</sup> (18.2, 11.3 <sup>†</sup> )	32.24 <sup>†</sup> (28.6, 21.5 <sup>†</sup> )	62.59 <sup>†</sup> (54.7, 52.1 <sup>†</sup> )	83.80 <sup>†</sup> (73.8, 71.1 <sup>†</sup> )	148.145 <sup>†</sup> (131, 128 <sup>†</sup> )
Power Rate*	kW/s	2.7 4.4 <sup>†</sup>	7.3 9.7 <sup>†</sup>	8.2 8.6 <sup>†</sup>	13 14 <sup>†</sup>	21 22 <sup>†</sup>
Inertia Time Constant	ms	18 11 <sup>†</sup>	7.8 5.9 <sup>†</sup>	7.1 6.8 <sup>†</sup>	6.2 6.0 <sup>†</sup>	4.3 4.2 <sup>†</sup>
Inductive Time Constant	ms	4.4	6.9	9.4	11	15

\* Typical value at armature winding temperature of 20°C, in combination with Servopack.

† Values show those of D series without holding brake.


### (3) Speed-torque characteristics

Typical at 20°C (Armature Winding Temp.)


**A**: Continuous Duty Zone

**B**: Intermittent Duty Zone


USADED-05E




USADED-10E




USADED-15E



USADED-22E



USADED-37E



### 3.1.5 S Series

#### (1) Ratings

Time Rating: Continuous

Insulation: Class B (Types USASEM-02A □ 2,  
-03A □ 2, -05A □ 2)  
Class F (Types USASEM-08A □ 1,  
-15A □ 1, -30A □ 1)

Isolation Voltage: 1500 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;

IP44 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15 μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

#### (2) Combination with encoder

##### • Standard

USASEM- □□□ AS : With absolute encoder (8192 pulses/rev)

USASEM- □□□ A3 : With incremental encoder (2048 pulses/rev)

##### • Semi-Standard

USASEM- □□□ AW : With absolute encoder (1024 pulses/rev)

USASEM- □□□ A4 : With incremental encoder (2500 pulses/rev)

Table 3.5 Ratings and Specifications of S Series AC Servomotors

Item	Motor Type USASEM-	02A □ 2	03A □ 2	05A □ 2	08A □ 1	15A □ 1	30A □ 1
		Rated Output*	W (HP)	154 (0.2)	308 (0.4)	462 (0.6)	771 (1.0)
Rated Torque*	N·m (lb·in)	0.49 (4.3)	0.98 (8.7)	1.47 (13)	2.45 (22)	4.90 (43)	9.81 (87)
Continuous Max. Torque*	N·m (lb·in)	0.57 (5.0)	1.18 (10)	1.67 (15)	3.33 (30)	6.18 (55)	12.2 (108)
Instantaneous Peak Torque*	N·m (lb·in)	1.47 (13)	2.94 (26)	4.02 (36)	7.35 (65)	13.7 (122)	29.0 (257)
Rated Current*	A	2.1	3.0	4.2	5.3	10.4	19.9
Rated Speed*	r/min	3000					
Instantaneous Max Speed*	r/min	4000					
Torque Constant	N·m/A (lb·in/A)	0.25 (2.19)	0.35 (3.10)	0.37 (3.25)	0.51 (4.49)	0.50 (4.43)	0.53 (4.64)
Moment of Motor Inertia $J_m (=GD^2/4)$	kg·m <sup>2</sup> × 10 <sup>-4</sup> (lb·in·S <sup>2</sup> × 10 <sup>-3</sup> )	0.13 (0.11)	0.51 (0.45)	0.75 (0.67)	2.85 (2.53)	3.25 (2.88)	5.74 (5.09)
Power Rate*	kW/s	18.5	18.9	28.9	21	74	167
Inertia Time Constant	ms	1.8	2.2	1.8	1.9	0.7	0.4
Inductive Time Constant	ms	1.5	2.7	3.1	6.2	13	26

\* Typical value at armature winding temperature of 100°C, in combination with Servopack.  
Other values at 20°C.




(3) Speed-torque characteristics

Typical at 100°C (Armature Winding Temp.)


**A**: Continuous Duty Zone

**B**: Intermittent Duty Zone


USASEM-02A




USASEM-03A




USASEM-05A




USASEM-08A



USASEM-15A



USASEM-30A



### 3.1.6 R Series (For 200V)

(1) Ratings

Time Rating: Continuous

Insulation: Class B

Isolation Voltage: 1000 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;  
IP44 (exclusive of shaft opening)

Ambient Temperature: 0 to +40°C

Storage Temperature: -20 to +60°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

(2) Combination with encoder

• Standard

USAREM- [ ] CS2 : With absolute encoder (8192 pulses/rev)

Table 3.6 Ratings and Specifications of R Series  
AC Servomotors (For 200V)

Item	Motor Type USAREM-	Motor Type USAREM-					
		A5C [ ] 2	01C [ ] 2	02C [ ] 2	03C [ ] 2	05C [ ] 2	07C [ ] 2
Rated Output*	W (HP)	50 (0.07)	100 (0.13)	200 (0.27)	300 (0.40)	500 (0.67)	700 (0.93)
Rated Torque*	N·m (oz·in)	0.159 (22.5)	0.318 (45)	0.637 (90)	0.955 (135)	1.59 (225)	2.22 (316)
Continuous Max. Torque*	N·m (oz·in)	0.19 (26.9)	0.382 (54.2)	0.765 (108.3)	1.15 (162.5)	1.90 (269.4)	2.67 (378)
Peak Torque*	N·m (oz·in)	0.476 (67.5)	0.955 (135)	1.91 (270)	2.86 (405)	4.76 (675)	6.68 (948)
Rated Current*	A	0.71	1.0	2.0	2.7	3.6	5.7
Rated Speed*	r/min	3000					
Max. Speed*	r/min	4500					
Torque Constant	N·m/A (oz·in/A)	0.235 (33.3)	0.353 (50.0)	0.346 (49.0)	0.378 (53.6)	0.466 (66.0)	0.426 (60.4)
Moment of Motor Inertia $J_M (=GD_M^2/4)$	kg·cm <sup>2</sup> (oz·in·s <sup>2</sup> × 10 <sup>-3</sup> )	0.076 (1.08)	0.125 (1.78)	0.507 (7.18)	0.766 (10.9)	2.72 (38.6)	3.72 (52.8)
Power Rate*	kW/s	3.30	8.09	8.01	11.9	9.26	13.3
Inertia Time Constant	ms	4.4	3.4	2.9	2.6	2.8	2.5
Inductive Time Constant	ms	1.3	1.6	4.1	4.5	9.4	10.0

\* Typical value at armature winding temperature of 75°C, in combination with Servopack.  
Other values at 20°C.


(3) Speed-torque characteristics

Typical at 20°C (Armature Winding Temp.)


- A**: Continuous Duty Zone
- B**: Intermittent Duty Zone

Note : Values in the intermittent duty zone are typical values when Servopack power supply voltage is 200 VAC. When it is less than 200 VAC, output characteristics may be reduced even if the values are within in the allowable variation range.


USAREM-A5C




USAREM-01C




USAREM-02C




USAREM-03C



USAREM-05C



USAREM-07C



### 3.1.7 R Series (For 100V)

(1) Ratings

Time Rating: Continuous

Insulation: Class B

Isolation Voltage: 1000 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;  
IP44 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Storage Temperature: -20 to + 60°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

(2) Combination with encoder

• Standard

USAREM- [ ] DS2 : With absolute encoder (8192 pulses/rev)

Table 3.7 Ratings and Specifications of R Series  
AC Servomotors (For 100V)

Item	Motor Type USAREM-	A5D [ ] 2	01D [ ] 2	02D [ ] 2	03D [ ] 2	05D [ ] 2
		Rated Output*	W (HP)	50 (0.07)	100 (0.13)	200 (0.27)
Rated Torque*	N·m (oz·in)	0.159 (22.5)	0.318 (45)	0.637 (90)	0.955 (135)	1.59 (225)
Continuous Max. Torque*	N·m (oz·in)	0.19 (26.9)	0.382 (54.2)	0.765 (108.3)	1.15 (162.5)	1.90 (269.4)
Peak Torque*	N·m (oz·in)	0.476 (67.5)	0.955 (135)	1.91 (270)	2.86 (405)	4.76 (675)
Rated Current*	A	1.2	1.7	2.9	3.6	5.5
Rated Speed*	r/min	3000				
Max. Speed*	r/min	4000				
Torque Constant	N·m/A (oz·in/A)	0.136 (19.3)	0.198 (28.1)	0.235 (33.3)	0.284 (40.3)	0.308 (43.6)
Moment of Motor Inertia J <sub>M</sub> (=GD <sub>M</sub> <sup>2</sup> /4)	kg·cm <sup>2</sup> (oz·in·s <sup>2</sup> ×10 <sup>-3</sup> )	0.076 (1.08)	0.125 (1.78)	0.507 (7.18)	0.766 (10.9)	2.72 (38.6)
Power Rate*	kW/s	3.30	8.09	8.01	11.9	9.26
Inertia Time Constant	ms	4.2	3.2	3.0	2.5	2.7
Inductive Time Constant	ms	1.4	1.7	4.0	4.6	9.6

\* Typical value at armature winding temperature of 75°C, in combination with Servopack.  
Other values at 20°C


### (3) Speed-torque characteristics

Typical at 20°C (Armature Winding Temp.)


- A** : Continuous Duty Zone
- B** : Intermittent Duty Zone

Note: Values in the intermittent duty zone are typical values when Servopack power supply voltage is 100 VAC. When it is less than 100 VAC, output characteristics may be reduced even if the values are within in the allowable variation range.


USAREM-A5D




USAREM-01D




USAREM-02D



USAREM-03D



USAREM-05D



### 3.1.8 P Series

(1) Ratings

Time Rating: Continuous

Insulation: Class B

Isolation Voltage: 1000 VAC, one minute

Insulation Resistance: 500 VDC, 10MΩ or more

Enclosure: Totally-enclosed, self-cooled;  
IP55 (exclusive of shaft opening)

Ambient Temperature: 0 to + 40°C

Storage Temperature: -20 to + 60°C

Ambient Humidity: 20% to 80%  
(non-condensing)

Vibration: 15μm or below

Finish in Munsell Notation: N1.5

Excitation: Permanent magnet

Mounting: Flange mounted

Drive Method: Direct drive

(2) Combination with encoder

• Standard

USAPEM- [ ] CW2 : With absolute encoder (1024 pulses/rev)

Table 3.8 Ratings and Specifications of P Series AC Servomotors

Item	Motor Type USAPEM-	01C [ ] 2	02C [ ] 2	03C [ ] 2	05C [ ] 2	07C [ ] 2
Rated Output*	W (HP)	100 (0.13)	200 (0.27)	300 (0.40)	500 (0.67)	750 (1.0)
Rated Torque*	N·m (oz·in)	0.32 (45)	0.64 (90)	0.95 (135)	1.59 (225)	2.39 (339)
Continuous Max. Torque*	N·m (oz·in)	0.32 (45)	0.64 (90)	0.95 (135)	1.59 (225)	2.39 (339)
Peak Torque*	N·m (oz·in)	0.96 (136)	1.91 (270)	2.86 (405)	4.76 (675)	7.06 (1000)
Rated Current*	Arms	1.0	2.0	2.7	3.3	5.7
Rated Speed*	r/min	3000				
Max. Speed*	r/min	4500				
Torque Constant	N·m/A (oz·in/A)	0.35 (49.6)	0.34 (47.8)	0.37 (52.8)	0.51 (72.5)	0.44 (62.6)
Moment of Motor Inertia J <sub>M</sub> (=GD <sub>M</sub> <sup>2</sup> /4)	kg·cm <sup>2</sup> (oz·in·s <sup>2</sup> ×10 <sup>-3</sup> )	0.39 (5.55)	0.64 (9.03)	0.98 (13.9)	4.78 (67.8)	6.57 (93.0)
Power Rate*	kW/s	2.59	6.37	9.30	5.27	8.71
Inertia Time Constant	ms	5.3	2.8	2.2	4.9	3.3
Inductive Time Constant	ms	4.7	5.8	6.4	10.0	14.0

\* Typical value at armature winding temperature of 75°C, in combination with Sevopack. Other values at 20°C.

### (3) Speed-torque characteristics


Typical at 20°C (Armature Winding Temp.)

- A**: Continuous Duty Zone
- B**: Intermittent Duty Zone


Note: Values in the intermittent duty zone are typical values when Servopack power supply voltage is 200 VAC. When it is less than 200 VAC, output characteristics may be reduced even if the values are within the allowable variation range.

3


Type USAPEM-01C




Type USAPEM-02C




Type USAPEM-03C



Type USAPEM-05C



Type USAPEM-07C



## 3.2 MECHANICAL CHARACTERISTICS

### 3.2.1 Mechanical Strength

AC servomotors withstand to 300% (350% only for D series) of the rated torque at output shaft.

### 3.2.2 Allowable Radial Load and Thrust Load

Table 3.9 shows allowable loads according to AC servomotor types.

Table 3.9 Allowable Radial Load and Thrust Load

#### • M Series

Motor Type USAM □ D-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
03 □ □ 1	490(110)	98(22) †
06 □ □ 1		
09B □ □ 2	686(154)	343(77)
12B □ □ 2	1470(330)	490(110)
20B □ □ 2		
30B □ □ 2		
44B □ □ 2	1764(397)	588(132)
60B □ □ 2		

#### • F Series

Motor Type USAFED-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
02 □ □ 1	147(33)	49(11) †
03 □ □ 1		
05 □ □ 1	490(110)	98(22) †
09 □ □ 1	686(154)	343(77)
13C □ □ 2		
20C □ □ 2		
30C □ □ 2	1470(331)	490(110)
44C □ □ 2		

#### • G Series

Motor Type USAGED-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
02 □ □ 1	147(33)	49(11) †
03 □ □ 1		
05 □ □ 1	490(110)	98(22) †
09 □ □ 1	686(154)	343(77)
13A □ □ 2		
20A □ □ 2		
30A □ □ 2	1470(331)	490(110)
44A □ □ 2		

#### • D Series

Motor Type USADED-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
05E □ □	686(154)	343(77)
10E □ □		
15E □ □	1176(265)	490(110)
22E □ □		
37E □ □		

#### • S Series

Motor Type USASEM-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
02A □ □	78.4(18)	39.2(9)
03A □ □	245(55)	98(22)
05A □ □		
08A □ □	392(88)	147(33)
15A □ □	490(110)	
30A □ □	686(154)	196(44)

#### • R Series

Motor Type USAREM-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
A5 □ □ □ 2	78.4(18)	39.2(9)
01 □ □ □ 2		
02 □ □ □ 2	245(55)	98(22)
03 □ □ □ 2		
05 □ □ □ 2		
07 □ □ □ 2	392(88)	147(33)

#### • P Series


Motor Type USAPEM-	Allowable Radial Load* N(lb)	Allowable Thrust Load N(lb)
01C □ □ 2	88.2(20)	39.2(9)
02C □ □ 2	147(33)	58.8(13)
03C □ □ 2	196(44)	
05C □ □ 2	343(77)	98(22)
07C □ □ 2	441(99)	127.4(29)

- \* Maximum values of the load applying to the shaft extension.  
 † Do not apply the exceeding load because motor can not be rotated.



### 3.2.3 Mechanical Specifications

Table 3.10 Mechanical Specifications in mm

Accuracy(T. I. R.)* <sup>1</sup>		Reference Diagram
Flange surface perpendicular to shaftⒶ	0.04 (0.06)* <sup>2</sup>	
Flange diameter concentric to shaftⒷ	0.04	
Shaft run outⒸ	0.02 (0.04)* <sup>3</sup>	

\*1 T. I. R. (Total Indicator Reading)

\*2 Accuracy for motor types USADED-15E, -22E, and -37E.

\*3 Accuracy for motor types USAMED-44B □ 2 and USAMKD-60B □ 2.

### 3.2.4 Rotating Direction

AC Servomotor rotates CCW viewed from the load side when connection shown in Par. 3.3.1 is performed and forward command is given to Servopack with parameter 14, b0 setting = 0 (Fig. 3.11).

### 3.2.5 Shock Resistance

When mounted horizontally and exposed to vertical shock impulses, the motor can withstand up to two incidents with shock acceleration of  $490 \text{ m/s}^2$  (50G) (Fig. 3.12).

#### Note

A precision detector is mounted on the opposite drive end of AC servomotor. Care should be taken to protect the shaft from impacts that could damage the detector.

### 3.2.6 Vibration Resistance

When mounted horizontally, the motor can withstand vibration (vertical, lateral, axial) of  $24.5 \text{ m/s}^2$  (2.5G) (Fig. 3.13).

### 3.2.7 Vibration Class

Vibration of the motor running at rated speed is  $15 \mu\text{m}$  or below (Fig. 3.14).




Fig. 3.11 Forward Rotation Direction




Fig. 3.12 Impact Resistance




Fig. 3.13 Vibration Resistance




Fig. 3.14 Vibration Checking


### 3.3 RECEPTACLES

#### 3.3.1 Connector Specifications

(1) Without brake (M, F, G, S, R series)

(a) Motor receptacle

• M, F, G, R series



A	Phase U
B	Phase V
C	Phase W
D	Frame Ground

• S series


Type USASEM-02

Color of Lead	Applicable
Red	Phase U
White	Phase V
Blue	Phase W
Green	Frame Ground

Fan terminal


connector specifications

Type USAMKD-60B□□2




A, B	Fan motor
C	-
D, E	Alarm terminal
F	-

Type USASEM-03A to 30A



A	Phase U
B	Phase V
C	Phase W
D	Frame Ground

Fan motor connection



Power supply: single-phase

200/200/220V, 50/60/60Hz

Alarm contact :

OFF at fan rotation normal

ON at  $1800 \pm 200$  r/min or less


ON for 3 seconds after starting

Contact capacity :

Resistance load max 110V 0.3A


(b) Detector receptacle

• Incremental encoder




A	Channel A output	K	-
B	Channel A output	L	-
C	Channel B output	M	-
D	Channel B output	N	-
E	Channel C output	P	-
F	Channel C output	R	-
G	0V	S	-
H	+5VDC	T	-
J	Frame Ground	-	-

• Absolute encoder  
(8192P/R)



A	Channel A output	J	Frame Ground
B	Channel $\bar{A}$ output	K	—
C	Channel B output	L	—
D	Channel $\bar{B}$ output	M	—
E	Channel Z output	N	—
F	Channel $\bar{Z}$ output	P	—
G	0V	R	Reset
H	+5VDC	S	0V(battery)
-	—	T	3.6V(battery)


(1024P/R)



A	Channel A output	J	Frame Ground
B	Channel A output	K	Channel S output
C	Channel B output	L	Channel $\bar{S}$ output
D	Channel B output	M	—
E	Channel Z output	N	—
F	Channel Z output	P	Capacitor reset
G	0V	R	Reset
H	+5VDC	S	0V(battery)
-	—	T	3.6V(battery)


(2) Without brake (P series)

(a) Motor side



Phase U	Red
Phase V	White
Phase W	Blue
Frame Ground	Green


(b) Detector side (absolute encoder)



1	Channel A output	Blue	9	Frame ground	Green/Yellow
2	Channel $\bar{A}$ output	White/Blue	10	Channel S output	Purple
3	Channel B output	Yellow	11	Channel $\bar{S}$ output	White/Purple
4	Channel $\bar{B}$ output	White/Yellow	12	Capacitor reset	Grey
5	Channel Z output	Green	13	Reset	White/Grey
6	Channel $\bar{Z}$ output	White/Green	14	0V(battery)	White/Orange
7	0V	Black	15	3.6V(battery)	Orange
8	5VDC	Red	—	—	—

(3) With brake

- M, F (except models 02 and 03), G, D Series



A	Phase U	E	Brake terminal
B	Phase V	F	Brake terminal
C	Phase W	G	-
D	Frame Ground	-	-

Notes:

1. D series is provided with brake as standard.
2. For D series motor without brake, pins E and F are not used.

- F Series (models 02 and 03)



A	Phase U	E	Brake terminal
B	Phase V	F	Brake terminal
C	Phase W	-	-
D	Frame Ground	-	-


- S, R Series

USASEM-02A

Color of Lead	Applicable
Red	Phase U
White	Phase V
Blue	Phase W
Black	Brake
Black	Brake
Green	Frame Ground

USASEM -03A, -05A


USAREM -02C, -02D, -03C, -03D



A	Phase U
B	Phase V
C	Phase W
D, E	Brake terminal
F	Frame Ground


USASEM -08A to -30A

USAREM -05C, -05D, -07C




A	Phase U
B	Phase V
C	Phase W
D, E	Brake terminal
F	Frame Ground

USAREM -A5C, -A5D, -01C, -01D



A	Phase U
B	Phase V
C	Phase W
D, E	Brake terminal
F	Frame Ground

- P Series



Phase U	Red
Phase V	White
Phase W	Blue
Frame Ground	Green
Brake terminal	Black
Brake terminal	Black

**NOTE**

**3**

### 3.3.2 List of Standard Combination

Table 3.11 M Series: Characteristics of AC Servomotor, Detector, and Holding Brake (Option) for Standard Combination

AC Servomotor Type USAMED-	AC Servomotor				Detector			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
03 [ ] 1	MS3102A 18-10P	MS3108B 18-10S	MS3106B 18-10S	MS3057 -10A	MS3102A 20-29P	MS3108B 20-29S	MS3106B 20-29S	MS3057 -12A
06 [ ] 1								
09B [ ] 2								
12B [ ] 2								
20B [ ] 2								
30B [ ] 2								
44B [ ] 2	MS3102A 32-17P	MS3108B 32-17S	MS3106B 32-17S	MS3057 -20A				
USAMKD-60B [ ] 2*								

Table 3.12 F Series: Characteristics of AC Servomotor, Detector, and Holding Brake (Option) for Standard Combination

AC Servomotor Type USAFED-	AC Servomotor				Detector			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02 [ ] 1	MS3102A 14S-2P	MS3108B 14S-2S	MS3106B 14S-2S	MS3057 -6A	MS3102A 20-29P	MS3108B 20-29S	MS3106B 20-29S	MS3057 -12A
03 [ ] 1								
05 [ ] 1								
09 [ ] 1	MS3102A 18-10P	MS3108B 18-10S	MS3106B 18-10S	MS3057 -10A				
13C [ ] 2								
20C [ ] 2	MS3102A 22-22P	MS3108B 22-22S	MS3106B 22-22S	MS3057 -12A				
30C [ ] 2								
44C [ ] 2								

Table 3.13 G Series: Characteristics of AC Servomotor, Detector, and Holding Brake (Option) for Standard Combination

AC Servomotor Type USAGED-	AC Servomotor				Detector			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02 [ ] 1	MS3102A 14S-2P	MS3108A 14S-2S	MS3106B 14S-2S	MS3057 -6A	MS3102A 20-29P	MS3108B 20-29P	MS3106B 20-29S	MS3057 -12A
03 [ ] 1								
05 [ ] 1								
09 [ ] 1								
13A [ ] 2								
20A [ ] 2								
30A [ ] 2	MS3102A 22-22P	MS3108B 22-22S	MS3106B 22-22S	MS3057 -12A				
44A [ ] 2								

Holding Brake				
	Receptacle	L-type Plug	Straight Plug	Cable Clamp
	MS3102A 20-15P	MS3108B 20-15S	MS3106B 20-15S	MS3057 -12A
	MS3102A 24-10P	MS3108B 24-10S	MS3106B 24-10S	MS3057 -16A
	-	-	-	-

\* Cooling fan required:  
 Receptacle type  
 MS3102A14S-6B  
 Plug type  
 MS3108B14S-6S  
 Cable clamp type  
 MS3057-6A

Note: These connectors  
 are made by  
 DAI-ICHI DENSHI  
 KOGYO Co., Ltd.

Holding Brake				
	Receptacle	L-type Plug	Straight Plug	Cable Clamp
	MS3102A 14S-6P	MS3108B 14S-6S	MS3106B 14S-6S	MS3057 -6A
	MS3102A 20-15P	MS3108B 20-15S	MS3106B 20-15S	MS3057 -12A
	MS3102A 24-10P	MS3108B 24-10S	MS3106B 24-10S	MS3057 -16A

Note: These connectors  
 are made by  
 DAI-ICHI DENSHI  
 KOGYO Co., Ltd.

Holding Brake				
	Receptacle	L-type Plug	Straight Plug	Cable Clamp
	MS3102A 14S-6P	MS3108B 14S-6S	MS3106B 14S-6S	MS3057 -6A
	MS3102A 20-15P	MS3108B 20-15S	MS3106B 20-15S	MS3057 -12A
	MS3102A 24-10P	MS3108B 24-10S	MS3106B 24-10S	MS3057 -16A

Notes:  
 1. For connection parts(plugs, clamps, etc)  
 contact your Yaskawa representative.  
 For connecting method, there are two  
 types: soldering(MS type)and  
 caulking(JA type).  
 2. These connectors are made by DAI-ICHI  
 DENSHI KOGYO Co., Ltd.

Table 3.14 D Series: Characteristics of AC Servomotor, Detector, and Holding Brake for Standard Combination

AC Servomotor Type USADED-	Holding Brake				Detector			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
05E □	MS3102A 20-15P	MS3108B 20-15S	MS3106B 20-15S	MS3057 -12A	MS3102A 20-29P	MS3108B 20-29S	MS3106B 20-29S	MS3057 -12A
10E □								
15E □								
22E □								
37E □	MS3102A 24-10P	MS3108B 24-10S	MS3106B 24-10S	MS3057 -16A				

Table 3.15 S Series: Characteristics of AC Servomotor, Detector and Holding Brake (Option) for Standard Combination

AC Servomotor Type USASEM-	AC Servomotor				Detector			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02A □	Since lead outlet method differs, refer to the data separately.							
03A □	MS3102A 18-10P	MS3108B 18-10S	MS3106B 18-10S	MS3057 -10A	MS3102A 20-29P	MS3108B 20-29S	MS3106B 20-29S	MS3057 -12A
05A □								
08A □								
15A □								
30A □	MS3102A 20-4P	MS3108B 20-4S	MS3106B 20-4S	MS3057 -12A				

Note: These connectors made by DAI-ICHI DENSHI KOGYO CO., LTD.

Table 3.16 R Series: Characteristics of AC Servomotor, Detector, and Holding Brake (Option) for Standard Combination

AC Servomotor Type USAREM-	AC Servomotor			Detector			Holding Brake		
	Receptacle Type	L-type Plug	Cable Clamp	Receptacle Type	L-type Plug	Cable Clamp	Receptacle Type	L-type Plug	Cable Clamp
A5C □ 2	MS3101A 14S-2P	MS3106B* 14S-2S	MS3057 -6A	MS3101A 20-29A	MS3106B 20-29S*	MS3057 -12A	MS3101A 14S-6P	MS3106B 14S-6S*	MS3057 -6A
01C □ 2							MS3102A 18-12P	MS3108B 18-12S	MS3057 -10A
02C □ 2	MS3102A 18-10P	MS3108B 18-10S	MS3057 -10A	MS3102A 20-29P	MS3108B 20-29S		MS3102A 20-17P	MS3108B 20-17S	MS3057 -12A
03C □ 2									
05C □ 2	MS3102A 20-4P	MS3108B 20-4S	MS3057 -12A						
07C □ 2									
A5D □ 2	MS3101A 14S-2P	MS3106B 14S-2S*	MS3057 -6A	MS3101A 20-29A	MS3106B 20-29S*	ME3057 -12A	MS3101A 14S-6P	MS3106B 14S-6S*	MS3057 -6A
01D □ 2							MS3102A 18-12P	MS3108B 18-12S	MS3057 -10A
02D □ 2	MS3102A 18-10P	MS3108B 18-10S	MS3057 -10A	MS3102A 20-29P	MS3108B 20-29S		MS3102A 20-17P	MS3108B 20-17S	MS3057 -12A
03D □ 2									
05D □ 2	MS3102A 20-4P	MS3108B 20-4S	MS3057 -12A						

\* Straight Plug

Note: These connectors are made by DAI-ICHI DENSHI KOGYO Co., Ltd.



Notes:

1. For connection parts(plugs, clamps, etc.), contact your Yaskawa representative For connecting method, there are two types:soldering(MS type) caulking(JA type).
2. These connectors are made by DAI-ICHI DENSHI KOGYO Co., Ltd.

Holding Brake				
	Receptacle	L-type Plug	Straight plug	Cable Clamp
	MS3102A 18-12P	MS3108B 18-12S	—	MS3057 -10A
	MS3102A 20-17P	MS3108B 20-17S	—	MS3057 -12A

Note: These connectors are made by DAI-ICHI DENSHI KOGYO Co., Ltd.

Table 3.17 P Series: Characteristics of AC Servomotor, Detector, and Holding Brake for Standard Combination

AC Servomotor Type USAPEM-	AC Servomotor	Detector		Holding Brake
	Pin Terminal	Connector (MATE-N-LOCK Conversal)		Pin Terminal
		Plug	Pin	
01C □ 2	PC2005-M	172171-1	170363-1	PC2005-M
02C □ 2	PC2005-M	172171-1	170363-1	PC2005-M
03C □ 2	PC2005-M	172171-1	170363-1	PC2005-M
05C □ 2	PC2005-M	172171-1	170363-1	PC2005-M
07C □ 2	PC2005-M	172171-1	170363-1	PC2005-M

Note: The type of connectors prepared by users are shown in the table below.

AC Servomotor	user pin terminal (common for types with brake and without brake) PC 2005F appropriate tool NA-3 head N3-5 manual tool NH-5	NICHIFU TERMINAL INDUSTRIAL CO., LTD.
Detector	user cap 172163-1 socket 170365-1 manual tool 724649-1	AMP (Japan) Ltd.

# 4

# RATINGS AND SPECIFICATIONS OF AC SERVOPACK

## 4.1 RATINGS AND SPECIFICATIONS

Table 4.1 AC Servopack Ratings and Specifications

Servopack Type		ACR-HR [.....]	A5BAB12	01BAB12	02BAB12	03BAB12	05BAB12	10BAB	15BAB	
Max. Applicable Motor Capacity kW (HP)			0.05 (0.07)	0.1 (0.13)	0.2 (0.27)	0.3 (0.40)	0.5 (0.67)	1.0 (1.3)	1.5 (2.0)	
Basic Specifications	Input Power Supply	Main	Single-phase AC				3-phase AC			
		No. of Phases								
		Voltage	200 to 230V +10 to -15% 50/60Hz							
	Control		Single-phase 200 to 230VAC +10 to -15% 50/60Hz							
	Control Method		Full-wave rectifying, transistorized PWM control, sine-wave drives							
	Feedback		Absolute encoder (8192 or 1024 pulses/rev), incremental encoder (8192, 2500, or 2048 pulses/rev)							
	Environmental Conditions	Ambient Temp.		0 to +55°C						
		Storage Temp.		-20 to +85°C						
		Ambient/Storage Humidity		90% or less (non-condensing)						
		Vibration-/Shock Resistance		4.9m/s <sup>2</sup> (0.5G)/19.6m/s <sup>2</sup> (2G)						
Configuration, Dimensions in mm (in.)		Rack-mounted A5 to 05: 100W × 250H × 250D (3.94W × 9.84H × 9.84D) 10 and 15: 150W × 250H × 250D (5.91W × 9.84H × 9.84D)								
Positioning Control Specifications	Station No. Command Method	Operation Spec.	Constant point positioning by station No. command (contact data)							
		Command Input	Position command: BCD (up to 3-digit 000 to 999) or BIN (up to 12-bit 0 to 4095)							
		System	Both absolute and incremental commands available							
	DG-SW Command Method	Operation Spec.	Positioning by DG-SW command data							
		Command Input	Position command: Sign + up to 8 digits (-99999999 to +99999999) Speed command: Up to 6 digits (000000 to 240000), to be less than motor max. speed							
		System	Both absolute and incremental commands available							
	Serial Communication Command Method	Operation Spec.	Positioning by serial communication							
		Command Input	RS422, asynchronous, communication speed 9.6/4.8/2.4/1.2 kBaud							
		System	Both absolute and incremental commands available							
	Command Table Method	Operation Spec.	Positioning by position No. and speed No. command (contact data)							
		Command Input	Position command: Sign + up to 8 digits. (-99999999 to +99999999) Speed command: Up to 6 digits (000000 to 240000), to be less than motor max. speed Position/speed No. command: BIN (up to 6 bits 1 to 64)							
		System	Only absolute value command available							
	Others	Operation Spec.	Positioning by pulse train (line PG or pulse train input)							
		Command Input	Position command: Number of pulses — A + B or UP + DN or P + SIGN Speed command: Up to 400 kpps (A + B : 1.6 Mpps)							
		System	Only incremental command available							
Common Built-in Function	Dynamic Brake (DB)		Operated at main power OFF, servo alarm, servo OFF							
	Holding Brake Interface		Output signal for turning brake power supply ON/OFF (brake timing is set by parameter.)							
	Regeneration		A5, 01: not provided, 02 to 15: built-in (regenerating resistor included)							
	Overtravel Protection		By soft limit and hard LS: internal command stop at operation							
	External Current Limit		Current limit value switching by contact input Current limit value: Common in FWD/REV, FWD only, REV only (parameter setting)							
	Protective Functions		OV, OC, OL, OS, MCCB, PG, UV, CPU, ABS, POS, O-PH, RWY, RG, HARD, OF, PRM (See Table 4.2)							
	Display		Main circuit power supply: yellow LED, control power supply: green LED, alarm: red LED Alarm contents: 7-segment							
	Monitor		Serial communication (position, speed, torque, etc.) Speed command, torque command or speed output in analog value							
	Positioning Control Function		Linear accel/decel, exponential accel/decel, A/B function, pulse multiplication, soft OT, backlash compensation, COIN NEAR, motor-line PG switching (incremental operation), etc.							
	Control Interface I/O	Input	Serial I port and digital 24V system × 20 (Max.)							
Output		Serial I port and digital 24V system × 18 (Max.), 5V system 2 circuits (PG output)								
Gain and Parameter Settings		Serial communication (RS422, asynchronous, communication speed (9.6/4.8/2.4/1.2 kBaud) (By personal computer)								
Absolute Encoder Battery		Provided on the Servopack panel								
Applicable Inertia J <sub>L</sub>		5 times or less of rotor inertia J <sub>m</sub> (motor GD <sup>2</sup> ) for M, F, G, D, S or P series; 10 times or less for R series								

ASBAB11	O1BAB11	O2BAB11	O3BAB11	O5BAB11	O3BB	O5BB	10BB	15BB	20BB	30BB	44BB	60BB
0.05 (0.07)	0.1 (0.13)	0.2 (0.27)	0.3 (0.40)	0.5 (0.67)	0.3 (0.40)	0.5 (0.67)	1.0 (1.3)	1.5 (2.0)	2.0 (2.7)	3.0 (4.1)	4.4 (5.9)	6.0 (8.2)
Single-phase AC						3-phase AC						
100 to 115V +10 to -15% 50/60Hz						200 to 230V +10 to -15% 50/60Hz						
Single-phase 100 to 115VAC +10 to -15% 50/60Hz						Single-phase 200 to 230VAC +10 to -15% 50/60Hz						
Full-wave rectifying, transistorized PWM control, sine-wave drives												
Absolute encoder (8192 or 1024pulses/rev), incremental encoder (8192, 2500, or 2048pulses/rev)												
0 to +55°C												
-20 to +85°C												
90% or less (non-condensing)												
4.9m/s <sup>2</sup> (0.5G)/19.6m/s <sup>2</sup> (2G)												
Rack-mounted A5 to O3: 100W × 250H × 250D (3.94W × 9.84H × 9.84D) O5: 150W × 250H × 250D (5.91W × 9.84H × 9.84D)						Base-mounted O3 to 15: 150W × 350H × 220D (5.91W × 13.78H × 8.66D) 20 and 30: 150W × 450H × 220D (5.91W × 17.72H × 8.66D) 44: 150W × 450H × 300D (5.91W × 17.72H × 11.81D) 60: 180W × 450H × 325D (7.09W × 17.72H × 12.80D)						
Constant point positioning by station No. command (contact data)												
Position command: BCD (up to 3-digit 000 to 999) or BIN (up to 12-bit 0 to 4095)												
Both absolute and incremental commands available												
Positioning by DG-SW command data												
Position command: Sign + up to 8 digits (-99999999 to +99999999) Speed command: Up to 6 digits (000000 to 240000), to be less than motor max. speed												
Both absolute and incremental commands available												
Positioning by serial communication												
RS422, asynchronous, communication speed 9.6/4.8/2.4/1.2 kBaud												
Both absolute and incremental commands available												
Positioning by position No. and speed No. command (contact data)												
Position command: Sign + up to 8 digits. (-99999999 to +99999999) Speed command: Up to 6 digits (000000 to 240000), to be less than motor max. speed Position/speed No. command: BIN (up to 6 bits 1 to 64)												
Only absolute value command available												
Positioning by pulse train (line PG or pulse train input)												
Position command: Number of pulses — A + B or UP + DN or P + SIGN Speed command: Up to 400 kpps (A + B : 1.6 Mpps)												
Only incremental command available												
Operated at main power OFF, servo alarm, servo OFF												
Output signal for turning brake power supply ON/OFF (brake timing is set by parameter.)												
AS: not provided			O1 to O5: built-in (regenerating resistor included)			Built-in (regenerating resistor included). Note that regenerating resistor provided separately for 60BB.						
By soft limit and hard LS: internal command stop at operation												
Current limit value switching by constant input Current limit value: Common in FWD/REV, FWD only, REV only (parameter setting)												
OV, OC, OL, OS, MCCB, PG, UV, CPU, ABS, POS, RWY, RG, HARD, OF, PRM (See Table 4.2)						OV, OC, OL, OS, MCCB, PG, UV, CPU, ABS, POS, O-PH, RWY, PG, HARD, OF, PRM, OH (See Table 4.2)						
Main circuit power supply: yellow LED, control power supply: green LED, alarm: red LED Alarm contents: 7-segment						Main circuit power supply: green LED, control power supply: green LED, alarm: red LED Alarm contents: code output in 7-segment, fault contents display in data display section						
Serial communication (position, speed, torque, etc.) Speed command, torque command or speed output in analog value												
Linear accel/decel, exponential accel/decel, A/B function, pulse multiplication, soft OT, backlash compensation, COIN NEAR, motor line PG switching (incremental operation), etc.												
Serial 1 port and digital 24V system × 20 (Max.)												
Serial 1 port and digital 24V system × 18 (Max.), 5V system 2 circuits (PG output)												
Serial communication (RS422, asynchronous, communication speed (9.6/4.8/2.4/1.2 kBaud) (By personal computer)						Serial communication (RS422, asynchronous, communication speed 9.6/4.8/2.4/1.2 kBaud) or selection by AC Servopack switch						
Provided on the Servopack panel						Provided on Servopack board						
5 times or less of rotor inertia J <sub>v</sub> (motor GD <sup>2</sup> ) for M, F, G, D, S or P series; 10 times or less for R series												

## 4.2 INTERNAL BLOCK DIAGRAM

- Servopack Type CACR-HRA5BAB[ ] to -05BAB[ ]




Fig. 4.1 Internal Block Diagram of Servopack Type CACR-HRA5BAB[ ] to -05BAB[ ]  
 (Regenerative transistor TRI not provided for A5BAB11, A5BAB12 or 01BAB12)

• Servopack Type CACR-HR10BAB, -15BAB





Fig. 4.2 Internal Block Diagram Servopack Type CACR-HR10BAB, -15BAB

• Servopack Type CACR-HR □□ BB



- 1: 1THS not provided for HR03BB to HR10BB.
- 2: 1FAN not provided for HR03BB to HR15BB.
- 1FAN provided for control power supply of type HR60BB
- 3: 2R not provided for HR03BB to HR10BB.
- 4: Added only for HR60BB.  
(for connection of motor cooling fan)
- 5: 1R and 2R not provided for HR60BB.  
External resistor is connected between Y3 and Y4.

Fig. 4.3 Internal Block Diagram Servopack Type CACR-HR03BB to HR60BB

## 4.3 PROTECTIVE CIRCUIT

Servopack provides functions to protect the Servopack and motor from malfunctions.

### (1) Dynamic brake function

Servopack incorporates a dynamic brake for emergency stop. This brake operates when:

- Alarm (fault detection) occurs.
- Servo ON command is turned OFF.
- Main power supply is turned OFF.

### (2) Fault detecting functions

Table 4.2 Trouble Detecting Functions

Fault	Detection
Overcurrent (OC)	Overcurrent flow in the main circuit (at 1.2 times or more of inst. max. current)
Circuit Protector Trip (MCCB)	Circuit protector tripped
Regeneration Trouble (RG)	Regenerative circuit not activated in Servopack.
Overvoltage (OV)	Excessively high DC voltage in the main circuit (approx 420V.)
Overspeed (OS)	Excessively large speed feedback detected
Under Voltage (UV)	Low DC voltage in the main circuit after power ON. (150V or less.)
Overload (OL)	Overload condition of motor and Servopack.
Heatsink Overheat (OH)	Overheat of heatsink (approx 85°C min.) (only for type HR [ ] BB)
PG Disconnection (PG)	Encoder signal disconnection
Overflow Deviation (OF)	Excessive following error
Open Phase (O-PH)	Any one phase open in three-phase power input.
Overrun Prevention (RWY)	Wrong wiring of motor circuit or PG signal line.
CPU Error (CPU)	Errors related to CPU
Hardware Error (HARD)	
Abso Error (ABS)	Errors related to absolute encoder
Position Error (POS)	
Parameter Error (PRM)	Data set value error of parameter
Battery Voltage Low	Battery voltage drop or battery disconnection

(3) Overload Detection (OL) Level

Overload detection level is set as shown in Fig. 4.4 when motor rated current = 100%. (When allowable current applying time at motor locking is at the maximum, operating time at higher rotating speed is shorter for the same overload.)

NOTE

Overload detection level is determined with hot start conditions of ambient temperature 55° C. The set value cannot be changed.




Fig. 4.4 Overload Characteristics



(4) Servo alarm output [ALM]

If any fault detection circuits in Table 4.2 functions, the power drive circuit in the Servopack is turned off, 7-segment LEDs indicate the operation status and a servo alarm signal is output.

(5) Protective circuit operation

An alarm signal indicates some fault. Check the cause and fix the problem, and restart the operation. Before checking the cause, turn off the main power supply to avoid danger. Apply the sequence so that the alarm signal turns off only the main circuit (Ⓡ, Ⓢ, Ⓣ), as shown in Figs. 5.17 and 5.18. This allows rapid reaction in the event of a malfunction.

If the power to the control circuit (Ⓡ, Ⓣ) is simultaneously turned off, this also turns off the LED in the Servopack indicating the cause of the alarm signal.

CAUTION

When an alarm signal cuts off only the main circuit, turn off servo ON (SVON) signal before supplying power to the main circuit to resume the operation.

(6) Resetting servo alarm

To reset the servo alarm, turn on alarm reset signal  $\overline{\text{RST}}$  (or serial communication command ARES ).

If ? is on (e.g., Servopack is over loaded), it takes a few minutes to reset the alarm condition.

## 4.4 PRECAUTIONS FOR APPLICATION

### 4.4.1 Overhanging Load

The motor is rotated by the load; Additional regenerative resistor may be required against this rotation and achieve continuous running.

Example: Vertical axis without counterweight

Since Servopack has the regenerative brake capability of short time (corresponding to the motor stopping time), for application to a minus load, contact your Yaskawa representative.

### 4.4.2 Load Inertia ( $J_L$ )

The allowable load inertia  $J_L$  converted to the motor shaft must be within five times (M, F, G, D, S, P series) or ten times (R series) the inertia of the applicable AC servomotor. If the allowable inertia is exceeded, an overvoltage alarm may be given during deceleration. If this occurs, take the following actions:

- Reduce the current limit.
- Slow down the deceleration curve.
- Decrease the maximum speed.

For details, contact your Yaskawa representative.

### 4.4.3 Allowable Cyclic Operating Frequency

Start/Stop cyclic operating frequency is limited separately by Servopack and Servomotor. It is necessary to satisfy both conditions.

(1) Allowable cyclic operating frequency limited by Servopack.

Servopack limitation is due to Servopack built-in regenerative resistor generating power. Allowable frequency differs depending on combined motor types, capacities, load inertia

$J_L$ , accel/decel current values and motor speed.

For the following cases, contact your Yaskawa representative.

- When start/stop cyclic operating frequency up to rated speed exceeds 60 times/min at load inertia  $J_L = 0$ .
- When start/stop cyclic operating frequency up to rated speed exceeds  $\frac{60}{m+1}$  times/min at load inertia  $J_L = \text{motor inertia } J_M \times m$  times.

(2) Allowable cyclic operating frequency limited by Servomotor

When AC Servomotor rms torque in an operation cycle is within the continuous duty zone of motor performance (Par. 3.1), the operation can be repeated in the operation cycle.

#### 4.4.4 High Voltage Line

If the supply voltage is 400/440 V, the voltage must be dropped from 400/440V to 200 V\* by using a power transformer. Table 5.13 shows the transformer selection. Connection should be made so that the power is supplied and cut at the primary side of the transformer.

\* 100V for Servopack type HR [ ] BAB11.

## 4.5 POWER LOSS

The power loss of Servopack is shown in Table 4.2.

Table 4.2 Power Loss at Rated Output

Servopack Type CACR-	Output Current A	Power Loss			
		Main Circuit W	Regenerative Resistor * W	Control Circuit W	Total W
HRA5BAB12	0.7	20	—	30	50
HR01BAB12	1.0	25	—		55
HR02BAB12	2.0	30	6		66
HR03BAB12	2.7	35	6		71
HR05BAB12	3.6	55	6		91
HR10BAB	7.6	70	20		120
HR15BAB	11.7	80	20		130
HR03BB	3.0	20	10	60	90
HR05BB	4.2	40	10		110
HR10BB	7.6	70	20		150
HR15BB	11.7	80	20		160
HR20BB	18.8	100	40		200
HR30BB	26.0	160	80		300
HR44BB	33.0	210	100		370
HR60BB	45.0	300	120	480	
HRA5BAB11	1.2	20	—	30	50
HR01BAB11	1.7	25	6		61
HR02BAB11	2.9	40	6		76
HR03BAB11	3.6	50	6		86
HR05BAB11	5.5	45	15		90

\* Power loss in regenerative resistors occurs at motor deceleration. The maximum allowable value of average power loss is shown. When a motor operates in a duty cycle exceeding this value, a regenerative resistor must be provided.

# 5 CONNECTION

## 5.1 TYPICAL CONNECTION

### 5.1.1 Basic Connection





Fig. 5.1 Basic Connection

## 5.1.2 Typical Connection at Positioning by Station No.

Note: For power supply and motor connection, refer to Fig. 5.1.




\*1 Signals related to zero-point return are needed when incremental encoder is used.  
LS: Limit Switch

Fig. 5.2 Typical Connection at Positioning by Station No.

### 5.1.3 Typical Connection at Positioning by DG-SW Data

Note: For power supply and motor connection, refer to Fig. 5.1.



Note: For internal circuitry refer to Fig. 5.4. Additionally, the wiring length of the DG-SW unit must be 5m or less.

\*1 Signals related to zero-point return are needed when incremental encoder is used.

Fig. 5.3 Typical Connection at Positioning by DG-SW Data

5.1.3 Typical Connection at Positioning by DG-SW Data (Cont'd)





Fig. 5.4 Details in DG-SW Unit



## 5.1.4 Typical Connection at Positioning by Serial Communication

Note: For power supply and motor connection, refer to Fig. 5.1.




\*1 Signals related to zero-point return are needed when incremental encoder is used.

Fig. 5.5 Typical Connection at Positioning by Serial Communication Input

### 5.1.5 Typical Connection at Positioning by Command Table

Note: For power supply and motor connection, refer to Fig. 5.1.



\*1 Signals related to zero-point return (homing) are needed when incremental encoder is used.  
LS : Limit Switch

\*2 Set PRM20b5=1, PRM65b0=1 when zone signals are used.

Fig. 5.6 Typical Connection at Positioning by Command Table

## 5.2 MAIN CIRCUIT TERMINAL NAMES AND OUTLINE

Table 5.1 Main Circuit Terminal Names and Outline

Symbol	Name	Outline
*1 Ⓡ Ⓢ Ⓣ	Main circuit power supply input terminal	*2 3-phase 200 to 230VAC $\begin{matrix} +10\% \\ -15\% \end{matrix}$ , 50/60Hz
Ⓤ Ⓥ Ⓦ	Motor connection terminal	Ⓤ and motor terminal A; Ⓥ and motor terminal B; Ⓦ and motor terminal C connected
*3 Ⓡ Ⓣ	Control power supply input terminal	*4 Single-phase 200 to 230VAC $\begin{matrix} +10\% \\ -15\% \end{matrix}$ , 50/60Hz
Ⓣ	Grounding terminal	Connected with motor terminal D to ground.
Ⓨ3 Ⓨ4	Regenerative resistor connecting terminal	*5 Regenerative resistor connecting terminal (Normally, no connection is necessary)
*6 ⓕ1 ⓕ2 ⓕ3	Motor cooling fan connecting terminal	Connection needed only when Type USAMKD-60B is used.

\*1 : Ⓡ, Ⓣ for Type HR [ ] BAB11

\*2 : Single-phase 100 to 115VAC  $\begin{matrix} +10\% \\ -15\% \end{matrix}$ , 50/60Hz for Type HR [ ] BAB11.

Single-phase 200 to 230VAC  $\begin{matrix} +10\% \\ -15\% \end{matrix}$ , 50/60Hz for Type HR [ ] BAB12.

\*3 : Ⓡ, Ⓢ, Ⓣ only for Type HR60BB

\*4 : Single-phase 100 to 115VAC  $\begin{matrix} +10\% \\ -15\% \end{matrix}$ , 50/60Hz for Type HR [ ] BAB11.

\*5 : External resistor must be connected for Type HR60BB.

\*6 : Provided only for Type HR60BB.

## 5.3 CONNECTOR TERMINAL (2CN) FOR I/O SIGNAL

### 5.3.1 Applicable Receptacle Specifications

Table 5.2 Applicable Receptacle Specifications

Specifications of Connector Used in Servopack	Applicable Receptacle Type			
	Soldered Type	Caulking Type	Case	Maker
MR-20RFA Right angle 20P	MR-20M*	MRP-20M01	MR-20L*	HONDA Tsushin Co., Ltd.

\* Standard attachment of Servopack

### 5.3.2 Connector 2CN Layout and Connection

Table 5.3 shows the terminal layout of connector 2CN and Fig. 5.7 shows the wiring diagram for 2CN.

Table 5.3 Connector 2CN Layout

1	2	3	4	5	6	7
STP	+24V	—	—	—	(BAT+)	(BAT-)
(At Zero-Point Return) Zero-Point Stop LS Input	STP 24V	—	—	—	(Battery Input for Absolute Encoder)	
	8	9	10	11	12	13
	$\overline{\text{SVON}}$	N-OT	P-OT	ALM	$\overline{\text{BK}}$	OV
Servo ON Input	Overtravel LS Input		Servo Alarm Output	Brake Release Command Output	OV for ALM. BK Signal	
	Reverse Side	Forward Side				
14	15	16	17	18	19	20
—	STOP	$\overline{\text{AST}}$	DEC	$\overline{\text{PCON}}$	24V	FG
—	Temporary Stop Command Input	Start Command Input	(At Zero-Point Return) Decel LS Input	Proportional Operation Command Input	24V for Input Signal	Frame Ground (Shielding Process)












Fig. 5.7 Wiring Diagram for 2CN



### 5.3.3 Description and Usage of I/O Signals of Connector 2CN

#### (1) Input Signals

L level when contact closed, H level when opened.

Signal Name	Pin No.	Name	Effective Logic	Function
$\overline{\text{SVON}}$	8	Servo ON		Base block on main circuit transistors is released. Motor becomes in current conduction when this signal is ON.
$\overline{\text{AST}}$	16	Operation start	 Starts by rising edge.	Operation start signal in automatic operation mode or zero-point return mode.
STOP	15	Temporary stop reference	 5ms or more	Operation stop command in automatic operation mode or zero-point return (homing) mode. When this signal is OFF, operation stops at specified accel/ decel speed (parameter setting).
N-OT	9	Forward side overtravel LS		Connects overtravel limit switch signal according to forward or reverse side. This signal is turned on at normal operation and off when limit switch is active.
P-OT	10	Reverse side overtravel LS		
DEC	17	Zero-point return(homing) decel LS		Used in zero-point return (homing) mode I (refer to Par.6.2.3 (1) d). After 2-step deceleration by DEC signal and phase-C pulse signal, zero-point return is performed.
STP	1	Zero-point return(homing) stop LS		Used in zero-point return (homing) mode II (refer to Par.6.2.3 (1) d). After deceleration by STP signal, zero-point return is performed.
$\overline{\text{PCON}}$	18	Proportional operation command		Speed loop control mode is switched from PI (proportional-integer) to P (proportional) operation.
(BAT+)	6	Absolute encoder battery input	 3.6V	Not used normally. (Battery provided for HRC3BAB on the panel and for HRC3BBB on the board.)
(BAT-)	7			

## (2) Output Signals

Signal Name	Pin No.	Name	Effective Logic	Function
ALM	11	Servo alarm		Output transistor is turned off when an alarm occurs. (Normally ON)
$\overline{\text{BK}}$	12	Brake release signal		Output transistor is turned on by brake control circuit when servo ON status.

## 5.4 CONNECTOR TERMINAL (3CN) FOR ENCODER

### 5.4.1 Applicable Receptacle and Cable Specifications




Table 5.4 Applicable Receptacle and Cable Specifications

Specifications of Connector Used in Servopack	Applicable Receptacle Type				Connecting Cable Specifications
	Soldered Type	Caulking Type	Case	Maker	
MR-2ORMA Right angle 20P	MR-20F *	MRP-20F01	MR-20L *	HONDA Tsushin Co., Ltd.	DP8409123, B9400064 or DE8400093

\* Standard attachment of Servopack

Note: For connecting cables, YASKAWA supply the cables with the following specifications. However, they are not attached to Servopack or motor. They can be purchased at prepared length on request. (Table 5.5)

Table 5.5 Applicable Cable Specifications

Applicable Encoder	Absolute Encoder	Incremental Encoder	Absolute Encoder, Incremental Encoder																																																				
Connecting Method	Soldered type	Soldered type	Caulking type																																																				
Cable Specification	YASKAWA DWG. No. DP8409123	YASKAWA DWG. No. B9400064	YASKAWA DWG. No. DE8400093																																																				
Maker	Fujikura Cable Co.																																																						
Finished Dimension	φ 8.0mm	φ 7.5mm	φ 10.0mm																																																				
(Recommended Receptacle Type)	(For soldered type)	(For soldered type)	(For caulking type)																																																				
Internal Configuration and Lead Colors (DP8409123 and B9400064 are standard.)																																																							
	<table border="1"> <tr><td>A<sub>1</sub></td><td>Red</td></tr> <tr><td>A<sub>2</sub></td><td>Black</td></tr> <tr><td>A<sub>3</sub></td><td>Green/yellow</td></tr> <tr><td>B<sub>1</sub></td><td>Blue-white/blue</td></tr> <tr><td>B<sub>2</sub></td><td>Yellow-white/yellow</td></tr> <tr><td>B<sub>3</sub></td><td>Green-white/green</td></tr> <tr><td>B<sub>4</sub></td><td>Orange-white/orange</td></tr> <tr><td>B<sub>5</sub></td><td>Purple-white/purple</td></tr> <tr><td>B<sub>6</sub></td><td>Gray-white/gray</td></tr> </table>	A <sub>1</sub>	Red	A <sub>2</sub>	Black	A <sub>3</sub>	Green/yellow	B <sub>1</sub>	Blue-white/blue	B <sub>2</sub>	Yellow-white/yellow	B <sub>3</sub>	Green-white/green	B <sub>4</sub>	Orange-white/orange	B <sub>5</sub>	Purple-white/purple	B <sub>6</sub>	Gray-white/gray	<table border="1"> <tr><td>A<sub>1</sub></td><td>Red</td></tr> <tr><td>A<sub>2</sub></td><td>Black</td></tr> <tr><td>A<sub>3</sub></td><td>Green/yellow</td></tr> <tr><td>F<sub>1</sub></td><td>Blue-white/blue</td></tr> <tr><td>F<sub>2</sub></td><td>Yellow-white/yellow</td></tr> <tr><td>F<sub>3</sub></td><td>Pale green-white/pale green</td></tr> <tr><td>F<sub>4</sub></td><td>Orange-white/orange</td></tr> </table>	A <sub>1</sub>	Red	A <sub>2</sub>	Black	A <sub>3</sub>	Green/yellow	F <sub>1</sub>	Blue-white/blue	F <sub>2</sub>	Yellow-white/yellow	F <sub>3</sub>	Pale green-white/pale green	F <sub>4</sub>	Orange-white/orange	<table border="1"> <tr><td>1</td><td>Blue-white</td></tr> <tr><td>2</td><td>Yellow-white</td></tr> <tr><td>3</td><td>Green-white</td></tr> <tr><td>4</td><td>Red-white</td></tr> <tr><td>5</td><td>Purple-white</td></tr> <tr><td>6</td><td>Blue-brown</td></tr> <tr><td>7</td><td>Yellow-brown</td></tr> <tr><td>8</td><td>Green-brown</td></tr> <tr><td>9</td><td>Red-brown</td></tr> <tr><td>10</td><td>Purple-brown</td></tr> </table>	1	Blue-white	2	Yellow-white	3	Green-white	4	Red-white	5	Purple-white	6	Blue-brown	7	Yellow-brown	8	Green-brown	9	Red-brown	10	Purple-brown
	A <sub>1</sub>	Red																																																					
	A <sub>2</sub>	Black																																																					
A <sub>3</sub>	Green/yellow																																																						
B <sub>1</sub>	Blue-white/blue																																																						
B <sub>2</sub>	Yellow-white/yellow																																																						
B <sub>3</sub>	Green-white/green																																																						
B <sub>4</sub>	Orange-white/orange																																																						
B <sub>5</sub>	Purple-white/purple																																																						
B <sub>6</sub>	Gray-white/gray																																																						
A <sub>1</sub>	Red																																																						
A <sub>2</sub>	Black																																																						
A <sub>3</sub>	Green/yellow																																																						
F <sub>1</sub>	Blue-white/blue																																																						
F <sub>2</sub>	Yellow-white/yellow																																																						
F <sub>3</sub>	Pale green-white/pale green																																																						
F <sub>4</sub>	Orange-white/orange																																																						
1	Blue-white																																																						
2	Yellow-white																																																						
3	Green-white																																																						
4	Red-white																																																						
5	Purple-white																																																						
6	Blue-brown																																																						
7	Yellow-brown																																																						
8	Green-brown																																																						
9	Red-brown																																																						
10	Purple-brown																																																						
	Twisted cable	Twisted cable	Twisted cable																																																				
YASKAWA Specifications	Standard length: 5m, 10m, 20m Terminal ends are not provided (without connectors).																																																						

NOTES

1. When applicable cable is used, allowable wiring distance between Servopack and motor (PG) is up to 20m.
2. When wiring distance between Servopack and motor (PG) exceeds 20m, cable which can be used for up to 50m (YASKAWA DWG No. DP8409179) is available. Contact your YASKAWA representative.



## 5.4.2 Connector 3CN Layout and Connection

The terminal layout for the Servopack connector (3CN) is shown in Table 5.6, the connection with absolute encoder in Figs. 5.8 and 5.9 and the connection with incremental encoder in Figs. 5.10 and 5.11.

Table 5.6 Connector 3CN Layout

1	2	3	4	5	6	7
PGOV	PGOV	PGOV	PG5V	PG5V	PG5V	—
8	9	10	11	12	13	
—	—	—	—	BAT†	BATO†	
14	15	16	17	18	19	20
PC	*PC	PA	*PA	PB	*PB	FG

† Required only when absolute encoder is used.




Fig. 5.8 Connection between 3CN and Absolute Encoder  
(When soldered type cable DP8409123 is used)




Fig. 5.9 Connection between 3CN and Absolute Encoder  
(When caulking type cable DE8400093 is used)




Fig. 5.10 Connection between 3CN and Incremental Encoder  
(When soldered type cable B9400064 is used)




Fig 5.11 Connection between 3CN and Incremental Encoder  
(When caulking type cable DE8400093 is used)

## 5.5 CONNECTOR TERMINAL (4CN) FOR I/O SIGNAL

### 5.5.1 Applicable Receptacle

Table 5.7 Applicable Receptacle

Specifications of Connector Used in Servopack	Applicable Receptacle Type			
	Soldered Type	Caulking Type	Case	Maker
MR-20RMA Right angle 20P	MR-20F*	MRP-20F01	MR-20L*	HONDA Tsushin Co., Ltd.




\* Standard attachment of Servopack

### 5.5.2 Connector 4CN Layout and Connection

Table 5.8 shows the terminal layout of connector 4CN and Fig.5.12 shows the wiring diagram for 4CN.

Table 5.8 Connector 4CN Layout

1	2	3	4	5	6	7
0V	0V	0V	—	(+5V)	—	—
0V for (Serial communication) (Pulse train command) (PG division output) signal			—	+5V output (Pull-up resistor connection)	—	—
8		9	10	11	12	13
*TXD		*RXD	*CB	*CA	*FB	*FA
For serial communication (RS 422)		Line receiver negative side input for pulse train command		PG division output line driver negative side output		
Line driver negative side output	Line receiver negative side input	$\overline{B\phi}$ Input	$\overline{A\phi}$ Input	$\overline{B\phi}$ Output	$\overline{A\phi}$ Output	
14	15	16	17	18	19	20
TXD	RXD	CB	CA	FB	FA	FG
For serial communication (RS 422)		Line receiver positive side input for pulse train command		PG division output line driver positive side output		Frame Ground (Shielding process)
Line driver positive side output	Line receiver positive side input	$B\phi$ Input	$A\phi$ Input	$B\phi$ Output	$A\phi$ Output	



Note: The wiring length of the external pulse generator, line PG or external position indicator must be 5m or less.










Fig. 5.12 Wiring Diagram for 4CN

### 5.5.3 Description and Usage of I/O Signals of Connector 4CN

Signal Name	Pin No.	Name		Circuit Configuration	Function
TXD	14	Data transmit signal	Positive side output	(Line driver) 	Data transmit signal from Servopack by serial communication with RS422 specifications. When external position indicator (MCIF-L8) is used, current position data are sent. When data are not sent, signal line becomes high impedance.
*TXD	8		Negative side output		
RXD	15	Data receiving signal	Positive side input	(Line receiver) 	Data receiving signal from master controller (personal computer, etc.) by serial communication with RS422 specifications.
*RXD	9		Negative side input		
OV	1	OV for signal			TXD(*TXD), RXD(*RXD), OV for signal
CA	17	Pulse train input signal	Aφ	(Line receiver) 	<ol style="list-style-type: none"> <li>Reference pulse is input for positioning in external pulse train operation mode. (For pulse forms, refer to Par. 8.2 "PARAMETER 19".)</li> <li>When line PG (refer to Par. 6.2.5 (5)), feedback pulse is input.</li> </ol>
*CA	11		$\overline{A\phi}$		
CB	16		Bφ	(Line receiver) 	
*CB	10		$\overline{B\phi}$		
OV	2	OV for signal			CA(*CA), CB(*CB), OV for signal
FA	19	PG division output signal	Aφ	(Line driver) 	PG (encoder) division output can be obtained. Dividing ratio is set by parameters. Refer to Par. 8.2 "Parameter 64".
*FA	13		$\overline{A\phi}$		
FB	18		Bφ	(Line driver) 	Note: Even if motor rotating direction setting (b0 of parameter 14) is changed to 1 (rotating direction is reversed), phase relation between phases A and B is not changed.
*FB	12		$\overline{B\phi}$		
OV	3	OV for signal			OV for signal FA(*FA), FB(*FB)

Note: Serial data sending signal  
When data are not sent, signal line becomes high impedance. Therefore, mount pull-up and pull-down resistors on the host controller data receiving section.




Fig. 5.13

When CACR-HR [ ] [ ] BB is used on one axis and shorting pins SEL-1 and SEL-2 are at 2-3 side, no resistor at the host controller side is needed since pull-up and pull-down resistors are connected at Servopack side.  
For multi-axis configuration, switch SEL-1 and SEL-2 to 1-2 side and connect pull-up and pull-down resistors in the host controller side.

## 5.6 CONNECTOR TERMINAL (5CN) FOR I/O SIGNAL

### 5.6.1 Applicable Receptacle Specifications

Table 5.9 Applicable Receptacle Specifications

Specifications of Connector Used in Servopack	Applicable Receptacle Type			
	Soldered Type	Caulking Type	Case	Maker
MR-5ORMA Right angle 50P	MR-50F*	MRP-50F01	MR-50L*	HONDA Tsushin Co., Ltd.

\* Standard attachment of Servopack

### 5.6.2 Connector 5CN Layout and Connection

The layout for the Servopack connector (5CN) differs partially depending on position reference method (set by parameter 15). Table 5.10 shows "Station No. Command Method", Table 5.11 shows "DG-SW Command" and Table 5.12 shows "Command Table Method". "Common I/O signal" described in Par.5.6.3(1) can be used for serial command method.

Figs.5.14, 5.15 and 5.16 show the wiring diagram for 5CN.

Table 5.10 Connector 5CN Layout (Station No. Command Method)

Parameter 15 set value = 0

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
+24V	0 <sub>2</sub> V	AUT-LT	MAN-LT	POST	POS2	ERR	CUR	ZRN	MAN	MCW	MCCW	DRO	DRI	RST	CDO	CDI	0 <sub>2</sub> V
I/O 24V input	Output common OV	Operation display output	Operation mode output	Positioning complete output (COIN)	Positioning near output (NEAR)	Command error output	Current limit command input	Operation setting input	Operation mode input	Manual command input	Manual operation command input	Rotating select input	Rotating direction select input	Alarm reset input	Reference data input	Reference data input	OV pin for I/O 24V
		Auto mode	Manual mode				Zero- point return (homing) mode		Manual mode	CW opera- tion	CCW opera- tion	• No. increase direction • No. decrease direction • Short-cut direction			1 (1)	2 (2)	
		19	20	21	22	23	24	25	26	27	28	29	30	31	32		
		ALO	AL1	AL2	AL3	P0	CD2	CD3	CD4	CD5	CD6	CD7	CD8	CD9	CD10		
		Alarm code output (Binary)		Current station No. data output		Ref. data input											
		"1"	"2"	"4"	"8"	4 (4)	8 (8)	16 (10)	32 (20)	64 (40)	128 (80)	256 (100)	512 (200)	1024 (400)			
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
0 <sub>2</sub> V	PI	P2	P3	P4	BATALM		CD11			PSO	PSI	SP2ND	SP3RD	PULS			FG
Output common OV	Current station No. data output	Current station No. data output	Current station No. data output	Current station No. data output	Battery voltage low alarm output		Ref. data input		Station No. reading select input (P0 to P4 output control)	Speed select input	Speed select code	Pulse opera- tion mode selec- tion input					Frame ground
	2	4	8	16			2048 (800)			(1st speed) to (4th speed)							



Table 5.11 Connector 5CN Layout (DG-SW Command Method)

Parameter 15 set value = 1

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
+24V	0 <sub>2</sub> V	AUT-LT	MAN-LT	POSI	POS2	ERR	CUR	ZRN	MAN	MCW	MCCW			RST	DS110	DS111	0 <sub>2</sub> V	
I/O 24V input	Output common 0V	Operation display output	Manual mode	Positioning complete output (COIN)	Positioning near output (NEAR)	Command error output	Current limit command input	Zero- point return (homing) mode	Operation mode setting input	Manual operation command input	Manual operation command input				Alarm reset input	Ref. data input		0V pin for I/O 24V
		Auto mode	Manual mode													1	2	
		19	20	21	22	23	24	25	26	27	28	29	30	31	32			
		ALO	AL1	AL2	AL3	DS00	DS112	DS113	DS114	DS115	DS116	DS117	DS120	DS121	DS122			
		Alarm code output (Binary)		Data strobe output		Position ref. data input		Speed ref. data input										
		"1"	"2"	"4"	"8"	1 (LSB)*	4	8	1	2	4	8	1	2	4			
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	
0 <sub>2</sub> V	DS01	DS02	DS03	DS04	BATALM		DS123	DS124	DS125	DS126	DS127	SP2ND	SP3RD	PULS	LPC		FC	
Output common 0V	Data strobe output	Battery voltage low alarm output	Speed ref. data input		Speed select code input	Pulse opera- tion mode select- ion input	Speed ref. data input		Speed select code input	Line PC select input	Line PC select input						Frame ground	
2	3	4 (MSD)†	(Sign)		8	1	2	4	8	(1st speed) to (4th speed)								

\* LSB: Least Significant Digit  
† MSD: Most Significant Digit



• Wiring Diagram for 5CN (Station No. Command Method)

Parameter 15 set value = 0





Fig. 5.14 Wiring Diagram for 5CN (Station No. Command Method)

• Wiring Diagram for 5CN (DG-SW Command Method)

Parameter 15 set value = 1



Note: The wiring length of the DG-SW unit must be 5m or less.

Fig. 5.15 Wiring Diagram for 5CN (DG-SW Command Method)

• Wiring Diagram for 5CN (Command Table Method)

Parameter 15 set value = 4




Fig. 5.16 Wiring Diagram for 5CN (Command Table Method)

5

### 5.6.3 Description and Usage of I/O Signals of Connector 5CN





(1) Common I/O signals: Can be used regardless of position reference method (set by parameter 15), including serial command method.

#### • Output Signals

Signal Name	Pin No.	Name	Effective logic	Function										
$\overline{AL0}$	19	Servo Alarm Code Output* (1, 2, 4, 8)		Outputs the contents in binary when an alarm occurs (ALM signal = H level) or an error occurs ( $\overline{ERR}$ signal = L level). (Refer to Par. 6.3.2 (9).)										
$\overline{AL1}$	20													
$\overline{AL2}$	21													
$\overline{AL3}$	22													
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Signal Name</th> <th><math>\overline{AL0}</math></th> <th><math>\overline{AL1}</math></th> <th><math>\overline{AL2}</math></th> <th><math>\overline{AL3}</math></th> </tr> </thead> <tbody> <tr> <td>Binary</td> <td>1</td> <td>2</td> <td>4</td> <td>8</td> </tr> </tbody> </table>					Signal Name	$\overline{AL0}$	$\overline{AL1}$	$\overline{AL2}$	$\overline{AL3}$	Binary	1	2	4	8
Signal Name	$\overline{AL0}$	$\overline{AL1}$	$\overline{AL2}$	$\overline{AL3}$										
Binary	1	2	4	8										
$\overline{ERR}$	7	Error Output		Outputs if contact reference data error or malfunction during motor applied with current. Does not operate when $\overline{ERR}$ signal is operating (L level).										
$\overline{POS1}$	5	Positioning Complete Output (COIN)		Outputs with   current position - aimed position   $\leq$ parameter 6 set value. (Refer to Par. 8.2, "Parameter 6".)										
$\overline{POS2}$	6	Positioning Near Output (NEAR)		Outputs with   current position - aimed position   $\leq$ parameter 45 set value. (Refer to Par. 8.2, "Parameter 45".)										
$\overline{AUT-LT}$	3	Operation Mode Display Output		Auto	Outputs when "auto operation mode" is set during servo ON status.									
$\overline{MAN-LT}$	4			Manual	Outputs when "manual operation mode" is set during servo ON status.									
$\overline{BATALM}$	38	Battery Voltage Low Alarm		Detects and outputs when battery voltage provided on the board is low (only at power supply turned ON).										



\* In the station No. command method (parameter 15 set value = 0), by setting parameter 20 b6=1 and parameter 66 b4=1, current data (station No.) output signals (P5 to P8) are enabled.

• Input Signals

Signal Name	Pin No.	Name		Effective Logic	Function			
ZRN	9	Operation Mode Setting Input	Zero-Point Return (Homing)	Operation mode is determined by combination of three types of signals H or L level setting described on the left.	ZRN	MAN	PULS	Operation Mode
MAN	10		Auto/Manual		H	H	H	Auto
PULS	47		Pulse Operation		H	L	H	Manual
					L	H	H	Zero-point return (homing)
					H	H	L	Pulse
MCW	11	Manual Operation Command	Motor Reverse Direction		Signal becomes effective in manual operation mode setting. Operation can be performed only while this signal is turned on.			Motor reverse direction command
MCCW	12		Motor Forward Direction					Motor forward direction command
RST	15	Alarm Reset			Resets alarm status. Check the alarm contents before turning on this signal.			
SP2ND	45	Speed Select Signal	2nd Speed	Selects parameter setting (1st speed) to (4th speed) reference speed.	SP2ND	SP3RD	Auto/Manual Operation Mode	Pulse Operation Mode
SP3RD	46		3rd Speed				Parameter No. (Contents)	Input pulse multiplication
					H	H	4 (1st speed)	× 1
					L	H	31 (2nd speed)	× 10
					H	L	32 (3rd speed)	× 100
					L	L	33 (4th speed)	× 1
CUR	8	Current Limit Command			Motor current is limited with current value set by parameter by turning on this signal.			
LPG	48	Line PG Select Input			Signal used for line PG. Feedback system is switched to line PG by turning on this signal.			

5


(2) Reference data signal for Station No. reference method  
 (Parameter 15 Set Value = 0)

Signal Name	Pin No.	Name	Effective Logic	Function				
$\overline{DRO}$	13	Rotating Direction Select Input	+	Rotating direction is set by signal combination.	$\overline{DRO}$	$\overline{DRI}$	Absolute Mode	Incremental Mode
					H	H	Short-cut direction	(Error)
$\overline{DRI}$	14		-		L	H	Station No. increase direction	Station No. increase direction
					H	L	Station No. decrease direction	Station No. decrease direction
					L	L	(Error)	(Error)
Absolute/incremental modes are set by parameter 14 b3.								
$\overline{CD0}$	16	Station No. Reference Data			BCD setting (0 to 999)	Binary setting (0 to 4095)	1	1
$\overline{CD1}$	17						2	2
$\overline{CD2}$	24						4	4
$\overline{CD3}$	25						8	8
$\overline{CD4}$	26						10	16
$\overline{CD5}$	27						20	32
$\overline{CD6}$	28						40	64
$\overline{CD7}$	29						80	128
$\overline{CD8}$	30						100	256
$\overline{CD9}$	31						200	512
$\overline{CD10}$	32						400	1024
$\overline{CD11}$	40	800	2048					
BCD/binary are selected by parameter setting (14 b4).								
$\overline{PS0}$	43	Station No. Read-out Select Input		Reads out current station No. data output ( $\overline{P0}$ to $\overline{P4}$ ) by signal combination.	H	L	H	L
$\overline{PS1}$	44				H	H	L	L
$\overline{P0}$	23	Current Station No. Data Output			(BCD) : (BINARY)	(BCD) : (BINARY)	(BCD) : (BINARY)	(BCD) : (BINARY)
$\overline{P1}$	34				1 : 1	1 : 1	10 : 16	100 : 256
$\overline{P2}$	35				2 : 2	2 : 2	20 : 32	200 : 512
$\overline{P3}$	36				4 : 4	4 : 4	40 : 64	400 : 1024
$\overline{P4}$	37				8 : 8	8 : 8	80 : 128	800 : 2048
		10 : 16	Parity	Parity	Parity			



- Notes: 1. Parity outputs so that number of low level of  $\overline{P0}$  to  $\overline{P4}$  becomes odd number.  
 2. Current station No. data output is a coded output as in the following example.

when :  $\overline{PS0} = H$ ,  $\overline{PS1} = H$ , parameter 14 b4 = 0



3. If motor stops at a position between two stations, the nearer station No. is output.
4. During motor rotation, current station No. data output is unstable.

5

(3) Reference data signal for DG-SW reference method  
 (Parameter 15 Set Value = 1)


Signal Name	Pin No.	Name	Effective Logic	Function						
$\overline{DS110}$	16	Position Ref. Data Input		1					BCD Selected by data strobe output described below is input by 2 digits.	
$\overline{DS111}$	17			2	$10^0$	$10^2$	$10^4$	$10^6$		+
$\overline{DS112}$	24			4	digit	digit	digit	digit		-
$\overline{DS113}$	25			8						
$\overline{DS114}$	26			1						
$\overline{DS115}$	27			2	$10^1$	$10^3$	$10^5$	$10^7$		
$\overline{DS116}$	28			4	digit	digit	digit	digit		
$\overline{DS117}$	29			8						
$\overline{DS120}$	30	Speed Ref. Data Input		1						
$\overline{DS121}$	31			2	$10^0$	$10^2$	$10^4$			
$\overline{DS122}$	32			4	digit	digit	digit			
$\overline{DS123}$	40			8						
$\overline{DS124}$	41			1						
$\overline{DS125}$	42			2	$10^1$	$10^3$	$10^5$			
$\overline{DS126}$	43			4	digit	digit	digit			
$\overline{DS127}$	44			8						
$\overline{DS00}$	23	Data Strobe Output	Read-in time for one digit can be set by parameter 77. (Normally, it is set to 24ms.)  24ms to 2000ms 						Data strobe is output in order by any pulse width.	
$\overline{DS01}$	34									It takes 5 times of pulse width to read-in all digits.
$\overline{DS02}$	35									
$\overline{DS03}$	36									
$\overline{DS04}$	37									

(4) Reference data signal for command table method  
(Parameter 15 set Value = 4)

Signal Name	Pin No.	Name	Effective Logic	Function	
$\overline{CD0}$	16	Position No., Speed No., Reference Data Input		1	Specifies position No. and speed No. in $\overline{CD0}$ to $\overline{CD5}$ codes. Specifies 64 when all $\overline{CD0}$ to $\overline{CD5}$ codes are OFF(H). Set parameter 14 b4=0 since $\overline{CD0}$ to $\overline{CD5}$ are effective only in binary setting.
$\overline{CD1}$	17			2	
$\overline{CD2}$	24			4	
$\overline{CD3}$	25			8	
$\overline{CD4}$	26			16	
$\overline{CD5}$	27			32	
$\overline{P0}$	23	Zone Signal Output		1	Output only when parameter 20 b5=1 and parameter 65 b0=1 are set.
$\overline{P1}$	34			2	
$\overline{P2}$	35			4	
$\overline{P3}$	36			8	
$\overline{P4}$	37			16	

Notes

1. Zone signals are coded output as shown below. (It is safe to read in the data during stop because of coded output.)



2. Boundary positions of BT1 to BT31 are set by serial command. Positions must be arranged in the order as shown above.

3. It takes 40ms maximum from boundary position passing to zone signal change.

4. Even if the number of boundary positions to be set is less than 31, keep the order from BT1 to BT31. (Set so as to be  $BT_n \text{ value} \leq BT_{n+1} \text{ value}$ .)

## 5.7 POWER SUPPLY CONNECTION

### 5.7.1 Power Supply ON/OFF

For main circuit power supply (R, S, T) \*1 or control power supply (r, t) to turn on in sequence, they are turned on simultaneously or the control power supply is turned on before the main circuit power supply. (see Figs. 5.17 and 5.18.)

\*1 (R, T) for Servopack Type HR [ ] [ ] BAB1 [ ] .




Fig. 5.17 Typical Connection when Both Control Power Supply and Main Power Supply are Turned ON/OFF Simultaneously




Fig. 5.18 Typical Connection when only Main Circuit Power Supply is Turned ON/OFF

\*2 HR [ ] BAB12 — Single-phase 200 to 230VAC (50/60Hz)

HR [ ] BAB11 — Single-phase 100 to 115VAC (50/60Hz)

Note: 1SUP, 2SUP: Surge suppressor

CR50500BA (made by OKAYA ELECTRIC INDUSTRIES Co., Ltd.) or equivalent

1D: Flywheel diode (to prevent Ry spikes)

For power supply to turn off in sequence, both power supplies are turned off simultaneously (including momentary power loss) (Fig. 5.17) or the main circuit power supply is turned off before the control power supply (Fig. 5.18).

(Precautions for Figs. 5.17 and 5.18)

- Main circuit power supply must be turned off by SERVO ALARM signal.

(If the control supply is also turned off, LED which indicates the servo alarms also goes out)

- In power supply ON-OFF sequence in Fig. 5.17, it takes approx. 1 second at maximum to establish a normal signal in the control circuit (1Ry is turned on).

Note : Because of initializing the Servopack, SERVO ALARM signal is output for approx. 1 second at maximum (typical 200 to 300ms) when the control power supply is turned on.

Therefore, hold POWER ON signal for more than 1 second.

However, in the sequence in Fig. 5.18, it is not necessary since the control power supply is always turned on.

- Since Servopack is of capacitor input type, large charging current (charging time is 0.5 second) is applied when the main circuit power supply is turned on. Therefore, frequent switching of power supply will result in deterioration of the main circuit elements which may cause unexpected trouble.

(Motor operation start/stop must be performed by turning operation signal ON-OFF. Do not use the power supply ON-OFF.)

- Turn on or off Servopack power supply in SERVO OFF state to prevent trouble at transition.

## 5.7.2 Power Supply Line Protection

Servopack is of line operated type using commercial power supply (200V) \*.

Circuit breakers (MCCB) or fuses must be used to protect the power-supply lines to the Servopack. Select the breakers or fuses based on the number of Servopacks and their ratings. (Refer to Table 5.13.)

Do not use fast-blow fuses because the in-rush current will destroy them.

\* : 100V for Servopack Type HR [ ] [ ] BAB11.

Table 5.13 Power Supply Capacity and MCCB or Fuse Capacity

Servopack Type CACR-	Power Supply *1 Capacity per Servopack (kVA)	Power Supply *2 Capacity per MCCB or Fuse (A)
HRA5BAB12	0.3	5
HR01BAB12	0.5	5
HR02BAB12	0.75	5
HR03BAB12	1.0	7
HR05BAB12	1.4	11
HR10BAB	2.1	8
HR15BAB	3.1	10
HR03BB	0.65	5
HR05BB	1.1	5
HR10BB	2.1	8
HR15BB	3.1	10
HR20BB	4.1	12
HR30BB	6.0	18
HR44BB	8.0	24
HR60BB	11	32
HRA5BAB11	0.3	5
HR01BAB11	0.5	5
HR02BAB11	0.75	8
HR03BAB11	1.0	11
HR05BAB11	1.4	15

\*1 : Values at rated load

\*2 : Breaking characteristic (25°C) : 200% 2s or more, 700% 0.01s or more

Note : Use a high-speed type of earth leakage circuit breaker. (Time-delay type is not adjustable.)

## 5.8 RATED CURRENT AND TYPICAL APPLICABLE CABLE SIZE

Tables 5.14 and 5.15 show Servopack external terminal rated current and typical applicable cable size for rated current. Applicable cables and sizes are selected according to current capacity. The values shown in Table 5.15 are obtained under conditions where rated current is applied at ambient temperature of 40°C and in three lead wires. Table 5.16 shows the types of applicable cables.

Table 5.14 Servopack External Terminal Rated Current (A: rms)

External Terminal Name		Terminal Symbol	Type CACR- [ ]						
			HRA5BAB12	HRO1BAB12	HRO2BAB12	HRO3BAB12	HRO5BAB12	HR10BAB	HR15BAB
On-line	Main circuit power supply input terminal	R, T*	1.3	2.5	4.4	6.5	10.4	8	10
	Motor connection terminal	U, V, W	0.7	1.0	2.0	2.7	3.6	7.6	11.7
	Control power supply input terminal	r, t	0.5						
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	100mA DC Max.						
	PG signal connector	3CN	100mA DC Max. 500mA for power supply line						
	Grounding terminal	FG	-						

\* R, S, T for Servopack HR10BAB and HR15BAB.

External Terminal Name		Terminal Symbol	Type CACR- [ ]							
			HR03BB	HR05BB	HR10BB	HR15BB	HR20BB	HR30BB	HR44BB	HR60BB
On-line	Main circuit power supply input terminal	R, S, T	2	5	8	10	12	18	24	32
	Motor connection terminal	U, V, W	3.0	4.2	7.6	11.7	18.8	26.0	33.0	45
	Control power supply input terminal	r, t	0.5							
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	100mA DC Max.							
	PG signal connector	3CN	100mA DC Max. 500mA for power supply line							
	Grounding terminal	FG	-							

External Terminal Name		Terminal Symbol	Type CACR- [ ]				
			HRA5BAB11	HRO1BAB11	HRO2BAB11	HRO3BAB11	HRO5BAB11
On-line	Main circuit power supply input terminal	R, T	2.6	4.5	8.0	11.0	15.0
	Motor connection terminal	U, V, W	1.2	1.7	2.9	3.6	5.5
	Control power supply input terminal	r, t	0.5				
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	100mA DC Max.				
	PG signal connector	3CN	100mA DC Max. 500mA for power supply line				
	Grounding terminal	FG	-				

Table 5.15 Typical Applicable Cable Size (mm<sup>2</sup>)

External Terminal Name		Terminal Symbol	Type CACR- [ ]					
			HRA5BAB12	HRO1BAB12	HRO2BAB12	HRO3BAB12	HRO5BAB12	HR10BAB
On-line	Main circuit power supply input terminal	R, T*	1.25			2.0		3.5
	Motor connection terminal	U, V, W	1.25				3.5	
	Control power supply input terminal	r, t	1.25					
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	Twisted pair cable or twisted pair totally shielded cable Core cable 0.2mm or more, plated soft steel twisted cable Finished dimensions : 5CN $\phi$ 16 or less 2CN, 3CN, 4CN $\phi$ 11 or less					
	PG signal connector	3CN						
	Grounding terminal	FG	1.25				2.0	

External Terminal Name		Terminal Symbol	Type CACR- [ ]						
			HRO3BB	HRO5BB	HR10BB	HR15BB	HR20BB	HR30BB	HR44BB
On-line	Main circuit power supply input terminal	R, S, T	1.25		2.0	3.5		5.5	8.0
	Motor connection terminal	U, V, W	1.25		3.5		5.5	8.0	
	Control power supply input terminal	r, t	1.25						
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	Twisted pair cable or twisted pair totally shielded cable Core cable 0.2mm or more, plated soft steel twisted cable Finished dimensions : 5CN $\phi$ 16 or less 2CN, 3CN, 4CN $\phi$ 11 or less						
	PG signal connector	3CN							
	Grounding terminal	FG	2.0						

External Terminal Name		Terminal Symbol	Type CACR- [ ]				
			HRA5BAB11	HRO1BAB11	HRO2BAB11	HRO3BAB11	HRO5BAB11
On-line	Main circuit power supply input terminal	R, T	1.25		2.0		
	Motor connection terminal	U, V, W	1.25				2.0
	Control power supply input terminal	r, t	1.25				
Off-line	Control I/O signal connectors	2CN, 4CN, 5CN	Twisted pair cable or twisted pair totally shielded cable Core cable 0.2mm or more, plated soft steel twisted cable Finished dimensions : 5CN $\phi$ 16 or less 2CN, 3CN, 4CN $\phi$ 11 or less				
	PG signal connector	3CN					
	Grounding terminal	FG	1.25				

\*: R, S, T for Srvopack Type HAR10BAB, HAR15BAB.

Notes: 1. All sizes are for HIV [ ] or more.

2. Applicable cable size selecting conditions :

Rated current is applied at ambient temperature of 40°C and in three lead wires.



Table 5.16 Applicable Cable


Cable Type		Conduit Allowable Temperature (°C)
Symbol	Name	
PVC	General vinyl cable	—
IV	600V vinyl cable	60
HIV	Special heat-resistant vinyl cable	75

## 5.9 NOISE CONTROL

Servopack uses power transistors in the main circuit. When these transistors are switched, the effect of di/dt or dv/dt (switching noise) may sometimes occur depending on the wiring or grounding method.

The Servopack incorporates CPU. This requires wiring and treatment to prevent noise interference. The recommended wiring and grounding are for reducing switching noise shown in Fig. 5.19.

### (1) Grounding method



\* 100 V For Servopack Type HR BAB11

P: Twisted cable

Notes:

- 1 Use wires of 3.5mm<sup>2</sup> or more for grounding to the case (preferably flat-woven copper wire).
- 2 Connect line filters observing the precautions as shown in (2) Noise filter installation.

Fig. 5.19 Grounding Method

## 5.9 NOISE CONTROL (Cont'd)

- Motor frame grounding

When the motor is at the machine side and grounded through the frame, Cf dv/dt current flows from the PWM power through the stray capacity of the motor. To prevent this effect of current, motor ground terminal ① (motor frame) should be connected to terminal ⊕ of Servopack.

(Terminal ⊕ of Servopack should be directly grounded.)

- Metallic Conduit Grounding

When motor wiring is in a metallic conduit, ground the conduit and the terminal box. Perform the following grounding procedures at one point.





### (2) Noise filter installation

When noise filters are installed to prevent noise from the power line, the block type must be used. The recommended noise filter is shown in Table 5.17. The power supply to peripherals also needs noise filters.

#### Note

If the noise filter connection is wrong, the effect decreases greatly. Observing the precautions, carefully connect them as shown in Figs. 5.20 to 5.23.

Table 5.17 Recommended Noise Filter

Servopack Type CACR-	Applicable Noise Filter	Recommended Noise Filter		Servopack Type CACR-	Applicable Noise Filter	Recommended Noise Filter	
		Type	Specifications			Type	Specifications
HRA5BAB12 HRO1BAB12 HRO2BAB12	<p>(CORRECT)</p>  <p>(WRONG)</p> 	LF-205A	Single-phase 200VAC class, 5A	HR44BB HR60BB	<p>(CORRECT)</p>  <p>(WRONG)</p> 	LF-340	Three-phase 200VAC class, 40A
HR03BAB12		LF-210	Single-phase 200VAC class, 10A	HRA5BAB11		LF-350	Three-phase 200VAC class, 50A
HR05BAB12		LF-215	Single-phase 200VAC class, 15A	HRO1BAB11		LF-205A	Single-phase 200VAC class, 5A
HR10BAB HR15BAB		LF-315	Three-phase 200VAC class, 15A	HRO2BAB11		LF-210	Single-phase 200VAC class, 10A
HR03BB HRO5BB		LF-305	Three-phase 200VAC class, 5A	HR03BAB11		LF-215	Single-phase 200VAC class, 15A
HR10BB HR15BB		LF-315	Three-phase 200VAC class, 15A	HR05BAB11		LF-220	Single-phase 200VAC class, 20A
HR20BB		LF-320	Three-phase 200VAC class, 20A				
HR30BB		LF-330	Three-phase 200VAC class, 30A				

Note: Noise filter made by Tokin Corp.

- (a) Separate the input leads from the output. Do not bundle or run them in the same duct.




Fig. 5.20

- (b) Do not bundle the ground lead with the filter output line or other signal lines or run them in the same duct.




Fig. 5.21

- (c) Connect the ground lead singly to the box or the ground panel.




Fig. 5.22

- (d) The filter on the control panel is required to ground to the equipment ground terminal.




Fig. 5.23

## 5.9 NOISE CONTROL (Cont'd)

### (3) Serial communication line noise preventive action

When personal computers, etc. are used as master controllers, insert troidal core (ESD-RB series by Tokin Corp. or equivalent) in the input section as a noise preventive action.

Take some noise preventive action (such as insertion of a line filter) in the power supply lines.




Fig. 5.24

## 6 I/O SIGNAL OPERATION AND FUNCTIONS

### 6.1 OPERATION AND FUNCTIONS OF 2CN INPUT SIGNAL


#### 6.1.1 Signal Timing

- $\overline{\text{SVON}}$ ,  $\overline{\text{AST}}$ , STOP, N-OT, P-OT, DEC,  $\overline{\text{PCON}}$

These signals are sampled every 2ms and read-in whenever the same levels are continued more than two times. (2 to 4ms filter)


It is necessary to hold more than 5ms to be effective.

#### Example of $\overline{\text{AST}}$ Signal



- Since STP signal has a small filter, the above example is not applied.


#### 6.1.2 Input Circuit (Refer to Fig. 5.7 for Connection.)



### 6.1.3 Signal Operation and Functions


#### (1) Servo on $\overline{SVON}$

By turning on this signal, Servopack main circuit power drive circuit operates according to the following conditions and the motor is applied with current.



#### (2) Operation start $\overline{AST}$

- ① Operation start signal in automatic operation mode or zero-point return (homing) mode. 5ms or more pulse width required.
- ②  $\overline{AST}$  signal becomes effective when the following conditions are satisfied and operation is started by signal rising edge.



#### Notes:

- Position reference not normal: when reference data exceed software overtravel value (refer to Par. 8.3 "Parameters 40, 41").
- Speed reference not normal : when data exceed speed limit value (refer to Par. 8.3 "Parameter 46").



\* The STOP signal is active when contact is open.

In the above cases, an error occurs by turning  $\overline{AST}$  signal on and operation does not start. Instead,  $\overline{ERR}$  signal (refer to Par. 6.3.2 (3)) is output.

③ When  $\overline{AST}$  signal is not accepted (disregarded):

- Motor is moving.
- Motor is not under current conduction.
- Automatic operation mode or zero-point return (homing) mode is not selected.

④ Timing chart




( $\alpha$  is accel/decel rate and set by parameter.)


### 6.1.3 Signal Operation and Functions (Cont'd)

#### (3) Temporary stop [STOP]

- ① Temporary stop reference in automatic operation mode or zero-point return (homing) mode. 5ms more than pulse width is required.
- ② If STOP signal is turned on during operation, it is detected by the signal rising edge and deceleration to a stop is performed at parameter set speed.




- ③ STOP signal contains feed hold function. That is, when position reference data are not discharged completely and operation stops after STOP signal is turned on, if  $\overline{\text{AST}}$  signal is turned on, aimed position and feeding speed will be processed with the former data. (Remaining positioning)






- ④ Feed hold functions when  $\overline{\text{AST}}$  signal is turned on with STOP signal turned on.



- ⑤ Typical operation with STOP signal



- ⑥ Feed hold release

- After  $\overline{\text{AST}}$  signal is turned on when STOP signal is OFF.
- Operation mode is switched.
- Baseblocking (current is not applied to motor.)

- ⑦ When STOP signal input remains open, stop status continues. Therefore, when STOP signal is not used, set parameter 19 b1 = 1.


### 6.1.3 Signal Operation and Functions (Cont'd)

#### (4) Overtravel LS (P-OT, N-OT)

- ① When P or N-OT signal operates, speed reference in the moving direction is forced to be 0. (Motor stops at maximum deceleration rate during operation.)
- ② Relation between reference direction, motor rotating direction and P-ON or N-OT Signal.

Parameter 14b0	Reference Direction (Ref Data Polarity)	Motor Rotating Direction	Effective OT Signal
0 (Standard)	+	Forward(CCW)	P-OT
	-	Reverse(CW)	N-OT
1 (Reverse Connection)	+	Reverse(CW)	P-OT
	-	Forward(CCW)	N-OT

- ③ When P-ON and N-OT signal are not used, set parameter 19 b0 = 1.
- ④ After P-OT or N-OT signal is detected, there is a 4ms lag time at maximum until braking is actually applied. Additionally, there is a braking time until stop. When LS is set, these points must be considered.



#### (5) LS related to zero-point return (homing) [DEC, STP]

Refer to the zero-point return (homing) mode described in Par. 6.2.3 (1) (d).

#### (6) Proportional operation reference [PCON]

Speed loop control mode is changed from PI operation to P operation by turning on this signal, and servo rigidity is reduced.

## 6.2 OPERATION AND FUNCTIONS OF 5CN INPUT SIGNAL


### 6.2.1 Signal Timing

Input signals are divided into four groups (CH0 to CH3: refer to Figs. 5.14, 5.15 and 5.16).


Each group is sampled every 8ms with 2ms width pulse.

When the same level continues three times or more, each signal is read-in (24 to 32ms filter).

Signal must be hold more than 30ms to be effective.



### 6.2.2 Input Circuit (Refer to Figs. 5.14, 5.15 and 5.16 for Typical Connection.)



### 6.2.3 Signal Operation and Functions


(1) Operation mode setting  $\overline{\text{MAN}}$ ,  $\overline{\text{ZRN}}$ ,  $\overline{\text{PULS}}$

Automatic, manual, external pulse train or zero-point return (homing) operation mode is selected by operation mode signal setting, as shown below:

Operation Mode	Operation Mode Setting Signal			Description
	$\overline{\text{MAN}}$	$\overline{\text{PULS}}$	$\overline{\text{ZRN}}$	
Automatic	H	H	H	Sets position data and performs positioning by turning on $\overline{\text{AST}}$ signal.
Manual	L	H	H	Performs constant speed operation by manual signal ( $\overline{\text{MCW}}$ , $\overline{\text{MCCW}}$ ).
External pulse train	H	L	H	Performs positioning by pulse train reference.
Zero-point return(homing)	H	H	L	Zero-point return method is selected by parameter setting.
	H	L	L	Setting status described on the left is considered as an error and ERR signal is output. Operation cannot be performed.
	L	H	L	
	L	L	H	
	L	L	L	

Note:

1. If operation mode is switched during motor rotating, the motor will stop.  
(In this case, there is no feed hold)
2. 50ms or more is needed for timing with  $\overline{\text{AST}}$  signal.




(a) Automatic operation mode

Position Reference Method	Parameter 15 Set Value	Position Data	Reference Direction	Operation
Station No. Reference Method	0	Station No. Reference contact data $\overline{CD0}$ to $\overline{CD11}$ .	By rotating direction selection signal $\overline{DR0}$ or $\overline{DR1}$ .	By turning on $\overline{AST}$ signal, the axis is positioned at station No. set at constant data. (Absolute value or incremental reference)
DG-SW Reference Method	1	DG-SW Reference data value	DG-SW reference data polarity (+/-)	By turning on $\overline{AST}$ signal, the axis is moved to the position set by DG-SW reference data. (Absolute or incremental reference)
		$\overline{DS110}$ to $\overline{DS117}$ $\overline{DS00}$ to $\overline{DS04}$		
Command Table Method	4	Position No., speed No. selection signals $\overline{CD0}$ to $\overline{CD5}$		By turning ON the $\overline{AST}$ signal, positioning is performed at the position specified by position No. selection signals.

Notes:

- There are four speed setting methods by parameter setting.
  - (1st speed) to (4th speed) by selected  $\overline{SP2ND}$  and  $\overline{SP3RD}$  (speed setting signal)
  - DG-SW
  - serial command
  - speed table
- Timing with  $\overline{AST}$  signal



Since DG-SW data are strobed for five times by 2 digits, it takes more than 120ms\* for complete input of all digits. Refer to Par. 5.6.3 (3).




\* For parameter 65 setting "b2 = 0".

### 6.2.3 Signal Operation and Functions (Cont'd)

(b) Manual operation mode


Constant start operation is performed only when manual operation signal ( $\overline{\text{MCW}}$  or  $\overline{\text{MCCW}}$ ) is turned on. Operation method is set on parameter 15.

(Position reference method: Station No., DG-SW or command table)


Items	Contents
Accel/Decel speed speed	 <p>SPEED : FOUR TYPES OF SETTING METHODS AVAILABLE</p> <p><math>\alpha</math>: ACCELERATION RATE (PARAMETER SETTING)</p>
Conditions	 <p>MOTOR CURRENT CONDUCTION (SERVO ON)</p> <p>MANUAL OPERATION MODE</p> <p>MCCW ON</p> <p><math>\overline{\text{MCW}}</math> ON</p> <p>MOTOR FORWARD RUNNING</p> <p>MOTOR REVERSE RUNNING</p>
Operation	<p>Station No. Ref. Method            (Parameter 15) = 0</p> <p>MCW (OR MCCW)</p>  <p>(STOPPING TARGET POINT) (IS INDICATED BY NO. 2.)</p> <p>(STATION NO.) No.1 No.2 POSITION</p> <p>Due to accel/decel rate, the second, nearest station may be selected.</p>
	<p>DG-SW Ref. Method            (Parameter 15) = 1</p> <p>Stops at a deceleration rate set to parameter after operation signal is turned OFF.</p>
	<p>Command Table Method            (Parameter 15) = 4</p>

Notes:

1. Timing with operation setting signal



2. When speed select signal ( $\overline{SP2ND}$ ,  $\overline{SP3RD}$ ) is used and speed is changed during operation, corresponding parameter speed is set.




3. In DG-SW speed reference, speed varies if the setting is changed while  $\overline{MCW}$  ( $\overline{MCCW}$ ) is turned on since setting data are read-in every 120ms\*. However, do not change DG-SW setting during operation, incorrect data may be read-in.

\* Parameter 65 b2 = 0

### 6.2.3 Signal Operation and Functions (Cont'd)

#### (c) Pulse train operation mode


In this mode, positioning by external reference pulse train is performed.



#### Notes:

1. One-pulse input moves one reference unit.
2. Frequency  $\rightarrow$  reference speed  $\{ f \text{ (pps)} \rightarrow f \times 60 \text{ (reference unit) /min.} \}$   
 Number of pulses  $\rightarrow$  Positioning value  $\{ P \text{ (pulse)} \rightarrow P \text{ (reference unit)} \}$
3. For pulse train signal form to be input to 4CN, refer to Par. 8.2 "Parameter.19 b3".
4. Speed select signals ( $\overline{\text{SP2ND}}$ ,  $\overline{\text{SP3RD}}$ ) at pulse operation mode determines input pulse multiplier.


$\overline{\text{SP2ND}}$	$\overline{\text{SP3RD}}$	Pulse Multiplier
H	H	$\times 1$
L	H	$\times 10$
H	L	$\times 100$
L	L	$\times 1$





(d) Zero-point return (homing) mode (positioning using LS)

When zero-point return mode is used, set parameter 18 b4 = 1.




### 6.2.3 Signal Operation and Functions (Cont'd)


Note 1: Related parameters: Parameters described below become effective when parameter 18 b4 = 1, ineffective when b4 = 0.

Parameter No.	Name	Setting Range	Unit
50	Zero-point return (homing) direction	0:FWD, 1: REV direction	
51	Zero-point return feed speed	0 to 240000	×1000 • reference unit/min.
52	Zero-point return approach speed	0 to 240000	
53	Zero-point return creep speed	0 to 240000	
54	Zero-point return final traveling distance	FWD: 0 to +99999999	Reference unit
		REV: -99999999 to 0	

Note 2: When DEC signal is at H level in mode I and  $\overline{AST}$  signal is activated, operation is started at approach speed (parameter 52) from the beginning, regardless of zero-point return feed speed (parameter 51).



Note 3: When STP signal is at H level in mode II and  $\overline{AST}$  signal is activated, an error occurs ( $\overline{ERR}$  signal is output.)



(2) Speed selection [ $\overline{SP2ND}$ ,  $\overline{SP3RD}$ ]

- In automatic or manual operation mode, reference speed can be selected from (1st speed) to (4th speed) by combination of speed selection signals and speed reference selection (Refer to Par.8.2 "Parameter 18 b2, b3").


Speed Select Signal		Parameter		
$\overline{SP2ND}$	$\overline{SP3RD}$	No.	Name	Setting Range/Unit
H	H	4	1st feed speed	1 to 240000 ( $\times 1000 \cdot$ reference unit/min.)
L	H	31	2nd feed speed	
H	L	32	3rd feed speed	
L	L	33	4th feed speed	

- In pulse operation mode,  $\overline{SP2ND}$  and  $\overline{SP3RD}$  are used to select input pulse multiplier. (Refer to 6.2.3(1) (c) Note 4.)

6

(3) Alarm reset [ $\overline{RST}$ ]

- Signal to reset servo alarm status. This becomes effective with pulse width of 30ms or more.
- Refer to Par.6.1.3 (3) for the operation of  $\overline{RST}$  signal.
- If  $\overline{RST}$  signal is activated, at normal operation (not in servo alarm status), alarm output signal ALM becomes H.



### 6.2.3 Signal Operation and Functions (Cont'd)


#### (4) Current limit command $\overline{\text{CUR}}$

- By setting parameter 17 b0 = 1, plus or minus side current limit value set by parameter becomes effective when  $\overline{\text{CUR}}$  signal is turned on.
- Relation between current limit parameter and  $\overline{\text{CUR}}$  signal is shown in the table below:


Parameter		Parameter 17	Parameter 17 b0 = 1		
Name	No.	bo = 0	CUR signal = H	$\overline{\text{CUR}}$ signal = L	
		(Current Limit Value)	(Plus limit value)	(Minus limit value)	
(Motor special current limit value)	(7)	○	○	○	○
Current limit value	34	×	○	○	○
Plus limit value	35	×	×	○	×
Minus limit value	36	×	×	×	○

#### Notes:

1. Parameters with ○ are effective. When more than one parameter has ○, the smaller set value becomes effective.
2. Parameter 34 "current limit value" is effective for both plus and minus.
3. Limit value of parameters 35 and 36 are explained below:



(5) Line PG (external PG) switching [ $\overline{LPG}$ ]



- When  $\overline{LPG}$  signal is turned on, position feedback signal is switched from motor PG to line PG and position fully closed loop by line PG is formed.
- Line PG output pulse corresponds to reference data one-by-one. That is, one pulse from line PG is read-in as one reference unit move.
- When line PG is used, zero-point return (homing) cannot be performed. Entering zero-point return mode causes an error.

6

(6) Input signal used in station No. reference method

(a) Rotating direction selection [ $\overline{DRO}$ ,  $\overline{DRI}$ ]

By combining  $\overline{DRO}$  and  $\overline{DRI}$  signals, the rotating direction at the motor shaft (viewed from the load side) in automatic operation mode is selected as shown below:

Parameter 14-b3	Signal	$\overline{DRO}$	H	L	H	L
		$\overline{DRI}$	H	H	L	L
0	Absolute mode	Short-cut direction	Station No. increasing direction (Example)	Station No. decreasing direction (Example)	(This setting causes an error.)	
1	Incremental mode	(This setting causes an error.)				

### 6.2.3 Signal Operation and Functions (Cont'd)

(b) Station No. reference data ( $\overline{CD0}$  to  $\overline{CD11}$ )

Contact data input signal to specify the positioning station No.

By parameter (14 b4) setting, BCD or binary code is selected.


- Absolute mode: Move to data ( $\overline{CD0}$  to  $\overline{CD11}$ ) station No. position. (Parameter 14 b4 = 0)
- Incremental mode: Data ( $\overline{CD0}$  to  $\overline{CD11}$ ) indicates station No. to move to. (Parameter 14 b4 = 1)

(Example)

When data ( $\overline{CD0}$  to  $\overline{CD11}$ ) value is "3" with current station No. ⑤, ( $\overline{DR0} = L$ ,  $\overline{DR1} = H$ ) is input after start command is turned on.

<Absolute mode> : Move to station No. ③ position. (----->)

<Incremental mode> : Move to station No. ⑧ position. (————>)



• Station No. reference data codes

Parameter 14-b4	Data Code	$\overline{CD0}$	$\overline{CD1}$	$\overline{CD2}$	$\overline{CD3}$	$\overline{CD4}$	$\overline{CD5}$	$\overline{CD6}$	$\overline{CD7}$	$\overline{CD8}$	$\overline{CD9}$	$\overline{CD10}$	$\overline{CD11}$
1	BCD (0 to 999)	1	2	4	8	10	20	40	80	100	200	400	800
0	Binary (0 to 4095)	1	2	4	8	16	32	64	128	256	512	1024	2048

(c) Station No. read-out selection ( $\overline{PS0}$ ,  $\overline{PS1}$ )


Current station No. value is read-out by current data (station No.) output signal ( $\overline{P0}$  to  $\overline{P4}$ )  $\overline{P0}$  to  $\overline{P4}$  have only 5 bits. Therefore, by selecting  $\overline{PS0}$  and  $\overline{PS1}$ , data must be read-out successively.

Output signals ( $\overline{P0}$  to  $\overline{P4}$ ) change the codes as shown in the table below by combining  $\overline{PS0}$  or  $\overline{PS1}$  H and L.


Input Signal \ Output Signal		$\overline{PS0}$	H	L	H	L
		$\overline{PS1}$	H	H	L	L
BCD setting parameter 14 b4 = 1	$\overline{P0}$	1	1	10	100	
	$\overline{P1}$	2	2	20	200	
	$\overline{P2}$	4	4	40	400	
	$\overline{P3}$	8	8	80	800	
	$\overline{P4}$	10	Odd parity	Odd parity	Odd parity	
Binary parameter 14 b4 = 0	$\overline{P0}$	1	1	16	256	
	$\overline{P1}$	2	2	32	512	
	$\overline{P2}$	4	4	64	1024	
	$\overline{P3}$	8	8	128	2048	
	$\overline{P4}$	16	Odd parity	Odd parity	Odd parity	

Notes:

- In a case other than  $\overline{PS0} = \overline{PS1} = H$ ,  $\overline{P4}$  becomes parity bit.  
 For example, in BCD setting, when  $\overline{PS0} = L$  and  $\overline{PS1} = H$ , and  $(\overline{P0}$  to  $\overline{P3})$  is 7, data are output as  $\overline{P4} = H$  so that the figure below becomes an odd number (3) completely at low level with  $\overline{P0} = L$ ,  $\overline{P1} = L$ ,  $\overline{P2} = L$  and  $\overline{P3} = H$ .




- Timing with which current value data (station No.) is read-out several times must be as follows.



## 6.3 OPERATION AND FUNCTIONS OF 2CN/5CN OUTPUT SIGNAL

### 6.3.1 Output Circuit (Refer to Figs. 5.7, 5.14 and 5.15.)




- Applied voltage:  $V_o \leq 30V$
- Applied current:  $I_p \leq 50mA$
- Flywheel diode: Use diode having repetitive peak reverse voltage 5 times more than the voltage.

### 6.3.2 Signal Operation and Functions

#### (1) Alarm [ALM]

- When fault detection function (see Table 4.1) operates, the power drive circuit in the Servopack is turned off and alarm signal is output. Then the alarm contents are displayed to a 7-segment LED.
- Alarm signal timing






(2) Brake release signal  $\overline{BK}$

Brake release signal  $\overline{BK}$  is an output signal to interlock the timing between current conduction or motor speed and brake release.

By setting parameter 19,b2 = 1, the brake release signal becomes effective. In this case, interlocking constant set by parameter 43 or 44 becomes effective.



### 6.3.2 Signal Operation and Functions (Cont'd)

#### (3) Reference Error $\overline{\text{ERR}}$

Output when reference data by contact signal is incorrect or operation is abnormal under motor current conduction. At this time, the motor cannot be driven.


Error Contents			$\overline{\text{ERR}}$ Output Timing	
Reference Error	At station No. Reference	Commands A to F at BCD setting	<p><math>\overline{\text{ERR}}</math> is released by correcting reference or switching operation mode once.</p>	
		Commands station 0 at setting "station No. 0 not provided" in absolute reference mode.		
	At DG-SW reference	Commands position data exceeding software over-travel set value.		
		Commands data exceeding speed limit value.		
Operation Error, etc.	At station No. Reference	Operation mode improper setting (refer to Par. 6.2.3 (1).)	<p><math>\overline{\text{ERR}}</math> signal is output in the conditions as described on the left. Recovery from error immediately releases <math>\overline{\text{ERR}}</math>.</p>	<p><math>\overline{\text{ERR}}</math> is not output at baseblock.</p> <p>At baseblock, <math>\overline{\text{ERR}}</math> is output only when:</p> <ul style="list-style-type: none"> <li>• out of software overtravel range</li> <li>• external over-travel is detected</li> </ul>
		At DG-SW Reference		
	$\overline{\text{LPG}}$ signal is turned on in pulse operation mode.			
	Software over-travel is applied during operation in pulse or manual operation mode.			
	External over-travel (P-OT, N-OT) is applied.			

(4) Alarm code ( $\overline{AL0}$  to  $\overline{AL3}$ )

- When an alarm occurs (ALM signal = H) or an error occurs ( $\overline{ERR}$  signal = L), the contents are output in 4-bit code.


For details of alarm or error contents and corresponding alarm code signals, refer to (9) "Servopack status output signal".

- Output timing



(5) Operation mode display ( $\overline{AUT-LT}$ ,  $\overline{MAN-LT}$ )

Output conditions of each signal are as follows:



(6) Battery voltage low-level detection [ $\overline{BATALM}$ ]

If Servopack built-in battery (nominal voltage 3.6V) voltage becomes less than 3.3V (detected range 3.0 to 3.3V), it is detected when the control power supply is turned on and  $\overline{BATALM}$  signal is output. At this time, a 7-SEG LED blinks  $\square d$ .

(7) Positioning complete, positioning near ( $\overline{COIN}$  ( $\overline{NEAR}$ ))

$\overline{COIN}$  ( $\overline{NEAR}$ ) signal is output with the conditions according to positioning complete (near) width set by parameter and operation mode.


Output Signal	Parameter (Refer to Par. 8.2.)			
	Name	Parameter No.	Setting Range	Unit
$\overline{COIN}$	Positioning complete width	6	1 to 250	Reference unit
$\overline{NEAR}$	Positioning near width	45	0 to 3000	

$\overline{COIN}$  ( $\overline{NEAR}$ ) signal is always output during baseblock.


### 6.3.2 Signal Operation and Functions (Cont'd)

(a) Output specifications in automatic operation mode


① At mode switching and relation with  $\overline{\text{AST}}$  signal




②  $\overline{\text{COIN}}$  signal becomes as shown below if an error occurs when  $\overline{\text{AST}}$  signal is turned on.





③ Conditions where  $\overline{\text{COIN}}$  ( $\overline{\text{NEAR}}$ ) signal is output during automatic operation



④ When  $\overline{\text{AST}}$  signal is turned on during automatic operation




⑤  $\overline{\text{COIN}}$  signal is not output in feed hold status.



(b) Output specifications in manual operation mode

In manual operation mode,  $\overline{\text{COIN}}$  is output during stop. When operation signal ( $\overline{\text{MCW}}$ ,  $\overline{\text{MCCW}}$ ) is turned on,  $\overline{\text{COIN}}$  becomes high.



(8) Station No. Output ( $\overline{\text{P0}}$  to  $\overline{\text{P4}}$ )

(a) Station No. reference method (parameter 15 set value = 0)

- Positioning station No. is indicated in BCD or binary code(5 bits).

(BCD/binary setting depends on parameter 14 b4.)

- By combining H and L levels of read-out input signal ( $\overline{\text{PS0}}$ ,  $\overline{\text{PS1}}$ ), the code contents of  $\overline{\text{P0}}$  to  $\overline{\text{P4}}$  changes. Refer to Par. 6.2.3 (6) (c).

(b) Command table method (parameter 15 set value = 4)

- By setting parameter 20 b5 = 1 and parameter 65 b0 = 1,  $\overline{\text{P0}}$  to  $\overline{\text{P4}}$  become zone signals.

### 6.3.2 Signal Operation and Functions (Cont'd)

#### (9) Servopack status output signals

Servopack Status				Status Output Signal							
7SEG. LED	Contents			ALM	$\overline{\text{ERR}}$	Alarm Code					
						$\overline{\text{AL3}}$	$\overline{\text{AL2}}$	$\overline{\text{AL1}}$	$\overline{\text{AL0}}$		
Status	.	Motor current Conduction	Ref. Operation	Normal	0	1	1	1	1	1	
				Mode Error	0	0	0	1	0	1	
				Position Error	0	0	0	1	0	0	
				Speed Error	0	0	0	0	1	1	
	-	Base-blocking			0	1	1	1	1	1	
	P	P-Side Overtravel			0	0	1	1	0	1	
		P-Side Software Overtravel			0	0	1	0	1	1	
	N	N-Side overtravel			0	0	1	1	0	0	
		N-Side Software Overtravel			0	0	1	0	1	0	
	d	Battery Voltage Low			-	-	-	-	-	-	
	Alarm	G	Abso Error			1	1	0	1	1	1
		I	Overcurrent			1	1	1	1	1	0
2		MCB Trip			1	1	1	1	0	1	
3		Regenerative Error			1	1	1	1	0	0	
4		Overvoltage			1	1	1	0	1	1	
5		Overspeed			1	1	1	0	1	0	
6		Main Circuit Power Supply Error			1	1	1	0	0	1	
7		Overload			1	1	1	0	0	0	
8		Position Error			1	1	0	1	1	1	
8		Heat Sink Overheat			1	1	0	1	0	1	
9		PG Disconnection			1	1	0	0	1	1	
F		Open Phase			1	1	0	0	0	0	
H		Hardware Error			1	1	1	1	1	1	
J		Overflow			1	1	1	1	0	0	
L		Overrun			1	1	0	0	1	1	
Y		Parameter Error			1	1	0	0	0	1	
	CPU Error			1	1	1	1	1	1		

Notes:


1. At battery voltage low-level detection, LED indicator d blinks.
2. At CPU error, LED indicator is uncertain.
3. Status output signal  
0: Relay ON, 1: Relay OFF, -: Not defined

# 7 SERIAL COMMUNICATION

## 7.1 SPECIFICATIONS

Items	Specifications
Standard in complying with	RS422
Communication method	Asynchronous (ASYNC)
Baud rate	9600, 4800, 2400, 1200, Baud, selected at initial setting (9600 Baud prior to shipping)
Start bit	1 bit
Data	7-bit ASCII code (JIS X 0201, former C6220)
Parity	1 bit even
Stop bit	1 bit
Start/stop	XON/XOFF control

1-CHARACTER CONFIGURATION



## 7.2 CONTROL CONFIGURATION

	1-axis Control	Multi-axis Control
Outline	<p>HOST CONTROLLER</p> <p>4CN</p> <p>SERVOPACK</p> <p>MOTOR (M)</p>	<p>HOST CONTROLLER</p> <p>4CN</p> <p>#1 SERVOPACK</p> <p>MOTOR (M)</p> <p>#2 SERVOPACK</p> <p>MOTOR (M)</p> <p>(UP TO 16 AXES AVAILABLE.)</p>
Initial Setting	<ul style="list-style-type: none"> <li>Baud rate (not required for 9600 Baud)</li> </ul>	<ul style="list-style-type: none"> <li>Address (For how to use axis address, refer to Par. 7.3.2.)</li> <li>Baud rate</li> </ul>

Note: For initial setting method, refer to Par. 11.2.1 (1).

## 7.3 COMMAND TRANSMISSION (MASTER CONTROLLER → SERVOPACK)

### 7.3.1 Transmission Method

	One-axis Control	Multi-axis Control
Command	<div style="border: 1px solid black; padding: 2px; display: inline-block;">COMMAND CHAR- ACTER LINE</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 20px;">CR</div>	<ul style="list-style-type: none"> <li>• When axis is specified:  <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 10px;">AXIS NO.</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 10px;">COMMAND CHAR- ACTER LINE</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">CR</div> </li> <li>• When all axes are specified:  <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 10px;">COMMAND CHAR- ACTER LINE</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">CR</div> </li> </ul> <p>(Command becomes effective for all axes.)</p>
Example	<ul style="list-style-type: none"> <li>• SVON <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• SPD12345 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• MOV1234 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• ST <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> </ul>	<ul style="list-style-type: none"> <li>• 1SVON <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• 2SVON <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• 1SPD123 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• 2SPD456 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• 1MOV123 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• 2MOV456 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> <li>• ST <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 5px;">CR</div></li> </ul>



### 7.3.2 How to Use Axis Address

#### (1) How to set axis address and axis designation

Control Configuration	Axis Address Setting		Axis Designation Method				
	10-digit	1-digit	Not designated	Axis No. = m	Axis No. = 0m	Axis No. = n0	Axis No. = nm
One-axis control	Not required	0	Possible	Not used	Not used	Not used	Not used
Multi-axis control; 2 to 9 axes group designation not provided	Not required	M	Possible	Possible	Not used	Not used	Not used
Multi-axis control; 2 to 9 axes group designation provided	N	M	Possible	Prohibited	Possible	Possible	Possible
Multi-axis control; 10 to 16 axes	N	M	Possible	Prohibited	Possible	Possible	Possible

Note: M, N, m or n is a number from 1 to 9.

#### (2) Axis designation function (M, N, m or n is a number from 1 to 9.)

##### (a) One-axis control

Axis Designation	Axis with Effective Command	Use of Command to Require Response	Response for Command (ERR [ ] , OK*)
Not provided	—	Possible	Provided

\* Response OK to command is given only when parameter 72 b4=1 is set.

##### (b) Multi-axis (2 to 9 axes) control without group designation

Axis Designation	Axis with Effective Command	Use of Command to Require Response	Response for Command (ERR [ ] , OK*)
Not provided	All axes	Not possible	Not Provided
Axis No. = m	Axis with axis address m	Possible	Provided

\* Response OK to command is given only when parameter 72 b4=1 is set.

(c) Multi-axis (2 to 9 axes) control with group designation and multi-axis control for 10 axes or more (up to 16 axes)

Axis Designation	Axis with Effective Command	Use of Command to Require Response	Response for Command (ERR [ ] , OK*)
Not provided	All axes	Not possible	Not provided
Axis No. = 0m	Axes with M = m (group)	Not possible	Not provided
Axis No. = n0	Axes with N = n (group)	Not possible	Not provided
Axis No. = nm	Axes with N = n and M = m (group)	Possible	provided

\* Response OK to command is given only when parameter 72 b4 = 1 is set.

(3) Precautions on multi-axis control

If no axis is designated on serial command, a command is effective for all axes. Do not forget to designate axis number when one axis operation is required. (Pay attention especially to RES or ST command.)

## 7.4 TRANSMISSION DATA (SERVOPACK → HOST CONTROLLER)

(1) Data

DATA CHARACTER LINE CR LF

(2) Example

• ALM     . RUN     CR LF


Monitor data

• PUN = +1 2 3 4 5 6 7 8 CR

• COIN CR LF

.....Automatic transmission data  
(One-axis control only)

## 7.5 SERIAL COMMUNICATION AND TYPICAL SERVOPACK RESPONSE



## 7.6 SERIAL COMMUNICATION CONTROL CODE

Control Code	Contents
DC3(Ctrl-S, 13H)	Stops transmission. (X-OFF)
DC1(Ctrl-Q, 11H)	Restart transmission. (X-ON)
ETX(Ctrl-C, 03H)	Monitor data transmission from Servopack is canceled. (For restart, send monitor command to Servopack again.)
ENQ(Ctrl-E, 05H)	Switches echo-back "provided/not provided" from Servopack for command. (At initialization, echo-back is set to "not provided.")

Example

◎ (INITIAL)  
 ① (COMMAND) MON1  
 ② (MONITOR DATA) PUN = +123  
 ③ Ctrl-E  
 ④ (COMMAND) MON3  
 ⑤ (ECHO BACK) MON3  
 ⑥ (MONITOR DATA) NFB = 0  
 ⑦ Ctrl-E  
 ⑧ (COMMAND) MON4  
 ⑨ (MONITOR DATA) NREF = 0

Note: Echo-back functions only for one-axis control.  
Echo-back is not provided for multi-axis control.

## 7.7 AUTOMATIC TRANSMISSION DATA FROM SERVOPACK

- Monitor data are sent automatically from Servopack only in one-axis control. (Transmission is completed at one time.)

Transmission Conditions		Data Display
At Positioning Completion		COIN
At Positioning Near		NEAR
At Alarm Occurrence		ALM <u>n.</u> <u>nnnnn</u> ↑        ↑ Alarm    Alarm code     abbreviation
At Parity Error		ERR PE
At Command Error	Command Error (Undefined command is sent.)	ERR SN
	No. (p.pp) Error (ALMp, MONp, PRMpp, etc.)	ERR PN
	Data (n.....n) Error (Exceeding specified digits)	ERR OV

- In multi-axis control, ERR SN(PN, OV) data are automatically sent only when axis designation command (1MON1, 2MON1, etc.) error occurs. (Automatic transmission is not performed.)

• Communication Error Cause

× : No error occurs      ○ : Only ERR OV occurs at excessive number of digits.

	Command	ERR PN	ERR OV	ERR SN
Operation	SVON	×	×	$\overline{\text{RST}}$ ON, OL status
	SVOFF	×	×	
	ARES	×	×	
	ZEROSSET (±) nnnnnnnn	×	○	
	RES	×	×	
Move command	POS (±) nnnnnnnn	×	Software overtravel exceeded	*
	POSI (±) nnnnnnnn	×	Software overtravel exceeded	*
	JOG (±) nnnnnn	×	speed limit exceeded	*
	MOV (±) nnnnnnnn	×	○	
	MOVI (±) nnnnnnnn	×	○	
	SPD nnnnnn	×	speed limit exceeded	
	ST	×	×	*
	JOGP	×	speed limit exceeded	*
	JOGN	×	speed limit exceeded	*
	ZRN	×	speed limit exceeded	*
	PCON	×	×	
	PCOFF	×	×	
	SKIP	×	×	
	HOLD	×	×	
	PON	×	×	Motor not under current conduction
	POFF	×	×	Not in pulse mode
SET (±) nnnnnnnn	×	○		
Parameter	PRM	×	×	
	PRMpp	Other than 0 to 99	×	
	PRMpp= (±) nnnnnnnn	Other than 0 to 99	Exceeding number of bytes determined per parameter No.	
Monitor	MU=n	×	Other than 1 or 2	
	MONp	Other than 1 to 6	×	
	INp	Other than 1 to 8	×	
	OUTp	Other than 1 to 3	×	
	ALM (p)	Other than 0 to 9	×	

\* Refer to the next page.

Cause of ERR SN marked with \*

Cause Move Command	Motor is not under current conduction	Currently moving	Command exceeds software overtravel	OT condition in the commanded direction	STOP signal is turned OFF (STOP is OFF.)	Speed limit is exceeded.
POS	○	○	×	○	×	○
POSI	○	○	×	○	×	○
JOG	○	○	○	○	×	×
ST	○	○	○	○	○	○
JOGP	○	○	○	○	×	×
JOGN	○	○	○	○	×	×
ZRN *	○	○	○	○	○	×

○ : An error occurs.

× : An error does not occur.

\* ERR SN is displayed when ZRN is commanded and STP signal is OFF in the zero-point return (homing) mode II (PRM49=1).

## 7.8 SERIAL COMMAND

### 7.8.1 Serial Command List

	Command	Contents	
Operation	SVON	Performs current conduction to motor.	
	SVOFF	Stops current conduction to motor.	
	ARES	Resets alarm.	
	ZEROSSET ( $\pm$ ) nnnnnnnn	Re-writes machine zero-point so that current position will be ( $\pm$ ) nnnnnnnn.	
	RES	Performs the same operation as control power supply OFF/ON.	
Moving Command	POS ( $\pm$ ) nnnnnnnn	Performs positioning at linear accel/decel speed in ( $\pm$ ) nnnnnnnn. (Absolute value)	
	POSI ( $\pm$ ) nnnnnnnn	Performs positioning at linear accel/decel speed in ( $\pm$ ) nnnnnnnn. (Incremental value)	
	JOG ( $\pm$ ) nnnnnn	Performs constant speed operation at ( $\pm$ ) nnnnnnn speed.	
	MOV ( $\pm$ ) nnnnnnnn	Sets position reference. (Absolute value)	
	MOVI ( $\pm$ ) nnnnnnnn	Sets position reference. (Incremental value)	
	SPD nnnnnn	Sets speed reference.	
	ST	Starts automatic operation.	
	JOGP	Starts manual operation: plus direction	
	JOGN	Starts manual operation: minus direction	
	ZRN	Starts zero-point return (homing).	
	PCON	Performs P (proportional) operation in speed loop.	
	PCOFF	Releases P operation of speed loop.	
	SKIP	Decelerates and stops.	
	HOLD	Feed hold (remaining amount is held.)	
	PON	Enters pulse operation mode.	
	POFF	Clears pulse operation mode.	
	SET ( $\pm$ ) nnnnnnnn	Re-writes current position to ( $\pm$ ) nnnnnnnn.	
	Parameter	PRM	Sends all parameters. (Unused parameters are not sent.)
		PRMpp	Sends parameters with pp (parameter number).
PRMpp= ( $\pm$ ) nnnnnnnn		Re-writes parameters with pp (parameter number) to ( $\pm$ ) nnnnnnnn.	
Monitor	MU=n	Selects monitor signal. n=1: torque reference, n=2: speed reference	
	MONp	Sends monitor data.	
	INp	Sends input signal status.	
	OUTp	Sends output signal status.	
	ALM (p)	Sends alarm code. p not provided: current alarm, p = 1 to 9: alarm which occurred p times before	
Command Table Setup	PT/VT/BT	Sends all command table positions/speeds/boundary positions.	
	PTpp/VTpp/BTpp	Sends position/speed/boundary position number pp.	
	PTpp=(+)nnnnnnnn VTpp=(+)nnnnnnnn BTpp=(+)nnnnnnnn	Re-writes position/speed/boundary position number pp.	

## 7.8.2 Command Functions

### (1) Parameter operation commands

Monitor or re-write parameter contents.

(Since parameters are stored in E<sup>2</sup>PROM, the contents are not erased even if the control power supply is turned off.)

For details, refer to Par. 8.1 "PARAMETER LIST".

Command	Function/Contents
PRM	<p>All parameters are sent from Servopack by this command. (For parameter 21 and beyond, unused parameters are not sent.) Used for parameter contents check.</p> <p>(Example)</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>COMMAND</p> <div style="border: 1px solid black; padding: 2px 5px; display: inline-block;">PRM</div> </div> <div style="margin-right: 20px;">→</div> <div style="border-left: 1px solid black; border-right: 1px solid black; padding: 5px;"> <p>PRM1 = × × ..... ×</p> <p>PRM2 = × × ..... ×</p> <p>.....</p> <p>PRM49 = × × ..... ×</p> <p>.....</p> </div> <div style="margin-left: 20px;"> <p>(Sent from Servopack.)</p> </div> </div>
PRMpp (pp: parameter number)	<p>Contents of parameters with pp are sent from Servopack. Used for specified parameter contents check.</p> <p>(Example)</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>COMMAND</p> <div style="border: 1px solid black; padding: 2px 5px; display: inline-block;">PRM30</div> </div> <div style="margin-right: 20px;">→</div> <div style="margin-left: 20px;"> <p>PRM30 = × × ..... ×</p> <p>(Sent from Servopack.)</p> </div> </div>
<p>PRMpp = ± n...n</p> <p style="margin-left: 40px;">} within 8 digits</p> <p style="margin-left: 40px;">pp: parameter number,</p> <p style="margin-left: 40px;">n: 0 to 9</p>	<p>Re-writes parameter with parameter No. pp to (±n.....n). You can omit the +.</p> <p>For off-line parameters (refer to the note below), execute command <span style="border: 1px solid black; padding: 2px 5px;">RES</span> after this command.</p> <p>Unless <span style="border: 1px solid black; padding: 2px 5px;">RES</span> command is executed, the parameter contents will not be re-written.</p> <p>(Example)</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>COMMAND</p> </div> <div style="border-left: 1px solid black; padding-left: 5px;"> <ul style="list-style-type: none"> <li>• <span style="border: 1px solid black; padding: 2px 5px; display: inline-block;">PRM10 = 123</span></li> <li>• <span style="border: 1px solid black; padding: 2px 5px; display: inline-block;">PRM12 = -456</span></li> <li>• <span style="border: 1px solid black; padding: 2px 5px; display: inline-block;">PRM20 = 789</span></li> <li>• <span style="border: 1px solid black; padding: 2px 5px; display: inline-block;">RES</span></li> </ul> </div> <div style="margin-left: 20px;"> <p>← For off-line parameters, execute <span style="border: 1px solid black; padding: 2px 5px;">RES</span> command without fail.</p> </div> </div>

(Cont'd)



(Cont'd)

Command	Function/Contents
TRMpp = ± n...n within 8 digits (pp: Parameter No.) n: 0 to 9	For applications where the online parameter (refer to the note below) is re-written frequently during operation, use this command instead of <span style="border: 1px solid black; padding: 2px;">PRMpp = ± n.....n</span> Functions are the same. (Number of write-in times is limited on E <sup>2</sup> PROM physical characteristic). Contents set by this command are returned to the contents set by <span style="border: 1px solid black; padding: 2px;">PRMpp = ± n.....n</span> command at the beginning by turning on/off the control power supply or executing <span style="border: 1px solid black; padding: 2px;">RES</span> command.

Note: Examples of Parameter Contents Renewal Command

Online Parameter* <sup>1</sup>	Offline Parameter* <sup>2</sup>	
PRM1 = 50 PRM2 = 100 PRM5 = 30	PRM17 = 11111 PRM18 = 10100 PRM19 = 11111 RES	*1 Online parameter: Parameter is renewed only by parameter write-in command. *2 Offline parameter: Parameter is renewed after <span style="border: 1px solid black; padding: 2px;">RES</span> command is sent after command.

(2) Basic operation command

Command	Function/Contents
RES	Provides initial reset ; the same conditions as when control power supply is switched from OFF to ON, or to the Servopack control section. <span style="border: 1px solid black; padding: 2px;">ZEROSSET ± n...n</span> command cannot be effective unless <span style="border: 1px solid black; padding: 2px;">RES</span> command is executed successively.
ARES	When Servopack detects an alarm, the alarm is reset by this command. The same operation as alarm reset signal RST.
ZEROSSET ± n...n 8 digits (+ can be omitted.)	[ ± n.....n ] is a position with reference of machine zero point (home position). (Unit: reference unit) • <span style="border: 1px solid black; padding: 2px;">ZEROSSET ± n.....n</span> • <span style="border: 1px solid black; padding: 2px;">RES</span> By execution of the above commands, current position is set to [ ± n...n ]. Note: Current position is a value indicated by monitor data <PUN = ± × × ..... × > (refer to (4) "Monitor Command").
SVON SVOFF	Servopack main circuit power drive circuit operates by <span style="border: 1px solid black; padding: 2px;">SVON</span> command and the motor becomes in current conduction. The current conduction to motor is released by <span style="border: 1px solid black; padding: 2px;">SVOFF</span> command. (These two commands perform the same operation as SERVO ON signal <span style="border: 1px solid black; padding: 2px;">SVON</span> . <div style="text-align: center; margin: 10px 0;"> <span style="border: 1px solid black; padding: 2px;">SVON</span>                      <span style="border: 1px solid black; padding: 2px;">SVOFF</span>  ▼    ▼  MOTOR STATUS    NON CURRENT CONDUCTION    CURRENT CONDUCTION    NON CURRENT CONDUCTION </div>

7



## 7.8.2 Command Functions (Cont'd)

### (3) Move command

Command	Function/Contents										
SPD $n\cdots n$ Max. 6-digit	Setting command for speed reference. ( $nn\cdots nn$ ) unit is [ $\times 1000$ reference unit/min]. Speed reference value is the set value of parameter 4 when the power supply is turned ON or <b>RES</b> command is executed. <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;">Example</p> <p>Reference unit = 0.01mm: When 15m/min;  <math>\frac{15000\text{mm} / \text{min}}{0.01\text{mm}} = 1500000</math> reference units/min.  <math>= 1500</math> [<math>\times 1000</math> reference units/min]  <math>\therefore</math> <b>SPD 1500</b></p> </div>										
MOV $\pm n\cdots n$ Max. 8-digit (+ can be omitted)	Setting command for position reference. ( $\pm n\cdots nn$ ) unit is [reference unit]. (+ $n\cdots nn$ ) : Motor FWD run, (- $n\cdots nn$ ) : Motor REV run Position reference value becomes 0 when the power supply is turned ON and <b>RES</b> command is executed. Operation differs depending on parameter 14 b3 [position reference mode] setting. <table border="1" style="margin: 10px auto; width: 60%;"> <thead> <tr> <th colspan="2">Parameter</th> <th rowspan="2">Position Reference Mode</th> </tr> <tr> <th>No.</th> <th>Set Value</th> </tr> </thead> <tbody> <tr> <td rowspan="2">14 b3</td> <td>0</td> <td>Absolute value</td> </tr> <tr> <td>1</td> <td>Incremental value</td> </tr> </tbody> </table> <div style="display: flex; justify-content: space-around;"> <div style="width: 45%;"> <p style="text-align: center;">Absolute Mode</p> <p style="text-align: center;">(Data are in absolute value.)</p> </div> <div style="width: 45%;"> <p style="text-align: center;">Incremental Mode</p> <p style="text-align: center;">(Data are in incremental value.)</p> </div> </div>	Parameter		Position Reference Mode	No.	Set Value	14 b3	0	Absolute value	1	Incremental value
Parameter		Position Reference Mode									
No.	Set Value										
14 b3	0	Absolute value									
	1	Incremental value									

(Cont'd)



(Cont'd)

Command	Function/Contents																								
<p>MOVI ± n.....n            Max. 8-digit            (+ can be omitted)</p>	<p>Position reference setting command which is effective when position reference mode is absolute mode (14 b3 = 0). Data are in <u>incremental value</u>.</p>  <p>Note: Do not use this command for incremental mode (parameter 14 b3 = 1). Does not operate normally.</p>																								
<p>ST</p>	<p>Command to start automatic operation after speed or position data setting command. ST command is disregarded during positioning.</p> <p>(Example)</p> <ol style="list-style-type: none"> <li>① <table border="0" style="display: inline-table; vertical-align: middle;"> <tr><td style="border: 1px solid black; padding: 2px;">SPD</td><td style="padding: 2px;">n...n</td><td style="padding: 2px;">.....</td><td style="padding: 2px;">Speed data setting</td></tr> <tr><td style="border: 1px solid black; padding: 2px;">MOV ±</td><td style="padding: 2px;">n...n</td><td style="padding: 2px;">.....</td><td style="padding: 2px;">Position data setting</td></tr> <tr><td style="border: 1px solid black; padding: 2px;">ST</td><td colspan="3"></td></tr> </table> </li> <li>② <table border="0" style="display: inline-table; vertical-align: middle;"> <tr><td style="border: 1px solid black; padding: 2px;">MOV ±</td><td style="padding: 2px;">n...n</td><td style="padding: 2px;">.....</td><td rowspan="2" style="padding: 2px;">Operates at speed which was set before.</td></tr> <tr><td style="border: 1px solid black; padding: 2px;">ST</td><td colspan="2"></td></tr> </table> </li> <li>③ <table border="0" style="display: inline-table; vertical-align: middle;"> <tr><td style="border: 1px solid black; padding: 2px;">RES</td><td colspan="3" rowspan="2" style="padding: 2px;">In this case, returns to zero point (home position) at speed set in parameter 4.</td></tr> <tr><td style="border: 1px solid black; padding: 2px;">ST</td></tr> </table> </li> </ol> <p>Notes:</p> <ol style="list-style-type: none"> <li>1. When <span style="border: 1px solid black; padding: 2px;">ST</span> command is sent for special axis operation check after parameter change for special axis in case of multi-axis configuration, <u>be sure to designate the axis.</u>              If <span style="border: 1px solid black; padding: 2px;">ST</span> command is sent without axis designation after <span style="border: 1px solid black; padding: 2px;">RES</span> command is sent to all axes or the control power supply is turned OFF and then ON, all axes will operate as described in (Example) ③.</li> <li>2. If STOP signal input (2CN-15) remains open, <span style="border: 1px solid black; padding: 2px;">ERR SN</span> (command error) occurs even if <span style="border: 1px solid black; padding: 2px;">ST</span> command is sent at move command execution. When STOP signal is not used, set parameter 19 b1=1.</li> </ol>	SPD	n...n	.....	Speed data setting	MOV ±	n...n	.....	Position data setting	ST				MOV ±	n...n	.....	Operates at speed which was set before.	ST			RES	In this case, returns to zero point (home position) at speed set in parameter 4.			ST
SPD	n...n	.....	Speed data setting																						
MOV ±	n...n	.....	Position data setting																						
ST																									
MOV ±	n...n	.....	Operates at speed which was set before.																						
ST																									
RES	In this case, returns to zero point (home position) at speed set in parameter 4.																								
ST																									
<p>JOGP            JOGN</p>	<p>Manual jog operation start command. The speed is set by command  <span style="border: 1px solid black; padding: 2px;">SPD</span> : <span style="border: 1px solid black; padding: 2px;">JOGP</span> : Motor FWD run, <span style="border: 1px solid black; padding: 2px;">JOGN</span> : Motor REV run.  <span style="border: 1px solid black; padding: 2px;">SKIP</span> command is used for stop.</p> 																								

7

(Cont'd)

(3) Move command (Cont'd)

Command	Function/Contents
SKIP	<p>Command to stop operation after deceleration set by a parameter.</p> <p>(Example 1)</p>  <p>(Example 2)</p> <p>When <b>SKIP</b> command is input during positioning by <b>MOV</b> command in absolute mode, the remaining positioning is executed only by <b>ST</b> command after stopping.</p>  <p>POSITION</p>



(Cont'd)

(Cont'd)

Command	Function/Contents
---------	-------------------

ZRN

Command to start zero-point return (homing) operation as shown below:

	Zero-point Return Method	Operation Pattern
<p>Mode I (Parameter 49 = 0)</p>	<p>3-step deceleration method using DEC signal (decel LS), C<math>\phi</math> pulse signal (in Servopack)</p>	<p>(PARAMETER 50 = 0)</p> 
<p>Mode II (Parameter 49 = 1)</p>	<p>2-step deceleration method using STP signal (decel LS)</p>	<p>(PARAMETER 50 = 0)</p> 




Note 1: Related parameters

Parameters shown below are effective when parameter 18 b4 = 1.  
Does not operate when b4 = 0.

Parameter No.	Name	Unit	
50	Zero-point return direction	0: FWD direction 1: REV direction	
51	Zero-point return feeding speed	0 to 240000	×1000 reference unit/min
52	Zero-point return approach speed	0 to 240000	
53	Zero-point return creep speed	0 to 240000	
54	Zero-point return final traveling distance	FWD: 0 to +99999999 REV: 0 to -99999999	Reference unit



(Cont'd)

(3) Move command (Cont'd)

Command	Function/Contents
<p>HOLD</p>	<p>(1) When this command is sent during positioning by <b>ST</b> command, operation stops at a specified deceleration speed. However, the remaining amount is held. (Feed hold function)</p>  <p>(2) When <b>HOLD</b> command is sent during manual operation (<b>JOGP</b>, <b>JOGN</b>, <b>JOG ±n.....n</b> command) or during operation by <b>POS</b>, <b>POSI</b> command, the same operation is performed as <b>SKIP</b> command.</p>
<p>POS (±) n.....n Max. 8-digit</p> <p>POSI (±) n.....n Max. 8-digit</p>	<p>Command to perform positioning by linear accel/decel. Data (±) n.....n moves to position [ (±) n.....n ] in absolute value for POS; moves by distance [ (±) n.....n ] in incremental value for POSI. [Speed is a set value of parameter (4). ]</p> <p>(Example) SPEED • POS1000 • POSI500</p> 
<p>JOG (±) n.....n Max. 6-digit</p>	<p>Command to perform manual jog operation at speed [ (±) n.....n ]</p> 

(Cont'd)

(Cont'd)

Command	Function/Contents
PON POFF	<p>Command to turn on/off pulse operation mode (positioning operation by external pulse train command). [PON] enters pulse operation mode and [POFF] releases it.</p> 
PCON PCOFF	<p>Command to change Servopack speed loop control mode from PI (proportion - integer) operation to P (proportion) operation. [PCON] enters P operation and [PCOFF] returns to PI operation.</p>
SET (±) n...n Max. 8-digit	<p>Command to re-write the current position to [ (±) n...n ]. After execution of this command, a new coordinate becomes effective.</p> <p>(Example)</p>  <p>Note: Coordinate which has been changed by [SET] command is returned to the former by [RES] command or turning on/off the control power supply.</p>

(Cont'd)

(3) Move command (Cont'd)

Command	Function/Contents
PT	<p>All position tables are sent from the Servopack by this command. (Example)</p> <p>Command <math>\rightarrow</math> <math>\left\{ \begin{array}{l} \text{PT01} = \pm n \dots n \\ \text{PT02} = \pm n \dots n \\ \dots \dots \dots \\ \text{PT64} = \pm n \dots n \end{array} \right.</math></p> <p>(Sent from Servopack)</p>
PTpp (pp: Position No. pp=1 to 64)	<p>Position No. pp reference position is sent from the Servopack. (Example)</p> <p>Command <math>\boxed{\text{PT25}}</math> <math>\rightarrow</math> PT25 = +00050000</p> <p>(Sent from Servopack)</p>
<p>PTpp = <math>\pm n \dots n</math> (Max. 8 digits)</p> <p><math>\left\{ \begin{array}{l} \text{pp} : \text{Position No.} \\ \pm n \dots : \text{Reference position} \end{array} \right.</math></p> <p>pp = 1 to 64</p>	<p>A command to change position No. pp reference position to (<math>\pm n \dots n</math>). + can be omitted. Becomes effective by execution of <math>\boxed{\text{RES}}</math> command or ON/OFF of control power supply. (Example) <math>\bullet</math> <math>\boxed{\text{PT25}=50050}</math></p> <p>Command <math>\bullet</math> <math>\boxed{\text{RES}}</math></p> <p><math>\bullet</math> Reference position (<math>\pm n \dots n</math>) unit is [reference unit]. Note: Data cannot be changed frequently because of characteristics of E<sup>2</sup>PROM.</p>
VT	<p>All speed tables are sent from Servopack by this command. (Example)</p> <p>Command <math>\rightarrow</math> <math>\left\{ \begin{array}{l} \text{VT01} = n \dots n \\ \text{VT02} = n \dots n \\ \dots \dots \dots \\ \text{VT64} = n \dots n \end{array} \right.</math></p> <p>(Sent from Servopack)</p>
VTpp (pp: Speed No. pp=1 to 64)	<p>Speed No. pp reference speed is sent from the Servopack. (Example)</p> <p>Command <math>\boxed{\text{VT25}}</math> <math>\rightarrow</math> VT25 = 001200</p> <p>(Sent from Servopack)</p>
<p>VTpp = n...n (Max. 6 digits)</p> <p><math>\left\{ \begin{array}{l} \text{pp} : \text{Speed No.} \\ n \dots : \text{Reference speed} \end{array} \right.</math></p> <p>pp = 1 to 64</p>	<p>A command to change speed No. pp reference speed to (n...n). Becomes effective by execution of <math>\boxed{\text{RES}}</math> command or ON/OFF of control power supply. (Example) <math>\bullet</math> <math>\boxed{\text{VT25}=1250}</math></p> <p>Command <math>\bullet</math> <math>\boxed{\text{RES}}</math></p> <p><math>\bullet</math> Reference speed (n...n) unit is [<math>\times 1000</math> reference unit/minute].</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center;"><b>Example</b></p> <p>When reference unit = 0.01mm and at 15m/min:</p> <math display="block">\frac{15000\text{mm/min.}}{0.01\text{mm}} = 1500000 \text{ reference unit/min.}</math> <math display="block">= 1500 [\times 1000 \text{ reference unit/min.}]</math> <p>Therefore, <math>\boxed{\text{VT25} = 1500}</math> is obtained.</p> </div> <p>Note: Data cannot be changed frequently because of characteristics of E<sup>2</sup>PROM.</p>



(Cont'd)

Command	Function/Contents
BT	<p>All boundary tables for zone signals are sent from the Servopack by this command. (Example)</p> <p>Command <span style="border: 1px solid black; padding: 2px;">BT</span> → <math>\left\{ \begin{array}{l} BT01 = \pm n \dots n \\ BT02 = \pm n \dots n \\ \dots \dots \dots \\ BT31 = \pm n \dots n \end{array} \right.</math> (Sent from Servopack)</p>
BTpp (pp: Boundary No. pp=1 to 31)	<p>Boundary No. pp boundary position is sent from the Servopack. (Example)</p> <p>Command <span style="border: 1px solid black; padding: 2px;">BT25</span> → BT25 = +00050000 (Sent from Servopack)</p>
BTpp = $\pm n \dots n$ (Max. 8 digits) pp :Boundary No. $\left. \begin{array}{l} \pm n \dots n : \text{Boundary} \\ \text{position} \end{array} \right\}$ pp = 1 to 31	<p>A command to change boundary No. pp boundary position to (<math>\pm n \dots n</math>). + can be omitted. Becomes effective by execution of <span style="border: 1px solid black; padding: 2px;">RES</span> command or ON/OFF of control power supply. (Example)</p> <ul style="list-style-type: none"><li>• <span style="border: 1px solid black; padding: 2px;">BT25=50050</span></li></ul> <p>Command</p> <ul style="list-style-type: none"><li>• <span style="border: 1px solid black; padding: 2px;">RES</span></li></ul> <ul style="list-style-type: none"><li>• Boundary position unit is [reference unit].</li><li>• For boundary position, write in the data so as to be <math>BT01 \leq BT02 \leq BT03 \leq \dots \leq BT31</math></li></ul> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"><p style="text-align: center;"><span style="border: 1px solid black; padding: 2px;">Example</span></p><p style="text-align: center;">When only BT01 to BT10 are used, set as follows:</p><div style="text-align: center;"><span style="border: 1px solid black; padding: 2px; display: inline-block;">BT11 = + 99999999</span> ⋮ <span style="border: 1px solid black; padding: 2px; display: inline-block;">BT31 = + 99999999</span></div></div> <p>Note: Data cannot be changed frequently because of characteristics of E<sup>2</sup>PROM.</p>

(4) Monitor commands

By executing monitor commands, monitor data are sent continuously and repeatedly from the Servopack\* (excluding ALM and ALMp commands). Data are indicated by **CHARACTER STRING** **CR** without **LF**. By sending some characters to the Servopack, monitor data transmission is stopped after sending **LF**.

\* When parameter 72 b5 = 1 is set, data are sent from the Servopack only one time.

(a) MON commands

Command	Data Sent from Servopack		(Unit) Others
	Name	Display	
MON1	Current Position	PUN = ± $\boxed{n \dots n}$ 8 digits	(Reference unit)
MON2	Position following error	PER = ± $\boxed{n \dots n}$ 8 digits	×4 multiplier of encoder pulse
MON3	Current speed (motor speed)	NFB = ± $\boxed{n \dots n}$ 5 digits	( r/min )
MON4	Reference speed	NREF = ± $\boxed{n \dots n}$ 6 digits	( ×1000) reference unit/min
MON5	Torque reference	TREF = ± $\boxed{n \ n \ n}$ 3 digits	(%)
MON6	Servopack status	STS = $\begin{matrix} n & n & n \\ \swarrow & \uparrow & \searrow \\ (PRDY) & (SLIM) & (TLIM) \end{matrix}$	

	Status	n Value	
PRDY	Main circuit DC power supply	Normal	1
		Low	0
SLIM	Speed limit function	Speed limiting (active)	1
		Inactive	0
TLIM	Current limit function	Current limiting(active)	1
		Inactive	0

(b) Input signal status

Command	Data Sent from Servopack		Remarks	
	Contents	Display		
IN1	Connector 2CN input	$IN_p = n_7 n_6 n_5 n_4 n_3 n_2 n_1 n_0$ (p corresponds to command number.) $n_0$ to $n_7$ is "0" or "1"	Refer to the Note described below:	
IN2	Connector 5CN input			
IN3				
IN4				
IN5				
IN6	Input pulse signal			
IN7	DG-SW setting	Position reference	DS1 = ±nnnnnnnn	Data are in decimal.
IN8		Speed reference	DS2 = ±nnnnnnnn	

Note:  $IN_p = n_7 n_6 n_5 n_4 n_3 n_2 n_1 n_0$

Monitor data indicate input signal status.

- Contact <closed: 0, open: 1>
- Pulse <H level: 1, L level: 0>

The following table shows each data digit and corresponding connector pin number and signal name.

		$n_7$	$n_6$	$n_5$	$n_4$	$n_3$	$n_2$	$n_1$	$n_0$
IN1	2CN PIN NO.	1	15	16	17	18	8	9	10
		STP	STOP	AST	DEC	PCON	SVON	N-OT	P-OT
IN2	5CN PIN NO.	15	14	13	12	11	10	9	8
		RST	DR1	DR0	MCCW	MCW	MAN	ZRN	CUR
IN3		29	28	27	26	25	24	17	16
IN4		44	43	42	41	40	32	31	30
IN5					49	48	47	46	45
					LPG	PULS	SP3RD	SP2ND	
IN6	INPUT PULSE				PG PULSE			REF. PULSE	
					PA	PB	PC	CA	CB

(4) Monitor commands (Cont'd)

(c) Output signal status

Command	Data Sent from Servopack		Remarks
	Contents	Display	
OUT1	Connector 2CN output	OUT1 = n <sub>1</sub> n <sub>0</sub>	Refer to the Note below:
OUT2		OUT2 = n <sub>7</sub> n <sub>6</sub> n <sub>5</sub> n <sub>4</sub> n <sub>3</sub> n <sub>2</sub> n <sub>1</sub> n <sub>0</sub>	
OUT3		OUT3 = n <sub>7</sub> n <sub>6</sub> n <sub>5</sub> n <sub>4</sub> n <sub>3</sub> n <sub>2</sub> n <sub>1</sub> n <sub>0</sub>	

Note:  $OUT_p = n_7 n_6 n_5 n_4 n_3 n_2 n_1 n_0$

Monitor data indicate output signal status.

0 when output relay is ON, 1 when OFF.

The following table shows each data digit and corresponding connector pin number and signal name.

		n <sub>7</sub>	n <sub>6</sub>	n <sub>5</sub>	n <sub>4</sub>	n <sub>3</sub>	n <sub>2</sub>	n <sub>1</sub>	n <sub>0</sub>
OUT1	2CN PIN NO.							12	11
								BK	ALM
OUT2	5CN PIN NO.	21	20	19	7	6	5	4	3
		AL2	AL1	AL0	ERR	POS2	POS1	MAN-LT	AUT-LT
39		38	37	36	35	34	23	22	
OUT3				DS04	DS03	DS02	DS01	DS00	AL3



## (4) Monitor commands (Cont'd)

## (e) Servopack Status and automatic transmission data

Servopack Status				Automatic Transmission Data		Note	
7SEG. LED	Contents			Alarm	Error		
Status	Motor Current Conduc- tion	Ref. Operation	Normal	—	—		
			Command	—	ERR SN		
			No. Error	—	ERR PN		
			Data Error	—	ERR OV	1	
	.	Baseblocking			—	—	
P.	P-Side Overtravel			ALM P. P-OT	—		
	P-Side Software Overtravel			ALM P. P-LS	—	1	
N.	N-Side Overtravel			ALM N. N-OT	—		
	N-Side Software Overtravel			ALM N. N-LS	—	1	
d.	Battery Voltage Low			ALM D. BAT	—	2	
Alarm	Q.	Abso Error			ALM Q. ABS	—	
	I.	Overcurrent			ALM I. OC.	—	
	2.	MCB trip			ALM 2. MCB	—	
	3.	Regenerative Error			ALM 3. RG	—	
	4.	Overvoltage			ALM 4. OV	—	
	5.	Overspeed			ALM 5. OS	—	
	6.	Main Circuit Power Supply Error			ALM 6. UV	—	
	7.	Overload			ALM 7. OL	—	
	8.	Position Error			ALM 8. POS	—	
	R.	Heat Sink Overheat			ALM A. OH	—	
	£.	PG Disconnection			ALM C. PG	—	
	F.	Open Phase			ALM F. O-PH	—	
	H.	Hardware Error			ALM H. HARD	—	
	J.	Overflow			ALM J. OF	—	
	L.	Overrun			ALM L. RWY	—	
	Y.	Parameter Error			ALM Y. PRMpp	—	3
(Un- defined)	CPU Error				—	4	

## Note:

- When a position reference which is out of P or N side software overtravel range is input, a data fault error (ERR OV) occurs.  
When the current position is out of P or N side software overtravel range, (ALM P. P-LS or ALM N. N-LS) occurs.
- Battery low-level detection LED indicator **d.** blinks.
- pp indicates a parameter number. (00 means Position / Speed / Boundary table error.)  
For answer to ALMp command, ?? is not output.  
Answer data are "ALM Y. PRM".
- In case of CPU error, LED indication is uncertain.


# 8 PARAMETERS

Servopack type CACR-HR sets gain, internal constants, and function selection by parameters (serial communication).

- Parameter setter: Personal computer and terminal emulator software
- Serial communication specifications: See Section 7.

(For type CACR-HR ~~BB~~ BB, data can be set in Servopack setting and displaying section. Refer to Par. 9.1.3)

## 8.1 GENERAL PROCEDURE FOR DEFINING PARAMETERS



## 8.1 GENERAL PROCEDURE FOR DEFINING PARAMETERS (Cont'd)

The flow chart on the previous page shows the steps necessary to determine parameters for HR-Servo applications.

### ◆ Step 1

Determine the motor type and motor-parameter number (PRM7) from the table on page 160. If the motor is equipped with an incremental encoder set parameter PRM9 to 1. Set this parameter to 0, in case of a motor with absolute encoder. Parameter PRM8 holds the encoder resolution. The standard absolute encoder has 8,192 lines per revolution, providing 32,768 ( $8,192 \times 4$ ) pulses per motor revolution (PRM8 = 32,768).

### ◆ Step 2


Parameters PRM12 and PRM13 define the gear ratio as a ratio of 2 integer numbers. Set parameter PRM12 to the motor speed, and set parameter PRM13 to the gearbox-output speed.

### ◆ Step 3


Determine the desired programming resolution, also referred to as Reference Unit. Typical values are 0.001", 0.001mm, 0.01 degrees. This is minimum position increment that can be programmed and is different from the encoder resolution. The programming resolution is determined by parameters, the encoder resolution is determined by the number of encoder pulses and the machine configuration (gear ratio, screw pitch, etc.)

### ◆ Step 4


Determine the amount of linear or rotary motion for one revolution of the gearbox-output shaft (one motor revolution, in case of direct drive); also referred to as Feed Constant (FC) in this document. The illustration below shows three common application examples.



FC = Lead of Screw



FC = One Rotation  
(360 Degrees, 1 Rev..., etc)



FC =  $\pi D$

There are no restrictions for choosing the units of FC (inches, mm, degrees, furlongs, or anything else). Divide the value of FC by the programming resolution determined in step 3. Omit any remaining digits after the decimal point. The result is the value for parameter PRM11.

$$\text{PRM11} = \text{FC/Reference Unit.}$$



◆ Step 5

There is a restriction for the HR-Servo as far as the number of encoder pulses per Reference Unit is concerned. The number of encoder pulses per Reference Unit has to be equal to or larger than 0.01 pulses, and equal to or smaller than 100 pulses. This may be quickly checked, evaluating the formula below.

$$0.01 \leq \frac{\text{PRM8} \times \text{PRM12}}{\text{PRM11} \times \text{PRM13}} \leq 100$$

If the calculated value is smaller than one, the programming resolution is smaller than the encoder resolution. This means that the positioning accuracy is not as good as the programming resolution (less than one encoder pulse per Reference Unit).

◆ Step 6

If the result of the calculation in step 5 is outside the limits, -revise the selected programming resolution (Reference Unit) and go back to step 4.

◆ Step 7

Determine the feed speed expressed in terms of Reference Units per minute. Set parameter PRM4 to the speed in Reference Units per minute divided by 1,000.


$$\text{PRM4} = \frac{\text{Speed [Reference Unit per minute]}}{1,000}$$

The other parameters related to speed, PRM31, PRM32, PRM33, PRM46, PRM48, PRM51, PRM52 and PRM53 are optional. They have to set only, if the associated optional functions are enabled. The procedure for setting the optional, speed related parameters is the same as the procedure for parameter PRM4.

◆ Step 8

Set all other parameters required for your application. Refer to pages 150 through 181 for details.

Example:



## 8.1 GENERAL PROCEDURE FOR DEFINING PARAMETERS (Cont'd)

### ◆ Step 1

Motor and encoder parameters

- A. Motor type: PRM7 = 54
- B. Encoder type: PRM9 = 1
- C. Encoder pulses per revolution: PRM8 = 32,768

### ◆ Step 2

Parameters for the gear reduction

- A. Motor speed: PRM12 = 203
- B. Gearbox-output speed: PRM13 = 10

All parameters have to be integers ("whole numbers"). Only the ratio of parameters PRM12 and PRM13 is used for "internal" calculations.

### ◆ Step 3

Programming resolution (Reference Unit): 0.01" (preliminary value)

### ◆ Step 4

Amount of linear motion for one revolution of the gearbox-output shaft, Feed Constant (FC)

- A.  $FC = \pi \times D = 3.14159 \times 7.5 \text{ inches} = 23.562 \text{ inches}$
- B.  $PRM11 = FC/Reference \text{ Unit} = 23.562/0.01 = 2356$

### ◆ Step 5

Programming resolution (Reference Unit) within limits?

- A.  $PRM8 \times PRM12 / (PRM11 \times PRM13) = 32,768 \times 203 / (2356 \times 10) = 282$
- B. This value is outside the limits
- C. Next step is step 6

### ◆ Step 6

Revised programming resolution (Reference Unit): 0.001"

### ◆ Step 4

Amount of linear motion for one revolution of the gearbox-output shaft, Feed Constant (FC)

- A.  $FC = \pi \times D = 3.14159 \times 7.5 \text{ inches} = 23.562 \text{ inches}$
- B.  $PRM11 = FC/Reference \text{ Unit} = 23.562/0.001 = 23,562$

### ◆ Step 5

Programming resolution (Reference Unit) within limits?

- A.  $PRM8 \times PRM12 / (PRM11 \times PRM13) = 32,768 \times 203 / (23,562 \times 10) = 28$
- B. This value is within the limits
- C. Next step is step 7

◆ Step 7

Feed speed parameter value

- A.  $1,750\text{ipm} = 1,750,000 \text{ Reference Units per minute (programming resolution} = 0.001\text{'')}$
- B.  $\text{PRM4} = \text{Speed [Reference Unit per minute]} / 1000 = 1,750,000 / 1,000 = 1,750$

◆ Step 8

Other parameters, pages 150 through 181

◆ Results

PRM4	=1,750
PRM7	=54
PRM8	=32,768
PRM9	=1
PRM11	=23,562
PRM12	=203
PRM13	=10

## 8.2 PARAMETER LIST

Changing process: ON (on-line parameters), OFF (off-line parameters: effective with command <RES> or by turning the power off and then on once.)

●: Typical parameters which require setting in each position reference method standard way of use

▲: Parameter to be set in each position reference method if necessary

□: Normally not used.

## 8.2 PARAMETER LIST (Cont'd)

No.	Name	Range	Unit <→Related Parameter No. >	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DC-SW	Serial command	Command table
1	Position loop gain: Kp	0 to 200	S <sup>-1</sup>	<input type="radio"/>		30	●	●	●	●
2	Speed loop gain: Kv	1 to 200		<input type="radio"/>		15	●	●	●	●
3	Integral time constant : Ti	1 to 255	×2(ms)	<input type="radio"/>		10	●	●	●	●
4	1st feeding speed	1 to 240000	(×1000) · reference unit/min	<input type="radio"/>		60	●	●	●	●
5	Linear accel/ decel time l	8 to 60000	ms	<input type="radio"/>		100	●	●	●	●
6	Positioning complete range	1 to 250	Reference unit	<input type="radio"/>		1	●	●	●	●
7	Motor selection	0 to 79			<input type="radio"/>	(Note)	●	●	●	●
8	Encoder pulse	4096 to 32768	Pulse (×4)		<input type="radio"/>	32768	●	●	●	●
9	Encoder selection	0: absolute 1: incremental			<input type="radio"/>	0	●	●	●	●
10	Absolute encoder allow- able error amount	0 to 99999999	Pulse		<input type="radio"/>	32768	●	●	●	●
11	Reference unit/machine one rotation	1 to 1500000	Reference unit		<input type="radio"/>	32768	●	●	●	●
12	Gear ratio setting (motor side speed)	1 to 10000000	Rotation		<input type="radio"/>	1	●	●	●	●
13	Gear ratio setting (machine side speed)	1 to 10000000	Rotation		<input type="radio"/>	1	●	●	●	●
14	Mode setting	0 to 11111	Bit (5-bit)		<input type="radio"/>	00000				
	b0: Motor rotating direction (REV run connection)	0: FWD run 1: REV run				0	▲	▲	▲	▲
	b1: Finite positioning/ infinite positioning mode setting	0: Finite posi- tioning 1: Infinite posi- tioning				0	●	●	●	●
	b2: Linear/rotation type mode setting	0: Linear type 1: Rotation type				0	●	●	●	●
	b3: Position reference mode	0: Absolute 1: Incremental				0	●	●	●	●
	b4: Position data code	0: Binary 1: BCD				0	●	●		●
15	Position reference method	0: Station No. (contact)	<→16. 20/b2>		<input type="radio"/>	2	●	●	●	●
		1: DC-SW	<→20/b1>							
		2: Serial command								
		4: Command table								

(Cont'd)

(Cont' d)

No.	Name	Range	Unit <→Related Parameter No. >	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DG-SW	Serial command	Command table
16	Station No.	1 to 4096	<→20/b2>		○	1	●			
17	Function selection 1	0 to 11111	Bit (5-bit)		○	00000				
	b0: Current limit	1: Set	<→34 to 36>			0		▲	▲	
	b1: Feed forward	1: Provided	<→37>			0		▲	▲	
	b2: 2-step accel/decel	1: 2-step (0: 1-step)	<→38, 39>			0	▲	▲	▲	▲
	b3: Speed limit	1: Set	<→46>			0		▲		
	b4: Accel/decel type designation	1: Set	<→68 to 71, 47, 48>			0		▲	▲	
18	Function selection 2	0 to 11111	Bit (5-bit)		○	00000				
	b0: Software overtravel (Position reference fault detection)	1: Set	<→40, 41>			0		▲	▲	
	b1: Backlash compensa- tion	1: Provided	<→42>			0	▲	▲	▲	▲
	b2: Speed reference (automatic mode)	1: Set	<→61>			0		▲		▲
	b3: Speed reference (manual mode)	1: Set	<→62>			0		▲		
	b4: Zero-point return	1: Used	<→49 to 54>			0		▲	▲	
19	Function selection 3	0 to 11111111	Bit (8-bit)		○	000000				
	b0: OT signal	1: Mask	<→19/b6>			0	▲	▲	▲	▲
	b1: STOP signal	1: Mask	<→72/b1>			0	▲	▲	▲	▲
	b2: Brake release signal	1: Used	<→43, 44>			0	▲	▲	▲	▲
	b3: Pulse input (reference)	1: Used	<→63>			0		▲	▲	
	b4: Pulse output (with- out FB zero point)	1: Used	<→64>			0		▲	▲	
	b5: Positioning (sta- tion) near signal	1: Used	<→45>			0	▲	▲	▲	▲
	b6: OT signal switching	0: Standard 1: Inversion				0		▲	▲	
	b7: Torque filter time constant change	0: Not change 1: Change	<→90>			0	▲	▲	▲	▲

(Cont' d)

## 8.2 PARAMETER LIST (Cont'd)

No.	Name	Range	Unit <→Related Parameter No.>	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DG-SW	Serial command	Command table
20	Function selection 4	0 to 1111111	Bit (7-bit)			0000000				
	b0	0				0				
	b1: External position indicator	1: Used 0: Not used	<→67>			0		●		
	b2: Station No. 0	0: Provided 1: Not provided			○	0	●			
	b3: Simplified S-curve accel/decel	1: Used 0: Not used	<→76>			0	▲	▲	▲	▲
	b4: Function 7 setting	0: Not set 1: Set	<→72>			0	▲	▲	▲	▲
	b5: Function 5 setting	0: Not set 1: Set	<→65>			0	▲	▲	▲	▲
	b6: Function 6 setting	0: Not set 1: Set	<→66>			0	▲		▲	
21 to 30	For future use					0				
31	2nd feed speed	1 to 240000	(×1000) · reference unit/min	○		1	▲	▲		
32	3rd feed speed	1 to 240000	(×1000) · reference unit/min	○		1	▲	▲		
33	4th feed speed	1 to 240000	(×1000) · reference unit/min	○		1	▲	▲		
34	Current limit value	0 to 400	%	○		400		▲	▲	
35	Plus side current limit value (current limiting)	0 to 400	%	○		400		▲	▲	
36	Minus side current limit value (current limiting)	0 to 400	%	○		400		▲	▲	
37	Feedforward compensation value	0 to 200	%	○		0		▲	▲	
38	Linear accel/decel time 2	8 to 60000	ms	○		100		▲	▲	
39	Linear accel/decel accel switching speed	0 to 240000	(×1000) · reference unit/min	○		240000		▲	▲	
40	Plus side software overtravel (plus side position reference fault detection value)	±99999999	Reference unit	○		+99999999			▲	
41	Minus side software overtravel (minus side position reference fault detection value)	±99999999	Reference unit	○		-99999999			▲	
42	Backlash compensated amount	0 to ±30000	Pulse	○		0	▲	▲	▲	▲

(Cont'd)

No.	Name	Range	Unit <->Related Parameter No. >	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DG-SW	Serial command	Command table
43	Braking time	8 to 1000	ms	○		8	▲	▲	▲	▲
44	Brake ON. motor speed	1 to 10000	r/min	○		1	▲	▲	▲	▲
45	Positioning near range (station near range)	0 to 30000	Reference unit	○		1	▲	▲	▲	▲
46	Speed limit value	1 to 240000	(×1000) · reference unit/min	○		240000		▲		
47	Exponential accel/decel time constant	8 to 1000	ms	○		100		▲	▲	
48	Exponential accel/decel bias speed	0 to 240000	(×1000) · reference unit/min	○		0		▲	▲	
49	Zero-point return (homing) mode	0: DEC+C, 1:STP		○		1		▲	▲	
50	Zero-point return direc- tion	0: Plus direction 1: Minus direction		○		0		▲	▲	
51	Zero-point return feed speed	0 to 240000	(×1000) · reference unit/min	○		1		▲	▲	
52	Zero-point return ap- proach speed	0 to 240000	(×1000) · reference unit/min	○		1		▲	▲	
53	Zero-point return creep speed	0 to 240000	(×1000) · reference unit/min	○		1		▲	▲	
54	Zero-point return final travel distance	0 to ±9999999	Reference unit	○		0		▲	▲	
55 to 60	For future use					0				
61	Feed speed setting method (automatic mode)	0: Select by parameter at contacts 1: Digital switch 2: Serial command 4: Speed table			○	2		▲		
62	Feed speed setting method (manual mode)	0: Select by parameter at contacts 1: Digital switch 2: Serial command 4: Speed table			○	2		▲		

(Cont'd)

8

## 8.2 PARAMETER LIST (Cont'd)

No.	Name	Range	Unit <→Related Parameter No.>	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DG-SW	Serial command	Command table
63	Pulse signal status	0: 90° phase difference 2-phase pulse ×4 1: 90° phase difference 2-phase pulse ×2 2: 90° phase difference 2-phase pulse ×1 3: Sign + pulse train 4: CCW pulse + CW pulse			○	0		▲	▲	
64	Output pulse dividing ratio	2 to 64	1/2		○	2		▲		
65	Function selection 5	0 to 1111111	Bit (7-bit)			0000000				
	b0: Zone signal	1: Used 0: Not used				0				▲
	b1: Station near signal	1: Used 0: Not used	<→19/b5, 45>		○	0	▲			
	b2: DG-SW read-in time change	1: Change 0: Not change	<→77>			0		▲		
	b3: DG-SW digit number shift	1: Used 0: Not used	<→67>			0		▲		
	b4:	0				0				
	b5:	0				0				
b6: Positioning completion signal	1: Changed 0: Not changed				0	▲	▲	▲	▲	
66	Function selection 6	0 to 11111111	Bit (8-bit)			00000000				
	b0:	0				0				
	b1:	0				0				
	b2:	0				0				
	b3:	0				0				
	b4: Extension of station No. output	1: Used 0: Not used			○	0	▲			
	b5:	0				0				
	b6:	0				0				
b7: Servopack response axis address	1: Provided 0: Not provided				0				▲	
67	Decimal point position and digit number shift	0 to 7			○	0		●		
68	Accel/decel type setting (automatic mode)	0: Linear, simplified S curve 1: Exponent			○	0		▲	▲	
69	Accel/decel type setting (manual mode)	0: Linear, simplified S curve 1: Exponent			○	0		▲		
70	Accel/decel type setting (pulse mode)	0: Linear, simplified S curve 1: Exponent			○	0		▲	▲	
71	Accel/decel type setting (zero-point return mode)	0: Linear, simplified S curve 1: Exponent			○	0		▲	▲	

(Cont'd)



(Cont'd)

No.	Name	Range	Unit <→Related Parameter No. >	Change		Preset at the Factory	Position Reference Method			
				ON	OFF		Station No.	DG-SW	Serial command	Command table
72	Function selection 7	0 to 111111	Bit (6-bit)		○	000000				
	b0: Overrun detection alarm check	0: Check 1: Not check				0				
	b1: Remaining data after STOP signal	0: Appear 1: Disappear				0	▲	▲	▲	▲
	b2: FB after positioning stop	0: By contact 1: Motor PG				0		▲	▲	
	b3: Echo back at initialization	0: Not provided 1: Provided				0			▲	
	b4: OK response for serial command	0: No response 1: Response				0			▲	
	b5: Monitor Data Transmission Specification Change	0: Repeatedly 1: Only once				0			▲	
73 to 75	For future use				0					
76	Simplified S-curve accel/decel time	0 to 124	(+2)ms		○	0	▲	▲	▲	▲
77	DG-SW read-in scanning time	24 to 2000	ms		○	24		▲		
78 to 89	For future use					0				
90	Torque reference filter Time constant	0 to 100	(×32.5)μs		○	15	▲	▲	▲	▲
91 to 99	For future use					0				

Note: Refer to Table 8.1 for parameter No. 7 (motor selection) preset at the factory.



### 8.3 PARAMETER FUNCTION DETAILS

No.	Name	Contents
1	Position Loop Gain (Abbreviation: Kp)	Position loop gain set value. Unit: [S <sup>-1</sup> ], setting range: (0 to 200)
2	Speed Loop Gain (Abbreviation: Kv)	• Kv: Speed loop gain set value. Unit: [×2.5Hz], setting range: (1 to 200) (for equivalent inertia)
3	Integral Time Constant (Abbreviation: Ti)	• Ti: Speed loop integral time constant set value. Unit: [×2ms], setting range: (1 to 255)
<p>Notes:</p> <ol style="list-style-type: none"> <li>Relation between speed loop gain Kv and integral time constant Ti is defined by the following value in proportion to current reference, assuming speed deviation is εv:</li> </ol> $Kv (\epsilon v + \int \frac{\epsilon v}{Ti} dt)$ <ol style="list-style-type: none"> <li>Speed loop gain Kv cannot obtain a high value when machine system rigidity is low. (Oscillation occurs by forcing the value to increase.)</li> <li>Excessively small integral time constant Ti causes oscillation. Do not use it by making it extremely smaller than factory set value 10 (20ms) prior to shipping.</li> </ol>		



(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents																																		
4	(1st) Feeding Speed	<p>Acceleration speed value set value for reference speed and linear accel/decel.</p> <p>Unit : (<math>\times 1000</math> reference unit/min), setting range: (1 to 240000).</p> <p>(Example) For reference unit 0.01mm, feeding speed set value of 150m/min is as follows:</p> $\frac{(150 \times 10^3)}{0.01} = 15000000 \text{ reference unit/min}$ $= 15000 \times 1000 \text{ unit/min}$ $= \boxed{15000}$ <p>(1) For reference speed, this parameter set value is selected when speed select signals (5CN) both SP2ND and SP3RD are at H level.</p> <p>&lt; Speed selected by this parameter at contact &gt;</p> <table border="1"> <thead> <tr> <th colspan="3">Parameter</th> <th colspan="2">Speed Select Signal</th> </tr> <tr> <th>No</th> <th>Name</th> <th>Setting Range/Unit</th> <th><math>\overline{\text{SP2ND}}</math></th> <th><math>\overline{\text{SP3RD}}</math></th> </tr> </thead> <tbody> <tr> <td>4</td> <td>(1st) Feeding Speed</td> <td>1 to 240000</td> <td>H</td> <td>H</td> </tr> <tr> <td>31</td> <td>(2nd) Feeding Speed</td> <td rowspan="4">(<math>\times 1000</math> reference unit/min)</td> <td>L</td> <td>H</td> </tr> <tr> <td>32</td> <td>(3rd) Feeding Speed</td> <td>H</td> <td>L</td> </tr> <tr> <td>33</td> <td>(4th) Feeding Speed</td> <td>L</td> <td>L</td> </tr> </tbody> </table> <p>(2) Accel/decel speed set value (1-, 2-step linear accel/decel, simplified S-curve accel/decel)</p> <table border="1"> <thead> <tr> <th>Parameter No.</th> <td>4</td> <td>5</td> </tr> </thead> <tbody> <tr> <th>Set Value</th> <td>V</td> <td>T</td> </tr> </tbody> </table> <p>Accel speed <math>\alpha</math> is determined by <math>V/T</math> and becomes constant if feeding speed changes. (Accel speed constant control)</p>	Parameter			Speed Select Signal		No	Name	Setting Range/Unit	$\overline{\text{SP2ND}}$	$\overline{\text{SP3RD}}$	4	(1st) Feeding Speed	1 to 240000	H	H	31	(2nd) Feeding Speed	( $\times 1000$ reference unit/min)	L	H	32	(3rd) Feeding Speed	H	L	33	(4th) Feeding Speed	L	L	Parameter No.	4	5	Set Value	V	T
Parameter			Speed Select Signal																																	
No	Name	Setting Range/Unit	$\overline{\text{SP2ND}}$	$\overline{\text{SP3RD}}$																																
4	(1st) Feeding Speed	1 to 240000	H	H																																
31	(2nd) Feeding Speed	( $\times 1000$ reference unit/min)	L	H																																
32	(3rd) Feeding Speed		H	L																																
33	(4th) Feeding Speed		L	L																																
Parameter No.	4		5																																	
Set Value	V	T																																		

(Cont'd)

(Cont'd)

No.	Name	Contents
5	Linear Accel/Decel Time 1	<p>For linear accel/decel speed control, accel/decel speed is set with parameter 4. Unit: (ms), setting range: (8 to 60000)</p> <p>① For 1-step accel/decel, refer to the description of parameter 4. ② For 2-step accel/decel, (refer to the description of parameter 17 b2), the first-step accel/decel speed is set. ③ For simplified S-curve accel/decel (refer to the description of parameter 76), the second-step accel/decel speed is set.</p>  <p><math>\alpha_1</math>: 1st-step accel/decel speed (by <math>V_1/T_1</math>) <math>\alpha_2</math>: 2nd-step accel/decel speed (Refer to the description of parameter 17.)</p>
6	Positioning Complete Range (Abbreviation: COIN Width)	<p>If distance difference (in reference units) between current position and target position provided by reference data becomes lower than the value set by parameter 6, COIN signal is output. (In serial communication, <span style="border: 1px solid black; padding: 2px;">COIN</span> is automatically sent.) Setting range: 1 to 250 (reference unit).</p>  <p>P: Positioning complete range <math>x</math>:   Current position - target position   COIN signal is output when <math>x \leq p</math>.</p>










(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents																																																																																																																																																																																																
7	Motor Selection Code	<p>In Servopack type CACR-HR, each constant required for control with matching motors is determined by the code set in parameter 7 for perfect matching of Servopack and motors.</p> <p>Since a code number is provided for each motor type, check matching motor type and set the code number.</p> <table border="1"> <thead> <tr> <th colspan="2">M Series</th> <th colspan="2">F Series</th> <th colspan="2">G Series</th> <th colspan="2">D Series</th> <th colspan="2">S Series</th> <th colspan="2">R Series (200V)</th> <th colspan="2">R Series (100V)</th> <th colspan="2">P Series</th> </tr> <tr> <th>Motor Type USAMED-</th> <th>Code No.</th> <th>Motor Type USAFED-</th> <th>Code No.</th> <th>Motor Type USAGED-</th> <th>Code No.</th> <th>Motor Type USADED-</th> <th>Code No.</th> <th>Motor Type USASEM-</th> <th>Code No.</th> <th>Motor Type USAREM-</th> <th>Code No.</th> <th>Motor Type USAREM-</th> <th>Code No.</th> <th>Motor Type USAPEM-</th> <th>Code No.</th> </tr> </thead> <tbody> <tr> <td>—</td> <td>0</td> <td>02</td> <td>10</td> <td>02</td> <td>50</td> <td>—</td> <td>40</td> <td>02A</td> <td>20</td> <td>—</td> <td>30</td> <td>—</td> <td>60</td> <td>—</td> <td>70</td> </tr> <tr> <td>03</td> <td>1</td> <td>03</td> <td>11</td> <td>03</td> <td>51</td> <td>—</td> <td>41</td> <td>03A</td> <td>21</td> <td>—</td> <td>31</td> <td>—</td> <td>61</td> <td>—</td> <td>71</td> </tr> <tr> <td>06</td> <td>2</td> <td>05</td> <td>12</td> <td>05</td> <td>52</td> <td>05B</td> <td>42</td> <td>05A</td> <td>22</td> <td>A5C</td> <td>32</td> <td>A5D</td> <td>62</td> <td>—</td> <td>72</td> </tr> <tr> <td>09B</td> <td>3</td> <td>09</td> <td>13</td> <td>09</td> <td>53</td> <td>10B</td> <td>43</td> <td>08A</td> <td>23</td> <td>01C</td> <td>33</td> <td>01D</td> <td>63</td> <td>01C</td> <td>73</td> </tr> <tr> <td>12B</td> <td>4</td> <td>13C</td> <td>14</td> <td>13A</td> <td>54</td> <td>15B</td> <td>44</td> <td>15A</td> <td>24</td> <td>02C</td> <td>34</td> <td>02D</td> <td>64</td> <td>02C</td> <td>74</td> </tr> <tr> <td>20B</td> <td>5</td> <td>20C</td> <td>15</td> <td>20A</td> <td>55</td> <td>22B</td> <td>45</td> <td>—</td> <td>25</td> <td>03C</td> <td>35</td> <td>03D</td> <td>65</td> <td>03C</td> <td>75</td> </tr> <tr> <td>30B</td> <td>6</td> <td>30C</td> <td>16</td> <td>30A</td> <td>56</td> <td>37B</td> <td>46</td> <td>30A</td> <td>26</td> <td>05C</td> <td>36</td> <td>05D</td> <td>66</td> <td>05C</td> <td>76</td> </tr> <tr> <td>44B</td> <td>7</td> <td>44C</td> <td>17</td> <td>44A</td> <td>57</td> <td>—</td> <td>47</td> <td>—</td> <td>27</td> <td>07C</td> <td>37</td> <td>—</td> <td>67</td> <td>07C</td> <td>77</td> </tr> <tr> <td>USAMKD- 60B</td> <td>8</td> <td>—</td> <td>18</td> <td>—</td> <td>58</td> <td>—</td> <td>48</td> <td>—</td> <td>28</td> <td>—</td> <td>38</td> <td>—</td> <td>68</td> <td>—</td> <td>78</td> </tr> <tr> <td>—</td> <td>9</td> <td>—</td> <td>19</td> <td>—</td> <td>59</td> <td>—</td> <td>49</td> <td>—</td> <td>29</td> <td>—</td> <td>39</td> <td>—</td> <td>69</td> <td>—</td> <td>79</td> </tr> </tbody> </table>	M Series		F Series		G Series		D Series		S Series		R Series (200V)		R Series (100V)		P Series		Motor Type USAMED-	Code No.	Motor Type USAFED-	Code No.	Motor Type USAGED-	Code No.	Motor Type USADED-	Code No.	Motor Type USASEM-	Code No.	Motor Type USAREM-	Code No.	Motor Type USAREM-	Code No.	Motor Type USAPEM-	Code No.	—	0	02	10	02	50	—	40	02A	20	—	30	—	60	—	70	03	1	03	11	03	51	—	41	03A	21	—	31	—	61	—	71	06	2	05	12	05	52	05B	42	05A	22	A5C	32	A5D	62	—	72	09B	3	09	13	09	53	10B	43	08A	23	01C	33	01D	63	01C	73	12B	4	13C	14	13A	54	15B	44	15A	24	02C	34	02D	64	02C	74	20B	5	20C	15	20A	55	22B	45	—	25	03C	35	03D	65	03C	75	30B	6	30C	16	30A	56	37B	46	30A	26	05C	36	05D	66	05C	76	44B	7	44C	17	44A	57	—	47	—	27	07C	37	—	67	07C	77	USAMKD- 60B	8	—	18	—	58	—	48	—	28	—	38	—	68	—	78	—	9	—	19	—	59	—	49	—	29	—	39	—	69	—	79
M Series		F Series		G Series		D Series		S Series		R Series (200V)		R Series (100V)		P Series																																																																																																																																																																																				
Motor Type USAMED-	Code No.	Motor Type USAFED-	Code No.	Motor Type USAGED-	Code No.	Motor Type USADED-	Code No.	Motor Type USASEM-	Code No.	Motor Type USAREM-	Code No.	Motor Type USAREM-	Code No.	Motor Type USAPEM-	Code No.																																																																																																																																																																																			
—	0	02	10	02	50	—	40	02A	20	—	30	—	60	—	70																																																																																																																																																																																			
03	1	03	11	03	51	—	41	03A	21	—	31	—	61	—	71																																																																																																																																																																																			
06	2	05	12	05	52	05B	42	05A	22	A5C	32	A5D	62	—	72																																																																																																																																																																																			
09B	3	09	13	09	53	10B	43	08A	23	01C	33	01D	63	01C	73																																																																																																																																																																																			
12B	4	13C	14	13A	54	15B	44	15A	24	02C	34	02D	64	02C	74																																																																																																																																																																																			
20B	5	20C	15	20A	55	22B	45	—	25	03C	35	03D	65	03C	75																																																																																																																																																																																			
30B	6	30C	16	30A	56	37B	46	30A	26	05C	36	05D	66	05C	76																																																																																																																																																																																			
44B	7	44C	17	44A	57	—	47	—	27	07C	37	—	67	07C	77																																																																																																																																																																																			
USAMKD- 60B	8	—	18	—	58	—	48	—	28	—	38	—	68	—	78																																																																																																																																																																																			
—	9	—	19	—	59	—	49	—	29	—	39	—	69	—	79																																																																																																																																																																																			
8	Encoder Pulse	Encoder pulse resolution mounted at motor shaft opposite load side is set. Prior to shipping, value <input type="text" value="32768"/> (8192 × 4) is set.																																																																																																																																																																																																
9	Encoder Selection	<p>Identification code of encoder to be used is set. Factory setting is <input type="text" value="0"/>.</p> <p>Absolute encoder identification code: 0 Incremental encoder identification code: 1</p>																																																																																																																																																																																																
10	Absolute Encoder Allowable Error Amount	<p>Effective with parameter 9=0</p> <p>Absolute encoder absolute value data are checked when Servopack power supply is turned on. At this time, if an error amount (difference of position compared to position before previous power-down) exceeds parameter 10 set value, an alarm (ABS0 error) occurs.</p> <p>Set value prior to shipping is <input type="text" value="32768"/>.</p>																																																																																																																																																																																																

(Cont'd)

(Cont' d)

No.	Name	Contents												
11	Load Moving Amount at Load Side One Rotation (Reference unit)	<p>(1) Reference unit is the minimum unit of position data to move the load.            (Example: 0.01mm, 1<math>\mu</math>m, 0.1° or 0.01 inch)            For example, when reference unit is 1 <math>\mu</math>m, and position data value is 50000, actual moving amount will be:</p> $50000 \times 0.1 = 5000 \mu\text{m} = 5\text{mm.}$ <ul style="list-style-type: none"> <li>• Determine reference unit, considering machine specifications, positioning accuracy, etc.</li> <li>• Position data unit for DG-SW, serial communication, etc. is the reference unit.</li> <li>• Speed data unit in DG-SW, serial communication or parameter setting is (<math>\times 1000</math> reference unit/min) .</li> </ul> <p>(2) (Parameter 11) set value  <math display="block">= \frac{\text{Moving amount per load side rotation}}{\text{Reference unit}}</math> <p>The table below shows typical load moving amount rotation:</p> <table border="1" data-bbox="577 930 1372 1602"> <thead> <tr> <th data-bbox="577 930 817 1052">Load Moving Amount per Load Shaft Rotation</th> <th colspan="2" data-bbox="817 930 1372 1052">Typical Load Cofiguration</th> </tr> </thead> <tbody> <tr> <td data-bbox="577 1052 817 1234">P</td> <td data-bbox="817 1052 910 1234">Ball Screw</td> <td data-bbox="910 1052 1372 1234">  <p>ONE ROTATION P; BALL SCREW PITCH</p> </td> </tr> <tr> <td data-bbox="577 1234 817 1417">360°</td> <td data-bbox="817 1234 910 1417">Round Table</td> <td data-bbox="910 1234 1372 1417">  <p>360° ONE ROTATION</p> </td> </tr> <tr> <td data-bbox="577 1417 817 1602"><math>\pi D</math></td> <td data-bbox="817 1417 910 1602">Belt</td> <td data-bbox="910 1417 1372 1602">  <p>ONE ROTATION <math>\pi D</math></p> </td> </tr> </tbody> </table> <p>Parameter 11 setting range: 1 to 1500000</p> <p>(Exmapple) When load moving mount per load shaft rotation is 12mm and reference unit is 0.01mm, the following value is set:</p> <math display="block">\text{(Parameter 11)} = \frac{12}{0.01} = 1200</math> </p>	Load Moving Amount per Load Shaft Rotation	Typical Load Cofiguration		P	Ball Screw	 <p>ONE ROTATION P; BALL SCREW PITCH</p>	360°	Round Table	 <p>360° ONE ROTATION</p>	$\pi D$	Belt	 <p>ONE ROTATION <math>\pi D</math></p>
Load Moving Amount per Load Shaft Rotation	Typical Load Cofiguration													
P	Ball Screw	 <p>ONE ROTATION P; BALL SCREW PITCH</p>												
360°	Round Table	 <p>360° ONE ROTATION</p>												
$\pi D$	Belt	 <p>ONE ROTATION <math>\pi D</math></p>												

(Cont' d)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents													
12	Gear Ratio Setting $m$ (Motor Shaft Rotation Speed)	<p>(1) Assuming load shaft rotates <math>\ell</math> times when motor shaft rotates <math>m</math> times according to applicable machine specifications by parameter to set gear ratio, the following values are set:</p> <ul style="list-style-type: none"> <li>• (Parameter 12) = <math>m</math></li> <li>• (Parameter 13) = <math>\ell</math></li> </ul> <p>(2) Parameter 12 or 13 unit is (rotation) and the setting range is 1 to 10000000.</p> <p>(3) By parameters 8 and 11 to 13, reference data and encoder pulse conversion can be possible.</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <math display="block">\frac{B}{A} = \frac{(\text{PARAMETER 8}) \times (\text{PARAMETER 12})}{(\text{PARAMETER 11}) \times (\text{PARAMETER 13})}</math> </div> <p>However, the above indicates the number of encoder pulses per reference unit, having limiting conditions as follows:</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <math display="block">0.01 \leq \frac{B}{A} \leq 100</math> </div> <p>(You must reconsider the machine specifications to omit this condition.)</p> <p>(4) Precautions when <math>\frac{B}{A} &lt; 1</math></p> <p>Since the reference unit becomes smaller than the encoder pulse resolution, positioning accuracy becomes lower as <math>\frac{B}{A}</math> value becomes smaller.</p>													
13	Gear Ratio Setting $\ell$ (Load Shaft Rotation Speed)														
14	Mode Setting	By setting b4, b3, b2, b1 or b0 to "0" or "1", mode is set (b0 is LSB).													
	b0 Motor Rotating Direction Setting	Used when motor rotating direction for reference direction ( $\pm$ ) is changed.													
		<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Set Value</th> <th>Reference Direction</th> <th>Motor Shaft Rotating Direction</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td>+</td> <td>Forward direction</td> </tr> <tr> <td>-</td> <td>Reverse direction</td> </tr> <tr> <td rowspan="2">1</td> <td>+</td> <td>Reverse direction</td> </tr> <tr> <td>-</td> <td>Forward direction</td> </tr> </tbody> </table>	Set Value	Reference Direction	Motor Shaft Rotating Direction	0	+	Forward direction	-	Reverse direction	1	+	Reverse direction	-	Forward direction
Set Value	Reference Direction	Motor Shaft Rotating Direction													
0	+	Forward direction													
	-	Reverse direction													
1	+	Reverse direction													
	-	Forward direction													

(Cont'd)



(Cont'd)

No.	Name	Contents																									
14	b1 Finite Positioning/ Infinite Positioning Mode Setting	<p>Set according to machine specification.</p> <table border="1" data-bbox="582 367 1378 646"> <tr> <td data-bbox="582 367 797 493">Finite Positioning Mode (Set Value = 0)</td> <td data-bbox="797 367 1378 493">Used for configuration with a moving limit. (Software overtravel function provided.)</td> </tr> <tr> <td data-bbox="582 493 797 646">Infinite Positioning Mode (Set Value = 1)</td> <td data-bbox="797 493 1378 646">Used for configuration without moving limit (such as round table or press feeder one-direction feeding). (Position reference fault detection provided.)</td> </tr> </table>	Finite Positioning Mode (Set Value = 0)	Used for configuration with a moving limit. (Software overtravel function provided.)	Infinite Positioning Mode (Set Value = 1)	Used for configuration without moving limit (such as round table or press feeder one-direction feeding). (Position reference fault detection provided.)																					
Finite Positioning Mode (Set Value = 0)	Used for configuration with a moving limit. (Software overtravel function provided.)																										
Infinite Positioning Mode (Set Value = 1)	Used for configuration without moving limit (such as round table or press feeder one-direction feeding). (Position reference fault detection provided.)																										
	b2 Linear Type/Rotation Type Mode Setting.	<p>Set according to the machine specifications (Load is of linear type or rotating type). Positioning range is as shown below by mode.</p> <table border="1" data-bbox="577 787 1347 1008"> <tr> <td data-bbox="577 787 700 882">Linear (b2=0)</td> <td data-bbox="700 787 1347 882">-99999999 ~ +99999999</td> </tr> <tr> <td data-bbox="577 882 700 1008">Rotation (b2=1)</td> <td data-bbox="700 882 1347 1008">Positioning range is 0 to (parameter (11) set value - 1) regardless of rotating amount. (Range for one rotation)</td> </tr> </table>	Linear (b2=0)	-99999999 ~ +99999999	Rotation (b2=1)	Positioning range is 0 to (parameter (11) set value - 1) regardless of rotating amount. (Range for one rotation)																					
Linear (b2=0)	-99999999 ~ +99999999																										
Rotation (b2=1)	Positioning range is 0 to (parameter (11) set value - 1) regardless of rotating amount. (Range for one rotation)																										
	b3 Position Reference Mode	<p>Determines whether position data is of absolute value or incremental value. When reference data value is x, the aimed position after start command (AST signal or serial command <span style="border: 1px solid black; padding: 0 2px;">ST</span>) will be as shown below:</p> <table border="1" data-bbox="531 1218 1362 1648"> <thead> <tr> <th data-bbox="531 1218 669 1407" rowspan="3">Position Reference Mode</th> <th colspan="5" data-bbox="669 1218 1362 1281">Position Reference Method (by Parameter 15 Setting)</th> </tr> <tr> <th data-bbox="669 1281 816 1407" rowspan="2">Station No.</th> <th data-bbox="816 1281 962 1407" rowspan="2">DG-SW</th> <th colspan="2" data-bbox="962 1281 1255 1344">Serial Communication</th> <th data-bbox="1255 1281 1362 1407" rowspan="2">Command table</th> </tr> <tr> <th data-bbox="962 1344 1108 1407">MOV x</th> <th data-bbox="1108 1344 1255 1407">MOVI x</th> </tr> </thead> <tbody> <tr> <td data-bbox="531 1407 669 1533">Absolute value (b3 = 0)</td> <td data-bbox="669 1407 816 1533">x = Target station No.</td> <td data-bbox="816 1407 962 1533">Absolute value</td> <td data-bbox="962 1407 1108 1533">Absolute value</td> <td data-bbox="1108 1407 1255 1533">Incremental value</td> <td data-bbox="1255 1407 1362 1533">Absolute value</td> </tr> <tr> <td data-bbox="531 1533 669 1648">Incremental value (b3 = 1)</td> <td data-bbox="669 1533 816 1648">x = Number of stations to be moved</td> <td data-bbox="816 1533 962 1648">Incremental value</td> <td data-bbox="962 1533 1108 1648">Incremental value</td> <td data-bbox="1108 1533 1255 1648">(Do not use)</td> <td data-bbox="1255 1533 1362 1648">(Do not use)</td> </tr> </tbody> </table>	Position Reference Mode	Position Reference Method (by Parameter 15 Setting)					Station No.	DG-SW	Serial Communication		Command table	MOV x	MOVI x	Absolute value (b3 = 0)	x = Target station No.	Absolute value	Absolute value	Incremental value	Absolute value	Incremental value (b3 = 1)	x = Number of stations to be moved	Incremental value	Incremental value	(Do not use)	(Do not use)
Position Reference Mode	Position Reference Method (by Parameter 15 Setting)																										
	Station No.	DG-SW		Serial Communication		Command table																					
			MOV x	MOVI x																							
Absolute value (b3 = 0)	x = Target station No.	Absolute value	Absolute value	Incremental value	Absolute value																						
Incremental value (b3 = 1)	x = Number of stations to be moved	Incremental value	Incremental value	(Do not use)	(Do not use)																						

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)


No.	Name	Contents																																							
14	b4 Position Reference Code	<p>Position data code (BCD or binary) is selected.</p> <p>(1) Station No. reference method</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Input Signal</th> <th><math>\overline{CD0}</math></th> <th><math>\overline{CD1}</math></th> <th><math>\overline{CD2}</math></th> <th><math>\overline{CD3}</math></th> <th><math>\overline{CD4}</math></th> <th><math>\overline{CD5}</math></th> <th><math>\overline{CD6}</math></th> <th><math>\overline{CD7}</math></th> <th><math>\overline{CD8}</math></th> <th><math>\overline{CD9}</math></th> <th><math>\overline{CD10}</math></th> <th><math>\overline{CD11}</math></th> </tr> </thead> <tbody> <tr> <td>BCD (b4=1)</td> <td>1</td> <td>2</td> <td>4</td> <td>8</td> <td>10</td> <td>20</td> <td>40</td> <td>80</td> <td>100</td> <td>200</td> <td>400</td> <td>800</td> </tr> <tr> <td>Binary (b4=0)</td> <td>1</td> <td>2</td> <td>4</td> <td>8</td> <td>16</td> <td>32</td> <td>64</td> <td>128</td> <td>256</td> <td>512</td> <td>1024</td> <td>2048</td> </tr> </tbody> </table> <p>(2) Set BCD (b4 = 1) for DG-SW reference method                      (3) Set binary setting (b4 = 0) for command table method.</p>	Input Signal	$\overline{CD0}$	$\overline{CD1}$	$\overline{CD2}$	$\overline{CD3}$	$\overline{CD4}$	$\overline{CD5}$	$\overline{CD6}$	$\overline{CD7}$	$\overline{CD8}$	$\overline{CD9}$	$\overline{CD10}$	$\overline{CD11}$	BCD (b4=1)	1	2	4	8	10	20	40	80	100	200	400	800	Binary (b4=0)	1	2	4	8	16	32	64	128	256	512	1024	2048
Input Signal	$\overline{CD0}$	$\overline{CD1}$	$\overline{CD2}$	$\overline{CD3}$	$\overline{CD4}$	$\overline{CD5}$	$\overline{CD6}$	$\overline{CD7}$	$\overline{CD8}$	$\overline{CD9}$	$\overline{CD10}$	$\overline{CD11}$																													
BCD (b4=1)	1	2	4	8	10	20	40	80	100	200	400	800																													
Binary (b4=0)	1	2	4	8	16	32	64	128	256	512	1024	2048																													

15	Position Reference Method	<p>Applicable position data reference method is set.</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Set Value</th> <th>Position Data Reference Method</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Station No.</td> </tr> <tr> <td>1</td> <td>DG-SW</td> </tr> <tr> <td>2</td> <td>Serial Communication</td> </tr> <tr> <td>4</td> <td>Command Table</td> </tr> </tbody> </table>	Set Value	Position Data Reference Method	0	Station No.	1	DG-SW	2	Serial Communication	4	Command Table
Set Value	Position Data Reference Method											
0	Station No.											
1	DG-SW											
2	Serial Communication											
4	Command Table											

	Reference Method and Outline	Reference Input	Remarks
Station No.	Positioning to a station No. provided by parallel contact data (12-bit). Rotating direction is determined by direction select signal.		
DG-SW	Position reference by DG-SW (up to 8 digits) setting data.		
Serial Communication	Position reference command. Data are set by MOV or MOV1.		
Command Table	Positioning at position No. specified by parallel contact data (6-bit).		

(Cont'd)


(Cont'd)

No.	Name	Contents																									
16	Number of Stations	<p>Parameter to set the number of stations when the station No. reference method is selected. Setting range: 1 to 4096.</p> <p>By setting the number of stations N, N stations divided equally on the load shaft circumference are determined.</p> <p>Whether the station No. is taken from 0 or 1 is set by parameter 20 b2.</p>																									
17	<p>Function Selection 1</p> <p>b0 Current Limit</p> <p>b1 Feedforward Compensation</p>	<p>By setting (b4, b3, b2, b1, b0) to "0" or "1", each function can be selected.</p> <p>b0 = 1 when current limit value setting parameter 34, 35 or 36 function is to be effective. b0 = 0 when ineffective.</p> <p>The table below shows effective current limit values marked with ○ when b0 = 1.</p> <table border="1" data-bbox="586 785 1359 1157"> <thead> <tr> <th colspan="2" data-bbox="586 785 874 842">Parameter</th> <th data-bbox="874 785 1017 919">CUR Signal Not Turned ON (CUR-H)</th> <th colspan="2" data-bbox="1017 785 1359 842">CUR Signal ON (CUR-L)</th> </tr> <tr> <th data-bbox="586 842 659 919">No.</th> <th data-bbox="659 842 874 919">Name</th> <th data-bbox="874 842 1017 919"></th> <th data-bbox="1017 842 1187 919">+Side Limit Value (CLP)</th> <th data-bbox="1187 842 1359 919">-Side Limit Value (CLN)</th> </tr> </thead> <tbody> <tr> <td data-bbox="586 919 659 997">34</td> <td data-bbox="659 919 874 997">Current Limit Value</td> <td data-bbox="874 919 1017 997">○</td> <td data-bbox="1017 919 1187 997">○</td> <td data-bbox="1187 919 1359 997">○</td> </tr> <tr> <td data-bbox="586 997 659 1075">35</td> <td data-bbox="659 997 874 1075">Plus Side Current Limit Value</td> <td data-bbox="874 997 1017 1075">×</td> <td data-bbox="1017 997 1187 1075">○</td> <td data-bbox="1187 997 1359 1075">×</td> </tr> <tr> <td data-bbox="586 1075 659 1157">36</td> <td data-bbox="659 1075 874 1157">Minus Side Current Limit Value</td> <td data-bbox="874 1075 1017 1157">×</td> <td data-bbox="1017 1075 1187 1157">×</td> <td data-bbox="1187 1075 1359 1157">○</td> </tr> </tbody> </table> <p>(The figures below show observed waveform in monitor output.)</p>  <p>Note: Motor's maximum current limit value is effective when parameter set value is larger than motor's maximum current limit value. Motor's maximum current limit value is determined by parameter 7 motor code.</p> <p>• By setting b1 = 1, feedforward compensation functions and compensated amount (0 to 100%) set in parameter 37 becomes effective. • When b1 = 0, the feedforward compensation is ineffective. (Parameter 37 set value is ineffective.)</p>	Parameter		CUR Signal Not Turned ON (CUR-H)	CUR Signal ON (CUR-L)		No.	Name		+Side Limit Value (CLP)	-Side Limit Value (CLN)	34	Current Limit Value	○	○	○	35	Plus Side Current Limit Value	×	○	×	36	Minus Side Current Limit Value	×	×	○
Parameter		CUR Signal Not Turned ON (CUR-H)	CUR Signal ON (CUR-L)																								
No.	Name		+Side Limit Value (CLP)	-Side Limit Value (CLN)																							
34	Current Limit Value	○	○	○																							
35	Plus Side Current Limit Value	×	○	×																							
36	Minus Side Current Limit Value	×	×	○																							

8

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents																						
17	b2 2-step Accel/Decel	<p>1-step or 2-step accel/decel is selected.</p> <table border="1" data-bbox="582 346 1256 590"> <thead> <tr> <th rowspan="2">b2 Set Value</th> <th rowspan="2">Accel/Decel Type</th> <th colspan="4">Accel/Decel Setting Parameters</th> </tr> <tr> <th>4</th> <th>5</th> <th>38</th> <th>39</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1-step</td> <td>V</td> <td>T</td> <td>—</td> <td>—</td> </tr> <tr> <td>1</td> <td>2-step</td> <td>V1</td> <td>T1</td> <td>V2</td> <td>T2</td> </tr> </tbody> </table> <p>• 2-step accel/decel type speed setting</p>  <p>Accel/decel speed <math>\alpha 1</math> or <math>\alpha 2</math> is determined by <math>V1/T1</math> or <math>(V1-V2)/T2</math>. It is constant even if feeding speed changes.</p>	b2 Set Value	Accel/Decel Type	Accel/Decel Setting Parameters				4	5	38	39	0	1-step	V	T	—	—	1	2-step	V1	T1	V2	T2
b2 Set Value	Accel/Decel Type	Accel/Decel Setting Parameters																						
		4	5	38	39																			
0	1-step	V	T	—	—																			
1	2-step	V1	T1	V2	T2																			
	b3 Speed Limit	<p>By setting b3 = 1, parameter 46 speed limit value becomes effective.</p> <table border="1" data-bbox="582 1220 1356 1885"> <thead> <tr> <th>b3 Set Value</th> <th>Speed Limit Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td> <p>Max. r/min in motor specifications. (Determined by parameter 7.)</p> <table border="1" data-bbox="1044 1339 1333 1766"> <tr><td>M Series 2000r/min *1</td></tr> <tr><td>F Series 2500r/min</td></tr> <tr><td>G Series 3000r/min</td></tr> <tr><td>D Series 2500r/min</td></tr> <tr><td>S Series 4000r/min</td></tr> <tr><td>R Series 4500r/min *2</td></tr> <tr><td>P Series 4500r/min</td></tr> </table> <p>*1 1500r/min for types USAMED 44B [ ] 2 and USAMKD-60B [ ] 2. *2 4000r/min for 100V (USAREM- [ ] [ ] D [ ] 2)</p> </td> </tr> <tr> <td>1</td> <td>Smaller value (parameter 46 set value or the above motor max. speed)</td> </tr> </tbody> </table>	b3 Set Value	Speed Limit Value	0	<p>Max. r/min in motor specifications. (Determined by parameter 7.)</p> <table border="1" data-bbox="1044 1339 1333 1766"> <tr><td>M Series 2000r/min *1</td></tr> <tr><td>F Series 2500r/min</td></tr> <tr><td>G Series 3000r/min</td></tr> <tr><td>D Series 2500r/min</td></tr> <tr><td>S Series 4000r/min</td></tr> <tr><td>R Series 4500r/min *2</td></tr> <tr><td>P Series 4500r/min</td></tr> </table> <p>*1 1500r/min for types USAMED 44B [ ] 2 and USAMKD-60B [ ] 2. *2 4000r/min for 100V (USAREM- [ ] [ ] D [ ] 2)</p>	M Series 2000r/min *1	F Series 2500r/min	G Series 3000r/min	D Series 2500r/min	S Series 4000r/min	R Series 4500r/min *2	P Series 4500r/min	1	Smaller value (parameter 46 set value or the above motor max. speed)									
b3 Set Value	Speed Limit Value																							
0	<p>Max. r/min in motor specifications. (Determined by parameter 7.)</p> <table border="1" data-bbox="1044 1339 1333 1766"> <tr><td>M Series 2000r/min *1</td></tr> <tr><td>F Series 2500r/min</td></tr> <tr><td>G Series 3000r/min</td></tr> <tr><td>D Series 2500r/min</td></tr> <tr><td>S Series 4000r/min</td></tr> <tr><td>R Series 4500r/min *2</td></tr> <tr><td>P Series 4500r/min</td></tr> </table> <p>*1 1500r/min for types USAMED 44B [ ] 2 and USAMKD-60B [ ] 2. *2 4000r/min for 100V (USAREM- [ ] [ ] D [ ] 2)</p>	M Series 2000r/min *1	F Series 2500r/min	G Series 3000r/min	D Series 2500r/min	S Series 4000r/min	R Series 4500r/min *2	P Series 4500r/min																
M Series 2000r/min *1																								
F Series 2500r/min																								
G Series 3000r/min																								
D Series 2500r/min																								
S Series 4000r/min																								
R Series 4500r/min *2																								
P Series 4500r/min																								
1	Smaller value (parameter 46 set value or the above motor max. speed)																							

(Cont'd)

(Cont'd)

No.	Name	Contents																										
17	b4 Accel/Decel Type Setting	Accel/decel type (linear or exponent) is specified by b4 setting.  < Setting Method > <table border="1"><thead><tr><th>b4 Set Value</th><th>Accel/decel Type</th></tr></thead><tbody><tr><td>0</td><td>1-step or 2-step linear accel/decel and simplified S-curve accel/decel. (Always linear type regardless of operation mode.)</td></tr><tr><td>1</td><td>Set the following parameters according to the accel/decel type in each operation mode: <table border="1"><thead><tr><th>Parameter No.</th><th>Operation Mode</th><th>Linear Accel/Decel or Simplified S-Curve Accel/Decel</th><th>Exponential Accel/Decel</th></tr></thead><tbody><tr><td>68</td><td>Automatic</td><td>1</td><td>0</td></tr><tr><td>69</td><td>Manual</td><td>1</td><td>0</td></tr><tr><td>70</td><td>Pulse command</td><td>1</td><td>0</td></tr><tr><td>71</td><td>Zero-point return (homing)</td><td>1</td><td>0</td></tr></tbody></table></td></tr></tbody></table> <p>Note: Refer to parameters 47 and 48 for exponential accel/decel setting.</p>	b4 Set Value	Accel/decel Type	0	1-step or 2-step linear accel/decel and simplified S-curve accel/decel. (Always linear type regardless of operation mode.)	1	Set the following parameters according to the accel/decel type in each operation mode: <table border="1"><thead><tr><th>Parameter No.</th><th>Operation Mode</th><th>Linear Accel/Decel or Simplified S-Curve Accel/Decel</th><th>Exponential Accel/Decel</th></tr></thead><tbody><tr><td>68</td><td>Automatic</td><td>1</td><td>0</td></tr><tr><td>69</td><td>Manual</td><td>1</td><td>0</td></tr><tr><td>70</td><td>Pulse command</td><td>1</td><td>0</td></tr><tr><td>71</td><td>Zero-point return (homing)</td><td>1</td><td>0</td></tr></tbody></table>	Parameter No.	Operation Mode	Linear Accel/Decel or Simplified S-Curve Accel/Decel	Exponential Accel/Decel	68	Automatic	1	0	69	Manual	1	0	70	Pulse command	1	0	71	Zero-point return (homing)	1	0
b4 Set Value	Accel/decel Type																											
0	1-step or 2-step linear accel/decel and simplified S-curve accel/decel. (Always linear type regardless of operation mode.)																											
1	Set the following parameters according to the accel/decel type in each operation mode: <table border="1"><thead><tr><th>Parameter No.</th><th>Operation Mode</th><th>Linear Accel/Decel or Simplified S-Curve Accel/Decel</th><th>Exponential Accel/Decel</th></tr></thead><tbody><tr><td>68</td><td>Automatic</td><td>1</td><td>0</td></tr><tr><td>69</td><td>Manual</td><td>1</td><td>0</td></tr><tr><td>70</td><td>Pulse command</td><td>1</td><td>0</td></tr><tr><td>71</td><td>Zero-point return (homing)</td><td>1</td><td>0</td></tr></tbody></table>	Parameter No.	Operation Mode	Linear Accel/Decel or Simplified S-Curve Accel/Decel	Exponential Accel/Decel	68	Automatic	1	0	69	Manual	1	0	70	Pulse command	1	0	71	Zero-point return (homing)	1	0							
Parameter No.	Operation Mode	Linear Accel/Decel or Simplified S-Curve Accel/Decel	Exponential Accel/Decel																									
68	Automatic	1	0																									
69	Manual	1	0																									
70	Pulse command	1	0																									
71	Zero-point return (homing)	1	0																									

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents																																																	
18	Function Selection 2	By setting (b4, b3, b2, b1, b0) to "0" or "1", each function can be selected.																																																	
b0	Software overtravel (Position Reference Fault Detection)	<p>(1) Software overtravel function is effective in finite positioning mode while position reference fault detection function is effective in infinite positioning mode.</p> <table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Set Value</th> <th>Remarks</th> <th>Effective Function</th> </tr> </thead> <tbody> <tr> <td rowspan="2">14</td> <td>b1 = 0</td> <td>Finite positioning mode</td> <td>Software overtravel</td> </tr> <tr> <td>b1 = 1</td> <td>Infinite positioning mode</td> <td>Position reference fault detection</td> </tr> </tbody> </table> <p>(2)</p> <table border="1"> <thead> <tr> <th rowspan="2">b0 Set Value</th> <th colspan="2">Software Overtravel Set Position</th> </tr> <tr> <th>Plus Side (+LS)</th> <th>Minus Side (-LS)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>+99999999</td> <td>-99999999</td> </tr> <tr> <td>1</td> <td>(Parameter 40) set value</td> <td>(Parameter 41) set value</td> </tr> </tbody> </table> <p>Note: When incremental encoder is used (Parameter 9 = 1), software overtravel becomes effective after zero-point return (homing).</p> <p>(3)</p> <table border="1"> <thead> <tr> <th rowspan="2">b0 Set Value</th> <th colspan="2">Position Reference Range (Limit Value)</th> </tr> <tr> <th>Plus Side</th> <th>Minus Side</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>+99999999</td> <td>-99999999</td> </tr> <tr> <td>1</td> <td>(Parameter 40) set value</td> <td>(Parameter 41) set value</td> </tr> </tbody> </table> <p>(4) Finite positioning mode By software overtravel detection, operation is prohibited and</p> <ul style="list-style-type: none"> <li>• Error signal ERR is output.</li> <li>• <b>ERR OV</b> is automatically sent from Servopack in serial communication. (For only one-axis)</li> </ul> <p>Detecting operation differs as follows depending on operation mode.</p> <table border="1"> <thead> <tr> <th>Operation Mode</th> <th>Detecting Operation</th> </tr> </thead> <tbody> <tr> <td>Automatic</td> <td>When position data exceed software overtravel set value, detection is performed at turning on start signal AST or command <b>ST</b>.</td> </tr> <tr> <td>Manual</td> <td rowspan="2">When software overtravel set position is passed during operation, the operation stops at the position at a specified deceleration.</td> </tr> <tr> <td>Pulse</td> </tr> <tr> <td>Non-current conduction</td> <td>Detects when present position is out of software overtravel set position.</td> </tr> </tbody> </table> <p>(5) Infinite positioning mode When position reference value is out of the following range in the automatic operation mode, position reference fault error (alarm code output ALO = 0, AL1 = 0, AL2 = 1, AL3 = 0) occurs.      (Parameter 41) set value <math>\leq</math> position reference value <math>\leq</math> (Parameter 40) set value      (Example) Parameter 14 b1 = 1: Infinite positioning mode                        b3 = 1: Incremental reference                        Parameter 15 = 1 : DG-SW reference method                        Parameter 18 b0 = 1: Parameters 40 and 41 are effective.                        Parameter 40 = 5000                        Parameter 41 = 0</p> <p>When the parameters are set as shown above, by setting the digital switch to the following values and inputting the start signal:</p> <table> <tr> <td>Set value</td> <td></td> </tr> <tr> <td>+48000</td> <td>: Move to the plus side by 48000.</td> </tr> <tr> <td>+52000</td> <td rowspan="2">: Does not start because of position reference fault.</td> </tr> <tr> <td>- 2000</td> </tr> </table>	Parameter No.	Set Value	Remarks	Effective Function	14	b1 = 0	Finite positioning mode	Software overtravel	b1 = 1	Infinite positioning mode	Position reference fault detection	b0 Set Value	Software Overtravel Set Position		Plus Side (+LS)	Minus Side (-LS)	0	+99999999	-99999999	1	(Parameter 40) set value	(Parameter 41) set value	b0 Set Value	Position Reference Range (Limit Value)		Plus Side	Minus Side	0	+99999999	-99999999	1	(Parameter 40) set value	(Parameter 41) set value	Operation Mode	Detecting Operation	Automatic	When position data exceed software overtravel set value, detection is performed at turning on start signal AST or command <b>ST</b> .	Manual	When software overtravel set position is passed during operation, the operation stops at the position at a specified deceleration.	Pulse	Non-current conduction	Detects when present position is out of software overtravel set position.	Set value		+48000	: Move to the plus side by 48000.	+52000	: Does not start because of position reference fault.	- 2000
Parameter No.	Set Value	Remarks	Effective Function																																																
14	b1 = 0	Finite positioning mode	Software overtravel																																																
	b1 = 1	Infinite positioning mode	Position reference fault detection																																																
b0 Set Value	Software Overtravel Set Position																																																		
	Plus Side (+LS)	Minus Side (-LS)																																																	
0	+99999999	-99999999																																																	
1	(Parameter 40) set value	(Parameter 41) set value																																																	
b0 Set Value	Position Reference Range (Limit Value)																																																		
	Plus Side	Minus Side																																																	
0	+99999999	-99999999																																																	
1	(Parameter 40) set value	(Parameter 41) set value																																																	
Operation Mode	Detecting Operation																																																		
Automatic	When position data exceed software overtravel set value, detection is performed at turning on start signal AST or command <b>ST</b> .																																																		
Manual	When software overtravel set position is passed during operation, the operation stops at the position at a specified deceleration.																																																		
Pulse																																																			
Non-current conduction	Detects when present position is out of software overtravel set position.																																																		
Set value																																																			
+48000	: Move to the plus side by 48000.																																																		
+52000	: Does not start because of position reference fault.																																																		
- 2000																																																			

(Cont'd)

(Cont'd)

No.	Name	Contents																																				
18	b1 Backlash Compensation	Sets whether backlash compensation function is provided or not. <table border="1"><thead><tr><th>b1 Set Value</th><th>Backlash Compensation</th></tr></thead><tbody><tr><td>0</td><td>Not provided</td></tr><tr><td>1</td><td>Compensated amount is (parameter 42) set value.</td></tr></tbody></table>	b1 Set Value	Backlash Compensation	0	Not provided	1	Compensated amount is (parameter 42) set value.																														
	b1 Set Value	Backlash Compensation																																				
0	Not provided																																					
1	Compensated amount is (parameter 42) set value.																																					
b2	Speed Reference in Auto Operation Mode	Selects speed reference setter in automatic operation mode. <table border="1"><thead><tr><th rowspan="2">b2 Set Value</th><th colspan="4">Parameter 15 Setting (Position Reference Method)</th></tr><tr><th>0</th><th>1</th><th>2</th><th>4</th></tr></thead><tbody><tr><td></td><td>Station No.</td><td>DG-SW</td><td>Serial Communication</td><td>Command table</td></tr><tr><td>0</td><td>Selected by parameter at contact.</td><td>DG-SW</td><td>Serial command (SPD×××)</td><td>Speed table</td></tr><tr><td>1</td><td colspan="4">Speed reference setter can be selected regardless of position reference method. <table border="1"><thead><tr><th>Parameter No.</th><th>Set Value</th><th>Speed Reference Setter</th></tr></thead><tbody><tr><td rowspan="4">61</td><td>0</td><td>Selected by parameter at contact</td></tr><tr><td>1</td><td>DG-SW</td></tr><tr><td>2</td><td>Serial command</td></tr><tr><td>4</td><td>Speed table</td></tr></tbody></table></td></tr></tbody></table>	b2 Set Value	Parameter 15 Setting (Position Reference Method)				0	1	2	4		Station No.	DG-SW	Serial Communication	Command table	0	Selected by parameter at contact.	DG-SW	Serial command (SPD×××)	Speed table	1	Speed reference setter can be selected regardless of position reference method. <table border="1"><thead><tr><th>Parameter No.</th><th>Set Value</th><th>Speed Reference Setter</th></tr></thead><tbody><tr><td rowspan="4">61</td><td>0</td><td>Selected by parameter at contact</td></tr><tr><td>1</td><td>DG-SW</td></tr><tr><td>2</td><td>Serial command</td></tr><tr><td>4</td><td>Speed table</td></tr></tbody></table>				Parameter No.	Set Value	Speed Reference Setter	61	0	Selected by parameter at contact	1	DG-SW	2	Serial command	4	Speed table
b2 Set Value	Parameter 15 Setting (Position Reference Method)																																					
	0	1	2	4																																		
	Station No.	DG-SW	Serial Communication	Command table																																		
0	Selected by parameter at contact.	DG-SW	Serial command (SPD×××)	Speed table																																		
1	Speed reference setter can be selected regardless of position reference method. <table border="1"><thead><tr><th>Parameter No.</th><th>Set Value</th><th>Speed Reference Setter</th></tr></thead><tbody><tr><td rowspan="4">61</td><td>0</td><td>Selected by parameter at contact</td></tr><tr><td>1</td><td>DG-SW</td></tr><tr><td>2</td><td>Serial command</td></tr><tr><td>4</td><td>Speed table</td></tr></tbody></table>				Parameter No.	Set Value	Speed Reference Setter	61	0	Selected by parameter at contact	1	DG-SW	2	Serial command	4	Speed table																						
Parameter No.	Set Value	Speed Reference Setter																																				
61	0	Selected by parameter at contact																																				
	1	DG-SW																																				
	2	Serial command																																				
	4	Speed table																																				

Note: "Selected by parameter at contact" means to select parameter setting (1st speed) to (4th speed) by speed select signals SP2ND and SP3RD. Refer to the description of parameter 4.

(Cont'd)

8

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents																																									
18	b3 Speed Reference in Manual Operation Mode	<p>Selects speed reference setter in manual operation mode.</p> <table border="1"> <thead> <tr> <th rowspan="2">b3 Set Value</th> <th colspan="4">Parameter 15 setting (Position Reference Method)</th> </tr> <tr> <th>0</th> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td></td> <td>Station No.</td> <td>DG-SW</td> <td>Serial Communication</td> <td>Command table</td> </tr> <tr> <td>0</td> <td>Selected by parameter at contact.</td> <td>DG-SW</td> <td>Serial command (SPD×××)</td> <td>Speed table</td> </tr> <tr> <td>1</td> <td colspan="4">Speed reference setter can be selected regardless of position reference method.</td> </tr> <tr> <td></td> <td colspan="4"> <table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Set Value</th> <th>Speed Reference Setter.</th> </tr> </thead> <tbody> <tr> <td rowspan="4">62</td> <td>0</td> <td>Selected by parameter at contact</td> </tr> <tr> <td>1</td> <td>DG-SW</td> </tr> <tr> <td>2</td> <td>Serial command</td> </tr> <tr> <td>4</td> <td>Speed table</td> </tr> </tbody> </table> </td> </tr> </tbody> </table> <p>Note: "Selected by parameter at contact" means to select parameter setting (1st speed) to (4th speed) by speed select signals <math>\overline{SP2ND}</math> and <math>\overline{SP3RD}</math>. Refer to the description of parameter 4.</p>	b3 Set Value	Parameter 15 setting (Position Reference Method)				0	1	2	4		Station No.	DG-SW	Serial Communication	Command table	0	Selected by parameter at contact.	DG-SW	Serial command (SPD×××)	Speed table	1	Speed reference setter can be selected regardless of position reference method.					<table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Set Value</th> <th>Speed Reference Setter.</th> </tr> </thead> <tbody> <tr> <td rowspan="4">62</td> <td>0</td> <td>Selected by parameter at contact</td> </tr> <tr> <td>1</td> <td>DG-SW</td> </tr> <tr> <td>2</td> <td>Serial command</td> </tr> <tr> <td>4</td> <td>Speed table</td> </tr> </tbody> </table>				Parameter No.	Set Value	Speed Reference Setter.	62	0	Selected by parameter at contact	1	DG-SW	2	Serial command	4	Speed table
	b3 Set Value	Parameter 15 setting (Position Reference Method)																																									
0		1	2	4																																							
	Station No.	DG-SW	Serial Communication	Command table																																							
0	Selected by parameter at contact.	DG-SW	Serial command (SPD×××)	Speed table																																							
1	Speed reference setter can be selected regardless of position reference method.																																										
	<table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Set Value</th> <th>Speed Reference Setter.</th> </tr> </thead> <tbody> <tr> <td rowspan="4">62</td> <td>0</td> <td>Selected by parameter at contact</td> </tr> <tr> <td>1</td> <td>DG-SW</td> </tr> <tr> <td>2</td> <td>Serial command</td> </tr> <tr> <td>4</td> <td>Speed table</td> </tr> </tbody> </table>				Parameter No.	Set Value	Speed Reference Setter.	62	0	Selected by parameter at contact	1	DG-SW	2	Serial command	4	Speed table																											
Parameter No.	Set Value	Speed Reference Setter.																																									
62	0	Selected by parameter at contact																																									
	1	DG-SW																																									
	2	Serial command																																									
	4	Speed table																																									
b4 Zero-point Return (Homing)	<p>Set b4 = 1 so that parameters 49 to 54 required for operation in zero-point return mode (refer to Par. 6.2.3 (1) (d) ) will be effective.</p> <table border="1"> <thead> <tr> <th>b4 Set Value</th> <th>Operation in Zero-point Return Mode</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not : Parameters 49 to 54 setting are ineffective</td> </tr> <tr> <td>1</td> <td>Perform : Parameters 49 to 54 setting are effective</td> </tr> </tbody> </table>	b4 Set Value	Operation in Zero-point Return Mode	0	Not : Parameters 49 to 54 setting are ineffective	1	Perform : Parameters 49 to 54 setting are effective																																				
b4 Set Value	Operation in Zero-point Return Mode																																										
0	Not : Parameters 49 to 54 setting are ineffective																																										
1	Perform : Parameters 49 to 54 setting are effective																																										
19	Function Selection 3	<p>By setting (b7, b6, b4, b3, b2, b1, b0) to "0" or "1", each function can be selected.</p>																																									
	b0 OT Signal	<p>Enables or disables overtravel LS input signals P-OT and N-OT.</p> <table border="1"> <thead> <tr> <th>b0 Set Value</th> <th>P-OT and N-OT Signals</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Used (Closed input at normal operation)</td> </tr> <tr> <td>1</td> <td>Not used (Input can be opened.)</td> </tr> </tbody> </table>	b0 Set Value	P-OT and N-OT Signals	0	Used (Closed input at normal operation)	1	Not used (Input can be opened.)																																			
b0 Set Value	P-OT and N-OT Signals																																										
0	Used (Closed input at normal operation)																																										
1	Not used (Input can be opened.)																																										

(Cont'd)




(Cont'd)

No.	Name	Contents																																								
19	b1 STOP Signal	<p>Enables or disables STOP signal operation. To perform automatic operation in serial communication, set b1 = 1. If STOP signal input (2CN-15) remains open, <b>ST</b> command becomes <b>ERR SN</b></p> <table border="1"> <thead> <tr> <th>b1 Set Value</th> <th>STOP Signal</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Used (Closed input at operation.)</td> </tr> <tr> <td>1</td> <td>Not used (Input can be opened.)</td> </tr> </tbody> </table>	b1 Set Value	STOP Signal	0	Used (Closed input at operation.)	1	Not used (Input can be opened.)																																		
	b1 Set Value	STOP Signal																																								
	0	Used (Closed input at operation.)																																								
1	Not used (Input can be opened.)																																									
b2 Brake Release Signal	<p>Set b2 = 1 so that parameter 43 and 44 required for brake release signal output <math>\overline{BK}</math> (refer to Par. 6.3.2 (2)) operation will be effective.</p> <table border="1"> <thead> <tr> <th>b2 Set Value</th> <th><math>\overline{BK}</math> Signal</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not used (Parameters 43, and 44 setting are ineffective)</td> </tr> <tr> <td>1</td> <td>Used (Parameters 43, and 44 setting are effective)</td> </tr> </tbody> </table>	b2 Set Value	$\overline{BK}$ Signal	0	Not used (Parameters 43, and 44 setting are ineffective)	1	Used (Parameters 43, and 44 setting are effective)																																			
b2 Set Value	$\overline{BK}$ Signal																																									
0	Not used (Parameters 43, and 44 setting are ineffective)																																									
1	Used (Parameters 43, and 44 setting are effective)																																									
b3 Pulse Reference Input	<p>Set together with parameter 63 according to input pulse signal form in pulse train operation mode.</p> <table border="1"> <thead> <tr> <th rowspan="2">Signal Form</th> <th colspan="2">Parameter No.</th> <th rowspan="2">Signal Name</th> <th colspan="2">Pulse Waveform</th> </tr> <tr> <th>63</th> <th>19 b3</th> <th>Plus Side Reference</th> <th>Minus Side Reference</th> </tr> </thead> <tbody> <tr> <td rowspan="3">90° phase difference 2-phase pulse train</td> <td>×4</td> <td>0</td> <td>0</td> <td rowspan="3"> </td> <td rowspan="3"> </td> </tr> <tr> <td>×2</td> <td>1</td> <td rowspan="2">1</td> <td rowspan="2"> </td> <td rowspan="2"> </td> </tr> <tr> <td>×1</td> <td>2</td> </tr> <tr> <td rowspan="2">Sign + pulse train</td> <td rowspan="2">3</td> <td rowspan="2">1</td> <td>CA</td> <td> </td> <td> </td> </tr> <tr> <td>CB</td> <td> </td> <td> </td> </tr> <tr> <td rowspan="2">CCW + CW pulse train</td> <td rowspan="2">4</td> <td rowspan="2">1</td> <td>CA</td> <td> </td> <td> </td> </tr> <tr> <td>CB</td> <td> </td> <td> </td> </tr> </tbody> </table>	Signal Form	Parameter No.		Signal Name	Pulse Waveform		63	19 b3	Plus Side Reference	Minus Side Reference	90° phase difference 2-phase pulse train	×4	0	0			×2	1	1			×1	2	Sign + pulse train	3	1	CA			CB			CCW + CW pulse train	4	1	CA			CB		
Signal Form	Parameter No.		Signal Name	Pulse Waveform																																						
	63	19 b3		Plus Side Reference	Minus Side Reference																																					
90° phase difference 2-phase pulse train	×4	0	0																																							
	×2	1	1																																							
	×1	2																																								
Sign + pulse train	3	1	CA																																							
			CB																																							
CCW + CW pulse train	4	1	CA																																							
			CB																																							

8






(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents											
19	b4 Pulse Output	<p>PG dividing output signal (FA, FB) dividing ratio. (Refer to Fig. 5.12.)</p> <table border="1"> <thead> <tr> <th>b4 Set Value</th> <th>Parameter 64</th> <th>Dividing Ratio</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>—</td> <td>1</td> </tr> <tr> <td>1</td> <td>N(N-2 to 64)</td> <td>2/N</td> </tr> </tbody> </table>	b4 Set Value	Parameter 64	Dividing Ratio	0	—	1	1	N(N-2 to 64)	2/N		
	b4 Set Value	Parameter 64	Dividing Ratio										
	0	—	1										
1	N(N-2 to 64)	2/N											
b5 Positioning Near Signal and Station Near Signal	<p>For station near signal, refer to the description of parameter 65 b1. Set b5 = 1 so that (parameter 45) required for positioning near signal NEAR operation will be effective.</p> <table border="1"> <thead> <tr> <th>b5 Set Value</th> <th>Positioning Near Signal</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Does not operate. (Parameter 45 setting is ineffective.)</td> </tr> <tr> <td>1</td> <td>When distance difference (reference unit) between current position and aimed position is less than the value set by parameter 45, NEAR signal is output. (In serial communication, NEAR is automatically sent.)</td> </tr> </tbody> </table>	b5 Set Value	Positioning Near Signal	0	Does not operate. (Parameter 45 setting is ineffective.)	1	When distance difference (reference unit) between current position and aimed position is less than the value set by parameter 45, NEAR signal is output. (In serial communication, NEAR is automatically sent.)						
b5 Set Value	Positioning Near Signal												
0	Does not operate. (Parameter 45 setting is ineffective.)												
1	When distance difference (reference unit) between current position and aimed position is less than the value set by parameter 45, NEAR signal is output. (In serial communication, NEAR is automatically sent.)												
b6 OT Signal Switching	<p>Function can be inverted without switching P-OT and N-OT signals.</p>  <table border="1"> <thead> <tr> <th>b6 Set Value</th> <th>1LS</th> <th>2LS</th> <th></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>N-OT</td> <td>P-OT</td> <td>(Standard)</td> </tr> <tr> <td>1</td> <td>P-OT</td> <td>N-OT</td> <td></td> </tr> </tbody> </table> <p>P-OT: Stops + direction reference N-OT: Stops - direction reference</p>	b6 Set Value	1LS	2LS		0	N-OT	P-OT	(Standard)	1	P-OT	N-OT	
b6 Set Value	1LS	2LS											
0	N-OT	P-OT	(Standard)										
1	P-OT	N-OT											
b7 Torque Reference Filter Time Constant Change	<p>b7 = 1 when the function of parameter 90 which sets torque reference filter time constant to prevent shaft oscillation is to be effective; b7 = 0 when ineffective.</p> <table border="1"> <thead> <tr> <th>b7 Set Value</th> <th>Torque Reference Filter Time Constant</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0.45ms</td> </tr> <tr> <td>1</td> <td>Value set by parameter 90</td> </tr> </tbody> </table>	b7 Set Value	Torque Reference Filter Time Constant	0	0.45ms	1	Value set by parameter 90						
b7 Set Value	Torque Reference Filter Time Constant												
0	0.45ms												
1	Value set by parameter 90												

(Cont'd)

(Cont'd)

No.	Name	Contents					
20	Function Selection 4	By setting (b6, b5, b4, b3, b2, b1, b0) to "0" or "1", each function can be selected.					
	b0	(Always set to 0.)					
	b1 External Position Indicator	When used by connecting to external position indicator (MCIF-L8 type), set to b1 = 1. Decimal position of the external position indicator is selected by parameter 67.					
	b2 Station No. 0	In the station No. reference method (parameter 15 setting = 0), the number of stations N is set by parameter 16 and how to take the station No. is set by b2.  <table border="1"> <tr> <td>b2 Set Value</td> <td>0</td> <td>1</td> </tr> <tr> <td>How to Take Station No.</td> <td>Station No. 0 Provided </td> <td>Station No. 0 Not Provided </td> </tr> </table>	b2 Set Value	0	1	How to Take Station No.	Station No. 0 Provided 
b2 Set Value	0	1					
How to Take Station No.	Station No. 0 Provided 	Station No. 0 Not Provided 					
b3 Simplified S-curve Accel/Decel	Selects whether simplified S-curve accel/decel is used or not.  <table border="1"> <tr> <td>b3 Set Value</td> <td>Simplified S-curve Accel/Decel</td> </tr> <tr> <td>0</td> <td>Not used: Parameter 76 setting ineffective</td> </tr> <tr> <td>1</td> <td>Used : Parameter 76 setting effective</td> </tr> </table>	b3 Set Value	Simplified S-curve Accel/Decel	0	Not used: Parameter 76 setting ineffective	1	Used : Parameter 76 setting effective
b3 Set Value	Simplified S-curve Accel/Decel						
0	Not used: Parameter 76 setting ineffective						
1	Used : Parameter 76 setting effective						
b4 Function Selection 7 Setting (Related to Parameter 72)	Set to 1 when parameter 72 function is to be effective. (Normally set to 0.)  <table border="1"> <tr> <td>b4 Set Value</td> <td>Parameter 72 Setting Contents</td> </tr> <tr> <td>1</td> <td>Effective</td> </tr> <tr> <td>0</td> <td>Same function as parameter 72 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0 or b5 = 0 setting.</td> </tr> </table>	b4 Set Value	Parameter 72 Setting Contents	1	Effective	0	Same function as parameter 72 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0 or b5 = 0 setting.
b4 Set Value	Parameter 72 Setting Contents						
1	Effective						
0	Same function as parameter 72 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0 or b5 = 0 setting.						
b5 Function Selection 5 Setting (Related to Parameter 65)	Set to 1 when parameter 65 function is to be effective. (Normally set to 0.)  <table border="1"> <tr> <td>b5 Set Value</td> <td>Parameter 65 Setting Contents</td> </tr> <tr> <td>1</td> <td>Effective</td> </tr> <tr> <td>0</td> <td>Same function as parameter 65 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0 or b6 = 0 setting.</td> </tr> </table>	b5 Set Value	Parameter 65 Setting Contents	1	Effective	0	Same function as parameter 65 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0 or b6 = 0 setting.
b5 Set Value	Parameter 65 Setting Contents						
1	Effective						
0	Same function as parameter 65 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0 or b6 = 0 setting.						
b6 Function Selection 6 Setting (Related to Parameter 66)	Set to 1 when parameter 66 function is to be effective. (Normally set to 0.)  <table border="1"> <tr> <td>b5 Set Value</td> <td>Parameter 66 Setting Contents</td> </tr> <tr> <td>1</td> <td>Effective</td> </tr> <tr> <td>0</td> <td>Same function as parameter 66 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0, b6 = 0 or b7 = 0 setting.</td> </tr> </table>	b5 Set Value	Parameter 66 Setting Contents	1	Effective	0	Same function as parameter 66 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0, b6 = 0 or b7 = 0 setting.
b5 Set Value	Parameter 66 Setting Contents						
1	Effective						
0	Same function as parameter 66 b0 = 0, b1 = 0, b2 = 0, b3 = 0, b4 = 0, b5 = 0, b6 = 0 or b7 = 0 setting.						

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)



No.	Name	Contents																
31	2nd Feeding Speed	Effective in mode selected by parameter at contact	Speed reference value selected by speed select signal SP2ND or SP3RD. (selected by parameter at contact.)															
32	3rd Feeding Speed		<table border="1"> <tr> <td></td> <td>4 (1st Feeding Speed)</td> <td>31</td> <td>32</td> <td>33</td> </tr> <tr> <td>SP2ND</td> <td>H</td> <td>L</td> <td>H</td> <td>L</td> </tr> <tr> <td>SP3RD</td> <td>H</td> <td>H</td> <td>L</td> <td>L</td> </tr> </table>		4 (1st Feeding Speed)	31	32	33	SP2ND	H	L	H	L	SP3RD	H	H	L	L
	4 (1st Feeding Speed)		31	32	33													
SP2ND	H	L	H	L														
SP3RD	H	H	L	L														
33	4th Feeding Speed	Setting range: 1 to 240000 Unit: ×1000 reference units/min																
34	Current Limit Value	Effective by parameter 17 b0 = 1	Current limit value in plus/minus direction. Current limit works regardless of current limit signal CUR. Setting range: 0 to 400 Unit: %															
35	Plus Side Current Limit Value		Limit plus side current (activation current at motor FWD run)															
36	Minus Side Current Limit Value		Limit minus side current (activation current at motor REV run) (The smaller value between parameter set value and motor maximum current limit value becomes effective.)															
37	Feedforward Compensation Amount	Feedforward compensation amount becomes effective by parameter 17 b1 = 1. Setting range: 0 to 100, unit: %																
38	Linear Accel/Decel Time 2	Parameter to determine accel/decel speed at the second step in 2-step linear accel/decel type. In 2-step linear accel/decel, linear accel/decel type is selected by parameter 17 b4 and becomes effective by parameter 17 b2 = 1 setting.																
39	2-step Linear Accel/Decel Accel Speed Switching Speed	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Range</th> <th>Unit</th> </tr> </thead> <tbody> <tr> <td>38</td> <td>8 to 60000</td> <td>ms</td> </tr> <tr> <td>39</td> <td>0 to 240000</td> <td>×1000 reference units/min</td> </tr> </tbody> </table>		Parameter	Range	Unit	38	8 to 60000	ms	39	0 to 240000	×1000 reference units/min						
Parameter	Range	Unit																
38	8 to 60000	ms																
39	0 to 240000	×1000 reference units/min																

(Cont'd)

No.	Name	Contents	
40	Plus Side Software Overtravel (Plus Side Position Reference Fault Detection Value)	<p>(1) Parameter 14 b1 = 0 (finite positioning mode) Effective by parameter 18 b0 = 1 setting.</p> <p style="text-align: center;">-LS                      +LS</p> <p style="text-align: center;">-                      ▽                      ▽                      +</p> <p style="text-align: center;">-----&gt; POSITION</p> <p style="text-align: center;">(PROHIBIT)                      MOVING AREA                      (PROHIBIT)</p>	<p>(1) Parameter 14 b1 = 0 (finite positioning mode) Prohibits moving in + direction by set value.</p> <p>(2) Parameter 14 b1 = 1 (infinite positioning mode) A position reference value exceeding the set value results in a position reference fault error.</p>
41	Minus Side Software Overtravel (Minus Side Position Reference Fault Detection Value)	<p>Range: <math>\pm 99999999</math> Unit: Reference unit Note: When incremental encoder is used (Parameter 9 = 1), software overtravel becomes effective after zero-point return (homing).</p> <p>(2) Parameter 14 b1 = 1 (infinite positioning mode) Effective by parameter 18 b0 = 1 setting. When the position reference value is out of the following range in the automatic operation, a position reference fault error occurs. [Parameter 41] set value <math>\leq</math> position reference value <math>\leq</math> [Parameter 40] set value</p>	<p>(1) Parameter 14 b1 = 0 (finite positioning mode) Prohibits moving in - direction by set value.</p> <p>(2) Parameter 14 b1 = 1 (infinite positioning mode) A position reference value exceeding the set value results in a position reference fault error.</p>
42	Backlash Compensation Amount	<p>Effective by parameter 18 b2 = 1 setting.</p> <p>Setting range: 1 to <math>\pm 30000</math> Unit: Pulse (feedback pulse from encoder)</p> <p>[Relation between reference unit and pulse is indicated by B/A (refer to parameter 13.) ]</p>	
43	Brake Time	Effective by parameter 19 b2 = 1.	Setting range: 8 to 1000 Unit: ms
44	Brake ON Motor Speed	Refer to par. 6.3.2 (2) for operation.	Setting range: 1 to 10000 Unit: r/min (motor speed)
45	Positioning Near Range and Station Near Range	<p>Effective by parameter 19 b5 = 1.</p> <p>Setting range: 0 to 30000 Unit: Reference unit</p> <p>(Station near range when parameter 20 b5 = 1 or parameter 65 b1 = 1)</p>	
46	Speed Limit Value	<p>Effective by parameter 17 b3 = 1. Set value becomes load maximum speed.</p> <p>Set value: 1 to 240000 Unit: <math>\times 1000</math> reference unit/min</p>	

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Contents					
47	Exponential Accel/Decel Time Constant	<p>Accel/decel speed varies depending on set speed.</p>  <p>PARAMETER 47 (EXPONENTIAL ACCEL/DECCEL TIME CONSTANT)</p> <p>Exponential accel/decel becomes effective in a specified operation mode when exponential accel/decel type is set by parameter 17 b4 = 1 and parameters 68 to 71.</p>					
48	Exponential Accel/Decel Bias Speed	 <p>EXPONENTIAL ACCEL/DECCEL TIME CONSTANT (RANGE: 8 TO 1000, UNIT: ms)</p> <p>EXPONENTIAL ACCEL/DECCEL BIAS SPEED (RANGE: 0 TO 240000, UNIT: 1000 REFERENCE UNIT/MIN)</p>					
49	Zero-point Return (Homing) Mode	<table border="1"> <tr> <td>0</td> <td>Zero-point return mode I (Decel LS and Cφ pulse used)</td> </tr> <tr> <td>1</td> <td>Zero-point return mode II (STP signal used)</td> </tr> </table>	0	Zero-point return mode I (Decel LS and Cφ pulse used)	1	Zero-point return mode II (STP signal used)	
0	Zero-point return mode I (Decel LS and Cφ pulse used)						
1	Zero-point return mode II (STP signal used)						
50	Zero-point Return Direction	<table border="1"> <tr> <td>0</td> <td>Zero-point return toward plus direction</td> </tr> <tr> <td>1</td> <td>Zero-point return toward minus direction</td> </tr> </table>	0	Zero-point return toward plus direction	1	Zero-point return toward minus direction	
0	Zero-point return toward plus direction						
1	Zero-point return toward minus direction						
51	Zero-point Return Feeding Speed	<p>Effective by parameter 18 14b = 1</p> <p>Setting range: 0 to 240000 Unit: ×1000 reference unit/min</p>					
52	Zero-point Return Approach Speed						
53	Zero-point Return Creep Speed						
54	Zero-point Return Final Traveling Distance						
		<table border="1"> <thead> <tr> <th>Setting Range</th> <th>Unit</th> </tr> </thead> <tbody> <tr> <td>Plus direction: 0 to 99999999</td> <td rowspan="2">Reference unit</td> </tr> <tr> <td>Minus direction: -99999999 to 0</td> </tr> </tbody> </table>	Setting Range	Unit	Plus direction: 0 to 99999999	Reference unit	Minus direction: -99999999 to 0
Setting Range	Unit						
Plus direction: 0 to 99999999	Reference unit						
Minus direction: -99999999 to 0							

(Cont'd)

No.	Name		Conditioning Parameter		Contents		
			No.	Set Value			
61	Feed Speed Setting Method in Auto Operation Mode		18 b2	1	0	Selected by parameter at contact	
					1	DG-SW	
					2	Serial command	
					4	Speed table	
62	Feed Speed Setting Method in Manual Operation Mode		18 b3	1	0	Selected by parameter at contact	
					1	DG-SW	
					2	Serial command	
					4	Speed table	
63	Pulse Signal Form		19 b3	1	0	×4	
					1	90° phase difference 2-phase pulse	×2
					2		×1
					3	Sign + pulse train	
					4	CCW + CW pulse train	
64	Output Pulse Dividing Ratio		19 b4	1	Dividing ratio is 2/N when parameter set value is N (2 to 64)		
65	Function Selection 5		20 b5	1	By setting (b3, b2, b1, b0) to "0" or "1", each function can be selected.		
	b0	Zone Signal			Set b0 = 1 when outputs of $\overline{P0}$ to $\overline{P4}$ are used as zone signals.		
	<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th>b0 Set Value</th> <th>Zone Signal</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not Used</td> </tr> <tr> <td>1</td> <td>Used</td> </tr> </tbody> </table>				b0 Set Value	Zone Signal	0
b0 Set Value	Zone Signal						
0	Not Used						
1	Used						
b1	Station Near Signal	Set to b1 = 1 so that $\overline{NEAR}$ signal can function as station near signal. ( $\overline{NEAR}$ signal does not operate unless setting to parameter 19 b5 = 1.)					
<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th>b1 Set Value</th> <th><math>\overline{NEAR}</math> Signal</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Operates as positioning near signal.</td> </tr> <tr> <td>1</td> <td>In the station No. reference method (parameter 15 setting = 0), if distance difference (reference unit) between the current position and the nearest station position to the current position becomes less than the value set by parameter 45, <math>\overline{NEAR}</math> signal is output. (In serial communication, <math>\overline{NEAR}</math> is automatically sent.)</td> </tr> </tbody> </table> <p>Note: In this case, <math>\overline{NEAR}</math> signal output lag time is up to 40ms.</p>		b1 Set Value	$\overline{NEAR}$ Signal	0	Operates as positioning near signal.	1	In the station No. reference method (parameter 15 setting = 0), if distance difference (reference unit) between the current position and the nearest station position to the current position becomes less than the value set by parameter 45, $\overline{NEAR}$ signal is output. (In serial communication, $\overline{NEAR}$ is automatically sent.)
b1 Set Value	$\overline{NEAR}$ Signal						
0	Operates as positioning near signal.						
1	In the station No. reference method (parameter 15 setting = 0), if distance difference (reference unit) between the current position and the nearest station position to the current position becomes less than the value set by parameter 45, $\overline{NEAR}$ signal is output. (In serial communication, $\overline{NEAR}$ is automatically sent.)						

(Parameter setting becomes effective by conditioning parameter setting.)

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Conditioning Parameter		Contents							
		No.	Set Value								
65	b2	DG-SW Read-in Time Change	20 b5	1	<p>Set to b2 = 1 when DG-SW read-in time (data strobe output pulse width) is required to change in DG-SW reference method (parameter 15 setting = 1).</p> <table border="1"> <thead> <tr> <th>b2 Set Value</th> <th>DG-SW Read-in Time (Data Strobe Output Pulse Width)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>24ms</td> </tr> <tr> <td>1</td> <td>Parameter 77 set value</td> </tr> </tbody> </table> <p>When YASKAWA digital unit is used, it is not necessary to change DG-SW read-in time.</p>	b2 Set Value	DG-SW Read-in Time (Data Strobe Output Pulse Width)	0	24ms	1	Parameter 77 set value
	b2 Set Value	DG-SW Read-in Time (Data Strobe Output Pulse Width)									
	0	24ms									
	1	Parameter 77 set value									
	b3	DG-SW Shift Digit Number				<p>Set to b3 = 1 when position or speed input is multiplied by 10, 100, etc. in DG-SW reference method (parameter 15 setting = 1).</p> <p>Number of digits to be shifted is set by parameter 67.</p>					
b4					(Normally set to 0.)						
b5					(Normally set to 0.)						
b6	Position Completion Signal Change				<p>Set to b6 = 1 to change the specifications of positioning completion signal (COIN, 5CN-5).</p> <table border="1"> <thead> <tr> <th>b6 Set Value</th> <th>Specifications of Positioning Completion Signal (COIN Signal)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ON when reference is not being discharged and position error is smaller than parameter 6. OFF while start command input signal (AST) is ON and until zero-point return is completed in the zero-point return (homing) mode. (Normal specifications)</td> </tr> <tr> <td>1</td> <td> <p>OFF when power supply is turned ON.</p> <p>ON when operation is started in automatic operation mode and positioning is completed normally (reference discharge is completed and position error becomes smaller than parameter 6 set value.)</p> <p>Also OFF in the following cases:</p> <ul style="list-style-type: none"> <li>• Starting again in automatic operation mode</li> <li>• In baseblock status</li> <li>• Changing mode</li> <li>• At overtravel</li> <li>• While start command input signal is ON</li> </ul> </td> </tr> </tbody> </table>	b6 Set Value	Specifications of Positioning Completion Signal (COIN Signal)	0	ON when reference is not being discharged and position error is smaller than parameter 6. OFF while start command input signal (AST) is ON and until zero-point return is completed in the zero-point return (homing) mode. (Normal specifications)	1	<p>OFF when power supply is turned ON.</p> <p>ON when operation is started in automatic operation mode and positioning is completed normally (reference discharge is completed and position error becomes smaller than parameter 6 set value.)</p> <p>Also OFF in the following cases:</p> <ul style="list-style-type: none"> <li>• Starting again in automatic operation mode</li> <li>• In baseblock status</li> <li>• Changing mode</li> <li>• At overtravel</li> <li>• While start command input signal is ON</li> </ul>
b6 Set Value	Specifications of Positioning Completion Signal (COIN Signal)										
0	ON when reference is not being discharged and position error is smaller than parameter 6. OFF while start command input signal (AST) is ON and until zero-point return is completed in the zero-point return (homing) mode. (Normal specifications)										
1	<p>OFF when power supply is turned ON.</p> <p>ON when operation is started in automatic operation mode and positioning is completed normally (reference discharge is completed and position error becomes smaller than parameter 6 set value.)</p> <p>Also OFF in the following cases:</p> <ul style="list-style-type: none"> <li>• Starting again in automatic operation mode</li> <li>• In baseblock status</li> <li>• Changing mode</li> <li>• At overtravel</li> <li>• While start command input signal is ON</li> </ul>										

(Cont'd)



(Cont'd)

No.	Name	Conditioning Parameter		Contents																																		
		No.	Set Value																																			
66	Function Selection 6	20 b6	1	By setting (b7, b6, b5, b4, b3, b2, b1, b0) to "0" or "1", each function can be selected.																																		
	b0			(Normally set to 0.)																																		
	b1																																					
	b2																																					
	b3																																					
	b4 Station No. Output Extension			Set to b4 = 1 when alarm code outputs ( $\overline{AL0}$ to $\overline{AL3}$ ) are used as station No. outputs ( $\overline{P5}$ to $\overline{P8}$ ).																																		
				<table border="1"> <tr> <td>b4 Set Value</td> <td>5CN-19, 20, 21, 22 output at parameter 15 = 0</td> </tr> <tr> <td>0</td> <td>Alarm code output (<math>\overline{AL0}</math> to <math>\overline{AL3}</math>)</td> </tr> <tr> <td>1</td> <td>Station No. output (<math>\overline{P5}</math> to <math>\overline{P8}</math>)</td> </tr> </table>	b4 Set Value	5CN-19, 20, 21, 22 output at parameter 15 = 0	0	Alarm code output ( $\overline{AL0}$ to $\overline{AL3}$ )	1	Station No. output ( $\overline{P5}$ to $\overline{P8}$ )																												
b4 Set Value	5CN-19, 20, 21, 22 output at parameter 15 = 0																																					
0	Alarm code output ( $\overline{AL0}$ to $\overline{AL3}$ )																																					
1	Station No. output ( $\overline{P5}$ to $\overline{P8}$ )																																					
b5	(Normally set to 0.)																																					
b6																																						
b7 Servopack Response Axis Address	Set to b7 = 1 when axis address is provided for Servopack response. However, axis address can be provided only in multi-axis control. (Example)																																					
	Command <input type="checkbox"/> 3PRM30 → 3PRM30 = ××...× (Sent from Servopack)  Command <input type="checkbox"/> 5ALM → 5ALM COIN (Sent from Servopack)																																					
67	External Position Indicator Decimal Point Position and DG-SW Shift Digit Number	20 b1	1	When external position indicator is used (set to parameter 20 b1 = 1), decimal point which is indicated by value set by parameter 67 lights. <table style="margin: 10px auto; border-collapse: collapse;"> <tr> <td style="text-align: center;">7</td><td style="text-align: center;">6</td><td style="text-align: center;">5</td><td style="text-align: center;">4</td><td style="text-align: center;">3</td><td style="text-align: center;">2</td><td style="text-align: center;">1</td><td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td><td style="text-align: center;">↓</td> </tr> </table> <div style="text-align: center; border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <table border="1" style="border-collapse: collapse;"> <tr> <td style="width: 20px; text-align: center;">+</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> <td style="width: 20px; text-align: center;">.</td> </tr> <tr> <td style="text-align: center;">-</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> <td style="text-align: center;">.</td> </tr> </table> </div> <p style="text-align: center; margin-top: 5px;">External position indicator (Unit: Reference unit)</p> When setting to parameter 65 b3 = 1, DG-SW position or speed input is shifted to the left by the number of digits of the value set in parameter 67. (Digital switch reference) $\times 10^{(\text{PARAMETER 67 SET VALUE})}$ Example: When parameter 67 = 2 and DG-SW reference = 123; $123 \times 10^2 = 12300$ is referenced.	7	6	5	4	3	2	1	0	↓	↓	↓	↓	↓	↓	↓	↓	+	.	.	.	.	.	.	.	.	-	.	.	.	.	.	.	.	.
7	6	5	4	3	2	1	0																															
↓	↓	↓	↓	↓	↓	↓	↓																															
+	.	.	.	.	.	.	.	.																														
-	.	.	.	.	.	.	.	.																														
68	Accel/Decel Type Setting	17 b4	1	0 Linear or simplified S-curve accel/decel																																		
69				Automatic Operation Mode	1 Exponent																																	
					Manual Operation Mode	0 Linear or simplified S-curve accel/decel																																
70				Pulse Operation Mode		1 Exponent																																
					71	Zero-Point Return (Homing) Operation Mode	0 Linear or simplified S-curve accel/decel																															
1 Exponent																																						

(Parameter setting becomes effective by conditioning parameter setting.)

(Cont'd)

### 8.3 PARAMETER FUNCTION DETAILS (Cont'd)

No.	Name	Conditioning Parameter		Contents
		No.	Set Value	
72	Function Selection 6	By setting (b0, b1, b2, b3, b4, b5) to "0" or "1", the following function can be selected:		
		20 b4	1	Set Value and Function Provided/Not Provided
			0	1
	b0	Overrun Alarm Process	Set	Not set
	b1	Remaining Data Process after STOP signal is input	Hold (Feedhold)	Abandon (No feedhold)
	b2	PG (L-PG/M-PG) Selecting Method at Positioning Completion when Line PG Used	Selected by $\overline{L-PG}$ signal	Motor PG selected by force
	b3	Echo-back at Initialization	Not set	set
b4	OK Response for Command	Not set	set	
b5	Monitor Data Transmission Specification Change	Monitor data are sent repeatedly from Servopack.	Monitor data are sent only once from Servopack.	
76	Simplified S-curve Accel/Decel Time	20 b3	1	<p>Set accel/decel speed in simplified S-curve accel/decel control together with parameter 4.</p> <p>Unit: ms Setting range: 0 to 124</p> <p>1st or 3rd step accel/decel speed is set by this parameter.</p> <p>Positioning time is extended by (parameter 76 value + 2) (ms).</p> <p>Simplified S-curve accel/decel becomes effective by 20 b3 = 1 setting when linear accel/decel type is selected by parameter 17 b4.</p>
				<p> <math>V_1</math> : Parameter 4 set value  <math>T_1</math> : parameter 5 set value  <math>T_2</math> : parameter 76 set value + 2 (ms)  <math>\alpha_1</math> : 1st-step accel/decel speed (<math>V_1/T_1</math>)  <math>\alpha_2</math> : 2nd-step accel/decel speed (<math>V_1/T_1</math>)  <math>\alpha_3</math> : 3rd-step accel/decel speed (Same as <math>\alpha_1</math>)         </p>

(Parameter setting becomes effective by conditioning parameter setting.)

(Cont'd)

(Cont'd)

No.	Name	Conditioning Parameter		Contents
		No.	Set Value	
77	DG-SW Read-in Scanning Time	65 b2	1	<p>When position or speed reference is provided other than in exclusive-use digital switch unit in DG-SW reference method (set to parameter 15 = 1), DG-SW read-in scanning time (data strobe output pulse width) is set.</p> <p>Setting range: 24 to 2000 (ms)</p> <p>More than 24ms is needed for Servopack to read the data. Therefore, set a value added with 24ms to a time required to send the data at reference setter (sequencer) side. (Refer to Par. 5.6.3 (3).)</p> <p>Example</p> <p>(Parameter 77 set value) = 30ms + 24ms = 54ms or more</p>
90	Torque Reference Filter Time Constant	19 b7	1	<p>Set torque reference filter time constant. Used to prevent oscillation.</p> <p>Setting range: 0 to 100 [<math>\times 32.5 (\mu s)</math>]</p>

(Parameter setting becomes effective by conditioning parameter setting.)

## 9

## DISPLAY/SETTING/MONITOR FUNCTIONS

## 9.1 DISPLAY AND SETTING FUNCTIONS

## 9.1.1 Display

Status of drive is displayed by LED indicators or 7-segment indicator. For Servopack type HR  $\square\square\square$  BB, fault contents are displayed in the data display section.

Table 9.1 LED Indicators

Display Specifications	HR $\square\square\square$ BAB	HR $\square\square\square$ BB	Conditions at Lighting
Power Supply Display	MAIN (red)	—	Voltage remaining in Servopack DC main circuit (fail-safe lamp)
	MP (yellow)	MP (green)	Servopack DC main circuit voltage normal
	RUN (green)	P (green)	Servopack control power supply (+5V) normal
Alarm Display	ALARM (red)	ALM (red)	At alarm occurrence

Table 9.2 7-segment LED (Red) Display Specifications and Fault Contents Display Specifications of Servopack Type HR□BB

Fault Contents Display in Data Display Section	7-segment LED Display	Display Contents
. ? ? ? ? *	.	Baseblock is released. (Indicates current conduction to motor.)
- bb	-	Baseblocking (Stops current conduction.)
P.P-0t	P.	P-side overtravel
n.n-0t	n.	N-side overtravel
P.P-LS	P.	P-side software overtravel
n.n-LS	n.	N-side software overtravel
d.bRt	d. Blinks	Battery voltage low-level detection
0.RbS	0.	ABS0 error
1.0C	1.	Overcurrent
2.0Cb	2.	Circuit protector trip
3.rG	3.	Regenerative error
4.0U	4.	Overvoltage
5.0S	5.	Overspeed
6.0U	6.	Main circuit power supply error
7.0L	7.	Overload
8.P0S	8.	Position error
R.0H	R.	Heat sink overheat
C.PG	C.	PG disconnection
F.0-PH	F.	Open phase
H.HRtd	H.	Hardware error
J.0F	J.	Overflow
L.r0Y	L.	Overrun
Y.Pr ? ? **	Y.	Parameter error

- Servopack power circuit is base-blocked.
- Self-holding until resetting
- Servo alarm output

\*1 ???? varies as follows depending on the status:

At positioning completion: **COIn.**  
 At positioning near: **0ERR.**  
 At positioning: **rUn.**  
 At feed holding: **HOLD**

\*2 ?? indicates parameter No. (00 means Position / Speed / Boundary table error.)  
 (In alarm record display mode, ?? is not indicated.)

### 9.1.2 Display and Setting Functions for Servopack Type CACR-HR BAB

#### (1) I/O signal check

I/O signals can be checked by LED block on the panel. Table 9.3 shows the signals indicated by LED blocks according to SW setting. The table below shows I/O signal status:

	At LED Lighting	At LED Extinguishing
Contact Input	Open	Close
Pulse Input	H level	L level
Output Signal	Output relay OFF	Output relay ON




Table 9.3 Connector Pin Nos. and Names of Signals Indicated by LED Blocks


SW1		D7	D6	D5	D4	D3	D2	D1	D0
0	Signal Name and 2CN Pin No.	1	1 5	1 6	1 7	1 8	8	9	1 0
		STP	STOP	$\overline{AST}$	DEC	$\overline{PCON}$	$\overline{SVON}$	N-OT	P-OT
1	Signal Name and 5CN Pin No.	1 5	1 4	1 3	1 2	1 1	1 0	9	8
		$\overline{RST}$	$\overline{DR1}$	$\overline{DR0}$	$\overline{MCCW}$	$\overline{MCW}$	$\overline{MAN}$	$\overline{ZRN}$	$\overline{CUR}$
2		2 9	2 8	2 7	2 6	2 5	2 4	1 7	1 6
3		4 4	4 3	4 2	4 1	4 0	3 2	3 1	3 0
4					4 9	4 8	4 7	4 6	4 5
						$\overline{LPG}$	$\overline{PULS}$	$\overline{SP3RD}$	$\overline{SP2ND}$
5	Signal Name and Input Pulse				PG Pulse			Reference Pulse	
					PA	PB	PC	CA	CB
6	Signal Name and 2CN Pin No.							1 2	1 1
								$\overline{BK}$	ALM
7	Signal Name and 5CN Pin No.	2 1	2 0	1 9	7	6	5	4	3
		$\overline{AL2}$	$\overline{AL1}$	$\overline{AL0}$	$\overline{ERR}$	$\overline{POS2}$	$\overline{POS1}$	$\overline{MAN-LT}$	$\overline{AUT-LT}$
8		3 9	3 8	3 7	3 6	3 5	3 4	2 3	2 2
			$\overline{BATALM}$	$\overline{DS04}$	$\overline{DS03}$	$\overline{DS02}$	$\overline{DS01}$	$\overline{DS00}$	$\overline{AL3}$

(2) Baud rate and axis address setting (initial setting)

Baud rate and axis address do not have to be set for any reason other than setting change once set at test run.

Operation section (Servopack panel face)

SW1 to SW3 are digital switches (rotated by a small-size screwdriver).





Procedures	Operation Method	(7-SEG. LED) ALARM Lightig																								
①	Turn on only Servopak control power supply. ( LED <input type="checkbox"/> RUN lights.)	<input type="checkbox"/>																								
②	Set toggle switch (MO-neutral-WR) in neutral status.	<input type="checkbox"/> blinks.																								
③	Set SW1 to SW3 as shown below: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>6</td> <td>0</td> <td>0</td> </tr> </table>		SW1	SW2	SW3	6	0	0																		
SW1	SW2	SW3																								
6	0	0																								
④	Lower toggle switch to WR side. (Return to neutral.)	<input checked="" type="checkbox"/> blinks.																								
⑤	(1) Baud rate setting <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Baud Rate</td> <td>9600</td> <td>4800</td> <td>2400</td> <td>1200</td> </tr> <tr> <td>SW2 Set Value</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> </tr> </table> (2) Axis address setting (Refer to Par. 7.3 for how to use axis address.) <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Control Configuration</th> <th>SW3 Set Value (Axis address 10-digit setting)</th> <th>SW1 Set Value (Axis address 1-digit setting)</th> </tr> </thead> <tbody> <tr> <td>1-axis control</td> <td>Setting not needed.</td> <td>0</td> </tr> <tr> <td>Multi-axis control (2 to 9 axes) group designation not performed</td> <td>Setting not needed.</td> <td>Any number of 1 to 9</td> </tr> <tr> <td>Multi-axis control (2 to 9 axes) group designation performed</td> <td>Any number of 1 to 9</td> <td>Any number of 1 to 9</td> </tr> <tr> <td>Multi-axis control (10 to 16 axes)</td> <td>Any number of 1 to 9</td> <td>Any number of 1 to 9</td> </tr> </tbody> </table>		Baud Rate	9600	4800	2400	1200	SW2 Set Value	0	1	2	3	Control Configuration	SW3 Set Value (Axis address 10-digit setting)	SW1 Set Value (Axis address 1-digit setting)	1-axis control	Setting not needed.	0	Multi-axis control (2 to 9 axes) group designation not performed	Setting not needed.	Any number of 1 to 9	Multi-axis control (2 to 9 axes) group designation performed	Any number of 1 to 9	Any number of 1 to 9	Multi-axis control (10 to 16 axes)	Any number of 1 to 9
Baud Rate	9600	4800	2400	1200																						
SW2 Set Value	0	1	2	3																						
Control Configuration	SW3 Set Value (Axis address 10-digit setting)	SW1 Set Value (Axis address 1-digit setting)																								
1-axis control	Setting not needed.	0																								
Multi-axis control (2 to 9 axes) group designation not performed	Setting not needed.	Any number of 1 to 9																								
Multi-axis control (2 to 9 axes) group designation performed	Any number of 1 to 9	Any number of 1 to 9																								
Multi-axis control (10 to 16 axes)	Any number of 1 to 9	Any number of 1 to 9																								
⑥	Lower toggle switch to WR side. (Return to neutral.)	<input type="checkbox"/> blinks.																								
⑦	Set SW1 to SW3 as follows and keep toggle switch in MO. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> </table>	SW1	SW2	SW3	0	0	0	<input type="checkbox"/>																		
SW1	SW2	SW3																								
0	0	0																								
⑧	Turn off Servopak control power supply.	(Extinguished)																								
⑨	Turn on only Servopak control power supply again.	<input type="checkbox"/>																								


Baud rate and axis address setting are now completed.

(3) Machine zero-point setting






For type HR    BAB, machine zero-point can be set by switches on the panel in addition to serial communication.

Operation section (Servopack panel face)

SW1 to SW3 are digital switches (rotated by a small-size screwdriver.)



Setting is performed for the following procedures after moving to machine zero-point in manual operation mode.

Proce- dures	Operation Method	(7-SEG. LED) ALARM Lighting						
①	Set toggle switch (MO-neutral-WR) in neutral status.	 blinks.						
②	Set SW1 to SW3 as shown below: <table border="1" data-bbox="494 495 713 558"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>7</td> <td>0</td> <td>0</td> </tr> </table>	SW1	SW2	SW3	7	0	0	
SW1	SW2	SW3						
7	0	0						
③	Lower toggle switch to WR side. (Return to neutral.)	 blinks.						
④	Set SW1 to SW3 as shown below: <table border="1" data-bbox="494 705 713 768"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>7</td> <td>7</td> <td>7</td> </tr> </table>	SW1	SW2	SW3	7	7	7	
SW1	SW2	SW3						
7	7	7						
⑤	Lower toggle switch to WR side. (Return to neutral.)	 blinks.						
⑥	Set SW1 to SW3 as follows and keep toggle switch in MO. <table border="1" data-bbox="494 957 713 1020"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> </table>	SW1	SW2	SW3	0	0	0	 .
SW1	SW2	SW3						
0	0	0						
⑦	Turn off Servopack control power supply.	(Extinguished)						
⑧	Turn on only Servopack control power supply again.	 .						

Machine zero-point setting is now completed. (These procedures correspond to serial command "ZEROSSET 0".)

### 9.1.3 Display and Setting Functions for Servopack Type CACR-HR□□BB

The setting of parameter etc, can be performed using parameter display/setting functions built into Servopack.




Fig. 9.1 Setting/Display Section

Table 9.4 Setting/Display Setting Mode Selection

No.	Switch Depressed	Display	Contents
0	Initial Status	-.bb	Alarm/status display
1	NO/DATA	RL-00	Alarm record display (See Table 9.5.)
2	MODE/▷	cn-01	Parameter display/setting (See Table 9.6.)
3	MODE/▷	05-00	Machine zero-point setting (See Table 9.7.)
4	MODE/▷	55-00	Serial communication setting (See Table 9.8.)
5	MODE/▷	un-01	Monitor data display (See Table 9.9.)
6	MODE/▷	in-01	Input signal status display (See Table 9.10.)
7	MODE/▷	on-01	Output signal status display (See Table 9.11.)
8	MODE/▷	RL-00	Alarm record display (Return to No.1)

Depressing **HOME/SET** in the above 1 to 8, returns to initial status (alarm/status display).

Depressing **HOME/SET** in the above 0 status, resets an alarm when it occurs (same as serial command ARES) or performs Servopack initial reset when an alarm does not occur (same as serial command RES).

Table 9.5 Alarm Record Display Mode

△	NO/DATA	MODE/▷	HOME/SET
<p>• Alarm No. display</p> <p>1. (MOST RECENT ALARM) 2. (ALARM 1 TIME BEFORE) 3. (ALARM 9 TIMES BEFORE)</p>	<p>Exchange alarm No. with alarm content display. For alarm content display, refer to Table 9.2.</p>	<p>• Alarm No. display</p> <p>Parameter display/setting mode is entered.</p>	<p>• Alarm No. display</p> <p>Alarm/status (initial status) is displayed.</p>

Table 9.6 Parameter Display/Setting Mode

△	NO/DATA	MODE/▷	HOME/SET
<p>• Parameter No. display</p> <p>(PARAMETER No. 1) (PARAMETER No. 2) (PARAMETER No. 99)</p> <p>• Parameter data display Change the value which is blinking.</p>	<p>Exchange parameter No. with parameter data display.</p>	<p>• When parameter No. is displayed.</p> <p>Machine zero-point setting mode is entered.</p> <p>• When parameter data is displayed.</p> <p>Blinking digit (to be changed) is moved.</p> <p>(LOWER 4 DIGITS) (UPPER 4 DIGITS)</p> <p>In the above figure, the blinking digit changes as shown below:</p>	<p>• When parameter No. is displayed.</p> <p>Alarm/status (initial status) is displayed.</p> <p>• When parameter data is displayed.</p> <p>Displayed data are set. (Reset is required for offline parameters.)</p>

Note: For parameters, refer to Par. 8 "PARAMETER".

Table 9.7 Machine Zero-point Setting Mode

△	NO/DATA	MODE/▷	HOME/SET									
<ul style="list-style-type: none"> <li>• Zero-point No. display ineffective</li> <li>• Zero-point data display change the value which is blinking.</li> </ul>	<p>Exchange zero-point No. display (only <b>SS-00</b>) and zero-point data display.</p>	<ul style="list-style-type: none"> <li>• When zero-point No. is displayed.</li> </ul> <p>Serial communication setting mode is entered.</p> <ul style="list-style-type: none"> <li>• When zero-point data is displayed.</li> </ul> <p>Blinking digit (to be changed) is moved.</p> <div style="text-align: center;"> <p>⑦ ⑧ ⑨ ①</p> <table border="1" style="margin: auto;"> <tr> <td style="width: 20px; height: 20px;">4</td> <td style="width: 20px; height: 20px;">3</td> <td style="width: 20px; height: 20px;">2</td> <td style="width: 20px; height: 20px;">!</td> </tr> </table> <p>(LOWER 4 DIGITS)</p> <p>② ③ ④ ⑤ ⑥</p> <table border="1" style="margin: auto;"> <tr> <td style="width: 20px; height: 20px;">-</td> <td style="width: 20px; height: 20px;">8</td> <td style="width: 20px; height: 20px;">7</td> <td style="width: 20px; height: 20px;">6</td> <td style="width: 20px; height: 20px;">5</td> </tr> </table> <p>(UPPER 4 DIGITS)</p> <p>In the above figure, the blinking digit changes as shown below:</p> <div style="text-align: center;"> <p>① → ② → ... → ⑧ → ⑨</p> </div> </div>	4	3	2	!	-	8	7	6	5	<ul style="list-style-type: none"> <li>• When zero-point No. is displayed.</li> </ul> <p>Alarm/status (initial status) is displayed.</p> <ul style="list-style-type: none"> <li>• When zero-point data is displayed.</li> </ul> <p>Motor current position is set to displayed machine position.* (Reset is required after the setting.)</p>
4	3	2	!									
-	8	7	6	5								

\* Same as serial command ZEROSET ±nnnnnnnn.

Table 9.8 Serial Communication Setting Mode

△	NO/DATA	MODE/▷	HOME/SET
<ul style="list-style-type: none"> <li>• Set No. display</li> </ul> <div style="margin-left: 20px;"> <p>(BAUD RATE SETTING)</p> <p><b>SS-00</b></p> <p>↓</p> <p>(AXIS ADDRESS 1-DIGIT SETTING)</p> <p><b>SS-0!</b></p> <p>↓</p> <p>(AXIS ADDRESS 10-DIGIT SETTING)</p> <p><b>SS-02</b></p> </div> <ul style="list-style-type: none"> <li>• Set data display</li> </ul> <p>Change set data as follows:</p> <p>In baud rate setting 9600 → 4800 → 2400 → 1200</p> <p>In axis address setting 0 → 1 → 2 → 3 → 4 → 5 → 6 → 7 → 8 → 9</p>	<p>Exchange set No. display with set data display</p>	<ul style="list-style-type: none"> <li>• When set No. is displayed.</li> </ul> <p>Monitor data display mode is entered.</p>	<ul style="list-style-type: none"> <li>• When set No. is displayed.</li> </ul> <p>Alarm/status (initial status) is displayed.</p> <ul style="list-style-type: none"> <li>• When set data is displayed.</li> </ul> <p>Displayed data are set. (Reset is required after the setting.)</p>

Note: For how to use axis address (setting range), refer to Par. 7.3.2.

Table 9.9 Monitor Data Display Mode







△	NO/DATA	MODE/▷	HOME/SET
<p>• Monitor data No. display.</p>  <p>Monitor data Nos. are the same as serial communication monitor commands MON1 to MON6.</p>	<p>Exchange monitor data No. with monitor data display.</p>	<ul style="list-style-type: none"> <li>• When monitor No. is displayed.</li> </ul> <p>Input signal status display mode is entered.</p> <ul style="list-style-type: none"> <li>• When monitor data is displayed.</li> </ul> <p>Exchange monitor data upper 4 digits with lower 4 digits</p> 	<ul style="list-style-type: none"> <li>• When monitor No. is displayed.</li> </ul> <p>Alarm/status (initial status) is displayed.</p>

Table 9.10 Input Signal Status Display Mode

△	NO/DATA	MODE/▷	HOME/SET
<p>• Input signal No. display.</p>  <p>Input signal Nos. are the same as serial communication monitor commands IN1 to IN8.</p>	<p>Exchange input signal with input data display</p>	<ul style="list-style-type: none"> <li>• When input signal No. is displayed.</li> </ul> <p>Output signal status display mode is entered.</p> <ul style="list-style-type: none"> <li>• When input signal data is displayed.</li> </ul> <p>Exchange input signal data upper 4 digits with lower 4 digits.</p> 	<ul style="list-style-type: none"> <li>• When input signal No. is displayed.</li> </ul> <p>Alarm/status (initial status) is displayed.</p>

Note: For serial commands, refer to Par. 7.8 "SERIAL COMMANDS."

Table 9.11 Output Signal Status Display Mode


△	NO/DATA	MODE/▷	HOME/SET
<p>• Output signal No. display</p>  <p>(OUTPUT SIGNAL 1) (OUTPUT SIGNAL 2) (OUTPUT SIGNAL 3)</p> <p>Output signal Nos. are the same as serial communication monitor commands OUT1 to OUT3.</p>	<p>Exchange output signal with output data display.</p>	<p>• When output signal No. is displayed.</p> <p>Alarm record display mode is entered.</p> <p>• When output signal data is displayed.</p> <p>Exchange output signal data upper 4 digits with lower 4 digits.</p> 	<p>• When output signal No. is displayed.</p> <p>Alarm/status (initial status) is displayed.</p>

Note: For serial commands, refer to Par. 7.8 "SERIAL COMMANDS."





## 9.2.2 Servopack Type CACR-HR     BB



Pin No.	Signal Name	Name	Output Voltage
TM1-1	V <sub>TC</sub>	Motor speed	$\mp 2.0 \times \frac{P^*}{8192} \text{ V} / \pm 1000 \text{ r/min}$
TM1-2	T <sub>MON</sub>	Torque or speed reference	Torque reference: $\mp 3.0 \text{ V} / \pm 100\%$ Speed reference: $\pm 2.0 \text{ V} / \pm 1000 \text{ r/min}$
TM1-3	GND	0V for signal	0V

\* P value is number of encoder pulses per revolution (P/R) to be used.

Notes:

1. Torque reference or speed reference selection is performed by serial command. Torque reference is selected when power supply is turned on.

Command	T <sub>MON</sub> Output
MU = 1	Torque reference
MU = 2	Speed reference

2. Accuracy:  $\pm 10\%$
3. 8-bit D/A converter is used. Output may have 1-bit ripple.

Pin No.	Signal Name	Name		Output Voltage								
TM2-1 to TM2-3	—	—		Check terminals used only for shipping (Do not observe.)								
TM2-4	UREF	Phase U	Current reference monitor	Monitor of current reference								
TM2-5	VREF	Phase V										
TM2-6	IU	Phase U	Current Monitor	Type	03	05	10	15	20	30	44	60
TM2-7	IV	Phase V		Output Voltage (V/A)	0.4	0.24	0.16	0.08		0.04		
TM2-8	SG	0V for signal										

Notes:

1. Check terminals can be observed by oscilloscope.
2. At observation, do not contact adjacent check terminals.

# 10 INSTALLATION AND WIRING

## 10.1 RECEIVING

This motor has been put through severe tests at the factory before shipped. After unpacking, however, check and see the following.

- Its nameplate ratings meet your requirements.
- It has sustained no damage while in transit.
- The output shaft should be hand-rotated freely. However, the brake-mounted motor does not rotate as it is shipped with the shaft locked.
- Fastening bolts and screws are not loose.

If any part of the motor is damaged or lost, immediately notify us giving full details and nameplate data.

## 10.2 INSTALLATION

### 10.2.1 Servomotor

AC Servomotor can be installed either horizontally or vertically.

#### (1) Before mounting

Wash out anticorrosive paint on shaft extension and flange surface with thinner before connecting the motor to the driven machine. See Fig. 10.1.




Fig. 10.1 Anticorrosive Paint to be Removed

#### (2) Location

Use the motor under the following conditions.

- Indoors
- Free from corrosive and/or explosive gases or liquids
- Ambient temperature: 0 to +40°C
- Clean and dry
- Accessible for inspection and cleaning

If the AC servomotor is subject to excessive water or oil droplets, protect the motor with a cover. The motor can withstand a small amount of splashed water or oil.

(3) Environmental conditions

Ambient temperature: 0 to +40°C

Storage temperature: -20 to +60°C


Humidity: 20% to 80% RH (non-condensing)

(4) Load coupling

True alignment of motor and driven machine is essential to prevent vibration, reduced bearing and coupling life, or shaft and bearing failures.

Use flexible coupling with direct drive. The alignment should be made in accordance with Fig. 10.2.

When mounting coupling, ease the impact on the shaft and avoid the excessive force on the bearing.



- ① Measure the gap between the straightedge and coupling halves at four equidistant points of the coupling. The each reading should not exceed 0.03 mm (0.0012 in.).
- ② Align the shafts.
- ③ Measure the gap between the coupling faces at four equidistant points around the coupling rim with thickness gage. The maximum variation between any two readings should not exceed 0.03 mm (0.0012 in.)

Fig. 10.2 Alignment of Coupling

(5) Allowable bearing load

Avoid both excessive thrust and radial loads to the motor shaft. If unavoidable, never exceed the values in Table 3.9.

When mounting the gear, coupling and pulley, ease the impact on the shaft and avoid excessive force on the bearing.  $[98\text{m/s}^2(10G)\text{max}]$

## 10.2.2 Servopack

### (1) Installation

The Servopack type CACR-HR [ ] BAB [ ] is rack-mounted type, and type CACR-HR [ ] BB is base-mounted type.

### (2) Location

- When installed in a panel:  
Keep the temperature around Servopack at 55°C or below.
- When installed near a heat source:  
Keep the temperature around Servopack below 55°C.
- If subjected to vibration:  
Mount the unit on shock absorbing material.
- If corrosive gases are present:  
Avoid locations where corrosive gases exist as it may cause extensive damage over long use. Especially vulnerable are switching operation of contactors and relays.
- Unfavorable atmospheric conditions:  
Select a location with minimum exposure to oil, water, hot air, high humidity, excessive dust or metallic particles.

### (3) Mounting Direction

#### Ⓐ Type HR [ ] BAB [ ]

Mount the Servopack unit vertically on the wall with main terminals being at the bottom to take advantage of natural air convection (Fig. 10.3). Install it with setscrews tightened at four mounting holes in the unit base.




Fig. 10.3 Mounting Direction

#### Ⓑ Type HR [ ] BB

Mount the unit vertically on the wall using the mounting holes (4) on the base plate, with main terminals at the bottom (Fig. 10.4).




Fig. 10.4 Mounting Direction of Servopack

## 10.3 WIRING PRECAUTIONS

The following precautions should be taken for wiring.

(1) For signal lines and PG feedback lines, use twisted cables or multi-core shielded twisted-pair cables (Yaskawa Drawing No. DP8409123, DE8400093 or B9400064). (See Table 5.5.)

Cable length is a maximum of 5 m for reference input lines (DG-SW unit, reference pulse generator, display unit) and a maximum of 20 m for PG feedback lines. Use the shortest possible length. Contact your YASKAWA representative for longer PG feedback lines.

(2) For ground line, cable should be as heavy as possible to provide class 3 ground (ground resistance  $100\Omega$  or less). Make sure to ground at a central point. If the motor and machine are insulated, ground the motor.

(3) To prevent malfunction due to noise, take the following precautions:

- Place the noise filter, Servopack and I/O reference as near as possible to each other.
- Make sure to mount a surge absorbing circuit with relays, electromagnetic contacts, and solenoids.
- Run the power line and signal line, holding the distance to 30 cm or more; do not run them in the same duct or in a bundle.
- When the same power source is used for Servopack, as for an electric welder or electrical discharge machine or when a high-frequency noise source is present in the vicinity, use filters in the power and input circuits.
- The Servopack uses a PWM amplifier, and spurious noise may be present in the signal line.

(4) Remedy for Radio Frequency Interference (R.F.I.)

Servopack may interfere with radio reception. If the controller interferes with radio reception, connect a noise filter to the power supply.

(5) The signal line uses cables whose core is extremely fine (0.2 to 0.3 mm<sup>2</sup>). Avoid using excessive force which may damage these cables.

# 11 TEST RUN, MAINTENANCE, AND INSPECTION

## SAFETY PRECAUTIONS

- Power supply must be in conformance with the product ratings.  
For HR□□BAB□□ type, check  200V or  100V described on the panel surface and use 200 to 230VAC (+10%, -15%) 50/60Hz or 100 to 115VAC (+10%, -15%) 50/60Hz.  
For HR□□BB type, be sure to use 200 to 230VAC (+10%, -15%) 50/60Hz.  
Power supplies other than described above may cause a fault.
- Do not touch the current-conducting sections of the SERVOPACK without taking proper safety precautions. A high voltage (250 to 300 VDC) is applied, and contact is dangerous.
- Operate only when the terminal cover is set. Personnel may receive an electric shock if the cover is not set.
- The main circuit should not be touched for five or six minutes after switching off power. It is dangerous until the main circuit voltage lowers to approximately 20 V or less.
- Check safety procedures carefully before switching on and off power during maintenance work.
- This unit should never be used in a place which is exposed to corrosive liquids or gases such as acids and alkalis, as well as inflammable and explosive gases.
- Check to be sure that the SERVOPACK is grounded under class 3 grounding. (ground resistance 100Ω or less)
- The motor should be operated at an ambient temperature between 0 and 40°C with relative humidity of 20 to 80%. For the SERVOPACK between 0 and 55°C with 90% or below.
- Protect the AC servomotor against all moisture. Water may cause a short circuit or electric shock accident.
- Never use voltage resistance or insulation resistance test.

## 11.1 CHECK ITEMS BEFORE TEST RUN

### 11.1.1 Servomotor

Before test run, check the following.

- Connection to machines or devices, wiring, fuse connection, and grounding are correct.
- Bolts and nuts are not loose.
- For motors with oil seals, the seals are not damaged and are properly lubricated.

### 11.1.2 Servopack

- Connection and wiring leads are firmly connected to terminals or inserted into the connectors.
- The power supply is turned off if servo alarm occurs.
- Voltage supplied to Servopack is adjustable for the product ratings.

## 11.2 TEST RUN PROCEDURES

During test run, loads should not be applied to the servomotor. If it is necessary to start with the motor connected to the machine, confirm that the system is ready for emergency stop at any time.


### 11.2.1 Test-run Preparations

- (1) Servopack Initial Setting (Baud Rate, Axis Address Setting)
  - (a) Servopack Type HR   BAB

Baud rate or axis address does not have to be set for any reason other than setting change once set at test run.

Operation section (Servopack panel face)

SW1 to SW3 are digital switches (rotated by a small-size screwdriver).






Proce- dures	Operation Method	(7-SEG. LED) ALARM Lighting																								
①	Turn on only Servopack control power supply. ( LED <input type="checkbox"/> RUN Lights.)	<input type="checkbox"/>																								
②	Set toggle switch (MO-neutral WR) in neutral status.	<input type="checkbox"/> blinks.																								
③	Set SW1 to SW3 as shown below: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>6</td> <td>0</td> <td>0</td> </tr> </table>		SW1	SW2	SW3	6	0	0																		
SW1	SW2	SW3																								
6	0	0																								
④	Lower toggle switch to WR side. (Return to neutral.)	<input checked="" type="checkbox"/> blinks.																								
⑤	(1) Baud rate setting <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Baud Rate</td> <td>9600</td> <td>4800</td> <td>2400</td> <td>1200</td> </tr> <tr> <td>SW2 Set Value</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> </tr> </table> (2) Axis address setting (Refer to Par. 7.3 for how to use axis address.) <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Control Configuration</th> <th>SW3 Set Value (Axis address 10-digit set- ting)</th> <th>SW1 Set Value (Axis address 1-digit set- ting)</th> </tr> </thead> <tbody> <tr> <td>1-axis control</td> <td>Setting not needed.</td> <td>0</td> </tr> <tr> <td>Multi-axis control (2 to 9 axes) group designation not performed</td> <td>Setting not needed.</td> <td>Any number of 1 to 9</td> </tr> <tr> <td>Multi-axis control (2 to 9 axes) group designation performed</td> <td>Any number of 1 to 9</td> <td>Any number of 1 to 9</td> </tr> <tr> <td>Multi-axis control (10 to 16 axes)</td> <td>Any number of 1 to 9</td> <td>Any number of 1 to 9</td> </tr> </tbody> </table>		Baud Rate	9600	4800	2400	1200	SW2 Set Value	0	1	2	3	Control Configuration	SW3 Set Value (Axis address 10-digit set- ting)	SW1 Set Value (Axis address 1-digit set- ting)	1-axis control	Setting not needed.	0	Multi-axis control (2 to 9 axes) group designation not performed	Setting not needed.	Any number of 1 to 9	Multi-axis control (2 to 9 axes) group designation performed	Any number of 1 to 9	Any number of 1 to 9	Multi-axis control (10 to 16 axes)	Any number of 1 to 9
Baud Rate	9600	4800	2400	1200																						
SW2 Set Value	0	1	2	3																						
Control Configuration	SW3 Set Value (Axis address 10-digit set- ting)	SW1 Set Value (Axis address 1-digit set- ting)																								
1-axis control	Setting not needed.	0																								
Multi-axis control (2 to 9 axes) group designation not performed	Setting not needed.	Any number of 1 to 9																								
Multi-axis control (2 to 9 axes) group designation performed	Any number of 1 to 9	Any number of 1 to 9																								
Multi-axis control (10 to 16 axes)	Any number of 1 to 9	Any number of 1 to 9																								
⑥	Lower toggle switch to WR side. (Return to neutral.)	<input type="checkbox"/> blinks.																								
⑦	Set SW1 to SW3 as follows and keep toggle switch in MO. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> </table>	SW1	SW2	SW3	0	0	0	<input type="checkbox"/>																		
SW1	SW2	SW3																								
0	0	0																								
⑧	Turn off Servopack control power supply.	(Extinguished)																								
⑨	Turn on only Servopack control power supply again.	<input type="checkbox"/>																								

Baud rate and axis address setting are now completed.

(b) Servopack Type HR [ ] [ ] BB

Baud rate or axis address does not have to be set for any reason other than setting change once set at test run.

Operation section (Setting and display parts)



First, set jumpers **SEL1** and **SEL2** to cover pins 2 and 3 for single-axis control or 1 and 2 for multi-axis control.

Procedures	Operation Method	Display
①	Turn on only Servopack control power supply. (LED <b>P</b> lights.)	- <i>bb</i>
②	Depress SW3 <b>NO/DATA</b> .	<i>AL-00</i>
③	Depress SW5 <b>MODE/▷</b> three times until the display shown on the right is obtained.	<i>55-00</i>
④	Depress SW3 <b>NO/DATA</b> .	<i>9600</i>
⑤	Baud rate setting By depressing <b>△</b> , display changes as 9600→4800→ 2400→1200→9600 (cyclic). Depress SW4 <b>△</b> until desired value is displayed.	-
⑥	Depress SW6 <b>HOME/SET</b> . (Baud rate setting completed.)	-
⑦	Depress SW3 <b>NO/DATA</b> .	<i>55-00</i>
⑧	Depress SW4 <b>△</b> .	<i>55-01</i>
⑨	Depress SW3 <b>NO/DATA</b> .	<i>0</i>
⑩	Axis address (1-digit) setting By depressing SW4 <b>△</b> , the display changes from 0 to 9 (cyclic). • 0 is displayed for single-axis control. • Desired value from 1 to 9 is displayed to multi- axis control.	-
⑪	Depress SW6 <b>HOME/SET</b> . (Axis address 1-digit setting completed)	-
⑫	Depress SW3 <b>NO/DATA</b> .	<i>55-01</i>

The procedures from ⑬ to ⑰ are not necessary for single-axis control and control of 9 axes or less without group designation.  
Refer to Par. 7.3 for group designation.

Procedures	Operation Method	Display
⑬	Depress SW4 <input type="checkbox"/> $\Delta$ .	55-02
⑭	Depress SW6 <input type="checkbox"/> HOME/SET .	0
⑮	Axis address (10-digit) setting By depressing SW4 <input type="checkbox"/> $\Delta$ , the display changes from 0 to 9 (cyclic). Desired value from 1 to 9 is displayed.	—
⑯	Depress SW6 <input type="checkbox"/> HOME/SET .	—
⑰	Depress SW3 <input type="checkbox"/> NO/DATA .	55-02
⑱	Depress SW6 <input type="checkbox"/> HOME/SET .	— bb
⑲	Depress SW6 <input type="checkbox"/> HOME/SET . (Operation is reset. This procedure makes the above setting effective.)	

Servopack initial setting is now completed.

Note: Refer to Par. 7.3 for how to use axis address.

## (2) Parameter Setting

(By serial communication, parameter operation commands are sent from the master controller. For Servopack Type HR  BB, setting can be performed by using Servopack setting/display section. Refer to Par. 9.1.3.)

① All parameters required are written-in by using command  PRMpp =  $\pm n \dots n$  .

② Send command  RES after completing parameter writing-in.

③ Parameter contents check

Check that the parameter contents are set in accordance with the specifications by using command  PRM or  PRMpp .

Especially, check motor selection parameter, encoder pulse parameter, or encoder selection parameter (parameter Nos. 7 to 9) set value. Set a code or value (see the tables below) optimum for the matching motor type and encoder type.


M Series		F Series		G Series		D Series		S Series		R Series (200V)		R Series (100V)		P Series	
Type USAMED	Code No.	Type USAFED	Code No.	Type USAGED	Code No.	Type USADED	Code No.	Type USASEM	Code No.	Type USAREM	Code No.	Type USAREM	Code No.	Type USAPEM	Code No.
—	0	02	10	02	50	—	40	02A	20	—	30	—	60	—	70
03	1	03	11	03	51	—	41	03A	21	—	31	—	61	—	71
06	2	05	12	05	52	05E	42	05A	22	A5C	32	A5D	62	—	72
09B	3	09	13	09	53	10E	43	08A	23	01C	33	01D	63	01C	73
12B	4	13C	14	13A	54	15E	44	15A	24	02C	34	02D	64	02C	74
20B	5	20C	15	20A	55	22E	45	—	25	03C	35	03D	65	03C	75
30B	6	30C	16	30A	56	37E	46	30A	26	05C	36	05D	66	05C	76
44B	7	44C	17	44A	57	—	47	—	27	07C	37	—	67	07C	77
USAMKD-60B	8	—	18	—	58	—	48	—	28	—	38	—	68	—	78
—	9	—	19	—	59	—	49	—	29	—	39	—	69	—	79

Encoder Type	Encoder Pulse (Parameter 8)	Encoder Selection (Parameter 9)
Absolute Encoder 8192 pulses/rev	32768	0
Absolute Encoder 1024 pulses/rev	4096	0
Incremental Encoder 8192 pulses/rev	32768	1
Incremental Encoder 2048 pulses/rev	8192	1
Incremental Encoder 2500 pulses/rev	10000	1

### (3) Absolute Encoder Setup

The absolute encoder set-up procedure has to be performed before test-run, and when the Servopack is disconnected from the motor for an extended period of time. (The encoder data is maintained by battery back-up. The battery is in the Servopack.)

- ① For 1024pulses/rev, turn on the control power supply with normal wiring for 3 min or more.
- ② Turn off Servopack control power supply.
- ③ Absolute encoder setup.



- ④ Turn on the Servopack control power supply with absolute encoder connected to the Servopack. At this time, when 7-SEG.LED display is , setup is completed.
- ⑤ If ABSO error alarm (, serial communication ALM 0. ABS), perform the following steps:

Process at ABSO Error Occurrence

Temporary machine zero-point is set in serial communication.

- |   |   |  |
|---|---|--|
| <ol style="list-style-type: none"> <li>⑥ Send command <input type="text" value="ZEROSSET 0"/> .</li> <li>⑦ Send command <input type="text" value="RES"/> .</li> </ol> | } | Can be performed in Servopack operation section. (Refer to Par. 11.2.2 (3) "Note". |
|---|---|--|

- Setup is completed unless an alarm occurs.
- If an alarm occurs again repeat the above steps from starting at ①. If this is unsuccessful, there may be a problem related to the encoder or encoder connection.

#### (4) Input Signal Check

Check input signals are input normally to Servopack by using monitor commands **IN1** to **IN6**. (Refer to Par. 7.8.2 (4) (b).)

Check can be performed by Servopack LED display. (Refer to Table 9.3 or 9.4 for Servopack Type HR  BAB  or HR  BB.)

### 11.2.2 Operation Check

#### (1) Main Circuit Power Supply ON

① When the main circuit power supply ON circuit is composed according to Fig. 5.16, the power supply is turned on by depressing the power supply push-button switch.

② When the main power is applied normally, in Type HR  BAB , LED **MAIN** (above the circuit breaker) and **MP** light; in Type HR  BB, LED **MP** (green) lights.

#### (2) Motor Operation Check

① Servopack power circuit operates by sending serial command **SVON** to enable the Servopack. (7-SEG. LED **ALARM** \* indicator changes from  to .)

\* **ALM** for Type HR  BB

② Rotate the motor at a low speed by using command **JOG(±)n···n** and check that operation is normal.

#### (3) Machine Zero-point Setting (When using Absolute Encoder)

(a) DG-SW, serial communication command, or command table method

① Move to machine zero-point by manual operation command.

② Command **ZEROSSET(±)n···n** ((±)n···n: Machine zero-point)

③ Then send **RES**.


The machine zero-point setting is now completed.

(b) Station No. reference method

① Move to the reference station No. (see below) position.

Reference Station No.	Parameter 20 b2 Setting
0	0 (Station No. 0 provided)
1	1 (Station No. 0 not provided)

- ② Send command **ZEROSET 0** , then send **RES** .
- ③ Station No. is set as follows :



$$a = \frac{\text{(Parameter 11 set value)}}{N}$$

N indicates the number of stations (parameter 16 set value) and the values in the inner circle indicate current values.

Notes :

1. Current position is **PUN = × × ×** value indicated by **MON1** .
2. Reference equivalent to serial command **ZEROSET 0** can be performed from the Servopack's operation panel. (Refer to the next pages.)

(4) Machine Zero-point Setting (When Using Incremental Encoder)

- ① Set parameter 54 (Zero-point return final traveling distance) to 0, for zero-point return.
- ② Set the distance between zero-point return complete position and machine zero-point or reference station number at parameter 54.
- ③ Move the machine to internal zero-point return LS (DEC or STP) by manual operation command ; send control power ON/OFF or RES command.
- ④ Perform zero-point return.  
 Recheck that zero-point return complete position is the same as the machine zero-point or the reference station number.  
 In case of divergence, reset parameter 54 and repeat steps ③ and ④.


Note : Confirm that zero-point return LS (DEC or STP) is on the zero-point return direction, (parameter 50) before carrying out zero-point return.  
 When using an incremental encoder, software LS cannot be operated until zero-point return completion.



• Servopack Type HR  BAB

Operation section (Servopack panel face)

SW1 to SW3 are digital switches (rotated by a small-size screwdriver.)




Setting is performed for the following procedures after moving to the machine zero-point in manual operation mode.

Procedures	Operation Method	(7-SEG. LED) ALARM Lighting						
①	Set toggle switch (MO-neutral-WR) in neutral status.	— blinks.						
②	Set SW1 to SW3 as shown below: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>7</td> <td>0</td> <td>0</td> </tr> </table>		SW1	SW2	SW3	7	0	0
SW1	SW2	SW3						
7	0	0						
③	Lower toggle switch to WR side. (Return to neutral.)	0 blinks.						
④	Set SW1 to SW3 as shown below: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>7</td> <td>7</td> <td>7</td> </tr> </table>		SW1	SW2	SW3	7	7	7
SW1	SW2	SW3						
7	7	7						
⑤	Lower toggle switch to WR side. (Return to neutral.)	— blinks.						
⑥	Set SW1 to SW3 as follows and keep toggle switch in MO. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SW1</td> <td>SW2</td> <td>SW3</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> </tr> </table>	SW1	SW2	SW3	0	0	0	—
SW1	SW2	SW3						
0	0	0						
⑦	Turn off Servopack control power supply.	(Extinguished)						
⑧	Turn on only Servopack control power supply again.	—						

Machine zero-point setting is now completed.

- Servopack Type HR  BB
- Operation section (on Servopack PC board)



Setting is performed for the following procedures after moving to the machine zero-point in manual operation mode.

Procedures	Operation Method	Display
①	Depress SW3 <input type="button" value="NO/DATA"/> .	<i>RL-00</i>
②	Depress SW5 <input type="button" value="MODE/▷"/> twice until the display shown on the right is obtained.	<i>05-00</i>
③	Depress SW3 <input type="button" value="NO/DATA"/> .	<i>0000</i>
④	Depress SW6 <input type="button" value="HOME/SET"/> . (Set current position to machine zero-point)	—
⑤	Depress SW3 <input type="button" value="NO/DATA"/> .	<i>05-00</i>
⑥	Depress SW6 <input type="button" value="HOME/SET"/> . (Baud rate setting completed.)	<i>-.bb</i>
⑦	Depress SW6 <input type="button" value="HOME/SET"/> . (Operation is reset. This procedure makes the above setting effective.)	—

Machine zero-point setting is now completed.

## 11.3 SERVO PERFORMANCE ADJUSTMENT


### 11.3.1 Parameter Setting

- (1) Position Loop Gain  $K_p$  is stored in parameter 1. (30 is set prior to shipping).
- (2) Speed Loop Gain  $K_v$  is stored in parameter 2.

The cutoff frequency  $f_c$  based on the reflected load inertia can be calculated as follows. A factor of 2.5 applies to the value in parameter.

$$\text{Parameter 2 set value} \times 2.5 \text{ (Hz)}$$

Inertia variation for the same parameter value changes the cutoff frequency  $f_c$ .



{  $J_M$ : Motor inertia,  $J_L$ : Reflected load inertia }

$$J_L/J_M = x$$

$$\text{Cutoff frequency } f_c = \text{parameter 2} \times \frac{5}{x+1} \text{ (Hz)}$$

① Parameter

Set value is  $20(x+1)$

( $f_c = 100\text{Hz}$  for equivalent inertia)

- ② When mechanical system rigidity is low, it may be impossible to obtain the above value. Therefore, set  $20(x+15)$  at the beginning.

Then start increasing this number to the calculated optimum or up to system instability.

[Factory default is 15 with  $x=0$  (no load). ]

- (3) Integral time constant  $T_i$  is stored in parameter 3.

Default value is 10 (20ms). (Keep the default value.)

### 11.3.2 Adjusting Method—Kp, Kv' Optimum Setting

- Servopack Type HR [ ] [ ] BAB [ ] [ ]

Check terminal to monitor analog speed output V<sub>RG</sub> <sup>\*1</sup>.

- Servopack Type HR [ ] [ ] BB

Check terminal to monitor analog speed output TMI-1 <sup>\*2</sup>.

Speed Monitor Waveform	Adjusting Method	Remarks
	<p>Optimum setting status with good response follow-up performance without overshooting or oscillation.</p>	<p>Because of mechanical system rigidity, the waveform shown to the left may not be obtained.</p>
	<p>If overshooting or oscillation occurs;</p> <ul style="list-style-type: none"> <li>• Decrease Kp set value gradually.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>• Increase Kv' set value gradually.</li> <li>• If overshooting or oscillation go worse when increasing Kv' set value. Decrease Kv' set value gradually.</li> </ul>	<p>When considerable Kp value is required and overshooting must be avoided, increase accel/ decel time (parameter 5) value.</p>
	<p>For poor response follow-up performance:</p> <ol style="list-style-type: none"> <li>① Increase Kp set value gradually.</li> <li>② When Kp cannot be increased because of vibration, etc., increase Kv' set value gradually.</li> </ol>	<p>When Kv' set value increase causes vibration by ②, it indicates that follow-up performance (including that of the mechanical system) reaches the limit.</p>

\*1 Refer to Par. 9.2.1

\*2 Refer to Par. 9.2.2

## 11.4 INSPECTION AND MAINTENANCE

### 11.4.1 AC Servomotor

The AC Servomotor has no wearing parts (e.g. brushes), so simple daily inspection is sufficient. The inspection schedule for the motor is shown in Table 11.1.

Do not disassemble the motor. If disassembly is necessary, contact your Yaskawa representative.

Table 11.1 Inspection Schedule for Motors

Inspection Item	Frequency	Inspection Operation	
Vibration	Daily	Feel manually	If abnormal vibration or noise is found, contact your Yaskawa representative.
Noise		Aurally	
Exterior and Cleaning	As required	Clean with dry cloth or compressed air.	
Insulation Resistance	Yearly	Make sure that it is more than 10MΩ by measuring with a 500V megger after disconnecting the motor from Servopack.	
Oil Seal	Every 5000 hours	Replace oil seal.	
Overhaul	Every 20,000 hours or every 5-year	If worn or damaged, replace after disconnecting the motor from the driven machine.	

### 11.4.2 Servopack

Servopack does not require any daily maintenance. However, it is advisable to perform maintenance as shown in Table 11.2 at least once a year.

Table 11.2 Inspection Schedule for Servopack

Inspection Item	Frequency	Operation	Corrective Action
Cleaning of Servopack and board	Every 1 year	Visually check for dust or oil on parts.	Clean with dry cloth or compressed air.
Loose screws		Check for loose screws of terminals and connectors of 2CN to 5CN of Servopack.	Retighten.
Deterioration of Servopack and/or parts on the board		Visually check for discoloration, breakage or disconnection resulting from heat, bumping, etc.	Contact your YASKAWA representative.
Cooling fan		Check that the fan rotates normally.	

• Parts Replacement Schedule

The parts shown in Table 11.3 should be replaced periodically since they may become worn mechanically/physically or deteriorate with age.

Table 11.3 Parts Replacement Schedule

Parts Name	Interval	Remarks
Smoothing capacitor	7 to 8 years	Replace with new one. (Decided after inspection)
Circuit protector or relays	Variable	Upon inspection, decide whether they should be replaced.
Aluminum electrolytic capacitors on PC board	10 years	Replace with new board. (Decided after inspection)

Note: Optimum operating environment is as follows:

Ambient temperature: 30°C on average

Load factor: 80% or less

Operating rate: 20 hours or less per day

### 11.4.3 Battery Replacement

Replace the Servopack batteries (ER6VC3 provided with connector: made by Toshiba Battery Co., Ltd.) as follows. (Service life is about 10 years.)

- ① Remove the screws mounted on the panel and remove the battery holder (only for Servopack Type HR [ ] BAB [ ]).
- ② Pull out the battery connector from the connector on the board.
- ③ Insert a new battery connector correctly.
- ④ Remount the battery holder (only for Servopack Type HR [ ] BAB [ ]).
- ⑤ Insert a new battery in the battery holder.

## 11.5 TROUBLESHOOTING GUIDE

### 11.5.1 AC Servomotor

If malfunctions occur during operation, provide appropriate corrective actions according to Table 11.4. If any malfunction cannot be corrected, contact your Yaskawa representative.

**WARNING**  
 Actions in  should be implemented after turning off the power.






Table 11.4 Troubleshooting Guide for AC Servomotor

Trouble	Cause	Corrective Action
Motor does not start.*	Loose connection	Tighten connection
	Wrong wiring	Correct.
	Overload	Reduce load or use a larger motor.
Unstable operation	Wrong wiring	Inspect and correct wiring across motor terminals U, V, and W, and PG.
Motor overheats.	Excessive ambient temperature.	Reduce below 40 °C
	Motor dirty	Clean motor surface.
	Overload	Reduce load or use a larger motor.
Unusual noise	Motor loosely mounted	Tighten foundation bolts.
	Motor misaligned	Realign.
	Coupling out of balance	Balance coupling.
	Noisy bearing	Check alignment, loading of bearing, lubrication. Contact your YASKAWA representative if it cannot be corrected.
	Vibration of driven machine	Contact the machine manufacturer.

\* When the motor won't start, check if speed command has returned to zero.  
 (Example) Speed command is from speed table but data are not set in the table.

## 11.5.2 Servopack

Table 11.5 Typical Troubleshooting by 7-segment LED Indications

	Status when an error occurs	Cause	Corrective Action	
 ABSO ERROR	Occurs when control power is applied.	I	SERVOPACK or absolute encoder malfunction	Cycle the control power supply.
		II	Using an incremental encoder	Change parameter 9 to 1.
			Motor shaft rotates more than parameter 10 set value during control power loss.	Turn on $\overline{RST}$ signal. (Or send command  .) ↓ Set machine zero point.
		III	SERVOPACK loss of home position	Send command  . ↓ Set machine zero point.
		IV	Absolute encoder data fault	① Perform absolute encoder setup. ② Send command  . ↓ Set machine zero point.
		When occurs frequently	• Absolute encoder improper wiring • Connector contact fault	Correct wiring.
			Absolute encoder fault	Replace motor.
SERVOPACK fault	Replace SERVOPACK.			
 OVER-CURRENT	Occurs when control power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.	
	Occurs when main power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.	
	Occurs when servo on.	Motor improper wiring	Correct wiring. ↓ When occurs again, replace SERVOPACK.	
		Motor grounding	Replace motor.	
		SERVOPACK fault	Replace SERVOPACK.	
	Occurs when motor is running.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.	
		Improper motor code setting	Change parameter 7 to suitable value for the motor.	

(Cont'd)



(Cont'd)

	Status when an error occurs	Cause	Corrective Action
2 CIRCUIT PROTECTOR TRIP	In case SERVOPACK MCCB is not tripped	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	In case SERVOPACK MCCB is tripped		
	Occurs when control power is applied.	SERVOPACK MCCB is manually turned off. (type HR [ ] BB)	Turn on MCCB and cycle the control power.
	Occurs when main power is applied.	SERVOPACK MCCB is manually turned off. (type HR [ ] BAB)	Turn on MCCB and cycle the control power.
		SERVOPACK main circuit fault	Replace SERVOPACK.
	Occurs when servo on.	Motor improper wiring	Correct wiring. ↓ When occurs again, replace SERVOPACK.
Motor grounding		Replace motor.	
SERVOPACK fault		Replace SERVOPACK.	
3 REGENERA- TIVE ERROR	Occurs when control power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs in apporox. 0.5 to 1 second after main power is applied.	SERVOPACK fault	Replace SERVOPACK.
4 OVER- VOLTAGE	Occurs when control power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs when main power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs during deceleration	Excessive load inertia	Check application and motor sizing. (Reduce deceleration)
SERVOPACK fault		Replace SERVOPACK.	
5 OVERSPEED	Occurs when motor running.	Improper gain setting (Kp, Kv, acceleration)	Set gains as described in parameter 1, 2, 4.
		Falling load on vertical axis	Use holding brake.
		SERVOPACK fault	Replace SERVOPACK.
6 UNDER- VOLTAGE	Occurs when control power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs when main power is applied.		

(Cont'd)

(Cont' d)

	Status when an error occurs	Cause	Corrective Action
<b>7.</b> OVERLOAD	Occurs when control power is applied.	SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs during operation. (Operation restarts when control power supply is turned off and then on.)	Improper motor code setting	Change parameter 7 to suitable value for the motor.
		Operation is performed at 105 to 130% or more of rated load.	<ul style="list-style-type: none"> <li>• Check load (overload).</li> <li>• Verify motor sizing and application data.</li> </ul>
	<ul style="list-style-type: none"> <li>• Motor rotates but no torque is obtained.</li> <li>• Motor does not rotate.</li> </ul>	Improper motor code setting	Change parameter 7 to suitable value for the motor.
		Improper motor wiring or single-phase connection	Correct wiring.
		Improper encoder pulse/rev setting	Change parameter 8 to suitable value for the encoder.
<b>8.</b> POSITION ERROR	Occurs when control power is turned on.	Using an incremental encoder	Change parameter 9 to 1.
		Improper encoder pulse/rev setting	Change parameter 8 to suitable value for the encoder.
		Improper encoder wiring	Correct wiring.
		Absolute encoder malfunction	Set up absolute encoder.
		SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs during operation.	Improper encoder pulse/rev setting	Change parameter 8 to suitable value for the encoder.
		Improper encoder wiring	Correct wiring.
		Noise to encoder wiring	Perform noise treatment.
<b>9.</b> HEAT SINK OVERHEAT	<ul style="list-style-type: none"> <li>• Occurs during operation.</li> <li>• Occurs when control power is turned OFF and then ON again.</li> <li>• Operation restarts after reset and after a while.</li> </ul>	Fan does not rotate.	Check fan applied SERVOPACK type HR20, 30, 44BB.
		SERVOPACK ambient temperature exceeds 55°C.	Lower SERVOPACK ambient temperature to 55°C or less.

(Cont' d)

(Cont'd)

	Status when an error occurs	Cause	Corrective Action	
<b>E.</b> PG DIS- CONNECTION	Occurs when control power is applied.	Improper encoder wiring	Correct wiring.	
		Alarm of 12bit absolute encoder occurred	Perform absolute encoder setup.	
		Multifunction of absolute encoder	Perform absolute encoder setup.	
		SERVOPACK fault	Replace SERVOPACK.	
		Encoder fault	Replace motor.	
<b>F.</b> OPEN PHASE DETECTION	Occurs when control power is applied.	SERVOPACK multifunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.	
	Occurs when main power is applied.	3-phase power supply improper connection	Check connection.	
		Improper motor code setting (type HR [ ] BAb1 [ ] only)	Change parameter 7 to suitable value for the motor.	
		SERVOPACK multifunction or fault	Cycle the control power supply, ↓ When occurs again, replace SERVOPACK.	
<b>H.</b> HARD ERROR	Occurs when control power is applied.	SERVOPACK multifunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.	
	Occurs when main power is applied.			
	Occurs during operation.			
<b>J.</b> OVERFLOW	Occurs when control power is applied.		SERVOPACK multifunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs during motor running.	Occurs during accel./decel.	Excessive acceleration	Change parameter set value.
			Excessive feed speed	Change parameter or reference speed.
			Excessive load	Check load (torque, inertia) and application data.
	Occurs during motor running.	Vibration, etc. occurs.	Speed loop gain is low.	Set slightly larger parameter 2 set value.
		Motor does not operate on command.	Improper motor wiring	Correct wiring.
			Encoder multifunction or fault	When absolute encoder is used, perform absolute encoder setup. ↓ When occurs again or incremental encoder is used, replace motor.

(Cont'd)

11

(Cont'd)

	Status when an error occurs	Cause	Corrective Action
L OVERRUN	Occurs when control power is applied.	Absolute encoder is used.	Change parameter 9 to 0.
		Improper incremental encoder wiring.	Correct wiring.
		SERVOPACK malfunction or fault	Cycle the control power supply. ↓ When occurs again, replace SERVOPACK.
	Occurs at starting after operating for a while.	Improper motor code setting	Change parameter 7 to suitable value for the motor.
		Improper encoder pulse/rev setting	Change parameter 8 to suitable value for the encoder.
		Improper motor wiring	Correct wiring.
		Improper encoder wiring	Correct wiring.
Y PARAMETER ERROR	Occurs when control power is applied.	Parameter data fault (When error parameter No.≠00)	Verify parameter value and rewrite it.
		Table (Position/Speed/Boundary data fault) (When error parameter No.=00)	Check table value and rewrite it.
		SERVOPACK fault	Replace SERVOPACK.
d. (Blinks) BATTERY VOLTAGE LOW	Occurs when control power is applied.	Battery is not connected	Check battery connection.
		Battery connector contact fault	
		Battery voltage reduction	Replace battery. (If battery runs down in short time, check encoder connection or set up absolute encoder.)
		SERVOPACK fault	Replace SERVOPACK.

# 12 PERIPHERAL DEVICES

## 12.1 COMBINATION OF PERIPHERAL DEVICES

Table 12.1 Combination of Servopack, Servomotor M Series and Peripheral Devices

Servopack Type CACR-	AC Servomotor Type USAMED-	Power Capacity per Servopack* <sup>1</sup> kVA	Current Capacity Per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter* <sup>2</sup>		Power ON/OFF Magnetic Contactor	
					Type	200VAC Class		
HR03BAB12	03□□ 1	1.0	7	<div style="text-align: center;">                     Good                      ↓                      Poor  </div>	LF-215	15A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent	
HR10BAB	06□□ 1 09B □ 2	2.1	8		LF-315	15A		
HR15BAB	12B □ 2	3.1	10					
HR03BB	03□□ 1	0.65	5		LF-305	5A		
HR10BB	06□□ 1	1.5	8		LF-310	10A		
	09B □ 2	2.1	8					
HR15BB	12B □ 2	3.1	10		LF-315	15A		
HR20BB	20B □ 2	4.1	12		LF-320	20A		YASKAWA Type HI-18E (35A) or equivalent
HR30BB	30B □ 2	6.0	18		LF-330	30A		
HR44BB	44B □ 2	8.0	24		LF-340	40A		
HR60BB	(USAMKD-) 60B □ 2	11	32		LF-350	50A		YASKAWA Type HI-25E (50A) or equivalent

\*1 Values at rated load

\*2 Made by Tokin Corp.

Table 12.2 Combination of Servopack, Servomotor F Series and Peripheral Devices



Servopack Type CACR-	AC Servomotor Type USAFED-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor		
					Type	200VAC class			
HR03BAB12	02 [ ] 1	1.0	7	Good 	LF-210	10A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent		
	03 [ ] 1								
HR05BAB12	05 [ ] 1	1.4	11		LF-215	15A			
HR10BAB	09 [ ] 1	2.1	8		LF-315	15A			
HR15BAB	13C [ ] 2	3.1	10						
HR03BB	02 [ ] 1	0.65	5		Poor 	LF-305		5A	YASKAWA Type HI-18E (35A) or equivalent
	03 [ ] 1								
HR05BB	05 [ ] 1	1.1	5			LF-305		5A	
HR10BB	09 [ ] 1	2.1	8			LF-315		15A	
HR15BB	13C [ ] 2	3.1	10						
HR20BB	20C [ ] 2	4.1	12	LF-320		20A			
HR30BB	30C [ ] 2	6.0	18	LF-330		30A			
HR44BB	44C [ ] 2	8.0	24	LF-340		40A			

Table 12.3 Combination of Servopack, Servomotor G Series and Peripheral Devices



Servopack Type CACR-	AC Servomotor Type USAFED-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor		
					Type	200VAC class			
HR03BAB12	02 [ ] 1	1.0	7	Good 	LF-210	10A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent		
	03 [ ] 1								
HR05BAB12	05 [ ] 1	1.4	11		LF-215	15A			
HR10BAB	09 [ ] 1	2.1	8		LF-315	15A			
HR15BAB	13A [ ] 2	3.1	10						
HR03BB	02 [ ] 2	0.65	5		Poor 	LF-305		5A	YASKAWA Type HI-18E (35A) or equivalent
	03 [ ] 1								
HR05BB	05 [ ] 1	1.1	5			LF-305		5A	
HR10BB	09 [ ] 1	2.1	8			LF-315		15A	
HR15BB	13A [ ] 2	3.1	10						
HR20BB	20A [ ] 2	4.1	12	LF-320		20A			
HR30BB	30A [ ] 2	6.0	18	LF-330		30A			
HR44BB	44A [ ] 2	8.0	24	LF-340		40A			

Table 12.4 Combination of Servopack, Servomotor D Series and Peripheral Devices



Servopack Type CACR-	AC Servomotor Type USADED-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor
					Type	200VAC class	
HR05BAB12	05E □	1.4	11	Good  Poor 	LF-215	15A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent
HR15BAB	10E □	3.1	10		LF-315	15A	
HR05BB	05E □	1.5	8		LF-310	10A	
HR15BB	10E □	3.1	10		LF-315	15A	
HR20BB	15E □	4.1	12		LF-320	20A	YASKAWA Type HI-18 (35A) or equivalent
HR30BB	22E □	6.0	18		LF-330	30A	
HR44BB	37E □	8.0	24		LF-340	40A	

Table 12.5 Combination of Servopack, Servomotor S Series and Peripheral Devices



Servopack Type CACR-	AC Servomotor Type USADED-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor
					Type	200VAC class	
HR02BAB12	02A □	0.75	5	Good  Poor 	LF-205A	5A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent
HR03BAB12	03A □	1.0	7		LF-210	10A	
HR05BAB12	05A □	1.4	11		LF-215	15A	
HR10BAB	08A □	2.1	8		LF-315	15A	
HR15BAB	15A □	3.1	10		LF-305	5A	YASKAWA Type HI-18E (35A) or equivalent
HR03BB	02A □	0.65	5				
	03A □						
HR05BB	05A □	1.1	5		LF-315	15A	
HR10BB	08A □	2.1	8				
HR15BB	15A □	3.1	10		LF-330	30A	
HR30BB	30A □	6.0	18				

Table 12.6 Combination of Servopack, Servomotor R Series and Peripheral Devices







Servopack Type CACR-	AC Servomotor Type USARED-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor		
					Type	200VAC class			
HRA5BAB12	A5C [ ] 2	0.3	5	Good  Poor 	LF-205A	5A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent		
HR01BAB12	01C [ ] 2	0.5							
HR02BAB12	03C [ ] 2	0.75							
HR03BAB12	03C [ ] 2	1.0	LF-210		10A				
HR05BAB12	05C [ ] 2	1.4	LF-215		15A				
HR10BAB	07C [ ] 2	2.1	LF-315		10A				
HRA5BAB11	A5D [ ] 2	0.3	5		Good  Poor 	LF-205A		5A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent
HR01BAB11	01D [ ] 2	0.5							
HR02BAB11	02D [ ] 2	0.75	LF-210			10A			
HR03BAB11	03D [ ] 2	1.0	LF-215			15A			
HR05BAB11	05D [ ] 2	1.4	LF-220	20A					

Table 12.7 Combination of Servopack, Servomotor P Series and Peripheral Devices

Servopack Type CACR-	AC Servomotor Type USAPEN-	Power Capacity per Servopack kVA	Current Capacity per MCCB of Fuse A	Applicable Noise Filter	Recommended Noise Filter		Power ON/OFF Magnetic Contactor
					Type	200VAC class	
HR01BAB12	USAPEM-01C [ ] 2	0.5	5	Good  Poor 	LF-205A	5A	YASKAWA Type HI-15E <sub>2</sub> (30A) or equivalent
HR02BAB12	USAPEM-02C [ ] 2	0.75					
HR03BAB12	USAPEM-03C [ ] 2	1.0	LF-210		10A		
HR05BAB12	USAPEM-05C [ ] 2	1.4	LS-215		15A		
HR10BAB	USAPEM-10C [ ] 2	2.1	LF-315		10A		




## 12.2 BRAKE POWER SUPPLY

There are two types of brake power supplies for M, F, G and D series and for S, R and P series. Select one suitable for the applicable motor.

(a) Power supply unit for S, P, R series (made by YASKAWA CONTROL CO., LTD.)

- Input 100VAC, output 90VDC, Max. 1.0ADC (B9400876-2) type LPDE-1H01
- Input 200VAC, output 90VDC, Max. 1.0ADC (B9400876-1) type LPSE-2H01

Dimensions in mm (inches)




- Lead Length: 500mm for each (19.69inches.)
- Lead Color Distinction


AC Input Side		Brake Side
100V	200V	
Blue White	Yellow White	Red Black

- Max Ambient Temperature 60° C

100VAC: Internal Circuit



200VAC: Internal Circuit




- Notes:
1. Do not short-circuit between output leads.
  2. Insert a fuse in the input or output side to protect the power supply.
  3. Brake power supply circuit can be opened/closed either at AC or DC side. Normally, it is safer to open/close at AC side. (However, brake time becomes longer.) To open/close at DC side, brake coil may be damaged by surge voltage. Be sure to use a surge suppressor (CR50500BL (made by Okaya Electric Industries Co., Ltd.) or equivalent) near brake coil.

(b) Power supply unit for M, F, G, D series (made by Ogura Clutch Co., Ltd.)



- Input 100VAC, output 90VDC, Max. 1.0A (type OPR 109F)
- Input 200VAC, output 90VDC, Max. 1.0A (type OPR 109A)

Dimensions in mm (inches)




Type OPR109F Circuit Diagram

Type OPR109A Circuit Diagram



Recommended fuse : type MF60 NR2 (made by TOYO FUSE CO., LTD.)


Circuit Diagram



- Notes :
1. Do not short-circuit between output terminal Nos. 3 and 4.
  2. The rated current of the contact used for Nos. 5 and 6 is 5 to 10 times the rated current of the brake used. Contacts for DC power must be used.
  3. Insert a fuse in the input side to protect the power supply.
  4. Brake power supply circuit can be opened/closed either at AC or DC side. Normally, it is safer to open/close at AC side. (However, brake time becomes longer.) To open/close at DC side, brake coil may be damaged by surge voltage. Be sure to use a surge suppressor (CR50500BL(made by Okaya Electric Industries Co., Ltd.) or equivalent) near brake coil.

# 12.3 BRAKING RESISTOR UNIT (TYPE JUSP-RA03)

For Sarvopack Type CACR-HR60BB




## 12.4 EXTERNAL POSITION INDICATOR (TYPE MC1F-L8)

### (1) Specifications

Item \ Type	MC1F-L8	MC1F-L8-24*	MC1F-L8-A1 *
Power supply	5VDC, 1A	24VDC, 0.5A	100VAC, 0.2A
Power supply variation range	4.75 to 5.25V	18 to 27VDC	85 to 120VAC
Operating temperature	0 to +55°C		
Storage temperature	-20 to +80°C		
Operating/storage humidity	90% or less		
Vibration or shock resistance	Vibration resistance: 4.9m/s <sup>2</sup> (0.5G)(10 to 55Hz) Shock resistance: 19.6m/s <sup>2</sup> (2G)		
Number of display digits	- sign indication and 8-digit number		
Connecting method	Serial communication, connected to connector 4CN of CACR-HR.		

Note: Types marked with \* are manufactured on order.

### (2) Circuit block diagram




Note: Do not connect anything to 1CN pin 7 or 8 since they are for test. Other pins are not used.

Power Supply and Connection

Type \ ITB	1	2	3
MC1F-L8	+5V	0	FG
MC1F-L8 24	+24V	0	FG
MC1F-L8-A1	AC100V	(AC100V)	FG

(3) Dimensions in mm (inches)  
 Type MCIF-L8



Surface processing :  
 Electrodeposition coating, N1.5 in Munsell notation (black)  
 Mass : 0.6kg (1.3lb)


\*Applicable receptacle  
 soldered type : MR-16F  
 caulking type : MRP-16F01  
 case : MR-16L

## 12.5 DIGITAL SWITCH UNIT (TYPE MCIF-D   )





### (1) Specifications

Item \ Type	MCIF-D86	MCIF-D66	MCIF-D44	MCIF-D80	MCIF-D60	MCIF-D40
Data contents	2-step(position/speed reference data)			1-step(only position reference data)*		
Position reference data	BCD 8-digit	BCD 6-digit	BCD 4-digit	BCD 8-digit	BCD 6-digit	BCD 4-digit
Speed reference data	BCD 6-digit	BCD 6-digit	BCD 4-digit	None		
Operating temperature	0 to +55°C					
Storage temperature	-20 to +80°C					
Vibration or shock resistance	Vibration resistance: 4.9m/s <sup>2</sup> (0.5G)(10 to 55Hz) Shock resistance: 19.6m/s <sup>2</sup> (2G)					
Connecting method	Connect 5CN to CACR-HR.					

### (2) Circuit Diagram







(3) Dimensions in mm (inches)  
Type MCIF-D44, -D66, -D86



Number of Digits	Speed	Type	Lmm(in)
4	4	MCIF-D44	47.5(1.87)
6	6	MCIF-D66	63.5(2.5)
8	6	MCIF-D86	79.5(3.13)

Surface treatment :  
Electrodeposition N1.5 in Munsell notation (black)  
Approx. Mass : 0.3kg (0.7lb)

Type MCIF-D40, -D60, -D80



Number of Digits	Type	L mm(in)
4	MCIF-D40	47.5(1.87)
6	MCIF-D60	63.5(2.5)
8	MCIF-D80	79.5(3.13)


Surface treatment :  
Electrodeposition N1.5 in Munsell notation (black)  
Approx. Mass : 0.2kg (0.4lb)

\*Applicable receptacle  
soldered type : MR-25F  
caulking type : MRP-25F01  
case : MR-25L


## 12.6 CONTACT INPUT UNIT (TYPE MCIF-R86)

### (1) Specifications

Item	Type	MCIF-R86
Data contents		Position reference (sign signal and 8-digit BCD signal) Speed reference (6-digit BCD signal)
Operating temperature		0 to +55°C
Storage temperature		-20 to +80°C
Operating/storage humidity		99% or less
Vibration or shock resistance		Vibration resistance: 4.9m/s <sup>2</sup> (0.5G)(10 to 55Hz) Shock resistance: 19.6m/s <sup>2</sup> (2G)
Input conditions		<ul style="list-style-type: none"> <li>• Power supply 24VDC, photocoupler input (drive current 7mA)</li> <li>• Dry contact and transistor open collector input</li> <li>• Position data: 1CN connector</li> <li>• Speed data: 2CN connector</li> </ul>
Connecting method		Connect 3CN to CACR-HR 5CN




### (2) Dimensions in mm (inches) Type MCIF-R86



Attachments	
1CN connector for cable	
Case	MR-50L (Made by Honda)
Receptacle	MR-50F (Tsushin Co.)
2CN connector for cable	
Case	MR-34L (Made by Honda)
Receptacle	MR-34F (Tsushin Co.)
3CN connector for cable	
Case	MR-25L (Made by Honda)
Receptacle	MR-25F (Tsushin Co.)



(3) Circuit block diagram



# 12.7 MANUAL PULSE GENERATOR (TYPE PREH-2C3T/100-M1)


## (1) Specifications

Item	Type	PREH-2C3T/100-M1
Power supply		5VDC $\pm$ 10%, 150mA
Output waveform, output type		Rectangular wave, line driver output
Number of output pulses, output signal		100 pulses/rev. 90° phase difference 2 signals (phases A and B)
Operating temperature		0 to +50°C
Storage temperature		-30 to +70°C
Operating/storage humidity		20 to 80% RH
Vibration or shock resistance		Vibration resistance: 4.9m/s <sup>2</sup> (0.5G)(10 to 55Hz) Shock resistance: 19.6m/s <sup>2</sup> (2G)
Connecting method		Connect CACR-HR 4CN


## (2) Output terminal Arrangement

Symbol	Function
1	+V (DC5V)
2	V (0V)
3	SIG. A
4	SIG. $\bar{A}$
5	SIG. B
6	SIG. $\bar{B}$


Note: When connecting to Servopack, reverse SIG. A and SIG.  $\bar{A}$  on Par 5.1, as follows:




(3) Dimensions in mm (inches)



Note: Receiver IC is AM26LS32C, SN75175 or equivalent.



# 12.8 CONNECTING CABLE



Note: Cable length: 1,3 or 5 meters (39.37, 118.11 or 196.85 inches)  
 For 4CN or 5CN, select one cable suitable for the system.

## 12.9 PARAMETER SETTER (PF803)

### 12.9.1 Specifications

#### (1) Display

Display element	TN type LCD
Display screen	20 columns × 4 lines
Display character composition	5 × 7 dots matrix
Display character size	4.75 × 2.95 mm/character (0.19 × 0.12 in./character)
Display character type	Alphabets (capital, small), numeric, symbols (Total 195 types)
Cursor display method	Blinked block
Status display	4 LED lamps • Alphabet small letters mode: red • On-line mode: orange • Edit mode: green • Transmission mode: yellow
Backup battery check display	1 red LED lamp

#### (2) Control

CPU	8-bit CMOS micro-processor (Basic clock: 7.37MHz)
Buffer memory	2000 bytes for terminal, 100000 bytes for file data
Built-in backup battery	1 NiCd battery (3.6V, 40mAH, rechargeable) Exclusive-use for buffer memory backup
Buzzer	1 piezoelectric buzzer

### (3) Keyboard

Key top	Membrane shielded type
Switch for keys	Switch with click feedback
Data input keys	44 keys
Shift key	1 key for key top lower data input
Capital key	1 key for switching alphabet capital/small
Window key	1 key for window up/down
Battery check key	1 key for check voltage of battery exclusive use for buffer memory backup
Reset key	1 key
Key input code type	JIS code mode : 192 types ASCII code mode: 128 types
Function keys	For 5 keys Max. 64-code train registration possible per key

### (4) Interface

Using codes	JIS 7-bit, 8-bit or ASCII code
Character composition	Asynchronous type 9, 10, 11 or 12 bits
Parity	Even, odd, mark, space, or no-parity
Data type	Bit serial
Data communication speed	110, 150, 300, 600, 1200, 2400, 4800, 9600 or 19200 bps
Data signal type	• Host system port : RS-232C (in accordance with EIA-232D /JIS C6361)

(5) Power Supply

Using battery	Exclusive-use nickel-cadmium set battery (Type: FA4/700AAF) Nominal capacity: 700mAH
Power supply switch	1
Recharging jack	1
Consumed power	At normal operation: • Local mode At standby: 115mW At data processing: 300mW • Online mode At data processing: 580mW

(6) External Dimensions and Mass

Main body	205D × 110W × 35H mm (8.07D × 4.33W × 1.38H inches) Mass: 580 g (1.281b)
Interface cable, connector	Shielded cable, Host system side connector: D-sub(25pins) Removable from the main body Standard 2m (78.74in.) long (type PEC803-02)


(7) Operational Environment

Environment	Shockproof, dustproof and noise resistant specifications in standard interface cable (PEC803-02 type)
Ambient temperature	At operation: 0 to +45°C At storage : -10 to +60°C
Humidity	5 to 90% RH

(8) AC Adapter (Type PAC803-A)


Output	7.5VDC ± 1V, 2.25W
Power supply	100 ± 10VAC (50/60Hz)
External dimensions, mass	• Main body: 60D × 50W × 40H mm (2.36D × 1.97W × 1.57H inches) 210g (0.461b) • DC output cable: 1.9m (74.8 in.)
Operating temperature	+10 to +40°C
Applicable type	PF803-AS type, operation possible during recharging

## 12.9.2 External View





### 12.9.3 How to Use






#### Power Supply:

- Can be used with AC adapter connected.
- Can be recharged fully for 48 hours and used for 10 hours without AC adapter.
- If not used for 40 days or more, charge it, for at times setup information or files may disappear.

#### Key Operation:

- Do not depress **SHIFT** simultaneously with other keys. Depress **SHIFT** key and release it before depressing another key.

(Depressing **SHIFT** key changes the cursor from  to  .)

- After depressing **CTL BRK** key (control key), release it, depress another key.
- When used connecting with Servopack, if wrong key input is made, **DEL** and  key cannot be used.

In this case, input any character to cause an error by **ENT** and start key input again from the beginning.

Setup (For the first use, perform the following setup.)

< Operation >

1.
 

MENU	
F1=TELCOM	F2=TEXT
F3=SET UP	F4=TEST

<Display 1>
2. SHIFT + V  
F3
3.
 

SETUP-MODE	
F1=COM	F2=DISPLAY
F3=KEY	F4=RS232C
F5=MENU	
4. Set the setup data as the following procedure.
  - ① SHIFT + T  
F1

COMMUNICATION	SPEED	
9600 bps		
CODE	PARITY	STOP
ASCII	Even	1Bit

ENT

XON/XOFF	LOCAL	ECHO
Enable	Disable	
DELIMITER	CHARACTER	
Cr.Lf		

ENT
  - ② SHIFT + U  
F2

SET H-TAB	STOP
1	
CR OPERATION	
Cr	

ENT

MEMORY	RETENTION
Yes	

ENT

<Description>

Displayed when turning the power on.

Select SET UP.

Displayed setup-mode.  
Set by using the following keys.

- ⇨ : selects an item to be set.
- ⇩ : sets data. See next page.
- ENT : ends the setting.

COM is selected.

- Data to be set
 

COMMUNICATION	9600 bps
SPEED	
CODE	ASCII
PARITY	Even
STOP	1Bit
XON/XOFF	Enable
LOCAL ECHO	Disable
DELIMITER	
CHARACTER	Cr.Lf
- DISPLAY is selected.

- Data to be set
 

SET-H-TAB	STOP	1
CR OPERATION		Cr
MEMORY RETENTION		Yes

③ **SHIFT** + **V F3**

KEY CLICK  
 Yes  
 AUTO REPEAT  
 Yes

**ENT**

④ **SHIFT** + **W F4**

Control RS-232C Input Signals  
 CS DSR CD  
 No No No

**ENT**

⑤ **SHIFT** + **X F5**

MENU  
 F1=TELCOM      F2=TEXT  
 F3=SET UP      F4=TEST

<Display 1>

KEY is selected.

• Data to be set

KEY CLICK	Yes
AUTO REPEAT	Yes

RS-232C is selected.

• Data to be set

CS	No
DSR	No
CD	No

Returns to MENU.

Using method when connecting with Servopack (Turn on the Servopack control power supply.)

< Operation >

MENU  
 F1=TELCOM      F2=TEXT  
 F3=SET UP      F4=TEST

<Display 1>

1. **SHIFT** + **T F1**

TELCOM-MODE  
 F1=TERM      F2=UPLOAD  
 F3=DOWNLOAD  
 F5=MENU

<Display 4>

2. **SHIFT** + **T F1**

3. **CTL BRK** + **E -**

4. Check that characters are displayed by key input.

<Description>

Select TELCOM.

Select TERM.  
Perform echo-back.

**NOTE** If strange characters are displayed, clear the screen by depressing **CTL BRK** and **L** keys.

5. Set the parameter and the table.

(ex)

- Enter 20 to parameter No. 1.

[P] [R] [M] [1] [SHIFT] [E] [2] [0] [ENT]

- Enter 11110 to parameter No. 14.

[P] [R] [M] [1] [4] [SHIFT] [E] [1] [1] [1] [1] [0] [ENT]  
(b4) (b3) (b2) (b1) (b0)

- Enter -123 to position table No. 1.

[P] [T] [1] [SHIFT] [E] [SHIFT] [B] [1] [2] [3] [ENT]  
F1 ! = - ! " #

- Enter 1000 to speed table No. 25.

[V] [T] [2] [5] [SHIFT] [E] [1] [0] [0] [0] [ENT]  
F3 F1 " % = ! - - -

- Enter 98765 to block table No. 31.

[B] [T] [3] [1] [SHIFT] [E] [9] [8] [7] [6] [5] [ENT]  
- F1 # ! = > ( . & %

6. [R] [E] [S] [ENT]

7. After approx. 3 seconds:

[CTL] [E] [P] [R] [M] [ENT]  
BRK - ) ] @

8. Check by all parameter display.

[P] [T] [ENT]  
F1

Check by all position table display.

[V] [T] [ENT]  
F3 F1

Check by all speed table display.

[B] [T] [ENT]  
- F1

Check by all block table display.

9. [SHIFT] + [X] [F5]

```

TELCOM-MODE
F1=TERM      F2=UPLOAD
F3=DOWNLOAD
F5=MENU
    
```

< Display 4 >

10. When entering parameter and table to PF803 file.

① [SHIFT] + [V] [F3]

```

File Name?   *DNLOAD*
Free Memory   [ ]
[ ] Byte
    
```

REMAINING MEMORY

< Display 5 >

When setting is completed, send reset command.

**NOTE** 1. Unused parameters No. 21 and above are not displayed.

2. The amount of over-operation can be checked by using

[↑] [↓] key.

Return to <Display 4>.

Select DOWNLOAD.

CURRENT NUMBER OF FILES

② "File Name" +   
(8 max.)

③     (for parameter)  
   (for position table)  
   (for speed table)  
   (for block table)

④ Ends when decreasing remaining memory value stops.

11. Send parameter and table entered in PF803 file to Servopack.

①  +

File Name?	*UPLOAD*
Select File	<input type="text"/>

< Display 6 >

Completes when the cursor comes under File Name? after buzzer rings.

②  +

Input file name (within 8 characters)

and depress  key.

**NOTE** Wrong key input is cleared by  key.

(No display provided.)

Select UPLOAD.

Use following keys.

: enters to file name mode.

: selects the file.

: sends the data.


Returns to <Display 4>.

Personal Computer



File exchanging method with IBM\* PC-AT\* or 100% compatible (PC-DOS\* used)

\* These brand and product names are trademarks or registered trademarks of International Business Machines Corporation.

• Connection with a personal computer, use the connector conversion cable shown below.



- Personal computer setting : Set COM1 by MODE command as follows.

MODE COM1:BAUD=12, PARITY=E, DATA=7, STOP=1   
 or MODE COM1:12, E, 7, 1 

(baud rate = 1200 baud, even parity, character = 7 bit, stop bit = 1 bit)

- Parameter Setter Setting

< Operation >

1. 

MENU	
F1=TELCOM	F2=TEXT
F3=SET UP	F4=TEST
- <Display 1>
2. 

SHIFT	+	V F3
-------	---	---------
3. 

SETUP-MODE	
F1=COM	F2=DISPLAY
F3=KEY	F4=RS232C
F5=MENU	
4. Set the setup data as the following procedure.
  - ① 

SHIFT	+	T F1
-------	---	---------

COMMUNICATION	SPEED
1200 bps	
CODE PARITY	STOP
ASCII Even	1Bit

ENT
-----

XON/XOFF	LOCAL ECHO
Disable	Disable
DELIMITER	CHARACTER
Cr.Lf	




ENT
-----

<Description>

Displayed when turning the power on.

Select SET UP.

Displayed setup-mode.  
Set by using the following keys.

-  : selects an item to be set.
-  : sets data. See below.
-  : ends the setting.

COM is selected.

- Data to be set

COMMUNICATION	1200 bps
SPEED	
CODE	ASCII
PARITY	Even
STOP	1Bit
XON/XOFF	Disable
LOCAL ECHO	Disable
DELIMITER	
CHARACTER	Cr.Lf

DISPLAY is selected.

② **SHIFT** + **U F2**

SET H-TAB	STOP
I	
CR OPERATION	
Cr	

**ENT**

MEMORY	RETENTION
Yes	

**ENT**

③ **SHIFT** + **V F3**

KEY CLICK	
Yes	
AUTO REPEAT	
Yes	

**ENT**

④ **SHIFT** + **W F4**

Control RS-232C Input Signals	
CS DSR CD	
Yes Yes No	

**ENT**

⑤ **SHIFT** + **X F5**

MENU	
F1=TELCOM	F2=TEXT
F3=SET UP	F4=TEST

<Display 1>

• Data to be set

SET-H-TAB	STOP	1
CR OPERATION		Cr
MEMORY RETENTION		Yes

KEY is selected.

• Data to be set

KEY CLICK	Yes
AUTO REPEAT	Yes

RS-232C is selected.

• Data to be set

CS	Yes
DSR	Yes
CD	No

Returns to MENU.

• PF803 → Personal computer

- ① Personal computer side : COPY/A COM1
- ② PF803 side : Same as sending to Servopack. (Display 6)  
After sending, send  and  in TERM mode.

• Personal computer → PF803

- ① PF803 side : Same as receiving from Servopack.  
But, do not send
- ② Personal computer side : COPY/A  COM1
- ③ PF803 side : After receiving,  .

Perform setup (See pages 240 and 241) again after file exchanging with personal computers.


# 13 DIMENSIONS

## 13.1 AC SERVOMOTOR WITH ABSOLUTE ENCODER

(1) M Series

Dimensions in mm (inches)

Drawing 1 USAMED-03B□1, -06B□1 (Taper Shaft), -09B□2 (Straight Shaft)



For -03B□1, -06B□1


For -09B□2

Detail of Shaft Extension

Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Key and keyway comply with JIS B 1301-1976.  
(Parallel key, keyway : common class.)
3. Motor should be mounted with connectors down.
4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)

Drawing 2 USAMED-12B□2 to -44B□2 (Straight Shaft)




Detail of Shaft Extension

Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Motor should be mounted with connectors down.
3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)

Drawing 3 USAMKD-60B□2 (Straight Shaft)



Detail of Shaft Extension

Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Motor should be mounted with connectors down.
3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)



AC Servomotor Type USAMED*	Dwg. No.	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	Flange Surface						Shaft Extension		Approx Mass kg (lb)	
												LA	LB	LC	LE	LG	LH	LZ	S		Q
03B:1†	1	277 (10.91)	219 (8.63)	150 (5.91)	58 (2.28)	69 (2.72)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	9 (19.8)
06B:1†		334 (13.15)	276 (10.87)	207 (8.15)	58 (2.28)	69 (2.72)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	14 (30.9)
09B:2†		403 (15.87)	345 (13.59)	276 (10.87)	58 (2.28)	69 (2.72)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 (0.866)	40 (1.575)	20 (44.1)
12B:2†	2	344 (13.54)	265 (10.43)	211 (8.30)	79 (3.11)	54 (2.13)	171 (6.73)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 (1.3779)	76 (2.992)	22 (48.5)
20B:2		401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.01)	294 (11.57)	123 (4.84)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 (1.3779)	76 (2.992)	29 (63.9)
30B:2		486 (19.13)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.84)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 (1.3779)	76 (2.992)	41 (90.4)
44B:2		688 (27.09)	578 (22.76)	524 (20.63)	110 (4.33)	54 (2.13)	476 (18.74)	550 (21.65)	123 (4.84)	149 (5.87)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	42 (1.6535)	110 (4.33)	66 (145.5)
60B:2		800 (31.50)	690 (27.17)	—	110 (4.33)	—	476 (18.74)	583 (22.95)	123 (4.84)	149 (5.87)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	42 (1.6535)	110 (4.33)	71 (156.5)

\* For servomotor of 6kW, "K" is used instead of "E", because of externally fan-cooled type.  
† Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAMED-	Motor Connector Types				Absolute Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
03B:1 06B:1 09B:2	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
12B:2 20B:2 30B:2	MS3102 A22-22P	MS3108 B22-22S	MS3106 B22-22S	MS3057 -12A				
44B:2	MS3102	MS3108	MS3106	MS3057				
USAMKD-60B:2*	A32-17P	B32-17S	B32-17S	-20A				

\* Cooling fan receptacle : MS 3102 A 14 S-6P  
Cooling fan plug : MS 3108 B 14 S-6S  
Cooling fan clamp : MS 3057-6 A


Servomotors with a brake are also available.

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A) 0.04 (0.0016)	
Flange diameter concentric to shaft (B) 0.04 (0.0016)	
Shaft run out (C) 0.02 (0.0008) 0.04 (0.0016)	

\* T. I. R (Total Indicator Reading)  
† Accuracy for motor types USAMED-44BS2, USAMKD-60BS2.

## FAN TERMINAL CONNECTION (For only 60BS2)




A	Fan motor
B	Fan motor
C	—
D	Alarm terminal
E	Alarm terminal
F	—


## CONNECTOR SPECIFICATIONS

Motor Receptacle


Absolute Encoder Receptacle



A	Phase U
B	Phase V
C	Phase W
D	Ground




A	Channel A output	K	—
B	Channel A output	L	—
C	Channel B output	M	—
D	Channel B output	N	—
E	Channel C output	P	—
F	Channel C output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	Frame ground	—	—



Alarm Contact :  
OFF at normal fan rotation  
ON at 1800±200 r/min or less  
(ON during 3 seconds at start-up)  
Contact Capacity :  
Max. resistive load 110V, 0.3A


Drawing 1 USAFED-02C□1, -03C□1 (Taper Shaft)



Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Key and keyway comply with JIS B 1301-1976. (Parallel key, keyway: common class.)
3. Motor should be mounted with connectors down.
4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)

Drawing 2 USAFED-05C□1, -09C□1 (Taper Shaft), -13C□2 (Straight Shaft)




For -05CS1, -09CS1 For -13CS2  
Detail of Shaft Extension

Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Key and keyway comply with JIS B 1301-1976. (Parallel key, keyway: common class.)
3. Motor should be mounted with connectors down.
4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)

Drawing 3 USAFED-20C□2 to -44C□2 (Straight Shaft)



Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Motor should be mounted with connectors down.
3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : S (8192 P/R)  
Semi-standard : W (1024 P/R)

AC Servomotor Type USAFED-	Dwg. No.	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	Flange Surface						Shaft Extension		Approx Mass kg (lb)	
												LA	LB	LC	LE	LG	LH	LZ	S		Q
02C1*	1	234 (9.21)	197 (7.75)	137 (5.39)	37 (1.46)	60 (2.36)	90 (3.54)	172 (6.77)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 <sup>0</sup> <sub>(3.1496 -0.002)</sub>	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	5 (11.0)
03C1*		280 (11.02)	243 (9.56)	183 (7.2)	37 (1.46)	60 (2.36)	136 (5.35)	218 (8.58)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 <sup>0</sup> <sub>(3.1496 -0.002)</sub>	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	7 (15.5)
05C1*	2	277 (10.90)	219 (8.62)	150 (5.91)	58 (2.28)	69 (2.72)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(4.3307 -0.004)</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	9 (19.9)
09C1*		334 (13.14)	276 (10.86)	207 (8.16)	58 (2.28)	69 (2.72)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(4.3307 -0.004)</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	14 (30.9)
13C12*		403 (15.87)	345 (13.59)	276 (10.87)	58 (2.28)	69 (2.72)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(4.3307 -0.004)</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 <sup>0</sup> <sub>(0.8661 -0.006)</sub>	40 (1.57)	20 (44.1)
20C12*	3	344 (13.54)	265 (10.43)	211 (8.3)	79 (3.11)	54 (2.13)	172 (6.77)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(4.5 -0.001)</sub>	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(1.3379 -0.004)</sub>	76 (2.99)	22 (48.5)
30C12		401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.02)	294 (11.57)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(4.5 -0.001)</sub>	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(1.3379 -0.004)</sub>	76 (2.99)	29 (63.9)
44C12		486 (19.14)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(4.5 -0.001)</sub>	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(1.3379 -0.004)</sub>	76 (2.99)	41 (90.4)

\* Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAFED-	Motor Connector Types				Absolute Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02C1 03C1	MS3102 A14S-2P	MS3108 B14S-2S	MS3106 B14S-2S	MS3057 -6A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
05C1 09C1 13C12	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A				
20C12 30C12 44C12	MS3102 A22-22P	MS3108 B22-22S	MS3106 B22-22S	MS3057 -12A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A) 0.04 (0.0016)	
Flange diameter concentric to shaft (B) 0.04 (0.0016)	
Shaft run out (C) 0.02 (0.0008)	


Servomotors with a brake are also available.

\* T. I. R. (Total Indicator Reading)


## CONNECTOR SPECIFICATIONS

Motor Receptacle

Absolute Encoder Receptacle



A	Phase U
B	Phase V
C	Phase W
D	Ground



A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	Frame ground	—	—



AC Servomotor Type USAGED-	Dwg. No.	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	Flange Surface						Shaft Extension		Approx Mass kg (lb)	
												LA	LB	LC	LE	LG	LH	LZ	S		Q
02A:1*	1	234 (9.21)	197 (7.75)	137 (5.39)	37 (1.46)	60 (2.36)	90 (3.54)	172 (6.77)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 <sup>0</sup> <sub>(-0.000)</sub> (3.1496 <sup>0</sup> <sub>(-0.002)</sub> )	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	5 (11.0)
03A:1*		280 (11.02)	243 (9.56)	183 (7.2)	37 (1.46)	60 (2.36)	136 (5.35)	218 (8.58)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 <sup>0</sup> <sub>(-0.000)</sub> (3.1496 <sup>0</sup> <sub>(-0.002)</sub> )	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	7 (15.5)
05A:1*	2	277 (10.90)	219 (8.62)	150 (5.91)	58 (2.28)	69 (2.72)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(-0.005)</sub> (4.3307 <sup>0</sup> <sub>(-0.004)</sub> )	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	9 (19.9)
09A:1*		334 (13.14)	276 (10.86)	207 (8.16)	58 (2.28)	69 (2.72)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(-0.005)</sub> (4.3307 <sup>0</sup> <sub>(-0.004)</sub> )	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	14 (30.9)
13A:2*	3	403 (15.87)	345 (13.59)	276 (10.87)	58 (2.28)	69 (2.72)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>0</sup> <sub>(-0.005)</sub> (4.3307 <sup>0</sup> <sub>(-0.004)</sub> )	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 <sup>0</sup> <sub>(-0.003)</sub> (0.8661 <sup>0</sup> <sub>(-0.005)</sub> )	40 (1.57)	20 (44.1)
20A:2*		344 (13.54)	265 (10.43)	211 (8.3)	79 (3.11)	54 (2.13)	172 (6.77)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(-0.025)</sub> (4.5 <sup>0</sup> <sub>(-0.001)</sub> )	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(-0.004)</sub> (1.3379 <sup>0</sup> <sub>(-0.005)</sub> )	76 (2.99)	22 (48.5)
30A:2	3	401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.02)	294 (11.57)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(-0.025)</sub> (4.5 <sup>0</sup> <sub>(-0.001)</sub> )	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(-0.004)</sub> (1.3379 <sup>0</sup> <sub>(-0.005)</sub> )	76 (2.99)	29 (63.9)
44A:2		486 (19.14)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.88)	114.3 <sup>0</sup> <sub>(-0.025)</sub> (4.5 <sup>0</sup> <sub>(-0.001)</sub> )	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 <sup>0</sup> <sub>(-0.004)</sub> (1.3379 <sup>0</sup> <sub>(-0.005)</sub> )	76 (2.99)	41 (90.4)

\* Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAGED-	Motor Connector Types				Absolute Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02A:1 03A:1	MS3102 A14S-2P	MS3108 A14S-2S	MS3106 B14S-2S	MS3057 -6A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
05A:1 09A:1 13A:2	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A				
20A:2 30A:2 44A:2	MS3102 A22-22P	MS3108 B22-22S	MS3106 B22-22S	MS3057 -12A				

## MECHANICAL SPECIFICATIONS


Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A) 0.04 (0.0016)	
Flange diameter concentric to shaft (B) 0.04 (0.0016)	
Shaft run out (C) 0.02 (0.0008)	

Servomotors with a brake are also available.


\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

Motor Receptacle      Absolute Encoder Receptacle




A	Phase U
B	Phase V
C	Phase W
D	Ground



A	Channel A output	K	—
B	Channel A output	L	—
C	Channel B output	M	—
D	Channel B output	N	—
E	Channel C output	P	—
F	Channel C output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	Frame ground	—	—


Drawing 1 USADED-05E□2 to -37E□2



Notes :

1. Absolute encoder is used as a detector.
2. Plug and clamp are not attached for receptacle connection.
3. Motor should be mounted with connectors down.
4. □ in the models are as follows according to types of the encoder (P/R).  
 Standard : W (1024 P/R)  
 Semi-standard : S (8192 P/R)

**Straight Shaft/With Key**



Detail of Shaft Extension

Note: Key and keyway comply with JIS B 1301-1976 (parallel key, keyway: common class).

AC Servomotor Type USADED-	Shaft Extension					
	S	Q	QK	T	U	W
05E□2K□	22 <sup>0</sup> <sub>(0.8661 -0.0005)</sub> <sup>-0.013</sup>	50 (1.97)	45 (1.77)	6 (0.236)	3.5 (0.138)	6 (0.2362)
10E□2K□	22 <sup>0</sup> <sub>(0.8661 -0.0005)</sub> <sup>-0.013</sup>	50 (1.97)	45 (1.77)	6 (0.236)	3.5 (0.138)	6 (0.2362)
15E□2K□	28 <sup>0</sup> <sub>(1.1024 -0.0005)</sub> <sup>-0.013</sup>	50 (1.97)	45 (1.77)	7 (0.275)	4 (0.157)	8 (0.3149)
22E□2K□	28 <sup>0</sup> <sub>(1.1024 -0.0005)</sub> <sup>-0.013</sup>	50 (1.97)	45 (1.77)	7 (0.275)	4 (0.157)	8 (0.3149)
37E□2K□	32 <sup>0</sup> <sub>(1.2598 -0.0005)</sub> <sup>-0.016</sup>	60 (2.36)	50 (1.97)	8 (0.315)	5 (0.197)	10 (0.3937)

AC Servomotor Type USADED-	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	D	Flange Surface								Shaft Extension		Approx Mass kg (lb)	
												LA	LA1	LB	LC	LE	LG	LH	LZ	LZ1	S		Q
05E::20E*	237 (9.33)	182 (7.17)	137 (5.39)	55 (2.16)	45 (1.77)	82 (3.23)	158 (6.22)	—	143 (5.63)	92 (3.62)	130 (5.12)	200 (7.87)	—	114.3 <sup>+0.025</sup> <sub>-0.021</sub> (4.5)	180 (7.09)	3.2 (0.126)	12 (0.472)	230 (9.06)	13.5 (0.53)	—	22 <sup>+0.013</sup> <sub>-0.005</sub> (0.8661)	50 (1.97)	17 (16 ) [37.5 (35.3)]
10E::20E*	257 (10.12)	202 (7.96)	157 (6.18)	55 (2.16)	45 (1.77)	82 (3.23)	178 (7.0)	—	143 (5.63)	92 (3.62)	130 (5.12)	200 (7.87)	—	114.3 <sup>+0.025</sup> <sub>-0.021</sub> (4.5)	180 (7.09)	3.2 (0.126)	12 (0.472)	230 (9.06)	13.5 (0.53)	—	22 <sup>+0.013</sup> <sub>-0.005</sub> (0.8661)	50 (1.97)	19 (18 ) [41.9 (39.7)]
15E::20E	272 (10.71)	217 (8.47)	170 (6.69)	55 (2.16)	47 (1.85)	100 (3.94)	193 (7.60)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>+0.046</sup> <sub>-0.009</sub> (7.874)	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	M8	28 <sup>+0.013</sup> <sub>-0.005</sub> (1.1024)	50 (1.97)	30 (27 ) [66.2 (59.5)]
22E::20E	287 (11.30)	232 (9.06)	185 (7.28)	55 (2.16)	47 (1.85)	100 (3.94)	208 (8.19)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>+0.046</sup> <sub>-0.009</sub> (7.874)	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	M8	28 <sup>+0.013</sup> <sub>-0.005</sub> (1.1024)	50 (1.97)	32 (29 ) [70.6 (63.9)]
37E::20E	347 (13.66)	282 (11.02)	235 (9.25)	65 (2.56)	47 (1.85)	100 (3.94)	251 (9.88)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>+0.046</sup> <sub>-0.009</sub> (7.874)	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	M8	32 <sup>+0.016</sup> <sub>-0.006</sub> (1.2598)	60 (2.36)	39 (36 ) [86 (79.4)]

\* Not provided with an eyebolt.

Note: Dimensions above are applied for servomotor w/wo holding brake as well.  
Approx mass in ( ) is for servomotor without holding brake.

## CONNECTOR TYPES

AC Servomotor Type USADED-	Motor Connector Types				Absolute Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
05E::2::	MS3102	MS3108	MS3106	MS3057	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
10E::2::	A20-15P	B20-15S	B20-15S	-12A				
15E::2::	MS3102	MS3108	MS3106	MS3057				
22E::2::	A24-10P	B24-10S	B24-10S	-16A				
37E::2::	A24-10P	B24-10S	B24-10S	-16A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*		Reference Diagram
Flange surface perpendicular to shaft (A)	0.04 (0.0016) 0.06† (0.0026†)	
Flange diameter concentric to shaft (B)	0.04 (0.0016)	
Shaft run out (C)	0.02 (0.0008)	


\* T. I. R. (Total Indicator Reading)

† Accuracy for motor types USADED-15EW, -22EW, and -37EW.

Servomotors with a brake are also available.


## CONNECTOR SPECIFICATIONS

Motor Receptacle



A	Phase U	E	Brake term.
B	Phase V	F	Brake term.
C	Phase W	G	—
D	Ground		


Absolute Encoder Receptacle



A	Channel A output	K	Channel S output
B	Channel Ā output	L	Channel S output
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	Frame ground	—	—

When not provided with holding brake, E and F are not used.


Drawing 1 USASEM-02A 2



Notes:

1.  $\square$  in the models are as follows according to types of the encoder (P/R).  
Standard : S (B192 P/R)  
Semi-standard : W (1024 P/R)
2. Vibration class : V15
3. Plug and clamp are not attached for receptacle connection.
4. Motor should be mounted with connectors down.


Drawing 2 USASEM-03A 2, -05A 2 (Straight Shaft)



Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Motor should be mounted with connectors down.
3.  $\square$  in the models are as follows according to types of the encoder (P/R).  
Standard : S (B192 P/R)  
Semi-standard : W (1024 P/R)

Drawing 3 USASEM-08A 1, -15A 1, -30A 1 (Taper Shaft)



Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Key and keyway comply with JIS B 1301-1976.  
(Parallel key, keyway : precise class.)
3. Motor should be mounted with connectors down.
4.  $\square$  in the models are as follows according to types of the encoder (P/R).  
Standard : S (B192 P/R)  
Semi-standard : W (1024 P/R)



AC Servomotor Type USASEM-	Dwg. No.	L	LL	LM	LR	KB	KL	Flange Surface							Approx Mass kg (lb)
								LA	LB	LC	LE	LG	LH	LZ	
02A:2	1	201 (7.91)	171 (6.73)	83 (3.27)	30 (1.18)	72.5 (2.85)	—	80 (3.15)	50 <sup>0</sup> <sub>-0.025</sub> (1.9685 <sup>0</sup> <sub>-0.00098</sub> )	65 (2.56)	3 (0.118)	6 (0.2362)	90 (3.54)	5 (0.1968)	2.0 (4.4)
03A:2	2	208 (8.19)	178 (7.01)	114 (4.49)	30 (1.18)	79 (3.11)	—	90 (3.54)	70 <sup>0</sup> <sub>-0.030</sub> (2.7559 <sup>0</sup> <sub>-0.0012</sub> )	80 (3.15)	3 (0.118)	8 (0.31)	105 (4.13)	6 (0.236)	3.2 (7.1)
05A:2	2	230 (9.01)	200 (7.83)	136 (5.31)	30 (1.18)	101 (3.98)	—	90 (3.54)	70 <sup>0</sup> <sub>-0.030</sub> (2.7559 <sup>0</sup> <sub>-0.0012</sub> )	80 (3.15)	3 (0.118)	8 (0.31)	105 (4.13)	6 (0.236)	3.8 (8.4)
08A:1	3	270.5 (10.65)	212.5 (8.37)	149 (5.87)	58 (2.28)	115 (4.53)	102 (4.02)	130 (5.12)	110 <sup>0</sup> <sub>-0.035</sub> (4.3307 <sup>0</sup> <sub>-0.0014</sub> )	120 (4.72)	3 (0.118)	10 (0.39)	155 (6.1)	9 (0.35)	6.3 (13.9)
15A:1	3	325.5 (12.81)	267.5 (10.53)	204 (8.03)	58 (2.28)	166.5 (6.56)	109 (4.29)	145 (5.71)	110 <sup>0</sup> <sub>-0.035</sub> (4.3307 <sup>0</sup> <sub>-0.0014</sub> )	130 (5.12)	6 (0.24)	12 (0.47)	9 (6.5)	9 (0.35)	11.5 (25.4)
30A:1	3	374 (14.72)	304 (11.96)	240 (9.44)	70 (2.76)	206 (8.11)	135 (5.31)	200 (7.87)	114.3 <sup>0</sup> <sub>-0.040</sub> (4.5 <sup>0</sup> <sub>-0.0015</sub> )	180 (7.09)	6 (0.24)	18 (0.71)	230 (9.1)	13.5 (0.53)	24.5 (54)


AC Servomotor Type USASEM-	Dwg. No.	Shaft Extension										
		LW	Q	QK	QA	X	S	V	P	U	W	T
08A:1	3	18 (0.71)	28 (1.1)	25 (0.98)	12 (0.47)	10.3 (0.41)	16 (0.63)	21 (0.83)	M10 (P1.25)	4.3 <sup>0</sup> <sub>-0.01</sub> (0.169 <sup>0</sup> <sub>-0.0004</sub> )	5 (0.1968)	5 (0.1968)
15A:1	3	18 (0.71)	28 (1.1)	25 (0.98)	12 (0.47)	10.3 (0.41)	19 (0.75)	21 (0.83)	M10 (P1.25)	5.8 <sup>0</sup> <sub>-0.01</sub> (0.228 <sup>0</sup> <sub>-0.0004</sub> )	5 (0.1968)	5 (0.1968)
30A:1	3	20 (0.79)	36 (1.42)	32 (1.26)	14 (0.55)	12.5 (0.49)	22 (0.87)	24 (0.94)	M12 (P1.25)	6.6 <sup>0</sup> <sub>-0.01</sub> (0.26 <sup>0</sup> <sub>-0.0004</sub> )	6 (0.2362)	6 (0.2362)

## CONNECTOR TYPES

AC Servomotor Type USASEM-	Motor Connector Types				Absolute Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
03A:2 05A:2	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
08A:1 15A:1 30A:1	MS3102 A20-4P	MS3108 B20-4S	MS3106 B20-4S	MS3057 -12A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*		Reference Diagram
Flange surface perpendicular to shaft (A)	0.04 (0.0016)	
Flange diameter concentric to shaft (B)	0.04 (0.0016)	
Shaft run out (C)	0.02 (0.0008)	





Servomotors with a brake are also available.

\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

Motor Receptacle

Absolute Encoder Receptacle




A	Phase U
B	Phase V
C	Phase W
D	Ground

A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	Frame ground	—	—


(6) R Series

Dimensions in mm (inches)

USAREM-A5CS2K 50W, -01CS2K 100W.....(200V)  
 USAREM-A5DS2K 50W, -01DS2K 100W.....(100V)




USAREM-02CS2K 200W, -03CS2K 300W.....(200V)  
 USAREM-02DS2K 200W, -03DS2K 300W.....(100V)




Drawing No.	Servomotor Type USAREM-	L	LL	LM	S	LB	Approx. Mass	
							kg	(lb)
1	A5 C S2K	169 (6.66)	139 (5.48)	54 (2.13)	8 <sup>0</sup> <sub>-0.009</sub>	50 <sup>0</sup> <sub>-0.025</sub>	1.5	(3.3)
	01 C S2K	186.5 (7.34)	156.5 (6.16)	71.5 (2.81)	(0.315 <sup>0</sup> <sub>-0.00036</sub> )	(1.9685 <sup>0</sup> <sub>-0.00098</sub> )	1.8	(4.0)
2	02 C S2K	181.5 (7.15)	151.5 (5.96)	87.5 (3.44)	14 <sup>0</sup> <sub>-0.011</sub>	70 <sup>0</sup> <sub>-0.030</sub>	2.5	(5.5)
	03 C S2K	205.5 (8.09)	175.5 (6.91)	111.5 (4.39)	(0.551 <sup>0</sup> <sub>-0.00043</sub> )	(2.756 <sup>0</sup> <sub>-0.0012</sub> )	3.1	(6.9)
3	05 C S2K	See Drawing 3.			16 <sup>0</sup> <sub>-0.011</sub>	110 <sup>0</sup> <sub>-0.035</sub>	4.9	(10.8)
4	07 C S2K	See Drawing 4.			(0.631 <sup>0</sup> <sub>-0.00043</sub> )	(4.331 <sup>0</sup> <sub>-0.00014</sub> )	7.5	(16.5)

Dimensions in mm (inches)

USAREM-05CS2K 500W.....(200V)  
USAREM-05DS2K 500W.....(100V)



USAREM-07CS2K 700W.....(200V)



(6) R Series (Cont'd)

### CONNECTOR TYPES

Servomotor Type USAREM-	Encoder Side			Motor Side		
	Receptacle Type	Plug* Type	Cable Clamp Type	Receptacle Type	Plug* Type	Cable Clamp Type
A5  S2K 01  S2K	MS3101A20 -29P	MS3106B20 -29S	MS3057 -12A	MS3101A 14S-2P	MS3106B 14-2S	MS3057 -6A
02  S2K 03  S2K	MS3102A20	MS3108B20		MS3102A 18-10P	MS3108B 18-10S	MS3057 -10A
05  S2K 07  S2K	-29P	-29S		MS3102A 20-4P	MS3108B 20-4S	MS3057 -12A

\* Provided by customer

in type designation is C (200V class) or D (100V class).

Note:

1. With motor connection shown above, by plus reference voltage, the motor rotates counterclockwise (when viewed from the drive end).
2. Dimensions of the keyway are based on JIS B 1301 "Sunk keys and their corresponding key ways (close keys)." Parallel key has been attached. Tolerance of keyway is precision class.


### MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft $\text{\textcircled{A}}$	
Flange diameter concentric to shaft $\text{\textcircled{B}}$	
Shaft run out $\text{\textcircled{C}}$	

\* T. I. R. (Total Indicator Reading)

### CONNECTOR SPECIFICATIONS

Motor Receptacle



A	Phase U
B	Phase V
C	Phase W
D	Frame ground


Encoder Receptacle



A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	For reset
G	0V	S	0V (battery)
H	+5VDC	T	3.6V (battery)
J	—	—	—

### Straight Shaft

Servomotor proper is the same dimensions as standard servomotor. Details of shaft extension are shown below:




Detail of Shaft Extension

Dimensions in mm (inches)

Without Brake Type USAREM-	With Brake Type USAREM-	LR	S	LB
A5 □ S2	A5 □ S2B	30 (1.18)	8 <sup>0</sup> <sub>-0.009</sub> (0.31 <sup>0</sup> <sub>-0.00035</sub> )	50 <sup>0</sup> <sub>-0.025</sub> (1.97 <sup>0</sup> <sub>-0.00098</sub> )
01 □ S2	01 □ S2B		14 <sup>0</sup> <sub>-0.011</sub> (0.551 <sup>0</sup> <sub>-0.00043</sub> )	70 <sup>0</sup> <sub>-0.030</sub> (2.756 <sup>0</sup> <sub>-0.0012</sub> )
02 □ S2	02 □ S2B			
03 □ S2	03 □ S2B	40 (1.57)	16 <sup>0</sup> <sub>-0.011</sub> (0.6299 <sup>0</sup> <sub>-0.00043</sub> )	110 <sup>0</sup> <sub>-0.035</sub> (4.331 <sup>0</sup> <sub>-0.00014</sub> )
05 □ S2	05 □ S2B			
07CS2	07CS2B			

### Straight Shaft with Oilseal

Servomotor proper is the same dimensions as standard servomotor. Details of shaft extension are shown below.



Detail of Shaft Extension


Dimensions in mm (inches)

Without Brake Type USAREM-	With Brake Type USAREM-	LR	LE	LJ	LK	S	LB	Oilseal
A5 □ S2S	A5 □ S2SB	30 (1.18)	4.5 (0.18)	25 (0.98)	45 (1.77)	8 <sup>0</sup> <sub>-0.009</sub> (0.31 <sup>0</sup> <sub>-0.00035</sub> )	50 <sup>0</sup> <sub>-0.025</sub> (1.97 <sup>0</sup> <sub>-0.00098</sub> )	SB08187
01 □ S2S	01 □ S2SB							
02 □ S2S	02 □ S2SB			36 (1.42)	60 (2.36)	14 <sup>0</sup> <sub>-0.011</sub> (0.551 <sup>0</sup> <sub>-0.00043</sub> )	70 <sup>0</sup> <sub>-0.030</sub> (2.756 <sup>0</sup> <sub>-0.0012</sub> )	SB14287
03 □ S2S	03 □ S2SB							
05 □ S2S	05 □ S2SB	40 (1.57)	2.5 (0.10)	50 (1.97)	73 (2.87)	16 <sup>0</sup> <sub>-0.011</sub> (0.6299 <sup>0</sup> <sub>-0.00043</sub> )	110 <sup>0</sup> <sub>-0.030</sub> (4.331 <sup>0</sup> <sub>-0.00014</sub> )	SB16307
07CS2S	07CS2SB							


### Straight Shaft with Keyway and Oilseal

Servomotor proper and shaft extension are same dimensions as standard Servomotor. Oilseal is same dimensions as shown above.

Drawing 1 USAPEM-01CW2K, -02CW2K, -03CW2K (Straight Shaft, With Key)



Drawing 2 USAPEM-05CW2K, -07CW2K (Straight Shaft, With Key)



AC Servomotor Type USAPEM-	Dwg. No.	L	LL	LM	Shaft Extension						Approx. Mass kg (lb)	
					S	QK	U	W	T	M		
01CW2K	1	133 (5.24)	103 (4.06)	52 (2.05)	11 $\begin{smallmatrix} -0.011 \\ 0 \\ 0.00043 \end{smallmatrix}$ (0.433)	18 (0.71)	2.5 (0.10)	4 (0.157)	4 (0.157)	M3, Deep <sup>6</sup> (0.24)	1.7 (3.7)	
02CW2K	1	136 (5.35)	106 (4.17)	55 (2.17)	14 $\begin{smallmatrix} -0.011 \\ 0 \\ 0.00043 \end{smallmatrix}$ (0.551)	18 (0.71)	3 (0.12)	5 (0.197)	5 (0.197)	M4, Deep <sup>10</sup> (0.39)	2.0 (4.4)	
03CW2K	1	140 (5.51)	110 (4.33)	59 (2.32)	14 $\begin{smallmatrix} -0.011 \\ 0 \\ 0.00043 \end{smallmatrix}$ (0.551)	18 (0.71)	3 (0.12)	5 (0.197)	5 (0.197)	M4, Deep <sup>10</sup> (0.39)	2.3 (5.1)	
05CW2K	2	160 (6.30)	120 (4.72)	69 (2.72)	16 $\begin{smallmatrix} -0.011 \\ 0 \\ 0.00043 \end{smallmatrix}$ (0.630)	20 (0.79)	3 (0.12)	5 (0.197)	5 (0.197)	M4, Deep <sup>10</sup> (0.39)	4.6 (10.1)	
07CW2K	2	160 (6.30)	120 (4.72)	69 (2.72)	16 $\begin{smallmatrix} -0.011 \\ 0 \\ 0.00043 \end{smallmatrix}$ (0.630)	20 (0.79)	3 (0.12)	5 (0.197)	5 (0.197)	M4, Deep <sup>10</sup> (0.39)	5 (11.0)	


## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A) 0.04 (0.0016)	
Flange diameter concentric to shaft (B) 0.04 (0.0016)	
Shaft run out 0.02 (0.0008)	



\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

### • Motor Side



### • Encoder Side




1	Channel A output	Blue
2	Channel $\bar{A}$ output	White/Blue
3	Channel B output	Yellow
4	Channel $\bar{B}$ output	White/Yellow
5	Channel C output	Green
6	Channel $\bar{C}$ output	White/Green
7	0V (Power Supply)	Black
8	+5V (Power Supply)	Red
9	FG frame ground	Green/Yellow
10	Channel S output	Purple
11	Channel $\bar{S}$ output	White/Purple
12	Capacitor reset	Gray
13	Reset	White/Gray
14	0V (Battery)	White/Orange
15	3.6V (Battery)	Orange

# 13.2 AC SERVOMOTOR WITH INCREMENTAL ENCODER

(1) M Series

Dimensions in mm (inches)


Drawing 1 USAMED-03□□1, -06□□1 (Taper Shaft), -09B□□2 (Straight Shaft)



- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Key and keyway comply with JIS B 1301-1976.  
(Parallel key, keyway : common class.)
  3. Motor should be mounted with connectors down.
  4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (B192 P/R)  
Semi-standard : 3 (2048 P/R)

For -03B21, -06B21 For -09B22  
Detail of Shaft Extension


Drawing 2 USAMED-12B□□2 to -44B□□2 (Straight Shaft)



- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Motor should be mounted with connectors down.
  3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (B192 P/R)  
Semi-standard : 3 (2048 P/R)

Detail of Shaft Extension

Drawing 3 USAMKD-60B□□2 (Straight Shaft)



- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Motor should be mounted with connectors down.
  3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (B192 P/R)  
Semi-standard : 3 (2048 P/R)

Detail of Shaft Extension



AC Servomotor Type USAMED*	Dwg. No.	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	Flange Surface						Shaft Extension		Approx Mass kg (lb)	
												LA	LB	LC	LE	LG	LH	LZ	S		Q
03B:1†	1	263 (10.34)	205 (8.06)	150 (5.9)	58 (2.28)	55 (2.16)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>+0.005</sup> <sub>-0.004</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	8.5 (18.7)
06B:1†		320 (12.59)	262 (10.31)	207 (8.15)	58 (2.28)	55 (2.16)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>+0.005</sup> <sub>-0.004</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	13 (28.7)
09B:2†		389 (15.31)	331 (13.03)	276 (10.87)	58 (2.28)	55 (2.16)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 <sup>+0.005</sup> <sub>-0.004</sub>	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 <sup>+0.003</sup> <sub>-0.005</sub>	40 (1.575)	20 (44.1)
12B:2†	2	344 (13.54)	265 (10.43)	211 (8.30)	79 (3.11)	54 (2.13)	172 (6.77)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.87)	114.3 <sup>+0.025</sup> <sub>-0.001</sub>	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 <sup>+0.00</sup> <sub>-0.004</sub>	76 (2.992)	22 (48.5)
20B:2		401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.01)	294 (11.57)	123 (4.84)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 <sup>+0.025</sup> <sub>-0.001</sub>	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 <sup>+0.00</sup> <sub>-0.004</sub>	76 (2.992)	29 (63.9)
30B:2		486 (19.13)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.84)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 <sup>+0.025</sup> <sub>-0.001</sub>	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	35 <sup>+0.00</sup> <sub>-0.004</sub>	76 (2.992)	41 (90.4)
44B:2		688 (27.09)	578 (22.76)	524 (20.63)	110 (4.33)	54 (2.13)	476 (18.74)	550 (21.65)	123 (4.84)	149 (5.87)	92 (3.62)	200 (7.87)	114.3 <sup>+0.025</sup> <sub>-0.001</sub>	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	42 <sup>+0.006</sup> <sub>-0.005</sub>	110 (4.33)	66 (145.5)
60B:2		775 (30.51)	665 (26.18)	—	110 (4.33)	—	476 (18.74)	550 (21.65)	123 (4.84)	149 (5.87)	100 (3.94)	200 (7.87)	114.3 <sup>+0.025</sup> <sub>-0.001</sub>	180 (7.08)	3.2 (0.13)	18 (0.71)	230 (9.1)	13.5 (0.53)	42 <sup>+0.006</sup> <sub>-0.005</sub>	110 (4.33)	71 (156.9)

\* For servomotor of 6kW, "K" is used instead of "E", because of externally fan-cooled type.  
† Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAMED-	Motor Connector Types				Incremental Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
03B:1	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
06B:1								
09B:2								
12B:2	MS3102	MS3108	MS3106	MS3057				
20B:2	A22-22P	B22-22S	B22-22S	-12A				
30B:2								
44B:2	MS3102	MS3108	MS3106	MS3057				
USAMKD-60B:2*	A32-17P	B32-17S	B32-17S	-20A				

\* Cooling fan receptacle : MS3102A14S-6P  
Cooling fan plug : MS3108B14S-6P  
Cooling fan cable clamp : MS3057-6A

Servomotors with a brake are also available.  
For detailed information, refer to related Bulletins (TSE-S800-11.1).


## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A)	
Flange diameter concentric to shaft (B)	
Shaft run out (C)	


\* T. I. R. (Total Indicator Reading)  
† Accuracy for motor types USAMED-44B22, USAMKD-60B22.

## CONNECTOR SPECIFICATIONS

Motor Receptacle Incremental Encoder Receptacle




A	Phase U
B	Phase V
C	Phase W
D	Ground




A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	—
G	0V	S	—
H	+5VDC	T	—
J	Frame ground	—	—

## FAN TERMINAL CONNECTION (For only 60B22)



A	Fan motor
B	Fan motor
C	—
D	Alarm terminal
E	Alarm terminal
F	—



Alarm Contact :  
OFF at normal fan rotation  
ON at 1800±200 r/min or less  
(ON during 3 seconds at start-up)  
Contact Capacity :  
Max. resistive load 110V, 0.3A



AC Servomotor Type USAFED-	Dwg. No.	Flange Surface																Shaft Extension		Approx Mass kg (lb)			
		L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	LA	LB	LC	LE	LG	LH	LZ	S		Q		
02:0001*	1	190 (7.48)	153 (6.02)	113 (4.45)	37 (1.46)	40 (1.57)	90 (3.54)	132 (5.19)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 (3.1496)	$0_{-0.002}^{0.000}$	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	4 (8.8)	
03:0001*		236 (9.29)	199 (7.83)	159 (6.26)	37 (1.46)	40 (1.57)	136 (5.35)	178 (7.0)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 (3.1496)	$0_{-0.002}^{0.000}$	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	6 (13.2)	
05:0001*	2	263 (10.35)	205 (8.07)	150 (5.91)	58 (2.28)	55 (2.16)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	$0_{-0.004}^{0.005}$	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	8.5 (18.7)	
09:0001*		320 (12.6)	262 (10.32)	207 (8.16)	58 (2.28)	55 (2.16)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	$0_{-0.004}^{0.005}$	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	13 (28.7)	
13C:002*		389 (15.31)	331 (13.03)	276 (10.87)	58 (2.28)	55 (2.16)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	$0_{-0.004}^{0.005}$	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 (0.8661)	$0_{-0.005}^{0.000}$	40 (1.57)	20 (44.1)
20C:002*	3	344 (13.54)	265 (10.43)	211 (8.3)	79 (3.11)	54 (2.13)	171 (6.73)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	$0_{-0.001}^{0.025}$	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	$0_{-0.0004}^{+0.01}$	76 (2.99)	22 (48.5)
30C:002		401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.02)	294 (11.57)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	$0_{-0.001}^{0.025}$	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	$0_{-0.0004}^{+0.01}$	76 (2.99)	29 (63.9)
44C:002		486 (19.14)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	$0_{-0.001}^{0.025}$	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	$0_{-0.0004}^{+0.01}$	76 (2.99)	41 (90.4)


\* Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAFED-	Motor Connector Types				Incremental Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02:0001 03:0001	MS3102 A14S-2P	MS3108 B14S-2S	MS3106 B14S-2S	MS3057 -6A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
05:0001 09:0001 13C:002	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A				
20C:002 30C:002 44C:002	MS3102 A22-22P	MS3108 B22-22S	MS3106 B22-22S	MS3057 -12A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*		Reference Diagram
Flange surface perpendicular to shaft (A)	0.04 (0.0016)	
Flange diameter concentric to shaft (B)	0.04 (0.0016)	
Shaft run out (C)	0.02 (0.0008)	





Servomotors with a brake are also available. For detailed information, refer to related Bulletins (TSE-S800-11.1).

\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

Motor Receptacle


Incremental Encoder Receptacle



A	Phase U
B	Phase V
C	Phase W
D	Ground


A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	—
G	0V	S	—
H	+5VDC	T	—
J	Frame ground	—	—

Drawing 1 USAGED-02:1, -03:1 (Taper Shaft)




- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Key and keyway comply with JIS B 1301-1976. (Parallel key, keyway : common class.)
  3. Motor should be mounted with connectors down.
  4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (8192 P/R)  
Semi-standard : 3 (2048 P/R)

Drawing 2 USAGED-05:1, -09:1 (Taper Shaft), -13A:2 (Straight Shaft)



- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Key and keyway comply with JIS B 1301-1976. (Parallel key, keyway : common class.)
  3. Motor should be mounted with connectors down.
  4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (8192 P/R)  
Semi-standard : 3 (2048 P/R)

Drawing 3 USAGED-20A:2 to -44A:2 (Straight Shaft)



- Notes :
1. Plug and clamp are not attached for receptacle connection.
  2. Motor should be mounted with connectors down.
  3. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 2 (8192 P/R)  
Semi-standard : 3 (2048 P/R)

AC Servomotor Type USAGED-	Dwg. No.	Flange Surface										Shaft Extension		Approx Mass kg (lb)							
		L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	LA	LB		LC	LE	LG	LH	LZ	S	Q
02	1	190 (7.48)	153 (6.02)	113 (4.45)	37 (1.46)	40 (1.57)	90 (3.54)	132 (5.19)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 (3.1496)	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	4 (8.8)
03	1	236 (9.29)	199 (7.83)	159 (6.26)	37 (1.46)	40 (1.57)	136 (5.35)	178 (7.0)	—	76 (2.99)	87 (3.43)	100 (3.94)	80 (3.1496)	90 (3.54)	4 (0.157)	7 (0.276)	120 (4.72)	6.6 (0.26)	—	—	6 (13.2)
05	2	263 (10.35)	205 (8.07)	150 (5.91)	58 (2.28)	55 (2.16)	127 (5.0)	177 (6.97)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	8.5 (18.7)
09		320 (12.6)	262 (10.32)	207 (8.16)	58 (2.28)	55 (2.16)	184 (7.24)	234 (9.21)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	—	—	13 (28.7)
13A		389 (15.31)	331 (13.03)	276 (10.87)	58 (2.28)	55 (2.16)	253 (9.96)	303 (11.93)	—	109 (4.29)	92 (3.62)	145 (5.71)	110 (4.3307)	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	22 (0.8661)	40 (1.57)	20 (44.1)
20A		344 (13.54)	265 (10.43)	211 (8.3)	79 (3.11)	54 (2.13)	172 (6.77)	237 (9.33)	—	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	76 (2.99)	22 (48.5)
30A	3	401 (15.79)	322 (12.68)	268 (10.55)	79 (3.11)	54 (2.13)	229 (9.02)	294 (11.57)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	76 (2.99)	29 (63.9)
44A		486 (19.14)	407 (16.02)	353 (13.90)	79 (3.11)	54 (2.13)	314 (12.36)	379 (14.92)	123 (4.85)	139 (5.47)	92 (3.62)	200 (7.87)	114.3 (4.5)	180 (7.09)	3.2 (0.13)	18 (0.71)	230 (9.06)	13.5 (0.53)	35 (1.3779)	76 (2.99)	41 (90.4)


\* Not provided with an eyebolt.

## CONNECTOR TYPES

AC Servomotor Type USAGED-	Motor Connector Types				Incremental Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
02 03	MS3102 A14S-2P	MS3108 B14S-2S	MS3106 B14S-2S	MS3057 -6A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
05 09 13A	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A				
20A 30A 44A	MS3102 A22-22P	MS3108 B22-22S	MS3106 B22-22S	MS3057 -12A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*		Reference Diagram
Flange surface perpendicular to shaft (A)	0.04 (0.0016)	
Flange diameter concentric to shaft (B)	0.04 (0.0016)	
Shaft run out (C)	0.02 (0.0008)	




Servomotors with a brake are also available. For detailed information, refer to related Bulletins (TSE-S800-11.1).


\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

Motor Receptacle      Incremental Encoder Receptacle




A	Phase U
B	Phase V
C	Phase W
D	Ground



A	Channel A output	K	—
B	Channel A̅ output	L	—
C	Channel B output	M	—
D	Channel B̅ output	N	—
E	Channel C output	P	—
F	Channel C̅ output	R	—
G	0V	S	—
H	+5VDC	T	—
J	Frame ground	—	—


Drawing 1 USADED-05E□□2, -37E□□2



Notes :

1. Plug and clamp are not attached for receptacle connection.
2. Motor should be mounted with connectors down.
3. □□ in the models are as follows according to types of the encoder (P/R).  
 Standard : 3 (2048 P/R)  
 Semi-standard : 2 (8192 P/R)

**Straight Shaft/With Key**



Detail of Shaft Extension

Note: Key and keyway comply with JIS B 1301-1976 (parallel key, keyway: common class).

AC Servomotor Type USADED-	Shaft Extension					
	S	Q	QK	T	U	W
05E□□2K□□	22 (0.8661)	50 (1.97)	46 (1.77)	6 (0.236)	3.5 (0.138)	6 (0.2362)
10E□□2K□□	22 (0.8661)	50 (1.97)	45 (1.77)	6 (0.236)	3.5 (0.138)	6 (0.2362)
15E□□2K□□	28 (1.1024)	50 (1.97)	45 (1.77)	7 (0.275)	4 (0.157)	8 (0.3149)
22E□□2K□□	28 (1.1024)	50 (1.97)	45 (1.77)	7 (0.275)	4 (0.157)	8 (0.3149)
37E□□2K□□	32 (1.2598)	60 (2.36)	50 (1.97)	8 (0.315)	5 (0.197)	10 (0.3937)

AC Servomotor Type USADED-	L	LL	LM	LR	LT	KB1	KB2	IE	KL1	KL2	D	Flange Surface								Shaft Extension		Approx Mass kg (lb)	
												LA	LA1	LB	LC	LE	LG	LH	LZ	LZ1	S		Q
05E:2OE*	237 (9.33)	182 (7.17)	137 (5.39)	55 (2.16)	45 (1.77)	82 (3.23)	158 (6.22)	—	143 (5.63)	92 (3.62)	130 (5.12)	200 (7.87)	—	114.3 <sup>0</sup> <sub>(4.5)</sub> 0.025 <sup>0</sup> <sub>(0.001)</sub>	180 (7.09)	3.2 (0.126)	12 (0.472)	230 (9.06)	13.5 (0.53)	—	22 <sup>0</sup> <sub>(0.866)</sub> 0.013 <sup>0</sup> <sub>(0.0005)</sub>	50 (1.97)	17 (16) [37.5 (35.3)]
10E:2OE*	257 (10.12)	202 (7.96)	157 (6.18)	55 (2.16)	45 (1.77)	82 (3.23)	178 (7.0)	—	143 (5.63)	92 (3.62)	130 (5.12)	200 (7.87)	—	114.3 <sup>0</sup> <sub>(4.5)</sub> 0.025 <sup>0</sup> <sub>(0.001)</sub>	180 (7.09)	3.2 (0.126)	12 (0.472)	230 (9.06)	13.5 (0.53)	—	22 <sup>0</sup> <sub>(0.866)</sub> 0.013 <sup>0</sup> <sub>(0.0005)</sub>	50 (1.97)	19 (18) [41.9 (39.7)]
15E:2OE	272 (10.71)	217 (8.47)	170 (6.69)	55 (2.16)	47 (1.85)	100 (3.94)	193 (7.60)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>0</sup> <sub>(7.874)</sub> 0.046 <sup>0</sup> <sub>(0.0018)</sub>	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	MB	28 <sup>0</sup> <sub>(1.1024)</sub> 0.013 <sup>0</sup> <sub>(0.0005)</sub>	50 (1.97)	30 (27) [66.2 (59.5)]
22E:2OE	287 (11.30)	232 (9.06)	185 (7.28)	55 (2.16)	47 (1.85)	100 (3.94)	208 (8.19)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>0</sup> <sub>(7.874)</sub> 0.046 <sup>0</sup> <sub>(0.0018)</sub>	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	MB	28 <sup>0</sup> <sub>(1.1024)</sub> 0.013 <sup>0</sup> <sub>(0.0005)</sub>	50 (1.97)	32 (29) [70.6 (63.9)]
37E:2OE	347 (13.66)	282 (11.02)	235 (9.25)	65 (2.56)	47 (1.85)	100 (3.94)	258 (10.16)	142 (5.59)	162 (6.38)	92 (3.62)	130 (5.12)	235 (9.25)	250 (9.84)	200 <sup>0</sup> <sub>(7.874)</sub> 0.046 <sup>0</sup> <sub>(0.0018)</sub>	220 (8.66)	4 (0.157)	16 (0.63)	270 (10.63)	13.5 (0.53)	MB	32 <sup>0</sup> <sub>(1.2598)</sub> 0.016 <sup>0</sup> <sub>(0.0006)</sub>	60 (2.36)	39 (36) [86 (79.4)]

\* Not provided with an eyebolt.  
 Note: Dimensions above are applied for servomotor w/wo holding brake as well.  
 Approx mass in ( ) is for servomotor without holding brake.

## CONNECTOR TYPES

AC Servomotor Type USADED-	Motor Connector Types				Incremental Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
05E:2	MS3102	MS3108	MS3106	MS3057	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
10E:2	A20-15P	B20-15S	B20-15S	-12A				
15E:2	MS3102 A24-10P	MS3108 B24-10S	MS3106 B24-10S	MS3057 -16A				
22E:2								
37E:2								

## MECHANICAL SPECIFICATIONS


Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A) 0.04 (0.0016) 0.06† (0.0024†)	
Flange diameter concentric to shaft (B) 0.04 (0.0016)	
Shaft run out (C) 0.02 (0.0008)	

\* T. I. R. (Total Indicator Reading)  
 † Accuracy for motor types USADED-15E3, -22E3, and -37E3.

Servomotors with a brake are also available.  
 For detailed information, refer to related Bulletins (TSE-S800-11.1).

## CONNECTOR SPECIFICATIONS


Motor Receptacle



A	Phase U	E	Brake term.
B	Phase V	F	Brake term.
C	Phase W	G	—
D	Ground		


When not provided with holding brake, E and F are not used.

Incremental Encoder Receptacle



A	Channel A output	K	—
B	Channel Ā output	L	—
C	Channel B output	M	—
D	Channel B̄ output	N	—
E	Channel C output	P	—
F	Channel C̄ output	R	—
G	0V	S	—
H	+5VDC	T	—
J	Frame ground	—	—


Drawing 1 USASEM-02A□□2, -03A□□2, -05A□□2 (Straight Shaft)



## Notes :

1. Type USASEM-02A32 terminates in bare wires with a waterproof gland (seal) fitting. Therefore, the MS-connector part differs from the figure above. For details, contact your YASKAWA representative.
2. Plug and clamp are not attached for receptacle connection.
3. Motor should be mounted with connectors down.
4. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 3 (2048 P/R)  
Semi-standard : 4 (2500 P/R)

Drawing 2 USASEM-08A□□1, -15A□□1, -30A□□1 (Taper Shaft)



\*For only -15A31.

Detail of Shaft Extension

## Notes :

1. Hexagon socket head bolts should be used to mount the motor.
2. Plug and clamp are not attached for receptacle connection.
3. Key and keyway comply with JIS B 1301-1976.  
(Parallel key : precise class.)
4. Motor should be mounted with connectors down.
5. □ in the models are as follows according to types of the encoder (P/R).  
Standard : 3 (2048 P/R)  
Semi-standard : 4 (2500 P/R)



## Drawing 1

AC Servomotor Type USASEM-	L	LL	LM	LT	LR	KB1	Flange Surface and Shaft Extension								Approx Mass kg (lb)		
							LA	LB	LC	LE	LG	LH	LZ	S			
02A:12	164.5 (6.48)	134.5 (5.30)	95 (3.74)	39.5 (1.56)	30 (1.18)	76 (2.99)	80 (3.15)	50 (1.9685)	$0_{-0.025}^{0.001}$	65 (2.559)	3 (0.118)	6 (0.24)	89 (3.50)	5 (0.197)	8 (0.315)	$0_{-0.009}^{0.0003}$	1.4 (3.1)
03A:12	179 (7.05)	149 (5.87)	110 (4.33)	39 (1.54)	30 (1.18)	78 (3.07)	90 (3.54)	70 (2.7559)	$0_{-0.001}^{0.0002}$	80 (3.15)	3 (0.118)	8 (0.31)	105 (4.13)	6 (0.236)	14 (0.5512)	$0_{-0.0011}^{0.0004}$	2.6 (5.7)
05A:12	201 (7.91)	171 (6.73)	132 (5.20)	39 (1.54)	30 (1.18)	100 (3.94)	90 (3.54)	70 (2.7559)	$0_{-0.001}^{0.0002}$	80 (3.15)	3 (0.118)	8 (0.31)	105 (4.13)	6 (0.236)	14 (0.5512)	$0_{-0.0011}^{0.0004}$	3.3 (7.3)

## Drawing 2


AC Servomotor Type USASEM-	L	LL	LM	LT	LR	KB1	KB2	KL1	KL2	Flange Surface								Shaft Extension								Approx Mass kg (lb)				
										LA	LB	LC	LE	LG	LH	LZ	LW	Q	QK	QA	X	S	V	P	U		W	T		
08A:11	257 (10.12)	199 (7.84)	148.5 (5.85)	50.5 (1.99)	58 (2.28)	115 (4.53)	188 (7.4)	102 (4.02)	86 (3.39)	130 (5.12)	110 (4.3307)	$0_{-0.001}^{0.0005}$	120 (4.72)	3 (0.12)	10 (0.4)	155 (6.1)	9 (0.35)	18 (0.71)	28 (1.1)	25 (0.98)	12 (0.47)	10.3 (0.41)	16 (0.63)	21 (0.83)	M10 (P1.25)	4.3 (0.169)	$0_{-0.001}^{0.01}$	5 (0.1968)	5 (0.1968)	6 (13.2)
15A:11	325.5 (12.81)	267.5 (10.53)	203.5 (8.02)	56 (2.2)	58 (2.28)	166.5 (6.56)	239.5 (9.43)	109 (4.29)	87 (3.43)	145 (5.71)	110 (4.3307)	$0_{-0.001}^{0.0005}$	130 (5.12)	6 (0.24)	12 (0.47)	165 (6.5)	9 (0.35)	18 (0.71)	28 (1.1)	25 (0.98)	12 (0.47)	10.3 (0.41)	19 (0.75)	21 (0.83)	M10 (P1.25)	5.8 (0.228)	$0_{-0.001}^{0.01}$	5 (0.1968)	5 (0.1968)	11 (24.3)
30A:11	374 (14.72)	304 (11.97)	240 (9.45)	56 (2.2)	70 (2.76)	206 (8.11)	276 (10.87)	135 (5.32)	87 (3.43)	200 (7.87)	114.3 (4.5)	$0_{-0.001}^{0.0005}$	180 (7.09)	6 (0.24)	18 (0.71)	230 (9.1)	13.5 (0.53)	20 (0.79)	36 (1.42)	32 (1.26)	14 (0.55)	12.5 (0.49)	22 (0.87)	24 (0.94)	M12 (P1.25)	6.6 (0.26)	$0_{-0.001}^{0.01}$	6 (0.2362)	6 (0.2362)	24 (52.9)

## CONNECTOR TYPES

AC Servomotor Type USASEM-	Motor Connector Types				Incremental Encoder Connector Types			
	Receptacle	L-type Plug	Straight Plug	Cable Clamp	Receptacle	L-type Plug	Straight Plug	Cable Clamp
03A:12 05A:12	MS3102 A18-10P	MS3108 B18-10S	MS3106 B18-10S	MS3057 -10A	MS3102 A20-29P	MS3108 B20-29S	MS3106 B20-29S	MS3057 -12A
08A:11 15A:11 30A:11	MS3102 A20-4P	MS3108 B20-4P	MS3106 B20-4P	MS3057 -12A				

## MECHANICAL SPECIFICATIONS

Accuracy (T. I. R)*	Reference Diagram
Flange surface perpendicular to shaft (A)	0.04 (0.0016)
Flange diameter concentric to shaft (B)	0.04 (0.0016)
Shaft run out (C)	0.02 (0.0008)




Servomotors with a brake are also available. For detailed information, refer to related Bulletins (TSE-S800-11.1).

\* T. I. R. (Total Indicator Reading)

## CONNECTOR SPECIFICATIONS

Motor Receptacle

Incremental Encoder Receptacle



A	Phase U
B	Phase V
C	Phase W
D	Ground



A	Channel A output	K	—
B	Channel A output	L	—
C	Channel B output	M	—
D	Channel B output	N	—
E	Channel C output	P	—
F	Channel C output	R	—
G	0V	S	—
H	+5VDC	T	—
J	Frame ground	—	—

# 13.3 SERVOPACK

## 13.3.1 Rack-mounted Type CACR-HR | | | | | | | |--|--|--|-----|--|--| | | | | BAB | | | |--|--|--|-----|--|--|



Dimensions in mm (inches)

CACR-HRA5BAB11 to -HR03BAB11, CACR-HRA5BAB12 to -HR05BAB12



Type CACR-HR	Approx Mass kg(lb)
A5BAB12	3.7 (8.2)
01BAB12	
02BAB12	
03BAB12	
05BAB12	
A5BAB11	
01BAB11	
02BAB11	
03BAB11	

CACR-HR05BAB11, CACR-HR10BAB to -HR15BAB



Type CACR-HR	Approx Mass kg(lb)
10BAB	5.7(12.6)
15BAB	5.9(13.0)
05BAB11	5.7(12.0)


Attachments	
2CN connector for cable	
Case	: MR-20L
Receptacle	: MR-20M (Made by Honda Tsushin Co.)
3CN connector for cable	
Case	: MR-20L
Receptacle	: MR-20F (Made by Honda Tsushin Co.)
4CN connector for cable	
Case	: MR-20L
Receptacle	: MR-20F (Made by Honda Tsushin Co.)
5CN connector for cable	
Case	: MR-50L
Receptacle	: MR-50F (Made by Honda Tsushin Co.)

### 13.3.2 Base-mounted Type CACR-HR□□BB


Dimensions in mm (inches)

#### CACR-HR03BB to -HR15BB



#### CACR-HR20BB, -HR30BB



Approx. Mass : 7 kg (15.5lb)




Approx. Mass : 9 kg (19.9lb)




#### CACR-HR44BB



#### CACR-HR60BB



Approx. Mass : 12 kg (26.5lb)



Approx. Mass : 14kg(30.9lb)



#### Attachments (for both CACR-HR44BB and -HR60BB)

- 2CN connector for cable  
Case : MR-20L  
Receptacle : MR-20M\*
- 3CN connector for cable  
Case : MR-20L  
Receptacle : MR-20F\*
- 4CN connector for cable  
Case : MR-20L  
Receptacle : MR-20F\*
- 5CN connector for cable  
Case : MR-50L  
Receptacle : MR-50F\*

\* Made by Honda Tsushin Co.

## 14 APPENDIX PARAMETER SETTING

AC Servopack type CACR-HR is a position control provided with all constant setting and function selections using parameters. It is necessary to set the parameters before use.

For details of each parameter content, refer to the Section 8 in this manual. This section briefly describes parameter setting in checking method.


When it is required for YASKAWA to set parameters before delivery, fill out your machine configuration and specifications (sections ) and the required items in Par. 14.7 and contact your YASKAWA representative.

### 14.1 APPLICATIONS

### 14.2 ORDER ELECTRICAL DEVICES

Name	Type/Specifications	Q'ty
AC Servomotor	With encoder pulses/rev	
AC Servopack		
External Position Indicator	MCIF-L8 (Sigh + 8-digit)	
DG-SW (1 Set)	MCIF-D80 (Only position reference data)	
DG-SW (2 Set)	MCIF-D86 (Position or speed reference)	
Parameter Setter	PF803-ASY	

### 14.3 MACHINE CONFIGURATION




### 14.4 SPECIFICATIONS

Machine Specifications		Servomotor Specifications		Servopack Specification	
Using Axis	Horizontal Vertical	Rated Output		Input Power Supply	
			kW		
Max. Speed of Movable Section		Rated Speed		Continuous Output Current	
			r/min		
Total Deceleration Rate		Max. Speed		Max. Output Current	
			r/min		
Load Moving Amount per Load Shaft Rotation		Used Speed			
			r/min		
Load Torque *	N·m	Rated Torque			
			N·m (lb·in)		
Load Inertia J <sub>L</sub> *	kg·m <sup>2</sup> (lb·in·s <sup>2</sup> )	Rated Current			
			Arms		
Reference Unit(min.)		Rotor Inertia J <sub>M</sub>			
			kg·m <sup>2</sup> (lb·in·s <sup>2</sup> )		

\* Motor shaft conversion

# 14.5 SPEED DIAGRAM



## 14.6 PARAMETER SETTING TABLE

No	Name	Setting Range	Unit	Set Value
1	Position Loop Gain	0 to 200	S <sup>-1</sup>	
2	Speed Loop Gain	1 to 200	$\times 5J_M/(J_M+J_L)$ Hz	
3	Integral Time Constant	1 to 255	$\times 2$ ms	10
4	1st Feeding Speed (V <sub>1</sub> )	1 to 240000	( $\times 1000$ ) reference unit	
5	Linear Accel/Decel Time(t <sub>1</sub> )	8 to 60000	ms	
6	Positioning Complete Range	1 to 250	Reference unit/min	
7	Motor Selection Code	0 to 79		
8	Number of Encoder Pulses	4096 to 32768	Pulses/rev (at $\times 4$ )	
9	Encoder Selection Code	0: absolute, 1: incremental		
10	ABS0 Error Detection Range	0 to 99999999	Pulse (at $\times 4$ )	
11	Load Moving Amount per Load Shaft Rotation	1 to 15000000	Reference unit	
12	Gear Ratio Setting	Motor Shaft Speed	1 to 10000000 Rotation	
13		Load Shaft Speed		
14	Mode Setting	0 to 11111		
	b0: Motor rotating direction (+at reference)	0: FWD run, 1: REV run (CCW) (CW)		
	b1: Finite/infinite positioning mode	0: finite, 1: infinite		
	b2: Linear/rotating motion	0: linear, 1: rotation		
	b3: Position reference mode	0: absolute, 1: incremental		
	b4: Position data code	0: binary, 1: BCD		
15	Position Reference Input Method	0: station No., 1: DG-SW, 2: serial communication 4: command table		
16	Number of Stations	1 to 4096		
17	Function Selection 1	0 to 11111		0
	b0: Current limit	0: motor fixed value, 1: set		
	b1: Feed forward compensation	0: ineffective, 1: effective		0
	b2: Linear accel/decel 1-step/2-step	0: 1-step, 1: 2-step		
	b3: Speed limit	0: motor max. speed, 1: set		
	b4: Accel/decel type setting	0: linear (1-or 2-step), 1: selected in operation mode		
18	Function Selection 2	0 to 11111		
	b0: Software overtravel (position reference fault detection)	0: $\pm 99999999$ , 1: set		
	b1: Backlash compensation	0: not provided, 1: set		
	b2 Speed reference input method	Automatic mode	0: fixed by position reference method, 1: set	
	b3	Manual mode		
	b4: Zero-point return (homing) mode	0: not used, 1: used		

## 14.6 PARAMETER SETTING TABLE (Cont'd)

No	Name	Setting Range	Unit	Set Value	
19	Function Selection 3	0 to 11111111		<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	
	b0: OT signal	0: used, 1: not used		<input type="checkbox"/>	
	b1: STOP signal	0: used, 1: not used		<input type="checkbox"/>	
	b2: Holding brake release signal	0: not used, 1: used		<input type="checkbox"/>	
	b3: Pulse status in pulse mode	0: $A\phi + B\phi \times 4$ (fixed), 1: select		<input type="checkbox"/>	
	b4: Pulse output division rate	0: fixed dividing ratio 1:1 1: set dividing ratio		<input type="checkbox"/>	
	b5: Positioning (station) near signal	0: not used, 1: used		<input type="checkbox"/>	
	b6: OT signal switching	0: P-OT, N-OT operation in plus/minus direction, 1: N-OT, P-OT operation in plus/minus direction		<input type="checkbox"/>	
b7: Torque reference filter time constant change	0: no change, 1: change		<input type="checkbox"/>		
20	Function Selection 4	0 to 1111111		<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 0	
	b0:	0		<input type="checkbox"/> 0	
	b1: External position indicator	0: not used, 1: used		<input type="checkbox"/>	
	b2: Station No. (Q)	0: provided, 1: not provided		<input type="checkbox"/>	
	b3: Simplified S-curve Accel/Decel	0: not used, 1: used		<input type="checkbox"/>	
	b4: Pr72 function setting	0: not provided, 1: provided		<input type="checkbox"/>	
	b5: Pr65 function setting	0: not provided, 1: provided		<input type="checkbox"/>	
b6: Pr66 function setting	0: not provided, 1: provided		<input type="checkbox"/>		
31	Feeding Speed	2nd speed	1 to 240000	( $\times 1000$ ) reference unit/min	
32		3rd speed			
33		4th speed			
34	Current Limit Value	Plus/minus side	0 to 400	%	
35		Plus side			
36		Minus side			
37	Feedforward Compensation Value	0 to 100		%	0
38	Linear 2-step Accel Decel	Time ( $t_a$ )	8 to 60000	ms	
39		Switching speed ( $V_a$ )	0 to 240000	( $\times 1000$ )reference unit /min	
40	Software overtravel (position reference fault detection value)	Plus side	$\pm 99999999$	Reference unit	
41		Minus side			
42	Backlash Compensation	0 to $\pm 30000$		Pulse	
43	Braking Time	8 to 1000		ms	
44	Brake ON Motor Speed	1 to 10000		r/min	
45	Positioning (station) Near Range	0 to 30000		Reference unit	
46	Speed Limit Value	1 to 240000		( $\times 1000$ )reference unit/min	
47	Exponential Accel/Decel	Time constant ( $t_b$ )	8 to 1000	ms	
48		Bias speed ( $V_b$ )	0 to 240000	( $\times 1000$ )reference unit/min	



(Cont'd)

No	Name	Setting Range	Unit	Set Value	
49	Zero-point Return (Homing)	Method	0: mode I, 1: mode II		
50		Direction	0: plus direction, 1: minus direction		
51		Feeding speed	0 to 240000	( $\times 1000$ ) reference unit/min	
52		Approach speed			
53		Creep speed			
54	Final traveling distance	1 to $\pm 99999999$	Reference unit		
61	Speed Reference Input Method	Automatic mode	0: internal speed selection at contact,		
62		Manual mode	1: DG-SW, 2: serial command, 4: speed table		
63	Pulse Signal Status (with Pulse Mode)		0: $A\phi + B\phi \times 4$ , 1: $A\phi + B\phi \times 2$ , 2: $A\phi + B\phi \times 1$ , 3: sign + pulse train, 4: CCW pulse + CW pulse		
64	Output Pulse Dividing Ratio	2 to 60	2/N		
65	Function Selection 5	0 to 1111111			
	b0: Zone signal	0: not used, 1: used			
	b1: Station near signal	0: not used, 1: used			
	b2: DG-SW read-in time change	0: not change, 1: change			
	b3: DG-SW digit number shift	0: no shift, 1: shift			
	b4:	0			
	b5:	0			
	b6: Position completion signal change	0: not change 1: change			
66	Function Selection 6	0 to 11111111			
	b0:	0:			
	b1:	0:			
	b2:	0:			
	b3:	0:			
	b4: Station No. output extension	0: not extend 1: extend			
	b5:	0			
	b6:	0:			
	b7: Servopack axis address	0: not provided 1: provided			
67	External Position Indicator Decimal Point Position and Digit Number to Shift DG-SW Digit	0 to 7			
68	Accel/Decel Type Selection	Automatic mode	0: linear or simplified S-curve, 1: exponent		
69		Manual mode			
70		Pulse mode			
71		Zero-point return mode (Homing)			
72	Function Selection 7	0 to 11111			
	b0: Overrun detection alarm	0: detect, 1: not detect			
	b1: Remaining data after STOP signal	0: hold, 1: abandon			
	b2: PG selection when using line PG	0: by L-PG signal, 1: Forcing motor PG			
	b3: Echo-back at initialization	0: not echo back, 1: echo back			
	b4: OK response for command	0: no response, 1: response			
	b5: Monitor data transmission spec change	0: sent repeatedly 1: sent only once			
76	Simplified S-curve Accel/Decel Time	0 to 124	(+2)ms		
77	DG-SW Read-in Scanning Time	24 to 2000	ms		
90	Torque Reference Filter Time Constant	0 to 100	( $\times 32.5$ ) $\mu$ s		

Parameters 21 to 30, 55 to 60, 73 to 75, 78 to 89, 91 to 99 are for future use and all are set to "0"

## 14.7 PARAMETER CHECK LIST

### 14.7.1 Parameters Related to Motor Used

Motor Type: \_\_\_\_\_ (Pr7 = Codes as shown in the following table)

M Series		F Series		G Series		D Series	
Motor Type USAMED-	Code	Motor Type USAFED-	Code	Motor Type USAGED-	Code	Motor Type USADED-	Code
	0	02[ ][ ]1	10	02[ ][ ]1	50		40
03[ ][ ]1	1	03[ ][ ]1	11	03[ ][ ]1	51		41
06[ ][ ]1	2	05[ ][ ]1	12	05[ ][ ]1	52	05E [ ]	42
09B [ ] 2	3	09[ ][ ]1	13	09[ ][ ]1	53	10E [ ]	43
12B [ ] 2	4	13C [ ] 2	14	13A [ ] 2	54	15E [ ]	44
20B [ ] 2	5	20C [ ] 2	15	20A [ ] 2	55	22E [ ]	45
30B [ ] 2	6	30C [ ] 2	16	30A [ ] 2	56	37E [ ]	46
44B [ ] 2	7	44C [ ] 2	17	44A [ ] 2	57		47
USAMKD-60B [ ] 2	8		18		58		48

S Series		R Series (For 200V)		R Series (For 100V)		P Series	
Motor Type USASEM-	Code	Motor Type USAREM-	Code	Motor Type USAREM-	Code	Motor Type USAPEM-	Code
02A [ ]	20		30		60		70
03A [ ]	21		31		61		71
05A [ ]	22	A5C [ ] 2	32	A5D [ ] 2	62		72
08A [ ]	23	01C [ ] 2	33	01D [ ] 2	63	01C [ ] 2	73
15A [ ]	24	02C [ ] 2	34	02D [ ] 2	64	02C [ ] 2	74
	25	03C [ ] 2	35	03D [ ] 2	65	03C [ ] 2	75
30A [ ]	26	05C [ ] 2	36	05D [ ] 2	66	05C [ ] 2	76
	27	07C [ ] 2	37		67	07C [ ] 2	77

#### Encoder type

- Method:  Absolute encoder (Pr9 = 0)  
 Incremental encoder (Pr9 = 1)
- Number of pulses:  1024 pulses/rev (Pr8 = 4096)  
 2048 pulses/rev (Pr8 = 8192)  
 2500 pulses/rev (Pr8 = 10000)  
 8192 pulses/rev (Pr8 = 32768)


#### 14.7.2 Parameters Related to Machine Specifications

- ①  Linear motion (Pr14b2=0)      ②  Finite positioning (Pr14b1=0)  
 Rotating motion (Pr14b2=1)       Infinite positioning (Pr14b1=0)
- ③  Total reduction ratio \_\_\_\_\_ (=Pr13/Pr12)
- ④ Motor rotating direction when load moves in plus direction (viewed from load side)  
 CCW (Pr14b0=0)  
 CW (Pr14b0=1)
- ⑤ Reference unit(minimum) A = \_\_\_\_\_ (mm): position resolution
- ⑥ Load moving amount-per load shaft rotation P= \_\_\_\_\_ (mm)(Pr11=P/A)  
(Note) Limiting conditions:  $0.01 \leq (\text{Pr}8 \times \text{Pr}12)/(\text{Pr}11 \times \text{Pr}13) \leq 100$

### 14.7.2 Parameters Related to Machine Specifications (Cont'd)

#### ⑦ Accel/Decel type

	<input type="checkbox"/> All-mode Linear 1-step Accel/Decel Speed	<input type="checkbox"/> All-mode Linear 2-step Accel/Decel Speed	<input type="checkbox"/> All-mode Simplified S-curve Accel/Decel Speed	<input type="checkbox"/> Set in each Mode (Pr17b4=1)			
				Linear 1-step	Linear 2-step	Simplified S-curve	Exponential Accel/Decel Speed
<input type="checkbox"/> Automatic Mode				<input type="checkbox"/> Pr17b2=0 Pr68=0	<input type="checkbox"/> Pr17b2=1 Pr68=0	<input type="checkbox"/> Pr20b3=1 Pr68=0	<input type="checkbox"/> Pr68=1 { Pr17b2, Pr20b3 } Setting are not required.
<input type="checkbox"/> Manual Mode	Pr17b2=0 Pr17b4=0	Pr17b2=1 Pr17b4=0	Pr17b4=0 Pr20b3=1	<input type="checkbox"/> Pr17b2=0 Pr69=0	<input type="checkbox"/> Pr17b2=1 Pr69=0	<input type="checkbox"/> Pr20b3=1 Pr69=0	<input type="checkbox"/> Pr69=1 { Pr17b2, Pr20b3 } Setting are not required.
<input type="checkbox"/> Pulse Mode	{ Pr68 to Pr71 } Settings are not required.	{ Pr68 to Pr71 } Settings are not required.	{ Pr68 to Pr71 } Settings are not required.	<input type="checkbox"/> Pr17b2=0 Pr70=0	<input type="checkbox"/> Pr17b2=1 Pr70=0	<input type="checkbox"/> Pr20b3=1 Pr70=0	<input type="checkbox"/> Pr70=1 { Pr17b2, Pr20b3 } Setting are not required.
<input type="checkbox"/> Zero-point Return Mode				<input type="checkbox"/> Pr17b2=0 Pr71=0	<input type="checkbox"/> Pr17b2=1 Pr71=0	<input type="checkbox"/> Pr20b3=1 Pr71=0	<input type="checkbox"/> Pr71=1 { Pr17b2, Pr20b3 } Setting are not required.



	Pr				
V1(mm/min)	4				
V5(mm/min)	39	—		—	—
V6(mm/min)	48	—	—	—	—
t1(ms)	5				—
t5(ms)	38	—		—	—
t6(ms)	47	—	—	—	—
t7(ms)	76	—	—	—	—

(Pr4, 39, 47) = (Speed)/(1000 • A)

### 14.7.3 Parameters Related to Position Reference Method

① Reference input method

= Setting not required

		<input type="checkbox"/> Station No. Input	<input type="checkbox"/> DG-SW Input	<input type="checkbox"/> Serial Communication Input	<input type="checkbox"/> Command Table No. Input
Pr15		0	1	2	4
Pr16	Number of Stations				
Pr14b4	Position Data <input type="checkbox"/> Binary (= 0) <input type="checkbox"/> BCD (= 1)		1		0
Pr20	b1		Position Display <input type="checkbox"/> Not used (= 0) <input type="checkbox"/> Used (= 1)		
	b2	Station No. "0" <input type="checkbox"/> Provided (= 0) <input type="checkbox"/> Not provided (= 1)			
Pr65b0					Zone Signal <input type="checkbox"/> Not used (= 0) <input type="checkbox"/> Used (= 1)
Pr67			Position Display Decimal Point Position		

② Reference mode

Absolute value (Pr14b3=0)

Incremental value (Pr14b3=1)

### 14.7.4 Speed Reference Method

① Reference input method

= Setting not required

Speed Reference		Position Reference			<input type="checkbox"/> Station No. Input			<input type="checkbox"/> DG-SW Input			<input type="checkbox"/> Serial Communication Input			<input type="checkbox"/> Command Table No. Input		
		Pr18	Pr61	Pr62	Pr18	Pr61	Pr62	Pr18	Pr61	Pr62	Pr18	Pr61	Pr62	Pr18	Pr61	Pr62
Automatic Mode	<input type="checkbox"/> Contact*	b2=0			b2=1	0		b2=1	0		b2=1	0		b2=1	0	
	<input type="checkbox"/> DG-SW	Cannot be used			b2=0			b2=1	1		Cannot be used					
	<input type="checkbox"/> Serial Command	b2=1	2		b2=1	2		b2=0			b2=1	2				
	<input type="checkbox"/> Command Table	Cannot be used			Cannot be used			b2=1	4		b2=0					
Manual Mode	<input type="checkbox"/> Contact*	b3=0			b3=1	0		b3=1	0		b3=1	0		b3=1	0	
	<input type="checkbox"/> DG-SW	Cannot be used			b3=0			b3=1	1		Cannot be used					
	<input type="checkbox"/> Serial Command	b3=1		2	b3=1		2	b3=0			b3=1		2			
	<input type="checkbox"/> Command Table	Cannot be used			Cannot be used			b3=0		4	b3=0					

\* Select from internal speed by contact (only speed to be used is set.)

1st speed: V1= \_\_\_\_\_ mm/min (in/min) (Pr4)

2nd speed: V2= \_\_\_\_\_ mm/min (in/min) (Pr31)

3rd speed: V3= \_\_\_\_\_ mm/min (in/min) (Pr32)

4th speed: V4= \_\_\_\_\_ mm/min (in/min) (Pr33)

Pr4, Pr31 to 33 = (Speed)/(1000 • A)

↑  
Reference unit

### 14.7.5 Parameters Related to Position Control

① Speed loop gain

Motor inertia  $J_M =$  \_\_\_\_\_

Load inertia  $J_L =$  \_\_\_\_\_

$Pr2 = 20 \times (J_L + J_M) / J_M$

} (Motor shaft conversion value)

Note: When mechanical system rigidity is low and oscillation occurs, lower the above value.

② Positioning complete range

$C =$  \_\_\_\_\_ mm (inch) (Pr6 = C/A)

③ Positioning near range

Not used (Pr19b5=0, Pr45 setting not required)

Used (Pr19b5=1)

↳ Positioning near range  $N =$  \_\_\_\_\_ mm (inch)  
(Pr45 = N/A)

### 14.7.6 Selection Function

① Zero-point return (homing) mode:

Not used

(Pr18b4=0, Pr49 to 54 setting not required)

Used (Pr18b4=1)

	Pr	<input type="checkbox"/> Mode I (Decel LS + Cφ pulse) Pr49 = 0	<input type="checkbox"/> Mode II (STP signal) Pr49 = 1
Operation Pattern		<p>ZERO-POINT RETURN FEEDING SPEED</p> <p>ZERO-POINT RETURN APPROACH SPEED</p> <p>ZERO-POINT RETURN CREEP SPEED</p> <p>ZERO-POINT RETURN FINAL TRAVELING DISTANCE</p>	<p>ZERO-POINT RETURN APPROACH SPEED</p> <p>ZERO-POINT RETURN CREEP SPEED</p> <p>ZERO-POINT RETURN FINAL TRAVELING DISTANCE</p>
Zero-point Return Feeding Speed	50	<input type="checkbox"/> Motor FWD direction(=0)	<input type="checkbox"/> Motor REV direction(=1)
Feeding Speed* <sup>1</sup>	51		Setting not required
Approach Speed* <sup>1</sup>	52		
Creep Speed* <sup>1</sup>	53		
Final Traveling Distance* <sup>1</sup> (inch)	54		

\*1 Pr51 to Pr53 = (Speed)/(1000 · A)

\*2 Pr54 = (Distance)/A

- ② Pulse mode  Not used (Pr19b3, Pr63 setting not required)  
 Used (Pr19b3=1)

↳ Signal status

- 90 ° phase difference 2-phase pulse ×4 (Pr63=0)  
 90 ° phase difference 2-phase pulse ×2 (Pr63=1)  
 90 ° phase difference 2-phase pulse ×1 (Pr63=2)  
 Sign + pulse train (Pr63=3)  
 CW + CCW pulse train (Pr63=4)

- ③ Current limit  Not used (Pr17b0=0, Pr34 to 36 setting not required)  
 Used (Pr17b0=1)

- ↳  Plus/minus sides current limit value \_\_\_\_\_ % (=Pr34)  
 Plus side current limit value \_\_\_\_\_ % (=Pr35)  
 Minus side current limit value \_\_\_\_\_ % (=Pr36)

- ④ Speed limit  Not used (Pr17b3=0, Pr46 setting not required)  
 Used (Pr17b3=1)

↳ Speed limit value \_\_\_\_\_ mm/min  
 \_\_\_\_\_ (inch/min)  
 $Pr46 = (Speed)/(1000 \cdot A)$

- ⑤ Software overtravel

- Fixed (Pr18b0=0, Pr40, 41 setting not required)  
 Parameter setting (Pr18b0=1)

↳ Plus side software overtravel  $I_p =$  \_\_\_\_\_ mm(inch). (Pr40)  
 Minus side software overtravel  $I_n =$  \_\_\_\_\_ mm(inch) (Pr41)

Note: When incremental encoder is used (Parameter 9 = 1), software overtravel becomes effective after zero-point return (homing).

- ⑥ OT signal  Not used (Pr19b0=1)  
 Used (Pr19b0=0)
- ⑦ STOP signal  Not used (Pr19b1=1, Pr20b4, Pr72b1 setting not required)  
 Used (Pr19b1=0)

↳ Remaining data processed after STOP signal  
 Leave (Pr20b4=0, or Pr20b4=1, Pr72b1=0)  
 Abandon (Pr20b4=1, Pr72b1=1)

### 14.7.6 Selection Function (Cont'd)

⑧ Holding brake release signal

- Not used (Pr19b2=0, Pr43 and Pr44 setting not required)  
 Used (Pr19b2=1)

└─→ Braking time \_\_\_\_\_ ms (=Pr43)  
└─→ Brake ON motor speed \_\_\_\_\_ r/min(=Pr44)

⑨ Backlash compensation

- Not used (Pr18b1=0, Pr42 setting not required)  
 Used (Pr18b1=1)

└─→ Compensation value  $\delta =$  \_\_\_\_\_ mm(inch) (Pr42)  
$$\text{Pr42} = (\delta \times 32768 \times \text{Pr12}) / (A \times \text{Pr11} \times \text{Pr13})$$

⑩ Pulse output  Not used (Pr19b4=0, Pr64 setting not required)  
 Used (Pr19b4=1)

└─→ Dividing ratio (2/N) N = \_\_\_\_\_ (Pr64 = N)

⑪ Line PG

- Not used (Pr20b4, Pr72b2 setting not required)  
 Used ─→ PG selection after positioning complete  
 By L-PG signal  
(Pr20b4=0 or Pr20b4=1, Pr72b2=0)  
 Motor PG by force (Pr20b4=1, Pr72b2=1)



# AC SERVO DRIVES HR SERIES DESCRIPTIVE MANUAL

**TOKYO OFFICE** New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minatoku, Tokyo 105 Japan  
Phone 81-3-5402-4511 Fax 81-3-5402-4580

**YASKAWA ELECTRIC AMERICA, INC.**

**Chicago-Corporate Headquarters** 2942 MacArthur Blvd. Northbrook, IL 60062-2028, U.S.A.

Phone 1-847-291-2340 Fax 1-847-498-2430

**Chicago-Technical Center** 3160 MacArthur Blvd. Northbrook, IL 60062-1917, U.S.A.

Phone 1-847-291-0411 Fax 1-847-291-1018

**MOTOMAN INC.**

805 Liberty Lane West Carrollton, OH 45449, U.S.A.

Phone 1-937-847-6200 Fax 1-937-847-6277

**YASKAWA ELÉTRICO DO BRASIL COMÉRCIO LTDA.**

Avenida Brigadeiro Faria Lima 1664-5° CJ 504/511, São Paulo, Brazil

Phone 55-11-815-7723 Fax 55-11-870-3849

**YASKAWA ELECTRIC EUROPE GmbH**

Am Kronberger Hang 2, 65824 Schwalbach, Germany

Phone 49-6196-569-300 Fax 49-6196-888-301

**Motoman Robotics AB**

Box 504 S38525 Torsås, Sweden

Phone 46-486-48800 Fax 46-486-41410

**Motoman Robotec GmbH**

Kammerfeldstraße 1, 85391 Allershausen, Germany

Phone 49-8166-900 Fax 49-8166-9039

**YASKAWA ELECTRIC UK LTD.**

Unit2 Centurion Court Brick Close, Kjn Farm, Milton Keynes MK11 3JA, United Kingdom

Phone 44-1908-565874 Fax 44-1908-565891

**YASKAWA ELECTRIC KOREA CORPORATION**

Paik Nam Bldg. 901 188-3, 1-Ga Euljiro, Joong-Gu Seoul, Korea

Phone 82-2-776-7844 Fax 82-2-753-2639

**YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.**

151 Lorong Chuan, #04-01, New Tech Park Singapore 556741, Singapore

Phone 65-282-3003 Fax 65-289-3003

**YATEC ENGINEERING CORPORATION**

Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan

Phone 886-2-563-0010 Fax 886-2-567-4677

**BEIJING OFFICE** Room No. 301 Office Building of Beijing International Club, 21

Jianguomenwai Avenue, Beijing 100020, China

Phone 86-10-532-1850 Fax 86-10-532-1851

**SHANGHAI OFFICE** 27 Hui He Road Shanghai 200437 China

Phone 86-21-6553-6060 Fax 86-21-6553-6060

**YASKAWA JASON (HK) COMPANY LIMITED**

Rm. 2909-10, Hong Kong Plaza, 186-191 Connaught Road West, Hong Kong

Phone 852-2803-2385 Fax 852-2547-5773

**TAIPEI OFFICE** Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan

Phone 886-2-563-0010 Fax 886-2-567-4677



YASKAWA

YASKAWA ELECTRIC CORPORATION