

DRIVE OPERATION MODE SELECTION WITHOUT THE HAND/OFF/AUTO SELECTOR SWITCH OPTION TY

TABLE 1 FACTORY SET FP605 CONFIGURED DRIVE PARAMETERS

PARAMETER	DATA	UNIT	DESCRIPTION/REMARKS
b1-01	SEE TABLE 2 OR 3	N/A	FREQUENCY REFERENCE SELECTION 1
b1-02	SEE TABLE 2 OR 3	N/A	RUN COMMAND SELECTION 1
b1-15	SEE TABLE 2 OR 3	N/A	FREQUENCY REFERENCE SELECTION 2
b1-16	SEE TABLE 2 OR 3	N/A	RUN COMMAND SELECTION 2
d1-01	10.0	HZ.	FREQUENCY REFERENCE 1 - SEE TABLE 2 OR 3
d1-02	20.0	HZ.	FREQUENCY REFERENCE 2 - SEE TABLE 3
E1-01	208	VOLTS	INPUT VOLTAGE SETTING FOR BASE NUMBER "D__"
	240(480)		STANDARD INPUT VOLTAGE SETTING
E1-05	208	VOLTS	MAXIMUM OUTPUT VOLTAGE FOR BASE NUMBER "D__"
	230(460)		STANDARD MAXIMUM OUTPUT VOLTAGE SETTING
E2-01	—	AMPS	MOTOR FULL LOAD AMPS (MUST BE SET BY USER)
H1-05	SEE TABLE 2 OR 3	N/A	MULTI-FUNCTION DIGITAL INPUT TERMINAL S5 FUNCTION SELECTION
H1-06	SEE TABLE 2 OR 3	N/A	MULTI-FUNCTION DIGITAL INPUT TERMINAL S6 FUNCTION SELECTION
H3-02	SEE TABLE 2 OR 3	N/A	TERMINAL A1 FUNCTION SELECTION
H2-01	37	N/A	TERMINAL M1-M2 FUNCTION SELECTION = DURING FREQUENCY OUTPUT
H3-06	SEE TABLE 2 OR 3	N/A	TERMINAL A3 FUNCTION SELECTION
H3-09	SEE TABLE 2 OR 3	N/A	TERMINAL A2 SIGNAL LEVEL SELECTION
o2-03	1	N/A	USER INITIALIZATION FACTORY SET PARAMETER DEFAULT VALUES
o3-02	1	N/A	COPY ALLOWED SELECTION ENABLED

TABLE 2 F6C FACTORY SET DRIVE PARAMETERS

OPTION PRESENT	PARAMETER											DRIVE SPEED REFERENCE				DRIVE RUN/STOP CONTROL			
	A1-03	b1-01	b1-02	b1-15	b1-16	H1-05	H1-06	H3-02	H3-06	H3-09	DRIVE KEYPAD	0-10VDC AT TERM. A1 4-20mADC AT TERM. A2, OR 0-10VDC AT TERM. A3	SPEED POT	SERIAL COMM.	DRIVE TERMINAL S1 OR S2	DRIVE KEYPAD	DRIVE MOUNTED START/STOP PUSH BUTTONS	SERIAL COMM.	
NONE +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■		YES			YES				
NONE	2220	0	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■	d1-01				YES				
NONE	2220	1 ■	0	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■		YES				YES			
NONE	2220	0	0	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■	d1-01					YES			
T6 +	3330	1 ■	1 ■	0 ■	0 ■	0 ■	3 ■	0 ■	2 ■	2 ■		YES					YES		
T6	3330	0	1 ■	0 ■	0 ■	0 ■	3 ■	0 ■	2 ■	2 ■	d1-01					YES	YES		
TZ +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■			YES		YES				
TZ	2220	1 ■	0	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■			YES			YES			
TZ AND T6 +	3330	1 ■	1 ■	0 ■	0 ■	0 ■	3 ■	0 ■	2 ■	2 ■			YES				YES		
T3,TD,TG,TH,TJ,TL OR TQ +	2220	3	3	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■				YES				YES	
T3,TD,TG,TH,TJ,TL OR TQ	2220	1 ■	3	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■		YES						YES	
T3,TD,TG,TH,TJ,TL OR TQ	2220	0	3	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■	d1-01							YES	
T3,TD,TG,TH,TJ,TL OR TQ	2220	3	0	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■				YES		YES			
T3,TD,TG,TH,TJ,TL OR TQ	2220	3	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■				YES	YES				
T6 AND (T3,TD,TG,TH,TJ,TL OR TQ)	3330	3	1 ■	0 ■	0 ■	0 ■	3 ■	0 ■	2 ■	2 ■				YES			YES		
TZ AND (T3,TD,TG,TH,TJ,TL OR TQ)	2220	1 ■	3	0 ■	0 ■	3 ■	4 ■	0 ■	2 ■	2 ■			YES					YES	

+ = STANDARD FP605 CONFIGURED SET UP  
 ■ = FACTORY 2-WIRE INITIALIZATION DEFAULT SETTING

DRIVE OPERATION MODE SELECTION WITH THE HAND/OFF/AUTO SELECTOR SWITCH OPTION TY

TABLE 3 F6C FACTORY SET DRIVE PARAMETERS

OPTION PRESENT	PARAMETER											DRIVE SPEED REFERENCE		DRIVE RUN/STOP CONTROL				
	A1-03	b1-01	b1-02	b1-15	b1-16	H1-05	H1-06	H3-02	H3-06	H3-09	CONTROL BOARD SWITCH S1(A2)	DRIVE KEYPAD	SPEED POT	SIGNAL LEVEL AT TB1 (4) AND (5)	SERIAL COMM.	HAND/OFF/AUTO SWITCH IN THE "HAND" POSITION	RUN CONTACT AT TB1 (1) AND (2)	SERIAL COMM.
TY +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	F	2 ■	1 ■	d1-02		4 TO 20mADC		YES	YES	
TY	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	F	0	V	d1-02		0 TO 10VDC		YES	YES	
TY AND T6 +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	F	2 ■	1 ■	d1-02		4 TO 20mADC		YES	YES	
TY AND T6	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	0 ■	F	0	V	d1-02		0 TO 10VDC		YES	YES	
TY AND TZ +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	2	F	2 ■	1 ■		YES	4 TO 20mADC		YES	YES	
TY AND TZ	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	2	F	0	V		YES	0 TO 10VDC		YES	YES	
TY, TZ, AND T6 +	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	2	F	2 ■	1 ■		YES	4 TO 20mADC		YES	YES	
TY, TZ, AND T6	2220	1 ■	1 ■	0 ■	0 ■	3 ■	4 ■	2	F	0	V		YES	0 TO 10VDC		YES	YES	
TY AND (T3,TD,TG,TH,TJ,TL OR TQ)	2220	0	1 ■	3	3	2	1	0 ■	F	2 ■	1 ■	d1-01			YES	YES		YES
TY, TZ AND (T3,TD,TG,TH,TJ,TL OR TQ)	2220	1 ■	1 ■	3	3	2	1	0 ■	F	2 ■	1 ■		YES		YES	YES		YES

+ = STANDARD FP605 CONFIGURED SET UP  
 ■ = FACTORY 2-WIRE INITIALIZATION DEFAULT SETTING

**YASKAWA**

DRAWN BY: E. ACKERMAN	DATE: 9/12/22	TITLE: DRIVE PARAMETERS FP605 CONFIGURED
CHECKED BY: K. MALUSIC	DATE: 10/27/22	
APPROVED BY: R. JENSEN	DATE: 10/31/22	SIZE: D
ORIGINAL DESIGNER: E. ACKERMAN	DATE: 9/12/22	REVISION: 00
DRAWING #: UDE00749		PAGE: 1 of 1

REVISIONS				
REV.	DESCRIPTION	ECO #	DRAWN BY	DATE
00	INITIAL RELEASE	-	EAA	10/31/22

THIS DOCUMENT AND INFORMATION CONTAINED IN IT ARE CONFIDENTIAL, AND CANNOT BE COPIED OR DISCLOSED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF YASKAWA AMERICA INC.