

# MotionSuite™ MP940 Machine Controller Hardware Manual

# Table of Contents

|  |    |
|--|----|
| Section 1: Introduction.....                   | 1  |
| Machine Controller .....                       | 1  |
| Part Numbers .....                             | 3  |
| Section 2: Startup.....                        | 5  |
| Mounting Orientation .....                     | 5  |
| Mounting the MP940 to an SGDH .....            | 6  |
| Mounting the Battery Holder .....              | 8  |
| Power / Connections .....                      | 11 |
| Wiring - Single Phase .....                    | 12 |
| Wiring - Three Phase .....                     | 13 |
| SGDH and MP940 Startup Procedure .....         | 14 |
| Section 3: DIP Switch Definition .....         | 15 |
| Section 4: LED Indicators.....                 | 19 |
| LED Display .....                              | 19 |
| Section 5: Communications .....                | 21 |
| Serial Communication .....                     | 21 |
| System Configuration .....                     | 22 |
| Communication Specifications .....             | 23 |
| Mechatrolink.....                              | 27 |
| MP940 Master.....                              | 27 |
| Mechatrolink Connection .....                  | 28 |
| DeviceNet .....                                | 29 |
| Network Connections .....                      | 29 |
| Setting the Network Address .....              | 30 |
| Setting the Baud Rate .....                    | 30 |
| DeviceNet Status LEDs .....                    | 31 |
| Setup Requirements on the Network Master ..... | 31 |
| Troubleshooting .....                          | 32 |

|  |    |
|--|----|
| Section 6: Digital I/O .....                             | 39 |
| Digital I/O Specifications .....                         | 40 |
| Section 7: Limit Switch Inputs .....                     | 43 |
| Section 8: Analog I/O .....                              | 45 |
| Analog Input .....                                       | 45 |
| Analog Output.....                                       | 46 |
| Section 9: External Encoder .....                        | 47 |
| External Encoder Specifications .....                    | 48 |
| Section 10: Registration Latch.....                      | 49 |
| Main Encoder Registration Input.....                     | 50 |
| External Encoder Registration Input.....                 | 51 |
| Section 11: Maintenance.....                             | 53 |
| Battery Life .....                                       | 53 |
| Battery Replacement.....                                 | 53 |
| Section 12: Specifications.....                          | 55 |
| Physical Specifications .....                            | 55 |
| Hardware Specifications .....                            | 56 |
| Section 13: Dimensional Drawings and Cable Diagrams..... | 59 |
| Dimensions .....   | 59 |
| Connections .....  | 63 |
| Connector Specifications .....                           | 64 |
| I/O Connector .....                                      | 65 |
| Mechatrolink Cables .....                                | 67 |
| Mechatrolink Cable.....                                  | 67 |

## Section 1: Introduction

The MP940 is a 1.5 axis machine controller which connects to an SGDH servo amplifier via dual-port RAM.

This combination makes a fully integrated one-and-a-half-axis machine controller. It can be used to perform point-to-point positioning, or following of external devices. It has on-board digital and analog I/O, and network connections to link to other factory automation equipment.

Note: Refer to the SGDH User's Manual for SGDH information.

### Machine Controller



*Figure 1.1: MP940 Machine Controller / SGDH Combination*





Figure 1.2: Block Diagram of MP940 Functions



## Part Numbers


|                     |    | Description                                     | Item Number    |
|---------------------|----|---|----------------|
| MP940               | a) | Machine Controller with Mechatrolink Interface  | JEPMC-MC400    |
|                     |    | Machine Controller with DeviceNet Interface     | JEPMC-MC410    |
| I/O Cables          | b) | 1.0m 50 Pin I/O Cable                           | JZSP-CKI01-1   |
|                     |    | 2.0m 50 Pin I/O Cable                           | JZSP-CKI01-2   |
|                     |    | 3.0m 50 Pin I/O Cable                           | JZSP-CKI01-3   |
|                     |    | 1.0m 50 Pin I/O Cable (with terminal block)     | JUSP-TA50P     |
| Mechatrolink Cables | c) | Mechatrolink Cable 0.3m USB-USB                 | JEPMC-W6000-A3 |
|                     |    | Mechatrolink Cable 0.5m USB-USB                 | JEPMC-W6000-A5 |
|                     |    | Mechatrolink Cable 1.0m USB-USB                 | JEPMC-W6000-01 |
|                     |    | Mechatrolink Cable 3.0m USB-USB                 | JEPMC-W6000-03 |
|                     |    | Mechatrolink Cable 5.0m USB-USB                 | JEPMC-W6000-05 |
|                     |    | Mechatrolink Cable 10.0m USB-USB                | JPEMC-W6000-10 |
|                     |    | Mechatrolink Network Terminator Plug            | JEPMC-W6020    |
| Serial Cables       | d) | 3.0m Port #1 Cable                              | YS-15          |
|                     |    | 3.0m Port #1 or Port #2 Pigtail Cable           | YS-14          |
| Accessories         | e) | 3.6V Lithium Battery (with cable and connector) | BA000518       |
|                     |    | Battery Holder (replacement)                    | DF9402712      |
|                     |    | DC Power Supply Connector (replacement)         | UFS-0118       |
|                     |    | Mounting Clip A (replacement)                   | DF9402713      |
|                     |    | Mounting Clip B (replacement)                   | DF9402714      |
| Software            | f) | MotionWorks™                                    | MPE720         |
|                     |    | MotionWorks+™                                   | CP717PLUS      |

**NOTES:**

## Section 2: Startup

### Mounting Orientation


Mount the SGDH and MP940 in the appropriate direction for proper cooling, as shown on the left below.



***Figure 2.1: Mounting Orientation***

## Mounting the MP940 to an SGDH

1. Insert the lower two mounting notches into the mounting holes at the bottom of the right side of the SGDH.




**Figure 2.2: Mounting the MP940 to an SGDH Servo Amplifier**

2. Push the MP940 in the direction indicated by the arrows in the figure above, and insert the upper mounting notches of the MP940 into the upper mounting holes on the right side of the SGDH.



3. Insert the mounting clips into the mounting holes in the MP940, as shown in the figure below.




**Figure 2.3: Inserting the Mounting Clips**

4. While pulling out on the mounting clip, hook the mounting clip on the top of the MP940 case.
5. Mount the lower clip in the same manner.

## Mounting the Battery Holder


Follow the steps below to mount the battery holder. The mounting method for the MP940 battery holder is shown in the following figure.

1. Insert the battery holder into the MP940 upper battery holder mounting hole.
2. With the upper lock in contact with the battery holder mounting hole (top), push the bottom of the battery holder into the bottom mounting hole.



**Figure 2.4: Mounting the Battery Holder**


3. Push the holder up to ensure it is securely mounted.



**Figure 2.5: The Battery Holder is Securely Mounted**

## ■ Battery

A battery is needed during absolute encoder use for both MP940 and SGDH position data memory.



**Figure 2.6: MP940 and SGDH Batteries**


The batteries are required under the conditions listed below:

| SGDH | MP940 | Usage Method  |
|------|-------|---|
| No   | No    | <ul style="list-style-type: none"> <li>• FLASH Operation</li> <li>• Incremental encoder, or absolute encoder used as an incremental encoder.</li> </ul>               |
| No   | Yes   | <ul style="list-style-type: none"> <li>• No FLASH Operation (RAM used)</li> <li>• Incremental encoder, or absolute encoder used as an incremental encoder.</li> </ul> |
| Yes  | No    | <ul style="list-style-type: none"> <li>• FLASH Operation</li> <li>• Absolute encoder used.</li> </ul>   |
| Yes  | Yes   | <ul style="list-style-type: none"> <li>• No FLASH Operation (RAM used)</li> <li>• Absolute encoder used.</li> </ul>   |

## Power / Connections

The MP940 must be supplied with 24VDC. Detailed information on power requirements for the SGDh are found in the SGDh User’s Manual.

|                       |                      |
|-----------------------|----------------------|
| Power Consumption     | 20W                  |
| Recommended Fuse Size | 1A                   |
| Type of Power Supply  | Regulated 24VDC ±10% |



**Figure 2.7: MP940 Power Connection**

| Signal | Name         |
|--------|--------------|
| +24V   | +24VDC Input |
| GND    | 0VDC Input   |
| FG     | Frame Ground |

## Wiring - Single Phase

Apply power to the SGDH and MP940 at the same time. If the SGDH is not powered within 10 seconds after turning power ON to the MP940 (or vice versa), the units will not communicate with each other. Note: For maximum noise immunity, connect the FG to a ground terminal on the sub-panel, or to the ground terminal on the SGDH.




Figure 2.8: Single-phase Wiring

## Wiring - Three Phase

Apply power to the SGDh and MP940 simultaneously. If the SGDh is not powered within 10 seconds after turning power ON to the MP940 (or vice versa), the units will not communicate with each other. Note: For maximum noise immunity, connect the FG to a ground terminal on the sub-panel, or to the ground terminal on the SGDh.




Figure 2.9: Three-phase Wiring


## SGDH and MP940 Startup Procedure

Follow the steps below to set up the system.

1. Set the DIP switch of the MP940 as “MEMORY CLEAR”. (Only ‘INIT’ and TEST are ON.)
2. Apply power to both the SGDH and the MP940.
3. Verify that the MP940 is initialized. (RDY and RUN LED lights blink.)
4. Set the DIP switch to normal operation. (Only RUN is ON).
5. Cycle the power of the MP940 and the SGDH.
6. Start the MotionSuite™ software tool and connect ON LINE.

## Section 3: DIP Switch Definition

The function of the six switches is explained in the table below.




*Figure 3.1: MP940 DIP Switches*

### DIP Switch Settings

| Number | Name                     | Setting | Function  | Default Setting |
|--------|--------------------------|---------|---|-----------------|
| 6      | RUN                      | ON      | Application program runs at power ON  | ON              |
|        |                          | OFF     | Application program does not run at power ON  |                 |
| 5      | INIT                     | ON      | When DIP switch 4 is OFF:<br>Data is copied from flash memory to RAM at power ON.<br>When DIP switch 4 is ON:<br>Memory is cleared. | OFF             |
|        |                          | OFF     | When DIP switch 4 is OFF:<br>Data is not copied from flash memory to RAM at power ON.<br>When DIP switch 4 is ON:<br>Nothing        |                 |
| 4      | TEST                     | ON      | Terminal Mode/Initialization Mode   | OFF             |
|        |                          | OFF     | Online  |                 |
| 3      | FLASH                    | ON      | Program is copied from flash memory to RAM at power ON.   | OFF             |
|        |                          | OFF     | Program is not copied from flash memory to RAM at power ON  |                 |
| 2      | Programming Port Default | ON      | Defaults to Port 1 only   | OFF             |
|        |                          | OFF     | The programming port is set up through software selection   |                 |
| 1      | COPY                     | ON      | Global variables are copied from flash at power ON  | OFF             |
|        |                          | OFF     | Global variables are not copied from flash at power ON.   |                 |

## ■ Memory Initialization


To erase the application program, variables, and configuration data, set the DIP switches in the following order.

| Step 1                   | Step 2  | Step 3  | Step 4   | Step 5         |
|--------------------------|---|---|--|----------------|
| Turn the MP940 power OFF | Turn the INIT and TEST DIP switches to ON   | Turn on the power, and check that the RDY and RUN LEDs are flashing (approximately 3s). | Turn the power OFF. Turn the Run DIP switch ON.                                    | Turn power ON. |
|                          |  |   |  |                |

Note: Perform memory initialization if controller power is turned OFF while the battery is removed. This is not necessary if using the “Copy from Flash at Power Up” mode.

## ■ Standard Operation

The DIP switch pattern shown is the factory default setting.



*Figure 3.2: Factory Default Setting*

## ■Flash Memory Operation

### Outline Of Flash Operation


Programs created by the user are normally stored in RAM. The CPU executes programs stored in RAM. The programs stored in RAM can also be saved to the flash memory. Running programs after copying them from flash to RAM at power ON is called flash operation.

Flash memory saves programs even if there is no memory backup battery.

### Flash Start Mode

Transfer from flash memory to RAM occurs when DIP switch 3 is ON (flipped to the right) and the power is turned ON.

Note: MotionSuite™ software tools have a setting which copies the application program to flash when downloading. Refer to the software manual for details. The flash start mode does not work unless an application program has been saved to flash.



*Figure 3.3: Transfer from Flash Memory to RAM*

## ■Retaining Variable Data

The lithium battery makes it possible to save variable data in RAM even when the power is OFF. This is useful when saving data that changes during operation, such as a parts counter, or specific information about a job run. Programming must be written so that specific variables that must be retained are not initialized every time the power is turned ON.

## ■ Copying Servo Amplifier Pn Data from MP940 to SGDH

It is possible to load parameter data that was downloaded to the controller via MotionWorks or MotionWorks+ by turning off all DIP switches except the copy switch. The parameter transfer will occur at power up. The display panel on the SGDH will go off during the parameter transfer. Return the DIP switches to standard operation and cycle power after the operation is complete.

## Section 4: LED Indicators

### LED Display

The MP940 runs a series of tests during start-up. If an error is detected, the ERR LED flashes, and the content of the error corresponds to the number of flashes. MotionSuite™ software tools cannot communicate with the controller while an error LED is flashing or memory initialization is occurring. The MP940 LEDs are shown in the following table.

#### LED Display Patterns

| Type    | LED   |                |              |              | Meaning   |
|---------|---|----------------|--------------|--------------|---|
|         | RDY<br>(Green)                                  | RUN<br>(Green) | ERR<br>(Red) | BAT<br>(Red) |   |
| Normal  | ON  | OFF            | OFF          | OFF          | Application program stopped   |
|         | ON  | ON             | OFF          | OFF          | Normal application program execution  |
| Error   | OFF   | OFF            | ON           | OFF          | Memory error (initialization may be required)   |
|         | OFF   | OFF            | OFF          | OFF          | Initial operation (when display continues)  |
|         | OFF   | OFF            | Flashing     | OFF          | 1. 2 flashes: RAM error<br>2. 3 flashes: ROM error<br>3. 4 flashes: Peripheral LSI letter |
| Warning | —   | —              | —            | ON           | Battery alarm   |
|         | ON  | ON             | ON           | OFF          | 1. Operand error or I/O error   |
|         | System (S) register message<br>(no LED display) |                |              |              | Hardware status (Momentary Stop, RUN/STOP, Testing Mode, etc.)                            |
| Other   | Flashing  | Flashing       | OFF          | OFF          | Memory initialization by DIP switch setting complete.                                     |
|         | OFF   | OFF            | ON           | OFF          | Offline testing mode.   |


In addition, there are the following four LEDs.

| Description | Type         | Color | Meaning                           |
|-------------|--------------|-------|-----------------------------------|
| PRT1        | RS232        | Green | Flashes to indicate communication |
| PRT2        | RS422        | Green | Flashes to indicate communication |
| TX          | Mechatrolink | Green | Flashes to indicate communication |
| RX          | Mechatrolink | Green | Flashes to indicate communication |

### ■ I/O Status LED

The status of the digital inputs and outputs can be displayed by using an LED block accessory.

| No. | Signal Name | Note        | No. | Signal Name | Note |
|-----|-------------|-------------|-----|-------------|------|
| 1   | VCC         | Power (+5V) | 2   | —           | —    |
| 3   | —           | —           | 4   | LED0*       | —    |
| 5   | LED1*       | —           | 6   | —           | —    |
| 7   | LED2*       | —           | 8   | LEDPW0      | —    |
| 9   | LEDPW3      | —           | 10  | LEDPW2      | —    |
| 11  | LED3*       | —           | 12  | LED4        | —    |
| 13  | LED5*       | —           | 14  | LEDPW1      | —    |
| 15  | LED7        | —           | 16  | LED6*       | —    |




**Figure 4.1: MP940 LED Block**

## Section 5: Communications

### Serial Communication

The MP940 is equipped with one (1) RS-232C port and one (1) RS-422/485 port. PORT1 (RS-232) is the programming port.


The MP940 operates as either a master or slave according to setting in the MotionSuite™ software tools.



**Figure 5.1: Serial Transmission Interface**


## System Configuration

The figure below illustrates connection of a PC and an operator interface to the MP940.



**Figure 5.2: Serial System Configuration**

The figure below illustrates connection of a MotionSuite™ programming tool to the RS-232C port and branched connection of peripheral devices from the RS-485 port.




**Figure 5.3: Branched Connection of Peripheral Devices**

## Communication Specifications


| Item                  | Specification                             |   |
|-----------------------|---|---|
| Interface             | RS-232,<br>RS-422/485                     | 1 Port<br>1 Port  |
| Connector             | RS-232 PORT1<br>RS-422/485 PORT2          | MDR-14pin/female<br>MDR-14pin/female  |
| Transmission Range    | RS-232:<br>RS-422/485:                    | 15m Maximum<br>300m Maximum   |
| Baud Rate             | RS-232 PORT1<br>RS-422/485 PORT2:         | 9600, 14400, 19200bps<br>9600, 14400, 19200bps  |
| Synchronization Type  | Asynchronous (start-stop synchronization) |   |
| Transmission Protocol | MEMOBUS (Master/Slave)                    |   |
| Transmission Format   | Data Bit Length<br>Stop Bit<br>Parity Bit | 7 or 8 Bit<br>1 or 2 Bit (port 1 only) port 2 is fixed at 1 stop bit<br>Even/Odd/None |

### ■ Connector pins and signal names of port 1

|   | Pin | Signal Name | Description   | Pin | Signal Name | Description     |
|---|-----|-------------|---------------|-----|-------------|-----------------|
|  | 1   | TxD         | Transmit data | 8   | —           | —               |
|   | 2   | —           | —             | 9   | —           | —               |
|   | 3   | RxD         | Receive data  | 10  | —           | —               |
|   | 4   | —           | —             | 11  | —           | —               |
|   | 5   | —           | —             | 12  | RTS         | Request to Send |
|   | 6   | CTS         | Clear to Send | 13  | —           | —               |
|   | 7   | —           | —             | 14  | GND         | Ground          |

## ■ Connector pins and signal names of port 2

|  | Pin | Signal Name | Description                        | Pin | Signal Name | Description                            |
|--|-----|-------------|------------------------------------|-----|-------------|--|
| <br>PORT2 | 1   | TX+         | + side of transmission data        | 8   | TX+         | + side of transmission data            |
|  | 2   | TX-         | - side of transmission data        | 9   | TX-         | - side of transmission data            |
|  | 3   | RX+         | + side of received data            | 10  | RX+         | + side of received data                |
|  | 4   | RX-         | - side of received data            | 11  | TXR         | Transmission data termination resistor |
|  | 5   | —           | —                                  | 12  | —           | —                                      |
|  | 6   | RX-         | - side of received data            | 13  | VCC         | Power +5V                              |
|  | 7   | RXR         | Received data termination resistor | 14  | GND         | Ground                                 |




**Figure 5.4: Internal Termination Resistors**

The MP940 has two internal terminating resistors that are connected to the positive side of the signal. To terminate the signals, connect RXR and RX- together, as well as TXR and TX- signals.

**■RS422/485 Interface Cable**

1. Make sure that the drive system, control system, power system, and other transmission systems are separate from each other (i.e., do not run the power wire with the control wire).
2. The RS422/485 cable length is 300m maximum. Use the minimum length necessary.
3. The MP940 module RS422/485 interface is a non-isolated system. Errors may occur from noise in the connected terminal. If noise occurs, use a shield-type cable and modem to reduce the noise.
4. In the case of RS422, insert a terminating resistor as needed. Make the termination on the receiving side.
5. In the case of RS-485, attach a terminating resistor to both ends of the transmission line.




**Figure 5.5: Wiring Diagram**



## Mechatrolink Connection

The following figure shows the connection of the MP940 module to an I/O350 unit.


Use the standard cable (JEPMC-W6000-A3) when connecting an MP940 module to an I/O350, or when connecting one I/O350 to another I/O350.



**Figure 5.7: MP940 Connection to Multiple I/O 350 Modules**

Insert the USB terminator (JEPMC-W6020) into the terminal connector ((1) or (2) in the figure below). The mechatrolink connectors 1 and 2 are the same; the terminator may be inserted into either one.


Insert a USB terminator (JEPMC-W6020) into unused ports.



**Figure 5.8: Terminal Connectors**

There is only one channel per Mechatrolink port in the MP940 module. As shown in the figure above, the top and bottom of the connector are the same although there are two receptacles.

### ■The MP940 is used as a slave node:



The MP940 cannot communicate directly to the I/O350 or distributed I/O if configured as a slave.

## DeviceNet


The DeviceNet option is included with MP940D part number JEPMC-MC410.

## Network Connections

| Pin | Description | Color |
|-----|-------------|-------|
| 1   | V+          | Red   |
| 2   | CAN+        | White |
| 3   | Shield      | Bare  |
| 4   | CAN-        | Blue  |
| 5   | V-          | Black |

## Setting the Network Address


There are two rotary switches on the side of the MP940D. Rotate the switches to the appropriate node address. Every device on the network must have a unique address. For example, to set the unit to address 46, set the left dial to “4” and the right dial to “6” as shown below. Note: The maximum number of device nodes is 63.



**Figure 5.9: Rotary Switches**

## Setting the Baud Rate

There are four DIP switches on the side of the unit.



**Figure 5.10: DIP Switches**

Follow the chart to set each of the baud rates.

|      | DR1 | DR0 |
|------|-----|-----|
| 125k | OFF | OFF |
| 250k | OFF | ON  |
| 500k | ON  | OFF |

## DeviceNet Status LEDs

There are two status LEDs above the network connector. Their display is either green or red, depending on the current status. The left LED is MS (Module Status), and the right LED is NS (Network Status).

| Module Status  | Network Status | Explanation                                | Troubleshooting   |
|----------------|----------------|--|---|
| solid green    | solid green    | Normal running condition                   | No action required.   |
| flashing green | flashing green | No network power (24V)                     | Check the connection state of the rack and system bus cable connectors.   |
| solid green    | flashing red   | No response received from DeviceNet master | Check the connection state of the rack and system bus cable connectors.<br>Check the baud rate setting of each device.<br>Check the resistance and mounting of the termination resistor (121 ohms).<br>Check the operation of the DeviceNet master. |
| solid red      | OFF            | Hardware defect                            | Replace module.   |
| solid red      | solid red      | Hardware defect                            | Replace module.   |

## Setup Requirements on the Network Master

|             |                     |
|-------------|---------------------|
| Strobed     | No                  |
| Polled I/O  | Yes                 |
| Explicit    | No                  |
| Input Size  | 256 bytes (maximum) |
| Output Size | 256 bytes (maximum) |

Input/output size can be less, but the settings must agree on both master and slave setup configuration.

## Troubleshooting

When the LED detects an error during DeviceNet communications, it reports the error via the indicators. The following table gives probable causes and possible solutions.

### ■ Master

#### Troubleshooting the Master

| Indicators                 | Problem                     | Probable Cause   | Possible Solution   |
|----------------------------|-----------------------------|--|---|
| MS not lit<br>NS not lit   | No DeviceNet communications | No power to the MP940D   | Check the network power supply to the MP940D.   |
| MS red lit<br>NS not lit   |                             | Hardware malfunction   | Replace MP940D.   |
| MS red lit<br>NS red lit   |                             | Hardware malfunction   | Replace MP940D.   |
| MS green lit<br>NS red lit |                             | Duplicate MAC ID   | (1) Change the MAC ID address for the MP940D and cycle the power.<br>(2) Change the MAC ID addresses for other DeviceNet devices and cycle the power to the MP940D.   |
|                            |                             | Bus-OFF  | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the power supply voltage and connection for communications power.<br>(3) Check the network power supply voltage on the connector of each slave (11 to 24 V).<br>(4) Check the baud rate for each DeviceNet device in the network.<br>(5) Check the terminator (121Ω) and connection status. Check the length of the network.<br><br>Replace the MP940D. Then, either cycle the power for the MP940D or disconnect and reinsert the DeviceNet connectors. |
| MS green lit<br>NS not lit | Network power supply error  | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the power supply voltage and connection for communications power.<br>(3) Check the network power supply voltage on the connector of each slave (11 to 24V). |   |

### Troubleshooting the Master

| Indicators                            | Problem  | Probable Cause  | Possible Solution  |
|---------------------------------------|--|---|--|
| MS green lit<br>NS not lit<br>(cont.) | No DeviceNet communications<br>(cont.)   | DeviceNet network error   | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the baud rate for each DeviceNet device in the network.<br>(3) Check the terminator (121Ω) and connection status.<br>(4) Check the operation status of DeviceNet devices on the network.<br>(5) Replace the MP940D. |
| MS green lit<br>NS green flashing     |  | Connection not established with DeviceNet device  | Set the I/O allocations.   |
| MS green lit<br>NS red flashing       |  | DeviceNet I/O sizes different to setting  | (1) Change the I/O sizes for the I/O allocation.<br>(2) Change the I/O sizes for the DeviceNet device.   |
|                                       | No response from DeviceNet slave   | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the baud rate for each DeviceNet device in the network.<br>(3) Check the operation status of DeviceNet devices on the network. |  |
|                                       | DeviceNet device is idle   | Remove the cause of the idle status of the DeviceNet device.  |  |
| MS green lit<br>NS green lit          | Communications are occurring but the maximum communications cycle time exceeds the setting | Excessive traffic on DeviceNet. The communications cycle time setting is too low for the I/O command send time.   | Increase communications cycle time.  |
|                                       | Communications are occurring but the receive data refresh is delayed                       | Excessive traffic on DeviceNet. The communications cycle time setting is too low for the I/O response receive time. The processing load for data exchange with the slaves is too large.                               | (1) Increases communications cycle time for the DeviceNet slaves.<br>(2) Increase the baud rate.<br>(3) Increase the setting of the CPU scan time for the I/O allocation SYNC setting.   |

### Troubleshooting the Master

| Indicators                              | Problem  | Probable Cause  | Possible Solution   |
|---|--|---|---|
| MS green lit<br>NS green lit<br>(cont.) | MSG - SND function terminated due to error (during DeviceNet communications) | Parameter setting error   | (1) Verify the MSG - SND function parameter settings are correct.<br>•Data address<br>•Data size  |
| MS green lit<br>NS green flashing       |  | EM allocations not made   | (1) Set the EM allocation under “I/O Allocations.”  |
| MS green lit<br>NS red lit              |  | I/O communications error  | Remove the cause of the I/O error.  |
| MS green lit<br>NS green lit            | MSG - SND function remains BUSY and does not end                             | MSG - SND function parameter setting error                            | (1) Verify the MSG - SND function parameter settings are correct.<br>•Remote station #  |
|   |  | Excessive traffic on DeviceNet (Cannot send Explicit request message) | (1) Set longer communications cycle time.<br>(2) For multi-master configuration, increase the communications cycle time for the other master. |

## ■ Slave

### Troubleshooting Slaves

| Indicators                        | Problem                     | Probable Cause                                   | Possible Solution  |
|-----------------------------------|-----------------------------|--|--|
| MS not lit<br>NS lit              | No DeviceNet communications | No power supply to MP940D                        | Check the network power supply to the MP940D.  |
| MS red lit<br>NS not lit          |                             | Hardware malfunction                             | Replace the MP940D.  |
| MS red lit<br>NS red lit          |                             | Hardware malfunction                             | Replace the MP940D.  |
| MS green lit<br>NS red lit        |                             | Duplicate MAC ID                                 | (1) Change the MAC ID address for the MP940D and cycle the power<br>(2) Change the MAC ID addresses for other DeviceNet devices and cycle the power to the MP940D.   |
|                                   |                             | Bus-OFF  | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the power supply voltage and connections for communications power.<br>(3) Check for network power supply voltage on the DeviceNet connector of the MP940D (11 to 24V).<br>(4) Check the baud rate for each DeviceNet device on the network.<br>(5) Check the terminator (121Ω) and connection status.<br>(6) Check the length of the network.<br>(7) Replace the MP940D. Then, either cycle the power for the MP940D or disconnect and reinsert the DeviceNet connectors. |
| MS green lit<br>NS not lit        |                             | Communications power supply error                | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the power supply voltage and connections for network power.<br>(3) Check the communications power supply voltage on the DeviceNet connector of the MP940D (11 to 24V).<br>(4) Check the terminator (121Ω) and connection status.  |
| MS red lit<br>NS not lit          |                             | DeviceNet network error                          | (1) Check the wiring and connections for DeviceNet cables and connectors.<br>(2) Check the baud rate for each device.<br>(3) Check the terminator (121Ω) and connection status.<br>(4) Check the operation status of the DeviceNet master.<br>(5) Replace the MP940D.  |
| MS green lit<br>NS green flashing |                             | Connection not established with DeviceNet device | (1) Check the DeviceNet master scan list settings.<br>(2) Check the wiring and connections for DeviceNet cables and connectors.<br>(3) Check the baud rate for each device.<br>(4) Check the operation status of the DeviceNet master.   |

## ■ Slave

### Troubleshooting Slaves

| Indicators                                | Problem                             | Probable Cause   | Possible Solution  |
|---|-------------------------------------|--|--|
| MS green lit<br>NS green flashing (cont.) | No DeviceNet communications (cont.) | No response from DeviceNet master  | <ol style="list-style-type: none"> <li>(1) Check the wiring and connections for DeviceNet cables and connectors.</li> <li>(2) Check the baud rate for each device.</li> <li>(3) Check the terminator (121Ω) and connection status.</li> <li>(4) Check the operation status of the DeviceNet master.</li> <li>(5) Check the voltage and connection for network power supply.</li> <li>(6) Check the communications power supply voltage on the DeviceNet connector of the MP940D (11 to 24V).</li> </ol>              |
|   |                                     | DeviceNet I/O size different to setting  | <ol style="list-style-type: none"> <li>(1) Change the I/O sizes for the I/O allocations.</li> <li>(2) Change the I/O sizes for the DeviceNet device.</li> </ol>  |
| MS green lit<br>NS red flashing           |                                     | No response from DeviceNet master  | <ol style="list-style-type: none"> <li>(1) Check the wiring and connections for DeviceNet cables and connectors.</li> <li>(2) Check the baud rate for each device.</li> <li>(3) Check the terminator (121Ω) and connection status.</li> <li>(4) Check the operation status of the DeviceNet master.</li> <li>(5) Check the power supply voltage and connection for network power supply.</li> <li>(6) Check the communications power supply voltage on the DeviceNet connector of the MP940D (11 to 24V).</li> </ol> |
|   |                                     | DeviceNet I/O size different to setting  | <ol style="list-style-type: none"> <li>(1) Change the I/O sizes for the I/O allocations.</li> <li>(2) Change the I/O sizes for the DeviceNet device.</li> </ol>  |
| MS green lit<br>NS red flashing           |                                     | The MAC ID rotary switch setting is different than the MAC ID software setting | <ol style="list-style-type: none"> <li>(1) Change the MAC ID software setting.</li> <li>(2) Change the MAC ID rotary switch setting and cycle the power.</li> </ol>  |
| MS green lit<br>NS green lit              |                                     | The MAC ID rotary switch setting is different than the MAC ID software setting | <ol style="list-style-type: none"> <li>(1) Change the MAC ID software setting.</li> <li>(2) Change the MAC ID rotary switch setting and cycle the power.</li> </ol>  |

## ■ Slave


### Troubleshooting Slaves

| Indicators                   | Problem  | Probable Cause  | Possible Solution  |
|------------------------------|--|---|--|
| MS green lit<br>NS green lit | Communications are occurring but the receive data is not being refreshed | DeviceNet master is in idle status  | Remove the cause of the idle status of the DeviceNet master.   |
| MS green lit<br>NS green lit | Communications are occurring but the receive data refresh is delayed     | Excessive traffic on DeviceNet. The communications cycle time setting is too low for the I/O response receive time. The processing load for data exchange with the master is too large. | (1) Increase communications cycle time for the DeviceNet master.<br>(2) Increase the baud rate.<br>(3) Increase the CPU scan time for the I/O allocation SYNC setting. |

**NOTES:**

## Section 6: Digital I/O

The MP940 is equipped with eight digital inputs and eight digital outputs. There are two additional general purpose inputs available from the SGDH via dual port RAM.




*Figure 6.1: Digital I/O Connection*

## Digital I/O Specifications


### ■ Digital Input Specifications

| Item                   | Specification                            |
|------------------------|--|
| Number of Input Points | 8  |
| Input Format           | Sinking or Sourcing                      |
| Isolation              | Optical                                  |
| Voltage                | 24VDC $\pm$ 20%                          |
| Current Rating (ON)    | 5.3mA to activate                        |
| Input Impedance        | 4.4k $\Omega$                            |
| Operation Voltage      | Logic 0 < 5V<br>Logic 1 > 15V            |
| OFF Current            | 0.9mA or less                            |
| Response Time          | OFF to ON: < 0.5ms<br>ON to OFF: < 1.5ms |



## ■ Digital Output Specifications

| Item                    | Specification                           |
|-------------------------|---|
| Number of Output Points | 8                                       |
| Output Format           | Sinking                                 |
| Output Classification   | Transistor Output                       |
| Isolation               | Optical                                 |
| Load Voltage            | 24VDC $\pm$ 20%                         |
| Load Current            | 100mA / Output                          |
| ON Voltage              | 1.0V or less                            |
| Response Time           | OFF to ON < 0.25ms<br>ON to OFF < 0.5ms |
| External Common Power   | 24VDC $\pm$ 20% 15mA                    |
| Output Protection       | 1 internal fuse common to all outputs   |
| Fuse Rating             | 1.5A (Fusing Time: 5s or less at 3A)    |




A fuse is included on the common output line of the MP940 module as a protection circuit. However, there is a risk of the fuse not breaking due to an external short. Provide an external 100mA fuse on each output for added protection.

**NOTES:**

## Section 7: Limit Switch Inputs

The limit and home inputs are wired to the SGDH amplifier as shown in the figure below.



**Figure 7.1: SGDH I/O Specifications**

If your application does not require limit switches, they can be disabled. To disable the positive overtravel limit (P-OT), set the SGDH parameter Pn50A.digit3 to “8”.


To disable the negative overtravel limit (N-OT), set the SGDH parameter Pn50B.digit 0 to “8”.

Please read section 5.3.3 of the SGDH User’s Manual for further information.

## Section 8: Analog I/O


### Analog Input

The MP940 analog input comes from the SGDH analog input via dual port RAM. The analog input enters the SGDH on pin 5 of the CN1 connector. Normally, this is the VREF input, but when the MP940 and SGDH are combined, the VREF becomes available for general purpose.





**Figure 8.1: Analog Input Data**

| Item            | Specifications  |
|-----------------|---|
| Input Voltage   | ± 12V   |
| Input Impedance | Approximately 14k   |
| Resolution      | 16 bits over a ±15V range or 457µV/bit  |
| Accuracy        | The linearity of the analog input is guaranteed only within the range of ±12.0V |




## Analog Output

| Item                  | Content                                       |
|-----------------------|---|
| D/A Output Resolution | 16Bit over a +/-10V range, or 328 $\mu$ V/bit |




## Section 9: External Encoder



*Figure 9.1: The MP940 External Encoder*

## External Encoder Specifications


| Item              | Content   |
|-------------------|---|
| Input Format      | <ul style="list-style-type: none"> <li>• Quadrature</li> <li>• Pulse and Direction</li> <li>• 1 channel positive, 1 channel negative</li> </ul> |
| Maximum Frequency | 1MHz  |



## Section 10: Registration Latch

The registration latch is used to record (i.e., latch onto) the encoder position at the moment an external signal is input (rising edge).

|             |                                      |  |
|-------------|--------------------------------------|--|
| LATCH INPUT | Number of Latch Circuits             | 2  |
|             | Input Type                           | Current Source Photocoupler Isolation      |
|             | Main encoder latch input voltage     | 24VDC                                      |
|             | External encoder latch input voltage | Can be switched between 24VDC :12VDC :5VDC |




**Figure 10.1: Registration Latch**


## Main Encoder Registration Input

The registration latch for the SGDH is wired into the 1CN connector on the amplifier. Latch registration with this input is performed from the MP940 through dual port RAM.

Either the “C” channel or EXT3 can be used for the main encoder latch. If no latch is required by the application, EXT3 can be used for general purpose.



## External Encoder Registration Input



**NOTES:**

## Section 11: Maintenance

### Battery Life

The battery can preserve the program and data for a period of one year with power off. The battery has a life expectancy of five years under normal operating conditions. However, these values change depending on external conditions such as temperature.


Replace the battery within two weeks, when the “BAT” display LED is on. If the battery is replaced beyond two weeks, programs and data stored in the MP940 memory will be lost.

### Battery Replacement

Battery replacement is as follows.

#### ■Preparation


1. Save memory contents  
Before replacing the battery, save programs and data to a floppy disk or hard disk. The disk can be used if programs and data are accidentally erased due to a mistake when replacing the battery.
2. Replacement battery  
Use replacement battery type BA000518. This battery is not standard, and must therefore be purchased from Yaskawa. The replacement battery appears as in the diagram below.



*Figure 11.1: BA000518 Battery with Cable*

## ■ Prepare Replacement Battery

Prepare the replacement battery as in the drawing below.



*Figure 11.2: BA000518 (Battery with Cable)*

## ■ Battery Replacement

Replace the battery as follows:

1. Verify the controller power LED is ON. (The controller MUST have power when the battery is removed.)
2. Remove the connectors at the end of the battery leads from the MP940 module connector, and remove the battery from the internal battery holder.
3. Firmly insert the connector attached to the leads of the replacement battery into the MP940 module connector. Then insert the battery into the battery holder.
4. Verify the “BAT” LED is OFF.

Battery replacement is complete.

Always replace the battery with power ON. The programs and data stored in the MP940 module will be deleted if the battery is replaced with the power supply shut off from the MP940 module.

## Section 12: Specifications

### Physical Specifications

#### Physical Specifications of the MP940

|                                 | Item                      | Specification  |
|---------------------------------|---------------------------|--|
| Physical Environment            | Ambient Usage Temperature | 0 ~ +40°C (32° ~ 130°F)  |
|                                 | Storage Temperature       | -25 ~ +85°C (-10° ~ 185°F)   |
|                                 | Ambient Usage Humidity    | 30 ~ 95%RH (no condensation)   |
|                                 | Storage Humidity          | 5 ~ 95%RH (no condensation)  |
|                                 | Corrosion Resistance      | No flammable or corrosive gas  |
|                                 | Altitude                  | 2000m or less above sea level  |
| Electrical Operating Conditions | Noise Resistance          | Normal Mode: 1500Vp-p<br>Common Mode: 1500Vp-p<br>Pulse Width: 100ns/1μs<br>Pulse Rise Time: 1ns<br>(in noise simulator)   |
| Mechanical Operating Conditions | Vibration Resistance      | Vibration Amplitude/Acceleration:<br>10 ≤ f < 57Hz, Zero to Peak Amplitude: 0.075mm<br>57 ≤ f < 150Hz, Fixed Acceleration: 9.8m/s <sup>2</sup><br>X, Y, Z, directions: Sweeps (1 octave/min)<br>× Number of Sweeps: 10 |
|                                 | Shock Resistance          | Peak Acceleration: 147m/s <sup>2</sup> , Usage Time: 11ms<br>2 times in each direction (X, Y, and Z).  |
| Ground Conditions               | Grounding<br>Cooling Type | Type 3 Grounding<br>Natural Air Cooled   |
|                                 | External Dimensions       | W 45mm      H 142mm      D 129mm   |

## Hardware Specifications

### Hardware Specifications of MP940

| Item                | Specifications  |
|---------------------|---|
| Memory              | Flash: 2MB<br>RAM: 2MB (battery backed)   |
| Communication Ports | 1 RS-232C port<br>Baud Rate Setting: 9.6k/19.2 kbps<br>Protocol <ul style="list-style-type: none"> <li>• MEMOBUS</li> <li>• No Protocol</li> </ul>  |
|                     | 1 RS-422/485 port<br>Baud Rate Setting: 9.6k/19.2 kbps<br>Protocol <ul style="list-style-type: none"> <li>• MEMOBUS</li> <li>• No Protocol</li> </ul>   |
| Display LEDs        | Module Status Display LEDs<br>READY (green)<br>RUN (green)<br>ALM (red)<br>BATARM (red)<br>PRT1 (green)<br>PRT2 (green)   |
|                     | Mechatrolink Operation Display LEDs<br>RX (green)<br>TX (green)   |
| DIP Switches        | RUN<br>INIT<br>TEST<br>FLASH<br>PP<br>COPY  |
| Input Signals       | Input Points: 8<br>Input Format: Sinking or Sourcing<br>Isolation: Optical<br>Voltage: 24VDC ±20%<br>Rated Current: 5.3mA<br>Input Impedance: 4.4kΩ<br>Operating Voltage: ON Voltage 15VDC or more, OFF Voltage 5VDC or less<br>OFF Current: 0.9mA or less<br>Response Time: OFF→ON 0.25ms or less, ON→OFF 1ms or less  |
| Output Signals      | Output Points: 8<br>Output Format: Sinking output<br>Output Type: Transistor output<br>Isolation: Optical<br>Load Voltage: 24VDC±20%<br>Load Current: 100mA/output<br>ON Voltage: 1.0V or less<br>External Common Power Source: 24VDC ±20%, 15mA<br>Output Protection: 1 common fuse<br>Fuse Rating: 1.5A (fusing time: 5s or less at 3A)<br>Response Time: OFF→ON 0.25ms or less, ON→OFF 1ms or less |


**Hardware Specifications of MP940 (Continued)**

| Item                    | Specifications  |
|-------------------------|---|
| Latch Input             | Latch Input Circuit: 1MHz input maximum. Latches within 30 $\mu$ s.<br>Latch Input Format: quadrature; pulse and direction / channel up and channel down<br>Latch Counter: (external signal can be switched between 5V/12V/24V) |
| Analog Input            | SGDH velocity command used as analog input to controller  |
| Analog Output           | Resolution: 16-bit<br>Output Range: $\pm 10V$   |
| Controller Power Source | Input Signal: 24VDC $\pm 20\%$ (DC19.2V ~ 28.8V)<br>Input Current: 0.4A<br>Fuse Rating: 1.5A<br>Safety Certification: UL, CSA certified   |

**NOTES:**

## Section 13: Dimensional Drawings and Cable Diagrams

### Dimensions



**Figure 13.1: MP940 Dimensions**





Figure 13.2: MP940 YS15 Cable Drawing



**Figure 13.3: MP940 Cable**





Figure 13.4: I/O Cable Drawing

## Connections



*Figure 13.5: Connectors*

## Connector Specifications


| Name                   | Connector Name | # of Pins | Connector Model |   |              |
|------------------------|----------------|-----------|-----------------|---|--------------|
|                        |                |           | Controller Side | Cable Side  | Manufacturer |
| Battery Connector      | BAT            | 2         | DF3-2P-2DS      | Battery BA000518 Connector                          | HIROSE       |
| Serial Port RS-232C    | PORT1          | 14        | 10214-52A2JL    | Connector Unit 10114-3000VE<br>Shell 10314-52A0-008 | 3M           |
| Serial Port RS-422/485 | PORT2          | 14        | 10214-52A2JL    | Connector Unit 10114-3000VE<br>Shell 10314-52A0-008 | 3M           |
| Power Connector        | POWER          | 3         | SL3.5/3/90F     | BL3.5/3F-AU   | Weidmuller   |
| Mechatrolink Connector | MECHATROLINK   | 4         | DUSB-APA41-T11  | DUSB-   | —            |
| I/O Connector          | I/O            | 50        | 10250-52A2JL    | Connector Unit 10150-3000VE<br>Shell 10350-52A0-008 | 3M           |
| LED Connector          | LED            | 16        | IMSA-9220B-16A  | —   | —            |

## I/O Connector

| Number | Signal Name | Reference                   | Number | Signal Name | Reference                                 |
|--------|-------------|-----------------------------|--------|-------------|---|
| 1      | AO          | Analog Input                | 26     | AO_GND      | Analog Output Ground                      |
| 2      | —           | —                           | 27     | —           | —   |
| 3      | —           | —                           | 28     | —           | —   |
| 4      | PA+         | A_Pulse +                   | 29     | PB+         | B_Pulse +                                 |
| 5      | PA-         | A_Pulse -                   | 30     | PB-         | B_Pulse -                                 |
| 6      | GND         | Pulse Input Ground          | 31     | GND         | Pulse Input Ground                        |
| 7      | —           | —                           | 32     | —           | —   |
| 8      | —           | —                           | 33     | —           | —   |
| 9      | PILC 5V     | PI Latch Input Common (5V)  | 34     | PILC 12V    | PI Latch Input Common (12V)               |
| 10     | PILC 24V    | PI Latch Input Common (24V) | 35     | PIL         | PI Latch Input Common                     |
| 12     | —           | —                           | 36     | —           | —   |
| 12     | —           | —                           | 37     | —           | —   |
| 13     | DC 24V      | DI Power (input)            | 38     | DC 24V      | DI Power (input)                          |
| 14     | DI_00       | DI_00 Input (DI interrupt)  | 39     | DI_01       | DI_01 Input                               |
| 15     | DI_02       | DI_02 Input                 | 40     | DI_03       | DI_03 Input                               |
| 16     | DI_04       | DI_04 Input                 | 41     | DI_05       | DI_05 Input                               |
| 17     | DI_06       | DI_06 Input                 | 42     | DI_07       | DI_07 Input                               |
| 18     | —           | —                           | 43     | —           | —   |
| 19     | —           | —                           | 44     | —           | —   |
| 20     | DC 24V      | DO Power (input)            | 45     | DC 24V      | DO Power (input)                          |
| 21     | DO_00       | DO_00 Output                | 46     | DO_01       | DO_01 Output                              |
| 22     | DO_02       | DO_02 Output                | 47     | DO_03       | DO_03 Output                              |
| 23     | DO_04       | DO_04 Output                | 48     | DO_05       | DO_05 Output                              |
| 24     | DO_06       | DO_06 Output                | 49     | DO_07       | DO_07 Output (Counter coincidence output) |
| 25     | DO_GND      | DO Ground(0V)               | 50     | DO_GND      | DO Ground(0V)                             |


**Figure 13.6: I/O Connector**

### I/O Circuit of I/O Connector



Note: See Figure 3 for shield to connector shell termination details


## Mechatrolink Cables





*Figure 13.7: Mechatrolink Cable*

### Mechatrolink Cable


The internal cable connections between the MP940 and the I/O unit are shown below:



**External Views of Mechatrolink Cables**



**USB Terminator**



**YASKAWA ELECTRIC AMERICA, INC.**

2121 Norman Drive South, Waukegan, IL 60085, U.S.A.  
Phone: (847) 887-7000 Fax: (847) 887-7310 Internet: <http://www.yaskawa.com>

**MOTOMAN INC.**

805 Liberty Lane, West Carrollton, OH 45449, U.S.A.  
Phone: (937) 847-6200 Fax: (937) 847-6277 Internet: <http://www.motoman.com>

**YASKAWA ELETRICO DO BRASIL COMERCIO LTDA.**

Avenida Fagundes Filho, 620 Bairro Saude Sao Paulo-SP, Brasil CEP: 04304-000  
Phone: 55-11-5071-2552 Fax: 55-11-5581-8795 Internet: <http://www.yaskawa.com.br>

**YASKAWA ELECTRIC CORPORATION**

New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minatoku, Tokyo, 105-6891, Japan  
Phone: 81-3-5402-4511 Fax: 81-3-5402-4580 Internet: <http://www.yaskawa.co.jp>

**YASKAWA ELECTRIC (SHANGHAI) CO., LTD.**

4F No. 18 Aona Road, Waigaoqiao Free Trade Zone, Pudong New Area, Shanghai 200131, China  
Phone: 86-21-5866-3470 Fax: 86-21-5866-3869

**BEIJING OFFICE**

Room No. 301 Office Building of Beijing International Club,  
21 Jianguomanwai Avenue, Beijing 100020, China  
Phone: 86-10-6532-1850 Fax: 86-10-6532-1851

**SHANGHAI OFFICE**

27 Hui He Road Shanghai 200437 China  
Phone: 86-21-6553-6600 Fax: 86-21-6531-4242

**SHANGHAI YASKAWA-TONJI M & E CO., LTD.**

27 Hui He Road Shanghai 200437 China  
Phone: 86-21-6533-2828 Fax: 86-21-6553-6677

**BEIJING YASKAWA BEIKE AUTOMATION ENGINEERING CO., LTD.**

30 Xue Yuan Road, Haidian, Beijing 100083 P.R. China  
Phone: 86-10-6232-9943 Fax: 86-10-6234-5002

**SHOUGANG MOTOMAN ROBOT CO., LTD.**

7, Yongchang-North Street, Beijing Economic Technological Investment & Development Area,  
Beijing 100076 P.R. China  
Phone: 86-10-6788-0551 Fax: 86-10-6788-2878

**YASKAWA ELECTRIC (HK) COMPANY LIMITED**

Rm. 2909-10, Hong Kong Plaza, 186-191 Connaught Road West, Hong Kong  
Phone: 852-2803-2385 Fax: 852-2547-5773

**YASKAWA ELECTRIC KOREA CORPORATION**

Kfpa Bldg #1201, 35-4 Youido-dong, Yeongdungpo-Ku, Seoul 150-010, Korea  
Phone: 82-2-784-7844 Fax: 82-2-784-8495

**YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.**

151 Lorong Chuan, #04-01, New Tech Park Singapore 556741, Singapore  
Phone: 65-282-3003 Fax: 65-289-3003

**TAIPEI OFFICE (AND YATEC ENGINEERING CORPORATION)**

Shen Hsiang Tang Sung Chiang Building  
10F 146 Sung Chiang Road, Taipei, Taiwan  
Phone: 886-2-2563-0010 Fax: 886-2-2567-4677

**YASKAWA ELECTRIC TAIWAN CORPORATION**

Shen Hsiang Tang Sung Chiang Building  
10F 146 Sung Chiang Road, Taipei, Taiwan  
Phone: 886-2-2563-0010 Fax: 886-2-2567-4677

**YASKAWA ELECTRIC EUROPE GmbH**

Am Kronberger Hang 2, 65824 Schwalbach, Germany  
Phone: 49-6196-569-300 Fax: 49-6196-888-301 Internet: <http://www.yaskawa.de>

**MOTOMAN ROBOTEC GmbH**

Kammerfeldstrabe 1, 85391 Allershausen, Germany  
Phone: 49-8166-900 Fax: 49-8166-9039

**YASKAWA ELECTRIC UK LTD.**

1 Hunt Hill Orchardton Woods Cumbernauld, G68 9LF, United Kingdom  
Phone: 44-12-3673-5000 Fax: 44-12-3645-8182

**MOTOMAN ROBOTICS EUROPE AB**

Box 504 S38525, Torsas, Sweden  
Phone: 46-486-48800 Fax: 46-486-41410