



Speed / Torque Curves

200V



100V



A : CONTINUOUS DUTY ZONE

B : INTERMITTENT DUTY ZONE

*When combined with SGD4FE amplifier.