



* - INDICATES COMPONENTS NOT SUPPLIED BY YASKAWA.
 - - INDICATES CUSTOMER WIRING.
 SEE SHEET 2 FOR NOTES AND TABLES.

YASKAWA		DATE	1/29/14	TITLE	SCHEMATIC DIAGRAM
DESIGNED BY	P. STOCKUS	DATE	1/31/14	PROJECT	IQPUMP1000 CONFIGURED
CHECKED BY	D. TUMILSON	DATE	1/31/14	REVISED BY	
APPROVED BY	P. STOCKUS	DATE	1/31/14	SIZE	D
DRAWING #				REVISION	R01
				PAGE	1 of 2

REV.	DESCRIPTION	ECO #	DRAWN BY	DATE
01	CHANGED PM STYLE AND FAN SCHEMATIC	5448	NSL	8/11/14
00	INITIAL RELEASE	-	PS	1/31/14

REV.	DESCRIPTION	ECO #	DRAWN BY	DATE
01	CHANGED PM STYLE AND FAN SCHEMATIC	5448	NSL	8/11/14
00	INITIAL RELEASE	-	PS	1/31/14

TABLE 1 FACTORY SET IQPUMP1000 CONFIGURED DRIVE PARAMETERS

PARAMETER	DATA	UNIT	DESCRIPTION/REMARKS
b1-01	SEE TABLE 2	N/A	AUTO SET-POINT SELECTION
b1-02	SEE TABLE 2	N/A	RUN COMMAND SELECTION
E1-01	480	VOLTS	STANDARD INPUT VOLTAGE SETTING
E1-05	460	VOLTS	STANDARD MAXIMUM OUTPUT VOLTAGE SETTING
E2-01	---	AMPS	MOTOR FULL LOAD CURRENT (TO BE SET BY USER)
H1-03	25	N/A	TERMINAL S3 = EXTERNAL FAULT (NORMALLY CLOSED)
H1-05	SEE TABLE 2	N/A	TERMINAL S5 FUNCTION SELECTION
H1-07	24	N/A	TERMINAL S7 = EXTERNAL FAULT (NORMALLY OPEN)
H1-27	5.00	SEC	TERMINAL S7 EXTERNAL FAULT (EF7) DELAY TIME
H3-02	SEE TABLE 2	N/A	TERMINAL A1 FUNCTION SELECTION
H3-06	SEE TABLE 2	N/A	TERMINAL A3 FUNCTION SELECTION
H3-09	SEE TABLE 2	N/A	TERMINAL A2 FEEDBACK SIGNAL LEVEL SELECTION
o2-03	1	N/A	USER INITIALIZATION FACTORY SET PARAMETER DEFAULT VALUES (FOUND IN A1-03="1110")
o3-02	1	N/A	COPY ALLOWED SELECTION ENABLED
P1-02	1 *	N/A	SYSTEM UNITS (WHERE 1 = POUNDS PER SQUARE INCH (PSI))
P1-03	00145 *	SYSTEM UNITS	FEEDBACK DEVICE SCALING (TO BE SET BY USER)
P5-01	SEE TABLE 2	N/A	HAND MODE FREQUENCY REFERENCE SELECTION
P5-02	---	HZ	HAND MODE FREQUENCY REFERENCE (TO BE SET BY USER) - SEE TABLE 2
P5-04	SEE TABLE 2	N/A	DRIVE KEYPAD HAND KEY ENABLE/DISABLE
Q1-01	---	SYSTEM UNITS	AUTO MODE SET-POINT REFERENCE (TO BE SET BY USER)

* = FACTORY 2-WIRE INITIALIZATION/DEFAULT SETTING

NOTES:

- CONNECTED TO THE CABINET. CUSTOMER TO CONNECT THE CABINET GROUND LUGS TO EARTH GROUND AND UTILITY GROUND.
- THE CUSTOMER MUST USE TYPE 3R RATED HUBS OR FITTINGS (OR EQUIVALENT) TO MAINTAIN THE ENCLOSURE RATING.
- N/A
- N/A
- INSULATED TWISTED SHIELDED WIRE IS REQUIRED. 2 OR 3 CONDUCTOR #18GA. (BELDEN NO. 8760 OR 8770, OR EQUIVALENT). SHIELD TO CONNECT TO PROPER TERMINAL AS SHOWN. CONNECT THE SHIELD ONLY AT THIS END. STUB AND ISOLATE THE OTHER END. DO NOT RUN THESE WIRES IN THE SAME CONDUIT AS THE AC POWER AND AC CONTROL WIRES.
- CUSTOMER TO ADJUST THE THERMOSTAT ON THE SPACE HEATER HR1 FOR THE MINIMUM DESIRED TEMPERATURE INSIDE THE DRIVE CABINET. THIS SET TEMPERATURE IS NORMALLY SELECTED TO BE SLIGHTLY HIGHER THAN THE MINIMUM AMBIENT TEMPERATURE OF THE AIR SURROUNDING THE CABINET, AND IS THE TEMPERATURE AT WHICH THE SPACE HEATER HR1 WILL SHUT OFF.
- SERIAL COMMUNICATIONS OPTIONS T2, T3, T4, T5, T6, T7, T8, T9, T10, T11, T12, T13, T14, T15, T16, T17, T18, T19, T20, T21, T22, T23, T24, T25, T26, T27, T28, T29, T30, T31, T32, T33, T34, T35, T36, T37, T38, T39, T40, T41, T42, T43, T44, T45, T46, T47, T48, T49, T50, T51, T52, T53, T54, T55, T56, T57, T58, T59, T60, T61, T62, T63, T64, T65, T66, T67, T68, T69, T70, T71, T72, T73, T74, T75, T76, T77, T78, T79, T80, T81, T82, T83, T84, T85, T86, T87, T88, T89, T90, T91, T92, T93, T94, T95, T96, T97, T98, T99, T100, T101, T102, T103, T104, T105, T106, T107, T108, T109, T110, T111, T112, T113, T114, T115, T116, T117, T118, T119, T120, T121, T122, T123, T124, T125, T126, T127, T128, T129, T130, T131, T132, T133, T134, T135, T136, T137, T138, T139, T140, T141, T142, T143, T144, T145, T146, T147, T148, T149, T150, T151, T152, T153, T154, T155, T156, T157, T158, T159, T160, T161, T162, T163, T164, T165, T166, T167, T168, T169, T170, T171, T172, T173, T174, T175, T176, T177, T178, T179, T180, T181, T182, T183, T184, T185, T186, T187, T188, T189, T190, T191, T192, T193, T194, T195, T196, T197, T198, T199, T200, T201, T202, T203, T204, T205, T206, T207, T208, T209, T210, T211, T212, T213, T214, T215, T216, T217, T218, T219, T220, T221, T222, T223, T224, T225, T226, T227, T228, T229, T230, T231, T232, T233, T234, T235, T236, T237, T238, T239, T240, T241, T242, T243, T244, T245, T246, T247, T248, T249, T250, T251, T252, T253, T254, T255, T256, T257, T258, T259, T260, T261, T262, T263, T264, T265, T266, T267, T268, T269, T270, T271, T272, T273, T274, T275, T276, T277, T278, T279, T280, T281, T282, T283, T284, T285, T286, T287, T288, T289, T290, T291, T292, T293, T294, T295, T296, T297, T298, T299, T300, T301, T302, T303, T304, T305, T306, T307, T308, T309, T310, T311, T312, T313, T314, T315, T316, T317, T318, T319, T320, T321, T322, T323, T324, T325, T326, T327, T328, T329, T330, T331, T332, T333, T334, T335, T336, T337, T338, T339, T340, T341, T342, T343, T344, T345, T346, T347, T348, T349, T350, T351, T352, T353, T354, T355, T356, T357, T358, T359, T360, T361, T362, T363, T364, T365, T366, T367, T368, T369, T370, T371, T372, T373, T374, T375, T376, T377, T378, T379, T380, T381, T382, T383, T384, T385, T386, T387, T388, T389, T390, T391, T392, T393, T394, T395, T396, T397, T398, T399, T400, T401, T402, T403, T404, T405, T406, T407, T408, T409, T410, T411, T412, T413, T414, T415, T416, T417, T418, T419, T420, T421, T422, T423, T424, T425, T426, T427, T428, T429, T430, T431, T432, T433, T434, T435, T436, T437, T438, T439, T440, T441, T442, T443, T444, T445, T446, T447, T448, T449, T450, T451, T452, T453, T454, T455, T456, T457, T458, T459, T460, T461, T462, T463, T464, T465, T466, T467, T468, T469, T470, T471, T472, T473, T474, T475, T476, T477, T478, T479, T480, T481, T482, T483, T484, T485, T486, T487, T488, T489, T490, T491, T492, T493, T494, T495, T496, T497, T498, T499, T500, T501, T502, T503, T504, T505, T506, T507, T508, T509, T510, T511, T512, T513, T514, T515, T516, T517, T518, T519, T520, T521, T522, T523, T524, T525, T526, T527, T528, T529, T530, T531, T532, T533, T534, T535, T536, T537, T538, T539, T540, T541, T542, T543, T544, T545, T546, T547, T548, T549, T550, T551, T552, T553, T554, T555, T556, T557, T558, T559, T560, T561, T562, T563, T564, T565, T566, T567, T568, T569, T570, T571, T572, T573, T574, T575, T576, T577, T578, T579, T580, T581, T582, T583, T584, T585, T586, T587, T588, T589, T590, T591, T592, T593, T594, T595, T596, T597, T598, T599, T600, T601, T602, T603, T604, T605, T606, T607, T608, T609, T610, T611, T612, T613, T614, T615, T616, T617, T618, T619, T620, T621, T622, T623, T624, T625, T626, T627, T628, T629, T630, T631, T632, T633, T634, T635, T636, T637, T638, T639, T640, T641, T642, T643, T644, T645, T646, T647, T648, T649, T650, T651, T652, T653, T654, T655, T656, T657, T658, T659, T660, T661, T662, T663, T664, T665, T666, T667, T668, T669, T670, T671, T672, T673, T674, T675, T676, T677, T678, T679, T680, T681, T682, T683, T684, T685, T686, T687, T688, T689, T690, T691, T692, T693, T694, T695, T696, T697, T698, T699, T700, T701, T702, T703, T704, T705, T706, T707, T708, T709, T710, T711, T712, T713, T714, T715, T716, T717, T718, T719, T720, T721, T722, T723, T724, T725, T726, T727, T728, T729, T730, T731, T732, T733, T734, T735, T736, T737, T738, T739, T740, T741, T742, T743, T744, T745, T746, T747, T748, T749, T750, T751, T752, T753, T754, T755, T756, T757, T758, T759, T760, T761, T762, T763, T764, T765, T766, T767, T768, T769, T770, T771, T772, T773, T774, T775, T776, T777, T778, T779, T780, T781, T782, T783, T784, T785, T786, T787, T788, T789, T790, T791, T792, T793, T794, T795, T796, T797, T798, T799, T800, T801, T802, T803, T804, T805, T806, T807, T808, T809, T810, T811, T812, T813, T814, T815, T816, T817, T818, T819, T820, T821, T822, T823, T824, T825, T826, T827, T828, T829, T830, T831, T832, T833, T834, T835, T836, T837, T838, T839, T840, T841, T842, T843, T844, T845, T846, T847, T848, T849, T850, T851, T852, T853, T854, T855, T856, T857, T858, T859, T860, T861, T862, T863, T864, T865, T866, T867, T868, T869, T870, T871, T872, T873, T874, T875, T876, T877, T878, T879, T880, T881, T882, T883, T884, T885, T886, T887, T888, T889, T890, T891, T892, T893, T894, T895, T896, T897, T898, T899, T900, T901, T902, T903, T904, T905, T906, T907, T908, T909, T910, T911, T912, T913, T914, T915, T916, T917, T918, T919, T920, T921, T922, T923, T924, T925, T926, T927, T928, T929, T930, T931, T932, T933, T934, T935, T936, T937, T938, T939, T940, T941, T942, T943, T944, T945, T946, T947, T948, T949, T950, T951, T952, T953, T954, T955, T956, T957, T958, T959, T960, T961, T962, T963, T964, T965, T966, T967, T968, T969, T970, T971, T972, T973, T974, T975, T976, T977, T978, T979, T980, T981, T982, T983, T984, T985, T986, T987, T988, T989, T990, T991, T992, T993, T994, T995, T996, T997, T998, T999, T1000.
- WHEN OPTION TL IS ORDERED, A JUMPER IS REQUIRED FROM DRIVE TERMINALS (S1) TO (SN), SO THAT THE LONNWORKS SERIAL COMMUNICATIONS CAN BE USED TO CONTROL THE DRIVE. CUSTOMER TO REPLACE THE JUMPER WITH NORMALLY CLOSED SAFETY INTERLOCKS, IF APPLICABLE.

FIELD WIRING PRESSURE WIRE CONNECTOR WIRE TYPE RANGE AND TIGHTENING TORQUE SPECIFICATIONS

FOR 0 TO 100 AMPS, USE 60-75°C COPPER WIRE AND ABOVE 100 AMPS, USE 75°C COPPER WIRE.

CIRCUIT BREAKER (CB1)	WIRE SIZE RANGE (AWG)	TIGHTENING TORQUE (LB.-IN.)
AC MOTOR (A1-T1,T2,T3)	8 - 3/0	120
GROUND LUGS	CUSTOMER TO SUPPLY A UL LISTED CLOSED LOOP CONNECTOR PER AC DRIVE TECHNICAL MANUAL	120
NEUTRAL (1BNT)	14 - 2/0	120
CONTROL (1BT1)	6 - 2/0	120
	22 - 10	16 - 20

CONTROL OPTION PRESENT	FACTORY SET IQPUMP1000 CONFIGURED DRIVE PARAMETERS										AUTO MODE		HAND MODE				
	PARAMETER										SET-POINT	FEEDBACK	DRIVE KEYPAD IN THE "AUTO" MODE	DRIVE KEYPAD IN THE "HAND" MODE			
	b1-01	b1-02	H1-05	H3-02	H3-06	H3-09	P5-01	P5-04	DRIVE CONTROL BOARD SWITCH S1(A2)	DRIVE KEYPAD Q1-01					SERIAL COMM.	TERMINAL TBT1(4-6)	SIGNAL
NONE	0	0	80	0	20	2	1	1	1	1	YES	YES	0-10 VDC	YES	YES	DRIVE KEYPAD IN THE "AUTO" MODE	DRIVE KEYPAD IN THE "HAND" MODE
NONE	0	0	80	0	20	0	1	1	1	1	YES	YES	YES	YES	YES	DRIVE KEYPAD IN THE "AUTO" MODE AND AUTO MODE RUN/STOP CONTACT	DRIVE KEYPAD IN THE "HAND" MODE
NONE	0	1	80	0	20	2	1	1	1	1	YES	YES	YES	YES	YES	DRIVE KEYPAD IN THE "AUTO" MODE	DRIVE KEYPAD IN THE "HAND" MODE
NONE	0	1	80	0	20	0	1	1	1	1	YES	YES	YES	YES	YES	DRIVE KEYPAD IN THE "AUTO" MODE	DRIVE KEYPAD IN THE "HAND" MODE

* = FACTORY 2-WIRE INITIALIZATION/DEFAULT SETTING



YASKAWA

THIS DOCUMENT AND INFORMATION CONTAINED HEREIN ARE CONFIDENTIAL AND SHOULD NOT BE COPIED OR DISCLOSED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF YASKAWA AMERICA, INC.

DESIGNED BY	P. STOCKUS	DATE	1/29/14	TITLE	SCHEMATIC DIAGRAM
CHECKED BY	D. TUMILSON	DATE	1/31/14	PROJECT	IQPUMP1000 CONFIGURED
APPROVED BY	P. STOCKUS	DATE	1/31/14	SIZE	D
REVISION				REVISED BY	R01
				DATE	1/31/14
				PAGE	2 of 2

DRAWING # Q1C3J096-11