

Table 3-1. Digital Operator Controls

A. INDICATOR LAMPS	
NAME	FUNCTION
DRIVE	Lights when the GPD 503 is in the Drive mode of operation.
FWD	Lights when Forward motor run has been selected.
REV	Lights when Reverse motor run has been selected.
REMOTE SEQ	Lights when the GPD 503 is programmed to operate from external RUN and STOP signals.
REMOTE REF	Lights when the GPD 503 is programmed to operate by an external frequency reference signal.
RUN	Off when GPD 503 is in stopped condition; lights steadily when Run signal is active; blinks after Stop signal has been received and GPD 503 output is ramping down. (See Figure 3-2.)
STOP	Lights steadily at initial power-up; blinks after Run signal becomes active but frequency reference is zero; off when GPD 503 output is controlling motor speed. (See Figure 3-2.)