



NOTES:
 1. CUSTOMER TO CONNECT THE CABINET GROUND LUG TO EARTH GROUND.
 2. WITHOUT THE INPUT CIRCUIT BREAKER OPTION PC OR PM, BRANCH CIRCUIT PROTECTION MUST BE SUPPLIED BY THE INSTALLER.
 3. FOR 208VAC APPLICATIONS SET PARAMETERS E1-01 AND E1-05 TO 208.

* - INDICATES COMPONENTS NOT SUPPLIED BY YASKAWA.
 - - INDICATES CUSTOMER WIRING.
 SEE DRAWING UDE00362 FOR CUSTOMER CONNECTION TABLES.

REVISIONS				DATE	DRAWING #
REV.	DESCRIPTION	ECO #	DRAWN BY		
05	ADDED UDE00362 DRAWING NOTE	7462	KM	10/28/16	
04	DELETED REFERENCE TO D343,D396; B361-B590	4266	DRC	6/12/13	

YASKAWA		DATE: 6/21/12	TITLE: SCHEMATIC DIAGRAM Z1000 CONFIGURED
DRAWN BY: K. MALUSIC	CHECKED: K. FLIERL	DATE: 6/21/12	DATE: 6/21/12
APPROVED: K. FLIERL	ORIGINAL DESIGN: K. FLIERL	DATE: 6/21/12	DATE: 4/30/12
SIZE: D	REVISION: 05	PAGE: 1 of 1	
DS.Z1C1.01			