

USB Driver Installation

[Top](#) [Previous](#) [Next](#)

Follow these steps to install the COSMOS Series USB driver.

Note: These steps can also be used to install the Y-Stick (JVOP-181) driver.

Step 1: Start your computer

Step 2: Connect drive to computer with USB cable


Step 3: Power-up drive

Step 4: Wait until Windows reports that it is not able to find the driver.


Step 5: Click Windows Start button and right mouse click on "Computer", select properties.

Step 6: Click on Device Manager and the device manager window opens.


Next select the **COSMOS Series Inverter**, right mouse click and select Update Driver Software.




Step 7: Click on Browse my Computer for Driver Software




Step 8: Select DriveWizard Installation folder and click next.




Step 9: Click Install button to install the driver.




Step 10: Driver is now installed





Important Note: Follow these step A through E in case the driver did not install properly or Windows automatically selected another driver.

Step A: Right mouse click on the COSMOS Series Inverter or AC Drive USB Device and select Uninstall.



Step B: Next click Ok in the dialog box.



Step D: Unplug the USB cable from your computer and wait 10 sec then plug the USB cable back in.

Step E: Repeat steps 1 though 9 above to install the driver.