

Type CPCR-MR 052K

1. GENERAL DESCRIPTION

Servopack type CPCR-MR[]]K is designed as servo unit controller for our CNC YASNAC LX 1/2 and MX1/2 series Servopack can control a wide variety of speed range for servomotor feed drives (Cup Motor, Minertia Motor or Hi-Cup Motor)

Servopack with a transistorized PWM control offers a highly responsive servo system with superior stability In addition, low-noise servo drives and low-heat generation are two of Servopack's main features

This manual is used as a selection guide to determine a servo system for the CNC YASNAC LX1, MX1, LX2 and MX2

CONTENTS


2RATINGS AND SPECIFICATIONS	1 GENERAL DESCRIPTION · · ·	1	7 CONNECTION DIAGRAM · · · · · · · · · · · · 7
3 COMBINATION OF SERVOPACK WITH SERVOMOTOR AND REACTOR 3 8 CHARACTERISTICS OF SERVOPACK AND SERVOMOTOR COMBINATION 4 CHARACTERISTICS IN COMBINATION OF SERVOPACK WITH SERVOMOTOR 3 8 CHARACTERISTICS OF SERVOPACK AND SERVOMOTOR COMBINATION	2 RATINGS AND SPECIFICATIONS · ···	· 2	
4 CHARACTERISTICS IN COMBINATION OF SERVOPACK WITH SERVOMOTOR 8 1 Characteristics Description 12 5 INTERNAL BLOCK DIAGRAMS 3 8 2 Torque-Speed Characteristics 12 5 INTERNAL BLOCK DIAGRAMS 4 9 APPLICATION TECHNIC OF YASNAC 12 5 INPUT/OUTPUT SIGNALS 5 9 1 Servomoter Selection 15 6 INPUT/OUTPUT SIGNALS 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 1 List of Input/Output Signals 6 APPENDIX SELECTION LIST OF DC SERVOMOTOR 20 6 2 Description of Input/Output Signals 6 APPENDIX SELECTION LIST OF DC SERVOMOTOR 20		3	8 CHARACTERISTICS OF SERVOPACK AND
5 INTERNAL BLOCK DIAGRAMS 4 9 APPLICATION TECHNIC OF YASNAC 15 5 1 Servopack 4 9 APPLICATION TECHNIC OF YASNAC 15 5 2 Power Supply Unit 9 I Servomoter Selection 15 6 INPUT/OUTPUT SIGNALS 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 1 List of Input/Output Signals 6 APPENDIX SELECTION LIST OF DC SERVOMOTOR 20 6 2 Description of Input/Output Signals 6 APPENDIX SELECTION LIST OF DC SERVOMOTOR 20		3	8 1 Characteristics Description
6 INPUT/OUTPUT SIGNALS 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 1 List of Input/Output Signals 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 2 Description of Input/Output Signals 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 PENDIX SELECTION LIST OF DC SERVOMOTOR 6 9 3 Minimum Dog Length for Returning to Home Position 18 6 PENDIX SELECTION LIST OF DC SERVOMOTOR 6 9 3 Minimum Dog Length for Returning to Home Position 18	5 1 Servopack	•4	9 APPLICATION TECHNIC OF YASNAC
	6 1 List of Input/Output Signals · ·	6 6	9 3 Minimum Dog Length for Returning to Home Position 18 APPENDIX SELECTION LIST OF DC SERVOMOTOR

2. RATINGS AND SPECIFICATIONS

Item	Type CPCR-	MR05⊞K	MR073K	MR08[]K	MR15⊡K	MR22[]K	MR37[]K				
	ircuit DC Voltage	270 V (Supplied from power supply unit)									
Control	Power Supply		200/220 V	AC 50/60 Hz (Supp	blied from power su	upply unit)					
Ambien	t Temperature		·····	0 to +60°C (Fi	n: 0 to +45°C)						
Storage	• Temperature			-20°C te	o +85°C						
Storage	Humidity			90% o	r below						
Vibratio	on, Shock	· · · · · · · · · · · · · · · · · · ·	Vil	bration. 05G or les	ss, Shock 2G or le	ess					
Control	Method			Transistorized	/PWM control		· · · ·				
Maximum Acceleration/Deceleration Current		±25A (MR054K ±16A)	±30A	±25A (MR084K ±19A)	±40A (MR154K2 ±25A) (MR154K ±32A)	±40A	±60A				
Continu	ious Output Current	±9A	±14A	±8A	±13A	±18A	±24A				
Continu	ious Output Voltage			±2	00V						
	Reference Input Adjustable Range	Rated speed at 4 to 50 V									
	Differential Input Adjustable Range	Rated speed at 4 to 10V									
	External Current Limit	Maximum acceleration/deceleration current at +10 V									
Func-	Servo ON/OFF	Servo ON at LOW level (with pull-up resistor)									
tion	Dynamic Brake	·····	Operate	ed at alarm, Servo	OFF or control pov	ver OFF					
	TG ON/OFF		TG detec	ting level Rated s	peed or less (open	collector)	<u> </u>				
	Overload Detection			Not operated at 12	5%, 150 sec at 150	%, 50 sec at 200)%				
	Speed, Current Detection	Current at 2 V/100%, Speed at 3 6 V/1000 rpm, maximum output current \pm 10 mA									
	Device			Use c	of fuse						
Protec-	TG Trouble		Shortcircuit,	open, wrong, conn	ection, overspeed (1	20% to 140%)					
tion	Overcurrent		V_{CE} detection ($V_{CE} \ge 7 V$)								
	Overvoltage			Protected at	400 to 420 V						
Indica- tion	LED		 Power ON <u>POWER</u> (green) Input ON <u>IN</u>, TG ON <u>TG</u> (white) TG trouble, overcurrent, overvoltage, overload, blown fuse (red) 								

Table 1 Ratings and Specifications of Servopack

TYPE DESIGNATION



3. COMBINATION OF SERVOPACK WITH SERVOMOTOR AND REACTOR

Servopack Type CPCR-	Applicable Servomotor Type	Reactor (Separately Installed)	Servopack Type CPCR-	Applicable Servomotor Type	Reactor (Separately Installed)
MR052K	UGCMED-04	10mH, 14A (Dwg No DE 8402698)	MR154K2	UGJMED-60LA	5mH,11A(Dwg No DE8402744)
MR053K	UGMMEM-13	10mH,14A(Dwg No DE8402698)	MR155K1	UGHMED-12AA	10mH,14A(Dwg No DE8402698)
MR054K	UGJMED-40L	10mH, 14A (Dwg No DE8402698)	MR155K2	UGHMED-12GG	10mH,14A(Dwg No DE8402698)
MR055K	UGHMED-03GG	10mH,14A(Dwg No DE8402698)	MR222K	UGCMED-22	10mH,18A(Dwg No DE8403030)
MR073K	UGMMEM-25	10mH, 14A (Dwg No DE8402698)	MR224K	UGJMED-80LA	5mH,25A(Dwg No DE8402745)
MR082K	UGCMED-08	10mH,14A(Dwg No DE8402698)	MR225K1	UGHMED-20AA	10mH,18A(Dwg No DE8403030)
MR084K	UGJMED-60MA	5mH,11A(Dwg No DE8402744)	MR225K2	UGHMED-20GG	10 mH ,18A (Dwg. No DE 8403030)
MR085K1	UGHMED-06AA	10mH, 14A (Dwg No DE8402698)	MR372K	UGCMED-37	10mH,25A(Dwg No DE8402699)
MR085K2	UGHMED-06GG	10mH,14A(Dwg No DE8402698)	MR373K	UGMMED-1A	10 mH ,25A (Dwg. No DE 8402699)
MR152K	UGCMED-15	10mH,14A(Dwg No DE8402698)	MR374K	UGJMED-80KA	10mH,25A or 28A(Dwg No DE8401695)
MR153K	UGMMEM-50	10mH, 14A (Dwg No. DE 8402698)	MR375K1	UGHMED-30AA	10mH, 25A(Dwg No DE8402699)
MR154K	UGJMED-80MA	5mH,11A(Dwg No DE8402744)	MR375K2	UGHMED-30GG	10mH, 25A (Dwg No DE 8402699)

4. CHARACTERISTICS IN COMBINATION OF SERVOPACK WITH SERVOMOTOR

Table 3	Characteristics in	Combination of	Servopack	with Servomotor
---------	--------------------	----------------	-----------	-----------------

		Servopack	At	Rated Opera	ation	At Overspeed			Applicable
Servopack Type CPCR-	Servomotor Type	Maximum Current (A)	Rated Speed (rpm)	Continuous Effective Torque (kg cm)	Instantaneous Effective Torque (kg⋅cm)	Overspeed (rpm)	Continuous Effective Torque (kg cm)	Instantaneous Effective Torque (kg cm)	Load GD ² /4 (kg cm ²)
MR052K	UGCMED-04	25	1750	21.2	70 5	2400	18	70	22 4
MR053K	UGMMEM-13	25	3000	124	43 2	—	_		1 41
MR054K	UGJMED-40L	16	1000	23 2	78 4	1500	17	37	20 0
MR055K	UGHMED-03GG	25	1000	22 8	798	1500	22 8	79	20 3
MR073K	UGMMEM-25	30	3000	23 8	56 1		_		2 83
MR082K	UGCMEM-08	25	1750	396	161 5	2400	33	160	36 0
MR084K	UGJMED-60MA	19	1000	41 8	161 7	1500	27	105	44 0
MR085K1	UGHMED-06AA	25	1000	55 5	239 9	1500	48	223	73 3
MR085K2	UGHMED-06GG	25	1000	47 5	194 0	1500	38	195	33 0
MR152K	UGCMED-15	40	1750	79.3	303 2	2400	62	300	101
MR153K	UGMMEM-50	40	3000	47 5	162 6	-	_		9 00
MR154K	UGJMED-80MA	32	1000	101 7	3192	1200	104	237	140
MR154K2	UGJMED-60LA	25	1000	78 9	2104	1500	59	175	63 0
MR155K1	UGHMED-12AA	40	1000	111 2	444 6	1400	84	437	134
MR155K2	UGHMED-12GG	40	1000	111 2	444.6	1400	90	329	134
MR222K	UGCMED-22	40	1750	1169	295.3	2300	85	295	152
MR224K	UGJMED-80LA	40	1000	166.3	383 8	1500	110	290	245
MR225K1	UGHMED-20AA	40	1000	185 3	475 0	1400	188	463	292
MR225K2	UGHMED-20GG	40	1000	166 3	437¦0	1500	130	437	234
MR372K	UGCMED-37	60	1750	1957	465 7	2200	136	465	298
MR373K	UGMMEM-1 A	60	3000	95 0	236 5	—	_		25 2
MR 374 K	UGJMED-80 KA	43	1000	242.3	535 1	1300	185	345	335
MR375K1	UGHMED-30AA	60	1000	277.4	752 4	1200	188	752	494
MR375K2	UGHMED-30 GG	60	1000	266 0	786 6	1200	175	786	365

5. INTERNAL BLOCK DIAGRAMS

5.1 Servopack





Fig 1 Internal Block Diagram of Servopack





6. INPUT/OUTPUT SIGNALS

6.1 List of Input/Output Signals

Table 4 List of Input/Output Signals

Termin	al Syn	nbol	Signal Name	Description			
	P, N		Main Circuit Power Supply Input	270 to 310VDC (Supplied from the power supply unit)			
	r	, t	Control Power Supply Input	200/220 VAC, 50/60 Hz (Supplied from the power supply unit)			
Maın Circuit	Lı,	Le	DC Reactor Connection	Connected to the separately installed DC reactor			
Termi- nals	A	B	Motor Connection	A Connected to motor terminal A B Connected to motor terminal B			
	e, f		Thermoguard Connection	Connected to terminals B1 and B2 of Minertia Motor J series with a thermoguard			
		1-1	SERVO ON	See Table 5			
		1-3	OVERLOAD	See Table 6			
		1-4	SERVO READY	See Table 6			
		1-5 1-11	TG ON	See Table 6			
Control		1-6		Connected to TG terminal (-)			
Circuit Connec-	1CN	1-12	TG (FB)	Connected to TG terminal (+)			
tors		1-7	Speed Reference	Speed reference input 4 to 50 V			
		1-9	FUSE OFF	See Table 6			
		1-10	SERVO ALARM	See Table 6			
		1-13	SG 0V	SG 0V Signal grounding			
		1-20	Grounding				

6.2 Description of Input/Output Signals

• Input Signals (Input through open-collector)

Table 5 Input Signals

Signal Name	Functions						
SERVO ON	At LOW the controller is ready to operate Make a sequence so that SERVO ON signal is turned on after power is applied to the controller and main circuit, adjusting SERVO ON signal to HIGH turns off control power and main circuit power						
	CONTROL POWER						
	MAIN CIRCUIT POWER SUPPLY (P, N)						

• Output Signals (Output through open-collector Isink= 10 mA max)

Table 6 Output Signals

Signal Name	Functions
TG ON	TG ON signal turns LOW when motor speed ex- ceeds 1/10 of the rated speed
SERVO ALARM	TG lights up when TG failure (disconnection, shortcircuit, reverse connection) or motor overspeed is detected OC lights up when overcurrent is detected OV lights up when overvoltage is detected
SERVO READY	Applying power to main circuit without genera- tion of SERVO ALARM signal makes SERVO ALARM output LOW
OVERLOAD	OVERLOAD output signal turns HIGH when mo- tor overload (internal thermal relay circuit or thermostat) is detected
FUSE OFF	Blowing fuses in the Servopack unit turns FUSE OFF signal LOW

6.3 List of Terminal and Connector

• Terminal (Type LC-01-30)

Р	N	Lı	L2	A	в	r	t	е	f


Fig	3	Terminal	List
i ig	0	i ci minai	LISL

Connector (Type MR-20 RMA)

1	2	3	4	5	6	7	8	9	10
SERVO ON		OVERLOAD	SERVO READY	TG ON	TG ()	SPEED REFERENCE		FUSE OFF	SERVO ALARM
11	12	13	14	15	16	17	18	19	20
TG ON	TG (+)	SG OV		·	0 c	0 c	0 c	0 c	GROUND


7. CONNECTION DIAGRAM

7.1 Connection for YASNAC LX1/LX2



Note

- 1. Where supplying 230 VAC, connect a control power supply across terminals (23) ((23)) and (1) ((7)) of a power unit
- 2 For a Servomotor (Minertia motor J series) with built-in thermostat, connect the thermostat leads to the external terminals (and () of Servopack See figure surrounded by solid line at right. If a Servomotor without thermostat will be used, short-circuit across the terminals (and ()




Connection of Minertia Motor J Series and Servopack

Fig 5 Connection for YASNAC LX1/LX2

7.1 Connection for YASNAC LX1/LX2 (Cont'd)

• Wiring of Servopack and YASNAC LX1/LX2







Fig 6 Wiring of Servopack and YASNAC LX1/LX2

YASNAC		'LX 2		X-AXIS	
POWER INPUT TYPE CP(SERVO UNIT	
<u> </u>		SVONK		1-1	
E-	4	SRDX	1	1 - 4	
E-	- 19	0 C		1 - 19	
<u> </u>	9	FUX		1-9	
<u> </u>	17	0 C	1	1 - 17	
<u> </u>	3	OLX*	1	1-3	
E-	16	0 C		1 - 16	
<u> </u>	- 10	ALX*		1 - 10	
E-	18	0 C		1 - 18	
E	-5	TGONK		1 - 5	
E-	-11	0 C	1	1 - 11	
E-	- 12	ATX		1 - 12	
E -	-6	BTX	Р	1-6	
E-	.7	DAX	1	1 - 7	
E	- 13	SGX	Р	1 - 13	
		٦		Z-AXIS	
				SERVO UNIT	
		SVONZ		1-1	
F-		SRDZ		1-4	
	- 19	0C	1	1 - 19	
F-	-9	FUZ		1 - 9	
F-	· 17	0 C		1 - 17	
F-	- 3	<u> </u>		1 - 3	
F-	- 16	0 C		1 - 16	
F	- 10	ALZ*		1 - 10	
F	- 18	0 C		1 - 18	
F-	- 5	TGONZ		1 - 5	
F	- 11	0 C		1 - 11	
F-	- 12	ATX		1 - 12	
F	-6	BTX	Р	1-6	
F	-7	DAX		1 - 7	
F	- 13	SGX	Р	1 - 13	


* Normally closed contact

Fig 7 Detail of Wiring



Note

- 1 Where supplying 230 VAC, connect a control power supply across terminals (23) ((23)) and (1) (7) of a power unit
- 2 For a Servomotor (Minertia motor J series) with built-in thermostat, connect the thermostat leads to the external terminals (a) and (1) of Servopack See figure surrounded by solid line at right If a Servomotor without thermostat will be used, short-circuit across the terminals (a) and (1).



Connection of Minertia Motor J Series and Servopack

Fig 8 Connection for YASNAC MX1/MX2

7.2 Connection for YASNAC MX1/MX2 (Cont'd)

• Wiring of Servopack and YASNAC MX1/MX2




Fig 9 Wiring of Servopack and YASNAC MX1/MX2

Detail of Wiring

ASNAC MX 1/M	IX 2	Servopack	YASNAC MX 1/M	X 2	Servopack
YPE CP02		X-AXIS	POWER INPUT UNIT TYPE CP02		Z-AXIS
E - 12	ATX	1 CN-12	H-12	ATZ	1 CN-12
E-6	BTX P	1 CN-6	H-6	BTZ P	1 CN-6
E-7	DAX	1 CN-7	H-7	DAZ	1 CN-7
E-13	SGX P	1 CN-13	H-13	SGZ IP	1 CN-13
E-1	SVONX*	1 CN-1	H-1	SVONZ* I	1 CN-1
E-5	TGONX*	1 CN-5	H-5	TGONZ*	1 CN-5
E-11	0C	1 CN-11	H-11	0C	1 CN-11
<u> </u>	SRDX	1 CN-4	H-4	SRDZ	1 CN-4
E-19	0C	1 CN-19	H-19	0C	1 CN-19
E-9	FUX	1 CN-9	H-9	FUZ	1 CN-9
E-17	0C	1 CN-17	H∽17	0C 1	1 CN-17
E-3	OLX*	1 CN-3	H-3	OLZ*	1 CN-3
E-16	0C	1 CN-16	H-16	0C	1 CN-16
E - 10	ALX*	1 CN-10	H-10	ALZ*	1°CN-10
E-18	0C	1 CN-18	H-18	0C	1 CN-18
E-20	EPX		H-20	EPZ	1 CIV-10
		CPCR-MR[]K		X o	L
		Servopack	YASNAC MX I/M. POWER INPUT UNIT	X 2	CPCR-MR Servopack
		Servopack Y-AXIS	YASNAC MX 1/M POWER INPUT UNIT TYPE SR (1/02	X 2	L
F-12	ATY	Servopack Y-AXIS 1 CN-12	POWER INPUT UNIT	X2	Servopack
F-6	BTY P	Servopack Y-AXIS 1 CN-12 1 CN-6	POWER INPUT UNIT TYPE SR(1/02	-	Servopack 4 - AXIS
F-6 F-7	BTY P DAY	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7	POWER INPUT UNIT TYPE SRC1/02 E-12	AT4	Servopack 4 - AXIS 1 CN-12
F-6 F-7 F-13	BTY P DAY SGY P	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6	AT4	Servopack 4 - AXIS 1 CN-12 1 CN-6
F-6 F-7 F-13 F-1	BTY P DAY SGY P SVONY*	Servopack Y-AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1	POWER INPUT UNIT TYPE SR(1/02 E-12 $E-6$ $E-7$	AT4 BT4 P DA4 SG4 P SVON4*	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7
F-6 F-7 F-13 F-1 F-5	BTY P DAY SGY P SVONY* TGONY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-5	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13	AT4 BT4 P DA4 SG4 P	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13
F-6 F-7 F-13 F-1 F-5 F-11	BTY P DAY SGY P SVONY* TGONY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-1 1 CN-1 1 CN-1	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1	AT4 BT4 P DA4 SG4 P SVON4*	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-4 F-4 F-4 F-6 F-10 F-6 F-10 F-7 F-7	BTY P DAY SGY P SVONY* TGONY* 0C SRDY	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-1 1 CN-5 1 CN-11 1 CN-4	POWER INPUT UNIT TYPE SRC1/02 E-12 E-6 E-7 E-13 E-1 E-1 E-5	AT4 BT4 P DA4 SG4 P SVON4* TGON4*	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-5
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-11 1 CN-11 1 CN-19	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-1 E-5 E-11	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0 C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-5 1 CN-11
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-9 F-9	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-1 1 CN-5 1 CN-11 1 CN-4	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-1 E-5 E-11 E-4	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0C SRD4	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-17 F-17	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0C SRD4 0C FU4 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-17 F-3 F-3 F-3 F-3 F-3 F-4 F-19 F-1 F-3 F-3 F-3 F-3 F-3 F-3 F-3 F-3 F-4 F-	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-1 1 CN-1 1 CN-1 1 CN-1 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-1 E-5 E-11 E-4 E-19 E-9	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0C SRD4 0C FU4	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-17 F-17	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-9 E-17	AT4 BT4 P DA4 SG4 P SV0N4* TG0N4* 0C SRD4 0C FU4 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-7 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-17 F-3 F-3 F-3 F-3 F-3 F-4 F-19 F-3 F-4 F-	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-1 1 CN-19 1 CN-19 1 CN-17 1 CN-3	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-2 E-17 E-3	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0C SRD4 0C FU4 0C OL4*	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-17 1 CN-3
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-17 F-3 F-16 F-16 F-16 F-16 F-1	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-13 1 CN-11 1 CN-5 1 CN-11 1 CN-19 1 CN-19 1 CN-17 1 CN-3 1 CN-16	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-2 E-17 E-3 E-16	AT4 BT4 P DA4 SG4 P SV0N4* TG0N4* 0C SRD4 0C FU4 0C OL4* 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-17 1 CN-3 1 CN-16
F-6 F-7 F-13 F-1 F-5 F-11 F-4 F-19 F-9 F-7 F-3 F-16 F-10 F-1	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-7 1 CN-17 1 CN-3 1 CN-16 1 CN-10	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-2 E-17 E-3 E-16 E-10	AT4 BT4 P DA4 SG4 P SVON4* TGON4* 0C SRD4 0C FU4 0C OL4* 0C OL4* 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17 1 CN-3 1 CN-16 1 CN-10
F-6 $F-7$ $F-13$ $F-1$ $F-5$ $F-11$ $F-4$ $F-19$ $F-9$ $F-9$ $F-17$ $F-3$ $F-16$ $F-10$ $F-18$	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-7 1 CN-17 1 CN-3 1 CN-16 1 CN-10	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-9 E-17 E-3 E-16 E-10 E-18	AT4 BT4 P DA4 SG4 P SV0N4* TGON4* 0C SRD4 0C FU4 0C OL4* 0C OL4* 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17 1 CN-3 1 CN-16 1 CN-10
F-6 $F-7$ $F-13$ $F-1$ $F-5$ $F-11$ $F-4$ $F-19$ $F-9$ $F-9$ $F-17$ $F-3$ $F-16$ $F-10$ $F-18$	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-7 1 CN-17 1 CN-3 1 CN-16 1 CN-10	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-9 E-17 E-3 E-16 E-10 E-18	AT4 BT4 P DA4 SG4 P SV0N4* TGON4* 0C SRD4 0C FU4 0C OL4* 0C OL4* 0C	4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17 1 CN-3 1 CN-16 1 CN-10
F-6 $F-7$ $F-13$ $F-1$ $F-5$ $F-11$ $F-4$ $F-19$ $F-9$ $F-9$ $F-17$ $F-3$ $F-16$ $F-10$ $F-18$	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-7 1 CN-17 1 CN-3 1 CN-16 1 CN-10	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-9 E-17 E-3 E-16 E-10 E-18	AT4 BT4 P DA4 SG4 P SV0N4* TGON4* 0C SRD4 0C FU4 0C OL4* 0C OL4* 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-17 1 CN-3 1 CN-16 1 CN-10
F-6 $F-7$ $F-13$ $F-1$ $F-5$ $F-11$ $F-4$ $F-19$ $F-9$ $F-9$ $F-17$ $F-3$ $F-16$ $F-10$ $F-18$	BTY P DAY SGY P SVONY* TGONY* 0C SRDY 0C FUY 0C OLY* 0C ALY*	Servopack Y - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-7 1 CN-17 1 CN-3 1 CN-16 1 CN-10	POWER INPUT UNIT TYPE SR(1/02 E-12 E-6 E-7 E-13 E-1 E-5 E-11 E-4 E-19 E-9 E-17 E-3 E-16 E-10 E-18	AT4 BT4 P DA4 SG4 P SV0N4* TGON4* 0C SRD4 0C FU4 0C OL4* 0C OL4* 0C	Servopack 4 - AXIS 1 CN-12 1 CN-6 1 CN-7 1 CN-13 1 CN-13 1 CN-1 1 CN-5 1 CN-11 1 CN-4 1 CN-19 1 CN-9 1 CN-9 1 CN-17 1 CN-3 1 CN-16 1 CN-10

	AC MX 1/A	AX 2		Servopack
TYPE S	INPUT UNIT R 01/02			5-AXIS
	F - 12	AT4 ()	1 CN-12
	F-6	BT4 P		1 CN-6
	F-7	DA4	1	1 CN-7
	F - 13	SG4 P		1 CN-13
	F-1	SVON4*		1 CN-1
	F-5	TGON4*		1 CN-5
	F - 11	0C	i	1 CN-11
	F-4	SRD4		1 CN-4
	F - 19	00	i	1 CN-19
	F-9	FU4	1	1 CN-9
	F - 17	0C	1	1 CN-17
	F-3	OL4*	1	1 CN-3
	F - 16	0C	1	1 CN-16
	F – 10	AL4*		1 CN-10
	F - 18	0C	1	1 CN-18
	F - 20	EP4	,	
				CPCR-MR[]K


7.2 Connection for YASNAC MX1/MX2 (Cont'd)


Fig 10 Detail of Wiring (Cont'd)

8. CHARACTERISTICS OF SERVOPACK AND SERVOMOTOR COMBINATION

8.1 Characteristics Description

When Servopack is combined with DC Servomotor (Cup-Motor or Hi-Cup Motor), a torque-speed characteristics can be obtained by the following formula.





- Ra Armature resistance (Ω) at 20°C
- Rk: DC reactor resistance (Ω)
- Vr: Ripple voltage(V)
- 6 Transistor voltage drop (V)

Table 7 Relation between Servopack and DC Reactor

Servopack Type CPCR-	DC Reactor Resistance (Ω)	DC Reactor Specification Numbers
MR05[]K	02	DE 8402698
MR08[]]K	02	DE 8402698
MR15	02	DE 8402698
MR22[]K	0 15	DE 8403030
MR37:::K	010	DE 8402699

Note For Servomotor characteristics list, refer to the following lists

Cup Motor A series C74980107

HI-Cup Motor G series C74980109


8.2 Torque-Speed Characteristics

In combination of Servomotor (Cup Motor A series, Hi-Cup Motor G series) with Servopack (Type CPCR-MR []K), torque-speed characteristics are shown below.


Cup Motor A Series

• Cup-Motor Type: UGCMED-04 AA


Servopack Type: CPCR-MR 052 K



 Cup Motor Type · UGCMED-08 AA Servopack Type: CPCR-MR 082 K



• Cup Motor Type UGCMED-15 AA • Servopack Type CPCR-MR 152 K



Cup Motor Type: UGCMED-37 AA

• Servopack Type CPCR-MR 372 K




Fig 12 Torque-Speed Characteristics of Cup Motor A Series

- Cup Motor Type · UGCMED-22 AA
- Servopack Type CPCR-MR 222 K




Figure Description

An output torque of y-distance is expressed as a percentage.

- 100 % Output Torque = Torque Constant × Rated Current.
- Torque Constant= Instantaneous Max Torque (1 sec)
 Instantaneous Max Current (1 sec)


Dashed Bold Line Servopack max output current Vertical Line. Continuous output current T max Instantaneous max torque, 1 sec (kg·cm) N max. Instantaneous max speed, 1 sec (rpm) V_{AC} Input voltage (V) Ia Armature current (A) I(sp)max Max output current at driven side A· Continuous rating range

B Instantaneous rating range


8.2 Torque-Speed Characteristics (Cont'd)

Hi-Cup Motor G Series


- Hi-Cup Motor Type: UGHMED-03 GG
- Servopack Type: CPCR-MR 055 K




- Hi-Cup Motor Type: UGHMED-06 GG Servopack Type: CPCR-MR 085 K 1



- Hi-Cup Motor Type: UGHMED-12 GG
- Servopack Type: CPCR-MR 155 K 1



- Hi-Cup Motor Type: UGHMED-20 GG
- Servopack Type . CPCR-MR 225 K 1



• Hi-Cup Motor Type · UGHMED-30 GG • Servopack Type : CPCR-MR 375 K 2




Fig 13 Torque-Speed Characteristics of Hi-Cup Motor G Series

9. APPLICATION TECHNIC OF YASNAC

9.1 Servomotor Selection

Where selecting DC Servomotor, the functions shown below should be considered The motor is selected in accordance with customer's requirements.

- Motor speed
- Torque
- Positioning time
- Dimensions

For an example of motor selection, Table 8 is used In this case, the motor speed and the torque are important in selecting the motor.

9.1.1 Prerequisite

To select the motor, its prerequisite is shown below.

(1) Ball Screw Length and GD²/4 (Fig. 14)

The ball screw $GD^2/4$ is obtained by the following formula

$$GD^{2}/4 = M \times \left(\frac{D}{2}\right)^{2} \times \frac{1}{2}$$

= $n \left(\frac{D}{2}\right)^{2} \times \ell P \times \left(\frac{D}{2}\right)^{2} \times \frac{1}{2} \times 10^{-3} [\text{kg} \cdot \text{cm}^{3}]$
= $\frac{1}{32} \pi D^{4} \times \ell P \times 10^{-3} [\text{kg} \cdot \text{cm}^{3}]$

- D: Ball screw diameter [cm]
- ℓ Ball screw length [cm] (screw section+400mm)
- P Iron specific gravity [787 g/cm³]
- M Ball screw weight [kg]




Fig 14 Ball Screw Length and Ball Screw GD²/4


(2) Moving Member Weight and Ball Screw Shaft Inertia $GD^2/4$ (Fig. 15)


Ball screw shaft inertia $GD^2/4$ for moving member weight (work table, tool fixture, tool) depends on a ball screw pitch. The formula is as follows.


$$GD^2/4 = W \times \left(\frac{P}{2\pi}\right)^2 [kg \cdot cm^2]$$

P. Ball screw pitch [cm]

W: Moving member weight [kg]








(3) Motor Torque-Thrust Load

Fig 16 shows the relationship of motor torque and thrust load. The thrust load (F) is from the following formula.



Note: Data is under no friction and 100% efficiency.

Fig 16 Ball Screw Torque and Thrust Load

9.1 Servomotor Selection (Cont'd)

(4) Load GD²/4 – Accelerating Torque

Accelerating torque (T_L) used to accelerate to N rpm at accelerating time (ta) is calculated by the following formula. The same formula is used for decelerating torque See Figs 17 and 18




Fig 17 Speed-Time and Torque-Time

Accelerating torque $T_L = \frac{GD^2 \times N}{375 \times ta \times 10^2}$ [kg·cm]

- ta Accelerating time [sec]
- N Speed [rpm]
- GD² Total load inertia [kg cm²]

T' Friction torque

Actual accelerating torque $T = T_L + T'$




Fig 18 Total Load Inertia GD²/4 and Accelerating Torque

9.1.2 Selection Example

In this section, a Servomotor which met selection criteria shown in Table 8 is selected.

(1) Motor Speed N

Refer to Nos 6, 7, 12 and 13 in APPENDIX

(a) At quick feed (N₁) 12,000 [mm/min] = $N_1 \times \frac{4}{5} \times 10$ [mm/rev] $N_1 = \frac{12,000}{12 \times 14} = 1500$ [rpm]

$$10 \times \frac{10}{5}$$

(b) At cutting feed (N₂)

$$N_2 = \frac{2400}{10 \times \frac{4}{5}} = 300 \text{ [rpm]}$$

Motor Speed 1500 [rpm] ···· (A)

(2) Motor Torque at Cutting Operation

Refer to Nos 6, 7 and 10 in APPENDIX

(a) At feed of low speed


Friction torque T'=25 [kg·cm] \cdot (1)

(b) Cutting thrust

- Ball screw torque 160 [kg cm] (See Fig. 16.)
- Total reduction ratio $K \cdot \frac{4}{5}$

Rotor torque T=160×K =160× $\frac{4}{5}$

=128 [kg·cm] · · (2)



- Therefore, actual motor torque is as follows ①+②=25+128=153 [kg·cm]
- (c) Maximum torque at cutting operation 165 [kg·cm]=1 08 × 153 [kg·cm]

Motor Torque at Cutting Operation · 153 [kg·cm] ··· (B)

From (A) and (B), Servomotor type UGHMED-20GG can be selected as the first motor selection. See Tables 2 and 3. In this example, Cup motor and Hi-Cup motor only are considered for the selection

- (3) Motor Accelerating/Decelerating Torque at Quick Feed
- (a) How to obtain total load inertia GD²/4
- Ball screw inertia GD²/4

Refer to Fig. 14.

Ball screw inertia=30 [kg·cm²]······(3)

For calculation by the formula, see Paragraph 9.1.1(1).

• Ball screw shaft inertia GD²/4 to moving member weight

Refer to No. 4 in APPENDIX and Fig. 15.

Ball screw shaft inertia=29.5 [kg·cm²]······(4) For calculation by the formula, see Paragraph 9 1 1(2)

• Rotor inertia GD²/4 from load inertia GD²/4

See Paragraph 9.1.1(2)

Rotor inertia = $(3+4) \times K^2$

 $=(30+29.5)\times(\frac{4}{5})^2$ =381[kg·cm²]

However, No.9 in APPENDIX, that is:

Rotor inertia=68.9 [kg·cm²]·····(5)

The rotor inertia in APPENDIX contains coupling and gear inertias Therefore, 68.9 kg cm² should be used to obtain the total load inertia GD2/4

Total load inertia GD²/4

Rotor inertia of Hi-Cup motor type UGHMED-20 GG is 234 kg·cm² See Table 2 As a result of that.

Total Load Inertia GD ² /4=234+5	
=234+68.9	···· ·⑥
=302 9 [kg·cm ²]	-

(b) Accelerating/decelerating torque

Refer to Fig 18 Where accelerating/decelerating time at quick feed ta=0.2 sec, total load inertia=3029 kg·cm² and motor speed=1000 rpm, accelerating torque TL is 160 kg cm Howeve , since actual motor speed at quick feed is 1500 rpm, actual accelerating/decelerating torque is as follows.

Accelerating/decelerating torque=160×1.5

=240 [kg·cm]·····(7)

For calculation by the formula, see Paragraph 9 1.1 (4).

(c) Friction torque at quick feed

 $7' = 45 [kg \cdot cm] \cdots (8)$

Actual Accelerating/Decelerating	
Torque at Quick Feed = (7)+(8)	
=240+45	
=285 [kg · cm]	

- (4) Final Motor Selection
- at Quick Feed 1500 (rpm) Motor Speed at Cutting Feed 300 [rpm]

Motor Torque at Cutting Feed


153 [kg·cm] Motor Accelerating/Decelerating Torque 285 [kg·cm] at Quick Feed


The following Servomotor is selected in accordance with the values:

Hi-Cup Motor Type UGHMED-20GG

9.1.3 Selected Motor Check

in combination of Hi-Cup motor type UGHMED with Servopack type CPCR-MR 225 GD, torque-speed characteristics of Fig. 19 can accept the three selecting criteria described in Paragraph 9.1.2 (4). Therefore, Hi-Cup motor type UGHMED-20 GG is selected.





Furthermore, these values are within limits of the following three items shown in Table 3 Characteristics in Combination of Servopack and Servomotor.

Overspeed 1500 [rpm] = 1500 [rpm]


(Motor speed at quick feed)


- Continuous Effective 166.3 [kg·cm] > 153 [kg·cm] **Torque at Rated** (Motor torque at cutting feed) Operation
- Instantaneous $438 [kg \cdot cm] > 285 [kg \cdot cm]$ **Effective Torque** (Motor accel/decel torque at quick at Overspeed feed)


9.2 Coasting Distance After YASNAC Emergency Stop


9.2.1 Calculation of Coasting Distance

The coasting distance after YASNAC emergency stop functions during quick feed is obtained as shown below









The emergency stop is achieved by a dynamic brake. The coasting distance (S_{DB}) by the dynamic brake is obtained by the following formula.

 $S_{DB} = (V_0 \times t_D) \times (V_0 \times \tau) \text{ [mm]} \dots \text{ (2)}$

V Quick feed speed [mm/s]

- to Delay time of emergency stop reference todeceleration [sec]
- τ Decelerating constant [sec]

Fig. 21 shows relationship of S_{DB} and $GD_{L2}/4$ for DC Servomotor (Cup Motor A series, Hi-Cup Motor G series). These relationships are obtained using formulas (1) and (2), under t_D =0.04 sec.





Fig 21 Relationship of S_{DB} and GD_{L2}/4 for Cup Motor A Series



9.3 Minimum Dog Length for Returning to Home Position

For returning to home position, minimum dog length is obtained by the following formula. Refer to Fig. 23.

$$L_D \ge \frac{(V_0 - V_1)^2}{2D_c} + V_0 \times tc [mm]$$

- Vo: Quick feed speed [mm/sec]
- V1: Approach speed 1 [mm/sec]
- Dc: Quick feed accel/decel constant [mm/sec2]
- L_D: Dog length [mm]
- tc: Delay time of emergency stop reference to deceleration [sec]
- V2: Approach speed 2 [mm/sec]




Fig 23 Time Chart for Returning to Home Position


APPENDIX SELECTION LIST OF DC SERVOMOTOR FOR YASNAC

Selection List of DC Servomotor for YASNAC

	MACHINE NAME					APPVL.	CK.	SEL	٦
	MACHINE TYPE					<u></u>	<u> </u>	J SEL	1
	CNC NAME	YASNAC							
		IAGNAC							
No.		Items		x	Y	Z	,	T	
1	Moving Direction (Hor	izontal, Vertical, Rotatin	ng, Diagonal)	Horizontal				<u> </u>	
2	Max Stroke (between		(mm)	1000				†	
3	Table Support (Slip, R			Slip					
4	Moving Member Weig	ht (with Workpiece)	(kg)	1180					
5	Counterbalance		(kg)						
6		Diameter	(mm)	40				<u> </u>	
Ŭ	Ball Screw	Lead	(mm)	10					
		Length	(mm)	1506					
7	Total Reduction Ratio			4/5					
8	Friction Coefficient								
9	Rotor Inertia GD ² /4		(kg·cm²)	68 9					
		At Low Feed	(kg·cm)	25					
10	Load Torque	At Quick Feed	(kg·cm)	45					
		Cutting Thrust	(kg)	1000	1				
		At Max Cutting	(kg·cm)	165					
11	Duty	Max Cutting Duty	(% ED·min)	45%/12min		1			
	-	Positioning Frequenc	y (sec/time)	5					
12	Quick Feed		(mm/min)	12,000					
13	Max Cutting Speed		(mm/min)	2400					
14									_
15	Detector Type TFUE-					†			
		Feed per Revolution	(mm/rev)			1			
16	Motor	Туре							
		Quick Feed Speed	(rpm)	1500 🜩	Obtained in Para	graph 9 1 2	(a)		
17	Servopack Type CPCR	-				T	· · · · ·		
18	Position Loop Gain Kp		(sec ⁻¹)			<u> </u>		<u> </u>	
		Deceleration Stop	(mm)			†			
19	Decelerating Distance	Emergency Stop	(mm)			1			
		Zero Point Dog Lengt			· · · · · · · · · · · · · · · · · · ·	<u> </u>			
20	Accelerating/Decelerating Time at Remarks			Quick Feed: 0.2 [s	ec]			<u> </u>	

A Better Tomorrow for Industry through Automation Y YASKAWA Electric Mfg. Co., Ltd.

TOKYO OFFICE Ohtemach: Bldg , Chiyoda-ku, Tokyo, 100 Japan Phone (03) 284-9111, -9145 -9146 Telex YASKAWA J33530 Fax (03) 284-9034 TAIPEI OFFICE Union Commercial Bidg, 137, Nanking East Road Sec 2 Taipei Taiwan Phone (2) 531-7732, 551-7065 Fax (2) 537-3837 YASKAWA ELECTRIC AMERICA, INC SUBSIDIARY Chicago Office/YASNAC America 3160 MacArthur Blvd , Northbrook, Illinois 60062 U S A Phone (312) 291-2348 Telex (230) 270197 YSKW YSNC NBRK Fax (312) 564-3276 Los Angeles Office 14811 Myford Road, Tustin, California 92680 U S A Phone (714) 731-6841 Telex (230) 678396 YASKAWAUS TSTN Fax (714) 730-8294 New Jersey Office 769 Northfield Ave , Suite 140 West Orange NJ 07052 U S A Phone (201) 325-7397 Fax (201) 325-7398 VASKAWA ELECTRIC EUROPE GmbH SUBSIDIARY Monschauerstrasse 1, 4000 Dusseidori 11, West Germany Phone (0211) 501127 Telex (41) 8588673 YASD D Fax (0211) 507737



KELLINGER